

13 User Access and Authentication Commands

About This Chapter

- [13.1 AAA Configuration Commands](#)
- [13.2 RADIUS Configuration Commands](#)
- [13.3 HWTACACS Configuration Commands](#)
- [13.4 NAC Configuration Commands \(Unified Mode\)](#)
- [13.5 NAC Configuration Commands \(Common Mode\)](#)
- [13.6 Policy Association Configuration Commands](#)

13.1 AAA Configuration Commands

- [13.1.1 Command Support](#)
- [13.1.2 aaa](#)
- [13.1.3 aaa abnormal-offline-record](#)
- [13.1.4 aaa offline-record](#)
- [13.1.5 aaa online-fail-record](#)
- [13.1.6 aaa-authen-bypass](#)
- [13.1.7 aaa-author-bypass](#)
- [13.1.8 aaa-author-cmd-bypass](#)
- [13.1.9 aaa-author session-timeout invalid-value enable](#)
- [13.1.10 accounting interim-fail](#)
- [13.1.11 accounting realtime](#)

- 13.1.12 accounting start-fail
- 13.1.13 accounting-mode
- 13.1.14 accounting-scheme (AAA domain view)
- 13.1.15 accounting-scheme (AAA view)
- 13.1.16 admin-user privilege level
- 13.1.17 authentication ipv6-statistics enable
- 13.1.18 authentication-mode (authentication scheme view)
- 13.1.19 authentication-scheme (AAA domain view)
- 13.1.20 authentication-scheme (AAA view)
- 13.1.21 authentication-super
- 13.1.22 authentication-type radius chap access-type admin
- 13.1.23 authorization-cmd
- 13.1.24 authorization-info check-fail policy
- 13.1.25 authorization-mode
- 13.1.26 authorization-modify mode
- 13.1.27 authorization-scheme (AAA domain view)
- 13.1.28 authorization-scheme (AAA view)
- 13.1.29 cmd recording-scheme
- 13.1.30 cut access-user
- 13.1.31 display aaa
- 13.1.32 display aaa configuration
- 13.1.33 display aaa statistics offline-reason
- 13.1.34 display access-user (All views)
- 13.1.35 display accounting-scheme
- 13.1.36 display authentication ipv6-statistics status
- 13.1.37 display authentication-scheme
- 13.1.38 display authorization-scheme
- 13.1.39 display domain
- 13.1.40 display local-user
- 13.1.41 display local-user expire-time
- 13.1.42 display local-aaa-user password policy
- 13.1.43 display recording-scheme
- 13.1.44 display remote-user authen-fail

- 13.1.45 display service-scheme
- 13.1.46 dns (service scheme view)
- 13.1.47 domain (AAA view)
- 13.1.48 domain (system view)
- 13.1.49 domain-location
- 13.1.50 domain-name-delimiter
- 13.1.51 domainname-parse-direction
- 13.1.52 idle-cut (service scheme view)
- 13.1.53 local-aaa-user wrong-password
- 13.1.54 local-user
- 13.1.55 local-user change-password
- 13.1.56 local-user device-type
- 13.1.57 local-user expire-date
- 13.1.58 local-user password
- 13.1.59 local-aaa-user password policy access-user
- 13.1.60 local-aaa-user password policy administrator
- 13.1.61 local-user service-type
- 13.1.62 local-user time-range
- 13.1.63 local-user user-type netmanager
- 13.1.64 outbound recording-scheme
- 13.1.65 password alert before-expire
- 13.1.66 password alert original
- 13.1.67 password expire
- 13.1.68 password history record number
- 13.1.69 permit-domain
- 13.1.70 recording-mode hwtacacs
- 13.1.71 recording-scheme
- 13.1.72 redirect-acl
- 13.1.73 remote-aaa-user authen-fail
- 13.1.74 remote-user authen-fail unblock
- 13.1.75 reset aaa
- 13.1.76 reset aaa statistics offline-reason
- 13.1.77 reset access-user statistics

[13.1.78 reset local-user password history record](#)

[13.1.79 security-name enable](#)

[13.1.80 security-name-delimiter](#)

[13.1.81 service-scheme \(aaa domain view\)](#)

[13.1.82 service-scheme \(AAA view\)](#)

[13.1.83 state \(AAA domain view\)](#)

[13.1.84 statistic enable \(AAA domain view\)](#)

[13.1.85 system recording-scheme](#)

[13.1.86 user-group \(AAA domain view\)](#)

[13.1.87 user-password complexity-check](#)

13.1.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

13.1.2 aaa

Function

The **aaa** command displays the AAA view.

Format

aaa

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

Using the **aaa** command in the system view, you can enter the AAA view and perform the following security configurations for access users:

- Creating users

- Configuring user levels
- Creating an authentication scheme
- Creating an authorization scheme
- Creating a domain

Example

```
# Access the AAA view.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa]
```

13.1.3 aaa abnormal-offline-record

Function

The **aaa abnormal-offline-record** command enables the device to record users' abnormal logout information.

The **undo aaa abnormal-offline-record** command disables the device from recording users' abnormal logout information.

By default, the device records users' abnormal logout information.

Format

aaa abnormal-offline-record

undo aaa abnormal-offline-record

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

If users abnormally log out, run **aaa abnormal-offline-record** command to enable the record function for fault locating.

After the **undo aaa abnormal-offline-record** command is run, no abnormal logout information is recorded unless the **aaa abnormal-offline-record** command is run.

Example

```
# Enable the device to record users' abnormal logout information.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa abnormal-offline-record
```

Disable the device from recording users' abnormal logout information.

```
<HUAWEI> system-view  
[HUAWEI] undo aaa abnormal-offline-record
```

13.1.4 aaa offline-record

Function

The **aaa offline-record** command enables the device to record users' normal logout information.

The **undo aaa offline-record** command disables the device from recording users' normal logout information.

By default, the device is enabled to record user normal logout information.

Format

aaa offline-record

undo aaa offline-record

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

If users fail to get online, run **aaa offline-record** command to enable the record function for fault locating.

After the **undo aaa offline-record** command is run, no logout information is recorded unless the **aaa offline-record** command is run.

Example

Enable the device to record users' normal logout information.

```
<HUAWEI> system-view  
[HUAWEI] aaa offline-record
```

Disable the device from recording users' normal logout information.

```
<HUAWEI> system-view  
[HUAWEI] undo aaa offline-record
```

13.1.5 aaa online-fail-record

Function

The **aaa online-fail-record** command enables the device to record users' online failures.

The **undo aaa online-fail-record** command disables the device from recording users' online failures.

By default, the device records users' online failures.

Format

aaa online-fail-record

undo aaa online-fail-record

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

If you want to query the login failure records to find out unauthorized users, run the **aaa online-fail-record** command to enable the device to record users' online failures.

After the **undo aaa online-fail-record** command is run, no online failure is recorded unless the **aaa online-fail-record** command is run.

Example

Enable the device to record users' online failures.

```
<HUAWEI> system-view  
[HUAWEI] aaa online-fail-record
```

Disable the device from recording users' online failures.

```
<HUAWEI> system-view  
[HUAWEI] undo aaa online-fail-record
```

13.1.6 aaa-authen-bypass

Function

The **aaa-authen-bypass** command sets the bypass authentication timeout interval.

The **undo aaa-authen-bypass** command cancels the bypass authentication timeout interval.

By default, no bypass authentication timeout interval is set.

Format

aaa-authen-bypass enable time *time-value*

undo aaa-authen-bypass enable

Parameters

Parameter	Description	Value
enable	Enables remote bypass authentication.	-
time <i>time-value</i>	Specifies the bypass authentication timeout interval.	The value is an integer that ranges from 1 to 1440, in minutes.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

This command applies to the scenarios that require fast authentication response. When a user in a user domain where multiple authentication modes (for example, RADIUS authentication and local authentication) are configured, bypass authentication is enabled, and the bypass authentication timeout interval is configured, the user will be authenticated using the local authentication mode and the bypass authentication timer is enabled simultaneously if the RADIUS server does not respond to the authentication request. When other users in the same domain are authenticated during the configured bypass authentication timeout interval, the users are directly authenticated using the local authentication mode, so that the users can be authenticated without waiting until the RADIUS server responds to their authentication requests, accelerating the authentication response.

Precautions

When only one authentication mode is configured in a user domain and the bypass authentication timer is enabled, other users in the same domain are directly considered to fail the authentication during the bypass authentication timeout interval.

Example

Set the bypass authentication timeout interval to 3 minutes.

```
<HUAWEI> system-view  
[HUAWEI] aaa-authen-bypass enable time 3
```

Related Topics

[13.1.7 aaa-author-bypass](#)

[13.1.8 aaa-author-cmd-bypass](#)

13.1.7 aaa-author-bypass

Function

The **aaa-author-bypass** command sets the bypass authorization timeout interval.

The **undo aaa-author-bypass** command cancels the bypass authorization timeout interval.

By default, no bypass authorization timeout interval is set.

Format

aaa-author-bypass enable time *time-value*

undo aaa-author-bypass enable

Parameters

Parameter	Description	Value
enable	Enables remote bypass authorization.	-
time <i>time-value</i>	Specifies the bypass authorization timeout interval.	The value is an integer that ranges from 1 to 1440, in minutes.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

This command applies to the scenarios that require fast authorization response. When a user in a user domain where multiple authorization modes (for example, HWTACACS authorization and local authorization) are configured, bypass authorization is enabled, and the bypass authorization timeout interval is configured, the user will be authorized using the local authorization mode and the bypass authorization timer is enabled simultaneously if the HWTACACS server does not respond to the authorization request. When other users in the same domain are authorized during the configured bypass authorization timeout interval, the users are directly authorized using the local authorization mode, so that the users can be authorized without waiting until the HWTACACS server responds to their authorization requests, accelerating the authorization response.

Precautions

When only one authorization mode is configured in a user domain and the bypass authorization timer is enabled, other users in the same domain are directly considered to fail the authorization during the bypass authorization timeout interval.

Example

```
# Set the bypass authorization timeout interval to 3 minutes.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa-author-bypass enable time 3
```

Related Topics

[13.1.6 aaa-authen-bypass](#)

[13.1.8 aaa-author-cmd-bypass](#)

13.1.8 aaa-author-cmd-bypass

Function

The **aaa-author-cmd-bypass** command sets the command-line bypass authorization timeout interval.

The **undo aaa-author-cmd-bypass** command cancels the command-line bypass authorization timeout interval.

By default, no command-line bypass authorization timeout interval is set.

Format

```
aaa-author-cmd-bypass enable time time-value
```

```
undo aaa-author-cmd-bypass enable
```

Parameters

Parameter	Description	Value
enable	Enables remote command-line bypass authorization.	-
time <i>time-value</i>	Specifies the command-line bypass authorization timeout interval.	The value is an integer that ranges from 1 to 1440, in minutes.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

This command applies to the scenarios that require fast command-line authorization response. When a user in a user domain where multiple command-line authorization modes (for example, HWTACACS authorization and local authorization) are configured, command-line bypass authorization is enabled, and the command-line bypass authorization timeout interval is configured, the user will be authorized using the local authorization mode and the command-line bypass authorization timer is enabled simultaneously if the HWTACACS server does not respond to the command-line authorization request. When other users in the same domain are authorized during the configured command-line bypass authorization timeout interval, the users are directly authorized using the local authorization mode, so that the users can be authorized without waiting until the HWTACACS server responds to their authorization requests, accelerating the authorization response.

Precautions

When only one command-line authorization mode is configured in a user domain and the command-line bypass authorization timer is enabled, other users in the same domain are directly considered to fail the command-line authorization during the command-line bypass authorization timeout interval.

Example

Set the command-line bypass authorization timeout interval to 3 minutes.

```
<HUAWEI> system-view  
[HUAWEI] aaa-author-cmd-bypass enable time 3
```

Related Topics

[13.1.6 aaa-authen-bypass](#)

[13.1.7 aaa-author-bypass](#)

13.1.9 aaa-author session-timeout invalid-value enable

Function

The **aaa-author session-timeout invalid-value enable** command prevents a device from disconnecting or reauthenticating users when the RADIUS server delivers session-timeout with value 0.

The **undo aaa-author session-timeout invalid-value enable** command restores the default setting.

By default, when the RADIUS server delivers session-timeout with value 0, this attribute does not take effect.

Format

aaa-author session-timeout invalid-value enable

undo aaa-author session-timeout invalid-value enable

Parameters

None

Views

AAA view

Default Level

3: Management level

Usage Guidelines

When the RADIUS server delivers session-timeout with value 0:

- If the **aaa-author session-timeout invalid-value enable** command is not configured, the session-timeout attribute delivered by the server does not take effect and the period for disconnecting or reauthenticating users depends on the device configuration.
- If the **aaa-author session-timeout invalid-value enable** command is configured, the session-timeout attribute delivered by the server takes effect and the device does not disconnect or reauthenticate users.

You can run the **dot1x timer reauthenticate-period** *reauthenticate-period-value* or **mac-authen timer reauthenticate-period** *reauthenticate-period-value* command to configure the period for disconnecting or reauthenticating users on the device.

Example

Prevent the device from disconnecting or reauthenticating users when the RADIUS server delivers session-timeout with value 0.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] aaa-author session-timeout invalid-value enable
```

13.1.10 accounting interim-fail

Function

The **accounting interim-fail** command sets the maximum number of real-time accounting failures and configures a policy used after the number of real-time accounting failures exceeds the maximum.

The **undo accounting interim-fail** command restores the default maximum number of real-time accounting failures and the default policy.

By default, the maximum number of real-time accounting failures is 3 and the device keeps users online after the number of real-time accounting failures exceeds the maximum.

Format

```
accounting interim-fail [ max-times times ] { offline | online }
undo accounting interim-fail
```

Parameters

Parameter	Description	Value
max-times <i>times</i>	Specifies the maximum number of real-time accounting failures. If the maximum number of real-time accounting failures is reached and the next accounting request still has no response, the device considers that accounting fails and takes a policy for users.	The value is an integer that ranges from 1 to 255. The default value is 3.
offline	Disconnects users if real-time accounting fails.	-
online	Keeps users online if real-time accounting fails.	-

Views

Accounting scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After the real-time accounting function takes effect, the device sends real-time accounting requests to an accounting server, and the accounting server responds to the accounting requests. If the network is unstable, for example, a jitter occurs, the device may not receive response packets. As a result, accounting is interrupted for a short period of time. To reduce or prevent accounting interruption, run the **accounting interim-fail** command to set the maximum number of real-time accounting failures. The device considers that real-time accounting fails only after the number of consecutive real-time accounting failures exceeds the maximum.

Choose one of the following policies to be applied after the maximum number of real-time accounting failures is reached:

- **online**: To prevent users from being affected by network faults, use the **online** policy to allow paid users to go online.
- **offline**: To stop providing services when accounting fails, use the **offline** policy to force paid users to go offline.

Prerequisites

The real-time accounting function has been enabled by using the **accounting realtime** command.

Precautions

The **accounting interim-fail** command does not take effect for online users, but takes effect for the users who go online after the command is executed.

Example

In the accounting scheme **scheme1**, set the maximum number of real-time accounting failures to 5 and use the **offline** policy.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] accounting-scheme scheme1
[HUAWEI-aaa-accounting-scheme1] accounting realtime 3
[HUAWEI-aaa-accounting-scheme1] accounting interim-fail max-times 5 offline
```

Related Topics

[13.1.11 accounting realtime](#)

13.1.11 accounting realtime

Function

The **accounting realtime** command enables the real-time accounting function and sets the interval for real-time accounting in an accounting scheme.

The **undo accounting realtime** command disables the real-time accounting function.

By default, the device performs accounting based on user online duration, the real-time accounting function is disabled.

Format

accounting realtime *interval*

undo accounting realtime

Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the interval for real-time accounting.	The value is an integer that ranges from 0 to 65535, in minutes. When the value is set to 0, real-time accounting is disabled. The default value is 0.

Views

Accounting scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

This command applies to the users who are charged based on online duration. If a user goes offline unexpectedly, the accounting server cannot receive the accounting-stop packet, so it keeps charging the user while they are not receiving a service. To solve the problem, configure the real-time accounting function on the device. After the real-time accounting function is configured, the device periodically sends real-time accounting packets to the accounting server. After receiving the real-time accounting packets, the accounting server charges the user. If the device detects that the user goes offline, it stops sending real-time accounting packets and the accounting server stops accounting. The result of real-time accounting is precise.

Precautions

- When the accounting interval is set using both the **accounting realtime** command and the Acct-Interim-Interval attribute, if the Acct-Interim-Interval value range is 60-3932100, the interval set by Acct-Interim-Interval has a higher priority. Otherwise, the interval set by the **accounting realtime** command takes effect.
- If an accounting scheme is applied to a domain, the **accounting realtime** command does not affect online users, but only takes effect for the users who go online after the command is executed.
- If *interval* is set to 0 and the IP address of the client is changed, the device still sends a real-time accounting packet carrying the changed IP address information to the RADIUS server.
- A short interval for real-time accounting requires high performance of the device and accounting server. If there are more than 1000 users, setting a long interval for real-time accounting is recommended. The following table lists the suggested real-time accounting intervals for different user quantities.

Table 13-1 Real-time accounting interval for different user quantities

User Quantity	Interval for Real-Time Accounting (Minutes)
1-99	3
100-499	6
500-999	12
≥ 1000	≥ 15

Example

In the accounting scheme **scheme1**, enable the real-time accounting function and set the interval for real-time accounting to 6 minutes.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] accounting-scheme scheme1
[HUAWEI-aaa-accounting-scheme1] accounting realtime 6
```

Related Topics

[13.1.10 accounting interim-fail](#)

13.1.12 accounting start-fail

Function

The **accounting start-fail** command configures a policy for accounting-start failures.

The **undo accounting start-fail** command restores the default policy for accounting-start failures.

By default, users cannot go online if accounting-start fails. That is, the **offline** policy is used.

Format

accounting start-fail { offline | online }

undo accounting start-fail

Parameters

Parameter	Description	Value
offline	Rejects users' online requests if accounting-start fails.	-
online	Allows users to go online if accounting-start fails.	-

Views

Accounting scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

If a user goes online after an accounting scheme is applied, the device sends an accounting-start packet to an accounting server. When the network is working properly, the accounting server responds to the accounting-start packet. If a fault occurs on the network, the device may not receive the response packet from the accounting server. As a result, accounting fails. The device provides the following policies for accounting failures:

- **online**: To prevent users from being affected by network faults, use the **online** policy to allow paid users to go online.
- **offline**: To stop providing services when accounting fails, use the **offline** policy to force paid users to go offline.

Precautions

The command takes effect only when the accounting mode configured using the [13.1.13 accounting-mode](#) command is HWTACACS or RADIUS.

Example

In the accounting scheme **scheme1**, use the **online** policy for accounting-start failures.

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] accounting-scheme scheme1  
[HUAWEI-aaa-accounting-scheme1] accounting start-fail online
```

13.1.13 accounting-mode

Function

The **accounting-mode** command configures an accounting mode in an accounting scheme.

The **undo accounting-mode** command restores the default accounting mode in an accounting scheme.

By default, the accounting mode is **none**.

Format

accounting-mode { **hwtacacs** | **none** | **radius** }

undo accounting-mode

Parameters

Parameter	Description	Value
hwtacacs	Indicates that accounting is performed by an HWTACACS server.	-
none	Indicates non-accounting.	-
radius	Indicates that accounting is performed by a RADIUS server.	-

Views

Accounting scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

Enterprises or carriers need to generate revenue by charging users who are accessing the Internet.

When a user goes online, accounting starts after the user is authenticated and authorized. When the user goes offline, accounting stops. The client sends the account packet containing the user's online duration to the accounting server.

To charge users, set the accounting mode to RADIUS or HWTACACS. Generally, the accounting mode is consistent with the authentication mode. If you do not need to charge users, set the accounting mode to none.

Precautions

The device does not support local accounting. When the authentication scheme configured using the [13.1.18 authentication-mode \(authentication scheme view\)](#) command defines local authentication, you need to run the **accounting-mode none** command to configure non-accounting or run the [13.1.12 accounting start-fail](#) command to configure a policy for accounting-start failures.

Follow-up Procedure

Apply the accounting scheme to a domain to enable the device to charge the users in the domain using the [13.1.47 domain \(AAA view\)](#) command.

Example

Set the accounting mode to RADIUS in the accounting scheme **scheme1**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] accounting-scheme scheme1
[HUAWEI-aaa-accounting-scheme1] accounting-mode radius
```

13.1.14 accounting-scheme (AAA domain view)

Function

The **accounting-scheme** command applies an accounting scheme to a domain.

The **undo accounting-scheme** command restores the default accounting scheme of a domain.

By default, the accounting scheme named **default** is applied to a domain. In this default accounting scheme, non-accounting is used and the real-time accounting function is disabled.

Format

accounting-scheme *accounting-scheme-name*

undo accounting-scheme

Parameters

Parameter	Description	Value
<i>accounting-scheme-name</i>	Specifies the name of an accounting scheme.	The accounting scheme must already exist.

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To charge users in a domain, create an accounting scheme and perform configurations in the accounting scheme, for example, set the accounting mode and policy for accounting-start failures. Run the **accounting-scheme** command in the AAA domain view to apply the accounting scheme to the domain.

Prerequisites

An accounting scheme has been created and configured using the [13.1.15 accounting-scheme \(AAA view\)](#) command. For example, the accounting mode and policy for accounting-start failures have been configured.

Example

Apply the accounting scheme **account1** to the domain **isp1**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] accounting-scheme account1
[HUAWEI-aaa-accounting-account1] quit
[HUAWEI-aaa] domain isp1
[HUAWEI-aaa-domain-isp1] accounting-scheme account1
```

Restore the default accounting scheme of the domain **isp2**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain isp2
[HUAWEI-aaa-domain-isp2] undo accounting-scheme
```

Related Topics

[13.1.15 accounting-scheme \(AAA view\)](#)

[13.1.35 display accounting-scheme](#)

13.1.15 accounting-scheme (AAA view)

Function

The **accounting-scheme** command creates an accounting scheme and displays the accounting scheme view.

The **undo accounting-scheme** command deletes an accounting scheme.

By default, there is an accounting scheme named **default** in the system. This default accounting scheme can be modified but cannot be deleted. In this default accounting scheme, non-accounting is used and the real-time accounting function is disabled.

Format

accounting-scheme *accounting-scheme-name*

undo accounting-scheme *accounting-scheme-name*

Parameters

Parameter	Description	Value
<i>accounting-scheme-name</i>	Specifies the name of an accounting scheme.	The value is a string of 1 to 32 case-sensitive characters. It cannot contain spaces or the following symbols: / \ : * ? " < > @ ' %. The value cannot be - or --.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To charge users in a domain, create and configure an accounting scheme, for example, the accounting mode and policy for accounting-start failures. Run the **accounting-scheme** command in the AAA domain view to apply the accounting scheme to the domain.

Follow-up Procedure

After an accounting scheme is created:

- Run the **accounting interim-fail** command to set the maximum number of real-time accounting failures and configure a policy used after a real-time accounting failure.
- Run the **accounting realtime** command to enable the real-time accounting function and set the interval for real-time accounting in an accounting scheme.
- Run the **accounting start-fail** command to configure a policy for accounting-start failures.
- Run the **accounting-mode** command to configure an accounting mode in an accounting scheme.

After an accounting scheme is configured, run the **13.1.14 accounting-scheme (AAA domain view)** command in the AAA domain view to apply the accounting scheme to a domain.

Precautions

If the configured accounting scheme does not exist, the **accounting-scheme** command in the AAA view creates an accounting scheme and displays the accounting scheme view. If the configured accounting scheme already exists, the **accounting-scheme** command in the AAA view displays the accounting scheme view directly.

To delete an accounting scheme applied to a domain, run the **undo accounting-scheme (AAA domain view)** command.

Example

Create an accounting scheme named **scheme1**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] accounting-scheme scheme1
[HUAWEI-aaa-accounting-scheme1]
```

Enter the default accounting scheme view.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] accounting-scheme default
[HUAWEI-aaa-accounting-default]
```

Related Topics

[13.1.14 accounting-scheme \(AAA domain view\)](#)

13.1.16 admin-user privilege level

Function

The **admin-user privilege level** command configures a user as an administrator to log in to the device and sets the user level.

The **undo admin-user privilege level** command cancels the default user level.

By default, the user level is not configured.

Format

admin-user privilege level *level*

undo admin-user privilege level

Parameters

Parameter	Description	Value
<i>level</i>	Specifies the level of a user. A larger value indicates a higher user level. After logging in to the device, a user can run only the commands of the same level or lower levels.	The value is an integer that ranges from 0 to 15.

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The device provides hierarchical management of commands. A command has a level, and a user can run only the commands of the same level or lower levels. By using the **admin-user privilege level** command to set the user level, the device controls commands used by users.

By default, commands are classified into the following levels:

- Level 0 (visit level): Commands at level 0 include diagnosis commands such as ping and tracert commands and commands that are used to access a remote device such as the Telnet client. Commands at level 0 cannot be used to save configuration files.
- Level 1 (monitoring level): Commands at level 1 are used for system maintenance, including display commands. Commands at level 1 cannot be used to save configuration files.
- Level 2 (configuration level): Commands at level 2 are used for service configuration, including routing commands and commands at each network layer to provide network services for users.
- Level 3 (management level): Commands at level 3 are used for basic operations of the system to support services, including file system, FTP, Trivial File Transfer Protocol (TFTP), configuration file switching commands, slave board control commands, user management commands, command level configuration commands, and debugging commands.

To manage users refinedly, upgrade command levels to levels 0 to 15. You can run the **command-privilege level** command to upgrade command levels in a batch. You can also run the **command-privilege level rearrange** command to upgrade levels.

- If non-authentication is used, the administrator level is specified using the **user privilege** command in the VTY interface view.
- If local authentication is used, the administrator level is specified using the **local-user privilege level** command.
- If remote authentication is used, the administrator level can be set in the following ways, in descending order of priority:
 - a. Using the user level sent by an authentication server to the device after authentication has succeeded
 - b. Running the **admin-user privilege level** command to set the administrator level in a service scheme
 - c. Running the **user privilege** command to set the user level in the VTY interface view
- If remote authentication and local authentication are configured, remote authentication is first used. If remote authentication fails, local authentication is used. The administrator level can be set in the following ways, in descending order of priority:
 - a. Using the user level sent by an authentication server to the device after authentication has succeeded
 - b. Running the **local-user privilege level** command to set the local user level

 **NOTE**

The local user level is used only when the remote authentication server is faulty. If the remote authentication server responds to authentication requests but does not deliver user levels, the configured local user level does not take effect.

The device can update the configuration in a domain dynamically. After a service scheme is applied to a domain, you can directly modify the user level in the service scheme but cannot unbind the service scheme from the domain. To delete the service scheme, run the **undo service-scheme (AAA domain view)** command.

Follow-up Procedure

Run the **display service-scheme** command to view the user level in a service scheme.

Example

Configure a user as an administrator to log in to the device and set the administrator level to 15.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme svcscheme1
[HUAWEI-aaa-service-svcscheme1] admin-user privilege level 15
```

Related Topics

- [13.1.45 display service-scheme](#)
- [13.1.54 local-user](#)
- [13.1.82 service-scheme \(AAA view\)](#)
- [2.5.27 user privilege](#)

13.1.17 authentication ipv6-statistics enable

Function

The **authentication ipv6-statistics enable** command enables IPv6 traffic statistics collection.

The **undo authentication ipv6-statistics enable** command disables IPv6 traffic statistics collection.

By default, IPv6 traffic statistics collection is disabled.

NOTE

This function is only supported by the S5720HI.

You can configure this command on the S5720EI, S6720EI, and S6720S-EI, but the function does not take effect.

Format

authentication ipv6-statistics enable

undo authentication ipv6-statistics enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the **statistic enable (AAA domain view)** command is run to collect user traffic statistics, the switch does not collect statistics on IPv6 traffic by default. To enable IPv6 traffic statistics collection, run the **authentication ipv6-statistics enable** command.

Precautions

- The switch does not support IPv6 traffic statistics collection for Layer 2 Portal authentication users and user terminals with one MAC address and multiple IP addresses.
- The switch does not support IPv6 traffic statistics collection for Layer 3 Portal authentication users.

Example

```
# Enable IPv6 traffic statistics collection.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication ipv6-statistics enable
```

13.1.18 authentication-mode (authentication scheme view)

Function

The **authentication-mode** command configures an authentication mode for an authentication scheme.

The **undo authentication-mode** command restores the default authentication mode in an authentication scheme.

By default, local authentication is used.

Format

```
authentication-mode { hwtacacs | local | radius } * [ none ]
```

```
authentication-mode none
```

```
undo authentication-mode
```

Parameters

Parameter	Description	Value
hwtacacs	Authenticates users using an HWTACACS server. To perform HWTACACS authentication, configure an HWTACACS authentication server in an HWTACACS server template.	-
local	Authenticates users locally.	-
radius	Authenticates users using a RADIUS server. To perform RADIUS authentication, configure a RADIUS authentication server in a RADIUS server template.	-
none	Indicates non-authentication. That is, users access the network without being authenticated.	-

Views

Authentication scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To authenticate users, configure an authentication mode in an authentication scheme.

If multiple authentication modes are configured in an authentication scheme, the authentication modes are used according to the sequence in which they were configured.

- In the sequence of local authentication followed by remote authentication:
If a login account is not created locally but exists on the remote server, the authentication mode is changed from local authentication to remote authentication.
If a login account is created locally and on the remote server, and local authentication fails because the password is incorrect, remote authentication will not be performed.
- In the sequence of remote authentication followed by local authentication:
If a login account is created locally but not on the remote server, remote authentication fails and local authentication will not be performed.
A user is authenticated using the local authentication mode only when the remote server is Down or does not respond to the user's authentication request.

 **NOTE**

Normally, if the remote server is Down or does not respond, local authentication is used. If a large number of users need to go online through the device, the device may be unable to process responses from the server in a timely manner. As a result, the AAA module of the device cannot receive responses from the server until the protection timer expires. These users then cannot go online and cannot be authenticated using local authentication. In this case, reconnect these offline users to the device.

You can configure multiple authentication modes in an authentication scheme to reduce authentication failure possibilities.

- After the **authentication-mode radius local** command is used, the device cannot complete RADIUS authentication if it fails to connect to the RADIUS authentication server. In this case, the device starts local authentication.
- After the **authentication-mode local radius** command is used, if the entered user name exists on the device but the entered password is incorrect, the user fails the authentication; if the entered user name does not exist on the device, the user is redirected to the RADIUS authentication mode and is authenticated based on user information on the RADIUS server.

 **NOTE**

- When both RADIUS authentication and non-authentication are configured, if the user fails the RADIUS authentication, non-authentication cannot be used. As a result, a user fails to log in.
- If you run the **authentication-mode** command to configure non-authentication and run the **authentication-mode (user interface view)** command to configure AAA authentication, the device does not allow administrators to log in from the user interface view.

Precautions

If non-authentication is configured using the **authentication-mode** command, users can pass the authentication using any user name or password. Therefore, to

protect the device and improve network security, you are advised to enable authentication, allowing only authenticated users to access the device or network.

Example

Configure the authentication scheme named **scheme1** to use RADIUS authentication.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] authentication-scheme scheme1
[HUAWEI-aaa-authen-scheme1] authentication-mode radius
```

13.1.19 authentication-scheme (AAA domain view)

Function

The **authentication-scheme** command applies an authentication scheme to a domain.

The **undo authentication-scheme** command restores the default configuration of the authentication scheme in a domain.

By default, the authentication scheme named **radius** is applied to the **default** domain, the authentication scheme named **default** is applied to the **default_admin** domain, and the authentication scheme named **radius** is applied to other domains.

Format

authentication-scheme *scheme-name*

undo authentication-scheme

Parameters

Parameter	Description	Value
<i>scheme-name</i>	Specifies the name of an authentication scheme.	The value must be an existing authentication scheme name.

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To authenticate users in a domain, run the **authentication-scheme (AAA domain view)** command to apply an authentication scheme to a domain.

Prerequisites

An authentication scheme has been created and configured with required parameters, for example, the authentication mode and authentication mode for upgrading user levels.

Example

Apply the authentication scheme named **scheme1** to a domain named **domain1**.

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] domain domain1  
[HUAWEI-aaa-domain-domain1] authentication-scheme scheme1
```

Related Topics

[13.1.20 authentication-scheme \(AAA view\)](#)

[13.1.37 display authentication-scheme](#)

13.1.20 authentication-scheme (AAA view)

Function

The **authentication-scheme** command creates an authentication scheme and displays its view.

The **undo authentication-scheme** command deletes an authentication scheme.

By default, the default authentication scheme is used. This default authentication scheme can be modified but cannot be deleted. In the default authentication scheme:

- Local authentication is used.
- The **offline** policy is used for authentication failures.

By default, the system also provides the authentication scheme **radius**. The **radius** authentication scheme can be modified, but cannot be deleted. In the **radius** authentication scheme:

- RADIUS authentication is used.
- The **offline** policy is used for authentication failures.

Format

authentication-scheme *scheme-name*

undo authentication-scheme *scheme-name*

Parameters

Parameter	Description	Value
<i>scheme-name</i>	Specifies the name of an authentication scheme.	The value is a string of 1 to 32 case-sensitive characters. It cannot contain spaces or the following symbols: / \ : * ? " < > @ ' %. The value cannot be - or --.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To authenticate users, run the **authentication-scheme** command to create an authentication scheme. Creating an authentication scheme is necessary before performing authentication-relevant configurations.

Follow-up Procedure

After an authentication scheme is created, run the **authentication-mode (authentication scheme view)** command to configure an authentication mode in an authentication scheme.

After an authentication scheme is configured, run the **authentication-scheme (AAA domain view)** command to apply the authentication scheme to a domain.

Precautions

If the configured authentication scheme does not exist, the **authentication-scheme** command creates an authentication scheme and displays the authentication scheme view. If the configured authentication scheme already exists, the **authentication-scheme** command directly displays the authentication scheme view.

To delete an authentication scheme applied to a domain, run the **undo authentication-scheme (AAA domain view)** command.

Example

Create an authentication scheme named **newscheme**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] authentication-scheme newscheme
[HUAWEI-aaa-authen-newscheme]
```

Access the default authentication scheme view.

```
<HUAWEI> system-view
[HUAWEI] aaa
```

```
[HUAWEI-aaa] authentication-scheme default  
[HUAWEI-aaa-authen-default]
```

Related Topics

[13.1.19 authentication-scheme \(AAA domain view\)](#)

[13.1.37 display authentication-scheme](#)

13.1.21 authentication-super

Function

The **authentication-super** command configures an authentication mode for upgrading user levels in an authentication scheme.

The **undo authentication-super** command restores the default authentication mode for upgrading user levels in an authentication scheme.

By default, the **super** mode is used. That is, local authentication is used.

Format

```
authentication-super { hwtaacs | radius | super } * [ none ]
```

```
authentication-super none
```

```
undo authentication-super
```

Parameters

Parameter	Description	Value
hwtaacs	Uses HWTACACS authentication to upgrade user levels.	-
radius	Uses RADIUS authentication to upgrade user levels.	-
super	Uses local authentication to upgrade user levels.	-
none	Indicates that user levels can be upgraded without authentication.	-

Views

Authentication scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

If users in a domain need to upgrade their levels, the device requests the users to enter the password to authenticate the users. If AAA authentication has been configured using the [authentication-mode \(user interface view\)](#) command, run the **authentication-super** command to configure an authentication mode for upgrading user levels.

When you use the **super** command to switch a user level to a lower level or the same level, no authentication is required. When you use the **super** command to switch a user level to a higher level, authentication is required. The user can be granted rights only after being authenticated.

- If **super** is used and the local authentication is specified, run the [local-user](#) command in the AAA view to create a local user and set parameters for the local user.
- If **hwtacacs** is used and the HWTACACS authentication is specified, perform configurations relevant to HWTACACS authentication.
- If **radius** is used and the RADIUS authentication is specified, perform configurations relevant to RADIUS authentication.
- If **none** is used, no authentication is required.

Precautions

If multiple authentication modes are configured in an authentication scheme, these authentication modes are used in the sequence in which they were configured. The device uses another authentication mode only when it does not receive any response in the current authentication. The device does not switch to another authentication mode if the user fails to pass one authentication mode.

Example

Set the authentication mode to HWTACACS authentication in the authentication scheme **scheme1**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] authentication-scheme scheme1
[HUAWEI-aaa-authen-scheme1] authentication-super hwtacacs
```

Related Topics

[2.5.3 authentication-mode \(user interface view\)](#)

[13.1.19 authentication-scheme \(AAA domain view\)](#)

[13.1.20 authentication-scheme \(AAA view\)](#)

[13.1.37 display authentication-scheme](#)

13.1.22 authentication-type radius chap access-type admin

Function

The **authentication-type radius chap access-type admin** command replaces PAP authentication with CHAP authentication when RADIUS authentication is performed on administrators.

The **undo authentication-type radius chap access-type admin** command restores PAP authentication when RADIUS authentication is performed on administrators.

By default, PAP authentication is used when RADIUS authentication is performed on administrators.

Format

authentication-type radius chap access-type admin [ftp | ssh | telnet | terminal | http] *

undo authentication-type radius chap access-type admin

Parameters

Parameter	Description	Value
ftp	Replaces PAP authentication with CHAP authentication when RADIUS authentication is performed on administrators who access the device using FTP.	-
ssh	Replaces PAP authentication with CHAP authentication when RADIUS authentication is performed on administrators who access the device using SSH.	-

Parameter	Description	Value
telnet	Replaces PAP authentication with CHAP authentication when RADIUS authentication is performed on administrators who access the device using Telnet.	-
terminal	Replaces PAP authentication with CHAP authentication when RADIUS authentication is performed on administrators who access the device using a terminal.	-
http	Replaces PAP authentication with CHAP authentication when RADIUS authentication is performed on administrators who access the device using a web management system.	-

Views

Authentication scheme view

Default Level

3: Management level

Usage Guidelines

CHAP is ciphertext authentication protocol. During CHAP authentication, the NAS device sends the user name, encrypted password, and 16-byte random code to the RADIUS server. The RADIUS server searches for the database according to the user name and obtains the password that is the same as the encrypted password at the user side. The RADIUS server then encrypts the received 16-byte random code and compares the result with the password. If they are the same, the user is authenticated. If they are different, the user fails to be authenticated. In addition, if the user is authenticated, the RADIUS server generates a 16-byte random code to challenge the user. CHAP is more secure and reliable than PAP.

If no parameter is specified when you run the **authentication-type radius chap access-type admin** command, the configuration takes effect on the administrators who access the device using FTP, SSH, Telnet, Terminal, and HTTP.

When the device is connected to the RADIUS server that supports CHAP authentication, this function needs to be configured.

Example

Replace PAP authentication with CHAP authentication when RADIUS authentication is performed on administrators who access the device using FTP.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] authentication-scheme scheme1
[HUAWEI-aaa-authen-scheme1] authentication-type radius chap access-type admin ftp
```

Related Topics

[13.1.37 display authentication-scheme](#)

13.1.23 authorization-cmd

Function

The **authorization-cmd** command configures command-specific authorization for an administrator of a specific level. After command-specific authorization is enabled and an administrator of a specific level logs in to the device, the commands that the administrator enters can be executed only after being authorized by the HWTACACS server.

The **undo authorization-cmd** command disables command-specific authorization for an administrator of a specific level.

By default, the command-specific authorization is disabled. That is, an administrator of any level can execute only commands of or below its level after logging in to the device.

Format

authorization-cmd *privilege-level* **hwtacacs** [**local**] [**none**]

undo authorization-cmd *privilege-level*

Parameters

Parameter	Description	Value
<i>privilege-level</i>	Specified the administrator level.	The value is an integer that ranges from 0 to 15.
hwtacacs	Indicates HWTACACS authorization.	-
local	Indicates local authorization.	-

Parameter	Description	Value
none	Indicates that command line authorization is directly performed for a user if the HWTACACS server does not respond to the authorization request of the user.	-

Views

Authorization scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After being authorized, the users at a certain level can run the commands of the same or lower levels. Command line authorization can be configured to implement minimum user rights control. When command line authorization is enabled, each command entered by users can be executed only after being authorized. After command line authorization is enabled for users at a certain level, the commands run by the users at that level must be authorized by an HWTACACS server.

Precautions

You are advised to configure local authorization as a backup of command line authorization. If command line authorization cannot be performed because of a failure on an HWTACACS server, the device starts local authorization.

After the **authorization-cmd** command is executed, command line authorization does not take effect immediately. Command line authorization takes effect only when an authorization scheme containing command line authorization is applied to administrator view correctly.

NOTICE

After an authorization scheme containing command line authorization is applied to administrator view, if you run the **undo authorization-cmd** command, an online administrator at a certain level cannot run any commands except for the **quit** command. The administrator needs to log in again.

Example

Configure command line authorization administrators at level 2.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] authorization-scheme scheme1
[HUAWEI-aaa-author-scheme1] authorization-cmd 2 hwtacacs
```

13.1.24 authorization-info check-fail policy

Function

The **authorization-info check-fail policy** command determines whether the device allows users to go online after the authorization information check fails.

The **undo authorization-info check-fail policy** command restores the default configuration.

By default, the device allows users to go online after the authorization information check fails.

Format

authorization-info check-fail policy { online | offline }

undo authorization-info check-fail policy

Parameters

Parameter	Description	Value
online	Indicates that the device allows users to go online after the authorization information check fails.	-
offline	Indicates that the device prohibits users from going online after the authorization information check fails.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device supports user authorization through the ACL, UCL Group, User Group and VLAN delivered from the RADIUS server. If the ACL, UCL Group, User Group and VLAN delivered from the RADIUS server are not configured on the device, the authorization information check fails on the device.

You can use this command to configure the users to go online and the authorization information delivered by the RADIUS server does not take effect.

Example

```
# Configure the device to allow users to go online after the authorization information check fails.
```

```
<HUAWEI> system-view  
[HUAWEI] authorization-info check-fail policy online
```

13.1.25 authorization-mode

Function

The **authorization-mode** command configures an authorization mode for an authorization scheme.

The **undo authorization-mode** command restores the default authorization mode in an authorization scheme.

By default, local authorization is used.

Format

```
authorization-mode { hwtacacs | if-authenticated | local } * [ none ]
```

```
authorization-mode none
```

```
undo authorization-mode
```

Parameters

Parameter	Description	Value
hwtacacs	Indicates that the user is authorized by an HWTACACS server.	-
if-authenticated	Indicates that only the user who succeeds in authentication (authentication exemption excluded) is authorized. The configuration of if-authenticated authorization does not take effect in RADIUS authentication.	-
local	Authenticates users locally	-
none	Indicates non-authorization.	-

Views

Authorization scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To authorize users, configure an authorization mode in an authorization scheme.

You can configure multiple authorization modes in an authorization scheme to reduce the chance of authorization failures.

After the **authorization-mode hwtacacs local** command is used, if it fails to connect to the HWTACACS authentication server and HWTACACS authorization cannot be performed, the device starts local authorization.

Precautions

- If multiple authorization modes are used in an authorization scheme, the **if-authenticated** mode or **none** mode must be used as the last authorization mode.
- When the authorization mode is **if-authenticated** or **none**, the user privilege level is inherited from the user domain or is the same as that set in the VTY user view.
- If multiple authorization modes are configured in an authorization scheme, the authorization modes are used according to the sequence in which they were configured. The device uses another authorization mode only when it does not receive any response in the current authorization.

Example

Configure the authorization scheme named **scheme1** to apply HWTACACS authorization.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] authorization-scheme scheme1
[HUAWEI-aaa-author-scheme1] authorization-mode hwtacacs
```

13.1.26 authorization-modify mode

Function

The **authorization-modify mode** command configures the update mode for user authorization information delivered by the authorization server.

The **undo authorization-modify mode** command restores the default update mode for user authorization information delivered by the authorization server.

By default, the update mode of user authorization information delivered by the authorization server is **overlay**. That is, the new user authorization information overwrites all existing user authorization information.

Format

authorization-modify mode { modify | overlay }

undo authorization-modify mode

Parameters

Parameter	Description	Value
modify	Indicates the modify mode.	-
overlay	Indicates the overlay mode.	-

Views

AAA view

Default Level

3: Management level

Usage Guidelines

The authorization server can deliver all or part of user authorization information, such as the ACL rule and dynamic VLAN.

You can run the **authorization-modify mode** command to configure one of the following update modes for user authorization information delivered by the authorization server:

- **modify**: modification mode indicating that new user authorization information overwrites only existing user authorization information of the same type.
- **overlay**: overwriting mode indicating that new user authorization information overwrites all existing user authorization information.

If the authorization server has delivered ACL 3001 to a user, and the administrator needs to deliver new authorization information:

- In the **modify** mode, if the new authorization information is ACL 3002, the authorization information of the user is ACL 3002. If the new authorization information is VLAN 100, the authorization information of the user is ACL 3001 and VLAN 100.
- In the **overlay** mode, no matter whether the new authorization information is ACL 3002 or VLAN 100, the authorization information of the user is the new ACL or VLAN.

This command takes effect for only the authorization information delivered by the RADIUS server.

After a user group or service scheme is authorized to a user on the device and a certain attribute configured in the user group or service scheme is modified on the server, if other configured attributes need to be modified, the authorization information on the server must contain the previously modified attribute.

Otherwise, the original attribute value in the user group or service scheme will be restored. For example, to modify an attribute in a user group:

1. The device authorizes the user group configured with the VLAN and ACL attributes to a user.
2. To modify the VLAN attribute, authorize the new VLAN attribute to the user through the RADIUS server.
3. To modify the ACL attribute after the VLAN attribute is modified, you must authorize the modified VLAN attribute and new ACL attribute through the RADIUS server. Otherwise, the original VLAN attribute in the user group will be restored.

Example

Set the update mode of user authorization information delivered by the authorization server to **modify**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] authorization-modify mode modify
```

13.1.27 authorization-scheme (AAA domain view)

Function

The **authorization-scheme** command applies an authorization scheme to a domain.

The **undo authorization-scheme** command unbinds an authorization scheme from a domain.

By default, no authorization scheme is applied to a domain.

Format

authorization-scheme *authorization-scheme-name*

undo authorization-scheme

Parameters

Parameter	Description	Value
<i>authorization-scheme-name</i>	Specifies the name of an authorization scheme.	The authorization scheme must already exist.

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

RADIUS integrates authentication and authorization; therefore, RADIUS authorization and authentication must be used together. HWTACACS separates authentication from authorization; therefore, you can configure another authorization type even if HWTACACS authentication, local authentication, or non-authentication is used.

To authorize users in a domain, run the **authorization-scheme (AAA domain view)** command.

Prerequisites

An authorization scheme has been created and configured with required parameters, for example, the authorization mode and command line authorization.

Example

Apply the authorization scheme **author1** to the domain **isp1**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] authorization-scheme author1
[HUAWEI-aaa-author-author1] quit
[HUAWEI-aaa] domain isp1
[HUAWEI-aaa-domain-isp1] authorization-scheme author1
```

Related Topics

[13.1.28 authorization-scheme \(AAA view\)](#)

[13.1.38 display authorization-scheme](#)

13.1.28 authorization-scheme (AAA view)

Function

The **authorization-scheme** command creates an authorization scheme and enters the authorization scheme view, or directly enters an existing authorization scheme view.

The **undo authorization-scheme** command deletes an authorization scheme.

By default, the default authorization scheme is used. This default authorization scheme can be modified but cannot be deleted. In the default authorization scheme, local authentication is used and command line authorization is disabled.

Format

authorization-scheme *authorization-scheme-name*

undo authorization-scheme *authorization-scheme-name*

Parameters

Parameter	Description	Value
<i>authorization-scheme-name</i>	Specifies the name of an authorization scheme.	The value is a string of 1 to 32 case-sensitive characters. It cannot contain spaces or the following symbols: / \ : * ? " < > @ ' %. The value cannot be - or --.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

RADIUS integrates authentication and authorization; therefore, RADIUS authorization and authentication must be used together. HWTACACS separates authentication from authorization; therefore, you can configure another authorization type even if HWTACACS authentication, local authentication, or non-authentication is used. You must run the **authorization-scheme** command to create an authorization scheme before performing authorization-relevant configurations, for example, setting the authorization mode and command line authorization function.

Follow-up Procedure

After an authorization scheme is created:

- Run the **authorization-mode** command to configure an authorization mode in an authorization scheme.
- Run the **authorization-cmd** command to configure command line authorization for users at a certain level.

After an authorization scheme is configured, run the **authorization-scheme (AAA domain view)** command to apply the authorization scheme to a domain.

Precautions

- If the configured authorization scheme does not exist, the **authorization-scheme (AAA view)** command creates an authorization scheme and displays the authorization scheme view.
- If the configured authorization scheme already exists, the **authorization-scheme (AAA view)** command directly displays the authorization scheme view.

To delete the authorization scheme applied to a domain, run the **undo authorization-scheme (AAA domain view)** command.

Example

Create an authorization scheme named **scheme0**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] authorization-scheme scheme0
[HUAWEI-aaa-author-scheme0]
```

Enter the default authorization scheme view.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] authorization-scheme default
[HUAWEI-aaa-author-default]
```

Related Topics

[13.1.27 authorization-scheme \(AAA domain view\)](#)

13.1.29 cmd recording-scheme

Function

The **cmd recording-scheme** command applies a policy in a recording scheme to record the commands executed on the device.

The **undo cmd recording-scheme** command deletes a policy from a recording scheme.

By default, the commands that are used on the device are not recorded.

Format

cmd recording-scheme *recording-scheme-name*

undo cmd recording-scheme

Parameters

Parameter	Description	Value
<i>recording-scheme-name</i>	Specifies the name of a recording scheme.	The recording scheme must already exist.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

During the device configuration, incorrect operations may result in network faults. After the **cmd recording-scheme** command is executed, you can view records of the commands executed on the device to locate the network faults.

Prerequisites

A recording scheme has been created by using the **recording-scheme** command and a recording mode has been configured by using the **recording-mode hwtacacs** command.

Example

Configure a policy in the recording scheme **scheme0** to record the commands executed on the device.

```
<HUAWEI> system-view
[HUAWEI] hwtacacs-server template hw1
[HUAWEI-hwtacacs-hw1] quit
[HUAWEI] aaa
[HUAWEI-aaa] recording-scheme scheme0
[HUAWEI-aaa-recording-scheme0] recording-mode hwtacacs hw1
[HUAWEI-aaa-recording-scheme0] quit
[HUAWEI-aaa] cmd recording-scheme scheme0
```

Related Topics

[13.1.43 display recording-scheme](#)

[13.1.70 recording-mode hwtacacs](#)

[13.1.71 recording-scheme](#)

13.1.30 cut access-user

Function

The **cut access-user** command terminates one or multiple access user connections, also forcibly disconnecting online users.

Format

```
cut access-user { domain domain-name | interface interface-type interface-number [ vlan vlan-id [ qinq qinq-vlan-id ] ] | ip-address ip-address [ vpn-instance vpn-instance-name ] | mac-address mac-address | service-scheme service-scheme-name | access-slot slot-id | user-id begin-number [ end-number ] | username user-name }
```

cut access-user ssid *ssid-name* (This command is only supported by the S5720HI.)

```
cut access-user access-type { admin [ ftp | ssh | telnet | terminal | web ] | ppp } [ username user-name ]
```

 NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
domain <i>domain-name</i>	Disconnects sessions in a specified domain.	The value must be the name of an existing domain.
interface <i>interface-type interface-number</i>	Disconnects sessions on a specified interface. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-
vlan <i>vlan-id</i> [qinq <i>qinq-vlan-id</i>]	Disconnects sessions in a specified VLAN. <ul style="list-style-type: none"> <i>vlan-id</i> specifies the ID of a VLAN. In QinQ applications, this parameter specifies the inner VLAN ID. <i>qinq-vlan-id</i> specifies the outer VLAN ID. 	The values of <i>vlan-id</i> and <i>qinq-vlan-id</i> are integers that range from 1 to 4094.
ip-address <i>ip-address</i>	Disconnects sessions initiated by a specified IP address.	The value is in dotted decimal notation.
vpn-instance <i>vpn-instance-name</i>	Indicates the name of the VPN instance that the specified IP address belongs to.	The value must be an existing VPN instance name.
mac-address <i>mac-address</i>	Disconnects sessions initiated by a specified MAC address.	The value is in H-H-H format. An H contains 4 hexadecimal digits.
service-scheme <i>service-scheme-name</i>	Terminates connections based on the service scheme.	The value must be the name of an existing service scheme.

Parameter	Description	Value
access-slot <i>slot-id</i>	Disconnects sessions on a specified device. NOTE This parameter is valid for only users that go online through physical interfaces of the device, and is invalid for users that go online through Eth-Trunks.	The value range depends on the model of the device.
ssid <i>ssid-name</i>	Disconnects sessions initiated by a service set identifier (SSID) for a service set.	The SSID must already exist. NOTE SSID is supported only in the NAC unified mode.
user-id <i>begin-number</i> [<i>end-number</i>]	Disconnects sessions of a specified user.	The user-id must exist on the device.
username <i>user-name</i>	Disconnects sessions of a user with a specified user name.	The value must be the name of an existing user.
access-type	Displays information about the users using the specified authentication mode.	-
admin [ftp ssh telnet terminal web]	Displays information about the administrators using the specified authentication mode. <ul style="list-style-type: none"> • ftp: FTP user • ssh: SSH user • telnet: Telnet user • terminal: Terminal user • web: Web user 	-
ppp	Displays information about online users using PPP authentication.	-

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

Performing some configurations, such as AAA, on the device, requires that no users be online. You can run the **cut access-user** command to disconnect sessions.

Precautions

The **cut access-user** command interrupts all services of the user whose session is torn down.

If the character string of the user name contains spaces (for example, a b), you can run the **display access-user username "a b"** command to view online users.

If the character string of the user name contains spaces and quotation marks (""), simultaneously, you cannot use the user name to view online users. In this case, you can run the **display access-user | include username** command to view the user ID of the online user, and then run the **display access-user user-id user-id** command to view the user. Alternatively, you can run the **cut access-user user-id user-id** command to force the user to go offline.

Example

```
# Tear down the session initiated by the IP address 10.1.1.1.
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] cut access-user ip-address 10.1.1.1
```

Related Topics

[13.1.34 display access-user \(All views\)](#)

13.1.31 display aaa

Function

The **display aaa** command displays information about normal logout, abnormal logout, and login failures.

Format

```
display aaa { offline-record | abnormal-offline-record | online-fail-record } { all | reverse-order | domain domain-name | interface interface-type interface-number [ vlan vlan-id [ qinq qinq-vlan-id ] ] | ip-address ip-address [ vpn-instance vpn-instance-name ] | mac-address mac-address | access-slot slot-number | time start-time end-time [ date start-date end-date ] | username user-name [ time start-time end-time [ date start-date end-date ] ] } [ brief ]
```

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
offline-record	Displays normal logout records.	-
abnormal-offline-record	Displays abnormal logout records.	-
online-fail-record	Displays login failure records.	-
all	Displays all login and logout records.	-
reverse-order	Displays the records in a sequence reverse to the sequence in which they were generated. That is, the latest records are displayed first.	-
domain <i>domain-name</i>	Specifies the name of a domain.	The value is a string of 1 to 64 case-insensitive characters, excluding spaces, *, ?, and ".
interface <i>interface-type</i> <i>interface-number</i>	Specifies the type and number of an interface.	-
ip-address <i>ip-address</i>	Specifies an IP address.	The value is in dotted decimal notation.
vlan <i>vlan-id</i>	Specifies the inner VLAN ID.	The value is an integer that ranges from 1 to 4094.
qinq <i>qinq-vlan-id</i>	Specifies the outer VLAN ID.	The value is an integer that ranges from 1 to 4094.
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The value must be an existing VPN instance name.
mac-address <i>mac-address</i>	Specifies a MAC address.	The value is in H-H-H format. An H is a hexadecimal number of 4 digits.
access-slot <i>slot-number</i>	Specifies the slot ID.	The value is an integer. The value range depends on the model of the device.

Parameter	Description	Value
username <i>user-name</i>	Specifies a user.	The value must be an existing user.
time <i>start-time end-time</i>	Specifies a time range.	The format is HH:MM:SS, indicating hour:minute:second.
date <i>start-date end-date</i>	Specifies a date.	The format is YYYY/MM/DD. YYYY is the year, MM is the month, and DD is the day.
brief	Displays brief login and logout information.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

This command allows you to view information about user normal logouts, abnormal logouts, and login failures based on the domain name, interface, IP address, VPN instance, MAC address, or slot ID.

Precautions

Only letters, digits, and special characters can be displayed for **username**.

When the value of **username** contains special characters or characters in other languages except English, the device displays dots (.) for these characters. If there are more than three such consecutive characters, three dots (.) are displayed. Here, the special characters are the ASCII codes smaller than 32 (space) or larger than 126 (~).

When the value of **username** is longer than 20 characters, the device displays up to three dots (.) for the characters following 19; that is, only 22 characters are displayed.

Example

View information about user normal logouts in domain **rds**.

```
<HUAWEI> display aaa offline-record domain rds
```

```
-----
User name       : test@rds
Domain name     : rds
```

```
User MAC      : 0021-9746-b67c
User access type : 802.1x
User access interface : GigabitEthernet10/0/2
Qinq vlan/User vlan : 0/1
User IP address : 192.168.2.2
User IPV6 address : -
User ID      : 19
User login time : 2008/10/01 04:49:39
User offline time : 2008/10/01 04:59:43
User offline reason : EAPOL user request
```

Are you sure to display some information?(y/n)[y]:

Table 13-2 Description of the **display aaa offline-record domain** command output

Item	Description
User name	User name.
Domain name	Domain of a user.
User MAC	MAC address of a user.
User access type	<p>Access type of a user.</p> <ul style="list-style-type: none"> • 802.1x indicates that the user accesses the network through 802.1X. • API indicates that the user accesses the network through the API. • FTP indicates that the user accesses the network through FTP. • Telnet indicates that the user accesses the network through Telnet. • Terminal indicates that the user accesses the network through terminal. • SSH indicates that the user accesses the network through SSH. • x25-pad indicates that the user accesses the network through x25-pad. • HTTP indicates that the user accesses the network through HTTP. • Web indicates that the user accesses the network through web. <p>For the related command, see 13.1.61 local-user service-type.</p>
User access interface	Access interface of a user.

Item	Description
Qinq vlan/User vlan	VLAN that a user belongs to. <ul style="list-style-type: none">• In QinQ application, QinQvlan indicates the outer VLAN ID and Uservlan indicates the inner VLAN ID.• For a common VLAN, Uservlan indicates the VLAN ID, and QinQvlan is 0.
User IP address	IP address of a user.
User IPV6 address	IPv6 address of a user.
User ID	Index of a user.
User login time	Time when a user goes online.
User offline time	Time when a user goes offline.

Item	Description
User offline reason	<p>Reason why a user fails to go online or offline. The common reasons are as follows:</p> <ul style="list-style-type: none">• The value "EAPOL user request" indicates that an 802.1X user requests to go offline.• The value "PPP user request" indicates that a PPP user requests to go offline.• The value "Web user request" indicates that a web user requests to go offline.• The value "AAA cut command" indicates that a user is deleted using command line.• The value "Session time out" indicates that a session times out.• The value "Idle cut" indicates that a user is disconnected because the user does not perform any operation within a specified period.• The value "PPP authentication fail" indicates a PPP authentication failure.• The value "STA disassociation" indicates that an STA is disassociated.• The value "console reset or disable port" indicates that the management interface is down.• The value "Interface net down" indicates that an interface is down.• The value "No authentication server configured" indicates that no authentication server is configured.• The value "No radius-server template bound" indicates that no RADIUS server template is bound.• The value "No tacacs-server template bound" indicates that no TACACS server template is bound.• The value "No accounting server configured" indicates that no accounting server is configured.

Item	Description
	<ul style="list-style-type: none">• The value "Accounting server no response" indicates that the accounting server does not respond.• The value "Local Authentication user block" indicates that the local user is locked.• The value "Authorize vlan error" indicates that VLAN authorization fails.

13.1.32 display aaa configuration

Function

The **display aaa configuration** command displays the AAA configurations, for example, the domain, authentication scheme, authorization scheme, and accounting scheme.

Format

display aaa configuration

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

AAA configurations are limited by system specifications. Before performing AAA configurations, run the **display aaa configuration** command to check whether there are sufficient resources.

Example

Display the AAA summary.

```
<HUAWEI> display aaa configuration
```

```
Domain Name Delimiter      : @  
Domainname parse direction : Left to right
```

```

Domainname location      : After-delimiter
Administrator user default domain: default_admin
Normal user default domain : default
Domain                   : total: 32   used: 3
Authentication-scheme   : total: 17   used: 3
Accounting-scheme       : total: 16   used: 2
Authorization-scheme    : total: 16   used: 2
Service-scheme          : total: 16   used: 0
Recording-scheme        : total: 3    used: 1
Local-user               : total: 1000 used: 3
Local-user block retry-interval : 5 Min(s)
Local-user block retry-time  : 3
Local-user block time     : 5 Min(s)
Remote-user block retry-interval : 30 Min(s)
Remote-user block retry-time  : 30
Remote-user block time     : 30 Min(s)
    
```

Table 13-3 Description of the **display aaa configuration** command output

Item	Description
Domain Name Delimiter	<p>Domain name delimiter, which can be any of the following characters: \ / : < > @ ' %. The default domain name delimiter is @.</p> <p>To configure a domain name delimiter, run the 13.1.50 domain-name-delimiter command.</p>
Domain	<p>Number of domains.</p> <ul style="list-style-type: none"> total: indicates the total number of domains that can be created. used: indicates the number of domains that have been created.
Domainname parse direction	<p>Parsing direction of the domain name.</p> <ul style="list-style-type: none"> Left to right Right to left <p>To configure this parameter, run the 13.1.51 domainname-parse-direction command.</p>
Domainname location	<p>Domain name location.</p> <ul style="list-style-type: none"> After-delimiter: The domain name is placed behind the domain name delimiter. Before-delimiter: The domain name is placed before the domain name delimiter. <p>To configure this parameter, run the 13.1.49 domain-location command.</p>
Administrator user default domain	Domain name of administrator users.
Normal user default domain	Domain name of normal users.

Item	Description
Authentication-scheme	Number of authentication schemes. <ul style="list-style-type: none"> ● total: indicates the total number of authentication schemes that can be created. ● used: indicates the number of authentication schemes that have been created.
Accounting-scheme	Number of accounting schemes. <ul style="list-style-type: none"> ● total: indicates the total number of accounting schemes that can be created. ● used: indicates the number of accounting schemes that have been created.
Authorization-scheme	Number of authorization schemes. <ul style="list-style-type: none"> ● total: indicates the total number of authorization schemes that can be created. ● used: indicates the number of authorization schemes that have been created.
Service-scheme	Number of service schemes. <ul style="list-style-type: none"> ● total: indicates the total number of service schemes that can be created. ● used: indicates the number of service schemes that have been created.
Recording-scheme	Number of recording schemes. <ul style="list-style-type: none"> ● total: indicates the total number of recording schemes that can be created. ● used: indicates the number of recording schemes that have been created.
Local-user	Number of local users. <ul style="list-style-type: none"> ● total: indicates the total number of local users that can be created. ● used: indicates the number of local users that have been created.
Local-user block retry-interval	Authentication retry interval of a local account. To configure this parameter, run the 13.1.53 local-aaa-user wrong-password command.
Local-user block retry-time	Maximum number of consecutive authentication failures for a local account. To configure this parameter, run the 13.1.53 local-aaa-user wrong-password command.
Local-user block time	Locking time of a local account. To configure this parameter, run the 13.1.53 local-aaa-user wrong-password command.

Item	Description
Remote-user block retry-interval	Authentication retry interval of a remote AAA authentication user. To configure this parameter, run the 13.1.73 remote-aaa-user authen-fail command.
Remote-user block retry-time	Maximum number of consecutive authentication failures for a remote AAA authentication user. To configure this parameter, run the 13.1.73 remote-aaa-user authen-fail command.
Remote-user block time	Locking time of a remote AAA authentication user. To configure this parameter, run the 13.1.73 remote-aaa-user authen-fail command.
Session timeout invalid enable	<ul style="list-style-type: none">• Yes: The device will not disconnect or reauthenticate users when the RADIUS server delivers session-timeout with value 0.• No: The device will disconnect or reauthenticate users when the RADIUS server delivers session-timeout with value 0. To configure this parameter, run the 13.1.9 aaa-author session-timeout invalid-value enable command.

Related Topics

[13.1.2 aaa](#)

[13.1.47 domain \(AAA view\)](#)

13.1.33 display aaa statistics offline-reason

Function

The **display aaa statistics offline-reason** command displays the reasons why users go offline.

Format

display aaa statistics offline-reason

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

The **display aaa statistics offline-reason** command helps you know the reason why a user goes offline. You can locate network faults according to the command output.

Example

```
# Display reasons why users go offline.
```

```
<HUAWEI> display aaa statistics offline-reason
19 User request to offline      :2
87 AAA cut command             :1
```

Table 13-4 Description of the display aaa statistics offline-reason command output

Item	Description
19/87	Reason code.
User request to offline	A user requested to go offline.
2/1	Number of times users go offline.
AAA cut command	A user is disconnected by the 13.1.30 cut access-user command.

13.1.34 display access-user (All views)

Function

The **display access-user** command displays information about online users (including access users and administrators).

Format

```
display access-user [ domain domain-name | interface interface-type interface-number [ vlan vlan-id [ qinq qinq-vlan-id ] ] ] | ip-address ip-address [ vpn-instance vpn-instance-name ] | ipv6-address ipv6-address | access-slot slot-id ] [ detail ]
```

```
display access-user username user-name [ detail ]
```

```
display access-user ssid ssid-name (Only the S5720HI support this command.)
```

```
display access-user [ mac-address mac-address | service-scheme service-scheme-name | user-id user-id ]
```

```
display access-user statistics (Only the S5720HI support this command.)
```

display access-user access-type { **admin** [**ftp** | **ssh** | **telnet** | **terminal** | **web**] | **ppp** } [**username** *user-name*]

 **NOTE**

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
domain <i>domain-name</i>	Displays information about users in a specified domain.	The domain name must already exist.
interface <i>interface-type interface-number</i>	Displays information about users on a specified interface. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-
vlan <i>vlan-id</i> [qinq <i>qinq-vlan-id</i>]	Displays information about users in a VLAN. <ul style="list-style-type: none"> <i>vlan-id</i> specifies the ID of a VLAN. In QinQ applications, this parameter specifies the inner VLAN ID. <i>qinq-vlan-id</i> specifies the outer VLAN ID. <p>In the authorized ISP VLAN scenario, you can view the user information only when the specified VLAN ID is the ISP VLAN ID.</p>	The values of <i>vlan-id</i> and <i>qinq-vlan-id</i> are integers that range from 1 to 4094.
ip-address <i>ip-address</i>	Displays information about the user with a specified IP address. <p>NOTE When the user type is NAC or static, details about the user are displayed. When the user is in another type, brief information about the user is displayed.</p>	The value of <i>ip-address</i> is in dotted decimal notation.

Parameter	Description	Value
vpn-instance <i>vpn-instance-name</i>	Indicates the name of the VPN instance that the specified IP address belongs to.	The value must be an existing VPN instance name.
ipv6-address <i>ipv6-address</i>	Displays information about the user with a specified IPv6 address.	The value consists of 128 octets, which are classified into 8 groups. Each group contains 4 hexadecimal numbers in the format X:X:X:X:X:X.
mac-address <i>mac-address</i>	Displays information about the user with a specified MAC address.	The value is in H-H-H format. An H contains four hexadecimal digits.
service-scheme <i>service-scheme-name</i>	Displays information about the user with a specified service scheme.	The service scheme must already exist.
access-slot <i>slot-id</i>	Displays information about users connecting to a specified device.	The value range depends on the model of the device.
ssid <i>ssid-name</i>	Specifies the SSID for a service set.	The SSID must already exist. NOTE SSID is supported only in the NAC unified mode.
username <i>user-name</i>	Displays information about the user with a user name.	The user name must already exist.
statistics	Displays user statistics on the device. <ul style="list-style-type: none"> Historical user statistics: displays historical wireless user statistics on the device. Current online user statistics: displays current user statistics on the device. 	The keyword statistics is supported only in the NAC unified mode.

Parameter	Description	Value
user-id <i>user-id</i>	Displays information about sessions of a specified user. If this parameter is specified, detailed information about the user is displayed.	The user-id must exist on the device.
detail	Displays detailed information about users.	-
access-type	Displays information about the users using the specified authentication mode.	-
admin [ftp ssh telnet terminal web]	Displays information about the administrators using the specified authentication mode. <ul style="list-style-type: none"> • ftp: FTP user • ssh: SSH user • telnet: Telnet user • terminal: Terminal user • web: Web user 	-
ppp	Displays information about online users using PPP authentication.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

This command displays information about user sessions on the device.

Precautions

If the character string of the user name contains spaces (for example, a b), you can run the **display access-user username "a b"** command to view online users.

If the character string of the user name contains spaces and quotation marks (""") simultaneously, you cannot use the user name to view online users. In this case, you can run the **display access-user | include *username*** command to view the user ID of the online user, and then run the **display access-user user-id *user-id*** command to view the user. Alternatively, you can run the **cut access-user user-id *user-id*** command to force the user to go offline.

When displaying VPN user entries based on user IP address, you must set the **vpn-instance *vpn-instance-name*** parameter to specify the VPN instance to which the IP address belongs.

If **user-id** is specified, detailed information about the specified user is displayed. If **user-id** is not specified, brief information about all online users is displayed, including the user ID, user name, IP address, and MAC address of each user.

Only letters, digits, and special characters can be displayed for **username**.

When the value of **username** contains special characters or characters in other languages except English, the device displays dots (.) for these characters. If there are more than three such consecutive characters, three dots (.) are displayed. Here, the special characters are the ASCII codes smaller than 32 (space) or larger than 126 (~).

When the value of **username** is longer than 20 characters, the device displays up to three dots (.) for the characters following 19; that is, only 22 characters are displayed.

When **interface** is specified, the device displays the connection information of online wired users on the interface.

When querying user information based on interfaces, MAC addresses, or VLANs, the device only displays information about 802.1X, MAC address, or Portal authentication users.

Example

Display information about user sessions on the device.

```
<HUAWEI> display access-user
-----
UserID Username          IP address      MAC             Status
-----
1   normal@local         -              001b-21c4-3b56 Success
62  005500000001         192.168.1.121  0055-0000-0001 Open
32675 fztest           -              4611-97a4-0000 Success
16019 b002404           192.168.1.2   0000-c055-0102 Success
-----
Total: 4, printed: 4
```

NOTE

If you specify the **include** or **exclude** parameter in the command, the values of **Total** and **printed** are still the total number of users.

Display the user with the user ID being 1.

```
<HUAWEI> display access-user user-id 1
Basic:
User ID      : 1
User name    : normal
Domain-name  : rds
User MAC     : 3039-26e0-e5a6
```

```
User IP address      : 10.124.1.253
User vpn-instance   : -
User IPv6 address   : -
User access Interface : GigabitEthernet0/0/1
User vlan event     : Success
QinQVlan/UserVlan  : 0/20
User access time    : 2014/03/31 15:38:55
User accounting session ID : esap_lm000000000001245e5878016032
Option82 information : -
User access type    : MAC
Redirect ACL ID(Effective) : 3001
User Privilege      : 15
Terminal Device Type : Data Terminal
Dynamic ACL number(Effective) : 3100
Dynamic group index(Effective) : 10
Dynamic group name(Effective) : group10
Session Timeout     : 1800(s)
Termination Action  : RE-AUTHENTICATION
```

AAA:

```
User authentication type : MAC authentication
Current authentication method : RADIUS
Current authorization method : -
Current accounting method : RADIUS
```

Display the user with the user ID being 62.

<HUAWEI> **display access-user user-id 62**

Basic:

```
User ID              : 62
User name            : 005500000001
Domain-name         : -
User MAC             : 0055-0000-0001
User IP address      : 192.168.1.121
User vpn-instance   : -
User IPv6 address   : -
User access Interface : Wlan-Dbss3:152
User vlan event     : Open
QinQVlan/UserVlan  : 0/125
User access time    : 2015/07/10 11:27:12
User accounting session ID : esap_lm000000000001245e5878016032
Option82 information : -
User access type    : None
Redirect ACL ID(Effective) : 3001
User Privilege      : 15
AP ID                : 152
AP name              : ap-152
Radio ID             : 0
AP MAC               : 0000-0000-0002
SSID                 : 57-open
Online time          : 23(s)
```

AAA:

```
User authentication type : None
Current authentication method : None
Current authorization method : Local
Current accounting method : None
```

Display the user with the user ID being 32675.

<HUAWEI> **display access-user user-id 32675**

Basic:

```
User ID              : 32675
User name            : fztest
Domain-name         : fz
User MAC             : 4611-97a4-0000
User IP address      : -
User IPv6 address   : -
User access Interface : Eth-Trunk1
User vlan event     : Success
```

```

QinQVlan/UserVlan      : 0/18
User access time       : 2015/02/11 21:51:58
User accounting session ID : esap_lm000000000001245e5878016032
Option82 information   : -
User access type       : 802.1x
Redirect ACL ID(Effective) : 3001
User Privilege         : 15
AS ID                  : 1
AS name                : test
AS IP                  : 192.168.1.11
AS MAC                 : 0012-0016-4578
AS Interface           : GigabitEthernet0/0/1
Terminal Device Type   : Data Terminal
    
```

```

AAA:
User authentication type : 802.1x authentication
Current authentication method : RADIUS
Current authorization method : -
Current accounting method : RADIUS
    
```

Display the user with the user ID being 16019.

```

<HUAWEI> display access-user user-id 16019
Basic:
User ID          : 16019
User name        : b002404
Domain-name      : abc
User MAC         : 0000-c055-0102
User IP address  : 192.168.1.2
User vpn-instance : -
User IPv6 address : FC00:3::5689:98FF:FE01:583D
User IPv6 link local address : FE80::5689:98FF:FE01:583D
User access Interface : GigabitEthernet0/0/1
User vlan event  : Success
QinQVlan/UserVlan : 20/21
User vlan source : user request
User access time : 2016/08/16 18:32:16
User accounting session ID : esap_lm000000000001245e5878016032
Option82 information : -
User PIR(Kbps)     : 5000
User flow mapping name : zt
User flow queue name : zt
User access type   : MAC
Redirect ACL ID(Effective) : 3001
Terminal Device Type : Data Terminal
User inbound data flow(Packet) : -
User inbound data flow(Byte)   : -
User outbound data flow(Packet) : -
User outbound data flow(Byte)   : -
DAA Inbound data flow(Packet/Byte)
  Tariff level 1 : -/-
DAA Outbound data flow(Packet/Byte)
  Tariff level 1 : -/-
User Lease       : 600(s)
ISP VLAN         : 1000
ISP Interface    : GigabitEthernet0/1/17

AAA:
User authentication type : MAC authentication
Current authentication method : RADIUS
Current authorization method : -
Current accounting method : None
    
```

Table 13-5 Description of the **display access-user** command output

Item	Description
Basic	Basic information about a user.

Item	Description
UserID/User ID	Index of a user.
Username/User name	User name.
Domain-name	Authentication domain of a user.
MAC/User MAC	MAC address of a user.
IP address/User IP address	IP address of a user.
User vpn-instance	User VPN instance.
User IPv6 address	IPv6 address of a user.
User IPv6 link local address	IPv6 link-local address.
User access Interface	Access interface of a user.
Status/User vlan event	<p>Whether a user joins a VLAN.</p> <ul style="list-style-type: none"> • Open: For a wired user, the user goes online through the open function upon authentication failure. For wireless users, no authentication is performed. • Success: authentication is successful • Pre-authen: pre-authentication • Client-no-respond: the client does not respond • Fail-authorized: authorization upon authentication failure • Web-server-down: web server is Down • Aaa-server-down: AAA server is Down
QinQVlan/UserVlan	<p>VLAN that a user belongs to.</p> <ul style="list-style-type: none"> • In QinQ applications, QinQVlan indicates the outer VLAN ID and UserVlan indicates the inner VLAN ID. • For a common VLAN, UserVlan indicates the VLAN ID, and QinQVlan is 0.

Item	Description
User vlan source	Source of a user VLAN. <ul style="list-style-type: none"> • server vlan: The VLAN is delivered by the remote server. • user group vlan: the VLAN is bound to a user group. • service scheme vlan: The VLAN is configured in the service scheme view. • local event vlan: The authorized VLAN (visitor or survival) is configured locally. • user request: The VLAN is carried in the user request (authentication request).
User access time	Time when a user goes online. If a time zone is configured and the daylight saving time begins, the time is displayed in the format of YYYY/MM/DD HH:MM:SS UTC ±HH:MM DST.
User accounting session ID	ID of an accounting session.
Option82 information	Option 82 of a user.
User PIR(Kbps)	Peak Information Rate (PIR) in kbit/s.
User flow mapping name	Name of the user flow mapping template.
User flow queue name	Name of the user flow queue.
User access type	Access type of a user. For the related command, see local-user service-type .
Redirect ACL ID(Effective)	User Redirect ACL ID: <ul style="list-style-type: none"> • Effective: The redirection ACL has taken effect. • Ineffective: The redirection ACL does not take effect. The possible reason is that the ACL is not configured on the device.
User Privilege	Level of a user.
Terminal Device Type	Terminal device type of a user.

Item	Description
Dynamic ACL number(Effective)	ACL number: <ul style="list-style-type: none"> • Effective: The dynamic ACL has taken effect. • Ineffective: The dynamic ACL does not take effect. The possible causes are as follows: Dynamic RADIUS authorization fails; the ACL does not exist on the device; the wired user fails to obtain an IP address. NOTE This field is displayed only when ACL is dynamically delivered by the RADIUS server.
Dynamic ACL desc	Used by the RADIUS server to deliver IPv4 or IPv6 ACL rules to users. <ul style="list-style-type: none"> • Effective: The dynamic ACL rules have taken effect. • Ineffective: The dynamic ACL rules do not take effect.
Dynamic group index(Effective)	Index of a UCL group. This option is available only in NAC unified mode.
Dynamic group name(Effective)	Name of a UCL group. This option is available only in NAC unified mode.
Session Timeout	Timeout interval of sessions.
Termination Action	Action taken when a session times out. <ul style="list-style-type: none"> • RE-AUTHENTICATION: authentication is performed again • OFFLINE: the user is disconnected.
AP ID	ID of the AP connected to users.
AP name	Name of the AP connected to users.
Radio ID	ID of the radio.
AP MAC	MAC address of the AP connected to users.
SSID	SSID of a STA.
Online time	STA online time.
AAA	AAA information about a user.
User authentication type	Authentication type of a user, which depends on the access type of the user.
Current authentication method	Authentication method used for a user.

Item	Description
Current authorization method	Current authorization method.
Current accounting method	Current accounting method.
AS ID	ID of the access devices in policy association network.
AS name	Name of the access devices in policy association network.
AS IP	IP address of the access devices in policy association network.
AS MAC	MAC address of the access devices in policy association network.
AS Interface	Interface of the access devices in policy association network.
User inbound data flow(Packet)	Data traffic (number of packets) from users to the device.
User inbound data flow(Byte)	Data traffic (number of bytes) from users to the device.
User outbound data flow(Packet)	Data traffic (number of packets) from the device to users.
User outbound data flow(Byte)	Data traffic (number of bytes) from the device to users.
DAA Inbound data flow(Packet/Byte) (The Eth-Trunk contains a card that does not support this function)	DAA incoming traffic (number of packets or bytes)(The Eth-Trunk contains a card that does not support this function). NOTE The device does not support this item.
Tariff level 1	Tariff level. NOTE The device does not support this item.
DAA Outbound data flow(Packet/Byte)	DAA outgoing traffic (number of packets or bytes). NOTE The device does not support this item.
User Lease	User lease.
ISP VLAN	Authorized outbound interface VLAN.
ISP Interface	Authorized outbound interface.

13.1.35 display accounting-scheme

Function

The **display accounting-scheme** command displays the configuration of accounting schemes, including accounting scheme names and accounting modes.

Format

display accounting-scheme [*accounting-scheme-name*]

Parameters

Parameter	Description	Value
<i>accounting-scheme-name</i>	Specifies the name of an accounting scheme.	The accounting scheme must already exist.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After the accounting scheme configuration is complete, run the **display accounting-scheme** command to view the configuration of accounting schemes.

Before applying an accounting scheme to a domain, run the **display accounting-scheme** command to check whether configuration of the accounting scheme is correct.

Precautions

The **display accounting-scheme** command displays the detailed configuration if the name of an accounting scheme is specified. Otherwise, this command displays only the summary of accounting schemes.

Example

Display the summary of all accounting schemes.

```
<HUAWEI> display accounting-scheme
```

```
-----  
Accounting-scheme-name      Accounting-method  
-----  
default                      None  
radius-1                     RADIUS  
tacacs-1                     HWTACACS
```

```
-----  
Total of accounting-scheme: 3
```

Display the detailed configuration of the default accounting scheme.

```
<HUAWEI> display accounting-scheme default
```

```
Accounting-scheme-name      : default  
Accounting-method           : None  
Realtime-accounting-switch  : Disabled  
Realtime-accounting-interval(min) : -  
Start-accounting-fail-policy : Offline  
Realtime-accounting-fail-policy : Online  
Realtime-accounting-failure-retries : 3
```

Table 13-6 Description of the **display accounting-scheme** command output

Item	Description
Accounting-scheme-name	Name of an accounting scheme. To create an accounting scheme, run the accounting-scheme (AAA view) command.
Accounting-method	Accounting mode in the accounting scheme. The accounting modes are as follows: <ul style="list-style-type: none"> • HWTACACS: indicates that an HWTACACS server performs accounting. • None: indicates non-accounting. • RADIUS: indicates that a RADIUS server performs accounting. To configure an accounting mode, run the accounting-mode command.
Realtime-accounting-switch	Whether the real-time accounting function is enabled: <ul style="list-style-type: none"> • Disabled: indicates that the real-time accounting function is disabled. • Enabled: indicates that the real-time accounting function is enabled. To set the interval for real-time accounting, run the accounting realtime command.
Realtime-accounting-interval(min)	Interval for real-time accounting. To set the interval for real-time accounting, run the accounting realtime command.

Item	Description
Start-accounting-fail-policy	Policy used for accounting-start failures. <ul style="list-style-type: none">• Offline: disconnects users.• Online: keeps users online. To configure a policy for accounting-start failures, run the accounting start-fail command.
Realtime-accounting-fail-policy	Policy used for real-time accounting failures. <ul style="list-style-type: none">• Offline: disconnects users.• Online: keeps users online. To configure the policy used for real-time accounting failures, run the accounting interim-fail command.
Realtime-accounting-failure-retries	Number of retries before a real-time accounting failure is confirmed. To set the number of real-time retries before a real-time accounting failure is confirmed, run the accounting interim-fail command.

13.1.36 display authentication ipv6-statistics status

Function

The **display authentication ipv6-statistics status** command displays whether IPv6 statistics collection takes effect.

 **NOTE**

Only S5720EI, S5720HI, S6720EI, and S6720S-EI support this command.

Format

display authentication ipv6-statistics status

Parameters

None

Views

User view

Default Level

1: Monitoring level

Usage Guidelines

After IPv6 traffic statistics collection is globally enabled using the [13.1.17 authentication ipv6-statistics enable](#) command, you can run this command to check whether the function takes effect.

Example

Check whether IPv6 traffic statistics collection takes effect.

```
<HUAWEI> display authentication ipv6-statistics status
```

```
-----  
Slot-id          State  
-----  
6                success  
8                not support  
-----  
Total: 2
```

Table 13-7 Description of the **display authentication ipv6-statistics status** command output

Item	Description
Slot-id	Slot ID.
State	Whether IPv6 traffic statistics collection takes effect: <ul style="list-style-type: none">• success: The function takes effect.• failure: The function does not take effect.• not support: The device does not support the function.• unknown: Unknown error. To configure the IPv6 traffic statistics collection function, run the 13.1.17 authentication ipv6-statistics enable command.

13.1.37 display authentication-scheme

Function

The **display authentication-scheme** command displays the configuration of authentication schemes.

Format

display authentication-scheme [*authentication-scheme-name*]

Parameters

Parameter	Description	Value
<i>authentication-scheme-name</i>	Specifies the name of an authentication scheme.	The authentication scheme must already exist.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After the authentication scheme configuration is complete, run the **display authentication-scheme** command to view the configuration of authentication schemes.

Precautions

The **display authentication-scheme** command displays the detailed configuration if the command is executed in the authentication scheme view or the name of an authentication scheme is specified. Otherwise, this command displays only the summary of authentication schemes.

Example

Display the summary of all authentication schemes.

```
<HUAWEI> display authentication-scheme
-----
Authentication-scheme-name      Authentication-method
-----
default                          Local
radius                          RADIUS
-----
Total of authentication scheme: 2
```

Display the detailed configuration of the default authentication scheme.

```
<HUAWEI> display authentication-scheme default
Authentication-scheme-name      : default
Authentication-method           : Local
Radius authentication-type of admin : PAP(all)
```

Table 13-8 Description of the **display authentication-scheme** command output

Item	Description
Authentication-scheme-name	Name of an authentication scheme. To create an authentication scheme, run the 13.1.20 authentication-scheme (AAA view) command.
Authentication-method	Authentication mode in an authentication scheme. To configure an authentication mode in an authentication scheme, run the 13.1.18 authentication-mode (authentication scheme view) command.
Radius authentication-type of admin	Access type of administrators on whom CHAP authentication is performed. The value can be: <ul style="list-style-type: none">• PAP(all): PAP authentication is performed on the administrators of all access types when they are authenticated using RADIUS.• CHAP(ftp) PAP (other): CHAP authentication is performed on FTP users whose access types are displayed in brackets () when they are authenticated using RADIUS, and PAP authentication is performed on the administrators of other access types. To configure the access type, run the 13.1.22 authentication-type radius chap access-type admin command.

13.1.38 display authorization-scheme

Function

The **display authorization-scheme** command displays the configuration of authorization schemes.

Format

display authorization-scheme [*authorization-scheme-name*]

Parameters

Parameter	Description	Value
<i>authorization-scheme-name</i>	Specifies the name of an authorization scheme.	The authorization scheme must already exist.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After the authorization scheme configuration is complete, run the **display authorization-scheme** command to view the configuration of authorization schemes.

Before applying an authorization scheme to a domain, run the **display authorization-scheme** command to check whether configuration of the authorization scheme is correct.

Precautions

The **display authorization-scheme** command displays the detailed configuration if the name of an authorization scheme is specified. Otherwise, this command displays only the summary of authorization schemes.

Example

Display the summary of all authorization schemes.

```
<HUAWEI> display authorization-scheme
-----
Authorization-scheme-name    Authorization-method
-----
default                      Local
scheme0                      Local
-----
Total of authorization-scheme: 2
```

Display the detailed configuration of the authorization scheme **scheme0**.

```
<HUAWEI> display authorization-scheme scheme0
-----
Authorization-scheme-name : scheme0
Authorization-method      : Local
Authorization-cmd level 0 : Disabled
Authorization-cmd level 1 : Disabled
Authorization-cmd level 2 : Disabled
Authorization-cmd level 3 : Disabled
Authorization-cmd level 4 : Disabled
```

```

Authorization-cmd level 5 : Disabled
Authorization-cmd level 6 : Disabled
Authorization-cmd level 7 : Disabled
Authorization-cmd level 8 : Disabled
Authorization-cmd level 9 : Disabled
Authorization-cmd level 10 : Disabled
Authorization-cmd level 11 : Disabled
Authorization-cmd level 12 : Disabled
Authorization-cmd level 13 : Disabled
Authorization-cmd level 14 : Disabled
Authorization-cmd level 15 : Disabled
Authorization-cmd no-response-policy : Online
-----

```

Table 13-9 Description of the **display authorization-scheme** command output

Item	Description
Authorization-scheme-name	Name of the authorization scheme. To create an authorization scheme, run the authorization-scheme (AAA view) command.
Authorization-method	Authorization mode set for the authorization scheme. To configure an authorization mode, run the authorization-mode command.
Authorization-cmd level	Whether the command line authorization function is enabled for a user with a specified level: <ul style="list-style-type: none"> • Disabled: indicates that the command line authorization function is disabled. • Enabled: indicates that the command line authorization function is enabled. To set the command line authorization function, run the authorization-cmd command.
Authorization-cmd no-response-policy	Policy for command line authorization failures, in which users are allowed to go online.

13.1.39 display domain

Function

The **display domain** command displays the domain configuration.

Format

display domain [name *domain-name*]

Parameters

Parameter	Description	Value
name <i>domain-name</i>	Specifies the name of a domain. If this parameter is not specified, brief information about all domains is displayed.	The domain name must already exist.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After a domain is created by the **domain** command with required parameters specified, you can run the **display domain** command to view the domain configuration.

Example

Display brief information about all domains.

```
<HUAWEI> display domain
-----
index  DomainName
-----
0      default
1      default_admin
-----
Total: 2
```

Table 13-10 Description of the **display domain** command output

Item	Description
index	Index of a domain. To configure this parameter, run the 13.1.47 domain (AAA view) command.
DomainName	Name of a domain. To configure this parameter, run the 13.1.47 domain (AAA view) command.

Display the configuration of the domain **default**.

<HUAWEI> **display domain name default**

```

Domain-name           : default
Domain-index          : 0
Domain-state          : Active
Authentication-scheme-name : default
Accounting-scheme-name   : default
Authorization-scheme-name : -
Service-scheme-name     : -
RADIUS-server-template  : -
HWTACACS-server-template : -
User-group            : -
Push-url-address       : -
    
```

Table 13-11 Description of the **display domain name** command output

Item	Description
Domain-name	Name of a domain. To configure this parameter, run the 13.1.47 domain (AAA view) command.
Domain-index	Index of a domain. To configure this parameter, run the 13.1.47 domain (AAA view) command.
Domain-state	Status of a domain. <ul style="list-style-type: none"> Active: indicates that the domain is activated. Block: indicates that the domain is blocked. To configure this parameter, run the 13.1.83 state (AAA domain view) command.
Authentication-scheme-name	Name of the authentication scheme used in a domain. To configure this parameter, run the 13.1.19 authentication-scheme (AAA domain view) command.
Accounting-scheme-name	Name of the accounting scheme used in a domain. To configure this parameter, run the 13.1.14 accounting-scheme (AAA domain view) command.
Authorization-scheme-name	Name of the authorization scheme used in a domain. To configure this parameter, run the 13.1.27 authorization-scheme (AAA domain view) command.
Service-scheme-name	Name of the service scheme used in a domain. To configure this parameter, run the 13.1.81 service-scheme (aaa domain view) command.
RADIUS-server-template	Name of the RADIUS server template used in a domain. To configure this parameter, run the 13.2.22 radius-server (aaa domain view) command.

Item	Description
HWTACACS-server-template	Name of the HWTACACS server template used in a domain. To configure this parameter, run the 13.3.6 hwtacacs-server command.
User-group	Name of the user group for the users in a domain. To configure this parameter, run the 13.1.86 user-group (AAA domain view) command.
Push-url-address	The output displays a pushed URL used in the domain. To configure this parameter, run the 13.4.119 force-push command.

13.1.40 display local-user

Function

The **display local-user** command displays information about local users.

Format

display local-user [**domain** *domain-name* | **state** { **active** | **block** } | **username** *user-name*] *

Parameters

Parameter	Description	Value
domain <i>domain-name</i>	Displays information about local users in a specified domain.	The domain name must already exist.
state { active block }	Displays the attributes of local users in the specified state. <ul style="list-style-type: none"> ● active: indicates the active state. ● block: indicates the blocking state. 	-
username <i>user-name</i>	Displays information about a specified local user name.	The user name must already exist.

Views

All views

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The **display local-user** command output helps you check the configuration of local users and isolate faults related to the local users.

Precautions

If no parameter is specified, brief information about all local users is displayed. If a parameter is specified, detailed information about the specified local user is displayed.

Low-level users cannot view information about high-level users.

Example

Display brief information about local users.

```
<HUAWEI> display local-user
-----
User-name           State AuthMask AdminLevel
-----
user-a              A    A      0
user-c              A    A      0
-----
Total 2 user(s)
```

Display detailed information about the local user **user-a**.

```
<HUAWEI> display local-user username user-a
The contents of local user(s):
Password           : *****
State              : active
Service-type-mask  : A
Privilege level    : -
Ftp-directory      : -
HTTP-directory     : -
Access-limit       : Yes
Access-limit-max   : 4294967295
Accessed-num       : 0
Idle-timeout       : -
User-group         : -
Original-password  : No
Password-set-time  : 2019-12-01 18:42:57+01:00 DST
Password-expired   : No
Password-expire-time : -
Account-expire-time : -
```

NOTE

For a local user who fails to log in to the device but is not locked, **Retry-time-left** is displayed. For a local user whose initial password is changed, **Change password retry-count-left** is displayed. When the number of continuous login failures or the number of initial password change failures reaches the limit specified using the [13.1.53 local-aaa-user wrong-password](#) command, the user is locked.

Display information about local user **user1** who fails to log in to the device.

```
<HUAWEI> display local-user username
user1
The contents of local user(s):
Password      : *****
State         : active
Service-type-mask : T
Privilege level : 0
Ftp-directory  : -
HTTP-directory : -
Access-limit   : -
Accessed-num   : 0
Idle-timeout   : -
Retry-interval : 4 Min(s)
Retry-time-left : 1
Original-password : Yes
Password-set-time : 2019-01-27 13:26:55+08:00
Password-expired : No
Password-expire-time : -
Account-expire-time : -
```

Display information about local user **user1** whose initial password fails to be changed.

```
<HUAWEI> display local-user username user1
The contents of local user(s):
Password      : *****
State         : active
Service-type-mask : T
Privilege level : 0
Ftp-directory  : -
HTTP-directory : -
Access-limit   : -
Accessed-num   : 1
Idle-timeout   : -
Change password retry-interval : 4 Min(s)
Change password retry-count-left: 3
Original-password : Yes
Password-set-time : 2019-01-27 13:26:55+08:00
Password-expired : No
Password-expire-time : -
Account-expire-time : -
```

Display information about local users in blocking state.

```
<HUAWEI> display local-user state block
-----
User-name      State AuthMask AdminLevel
-----
test2          B   T      0
-----
```

Display information about local user **test2** in blocking state.

```
<HUAWEI> display local-user state block username test2
The contents of local user(s):
Password      : *****
State         : block
Service-type-mask : T
Privilege level : 0
Ftp-directory  : -
HTTP-directory : -
Access-limit   : -
Accessed-num   : 0
Idle-timeout   : -
Block-time-left : 8 Min(s)
Original-password : Yes
Password-set-time : 2019-01-27 13:26:55+08:00
Password-expired : No
Password-expire-time : -
Account-expire-time : -
```

Table 13-12 Description of the **display local-user** command output

Item	Description
User-name	Name of the local user. To configure this parameter, run the 13.1.54 local-user command.
State	State of the local user: <ul style="list-style-type: none"> ● A: Active ● B: Block To configure this parameter, run the 13.1.54 local-user command.
AuthMask	Access type of the local user. <ul style="list-style-type: none"> ● T: indicates the Telnet users. ● M: indicates the terminal users, which usually refer to the console users. ● S: indicates the SSH users. ● F: indicates the FTP users. ● W: indicates the web users. ● X: indicates the 802.1X users. ● A: indicates all access types. ● H: indicates the HTTP users. ● D: indicates the X25-PAD users. ● P: indicates the PPP users. ● Combination: For example, MH indicates either a terminal user or an HTTP user. To configure this parameter, run the 13.1.61 local-user service-type command.
AdminLevel	Local user level. To configure this parameter, run the 13.1.54 local-user command.
Password	Password of the local user. To configure this parameter, run the 13.1.54 local-user command.
Service-type-mask	Service type of the local user. Same as the AuthMask type. To configure this parameter, run the 13.1.61 local-user service-type command.
Privilege level	Local user level. To configure this parameter, run the 13.1.54 local-user command.

Item	Description
Ftp-directory	FTP directory of the local user. To configure this parameter, run the 13.1.54 local-user command.
HTTP-directory	HTTP directory of the local user. To configure this parameter, run the 13.1.54 local-user command.
Access-limit	Whether the maximum number of sessions of the local user is configured. To configure this parameter, run the 13.1.54 local-user command.
Access-limit-max	Maximum number of sessions of the local user. To configure this parameter, run the 13.1.54 local-user command.
Accessed-num	Number of established sessions.
Idle-timeout	Idle timeout interval. To configure this parameter, run the 13.1.54 local-user command.
User-group	Authorization information of the user group to which the local user is bound. To configure this parameter, run the 13.1.54 local-user command.
Original-password	Whether the password of a local user is the initial password: <ul style="list-style-type: none"> • Yes • No To configure this parameter, run the 13.1.66 password alert original command.
Password-set-time	Time when the local user's password is created. The value is in format local time + DST offset.
Password-expired	Whether a local user's password has expired: <ul style="list-style-type: none"> • Yes • No
Password-expire-time	Time when the local user's password expires. The value is in format local time + DST offset. To configure this parameter, run the 13.1.67 password expire command.

Item	Description
Account-expire-time	Expiry time of a local user account. The value is in format local time + DST offset. To configure this parameter, run the 13.1.57 local-user expire-date command.
Retry-interval	Login retry interval before a local user is locked. To configure this parameter, run the 13.1.53 local-aaa-user wrong-password command.
Retry-time-left	Remaining number of login retries before a local user is locked. To configure this parameter, run the 13.1.53 local-aaa-user wrong-password command.
Change password retry-interval	Retry interval for changing the initial password of a local user before the user is locked. To configure this parameter, run the 13.1.53 local-aaa-user wrong-password command.
Change password retry-count-left	Remaining number of initial password change retries before a local user is locked. To configure this parameter, run the 13.1.53 local-aaa-user wrong-password command.

Related Topics

[13.1.54 local-user](#)

13.1.41 display local-user expire-time

Function

The **display local-user expire-time** command displays the time when local accounts expire.

Format

display local-user expire-time

Parameters

None

Views

All views

Default Level

3: Management level

Usage Guidelines

The command output helps you diagnose and rectify the faults related to local user passwords.

Example

Display the time when local accounts expire.

```
<HUAWEI> display local-user expire-time
-----
Username          Password-expire  Account-expire  Expired
-----
zsh                2014-12-01 21:25:44  -                NO
mm001             2014-12-01 21:29:58  -                NO
-----
Total: 2, printed: 2
```

Table 13-13 Description of the **display local-user expire-time** command output

Item	Description
Username	Local account name. To configure this parameter, run the 13.1.54 local-user command.
Password-expire	Number of days after which the password expires. To configure this parameter, run the 13.1.67 password expire command.
Account-expire	Account expiration time. To configure this parameter, run the 13.1.57 local-user expire-date command.
Expired	Whether the local account has expired: <ul style="list-style-type: none"> • YES • NO <p>NOTE The displayed value and actual value may have a difference within one minute; there is a possibility that the password has expired, but the displayed value is NO. When the local user account or password has expired, the local user becomes invalid.</p>

Related Topics

[13.1.57 local-user expire-date](#)

[13.1.67 password expire](#)

13.1.42 display local-aaa-user password policy

Function

The **display local-aaa-user password policy** command displays the password policy of local user.

Format

display local-aaa-user password policy { access-user | administrator }

Parameters

Parameter	Description	Value
access-user	Indicates the password policy of local access users.	-
administrator	Indicates the password policy of local administrator.	-

Views

All views

Default Level

3: Management level

Usage Guidelines

After configuring the password policy for local users, you can run the **display local-aaa-user password policy** command to check whether the configuration is correct.

Example

Display the password policy of local access users.

```
<HUAWEI> display local-aaa-user password policy access-user  
Password control      : Enable  
Password history      : Enable (history records:5)
```

Table 13-14 Description of the **display local-aaa-user password policy access-user** command output

Item	Description
Password control	Whether the password control function is enabled: <ul style="list-style-type: none">• Enable• Disable To configure this function, run the 13.1.59 local-aaa-user password policy access-user command.

Item	Description
Password history	Whether the historical password recording function is enabled and the maximum number of historical passwords of each user. To configure this function, run the 13.1.68 password history record number command.

Display the password policy of local administrator.

```
<HUAWEI> display local-aaa-user password policy administrator
Password control          : Enable
Password expiration      : Enable (180 days)
Password history         : Enable (history records:5)
Password alert before expiration : 30 days
Password alert original   : Enable
```

Table 13-15 Description of the **display local-aaa-user password policy administrator** command output

Item	Description
Password control	Whether the password control function is enabled: <ul style="list-style-type: none"> • Enable • Disable To configure this function, run the 13.1.60 local-aaa-user password policy administrator command.
Password expiration	Whether the password expiration function is enabled and password expiration time. To configure this function, run the 13.1.67 password expire command.
Password history	Whether the historical password recording function is enabled and the maximum number of historical passwords of each user. To configure this function, run the 13.1.68 password history record number command.
Password alert before expiration	Password expiration prompt days. To configure this function, run the 13.1.65 password alert before-expire command.
Password alert original	Whether the device prompt users to change the initial passwords: <ul style="list-style-type: none"> • Enable • Disable To configure this function, run the 13.1.66 password alert original command.

Related Topics

- [13.1.59 local-aaa-user password policy access-user](#)
- [13.1.60 local-aaa-user password policy administrator](#)
- [13.1.67 password expire](#)
- [13.1.65 password alert before-expire](#)
- [13.1.66 password alert original](#)
- [13.1.68 password history record number](#)

13.1.43 display recording-scheme

Function

The **display recording-scheme** command displays the configuration of recording schemes.

Format

display recording-scheme [*recording-scheme-name*]

Parameters

Parameter	Description	Value
<i>recording-scheme-name</i>	Specifies the name of a recording scheme.	The recording scheme must already exist.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

The **display recording-scheme** command displays the configuration of recording schemes.

Example

Display the configuration of the recording scheme **scheme0**.

```
<HUAWEI> display recording-scheme scheme0
```

```
-----  
Recording-scheme-name      : scheme0  
HWTACACS-template-name    : tacas-1  
-----
```


Table 13-16 Description of the **display recording-scheme** command output

Item	Description
Recording-scheme-name	Name of the recording scheme. To create a recording scheme, run the recording-scheme command.
HWTACACS-template-name	Name of the HWTACACS server template associated with the recording scheme. To associate an HWTACACS server template with a recording scheme, run the recording-mode hwtacacs command.

Related Topics

[13.1.70 recording-mode hwtacacs](#)

[13.1.71 recording-scheme](#)

13.1.44 display remote-user authen-fail

Function

The **display remote-user authen-fail** command displays the accounts that fail in remote AAA authentication.

Format

display remote-user authen-fail [**blocked** | **username** *username*]

Parameters

Parameter	Description	Value
blocked	Displays all the remote AAA authentication accounts that have been locked.	-
username <i>username</i>	Displays details about the accounts that fail in remote AAA authentication. If the <i>username</i> parameter is not specified, basic information about all accounts that fail in remote AAA authentication is displayed.	It is a string of 1 to 253 case-insensitive characters without spaces.

Views

All views

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After the account locking function is enabled for the users who fail in AAA remote authentication, the device records all failed accounts, including:

- The accounts that failed in authentication and are locked, for example, when the user entered the wrong account name or password too many times.
- The accounts that failed in authentication, but are not locked, for example, when the number of times the account name or password was entered incorrectly did not exceed the limit.

Prerequisites

The [13.1.73 remote-aaa-user authen-fail](#) command has been enabled to lock the accounts that fail in remote AAA authentication.

Precautions

The device cannot back up a recorded account that fails the AAA authentication. If an active/standby switchover policy has been configured on the device, all user entries are cleared when the device completes an active/standby switchover.

Example

Display all accounts that have failed in remote AAA authentication.

```
<HUAWEI> display remote-user authen-fail
-----
Username           RetryInterval(Mins)  RetryTimeLeft  BlockTime(Mins)
-----
test@rds           5                    2              0
t@rds              0                    0              5
-----
Total 2, 2 printed
```

Display all locked accounts.

```
<HUAWEI> display remote-user authen-fail blocked
-----
Username           RetryInterval(Mins)  RetryTimeLeft  BlockTime(Mins)
-----
t@rds              0                    0              4
-----
Total 1, 1 printed
```

Display details about the account **test** that failed in remote AAA authentication.

```
<HUAWEI> display remote-user authen-fail username test
The contents of the user:
Retry-interval   : 0 Min(s)
Retry-time-left  : 0
Block-time-left  : 4 Min(s)
User-state       : Block
```

Table 13-17 Description of the **display remote-user authen-fail** command output

Item	Description
Username	User name.
RetryInterval(Mins)	Authentication retry interval, in minutes. To configure this parameter, run the 13.1.73 remote-aaa-user authen-fail command.
Retry-interval	Authentication retry interval. To configure this parameter, run the 13.1.73 remote-aaa-user authen-fail command.
RetryTimeLeft	Remaining number of consecutive authentication failures. To configure this parameter, run the 13.1.73 remote-aaa-user authen-fail command.
Retry-time-left	Remaining number of consecutive authentication failures. To configure this parameter, run the 13.1.73 remote-aaa-user authen-fail command.
BlockTime(Mins)	Remaining locking time of an account. To configure this parameter, run the 13.1.73 remote-aaa-user authen-fail command.
Block-time-left	Remaining locking time of an account. To configure this parameter, run the 13.1.73 remote-aaa-user authen-fail command.
User-state	User status: <ul style="list-style-type: none"> • Block • Active

Related Topics

[13.1.73 remote-aaa-user authen-fail](#)

13.1.45 display service-scheme

Function

The **display service-scheme** command displays the configuration of service schemes.

Format

display service-scheme [name *name*]

Parameters

Parameter	Description	Value
name <i>name</i>	Specifies the name of a service scheme.	The service scheme must already exist.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

The **display service-scheme** command displays the configuration of service schemes.

Before applying a service scheme to a domain, run the **display service-scheme** command to check whether the service scheme is correct.

Precautions

The **display service-scheme** command displays the detailed configuration if the command is executed in the service scheme view or the name of a service scheme is specified. Otherwise, this command displays only the summary of service schemes.

Example

Display information about all service schemes.

```
<HUAWEI> display service-scheme
-----
service-scheme-name      scheme-index
-----
svcscheme1                0
svcscheme2                1
-----
Total of service scheme: 2
```

Display the configuration of the service scheme **svcscheme1**.

```
<HUAWEI> display service-scheme name svcscheme1
service-scheme-name      : svcscheme1
service-scheme-primary-dns  : -
service-scheme-secondary-dns : -
service-scheme-adminlevel  : 15
service-scheme-uclgroup-ID  : 10
service-scheme-uclgroup-name : u1
service-scheme-acl-id      : 3001
service-scheme-redirect-acl-id: 3001
service-scheme-vlan        : 10
service-scheme-voicevlan   : enable
```

Table 13-18 Description of the **display service-scheme** command output

Item	Description
service-scheme-name	Name of a service scheme. To create a service scheme, run the service-scheme (AAA view) command.
scheme-index	Index of a service scheme.
service-scheme-primary-dns	Address of the primary DNS server. To configure this item, run the 13.1.46 dns (service scheme view) command.
service-scheme-secondary-dns	Address of the secondary DNS server. To configure this item, run the 13.1.46 dns (service scheme view) command.
service-scheme-adminlevel	Level of an administrator. To configure this item, run the admin-user privilege level command.
service-scheme-uclgroup-ID	Index of the bound UCL group. To configure this item, run the 13.4.193 ucl-group (service scheme view) command.
service-scheme-uclgroup-name	Name of the bound UCL group. To configure this item, run the 13.4.193 ucl-group (service scheme view) command.
service-scheme-acl-id	Bound ACL number. To configure this item, run the 13.4.12 acl-id (service scheme view) command.
service-scheme-redirect-acl-id	Number of the ACL used for redirection in the service scheme. To configure this item, run the 13.1.72 redirect-acl command.
service-scheme-vlan	User VLAN ID. To configure this item, run the 13.4.205 user-vlan (service scheme view) command.
service-scheme-voicevlan	Whether voice VLAN is enabled. To configure this item, run the 13.4.206 voice-vlan (service scheme view) command.

Related Topics

[13.1.82 service-scheme \(AAA view\)](#)

13.1.46 dns (service scheme view)

Function

The **dns** command configures the primary or secondary DNS server in a service scheme.

The **undo dns** command cancels the configuration of the primary or secondary DNS server in a service scheme.

By default, no primary or secondary DNS server is configured in a service scheme.

Format

dns *ip-address* [**secondary**]

undo dns [*ip-address*]

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the IP address of a DNS server.	The value is in dotted decimal notation.
secondary	Specifies the secondary DNS server.	-

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

If no DNS server is specified when a local address pool, DHCP server, or RADIUS server assigns IP addresses to users, the DNS server configured in the service scheme view is used.

Example

```
# Set the IP address of the primary DNS server in the service scheme svcscheme1 to 10.10.10.1.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] service-scheme svcscheme1  
[HUAWEI-aaa-service-svcscheme1] dns 10.10.10.1
```

```
# Set the IP address of the secondary DNS server in the service scheme svcscheme1 to 10.10.20.1.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa
```

```
[HUAWEI-aaa] service-scheme svcscheme1  
[HUAWEI-aaa-service-svcscheme1] dns 10.10.20.1 secondary
```

Related Topics

[13.1.45 display service-scheme](#)

13.1.47 domain (AAA view)

Function

The **domain** command creates a domain and displays its view.

The **undo domain** command deletes a domain.

By default, the device has two domains: **default** and **default_admin**. The two domains can be modified but cannot be deleted.

Format

domain *domain-name* [**domain-index** *domain-index*]

undo domain *domain-name*

Parameters

Parameter	Description	Value
<i>domain-name</i>	Specifies the name of a domain.	The value is a string of 1 to 64 case-insensitive characters. It cannot contain spaces or the following symbols: * ? ". The value cannot be - or --.
domain-index <i>domain-index</i>	Specifies the index of a domain.	The value is an integer that ranges from 0 to 31.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The device can manage users through domains. A domain is the minimum user management unit. A domain name can be an ISP name or the name of a service provided by an ISP. A domain can use the default authorization attribute, and be configured with a RADIUS template and authentication and accounting schemes.

If the domain to be configured already exists, the **domain** command displays the domain view.

If a user that belongs to this domain is online, you cannot run the **undo domain** command to delete the domain.

Prerequisites

To perform AAA for access users, you need to apply the authentication schemes, authorization schemes, and accounting schemes in the domain view. Therefore, authentication, authorization, and accounting schemes must be configured in the AAA view in advance.

Precautions

- The domain **default** is a global default common domain for user access, for example, NAC. By default, the domain is activated, and is bound to the authentication scheme **radius** and accounting scheme **default**, but is not bound to any authorization scheme.
- The domain **default_admin** is a global default management domain for users who log in to the device through HTTPS, SSH, Telnet, and the Web system, namely, administrators. By default, the domain is activated, and is bound to the authentication scheme **default** and accounting scheme **default**, but is not bound to any authorization scheme.

Example

Specify the domain named **domain1** and access the domain view.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain domain1
[HUAWEI-aaa-domain-domain1]
```

Related Topics

[13.1.39 display domain](#)

13.1.48 domain (system view)

Function

The **domain** command configures a global default domain.

The **undo domain** command restores the default setting.

By default, there are two global default domains: common domain **default** and administrative domain **default_admin**. The former is used as the global default domain of access users, while the latter as the global default domain of administrators.

Format

Common domain **default**:

domain *domain-name*

undo domain

Administrative domain **default_admin**:

domain *domain-name* **admin**

undo domain admin

Parameters

Parameter	Description	Value
<i>domain-name</i>	Specifies the name of a global default domain.	The domain must already exist.
admin	Configures a domain for administrators. If this parameter is not specified, the domain for common access users is configured.	-

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After the global default domain is configured, a user must be managed by the global default domain if their domain cannot be identified.

Precautions

You must create a domain before configuring the domain as the global default domain.

Example

Create domain **abc** and configure it as the global default common domain.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain abc
[HUAWEI-aaa-domain-abc] quit
[HUAWEI-aaa] quit
[HUAWEI] domain abc
```

Related Topics

[13.1.47 domain \(AAA view\)](#)

13.1.39 display domain

13.1.49 domain-location

Function

The **domain-location** command configures the position of a domain name.

The **undo domain-location** command restores the default position of a domain name.

By default, the domain name in the AAA view is placed behind the domain name delimiter, and no position is configured in the authentication profile view.

Format

domain-location { **after-delimiter** | **before-delimiter** }

undo domain-location

Parameters

Parameter	Description	Value
after-delimiter	Indicates that the domain name is placed behind the domain name delimiter.	-
before-delimiter	Indicates that the domain name is placed before the domain name delimiter.	-

Views

AAA view, authentication profile view

Default Level

In the AAA view, the default level is management level.

In the authentication profile view, the default level is configuration level.

Usage Guidelines

Usage Scenario

The format of a user name is **user name@domain name**. If **before-delimiter** is specified, the format **domain name@user name** is used.

You can use the **domain-location** command only when there is no online user.

Precautions

If you run the **domain-location** command in the AAA view, the position of a domain is configured globally and the configuration takes effect for all users.

When this command is executed in the authentication profile, the configuration takes effect only after the authentication profile is bound to a VAP profile.

When the command is executed in the AAA view, the configuration takes effect for all users. When the command is executed in the authentication profile, the configuration takes effect for only the users connected to this authentication profile.

Example

Configure the domain name before the domain name delimiter.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain-location before-delimiter
```

Related Topics

[13.1.32 display aaa configuration](#)

13.1.50 domain-name-delimiter

Function

The **domain-name-delimiter** command configures a domain name delimiter.

The **undo domain-name-delimiter** command restores the default domain name delimiter.

By default, the domain name delimiter in the AAA view is @, and no delimiter is available in the authentication profile view.

Format

domain-name-delimiter *delimiter*

undo domain-name-delimiter

Parameters

Parameter	Description	Value
<i>delimiter</i>	Specifies a domain name delimiter of only one bit.	The value can only be one of the following characters: \ / : < > @ ' %.

Views

AAA view, authentication profile view

Default Level

In the AAA view, the default level is management level.

In the authentication profile view, the default level is configuration level.

Usage Guidelines

Usage Scenario

Different AAA servers may use different domain name delimiters. To ensure that an AAA server obtains the correct user name and domain name, configure the same domain name delimiter on the device and the AAA server.

For example, if the domain name delimiter is %, the user name of **user1** in the domain **dom1** is **user1%dom1** or **dom1%user1**.

Precautions

Before using the **domain-name-delimiter** command, ensure that no local user exists.

If you run the **domain-name-delimiter** command in the AAA view, the domain name delimiter is configured globally and the configuration takes effect for all users.

When this command is executed in the authentication profile, the configuration takes effect only after the authentication profile is bound to a VAP profile.

When the command is executed in the AAA view, the configuration takes effect for all users. When the command is executed in the authentication profile, the configuration takes effect for only the users connected to this authentication profile.

Example

Configure the domain name delimiter as / in the AAA view.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain-name-delimiter /
```

Related Topics

[13.1.32 display aaa configuration](#)

[13.1.54 local-user](#)

13.1.51 domainname-parse-direction

Function

The **domainname-parse-direction** command configures the direction in which a domain name is parsed.

The **undo domainname-parse-direction** command restores the default direction in which a domain name is parsed.

By default, the domain name is parsed in the AAA view from left to right, and no direction is configured in which a domain name is parsed.

Format

domainname-parse-direction { **left-to-right** | **right-to-left** }

undo domainname-parse-direction

Parameters

Parameter	Description	Value
left-to-right	Parses a domain name form left to right.	-
right-to-left	Parses a domain name form right to left.	-

Views

AAA view, authentication profile view

Default Level

In the AAA view, the default level is management level.

In the authentication profile view, the default level is configuration level.

Usage Guidelines

Usage Scenario

In AAA implementations, users belong to different domains. A network access server (NAS) centrally manages users in a domain. During a user's login, the NAS parses the entered user name. A user is authenticated only when the user has the correct user name and domain name. When configuring an AAA scheme, run the **domainname-parse-direction** { **left-to-right** | **right-to-left** } command to configure the direction in which a domain name is parsed.

Assume that the user name is **username@dom1@dom2**.

- If the **domain-location** command configures the domain name behind the domain name delimiter:
 - When **left-to-right** is specified, the user name is **username** and the domain name is **dom1@dom2**.
 - When **right-to-left** is specified, the user name is **username@dom1** and the domain name is **dom2**.
- If the **domain-location** command configures the domain name before the domain name delimiter:
 - When **left-to-right** is specified, the user name is **dom1@dom2** and the domain name is **username**.
 - When **right-to-left** is specified, the user name is **dom2** and the domain name is **username@dom1**.

Precautions

If you run the **domainname-parse-direction** command in the AAA view, the direction in which a domain name is parsed is configured globally and the configuration takes effect for all users.

When this command is executed in the authentication profile, the configuration takes effect only after the authentication profile is bound to a VAP profile.

When the command is executed in the AAA view, the configuration takes effect for all users. When the command is executed in the authentication profile, the configuration takes effect for only the users connected to this authentication profile.

Example

Configure the device to parse a domain name from right to left in the AAA view.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domainname-parse-direction right-to-left
```

Related Topics

[13.1.32 display aaa configuration](#)

13.1.52 idle-cut (service scheme view)

Function

The **idle-cut** command enables the idle-cut function for domain users and sets the idle-cut parameters.

The **undo idle-cut** command disables the idle-cut function.

By default, the idle-cut function is disabled for domain users.

Format

idle-cut *idle-time flow-value* [**inbound** | **outbound**]

undo idle-cut

Parameters

Parameter	Description	Value
<i>idle-time</i>	Specifies the period in which an idle user can stay online.	The value is an integer that ranges from 1 to 1440, in minutes.
<i>flow-value</i>	Specifies the traffic threshold for idle-cut function. When the traffic of a user stays below this threshold for a certain period, the device considers that the user is in idle state.	The value is an integer that ranges from 0 to 4294967295, in kbytes.

Parameter	Description	Value
inbound	Indicates that the idle-cut function takes effect for only upstream traffic of users.	-
outbound	Indicates that the idle-cut function takes effect for only downstream traffic of users. NOTE If neither inbound nor outbound is specified, the idle-cut function takes effect for both upstream and downstream traffic.	-

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

If a user uses no or a little network traffic for a long time, the user still occupies certain bandwidth, which reduces access rate of other users. The idle-cut function disconnects the users whose traffic volume stays below the traffic threshold within the idle time, to save resources and improve service experience of other users.

Precautions

- The **idle-cut** command configured in the service scheme view takes effect only for administrators.

Example

```
# Enable the idle-cut function for the domain, and set the idle time to 1 minute  
and the traffic threshold to 10 kbytes.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] service-scheme huawei  
[HUAWEI-aaa-service-huawei] idle-cut 1 10
```

Related Topics

[13.1.45 display service-scheme](#)

13.1.53 local-aaa-user wrong-password

Function

The **local-aaa-user wrong-password** command enables local account locking function and sets the retry interval, consecutive incorrect password attempts, and locking duration.

The **undo local-aaa-user wrong-password** command disables local account locking function.

By default, the local account locking function is enabled, retry interval is 5 minutes, maximum number of consecutive incorrect password attempts is 3, and account locking period is 5 minutes.

Format

local-aaa-user wrong-password retry-interval *retry-interval* **retry-time** *retry-time* **block-time** *block-time*

undo local-aaa-user wrong-password

Parameters

Parameter	Description	Value
retry-interval <i>retry-interval</i>	Specifies the retry interval of a local account.	The value is an integer that ranges from 5 to 65535, in minutes.
retry-time <i>retry-time</i>	Specifies the consecutive incorrect password attempts.	The value is an integer that ranges from 3 to 65535.
block-time <i>block-time</i>	Specifies the local account locking duration. In actual application, there is a one minute difference in locking time.	The value is an integer that ranges from 5 to 65535, in minutes.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

This command applies to the following scenarios:

- The command locks a local account to improve password security of the local user. If the password is entered incorrectly more than a certain number of times within the given retry period, the account is locked. The device does not authenticate the user when the account is locked.
- The command locks a local account to ensure that the password will not be cracked by a brute force from a malicious user. When attempting to change the password, if the original password is entered incorrectly more than a certain number of times within the given retry period, the account is locked. The user cannot modify the password when the account is locked.

Follow-up Procedure

After a local account is locked, you can run the **local-user** *user-name* **state active** command to unlock the local account.

Precautions

Only entering the incorrect password can lock the account. Other local authentication failures will not lock the account.

Example

Enable local account locking, and set the authentication retry interval to 5 minutes, maximum number of consecutive incorrect password attempts to 3, and account locking period to 5 minutes.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] local-aaa-user wrong-password retry-interval 5 retry-time 3 block-time 5
```

13.1.54 local-user

Function

The **local-user** command creates a local user and sets parameters of the local user.

The **undo local-user** command deletes a local user.

By default, a local user exists in the system. The irreversible encryption algorithm is used, the level is 15, and service type is http and terminal. The default username and password are available in *S Series Switches Default Usernames and Passwords* (**Enterprise Network** or **Carrier**). If you have not obtained the access permission of the document, see **Help** on the website to find out how to obtain it.

Format

local-user *user-name* { **password** { **cipher** | **irreversible-cipher** } *password* | **access-limit** *max-number* | **ftp-directory** *directory* | **idle-timeout** *minutes* [*seconds*] | **privilege level** *level* | **state** { **block** | **active** } | **user-group** *group-name* } *

local-user *user-name* **http-directory** *directory*

undo local-user *user-name* [**access-limit** | **ftp-directory** | **http-directory** | **idle-timeout** | **privilege level** | **user-group** *group-name*]

Parameters

Parameter	Description	Value
<i>user-name</i>	Specifies the user name. If the user name contains a delimiter "@", the character before "@" is the user name and the character after "@" is the domain name. If the value does not contain "@", the entire character string represents the user name and the domain name is the default one.	The value is a string of 1 to 64 case-insensitive characters. It cannot contain spaces, asterisk, double quotation mark and question mark.

Parameter	Description	Value
<p>password { cipher irreversible-cipher } <i>password</i></p>	<p>Specifies the password of a local user.</p> <ul style="list-style-type: none"> • The cipher parameter indicates that the user password is encrypted using the reversible encryption algorithm. Unauthorized users can obtain the plain text by using the corresponding decryption algorithm, so security is low. • The irreversible-cipher parameter indicates that the user password is encrypted using the irreversible encryption algorithm. Unauthorized users cannot obtain the plain text by using the special encryption algorithm. User security is ensured. <p>If a user is allowed to encrypt the local user password using the irreversible encryption algorithm, the device does not support CHAP authentication for the user.</p> <p>NOTICE It is recommended that you set the user password when creating a user. The interaction method using the 13.1.58 local-user password command is recommended.</p>	<p>The value is a case-sensitive string without question marks (?) or spaces.</p> <ul style="list-style-type: none"> • If the cipher parameter is specified, the value of <i>password</i> can be a plain text of 8 to 128 characters or a cipher-text password of 48, 68, 88, 108, 128, 148, 168, or 188 characters. • If the irreversible-cipher parameter is specified, the value of <i>password</i> can be a plain text of 8 to 128 characters or a cipher-text password of 68 characters. <p>A simple local user password may bring security risks. The user password must consist of two types of characters, including uppercase letters, lowercase letters, numerals, and special characters. In addition, the password cannot be the same as the user name or user name in an inverse order.</p>

Parameter	Description	Value
access-limit <i>max-number</i>	<p>Specifies the number of connections that can be created with a specified user name.</p> <p>If this parameter is not specified, a user can establish a maximum of 4294967295 connections by default.</p>	<p>The value is an integer that ranges from 1 to 4294967295.</p> <p>The actual number of connections is the smaller value between <i>max-number</i> and the maximum number of users of a type on different models.</p>
ftp-directory <i>directory</i>	<p>Specifies the directory that FTP users can access.</p> <p>If this parameter is not specified, the FTP directory of the local user is empty. The device will check whether the default FTP directory has been set using the 2.7.75 set default ftp-directory command. If no FTP directory exists, FTP users cannot log in to the device.</p> <p>NOTE Ensure that the configured FTP directory is an absolute path; otherwise, the configuration does not take effect.</p>	<p>The value is a string of 1 to 64 case-sensitive characters without spaces.</p>
http-directory <i>directory</i>	<p>Specifies the directory that HTTP users can access.</p> <p>If this parameter is not specified, the HTTP directory of the local user is empty.</p>	<p>The value is a string of 1 to 64 case-sensitive characters without spaces.</p>

Parameter	Description	Value
<p>idle-timeout <i>minutes</i> [<i>seconds</i>]</p>	<p>Specifies the timeout period for disconnection of the user.</p> <ul style="list-style-type: none"> • <i>minutes</i> is the period when the user interface is disconnected in minutes. • <i>seconds</i> is the period when the user interface is disconnected in seconds. <p>If this parameter is not specified, the device uses the idle timeout interval configured by the 2.5.16 idle-timeout command in the user view.</p> <p>If <i>minutes</i> [<i>seconds</i>] is set to 0 0, the idle disconnection function is disabled.</p> <p>NOTICE If the idle timeout interval is set to 0 or a large value, the terminal will remain in the login state, resulting in security risks. You are advised to run the lock command to lock the current connection.</p>	<ul style="list-style-type: none"> • <i>minutes</i>: the value is an integer ranging from 0 to 35791 minutes. • <i>seconds</i>: the value is an integer ranging from 0 to 59 seconds.
<p>privilege level <i>level</i></p>	<p>Specifies the level of a local user. After logging in to the device, a user can run only the commands of the same level or lower levels.</p> <p>NOTE If this parameter is not specified, the user level is 0.</p> <p>The permission of API users is not controlled by this parameter. Therefore, you do not need to configure this parameter.</p>	<p>The value is an integer that ranges from 0 to 15. The greater the value, the higher the level of a user.</p>

Parameter	Description	Value
state { active block }	<p>Specifies the status of a local user.</p> <ul style="list-style-type: none"> • active indicates that a local user is in active state. The device accepts and processes the authentication request from the user, and allows the user to change the password. • block indicates that a local user is in blocking state. The device rejects the authentication request from the user and does not allow the user to change the password. <p>If a user has established a connection with the device, when the user is set in blocking state, the connection still takes effect but the device rejects subsequent authentication requests from the user.</p> <p>If this parameter is not specified, the status of a local user is active.</p>	-
user-group <i>group-name</i>	<p>Specifies the name of a user group.</p> <p>NOTE This parameter is supported only by the switches in the NAC common mode.</p>	The value is a string of 1 to 64 case-sensitive characters without spaces. It cannot contain spaces or the following symbols: / \ : * ? " < > @ ' %. The value cannot be - or --.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To facilitate device maintenance, run the **local-user** command on the device to create a local user and set parameters such as the password, user level, and FTP directory.

Prerequisites

Before adding a local user to a user group, ensure that the user group has been created using the [13.5.156 user-group](#) command.

Precautions

- For device security purposes, change the password periodically.
- Security risks exist if the user login mode is set to Telnet or FTP. You are advised set the user login mode to STelnet or SFTP and set the user access type to SSH.
When a device starts without any configuration, HTTP uses the randomly generated self-signed certificate to support HTTPs. The self-signed certificate may bring risks. Therefore, you are advised to replace it with the officially authorized digital certificate.
- After a local administrator logs in to the device, the administrator can create, modify, or delete attributes of other local users of the same or a lower level. The attributes include password, user level, maximum number of access users, and account validity period.
After you change the rights (for example, the password, level, FTP directory, idle timeout interval, or status) of a local account, the rights of users already online do not change. The change takes effect when the user next goes online.
- Online users cannot be deleted. When the user is offline or the **cut access-user username user-name** command is executed in the AAA view to disconnect the user, delete the user.
- The user name function may be invalid due to improper configuration of the domain name delimiter.
- One user group can be used by multiple local users. However, a local user belongs to only one user group. If the user groups have been configured for the local user and in the service template, only the user group configured for the local user takes effect. The user groups that are used by a local user or an online user cannot be deleted.
- The **idle-cut** command configured in the service scheme view takes effect only for administrators.

Example

Create a local user **user1**, and set the domain name to **vipdomain**, the password to **admin@12345** in cipher text, the maximum number of connections to 100, and the idle timeout interval to 10 minutes.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] local-user user1@vipdomain password irreversible-cipher admin@12345 access-limit
100 idle-timeout 10
```

Related Topics

[13.1.40 display local-user](#)

13.1.55 local-user change-password

Function

The **local-user change-password** command enables local users to change their passwords.

Format

local-user change-password

Parameters

None

Views

User view

Default Level

0: Visit level

Usage Guidelines

Usage Scenario

If you are a low-level administrator, to ensure security of the password, you can run the **local-user change-password** command in the user view to change your password after passing the authentication.

Precautions

- To modify the password, a local user must enter the old password.
- After the user that passes local authentication changes the password, the user must type the new password to pass local authentication.
- The **local-user change-password** command is used to change the password of a local user. It does not save the configuration, but the result of changing the password is saved through the **local-user password** command. If the server does not receive old password, new password, or confirmed password from the user within 30 seconds, it terminates the password change process. When the user presses **Ctrl+C** to cancel password change, the password change process is terminated.
- A simple password of a local user may bring security risks. When a local user changes the password, the new password must be a string of 8 to 128 characters and must contain at least two types of the following: uppercase letters, lowercase letters, digits, and special characters. In addition, the new password cannot be the same as the user name or the user name in a reverse order.

- For device security purposes, change the password periodically.

Example

The local user changes the password.

```
<HUAWEI> local-user change-password
Please configure the login password (8-128)
It is recommended that the password consist of at least 2 types of characters, including lowercase letters,
uppercase letters, numer
als and special characters.
Please enter old password:
Please enter new password:
Please confirm new password:
Info: The password is changed successfully.
```

13.1.56 local-user device-type

Function

The **local-user device-type** command configures the type of terminals allowed to access the network.

The **undo local-user device-type** command deletes the type of terminals allowed to access the network.

By default, the type of terminals allowed to access the network is not configured.

NOTE

This function is supported only by S5720HI.

Format

local-user *user-name* **device-type** *device-type* &<1-8>

undo local-user *user-name* **device-type**

Parameters

Parameter	Description	Value
<i>user-name</i>	Specifies the name of a local user. When querying and modifying the user account, you can use the wildcard *, for example, *@isp, user@*, and *@*.	The value is a string of 1 to 64 case-insensitive characters. It cannot contain spaces, asterisk, double quotation mark and question mark.
<i>device-type</i>	Specifies a terminal type.	The value is a string of 1 to 31 case-insensitive characters without spaces.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

You can run the **local-user device-type** command to configure the type of terminals allowed to access the network. In local authentication and authorization, the device checks whether a terminal is allowed to access the network. If so, the device checks the user name and password of the terminal.

Example

Set the type of the terminal that local user **hello** uses to access the network to **iphone**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] local-user hello device-type iphone
```

13.1.57 local-user expire-date

Function

The **local-user expire-date** command sets the expiration date of a local account.

The **undo local-user expire-date** command restores the default expiration date of a local account.

By default, a local account is permanently valid.

Format

local-user *user-name* **expire-date** *expire-date*

undo local-user *user-name* **expire-date**

Parameters

Parameter	Description	Value
<i>user-name</i>	Specifies a local account.	The value is a string of 1 to 64 case-insensitive characters. It cannot contain spaces, asterisk, double quotation mark and question mark.

Parameter	Description	Value
<i>expire-date</i>	Specifies the expiration date of the local account.	The value is in YYYY/MM/DD format. YYYY specifies the year, MM specifies the month, and DD specifies the day. The value ranges from 2000/1/1 to 2099/12/31.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After a local account is created, the account has no expiration date by default. You can run the **local-user expire-date** command to set the expiration date of a local account. When the expiration date is reached, the account expires. This configuration enhances network security.

Precautions

- For example, if the expiration date of the local account is set to 2013-10-1, the account becomes invalid at 00:00 on 2013-10-1.
- This function takes effect only for users who go online after this function is successfully configured.

Example

Set the expiration date of local account **hello@163.net** to 2013/10/1.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] local-user hello@163.net expire-date 2013/10/1
```

Related Topics

[13.1.54 local-user](#)

13.1.58 local-user password

Function

The **local-user password** command configures a password for a local account. By default, the password of a local account is empty.

Format

local-user *user-name* **password**

 NOTE

This command is an interactive command. After you enter **local-user** *user-name* **password** and press **Enter**, you can set the password as prompted. The local user password is a string of 8~128 case-sensitive characters.

Parameters

Parameter	Description	Value
<i>user-name</i>	Specifies the local user name.	The value is a string of 1 to 64 case-insensitive characters. It cannot contain spaces, asterisk, double quotation mark and question mark.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

If no password is configured when a local user is created, the password is empty, and the local user cannot log in to the device.

NOTICE

A simple local user password may bring security risks. The user password must consist of two types of characters, including uppercase letters, lowercase letters, numerals, and special characters. In addition, the password cannot be the same as the user name or user name in a reverse order.

Example

```
# Set the password to abc@#123456 for the local account hello@163.net.
```

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] local-user hello@163.net password
Please configure the login password (8-128)
It is recommended that the password consist of at least 2 types of characters, including lowercase letters, uppercase letters, numerals and special characters.
Please enter password: //Enter the password abc@#123456
Please confirm password: //Confirm the password abc@#123456
Info: Add a new user.
```

Related Topics

[13.1.40 display local-user](#)

13.1.59 local-aaa-user password policy access-user

Function

The **local-aaa-user password policy access-user** command enables the password policy for local access users and enters the local access user password policy view.

The **undo local-aaa-user password policy access-user** command disables the password policy of local access users.

By default, the password policy of local access users is disabled.

Format

local-aaa-user password policy access-user

undo local-aaa-user password policy access-user

Parameters

None

Views

AAA view

Default Level

3: Management level

Usage Guidelines

After a local user is created using the **local-user** command, the minimum length and complexity of the password are limited. If you want to improve password security, run this command to configure password policy. The new password cannot be the same as any previously used password stored on the device.

Example

```
# Enable the local access user password policy and enter the local access user  
password policy view.  
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] local-aaa-user password policy access-user  
[HUAWEI-aaa-lupp-acc]
```

Related Topics

[13.1.68 password history record number](#)

13.1.60 local-aaa-user password policy administrator

Function

The **local-aaa-user password policy administrator** command enables the password policy for local administrators and enters the local administrator password policy view.

The **undo local-aaa-user password policy administrator** command disables the password policy of local administrators.

By default, the password policy of local administrators is disabled.

Format

local-aaa-user password policy administrator

undo local-aaa-user password policy administrator

Parameters

None

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After a local user is created using the **local-user** command, the minimum length and complexity of the password are limited. If you want to improve password security, you can run the following commands to configure the password policy for the local administrators:

- Run the **password expire** command to set the password validity period.
- Run the **password alert before-expire** command to set the password expiration prompt days.
- Run the **password alert original** command to enable the device to prompt users to change initial passwords.
- Run the **password history record number** command to set the maximum number of previously used passwords recorded for each user.

Precautions

After the **undo local-aaa-user password policy administrator** command is executed, the administrator password policy will be disabled, causing a security risk.

In V200R010C00 and later versions, when the device starts with the default configurations, it automatically performs the following configurations and saves the configurations to the configuration file:

- Run the **local-aaa-user password policy administrator** command to enable the password policy for local administrators.
- Run the **password expire 0** command to configure the passwords of local administrators to be permanently valid.
- Run the **password history record number 0** command to configure the device not to check whether a changed password of a local administrator is the same as any historical password.

Example

```
# Enable the local administrator password policy and enter the local administrator password policy view.
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] local-aaa-user password policy administrator
[HUAWEI-aaa-lupp-admin]
```

Related Topics

- [13.1.54 local-user](#)
- [13.1.67 password expire](#)
- [13.1.65 password alert before-expire](#)
- [13.1.66 password alert original](#)
- [13.1.68 password history record number](#)

13.1.61 local-user service-type

Function

The **local-user service-type** command sets the access type for a local user.

The **undo local-user service-type** command restores the default access type for a local user.

By default, a local user cannot use any access type.

Format

local-user *user-name* **service-type** { **8021x** | **api** | **ftp** | **http** | **ppp** | **ssh** | **telnet** | **terminal** | **web** | **x25-pad** } *

undo local-user *user-name* **service-type**

NOTE

Only the S5720EI, S5720HI, S6720EI, and S6720S-EI support the **api** parameter.

Parameters

Parameter	Description	Value
<i>user-name</i>	Specifies a user name. If the user name contains a domain name delimiter such as @, the character before @ is the user name and the character behind @ is the domain name. If the value does not contain @, the entire character string is the user name and the domain name is the default one.	The value is a string of 1 to 64 case-insensitive characters. It cannot contain spaces, asterisk, double quotation mark and question mark.
8021x	Indicates an 802.1X user.	-
api	Indicates an API user, which is typically used for NETCONF access. NOTE If the access type of a user is API, the user name cannot be set to root .	-
ftp	Indicates an FTP user.	-
http	Indicates an HTTP user, which is usually used for web system login.	-
ppp	Indicates a PPP user.	-
ssh	Indicates an SSH user.	-
telnet	Indicates a Telnet user, which is usually a network administrator.	-
terminal	Indicates a terminal user, which is usually a user connected using a console port.	-
web	Indicates a Portal authentication user.	-
x25-pad	Indicates an X25-PAD user. NOTE Currently, the device does not support X25-PAD.	-

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The device can manage access types of local users. After you specify the access type of a user, the user can successfully log in only when the configured access type is the same as the actual access type of the user.

Local users have the following access types:

- Administrative: api, FTP, HTTP, SSH, Telnet, x25-pad, and Terminal
- Common: 802.1X, ppp, and web

Precautions

- When MAC authentication users use AAA local authentication, the device does not match or check the access type of local users. However, the access type must be configured; otherwise, local authentication for MAC address authentication users fails.
- Security risks exist if the user login mode is set to Telnet or FTP. You are advised set the user login mode to STelnet or SFTP and set the user access type to SSH.

When a device starts without any configuration, HTTP uses the randomly generated self-signed certificate to support HTTPs. The self-signed certificate may bring risks. Therefore, you are advised to replace it with the officially authorized digital certificate.

- Common access types cannot be configured together with administrative access types.

The API access type cannot be configured together with other access types.

If a user has been created and the password uses an irreversible encryption algorithm, the access type can only be set to an administrative one.

If a user has been created and the password uses a reversible encryption algorithm, the access type can be set to an administrative or common one. When the access type is set to an administrative one, the encryption algorithm of the password is automatically converted into an irreversible encryption algorithm.

Example

Set the access type of the local user **user1@vipdomain** to SSH.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] local-user user1@vipdomain service-type ssh
```

Related Topics

[13.1.54 local-user](#)

[13.1.40 display local-user](#)

13.1.62 local-user time-range

Function

The **local-user time-range** command sets the access permission time range for a local user.

The **undo local-user time-range** command deletes the access permission time range for a local user.

By default, a local account can access the network anytime.

Format

local-user *user-name* **time-range** *time-name*

undo local-user *user-name* **time-range**

Parameters

Parameter	Description	Value
<i>user-name</i>	Indicates the local account.	The value is a string of 1 to 64 case-insensitive characters. It cannot contain spaces, asterisk, double quotation mark and question mark.
<i>time-name</i>	Indicates the access permission time range of the local account. <i>time-name</i> specifies the name of the access permission time range.	The value is a string of 1 to 32 case-sensitive characters and must begin with a letter. In addition, the word all cannot be specified as a time range name.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Use Scenario

After a local account is created, the account has no expiration date by default. To restrict the network access time of a local account, run the **local-user time-range**

command. After the command is executed, the account can access network resources only in the specified time range.

Prerequisite

The time range has been created using the [14.1.26 time-range](#) command.

Precautions

If you run the **local-user time-range** and [13.1.57 local-user expire-date](#) commands in the AAA view multiple times, only the latest configuration takes effect.

After the access permission time range of an online local user is changed, the access permission time range of the user will take effect only when the user goes online next time.

Example

Set the access permission time segment of local account hello@163.net to 9:00-18:00 from Monday to Friday.

```
<HUAWEI> system-view
[HUAWEI] time-range huawei 9:00 to 18:00 working-day
[HUAWEI] aaa
[HUAWEI-aaa] local-user hello@163.net time-range huawei
```

Related Topics

[13.1.40 display local-user](#)

13.1.63 local-user user-type netmanager

Function

The **local-user user-type netmanager** command configures a local user as the NMS user.

The **undo local-user user-type netmanager** command cancels to configure a local user as the NMS user.

By default, no local user is configured as the NMS user.

Format

local-user *user-name* **user-type netmanager**

undo local-user *user-name* **user-type netmanager**

Parameters

Parameter	Description	Value
<i>user-name</i>	Specifies a user name.	The value is a string of 1 to 64 case-insensitive characters. It cannot contain spaces, asterisk, double quotation mark and question mark.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

When a VTY user logging in to the device is an NMS user, you need to run this command to set the user type. When the number of login VTY users has reached the maximum, an NMS user can log in using the reserved VTY numbers 16-20. The NMS user is allowed to log in to the device only after passing the AAA local authentication.

Prerequisite

The local user has been created using the **local-user** command. This user must pass the AAA local authentication.

Example

```
# Configure the local user user1@vipdomain as the NMS user.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] local-user user1@vipdomain password cipher Huawei@1234  
[HUAWEI-aaa] local-user user1@vipdomain user-type netmanager
```

13.1.64 outbound recording-scheme

Function

The **outbound recording-scheme** command applies a policy to a recording scheme to record the connection information.

The **undo outbound recording-scheme** command deletes a policy from a recording scheme. Connection information is not recorded then.

By default, connection information is not recorded.

Format

outbound recording-scheme *recording-scheme-name*

undo outbound recording-scheme

Parameters

Parameter	Description	Value
<i>recording-scheme-name</i>	Specifies the name of a recording scheme.	The recording scheme must already exist.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

Incorrect connections may result in network faults, for example, loops. The connection information recorded on a server helps you monitor devices. When network faults occur, you can locate faults based on the connection information recorded on the server.

Prerequisites

A recording scheme has been created using the **recording-scheme** command in the AAA view and an HWTACACS server template has been associated with a recording scheme using the **recording-mode hwtacacs** command in the recording scheme view.

Example

Apply a policy to the recording scheme **scheme** to record the connection information.

```
<HUAWEI> system-view
[HUAWEI] hwtacacs-server template hw1
[HUAWEI-hwtacacs-hw1] quit
[HUAWEI] aaa
[HUAWEI-aaa] recording-scheme scheme
[HUAWEI-aaa-recording-scheme] recording-mode hwtacacs hw1
[HUAWEI-aaa-recording-scheme] quit
[HUAWEI-aaa] outbound recording-scheme scheme
```

Related Topics

[13.1.43 display recording-scheme](#)

[13.1.71 recording-scheme](#)

13.1.65 password alert before-expire

Function

The **password alert before-expire** command to set the password expiration prompt days.

The **undo password alert before-expire** command restores the default password expiration prompt days.

By default, the number of password expiration prompt days is 30 days.

Format

password alert before-expire *day*

undo password alert before-expire

Parameters

Parameter	Description	Value
<i>day</i>	Indicates how long the system displays a prompt before the password expires. If the value is set to 0, the device does not prompt users that the passwords will expire.	The value is an integer that ranges from 0 to 999, in days. The default value is 30.

Views

Local administrator password policy view

Default Level

3: Management level

Usage Guidelines

When a user logs in to the device, the device checks how many more days the password is valid for. If the number of days is less than the prompt days set in this command, the device notifies the user in how many days the password will expire and asks the user whether they want to change the password.

- If the user changes the password, the device records the new password and modification time.
- If the user does not change the password or fails to change the password, the user can still log in as long as the password has not expired.

Example

```
# Set the number of password expiration prompt days to 90.  
<HUAWEI> system-view  
[HUAWEI] aaa
```

[HUAWEI-aaa] local-aaa-user password policy administrator
[HUAWEI-aaa-lupp-admin] password alert before-expire 90

13.1.66 password alert original

Function

The **password alert original** command enables the device to prompt users to change initial passwords.

The **undo password alert original** command disables the device from prompting users to change initial passwords.

By default, the device prompts users to change initial passwords.

Format

password alert original

undo password alert original

Parameters

None

Views

Local administrator password policy view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To improve device security, use this command to enable the initial password change prompt function. When a user logs in to the device:

- If the user enters the initial password, the device displays a message to ask whether to change the initial password. The user can select **Y** or **N**:
 - If the user selects **Y** to change the password, the user needs to enter the old password, new password, and confirm password. The password can be successfully changed only when the old password is correct and the new password and confirm password are the same and meet requirements (password length and complexity). After the password is changed, the user can log in to the device successfully.
 - If the user selects **N** or fails to change the password, and the initial password is the default password, the device does not allow the user to log in. If the initial password is not the default password, the device allows the user to log in.
- If the entered password is not the initial password, the device does not display any message and the user can successfully log in.

After the **undo password alert original** command is executed, the initial password alert will be disabled, causing a security risk.

 **NOTE**

The initial password may be the default password, the password created by a local user in the first login, or the password changed by another user (for example, user B changes user A's password, and user A uses the changed password to log in. The device displays a prompt message in this situation).

Precautions

This function is only valid for Telnet users, SSH users, and terminal users.

Example

```
# Enable the device to prompt users to change initial passwords.
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] local-aaa-user password policy administrator
[HUAWEI-aaa-lupp-admin] password alert original
```

13.1.67 password expire

Function

The **password expire** command sets the password validity period.

The **undo password expire** command restores the default password validity period.

By default, the password validity period is 90 days.

Format

password expire *day*

undo password expire

Parameters

Parameter	Description	Value
<i>day</i>	Indicates the password validity period. If the value is 0, the password is permanently valid.	The value is an integer that ranges from 0 to 999, in days. The default value is 90.

Views

Local administrator password policy view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To improve password security, the administrator can use this command to set the validity period for local user's password. When the validity period expires, the password becomes invalid.

If the local user still uses this password to log in to the device, the device allows the user to log in, prompts the user that the password has expired, and asks the user whether to change the password:

- If the user selects **Y**, the user needs to enter the old password, new password, and confirm password. The password can be successfully changed only when the old password is correct and the new password and confirm password are the same and meet requirements (password length and complexity). After the password is changed, the user can log in to the device successfully.
- If the user selects **N** or fails to change the password, the user cannot log in.

Precautions

Changing the system time will affect the password validity status.

After this command is executed, the device checks whether the password expires every minute; therefore, there may be a time difference within 1 minute.

In V200R010C00 and later versions, when the device starts with the default configurations, it automatically performs the following configurations and saves the configurations to the configuration file:

- Run the **local-aaa-user password policy administrator** command to enable the password policy for local administrators.
- Run the **password expire 0** command to configure the passwords of local administrators to be permanently valid.
- Run the **password history record number 0** command to configure the device not to check whether a changed password of a local administrator is the same as any historical password.

Example

```
# Set the password validity period to 120 days.  
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] local-aaa-user password policy administrator  
[HUAWEI-aaa-lupp-admin] password expire 120
```

13.1.68 password history record number

Function

The **password history record number** command sets the maximum number of historical passwords recorded for each user.

The **undo password history record number** command restores the default maximum number of historical passwords recorded for each user.

By default, five historical passwords are recorded for each user.

Format

password history record number *number*

undo password history record number

Parameters

Parameter	Description	Value
<i>number</i>	Indicates the maximum number of historical passwords recorded for each user. If the value is set to 0, the device will not check whether a changed password is the same as any historical password.	The value is an integer that ranges from 0 to 12. The default value is 5.

Views

Local administrator password policy view, local access user password policy view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To improve password security, it is not recommended that you use a previously used password. You can set the maximum number of historical passwords recorded for each user. When a user changes the password, the device compares the new password against the historical passwords stored on the device. If the new password is the same as a stored password, the device displays an error message to prompt the user that password change fails.

Precautions

When the number of recorded historical passwords reaches the maximum value, the later password will overwrite the earliest password on the device.

After the historical password recording function is disabled, the device does not record historical passwords; however, the passwords that have been stored are not deleted.

In V200R010C00 and later versions, when the device starts with the default configurations, it automatically performs the following configurations and saves the configurations to the configuration file:

- Run the **local-aaa-user password policy administrator** command to enable the password policy for local administrators.
- Run the **password expire 0** command to configure the passwords of local administrators to be permanently valid.

- Run the **password history record number 0** command to configure the device not to check whether a changed password of a local administrator is the same as any historical password.

Example

```
# Set the maximum number of historical passwords recorded for each
administrator to 10.
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] local-aaa-user password policy administrator
[HUAWEI-aaa-lupp-admin] password history record number 10

# Set the maximum number of historical passwords recorded for each local access
user to 10.
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] local-aaa-user password policy access-user
[HUAWEI-aaa-lupp-acc] password history record number 10
```

13.1.69 permit-domain

Function

The **permit-domain** command specifies permitted domains for WLAN users.

The **undo permit-domain** command deletes the permitted domains of WLAN users.

By default, no permitted domain is specified for WLAN users.

NOTE

This function is supported only by S5720HI.

Format

permit-domain name *domain-name* &<1-4>

undo permit-domain { **name** *domain-name* | **all** }

Parameters

Item	Description	Value
name <i>domain-name</i>	Specifies the name of a permitted domain for WLAN users.	The domain must already exist.
all	Deletes the permitted domain for all WLAN users.	-

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a permitted domain is specified on an authentication profile, only the WLAN users in the permitted domain can be authenticated, authorized, or charged.

Prerequisites

Permitted domains have been created using the **domain** command.

Precautions

This command applies only to wireless users.

When this command is executed in the authentication profile, the configuration takes effect only after the authentication profile is bound to a VAP profile.

This command is only available in the NAC unified mode.

Example

Specify permitted domain **dom** for WLAN users to the authentication profile **john**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain dom
[HUAWEI-aaa-domain-dom] quit
[HUAWEI-aaa] quit
[HUAWEI] authentication-profile name john
[HUAWEI-authen-profile-john] permit-domain name dom
```

Related Topics

[13.1.47 domain \(AAA view\)](#)

13.1.70 recording-mode hwtacacs

Function

The **recording-mode hwtacacs** command associates an HWTACACS server template with a recording scheme.

The **undo recording-mode** command unbinds an HWTACACS server template from a recording scheme.

By default, no HWTACACS server template is associated with a recording scheme.

Format

recording-mode hwtacacs *template-name*

undo recording-mode

Parameters

Parameter	Description	Value
<i>template-name</i>	Specifies the name of an HWTACACS server template.	The HWTACACS server template must already exist.

Views

Recording scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The device needs to send the records such as the executed commands, connection information, and system events to the specified HWTACACS accounting server; therefore, an HWTACACS server template needs to be associated with a recording scheme.

Prerequisites

The HWTACACS server template has been created by using the [13.3.13 hwtacacs-server template](#) command.

Example

Associate the recording scheme **scheme0** with the HWTACACS server template **tacacs1**.

```
<HUAWEI> system-view
[HUAWEI] hwtacacs-server template tacacs1
[HUAWEI-hwtacacs-tacacs1] quit
[HUAWEI] aaa
[HUAWEI-aaa] recording-scheme scheme0
[HUAWEI-aaa-recording-scheme0] recording-mode hwtacacs tacacs1
```

Related Topics

[13.3.3 display hwtacacs-server template](#)

[13.1.43 display recording-scheme](#)

[13.3.13 hwtacacs-server template](#)

[13.1.71 recording-scheme](#)

13.1.71 recording-scheme

Function

The **recording-scheme** command creates a recording scheme and displays the recording scheme view.

The **undo recording-scheme** command deletes a recording scheme.

By default, no recording scheme is configured on the device.

Format

recording-scheme *recording-scheme-name*

undo recording-scheme *recording-scheme-name*

Parameters

Parameter	Description	Value
<i>recording-scheme-name</i>	Specifies the name of a recording scheme.	The value is a string of 1 to 32 case-sensitive characters. It cannot contain spaces or the following symbols: / \ : * ? " < > @ ' %. The value cannot be - or --.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After a recording scheme takes effect, you can view the records such as the executed commands, connection information, and system-level events on the recording server. The records help you locate network faults. Because a recording scheme needs to be associated with an HWTACACS server template, the recording scheme is configured only when HWTACACS authentication or authorization is performed.

Creating a recording template using the **recording-scheme** command is mandatory for configuration.

Follow-up Procedure

Run the **recording-mode hwtacacs** command to associate an HWTACACS server template with the recording scheme.

After a recording scheme is created and associated with an HWTACACS server template, perform the following configurations in the AAA view:

- Run the **cmd recording-scheme** command to apply a policy in a recording scheme to record the commands executed on the device.
- Run the **outbound recording-scheme** command to apply a policy in a recording scheme to record the connection information.
- Run the **system recording-scheme** command to apply a policy in a recording scheme to record the system events.

Precautions

If the recording scheme to be configured does not exist, the **recording-scheme** command creates a recording scheme and displays the recording scheme view. If the recording scheme to be configured already exists, the **recording-scheme** command displays the recording scheme view.

Before deleting a recording scheme, ensure that the scheme has not been referenced by the **cmd recording-scheme** or **outbound recording-scheme** or **system recording-scheme** command.

Example

```
# Create a recording scheme scheme0.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] recording-scheme scheme0  
[HUAWEI-aaa-recording-scheme0]
```

Related Topics

- [13.1.29 cmd recording-scheme](#)
- [13.1.43 display recording-scheme](#)
- [13.1.64 outbound recording-scheme](#)
- [13.1.70 recording-mode hwtacacs](#)
- [13.1.85 system recording-scheme](#)

13.1.72 redirect-acl

Function

The **redirect-acl** command configures the ACL used for redirection in a service scheme.

The **undo redirect-acl** command deletes the ACL used for redirection in a service scheme.

By default, no ACL for redirection is configured in the service scheme.

Format

```
redirect-acl { acl-number | name acl-name }
```

undo redirect-acl

Parameters

Parameter	Description	Value
<i>acl-number</i>	Specifies the number of the ACL used for redirection.	The value ranges from 3000 to 3999 for wired users and from 3000 to 3031 for wireless users, and it must exist.
name <i>acl-name</i>	Specifies the name of the ACL used for redirection.	The ACL name must exist. The length ranges from 1 to 64.

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

In some authentication scenarios, after users succeed in authentication, the administrator needs to redirect HTTP/HTTPS traffic matching ACL permit rules to the Portal authentication page where users are authenticated again.

Precautions

Before running this command, you are advised to run the [14.1.5 acl \(system view\)](#) or [14.1.4 acl name](#) command to create an ACL.

If the ACL is not created before and after this command is run, the redirection ACL will fail to be delivered.

To redirect HTTPS traffic, run the [13.4.142 portal https-redirect enable](#) command to configure the HTTPS redirection function.

Example

Configure ACL 3001 for redirection in the service scheme **svcscheme1**.

```
<HUAWEI> system-view
[HUAWEI] acl 3001
[HUAWEI-acl-adv-3001] quit
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme svcscheme1
[HUAWEI-aaa-service-svcscheme1] redirect-acl 3001
```

Related Topics

[13.1.45 display service-scheme](#)

13.1.73 remote-aaa-user authen-fail

Function

The **remote-aaa-user authen-fail** command enables the remote AAA authentication account locking function, and sets the authentication retry interval, maximum number of consecutive authentication failures, and account locking period.

The **undo remote-aaa-user authen-fail** command disables the remote AAA authentication account locking function.

By default, the remote AAA account locking function is enabled, authentication retry interval is 30 minutes, maximum number of consecutive authentication failures is 30, and account locking period is 30 minutes.

Format

remote-aaa-user authen-fail retry-interval *retry-interval* **retry-time** *retry-time*
block-time *block-time*

undo remote-aaa-user authen-fail

Parameters

Parameter	Description	Value
retry-interval <i>retry-interval</i>	Specifies the authentication retry interval.	The value is an integer that ranges from 5 to 65535, in minutes.
retry-time <i>retry-time</i>	Specifies the maximum number of consecutive authentication failures.	The value is an integer that ranges from 3 to 65535.
block-time <i>block-time</i>	Specifies the account locking period.	The value is an integer that ranges from 5 to 65535, in minutes.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To ensure account security, you can enable the device to lock the accounts that fail in remote AAA authentication. If a user enters incorrect account and password

more than the maximum number of consecutive authentication failures within the given period, the account is locked. After a certain period, the account is unlocked.

Precautions

- This command is valid only for remote AAA authentication and is invalid for local authentication.
- In scenarios where an active/standby switchover is performed, the originally locked account is automatically unlocked.
- After the remote AAA authentication account locking function is disabled using the **undo remote-aaa-user authen-fail** command, the originally locked account is automatically unlocked.

Example

```
# Enable the remote AAA account locking function, and set the authentication  
retry interval to 5 minutes, maximum number of consecutive authentication  
failures to 3, and account locking period to 5 minutes.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] remote-aaa-user authen-fail retry-interval 5 retry-time 3 block-time 5
```

Related Topics

[13.1.44 display remote-user authen-fail](#)

[13.1.74 remote-user authen-fail unblock](#)

13.1.74 remote-user authen-fail unblock

Function

The **remote-user authen-fail unblock** command unlocks remote AAA authentication accounts.

Format

```
remote-user authen-fail unblock { all | username username }
```

Parameters

Parameter	Description	Value
all	Unlocks all accounts that fail the remote AAA authentication.	-
username <i>username</i>	Unlocks a specified account that fails the remote AAA authentication.	The value is a string of 1 to 253 case-insensitive characters without spaces.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

You may need to unlock remote AAA authentication accounts in the following situations:

- When a user enters an incorrect user name or password fewer times than the maximum permitted, run the **remote-user authen-fail unblock** command to unlock the user and delete the incorrect record of the user from the device.
- When a user is incorrectly locked or needs to be unlocked due to special reasons, run the **remote-user authen-fail unblock** command to unlock the user.

Example

Unlock the remote AAA authentication account **test**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] remote-user authen-fail unblock username test
```

Related Topics

[13.1.44 display remote-user authen-fail](#)

13.1.75 reset aaa

Function

Using the **reset aaa** command, you can clear records of abnormal offline, user offline and failure to get online.

Format

reset aaa { **abnormal-offline-record** | **offline-record** | **online-fail-record** }

Parameters

Parameter	Description	Value
abnormal-offline-record	Clears records of user abnormal offline.	-
offline-record	Clears records of user offline.	-
online-fail-record	Clears records of user failure to get online.	-

Views

System view

Default Level

3: Management level

Usage Guidelines

This command allows you to clear records of user offline, abnormal offline, and failure to get online. After the records are cleared, the function of recording information is enabled.

Example

Clear user offline records.

```
<HUAWEI> system-view  
[HUAWEI] reset aaa offline-record
```

13.1.76 reset aaa statistics offline-reason

Function

Using the **reset aaa statistics offline-reason** command, you can clear the statistics about reasons why users go offline.

Format

```
reset aaa statistics offline-reason
```

Parameters

None

Views

All views

Default Level

3: Management level

Usage Guidelines

You can use the **reset aaa statistics offline-reason** command to delete the statistics about reasons why users go offline, and then collect new statistics.

Example

Clear the statistics about reasons why users go offline.

```
<HUAWEI> reset aaa statistics offline-reason
```

13.1.77 reset access-user statistics

Function

The **reset access-user statistics** command deletes the statistics on access user authentication.

Format

```
reset access-user statistics
```

Parameters

None

Views

All views

Default Level

3: Management level

Usage Guidelines

When diagnosing and locating faults related to access user authentication, you need to collect statistics on user login and logout information within a period of time. Before the statistics collection, you can run the **reset access-user statistics** command to clear the historical statistics, and then run the **display access-user statistics** command to view the current statistics.

Example

```
# Delete the statistics on access user authentication.
```

```
<HUAWEI> reset access-user statistics
```

13.1.78 reset local-user password history record

Function

The **reset local-user password history record** command clears historical passwords stored for the local user.

Format

```
reset local-user [ user-name ] password history record
```

Parameters

Parameter	Description	Value
<i>user-name</i>	<p>Clears the historical passwords of the specified user.</p> <p>If this parameter is not specified, the historical passwords of all local users are cleared.</p>	The local user must exist on the device.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

If the administrator wants to record historical passwords of local users again, this command can be used to clear existing historical passwords.

Precautions

After this command is used, all historical passwords on the device are deleted and cannot be restored. This operation has security risks, so exercise caution when using it.

Example

Clear historical passwords of all local users.

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] reset local-user password history record
```

Related Topics

[13.1.68 password history record number](#)

13.1.79 security-name enable

Function

The **security-name enable** command enables the security string function.

The **undo security-name enable** command disables the security string function.

By default, the security string function is enabled.

NOTE

This function is supported only by S5720HI.

Format

security-name enable
undo security-name enable

Parameters

None

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Some special clients use user names in the format of **username@domain*securitystring** in which a security string and a security string delimiter (*) are added to the user name. To ensure that the AAA server can identify such user names, run the **security-name enable** command to enable the security string function on the device. When sending a user name to the AAA server, the device deletes ***securitystring** and only uses **username@domain** for authentication.

You can run the [13.1.80 security-name-delimiter](#) command to modify the security string delimiter.

Example

Enable the security string function.

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] security-name enable
```

13.1.80 security-name-delimiter

Function

The **security-name-delimiter** command configures a delimiter for a security string.

The **undo security-name-delimiter** command restores the default delimiter for a security string.

By default, the delimiter for a security string in the AAA view is *, and no delimiter is available in the authentication profile view.

 NOTE

This command only applies to 802.1X users. If the CHAP or PAP authentication is configured for 802.1X users, the device removes the security string, but does not encapsulate it into the HW-SecurityStr attribute. If the EAP authentication is configured for 802.1X users, the device removes the security string and encapsulates it into the HW-SecurityStr attribute.

This function is supported only by S5720HI.

Format

security-name-delimiter *delimiter*

undo security-name-delimiter

Parameters

Parameter	Description	Value
<i>delimiter</i>	Specifies a delimiter for a security string.	The value is \ / : < > @ ' % or *.

Views

AAA view, authentication profile view

Default Level

In the AAA view, the default level is management level.

In the authentication profile view, the default level is configuration level.

Usage Guidelines

Usage Scenario

Some STAs may use the user name in the format of **username@domain*securitystring**. * is the security string delimiter. To enable the AAA server to identify this type of user name, you need to configure a delimiter for a security string on the device. In this way, when sending the user name to the AAA server, the device deletes the ***securitystring** and only uses **username@domain** for authentication.

Precautions

When the command is executed in the AAA view, the configuration takes effect for all users. When the command is executed in the authentication profile, the configuration takes effect for only the users connected to this authentication profile.

The delimiter for a security string cannot be the same as the domain name delimiter.

If you run the **security-name-delimiter** command in the AAA view, the delimiter for a security string is configured globally.

When this command is executed in the authentication profile, the configuration takes effect only after the authentication profile is bound to a VAP profile.

Example

Configure the delimiter for a security string as / in the AAA view.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] security-name-delimiter /
```

13.1.81 service-scheme (aaa domain view)

Function

The **service-scheme** command applies a service scheme to a domain.

The **undo service-scheme** command unbinds a service scheme from a domain.

By default, no service scheme is bound to a domain.

Format

service-scheme *service-scheme-name*

undo service-scheme

Parameters

Parameter	Description	Value
<i>service-scheme-name</i>	Specifies the name of a service scheme.	The value must be an existing service scheme name.

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The authorization configuration in a service scheme takes effect only when the service scheme is applied to a domain.

Prerequisites

A service scheme has been created and configured with required parameters.

Example

Apply the service scheme **srvscheme1** to the domain **huawei**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme srvscheme1
[HUAWEI-aaa-service-srvscheme1] quit
[HUAWEI-aaa] domain huawei
[HUAWEI-aaa-domain-huawei] service-scheme srvscheme1
```

Related Topics

[13.1.45 display service-scheme](#)

[13.1.82 service-scheme \(AAA view\)](#)

13.1.82 service-scheme (AAA view)

Function

The **service-scheme** command creates a service scheme and displays the service scheme view.

The **undo service-scheme** command deletes a service scheme.

By default, no service scheme is configured.

Format

service-scheme *service-scheme-name*

undo service-scheme *service-scheme-name*

Parameters

Parameter	Description	Value
<i>service-scheme-name</i>	Specifies the name of a service scheme.	The value is a string of 1 to 32 case-sensitive characters. It cannot contain spaces or the following symbols: /, \, ;, *, ?, ", <, >, , @, ', and %. The value cannot be - or --.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The service scheme is used to assign IP address pool and DNS server parameters to users.

Follow-up Procedure

Run the [service-scheme \(AAA domain view\)](#) command to apply the service scheme to a domain.

Precautions

In traditional NAC mode, the authorization scheme is not supported.

If the service scheme to be configured does not exist, the [service-scheme \(AAA view\)](#) command creates a service scheme and displays the service scheme view. If the service scheme to be configured already exists, the [service-scheme \(AAA view\)](#) command displays the service scheme view.

To delete or modify the service scheme applied to a domain, run the [undo service-scheme \(AAA domain view\)](#) command to unbind the service scheme from the domain.

Example

```
# Create a service scheme srvscheme1.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] service-scheme srvscheme1  
[HUAWEI-aaa-service-srvscheme1]
```

Related Topics

[13.1.45 display service-scheme](#)

[13.1.81 service-scheme \(aaa domain view\)](#)

13.1.83 state (AAA domain view)

Function

The **state** command configures the state of a domain.

The **undo state** command restores the state of a domain.

By default, a domain is in active state after being created.

Format

```
state { active | block [ time-range time-name &<1-4> ] }
```

```
undo state [ block time-range [ time-name &<1-4> ] ]
```

Parameters

Parameter	Description	Value
active	Sets the domain state to active.	-
block	Sets the domain state to blocking.	-
time-range <i>time-name</i>	Indicates the block time range of the domain. <i>time-name</i> specifies the name of the block time range. If this parameter is not specified, the domain is always blocked.	The value is a string of 1 to 32 case-sensitive characters and must begin with a letter. In addition, the word all cannot be specified as a time range name.

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

If exceptions occur during service configuration, set the domain in blocking state to block access of new users. After the service configuration is complete, set the domain in active state.

Prerequisite

Before specifying the *time-name* parameter, ensure that the time range has been created using the [14.1.26 time-range](#) command.

Precautions

After the **state block** command is run to set the domain state to block, online users in the domain are not affected.

After the **state block time-range** command is run to set the state of a domain including online users to block, the domain state turns from active to block within the specified time range, and online users are forced to go offline.

Example

```
# Set the state of the domain vipdomain to blocking.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa
```

```
[HUAWEI-aaa] domain vipdomain  
[HUAWEI-aaa-domain-vipdomain] state block
```

Set the name of the time range in which the **vipdomain** domain state turns to block to **tim**.

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] domain vipdomain  
[HUAWEI-aaa-domain-vipdomain] state block time-range tim  
Warning: This operation may cause online users to go offline. Continue? [Y/N]Y
```

Related Topics

[13.1.47 domain \(AAA view\)](#)

13.1.84 statistic enable (AAA domain view)

Function

The **statistic enable** command enables traffic statistics collection for domain users.

The **undo statistic enable** command disables traffic statistics collection for domain users.

By default, traffic statistics collection is disabled for domain users.

NOTE

On the S1720GW-E, S1720GWR-E, S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S5700-10P-LI, S5700LI, S5700S-LI, S5720LI, and S5720S-LI, after an authentication profile in **multi-share** mode is applied to an Eth-Trunk interface, the device does not support the collection of statistics about both IPv4 and IPv6 upstream and downstream traffic for the users bound to the authentication profile.

Only the S5720EI, S1720GF, S1720GFR-P, S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S5700-10P-LI, S5700LI, S5700S-LI, S5720HI, S5720LI, S5720S-LI, S6720EI, and S6720S-EI support this command.

Format

statistic enable

undo statistic enable

Parameters

None

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To implement traffic-based accounting, you can use this command to enable traffic statistics collection for a domain. Then the device collects traffic statistics for the users in the domain. If an accounting server is configured, the device sends traffic statistics to the accounting server through accounting packets so that the server performs accounting for the users based on traffic statistics.

Follow-up Procedure

Run the [13.1.34 display access-user \(All views\)](#) command to view traffic statistics of users.

Precautions

This command collects service statistics for domain users. The device sends the statistics to the accounting server.

On the S5700LI, S5700S-LI, S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S5720LI, and S5720S-LI:

- This statistics collection function is only available for 802.1X authentication users.
- Traffic statistics are collected based on interfaces.
- The traffic statistics collection is valid for domain users only when interfaces are physical interface and each interface connects to only one domain user.
- The interface traffic statistics for the first 15s when a user goes online are not collected.
- When users are online, you cannot run the [reset_counters_interface](#) command to clear interface traffic statistics. Otherwise, the user traffic statistics are inaccurate.

After this command is run, the device does not collect IPv6 traffic statistics for users. To enable IPv6 statistics collection, run the [authentication ipv6-statistics enable](#) command.

Example

```
# Enable traffic statistics collection for domain users.
```

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] domain huawei  
[HUAWEI-aaa-domain-huawei] statistic enable
```

Related Topics

[13.1.39 display domain](#)

13.1.85 system recording-scheme

Function

The **system recording-scheme** command applies a policy in a recording scheme to record the system events.

The **undo system recording-scheme** command deletes a policy from a recording scheme. System events are not recorded then.

By default, system events are not recorded.

Format

system recording-scheme *recording-scheme-name*

undo system recording-scheme

Parameters

Parameter	Description	Value
<i>recording-scheme-name</i>	Specifies the name of a recording scheme.	The recording scheme must already exist.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The system events recorded on an HWTACACS server helps you monitor devices. When network faults occur, you can isolate faults based on the system events recorded on the HWTACACS server.

Prerequisites

A recording scheme has been created using the **recording-scheme** command in the AAA view and an HWTACACS server template has been associated with a recording scheme using the **recording-mode hwtacacs** command in the recording scheme view.

Precautions

Currently, the device can record only the events caused by the **reboot** command.

Example

Apply a policy in the recording scheme **scheme** to record the system events.

```
<HUAWEI> system-view
[HUAWEI] hwtacacs-server template hw1
[HUAWEI-hwtacacs-hw1] quit
[HUAWEI] aaa
[HUAWEI-aaa] recording-scheme scheme
[HUAWEI-aaa-recording-scheme] recording-mode hwtacacs hw1
```

```
[HUAWEI-aaa-recording-scheme] quit  
[HUAWEI-aaa] system recording-scheme scheme
```

Related Topics

[13.1.43 display recording-scheme](#)

[13.1.71 recording-scheme](#)

13.1.86 user-group (AAA domain view)

Function

The **user-group** command binds the users in a domain to the authorization information of a user group.

The **undo user-group** command unbinds the users in a domain from the authorization information of a user group.

By default, no authorization information of a user group is bound to the users in a domain.

NOTE

This command is supported only in the NAC common mode.

Format

user-group *group-name*

undo user-group

Parameters

Parameter	Description	Value
<i>group-name</i>	Specifies the name of a user group.	The user group name must already exist.

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

You can run the **user-group** command in the AAA domain to bind the users in a domain to the authorization information of a user group.

Precautions

- The user group to be specified using the **local-user user-group** command must have been created using the **user-group** command.
- A user group cannot be deleted after being referenced to a domain using this command.
- Huawei proprietary attribute 82 delivered by RADIUS cannot be used together with the function of binding authentication information of a user group to a domain.
- The priority of the authorization information delivered using this command is lower than that of the authorization information delivered using the **portal free-rule rule-id source ip ip-address mask { mask-length | ip-mask } [mac mac-address] [interface interface-type interface-number] destination user-group group-name** command.

Example

Bind the user group **group1** to the domain **test**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain test
[HUAWEI-aaa-domain-test] user-group group1
```

Related Topics

- [13.5.156 user-group](#)
- [13.5.157 user-group enable](#)

13.1.87 user-password complexity-check

Function

The **user-password complexity-check** command enables password complexity check.

The **undo user-password complexity-check** command disables password complexity check.

By default, a device checks password complexity.

Format

user-password complexity-check
undo user-password complexity-check

Parameters

None

Views

AAA view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

In the versions earlier than V200R003, the device uses simple user name and password rules, so the user names and passwords are easy to manage and remember; however, weak passwords have security risks. In V200R003 and later versions, the device poses stricter requirements on user names and passwords. After you create a local user by using the **local-user** command, the password must pass a complexity check performed by the device.

In V200R005 and later versions, you can choose whether to enable password complexity check.

Precautions

To ensure device security, do not disable password complexity check, and change the password periodically.

Example

Disable password complexity check.

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] undo user-password complexity-check
```

Related Topics

[13.1.54 local-user](#)

13.2 RADIUS Configuration Commands

[13.2.1 Command Support](#)

[13.2.2 called-station-id mac-format](#)

[13.2.3 calling-station-id mac-format](#)

[13.2.4 display radius-attribute](#)

[13.2.5 display radius-attribute check](#)

[13.2.6 display radius-attribute disable](#)

[13.2.7 display radius-attribute translate](#)

[13.2.8 display radius-server accounting-stop-packet](#)

[13.2.9 display radius-server authorization configuration](#)

[13.2.10 display radius-server configuration](#)

[13.2.11 display radius-server dead-interval dead-count](#)

- [13.2.12 display radius-server item](#)
- [13.2.13 display radius-server session-manage configuration](#)
- [13.2.14 display snmp-agent trap feature-name radius all](#)
- [13.2.15 radius-attribute check](#)
- [13.2.16 radius-attribute disable](#)
- [13.2.17 radius-attribute nas-ip](#)
- [13.2.18 radius-attribute nas-ipv6](#)
- [13.2.19 radius-attribute service-type with-authenonly-reauthen](#)
- [13.2.20 radius-attribute set](#)
- [13.2.21 radius-attribute translate](#)
- [13.2.22 radius-server \(aaa domain view\)](#)
- [13.2.23 radius-server accounting](#)
- [13.2.24 radius-server accounting-stop-packet resend](#)
- [13.2.25 radius-server algorithm](#)
- [13.2.26 radius-server attribute message-authenticator access-request](#)
- [13.2.27 radius-server attribute translate](#)
- [13.2.28 radius-server authentication](#)
- [13.2.29 radius-server authorization](#)
- [13.2.30 radius-server authorization attribute-decode-sameastemplate](#)
- [13.2.31 radius-server authorization calling-station-id decode-mac-format](#)
- [13.2.32 radius-server dead-detect-condition by-server-ip](#)
- [13.2.33 radius-server dead-interval dead-count](#)
- [13.2.34 radius-server detect-server interval](#)
- [13.2.35 radius-server format-attribute](#)
- [13.2.36 radius-server hw-ap-info-format include-ap-ip](#)
- [13.2.37 radius-server hw-dhcp-option-format](#)
- [13.2.38 radius-server nas-identifier-format](#)
- [13.2.39 radius-server nas-port-format](#)
- [13.2.40 radius-server nas-port-id-format](#)
- [13.2.41 radius-server retransmit timeout dead-time](#)
- [13.2.42 radius-server session-manage](#)
- [13.2.43 radius-server shared-key \(RADIUS server template view\)](#)
- [13.2.44 radius-server shared-key \(system view\)](#)

[13.2.45 radius-server template](#)

[13.2.46 radius-server testuser](#)

[13.2.47 radius-server traffic-unit](#)

[13.2.48 radius-server user-name domain-included](#)

[13.2.49 reset radius-server accounting-stop-packet](#)

[13.2.50 snmp-agent trap enable feature-name radius](#)

[13.2.51 test-aaa](#)

13.2.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

13.2.2 called-station-id mac-format

Function

The **called-station-id mac-format** command sets the encapsulation format of the MAC address in the called-station-id (Type 30) attribute of RADIUS packets.

The **undo called-station-id mac-format** command restores the default encapsulation format of the MAC address in the called-station-id attribute of RADIUS packets.

By default, the encapsulation format of the MAC address in the called-station-id attribute of RADIUS packets is XX-XX-XX-XX-XX-XX, in uppercase.

Format

```
called-station-id mac-format { dot-split | hyphen-split } [ mode1 | mode2 ]  
[ lowercase | uppercase ]
```

```
called-station-id mac-format unformatted [ lowercase | uppercase ]
```

```
undo called-station-id mac-format
```

Parameters

Parameter	Description	Value
dot-split	Indicates that the dot (.) is used as the separator in a MAC address.	-
hyphen-split	Indicates that the hyphen (-) is used as the separator in a MAC address.	-
unformatted	Indicates that no separator is used in a MAC address.	-

Parameter	Description	Value
mode1	Indicates that the MAC address in the called-station-id attribute uses the XXXX-XXXX-XXXX or XXXX.XXXX.XXXX format.	-
mode2	Indicates that the MAC address in the called-station-id attribute uses the XX-XX-XX-XX-XX-XX or XX.XX.XX.XX.XX.XX format.	-
lowercase	Indicates that the MAC address in the called-station-id attribute uses the lowercase.	-
uppercase	Indicates that the MAC address in the called-station-id attribute uses the uppercase.	-

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

The Called-station-id (Type 30) attribute indicates the MAC address and SSID of an AP. The default format of the MAC address in the called-station-id attribute of RADIUS packets from the device is XX-XX-XX-XX-XX-XX. If the RADIUS server does not support the default format, run the **called-station-id mac-format** command to change the format.

Example

Set the dot as the separator in a MAC address and the encapsulation format of the MAC address in the called-station-id attribute to XX.XX.XX.XX.XX.XX in uppercase.

```
<HUAWEI> system-view
[HUAWEI] radius-server template huawei
[HUAWEI-radius-huawei] called-station-id mac-format dot-split mode2 uppercase
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.3 calling-station-id mac-format

Function

The **calling-station-id mac-format** command sets the encapsulation format of the MAC address in the calling-station-id (Type 31) attribute of RADIUS packets.

The **undo calling-station-id mac-format** command restores the default encapsulation format of the MAC address in the calling-station-id attribute of RADIUS packets.

By default, the encapsulation format of the MAC address in the calling-station-id attribute of RADIUS packets is xxxx-xxxx-xxxx, in lowercase.

Format

calling-station-id mac-format { dot-split | hyphen-split | colon-split } [mode1 | mode2] [lowercase | uppercase]

calling-station-id mac-format unformatted [lowercase | uppercase]

calling-station-id mac-format bin

undo calling-station-id mac-format

Parameters

Parameter	Description	Value
dot-split	Indicates that the dot (.) is used as the separator in a MAC address.	-
hyphen-split	Indicates that the hyphen (-) is used as the separator in a MAC address.	-
colon-split	Indicates that the colon (:) is used as the separator in a MAC address.	-
unformatted	Indicates that no separator is used in a MAC address.	-
mode1	Indicates that the MAC address in the calling-station-id attribute uses the "xxxxseparatorxxxxseparatorxxxx" format.	-
mode2	Indicates that the MAC address in the calling-station-id attribute uses the "xxseparatorxxseparatorxxseparatorxxseparatorxxseparatorxx" format.	-
lowercase	Indicates that the MAC address in the calling-station-id attribute uses the lowercase.	-
uppercase	Indicates that the MAC address in the calling-station-id attribute uses the uppercase.	-
bin	Indicates that the MAC address in the calling-station-id attribute uses the binary form.	-

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

The default format of the MAC address in the calling-station-id (Type 31) attribute of RADIUS packets from the device is xxxx-xxxx-xxxx. If the RADIUS server does not support the default format, run the **calling-station-id mac-format** command to change the format.

Example

Set the dot as the separator in a MAC address and the encapsulation format of the MAC address in the calling-station-id attribute to XX.XX.XX.XX.XX.XX in uppercase.

```
<HUAWEI> system-view
[HUAWEI] radius-server template huawei
[HUAWEI-radius-huawei] calling-station-id mac-format dot-split mode2 uppercase
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.4 display radius-attribute

Function

The **display radius-attribute** command displays the RADIUS attributes supported by the device.

Format

```
display radius-attribute [ name attribute-name | type { attribute-number1 | huawei attribute-number2 | microsoft attribute-number3 | dslforum attribute-number4 } ]
```

Parameters

Parameter	Description	Value
name <i>attribute-name</i>	Displays a specified RADIUS attribute.	The value is a string of 1 to 64 characters. After the name is entered, the system automatically associates the RADIUS attribute with the name.

Parameter	Description	Value
type { <i>attribute-number1</i> huawei <i>attribute-number2</i> microsoft <i>attribute-number3</i> dslforum <i>attribute-number4</i> }	Displays the RADIUS attribute of a specified type: <ul style="list-style-type: none"> • <i>attribute-number1</i> specifies the standard attribute. • huawei <i>attribute-number2</i> specifies a Huawei attribute. • microsoft <i>attribute-number3</i> specifies a Microsoft attribute. • dslforum <i>attribute-number4</i> specifies a Digital Subscriber Line Forum attribute. 	The value of <i>attribute-number1</i> , <i>attribute-number2</i> , <i>attribute-number3</i> , or <i>attribute-number4</i> is an integer that ranges from 1 to 2048.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Before connecting the device to a RADIUS server, run the **display radius-attribute** command to view the RADIUS attributes supported by the device. If the device and RADIUS server support different RADIUS attributes according to the command output, run the [13.2.16 radius-attribute disable](#) command on the device to disable RADIUS attributes that are not supported by the RADIUS server or run the [13.2.21 radius-attribute translate](#) command to translate RADIUS attributes.

Example

Display the RADIUS attributes supported by the device.

```
<HUAWEI> display radius-attribute
Codes: Auth(Authentication), Acct(Accounting)
      Req(Request), Accp(Accept), Rej(Reject)
      Resp(Response), COA(Change-of-Authorization)
      0(Can not exist in this packet)
      1(Can exist in this packet)
-----
Attribute      Service  Auth Auth Auth Acct Acct COA COA
Name(Type)     Type    Req  Accp Rej  Req  Resp Req Ack
-----
User-Name(1)   All     1   0   0   1   0   1   1
User-Password(2) All     1   0   0   0   0   0   0
CHAP-Password(3) All     1   0   0   0   0   0   0
```



```
NAS-IP-Address(4)    All    1  0  0  1  0  1  1
NAS-Port(5)         All    1  0  0  1  0  1  1
Service-Type(6)     All    1  1  0  0  0  0  0
.....
```

 **NOTE**

The preceding information is an example. The displayed attribute type depends on the actual situation.

Table 13-19 Description of the **display radius-attribute** command output

Item	Description
0(Can not exist in this packet)	Attribute not supported in packets.
1(Can exist in this packet)	Attribute supported in packets.
Attribute Name(Type)	Attribute name and type.
Service Type	Protocol type of the attribute.
Auth Req	Authentication request packet.
Auth Accp	Authentication accept packet.
Auth Rej	Authentication reject packet.
Acct Req	Accounting request packet.
Acct Resp	Accounting response packet.
COA Req	Change of Authorization (COA) request packet.
COA Ack	COA acknowledgement packet.

Display the RADIUS attribute numbered 2.

```
<HUAWEI> display radius-attribute type 2
Radius Attribute Type      : 2
Radius Attribute Name     : User-Password
Radius Attribute Description : This Attribute indicates the password of the user to be authenticated. Only
valid for the PAP authentication.
Supported Packets         : Auth Request
```

Table 13-20 Description of the **display radius-attribute type** command output

Item	Description
Radius Attribute Type	Type of the RADIUS attribute.
Radius Attribute Name	Name of the RADIUS attribute.
Radius Attribute Description	Description of the RADIUS attribute.
Supported Packets	Packets that support the RADIUS attribute.

Related Topics

[13.2.16 radius-attribute disable](#)

[13.2.21 radius-attribute translate](#)

13.2.5 display radius-attribute check

Function

The **display radius-attribute check** command displays the attributes to be checked in RADIUS Access-Accept packets.

Format

display radius-attribute [template *template-name*] check

Parameters

Parameter	Description	Value
template <i>template-name</i>	Displays the RADIUS attribute check configuration of a specified RADIUS server template.	The RADIUS server template must already exist.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After the **radius-attribute check** command is executed to configure the attributes to be checked in RADIUS Access-Accept packets, you can use the **display radius-attribute check** command to view these attributes.

Example

```
# Check the attributes to be checked in RADIUS Access-Accept packets.
```

```
<HUAWEI> display radius-attribute check
Server-template-name: test1
-----
check-attr
-----
Framed-Protocol
-----
```

Table 13-21 Description of the **display radius-attribute check** command output

Item	Description
Server-template-name	Name of the RADIUS server template.
check-attr	Attributes to be checked in RADIUS Access-Accept packets.
Framed-Protocol	Encapsulation protocol for services of the Frame type.

Related Topics

[13.2.15 radius-attribute check](#)

13.2.6 display radius-attribute disable

Function

The **display radius-attribute disable** command displays the disabled RADIUS attributes.

Format

display radius-attribute [template *template-name*] disable

Parameters

Parameter	Description	Value
template <i>template-name</i>	Displays the disabled RADIUS attributes in a specified RADIUS server template. If this parameter is not specified, the disabled RADIUS attributes in all the RADIUS server templates are displayed.	The value must be an existing RADIUS server template name.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can use the **display radius-attribute disable** command to view the RADIUS attributes disabled by using the **radius-attribute disable** command.

To enable a RADIUS attribute, run the **undo radius-attribute disable** command in the RADIUS server template view.

Example

Display the disabled RADIUS attributes on the device.

```
<HUAWEI> display radius-attribute disable
Packet-Type: Type of the RADIUS packets to be modified. 1 indicates valid; 0 indicates invalid. Bit 1 to bit 4 indicate the authentication request, authentication accept, accounting request, and accounting response packets.

Server-template-name: d
-----
Source-Vendor-ID Source-Sub-ID Dest-Vendor-ID Dest-Sub-ID Direct Packet-Type
-----
0          7          0          0          send    0 0 0 0
-----
```

Table 13-22 Description of the display radius-attribute disable command output

Item	Description
Server-template-name	RADIUS server template name.
Source-Vendor-ID	Vendor ID of the source attribute.
Source-Sub-ID	ID of the source attribute's sub-attribute.
Dest-Vendor-ID	Vendor ID of the destination attribute.
Dest-Sub-ID	ID of the destination attribute's sub-attribute.
Direct	Direction in which the attribute is translated. <ul style="list-style-type: none"> ● receive: Translates RADIUS attributes for received packets. ● send: Translates RADIUS attributes for sent packets.
Packet-Type	Type of RADIUS packets. <ul style="list-style-type: none"> ● 0: The RADIUS attributes of this type of packets are not translated. ● 1: The RADIUS attributes of this type of packets are translated.

Related Topics

[13.2.16 radius-attribute disable](#)

13.2.7 display radius-attribute translate

Function

The **display radius-attribute translate** command displays the RADIUS attribute translation configuration.

Format

display radius-attribute [**template** *template-name*] **translate**

Parameters

Parameter	Description	Value
template <i>template-name</i>	Displays the RADIUS attribute translation configuration of a specified RADIUS server template. <i>template-name</i> specifies the name of the RADIUS server template that is created using the radius-server template command. If this parameter is not specified, the disabled RADIUS attributes translation configuration in all the RADIUS server templates are displayed.	The value must be an existing RADIUS server template name.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After running the **radius-attribute translate** command to configure the device to translate RADIUS attributes, run the **display radius-attribute translate** command to check the configuration.

Example

```
# Display the RADIUS attribute translation configuration.
```

```
<HUAWEI> display radius-attribute translate  
Packet-Type: Type of the RADIUS packets to be modified. 1 indicates valid; 0 indicates invalid. Bit 1 to bit 4
```

indicate the authentication request, authentication accept, accounting request, and accounting response packets.

```
Server-template-name: rds
-----
Source-Vendor-ID Source-Sub-ID Dest-Vendor-ID Dest-Sub-ID Direct Packet-Type
-----
0          6          0          40      receive  0 0 0 0
-----
Server-template-name: eee
-----
Source-Vendor-ID Source-Sub-ID Dest-Vendor-ID Dest-Sub-ID Direct Packet-Type
-----
234567      123       2011       20      --      0 1 0 1
-----
```

Table 13-23 Description of the **display radius-attribute translate** command output

Item	Description
Server-template-name	Server template name.
Source-Vendor-ID	Vendor ID of the source attribute.
Source-Sub-ID	ID of the source attribute's sub-attribute.
Dest-Vendor-ID	Vendor ID of the destination attribute.
Dest-Sub-ID	ID of the destination attribute's sub-attribute.
Direct	Direction in which the attribute is translated. <ul style="list-style-type: none"> ● receive: Translates RADIUS attributes for received packets. ● send: Translates RADIUS attributes for sent packets.
Packet-Type	Type of RADIUS packets. <ul style="list-style-type: none"> ● 0: The RADIUS attributes of this type of packets are not translated. ● 1: The RADIUS attributes of this type of packets are translated.

Related Topics

[13.2.21 radius-attribute translate](#)

13.2.8 display radius-server accounting-stop-packet

Function

The **display radius-server accounting-stop-packet** command displays information about accounting-stop packets on the RADIUS server.

Format

display radius-server accounting-stop-packet { **all** | **ip** { *ip-address* | *ipv6-address* } }

Parameters

Parameter	Description	Value
all	Displays all the accounting-stop packets.	-
ip <i>ip-address</i>	Displays the accounting-stop packets with the specified IP address.	The value of <i>ip-address</i> is in dotted decimal notation.
ip <i>ipv6-address</i>	Displays the accounting-stop packets with the specified IPv6 address.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X.

Views

All views

Default Level

3: Management level

Usage Guidelines

The **display radius-server accounting-stop-packet** command output helps you check configurations or isolate faults.

Example

Display the accounting-stop packets with the IP address being 10.138.104.32.

```
<HUAWEI> display radius-server accounting-stop-packet ip 10.138.104.32
-----
Time Stamp  Resend Times  Session Time  Username
-----
1980409    6           22           g@rds
-----
Total: 1, printed: 1
```

Table 13-24 Description of the display radius-server accounting-stop-packet command output

Item	Description
Time Stamp	Timestamp of an accounting-stop packet.

Item	Description
Resend Times	Number of times that accounting-stop packets have been retransmitted.
Session Time	Session time, in seconds.
Username	User name.

Related Topics

[13.2.24 radius-server accounting-stop-packet resend](#)

[13.2.49 reset radius-server accounting-stop-packet](#)

13.2.9 display radius-server authorization configuration

Function

The **display radius-server authorization configuration** command displays the configuration of RADIUS authorization servers.

Format

display radius-server authorization configuration

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After running the **radius-server authorization** command to configure an authorization server, run the **display radius-server authorization configuration** command to check whether the authorization server configuration is correct.

Example

Display the configuration of RADIUS authorization servers.

```
<HUAWEI> display radius-server authorization configuration
-----
IP-Address   Shared-key   Group      Ack-reserved-interval
-----
10.10.1.114  *****    -          20
vpn-instance : -
```

1 RADIUS authorization server(s) in total

Table 13-25 Description of the **display radius-server authorization configuration** command output

Item	Description
IP-Address	IP address of a RADIUS authorization server. To configure this field, run the radius-server authorization command.
Shared-key	Shared key of the RADIUS authorization server. To configure this field, run the radius-server authorization command.
Group	RADIUS server group matching the RADIUS authorization server. To configure this field, run the radius-server authorization command.
Ack-reserved-interval	Holdtime of RADIUS authorization response packets. To configure this field, run the radius-server authorization command.
vpn-instance	Name of the VPN instance that the RADIUS authorization server is bound to. To configure this field, run the radius-server authorization command. NOTE Only the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support vpn-instance.

Related Topics

[13.2.29 radius-server authorization](#)

13.2.10 display radius-server configuration

Function

The **display radius-server configuration** command displays configuration information about a RADIUS server template.

Format

display radius-server configuration [template *template-name*]

Parameters

Parameter	Description	Value
template <i>template-name</i>	Specifies the name of a RADIUS server template. If this parameter is not specified, configuration information of all RADIUS server templates is displayed.	The RADIUS server template must already exist.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After the configuration of a RADIUS server template is completed or a RADIUS fault needs to be rectified, you can run this command to check whether the configuration of the RADIUS server template is correct.

Example

Display configuration information about the RADIUS server template named **shiva**.

```
<HUAWEI> display radius-server configuration template shiva
-----
Server-template-name      : shiva
Protocol-version          : standard
Traffic-unit              : B
Shared-secret-key         : %^%#O09i(W[^YT4g#Z37Nct9$IK#TH(-B6-1|<q|D)%"%#
Group-filter              : class
Timeout-interval(in second) : 5
Retransmission            : 2
EndPacketSendTime        : 0
Dead time(in minute)      : 5
Domain-included           : YES
NAS-IP-Address            : -
Calling-station-id MAC-format : xxxx-xxxx-xxxx
Called-station-id MAC-format : XX.XX.XX.XX.XX
NAS-Port-ID format        : New
Service-type              : -
NAS-IPv6-Address          : ::
Server algorithm          : master-backup
Detect-interval(in second) : 60
Testuser-username         : huawei
Testuser-ciperpwd         : %^%#.5*EDl^j_WXg[#Z>plj8;k|8.s*ju<_F~g9k`0*9%#
```

```

Authentication Server 1 : 10.7.66.66 Port:1812 Weight:80 [UP]
Vrf:- LoopBack:NULL Vlanif:NULL
Source IP: ::
Authentication Server 2 : 10.7.66.67 Port:1812 Weight:80 [UP]
Vrf:- LoopBack:NULL Vlanif:NULL
Source IP: ::
Accounting Server 1 : 10.7.66.66 Port:1813 Weight:80 [UP]
Vrf:- LoopBack:NULL Vlanif:NULL
Source IP: ::
Accounting Server 2 : 10.7.66.67 Port:1813 Weight:80 [UP]
Vrf:- LoopBack:NULL Vlanif:NULL
Source IP: ::
-----

```

Table 13-26 Description of the **display radius-server configuration template *template-name*** command output

Item	Description
Server-template-name	Name of a RADIUS server template. To configure this item, run the radius-server template command.
Protocol-version	RADIUS protocol version: <ul style="list-style-type: none"> • standard • huawei • iphotel • portal
Traffic-unit	Traffic unit in the RADIUS server template: <ul style="list-style-type: none"> • B: Byte • KB: Kilobyte • MB: Megabyte • GB: Gigabyte To configure this item, run the radius-server traffic-unit command.
Shared-secret-key	Shared key in the RADIUS server template. To configure this item, run the radius-server shared-key command.
Group-filter	Filtering field of a user group. Currently, only the class field can be used as the filtering field of a user group.
Timeout-interval(in second)	Response timeout period of a RADIUS server. To configure this item, run the 13.2.41 radius-server retransmit timeout dead-time command.
Retransmission	Number of times RADIUS packets are retransmitted. To configure this item, run the 13.2.41 radius-server retransmit timeout dead-time command.

Item	Description
EndPacketSendTime	Number of times RADIUS accounting-stop packets are retransmitted. To configure this item, run the radius-server accounting-stop-packet resend command.
Dead time(in minute)	Interval for the primary RADIUS server to revert to the active status. To configure this item, run the 13.2.41 radius-server retransmit timeout dead-time command.
Domain-included	Whether the RADIUS user name contains the domain name. <ul style="list-style-type: none"> ● YES: The user name contains the domain name. ● NO: The user name does not contain the domain name. ● Original: The device does not modify the user name entered by the user. To configure this item, run the 13.2.48 radius-server user-name domain-included command.
NAS-IP-Address	NAS IP address in RADIUS packets.
Calling-station-id MAC-format	Encapsulation format of the MAC address in the calling-station-id attribute of RADIUS packets.
Called-station-id MAC-format	Encapsulation format of the MAC address in the called-station-id attribute of RADIUS packets. To configure this item, run the 13.2.2 called-station-id mac-format command.
NAS-Port-ID format	Format of the NAS-Port-ID attribute on the RADIUS server. <ul style="list-style-type: none"> ● New: Uses the new format of the NAS-Port-ID attribute. ● Old: Uses the old format of the NAS-Port-ID attribute. ● Vm: Uses the NAS-Port-ID attribute format of the VM. <p>NOTE Only the S5720EI supports this parameter.</p> To configure this item, run the 13.2.40 radius-server nas-port-id-format command.

Item	Description
Service-type	Service type.
NAS-IPv6-Address	NAS IPv6 address in RADIUS packets.
Server algorithm	<p>Algorithm for selecting RADIUS servers.</p> <ul style="list-style-type: none"> • master-backup: Specifies the algorithm for selecting RADIUS servers as primary/secondary. • loading-share: Specifies the algorithm for selecting RADIUS servers as packet-based load balancing. • loading-share based-user: Specifies the algorithm for selecting RADIUS servers as single user-based load balancing. <p>To configure this item, run the 13.2.25 radius-server algorithm command.</p>
Detect-interval(in second)	Automatic detection interval for RADIUS servers. To configure this item, run the radius-server detect-server command.
Testuser-username	User name for automatic RADIUS server detection. To configure this item, run the radius-server testuser command.
Testuser-ciperpwd	User password for automatic RADIUS server detection. To configure this item, run the radius-server testuser command.
Authentication Server 1	IP address, interface number, weight, status, VPN instance, source interface, and source IP address of the primary RADIUS authentication server. To configure this item, run the radius-server authentication command.
Authentication Server 2	IP address, interface number, weight, status, VPN instance, source interface, and source IP address of the secondary RADIUS authentication server. To configure this item, run the radius-server authentication command.
Accounting Server 1	IP address, interface number, weight, status, VPN instance, source interface, and source IP address of the primary RADIUS accounting server. To configure this item, run the radius-server accounting command.

Item	Description
Accounting Server 2	IP address, interface number, weight, status, VPN instance, source interface, and source IP address of the secondary RADIUS accounting server. To configure this item, run the radius-server accounting command.

13.2.11 display radius-server dead-interval dead-count

Function

The **display radius-server dead-interval dead-count** command displays configuration information about the RADIUS server detection interval and maximum number of consecutive unacknowledged packets in each detection interval.

Format

```
display radius-server { dead-interval | dead-count }
```

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After the RADIUS server detection interval and maximum number of consecutive unacknowledged packets in each detection interval are configured using the [13.2.33 radius-server dead-interval dead-count](#) command, you can run the **display radius-server { dead-interval | dead-count }** command to check configuration information about the RADIUS server detection interval and maximum number of consecutive unacknowledged packets in each detection interval.

Example

```
# Display configuration information about the RADIUS server detection interval.
```

```
<HUAWEI> display radius-server dead-interval  
Radius server state detected internal is 5.
```

Display configuration information about the maximum number of consecutive packets that are not acknowledged by the RADIUS server in each detection interval.

```
<HUAWEI> display radius-server dead-count
Radius server state detected count is 2.
```

Table 13-27 Description of the **display radius-server { dead-interval | dead-count }** command output

Item	Description
Radius server state detected interval is	Detection interval of the current RADIUS server.
Radius server state detected count is	Maximum number of consecutive packets that are not acknowledged by the RADIUS server.

13.2.12 display radius-server item

Function

The **display radius-server item** command shows the RADIUS server configuration.

Format

```
display radius-server item { ip-address { ipv4-address | ipv6-address }
{ accounting | authentication } | template template-name }
```

Parameters

Parameter	Description	Value
ip-address { <i>ipv4-address</i> <i>ipv6-address</i> }	Specifies the IP address of the RADIUS server.	<i>ipv4-address</i> : The value is in dotted decimal notation. <i>ipv6-address</i> : The value is a 32-digit hexadecimal number.
accounting	Indicates the RADIUS accounting server.	-
authentication	Indicates the RADIUS authentication server.	-
template <i>template-name</i>	Specifies the RADIUS server template name.	The value must be an existing RADIUS server template name.

Views

ALL views

Default Level

3: Management level

Usage Guidelines

The **display radius-server item** command shows the RADIUS server configuration.

Example

Display the configuration of RADIUS server template **rds**.

```
<HUAWEI> display radius-server item template rds
```

```
-----  
Type      = auth-server  
State     = state-up  
AlarmFlag = false  
STUseNum  = 1  
IPAddress = 192.168.30.1  
AlarmTimer = 0xffffffff  
Head      = 1057  
Tail      = 1311  
ProbeID   = 255  
Type      = acct-server  
State     = state-up  
AlarmFlag = false  
STUseNum  = 1  
IPAddress = 192.168.30.1  
AlarmTimer = 0xffffffff  
Head      = 1057  
Tail      = 1311  
ProbeID   = 255  
-----
```

Table 13-28 Description of the **display radius-server item** template command output

Item	Description
Type	RADIUS server type: authentication or accounting server. <ul style="list-style-type: none">• auth-server: indicates authentication server.• acct-server: indicates accounting server.
State	RADIUS server status. <ul style="list-style-type: none">• state-up: indicates that the RADIUS server is in UP status.• state-down: indicates that the RADIUS server is in DOWN status.• state-probe: indicates that the RADIUS server is in detection status.

Item	Description
AlarmFlag	Alarm flag. <ul style="list-style-type: none">• true: indicates that an alarm about status change has been sent.• false: indicates that an alarm about status change is not sent.
STUseNum	RADIUS server template ID.
IPAddress	RADIUS server IP address.
AlarmTimer	ID of the alarm timer.
Head	Head pointer used to allocate the ID to RADIUS packets.
Tail	Tail pointer used to allocate the ID to RADIUS packets.
ProbeID	ID of probe packets.

13.2.13 display radius-server session-manage configuration

Function

The **display radius-server session-manage configuration** command displays session management configuration on the RADIUS server.

Format

display radius-server session-manage configuration

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After session management is enabled using the [radius-server session-manage](#) command on the RADIUS server, you can run this command to view session management configuration.

Example

Display session management configuration on the RADIUS server.

```
<HUAWEI> display radius-server session-manage configuration
-----
Session Manage Enable : True   Session Manage AnyServer : False
-----
IP Address      VPN Instance      Shared-key
-----
10.1.1.1       -                   *****
-----
1 Radius session manage server(s) in total
```

Table 13-29 Description of the **display radius-server session-manage configuration** command output

Item	Description
Session Manage Enable	Whether session management is enabled: <ul style="list-style-type: none"> • True: enabled • False: disabled To set this parameter, run the radius-server session-manage command.
Session Manage AnyServer	Whether any RADIUS session management server is configured: <ul style="list-style-type: none"> • True: configured • False: not configured
IP Address	IP address of the RADIUS session management server.
VPN Instance	Name of the VPN instance bound to the RADIUS session management server. NOTE Only the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support this parameter.
Shared-key	Shared key of the RADIUS session management server.
Radius session manage server(s) in total	Number of the RADIUS session management servers.

13.2.14 display snmp-agent trap feature-name radius all

Function

The **display snmp-agent trap feature-name radius all** command displays the status of all traps on the RDS module.

Format

```
display snmp-agent trap feature-name radius all
```

Parameters

None

Views

All views

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After enabling the trap function for the RDS module, you can run this command to check the status of all traps on the RDS module. To enable the trap function for the RDS module, run the **snmp-agent trap enable feature-name radius** command.

Prerequisites

The SNMP function has been enabled on the device.

Example

```
# Display the status of all traps on the RDS module.
```

```
<HUAWEI>display snmp-agent trap feature-name radius all
-----
Feature name: radius
Trap number : 4
-----
Trap name           Default switch status  Current switch status
hwRadiusAuthServerUp    off                    off
hwRadiusAuthServerDown  off                    off
hwRadiusAcctServerUp    off                    off
hwRadiusAcctServerDown  off                    off
```

Table 13-30 Description of the **display snmp-agent trap feature-name radius all** command output

Item	Description
Feature name	Name of the module to which a trap belongs.
Trap number	Number of traps.
Trap name	Name of a trap. Traps on the RDS module include: <ul style="list-style-type: none"> • hwRadiusAuthServerUp: The device sends a Huawei proprietary trap when it detects that communication with the RADIUS authentication server is restored. • hwRadiusAuthServerDown: The device sends a Huawei proprietary trap when it detects that communication with the RADIUS authentication server is interrupted. • hwRadiusAcctServerUp: The device sends a Huawei proprietary trap when it detects that communication with the RADIUS accounting server is restored. • hwRadiusAcctServerDown: The device sends a Huawei proprietary trap when it detects that communication with the RADIUS accounting server is interrupted.
Default switch status	Default status of the trap function: <ul style="list-style-type: none"> • on: The trap function is enabled by default. • off: The trap function is disabled by default.
Current switch status	Trap status: <ul style="list-style-type: none"> • on: The trap is enabled. • off: The trap is disabled.

Related Topics

[13.2.50 snmp-agent trap enable feature-name radius](#)

13.2.15 radius-attribute check

Function

The **radius-attribute check** command enables the device to check the specified attributes in the received RADIUS Access-Accept packets.

The **undo radius-attribute check** command disables the device from checking the specified attributes in the received RADIUS Access-Accept packets.

By default, the device does not check whether a RADIUS Access-Accept packet contains the specified attributes.

Format

radius-attribute check *attribute-name*

undo radius-attribute check [*attribute-name*]

Parameters

Parameter	Description	Value
<i>attribute-name</i>	Specifies the name of the RADIUS attribute. If this parameter is specified, the RADIUS Access-Accept packets are checked based on attribute names.	The value is a string of 1 to 64 characters. After the name is entered, the system automatically associates the RADIUS attribute with the name.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After the **radius-attribute check** command is executed, the device checks whether the received RADIUS Access-Accept packets contain the specified attributes. If yes, the device considers that authentication was successful; if not, the device considers that authentication failed and discards the packet. For example, after the **radius-attribute check filter-id** command is executed, the device checks the filter-id attribute in the received RADIUS Access-Accept packets. If a RADIUS packet does not contain this attribute, authentication fails.

Precautions

- When you use the **undo radius-attribute check** command with parameters, the device checks the specified attributes in the RADIUS Access-Accept packets. When you use the **undo radius-attribute check** command without any parameter, the device does not check RADIUS Access-Accept packets.
- The **display radius-attribute** can display RADIUS attribute names.

Example

```
# Check whether the RADIUS Access-Accept packets contain the framed-protocol attribute.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template test1  
[HUAWEI-radius-test1] radius-attribute check framed-protocol
```

Related Topics

[13.2.4 display radius-attribute](#)

13.2.16 radius-attribute disable

Function

The **radius-attribute disable** command disables a RADIUS attribute.

The **undo radius-attribute disable** command enables a disabled RADIUS attribute.

By default, no RADIUS attribute is disabled.

Format

radius-attribute disable *attribute-name* { **receive** | **send** } *

undo radius-attribute disable [*attribute-name*]

Parameters

Parameter	Description	Value
<i>attribute-name</i>	Specifies the name of a RADIUS attribute.	The value is a string of 1 to 64 characters. After the name is entered, the system automatically associates the RADIUS attribute with the name.
receive	Disables a RADIUS attribute for received packets.	-
send	Disables a RADIUS attribute for sent packets.	-

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

Generally, a RADIUS server connects to multiple network devices, which can be one vendor's devices or different vendors' devices. If some vendors' devices require

the RADIUS server to deliver an attribute to support a specified feature but other vendors' device do not support the delivered attribute, the RADIUS attribute may fail to be parsed.

The device may communicate with RADIUS servers of different vendors. Some RADIUS servers require the device to send some attributes but other RADIUS servers cannot process the attributes. Errors may occur.

The **radius-attribute disable** command disables RADIUS attributes on the device. You can configure the device to ignore incompatible attributes when receiving RADIUS packets to prevent parsing failures. You can also configure the device to disable RADIUS attributes when sending RADIUS packets. When the device sends RADIUS packets, it does not encapsulate the disabled RADIUS attributes in the RADIUS packets.

Prerequisites

The RADIUS attribute translation function has been enabled using the [13.2.27 radius-server attribute translate](#) command.

Precautions

Before disabling RADIUS attributes, run the [13.2.4 display radius-attribute](#) command to view the RADIUS attributes supported by the device.

Example

```
# Disable the Frame-Route attribute in sent packets.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template test1  
[HUAWEI-radius-test1] radius-server attribute translate  
[HUAWEI-radius-test1] radius-attribute disable framed-route send
```

Related Topics

[13.2.4 display radius-attribute](#)

[13.2.45 radius-server template](#)

13.2.17 radius-attribute nas-ip

Function

The **radius-attribute nas-ip** command sets the NAS-IP-Address attribute in a RADIUS packet sent from an NAS.

The **undo radius-attribute nas-ip** command deletes the configured NAS-IP-Address attribute.

By default, the source IP address of the NAS is the NAS-IP-Address attribute value.

Format

radius-attribute nas-ip *ip-address*

undo radius-attribute nas-ip

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the NAS-IP-Address attribute value in RADIUS packets sent by the device.	The value is a valid unicast address in dotted decimal notation.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

A RADIUS server uses the NAS-IP-Address attributes in RADIUS packets sent by NASs to identify NASs. You can run the **radius-attribute nas-ip** command in the RADIUS server template view to set the NAS-IP-Address attribute.

Prerequisites

A RADIUS server template has been created using the [radius-server template](#) command.

Precautions

If the RADIUS NAS-IP-Address attribute is set to an invalid IP address, the configuration fails and an error message is displayed.

Example

```
# Set the RADIUS NAS-IP-Address attribute.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template temp1  
[HUAWEI-radius-temp1] radius-attribute nas-ip 10.3.3.3
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.18 radius-attribute nas-ipv6

Function

The **radius-attribute nas-ipv6** command sets the NAS-IPv6-Address attribute in a RADIUS packet sent from a network access server (NAS).

The **undo radius-attribute nas-ipv6** command deletes the configured NAS-IPv6-Address attribute.

By default, no NAS-IPv6-Address attribute is configured.

Format

radius-attribute nas-ipv6 *ipv6-address*

undo radius-attribute nas-ipv6

Parameters

Parameter	Description	Value
<i>ipv6-address</i>	Specifies the NAS-IPv6-Address attribute in a RADIUS packet.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X:X.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The RADIUS server uses IP addresses to identify different NASs. The NAS-IPv6-Address attribute in a RADIUS packet can be configured using the **radius-attribute nas-ipv6** command in the RADIUS template.

Prerequisites

A RADIUS server template has been created using the [radius-server template](#) command.

Precautions

If the RADIUS NAS-IP-Address attribute is set to an invalid IP address, the configuration fails and an error message is displayed.

Example

```
# Set the RADIUS NAS-IPv6-Address attribute.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template temp1  
[HUAWEI-radius-temp1] radius-attribute nas-ipv6 FC00::7
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.19 radius-attribute service-type with-authenonly-reauthen

Function

The **radius-attribute service-type with-authenonly-reauthen** command set the reauthentication mode to reauthentication only.

The **undo radius-attribute service-type with-authenonly-reauthen** command restores the reauthentication mode to reauthentication and reauthorization.

By default, this command is not configured and the reauthentication mode is reauthentication and reauthorization.

Format

radius-attribute service-type with-authenonly-reauthen

undo radius-attribute service-type with-authenonly-reauthen

Parameters

None

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

A large number of users are online at the same time and each user has a lot of authorization information. If the users need to be reauthenticated, the device delivers authorization information to each user after the authentication is successful. It is difficult for the device to process a lot of authorization information. As a result, users go offline due to authorization failures. After the **radius-attribute service-type with-authenonly-reauthen** command is run in the RADIUS server template view, the device only reauthenticates users during reauthentication, and does not redeliver authorization information, preventing users from going offline due to authorization failures.

Precautions

After this command is configured, users still use the original authorization information after being successfully reauthenticated even if the user authorization information changes.

This function takes effect after the Service-Type attribute on the RADIUS server is set to Authenticate Only.

Example

```
# Set the reauthentication mode to reauthentication only.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template test  
[HUAWEI-radius-test] radius-attribute service-type with-authenonly-reauthen
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.20 radius-attribute set

Function

The **radius-attribute set** command modifies the RADIUS attributes.

The **undo radius-attribute set** command restores the default RADIUS attributes.

By default, values of the RADIUS attributes are not modified.

Format

radius-attribute set *attribute-name attribute-value* [**auth-type mac** | **user-type ipsession**]

undo radius-attribute set *attribute-name*

Parameters

Parameter	Description	Value
<i>attribute-name</i>	Specifies the name of the attribute to be modified.	The value is a string of 1 to 64 characters. After the name is entered, the system automatically associates the RADIUS attribute with the name.
<i>attribute-value</i>	Indicates the value of the attribute to be modified.	The value of <i>attribute-value</i> is automatically displayed.
auth-type mac	Sets the user authentication mode to MAC address authentication. Only the Service-Type attribute supports this parameter.	-

Parameter	Description	Value
user-type ipsession	Specifies the users with user type being IP session. Only the Service-Type attribute supports this parameter.	-

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The RADIUS attribute values of different vendors are different. To ensure that Huawei device can successfully communicate with the devices of other vendors, run the **radius-attribute set** command to modify the RADIUS attribute values.

For example, the Huawei device uses Service-Type value 2 to indicate an authentication request from a common user by default, while a non-Huawei RADIUS server uses Service-Type value 1 to indicate an authentication request from a common user; you can run the **radius-attribute set service-type 1** command to change the Service-Type value on the device so that the device can communicate with the RADIUS server.

Precautions

- The **radius-attribute set** command can modify only the RADIUS attributes in the authentication or accounting request packets sent from a device to the RADIUS server, and cannot modify the RADIUS attributes in the packets sent from the RADIUS server to a device.

If you run the **display radius-attribute** command to check the RADIUS attributes supported by a device and the **Auth Req** or **Acct Req** field in the command output displays 1, the RADIUS attributes supported by the device can be carried in the authentication or accounting request packets sent from the device to the RADIUS server.

Among the RADIUS attributes that can be carried in the authentication or accounting packets sent from the device to the RADIUS server, you cannot run the **radius-attribute set** command to modify the following attributes: User-Password, Agent-Circuit-Id, Agent-Remote-Id, NAS-IP-Address, NAS-IPv6-Address, CHAP-Password, CHAP-Challenge, EAP-Message, Framed-Interface-Id, Framed-IPv6-Prefix, and Message-Authenticator.

- The type of the attribute modified by the **radius-attribute set** command cannot be changed.

- The **radius-attribute set service-type *attribute-value* { auth-type mac | user-type ipsession }** command has a higher priority than the **radius-attribute set service-type *attribute-value*** command.
- If the value of the HW-Output-Committed-Information-Rate attribute is changed to 0, sent packets do not carry this attribute.

Example

Create the template **temp1** and set the Service-Type attribute value to 1.

```
<HUAWEI> system-view
[HUAWEI] radius-server template temp1
[HUAWEI-radius-temp1] radius-attribute set service-type 1
```

Related Topics

[13.2.45 radius-server template](#)

13.2.21 radius-attribute translate

Function

The **radius-attribute translate** command configures a RADIUS attribute to be translated.

The **undo radius-attribute translate** command cancels the configuration.

By default, no RADIUS attribute is translated.

Format

radius-attribute translate *src-attribute-name dest-attribute-name* { receive | send | access-accept | access-request | account-request | account-response } *

radius-attribute translate extend vendor-specific *src-vendor-id src-sub-id dest-attribute-name* { access-accept | account-response } *

radius-attribute translate extend *src-attribute-name* vendor-specific *dest-vendor-id dest-sub-id* { access-request | account-request } *

undo radius-attribute translate [*src-attribute-name*]

undo radius-attribute translate extend *src-attribute-name*

undo radius-attribute translate extend vendor-specific *src-vendor-id src-sub-id*

Parameters

Parameter	Description	Value
<i>src-attribute-name</i>	Specifies the name of the source attribute.	The value is a string of 1 to 64 characters. After the name is entered, the system automatically associates the RADIUS attribute with the name.
<i>dest-attribute-name</i>	Specifies the name of the destination attribute.	The value is a string of 1 to 64 characters. After the name is entered, the system automatically associates the RADIUS attribute with the name.
receive	Translates RADIUS attributes for received packets.	-
send	Translates RADIUS attributes for sent packets.	-
access-request	Translates RADIUS attributes for Authentication Request packets.	-
account-request	Translates RADIUS attributes for Accounting Request packets.	-
access-accept	Translates RADIUS attributes for Authentication Accept packets.	-
account-response	Translates RADIUS attributes for Accounting Response packets.	-
extend	Translates extended RADIUS attributes.	-

Parameter	Description	Value
vendor-specific <i>src-vendor-id src-sub-id</i>	<p>Specifies the source extended attribute to be translated.</p> <ul style="list-style-type: none">• <i>src-vendor-id</i>: The vendor ID in the extended RADIUS attributes needs to be translated.• <i>src-sub-id</i>: The sub ID in the RADIUS attributes needs to be translated.	<ul style="list-style-type: none">• The value of <i>src-vendor-id</i> is an integer ranging from 1 to 4294967295.• The value of <i>src-sub-id</i> is an integer ranging from 1 to 255.
vendor-specific <i>dest-vendor-id dest-sub-id</i>	<p>Specifies the destination extended attribute to be translated.</p> <ul style="list-style-type: none">• <i>dest-vendor-id</i>: The vendor ID in the extended RADIUS attributes needs to be translated.• <i>dest-sub-id</i>: The sub ID in the extended RADIUS attributes needs to be translated.	<ul style="list-style-type: none">• The value of <i>dest-vendor-id</i> is an integer ranging from 1 to 4294967295.• The value of <i>dest-sub-id</i> is an integer ranging from 1 to 255.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

Currently, RADIUS servers of different vendors may support different RADIUS attributes and have vendor-specific RADIUS attributes. To communicate with different RADIUS servers, the device provides the RADIUS attribute translation function. After RADIUS attribute translation is enabled, the device can translate RADIUS attributes when sending or receiving packets.

RADIUS attribute translation is used in the following modes:

- Format translation for the same attribute

This mode is widely applied. It solves the problem of compatibility because different users have different requirements for the format of a RADIUS attribute.

- Translation between different attributes

This mode is used because different vendors have different implementations of RADIUS attributes.

For example, the device delivers the priority of the administrator by using the Huawei proprietary attribute HW-Exec-Privilege (26-29), whereas another vendor's device delivers it by using the Login-service (15) attribute. When the device and the vendor's device use the same RADIUS server on a network, the user hopes that the device can deliver the priority of the administrator by using the Login-service (15) attribute. After the **radius-attribute translate** command is configured, the device automatically processes the Login-service attribute in the received RADIUS authentication response packet as the HW-Exec-Privilege attribute.

Prerequisites

RADIUS attribute translation has been enabled by using the **radius-server attribute translate** command.

Before configuring RADIUS attribute translation, run the **display radius-attribute** command to view the RADIUS attributes supported by the device.

Precautions

- When the device sends packets, if attribute A is to be translated to attribute B, the type of the encapsulated attribute is the same as that of attribute B but the attribute content and format are the same as those of attribute A.
- When the device receives packets, if attribute A is to be translated to attribute B, the device parses the received attribute A as attribute B.
- Three commands are available to translate RADIUS attributes:
 - To translate the attributes supported by the device to other attributes also supported by the device, run the **radius-attribute translate** command.
 - To translate the non-Huawei attributes not supported by the device to the attributes supported by the device, run the **radius-attribute translate extend vendor-specific** command.
 - To translate the attributes supported by the device to the non-Huawei attributes not supported by the device, run the **radius-attribute translate extend** command.
- The RADIUS attribute consists of Type, Length, and Value fields. A device can translate a non-Huawei RADIUS attribute (specified using the *src-sub-id* and *dest-sub-id* parameters) only when the length of the Type field in the RADIUS attribute is 1 byte.
- The device can translate the RADIUS attribute only when the type of the source RADIUS attribute is the same as that of the destination RADIUS attribute. For example, the types of NAS-Identifier and NAS-Port-Id attributes are string, and they can be translated into each other. The types of NAS-Identifier and NAS-Port attributes are string and integer respectively, they cannot be translated into each other.

Example

Configure the device to translate NAS-Identifier into NAS-Port-Id when sending RADIUS packets.

```
<HUAWEI> system-view
[HUAWEI] radius-server template temp1
[HUAWEI-radius-temp1] radius-server attribute translate
[HUAWEI-radius-temp1] radius-attribute translate nas-identifier nas-port-id send
```

Translate the Cisco No. 2 attribute (vendor ID 9) in Authentication Accept and Accounting Response packets to Huawei No. 155 extended attribute HW-URL-Flag.

```
<HUAWEI> system-view
[HUAWEI] radius-server template temp1
[HUAWEI-radius-temp1] radius-server attribute translate
[HUAWEI-radius-temp1] radius-attribute translate extend Vendor-Specific 9 2 HW-URL-Flag access-accept account-response
```

Translate the Huawei No. 153 extended attribute HW-Access-Type in Authentication Request and Accounting Request packets to Cisco No. 11 attribute.

```
<HUAWEI> system-view
[HUAWEI] radius-server template temp1
[HUAWEI-radius-temp1] radius-server attribute translate
[HUAWEI-radius-temp1] radius-attribute translate extend HW-Access-Type vendor-specific 9 11 access-request account-request
```

Related Topics

- [13.2.4 display radius-attribute](#)
- [13.2.7 display radius-attribute translate](#)
- [13.2.27 radius-server attribute translate](#)
- [13.2.45 radius-server template](#)

13.2.22 radius-server (aaa domain view)

Function

The **radius-server** command applies a RADIUS server template to a domain.

The **undo radius-server** command unbinds an RADIUS server template from a domain.

By default, the RADIUS server template **default** is bound to a configured domain and the domain **default**, and no RADIUS server template is bound to the domain **default_admin**.

Format

radius-server *template-name*

undo radius-server

Parameters

Parameter	Description	Value
<i>template-name</i>	Specifies the name of a RADIUS server template.	The RADIUS server template must already exist.

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To perform RADIUS authentication and accounting for users in a domain, apply a RADIUS server template to the domain. A RADIUS server template takes effect only after the RADIUS server template is applied to a domain.

Prerequisites

A RADIUS server template has been created using the [13.2.45 radius-server template](#) command.

Example

Apply the RADIUS server template **template1** to the domain **radius1**.

```
<HUAWEI> system-view
[HUAWEI] radius-server template template1
[HUAWEI-radius-template1] quit
[HUAWEI] aaa
[HUAWEI-aaa] domain radius1
[HUAWEI-aaa-domain-radius1] radius-server template1
```

Related Topics

[13.2.10 display radius-server configuration](#)

[13.2.45 radius-server template](#)

13.2.23 radius-server accounting

Function

The **radius-server accounting** command configures the RADIUS accounting server.

The **undo radius-server accounting** command deletes the configuration.

By default, no RADIUS accounting server is configured.

Format

radius-server accounting *ipv4-address* *port* [**vpn-instance** *vpn-instance-name* | **source** { **loopback** *interface-number* | **ip-address** *ipv4-address* | **vlanif** *interface-number* } | **weight** *weight-value*] *

radius-server accounting *ipv6-address* *port* [**source** { **loopback** *interface-number* | **ip-address** *ipv6-address* | **vlanif** *interface-number* } | **weight** *weight-value*] *

undo radius-server accounting [*ipv4-address* [*port* [**vpn-instance** *vpn-instance-name* | **source** { **loopback** *interface-number* | **ip-address** *ipv4-address* | **vlanif** *interface-number* } | **weight**] *]]

undo radius-server accounting [*ipv6-address* [*port* [**source** { **loopback** *interface-number* | **ip-address** *ipv6-address* | **vlanif** *interface-number* } | **weight**]]]

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
<i>ipv4-address</i>	Specifies the IPv4 address of a RADIUS accounting server.	The value is a valid unicast address in dotted decimal notation.
<i>ipv6-address</i>	Specifies the IPv6 address of a RADIUS accounting server.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X.
<i>port</i>	Specifies the port number of a RADIUS accounting server.	The value is an integer that ranges from 1 to 65535.
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance that the RADIUS accounting server is bound to.	The value must be an existing VPN instance name.
source loopback <i>interface-number</i>	Specifies the number of a loopback interface.	The loopback interface must already exist.

Parameter	Description	Value
source ip-address <i>ipv4-address</i>	<p>Specifies the source IPv4 address in RADIUS packets sent from the device to a RADIUS accounting server.</p> <p>If this parameter is specified, ensure that the value of this parameter is the same as the client's IPv4 address specified on the RADIUS accounting server.</p> <p>If this parameter is not specified, the IPv4 address of the outbound interface is used as the source IPv4 address in RADIUS packets sent from the device to a RADIUS accounting server.</p>	The value is a valid unicast address in dotted decimal notation.
source ip-address <i>ipv6-address</i>	<p>Specifies the source IPv6 address in RADIUS packets sent from the device to a RADIUS accounting server.</p> <p>If this parameter is not specified, the IPv6 address of the outbound interface is used as the source IPv6 address in RADIUS packets sent from the device to a RADIUS accounting server.</p> <p>This address cannot be a virtual IPv6 address of a VRRP6 group.</p>	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X:X.
source vlanif <i>interface-number</i>	<p>Specifies the IP address of a VLANIF interface as the source IP address.</p> <p><i>interface-number</i> specifies the number of a VLANIF interface.</p>	The VLANIF interface must exist.

Parameter	Description	Value
weight <i>weight-value</i>	Specifies the weight of a RADIUS accounting server. When multiple servers are available, the device uses the server with the highest weight to perform accounting. If the servers have the same weights, the device uses the server configured first to perform accounting.	The value is an integer that ranges from 0 to 100.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To perform accounting for users, configure a RADIUS accounting server. The device communicates with a RADIUS accounting server to obtain accounting information, and performs accounting for users based on the accounting information. The device sends accounting packets to the RADIUS accounting server only after the IP address and port number of the RADIUS accounting server are specified in the RADIUS server template.

Precautions

The IP address of the primary accounting server must be different from the IP address of the secondary accounting server; otherwise, the configuration fails.

Example

Configure the primary RADIUS accounting server.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template group1  
[HUAWEI-radius-group1] radius-server accounting 10.163.155.12 1813
```

Configure the secondary RADIUS accounting server.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template group1  
[HUAWEI-radius-group1] radius-server accounting 10.163.155.15 1813 weight 50
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.24 radius-server accounting-stop-packet resend

Function

The **radius-server accounting-stop-packet resend** command enables retransmission of accounting-stop packets and sets the number of accounting-stop packets that can be retransmitted each time.

The **undo radius-server accounting-stop-packet resend** command disables retransmission of accounting-stop packets.

By default, retransmission of accounting-stop packets is enabled, and the retransmission times is 3.

NOTE

The default settings are recommended. If accounting-stop packets need to be retransmitted many times, the RADIUS authentication performance of the switch will be affected and even cause a failure to send accounting-stop packets.

Format

radius-server accounting-stop-packet resend [*resend-times*]

undo radius-server accounting-stop-packet resend

Parameters

Parameter	Description	Value
<i>resend-times</i>	Specifies the number of accounting-stop packets that can be retransmitted each time.	The value is an integer that ranges from 0 to 300.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

When accounting-stop packets cannot be sent to the RADIUS server that is unreachable, you can run the **radius-server accounting-stop-packet resend** command to save the accounting-stop packets in the buffer and send them at the preset intervals until the number of allowed retransmission times is reached or the packets are sent successfully.

Example

Enable the retransmission of accounting-stop packets and set the number of accounting-stop packets that can be retransmitted each time to 50.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template test1  
[HUAWEI-radius-test1] radius-server accounting-stop-packet resend 50
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.25 radius-server algorithm

Function

The **radius-server algorithm** command configures the algorithm for selecting RADIUS servers.

The **undo radius-server algorithm** command restores the default algorithm for selecting RADIUS servers.

By default, the algorithm for selecting RADIUS servers is primary/secondary.

Format

radius-server algorithm { loading-share [based-user] | master-backup }

undo radius-server algorithm

Parameters

Parameter	Description	Value
loading-share	Sets the algorithm for selecting RADIUS servers to load balancing.	-
based-user	Sets the algorithm for selecting RADIUS servers to single user-based load balancing. If this parameter is not specified, the algorithm for selecting RADIUS servers is packet-based load balancing.	-
master-backup	Sets the algorithm for selecting RADIUS servers to primary/secondary.	-

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

When two or more than two RADIUS servers are available, you can use the **radius-server algorithm** command to set the algorithm for selecting RADIUS servers.

- When **master-backup** is specified, the weight is used to determine the primary and secondary RADIUS authentication or accounting servers. The server with a larger weight value is the primary server. If devices have the same weight, the server that was first configured is the primary server.
- When **loading-share** is specified, the device sends a packet to a server according to the weights configured on servers. For example, if the weights of RADIUS server A, RADIUS server B, and RADIUS server C are 80, 80, and 40 respectively, the probabilities of sending packets to RADIUS server A, RADIUS server B, and RADIUS server C are as follows:
 - RADIUS server A: $80/(80 + 80 + 40) = 40\%$
 - RADIUS server B: $80/(80 + 80 + 40) = 40\%$
 - RADIUS server C: $40/(80 + 80 + 40) = 20\%$

If the algorithm for selecting RADIUS servers is configured as single user-based load balancing, authentication server information is saved in the authentication phase, and the device preferentially sends an accounting request to the accounting server in the accounting phase when the accounting server is the same as the authentication server. If the algorithm for selecting RADIUS servers is configured as packet-based load balancing, authentication server information is not saved in the authentication phase, and the accounting server is reselected based on the algorithm in the accounting phase, which may result in that authentication and accounting for a user is not performed on the same server.

Precautions

If you run the **radius-server algorithm** command multiple times in the same RADIUS server template view, only the latest configuration takes effect.

Example

Set the algorithm for selecting RADIUS servers to load balancing.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template template1  
[HUAWEI-radius-template1] radius-server algorithm loading-share
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.26 radius-server attribute message-authenticator access-request

Function

The **radius-server attribute message-authenticator access-request** command carries the Message-Authenticator attribute in RADIUS authentication packets sent by the device.

The **undo radius-server attribute message-authenticator access-request** command cancels the Message-Authenticator attribute from RADIUS authentication packets sent by the device.

By default, RADIUS authentication packets do not carry the Message-Authenticator attribute.

Format

radius-server attribute message-authenticator access-request

undo radius-server attribute message-authenticator access-request

Parameters

None

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

The Message-Authenticator attribute is used to identify and verify authentication packets to prevent invalid packets.

NOTE

- This command is used when the PAP or CHAP authentication is enabled.
- When EAP authentication is enabled, RADIUS packets contain the Message-Authenticator attribute by default. You do not need to run this command.

Example

Configure the Message-Authenticator attribute to RADIUS authentication packets.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template test1  
[HUAWEI-radius-test1] radius-server attribute message-authenticator access-request
```

13.2.27 radius-server attribute translate

Function

The **radius-server attribute translate** command enables RADIUS attribute translation.

The **undo radius-server attribute translate** command disables RADIUS attribute translation.

By default, RADIUS attribute translation is disabled.

Format

radius-server attribute translate

undo radius-server attribute translate

Parameters

None

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

Currently, RADIUS servers of different vendors may support different RADIUS attributes and have vendor-specific RADIUS attributes. To communicate with different RADIUS servers, the device provides the RADIUS attribute translation function. After RADIUS attribute translation is enabled, the device can translate RADIUS attributes when sending or receiving packets.

Follow-up Procedure

After RADIUS attribute translation is enabled, perform either of the following operations to make the function to take effect:

- Run the **13.2.21 radius-attribute translate** command to specify the RADIUS attributes that you want to translate.
- Run the **13.2.16 radius-attribute disable** command to specify the RADIUS attributes that you do not want to translate.

Example

```
# Enable RADIUS attribute translation.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template test1  
[HUAWEI-radius-test1] radius-server attribute translate
```

Related Topics

[13.2.21 radius-attribute translate](#)

[13.2.45 radius-server template](#)

13.2.28 radius-server authentication

Function

The **radius-server authentication** command configures a RADIUS authentication server.

The **undo radius-server authentication** command deletes the configured RADIUS authentication server.

By default, no RADIUS authentication server is specified.

Format

radius-server authentication *ipv4-address* *port* [**vpn-instance** *vpn-instance-name* | **source** { **loopback** *interface-number* | **ip-address** *ipv4-address* | **vlanif** *interface-number* } | **weight** *weight-value*] *

radius-server authentication *ipv6-address* *port* [**source** { **loopback** *interface-number* | **ip-address** *ipv6-address* | **vlanif** *interface-number* } | **weight** *weight-value*] *

undo radius-server authentication [*ipv4-address* [*port* [**vpn-instance** *vpn-instance-name* | **source** { **loopback** *interface-number* | **ip-address** *ipv4-address* | **vlanif** *interface-number* } | **weight**] *]]

undo radius-server authentication [*ipv6-address* [*port* [**source** { **loopback** *interface-number* | **ip-address** *ipv6-address* | **vlanif** *interface-number* } | **weight**]]]

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
<i>ipv4-address</i>	Specifies the IPv4 address of a RADIUS authentication server.	The value is a valid unicast address in dotted decimal notation.

Parameter	Description	Value
<i>ipv6-address</i>	Specifies the IPv6 address of a RADIUS authentication server.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X.
<i>port</i>	Specifies the port number of a RADIUS authentication server.	The value is an integer that ranges from 1 to 65535.
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance that the RADIUS authentication server is bound to.	The value must be an existing VPN instance name.
source loopback <i>interface-number</i>	Specifies the IP address of the loopback interface taken as the source IP address. <i>interface-number</i> specifies the number of a loopback interface.	The loopback interface must already exist.
source ip-address <i>ipv4-address</i>	Specifies the source IPv4 address in RADIUS packets sent from the device to a RADIUS authentication server. If this parameter is specified, ensure that the value of this parameter is the same as the client's IPv4 address specified on the RADIUS authentication server. If this parameter is not specified, the IPv4 address of the outbound interface is used as the source IPv4 address in RADIUS packets sent from the device to a RADIUS authentication server.	The value is a valid unicast address in dotted decimal notation.

Parameter	Description	Value
source ip-address <i>ipv6-address</i>	Specifies the source IPv6 address in RADIUS packets sent from the device to a RADIUS authentication server. If this parameter is not specified, the IPv6 address of the outbound interface is used as the source IPv6 address in RADIUS packets sent from the device to a RADIUS authentication server. This address cannot be a virtual IPv6 address of a VRRP6 group.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X.
source vlanif <i>interface-number</i>	Specifies the IP address of a VLANIF interface as the source IP address. <i>interface-number</i> specifies the number of a VLANIF interface.	The VLANIF interface must exist.
weight <i>weight-value</i>	Specifies the weight of a RADIUS authentication server. When multiple servers are available, the device uses the server with the highest weight to perform authentication. If the servers have the same weights, the device uses the server configured first to perform authentication.	The value is an integer that ranges from 0 to 100. The default value is 80.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

To perform RADIUS authentication, configure a RADIUS authentication server in a RADIUS server template. The device uses the RADIUS protocol to communicate with a RADIUS authentication server to obtain authentication information, and authenticates users based on the authentication information. The device sends authentication packets to the RADIUS authentication server only after the IP address and port number of the RADIUS authentication server are specified in the RADIUS server template.

When the **radius-server algorithm master-backup** command has been executed to specify the master/backup algorithm on the RADIUS server and both the primary and secondary authentication servers are configured, the device sends an authentication request packet to the secondary authentication server in either of the following situations:

- The primary authentication server does not send an authentication response packet.
- The authentication request packet retransmission count reaches the maximum.

When the 802.1x authentication mode is set to EAP, the device and RADIUS authentication servers exchange packets multiple times. During the first exchange process, the device sends a request packet to the primary RADIUS authentication server. If the device resends the request packet for the maximum number of times but does not receive a response packet from the primary RADIUS authentication server, the device sends a request packet to the secondary RADIUS authentication server. If the secondary RADIUS authentication server sends a response packet to the device, the device will directly send request packets to the secondary RADIUS authentication server in the following exchange processes. In this way, the device does not need to send a request packet to the primary RADIUS authentication server first in the following exchange processes, shortening the authentication time and preventing the user authentication connection from being disconnected because the client does not receive a response packet for a long time.

Example

```
# Configure the IP address of the primary RADIUS authentication server to  
10.163.155.13 and the port number to 1812.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template group1  
[HUAWEI-radius-group1] radius-server authentication 10.163.155.13 1812
```

```
# Configure the IP address of the secondary RADIUS authentication server to  
10.163.155.15, the port number to 1812 and the weigh to 50.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template group1  
[HUAWEI-radius-group1] radius-server authentication 10.163.155.15 1812 weight 50
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.29 radius-server authorization

Function

The **radius-server authorization** command configures the RADIUS authorization server.

The **undo radius-server authorization** command deletes the configured RADIUS authorization server.

By default, no RADIUS authorization server is configured.

Format

```
radius-server authorization ip-address [ vpn-instance vpn-instance-name ]  
{ server-group group-name shared-key cipher key-string | shared-key cipher  
key-string [ server-group group-name ] } [ ack-reserved-interval interval ]
```

```
undo radius-server authorization { all | ip-address [ vpn-instance vpn-instance-  
name ] }
```

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the IP address of a RADIUS authorization server.	The value is a unicast address in dotted decimal notation.
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance that the RADIUS authorization server is bound to.	The value must be an existing VPN instance name.
server-group <i>group-name</i>	Specifies the name of a RADIUS group corresponding to a RADIUS server template.	The value is a string of 1 to 32 characters, including letters (case-sensitive), numerals (0 to 9), punctuation mark (.), dash (-), and underline (_). The value cannot be - or --.

Parameter	Description	Value
shared-key cipher <i>key-string</i>	Specifies the shared key of a RADIUS server.	The value is a case-sensitive character string without spaces or question marks (?). <i>key-string</i> can be a string of 1 to 128 characters in plain text or a string of 48, 68, 88, 108, 128, 148, 168, or 188 characters in cipher text.
ack-reserved-interval <i>interval</i>	Specifies the duration for retaining a RADIUS authorization response packet.	The value is an integer that ranges from 0 to 300, in seconds. By default, the value is 0s.
all	Deletes all RADIUS authorization servers.	-

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

An independent RADIUS authorization server can be used to authorize online users. RADIUS provides two authorization methods: Change of Authorization (CoA) and Disconnect Message (DM).

- CoA: After a user is successfully authenticated, you can modify the rights of the online user through the RADIUS authorization server. For example, a VLAN ID can be delivered to access users of a certain department through CoA packets, so that they belong to the same VLAN no matter which interfaces they connect to.
- DM: The administrator can forcibly disconnect a user through the RADIUS authorization server.

After the parameters such as IP address and shared key are configured for the RADIUS authorization server, the device can receive authorization requests from the server and grant rights to users according to the authorization information. After authorization is complete, the device returns authorization response packets carrying the results to the server.

Precautions

To improve security, it is recommended that the password contains at least three types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 16 characters.

Example

Specify a RADIUS authorization server.

```
<HUAWEI> system-view  
[HUAWEI] radius-server authorization 10.1.1.116 shared-key cipher Huawei@2012
```

Related Topics

[13.2.9 display radius-server authorization configuration](#)

[13.2.45 radius-server template](#)

13.2.30 radius-server authorization attribute-decode-sameastemplate

Function

The **radius-server authorization attribute-decode-sameastemplate** command configures the device to parse RADIUS dynamic authorization packet attributes based on the configuration in RADIUS server template.

The **undo radius-server authorization attribute-decode-sameastemplate** command restores the default method of parsing RADIUS authorization packet attributes.

By default, the device parses RADIUS dynamic authorization packet attributes based on global configuration.

Format

radius-server authorization attribute-decode-sameastemplate

undo radius-server authorization attribute-decode-sameastemplate

Parameters

None.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The device parses the MAC address in the Calling-Station-Id attribute in RADIUS dynamic authorization packets. By default, the MAC address format that can be parsed is configured using the **radius-server authorization calling-station-id decode-mac-format** command in the system view. When the device is connected to multiple RADIUS servers, the MAC address formats are different in the Calling-Station-Id attribute in dynamic authorization packets sent by different RADIUS servers. In this case, the MAC address may fail to be parsed if the same parse mode is used, resulting in that the device fails to be connected to some RADIUS servers. You can run the **radius-server authorization attribute-decode-sameastemplate** command to configure the device to parse RADIUS dynamic authorization packet attributes based on the Calling-Station-Id attribute encapsulation mode configured in each RADIUS server template, making the device be successfully connected to multiple RADIUS servers.

Prerequisites

This function is used to make the Calling-Station-Id attribute parse mode the same as the Calling-Station-Id attribute encapsulation mode configured in RADIUS server template. Therefore, make sure that the following steps have been performed before using this function.

1. The **calling-station-id mac-format** command has been run in the RADIUS server template view to configure the encapsulation mode of the MAC address in the Calling-Station-Id attribute.
2. The **radius-server authorization** command has been run in the system view to configure the authorization server to use the RADIUS server template **server-group**.

NOTE

If the RADIUS server template used by the authorization server is not specified, this function cannot be implemented on a device. You can run the **radius-server authorization calling-station-id decode-mac-format** command in the system view to configure the Calling-Station-Id attribute parse mode.

Precautions

The configuration in a RADIUS server template has a higher priority than the global configuration.

Example

Configure the RADIUS authorization server to parse attributes depending on the configuration in a RADIUS template.

```
<HUAWEI> system-view  
[HUAWEI] radius-server authorization attribute-decode-sameastemplate
```

13.2.31 radius-server authorization calling-station-id decode-mac-format

Function

The **radius-server authorization calling-station-id decode-mac-format** command sets the format of MAC address that can be parsed by a device in the calling-station-id (Type 31) attribute carried in RADIUS authorization packets.

The **undo radius-server authorization calling-station-id decode-mac-format** command restores the default format of the MAC address in the calling-station-id (Type 31) attribute.

By default, the MAC address format in the calling-station-id attribute carried in RADIUS dynamic authorization packets is xxxxxxxxxxxx, in lowercase.

Format

radius-server authorization calling-station-id decode-mac-format { bin | ascii
{ unformatted | { dot-split | hyphen-split } [common | compress] }

undo radius-server authorization calling-station-id decode-mac-format

Parameters

Parameter	Description	Value
bin	Indicates that the MAC address in the calling-station-id attribute uses the binary format.	-
ascii	Indicates that the MAC address in the calling-station-id attribute uses the ASCII format.	-
unformatted	Indicates that no separator is used in the MAC address in the calling-station-id field.	-
dot-split	Indicates that dots are used as the separators in MAC address.	-
hyphen-split	Indicates that the hyphens are used as the separators in MAC address.	-
common	Indicates that the MAC address in the calling-station-id attribute uses the "xxseparatorxxseparatorxxseparatorxxseparatorxxseparatorxx" format.	-
compress	Indicates that the MAC address in the calling-station-id attribute uses the "xxxxseparatorxxxxseparatorxxxx" format.	-

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

By default, the MAC address format in the calling-station-id attribute carried in RADIUS dynamic authorization packets is xxxxxxxxxxxx. If the MAC address format in the calling-station-id attribute sent by the RADIUS server is not the default format used on the device, run the **radius-server authorization calling-station-id decode-mac-format** command to change the MAC address format on the device.

When a device connects to multiple RADIUS servers, the RADIUS servers may send MAC addresses in different formats in the calling-station-id attribute to the device. You need to run the **radius-server authorization attribute-decode-sameasemplate** command to configure the device to parse the RADIUS authorization packet attributes based on the configuration in RADIUS server template, so that the device can work with these RADIUS servers.

Precautions

The configuration in a RADIUS server template has a higher priority than the global configuration.

Example

Set the format of MAC address that can be parsed by the device in the calling-station-id attribute to binary.

```
<HUAWEI> system-view  
[HUAWEI] radius-server authorization calling-station-id decode-mac-format bin
```

13.2.32 radius-server dead-detect-condition by-server-ip

Function

The **radius-server dead-detect-condition by-server-ip** command configures keepalive detection for RADIUS server based on the RADIUS server IP address.

The **undo radius-server dead-detect-condition by-server-ip** command restores the default setting.

By default, keepalive detection is performed for only RADIUS authentication server.

Format

radius-server dead-detect-condition by-server-ip

undo radius-server dead-detect-condition by-server-ip

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The device periodically sends authentication request packets to the RADIUS server in Down state. If the RADIUS server responds, the device sets the RADIUS authentication server status to Up. The device does not perform keepalive detection for RADIUS accounting servers in Down state. Instead, the device sets the RADIUS accounting server status to Up only when the server recovery time expires.

To allow the device to promptly detect the status of RADIUS accounting servers that are in Down state, run the **radius-server dead-detect-condition by-server-ip** command. After the command is executed, the device performs keepalive detection on RADIUS servers based on the RADIUS server IP address, so that the status of RADIUS accounting server is associated with the status of authentication server.

Precautions

After the **radius-server dead-detect-condition by-server-ip** command is executed, run the **radius-server testuser** command to configure automatic user detection.

When detecting the Down states of RADIUS authentication and accounting servers, the device counts the numbers of authentication and accounting request packets separately. After the **radius-server dead-detect-condition by-server-ip** command is executed, if the authentication and accounting servers sharing the same IP address are in the same VPN instance, the device accumulates the number of authentication and accounting packets sent by the servers. In addition, the status of RADIUS authentication server with the same IP address in the same VPN instance is updated.

Example

```
# Configure keepalive detection for RADIUS server based on RADIUS server IP address.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server dead-detect-condition by-server-ip
```

13.2.33 radius-server dead-interval dead-count

Function

The **radius-server dead-interval dead-count** command configures the RADIUS server detection interval and maximum number of consecutive unacknowledged packets in each detection interval.

The **undo radius-server dead-interval dead-count** command restores the default settings.

By default, the RADIUS server detection interval is 5 seconds and the maximum number of consecutive unacknowledged packets in each detection interval is 2.

Format

```
radius-server { dead-interval dead-interval | dead-count dead-count }
```

```
undo radius-server { dead-interval | dead-count }
```

Parameters

Parameter	Description	Value
<i>dead-interval</i>	Specifies the RADIUS server detection interval.	The value is an integer that ranges from 1 to 300, in seconds.
<i>dead-count</i>	Specifies the maximum number of consecutive unacknowledged packets in each detection interval.	The value is an integer that ranges from 1 to 65535.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After the system starts, the RADIUS server status detection timer runs. The device sets the RADIUS server status to Up. When the device sends a RADIUS request packet to the RADIUS server, if the conditions for setting the RADIUS server status to Down are met, the device sets the RADIUS server status to Down; if the conditions are not met, the RADIUS server status remains to be Up.

If multiple RADIUS servers are configured, some servers are Up and the other servers are Down, and the device receives an authentication request packet from a user, the device retransmits the packet to a RADIUS server in Up status based on the server priority and detects the actual status of the server. The following describes the process in which a device detects the status of a RADIUS server.

1. If the device receives no response packet from the RADIUS server and the number of times that the device receives no response packet after sending an authentication request packet is greater than or equal to the maximum number of consecutive unacknowledged packets within the detection interval, the device records a communication interruption.
2. If the device records two consecutive communication interruptions with one RADIUS server, the device considers that the RADIUS server is unavailable and the condition for the device to set the status of the RADIUS server to Down is met.

NOTE

If the first connection attempt fails but the second one succeeds, the device deletes the recorded communication interruption with the RADIUS server.

3. When sending an authentication request packet to the RADIUS server again, the device sets the server status to Down. If a response packet is received

from the server, the device restores the server status to Up. If no response packet is received from the server and the number of retransmission times is not reached, the device sends an authentication request packet to the server again. If the server still does not respond, the device no longer sends any authentication request packet to the server.

If the device sets the status of all servers that are originally set to Up to Down after the device completes the server status detection based on the preceding detection process or these servers do not respond to the authentication request packets sent from the device, the device sends an authentication request packet to a RADIUS server that is originally set to be Down based on the server priority to detect the server status. (In the original mechanism, the device does not send authentication request packets to the RADIUS servers that are originally set to be Down.)

Precautions

- If the device has reported a RADIUS server Up alarm and needs to report a RADIUS server Down alarm, the device will send the Down alarm 10 seconds after the Up alarm is sent, even if the RADIUS server Down detection interval is shorter than 10 seconds (for example, the value of *dead-interval* is set to 4 seconds, and the RADIUS server Down detection interval is 8 seconds). This function prevents frequent alarm sending.
- To rapidly detect whether the RADIUS server goes Down, when there are a small number of users, smaller values are recommended for the detection interval and maximum number.
- If a user terminal is authenticated using a client and more than one server is deployed on the live network, the authentication request packet is retransmitted by each server upon timeout. If a server is faulty, the timeout wait period of the client software is smaller than the total timeout period of the servers, and the client repeatedly redials and cannot access the network. In addition, if the RADIUS server escape function is configured, the total timeout period of the servers is required to be smaller than the timeout period of the client software, ensuring that the escape rights can be properly configured for the user.

Therefore, run the [13.2.41 radius-server retransmit timeout dead-time](#) and [13.2.33 radius-server dead-interval dead-count](#) commands to ensure that users can properly access the network or are configured with proper escape rights. For example, the response timeout period of the RADIUS server is within 4 seconds and the timeout period of the 802.1X client is more than 18 seconds. The recommended configurations in the active/standby mode are as follows:

- When a server is configured:
 - Run the **radius-server dead-interval 5** and **radius-server dead-count 1** commands in the system view.
 - Run the **radius-server retransmit 3 timeout 5** command in the RADIUS server template view.
- When two servers are configured:
 - Run the **radius-server dead-interval 2** and **radius-server dead-count 1** commands in the system view.

- Run the **radius-server retransmit 3 timeout 2** command in the RADIUS server template view.
- When three servers are configured:
 - Run the **radius-server dead-interval 1** and **radius-server dead-count 1** commands in the system view.
 - Run the **radius-server retransmit 5 timeout 1** command in the RADIUS server template view.

Example

Set the RADIUS server detection interval to 10 seconds and maximum number of consecutive unacknowledged packets in each detection interval to 2.

```
<HUAWEI> system-view  
[HUAWEI] radius-server dead-interval 10  
[HUAWEI] radius-server dead-count 2
```

13.2.34 radius-server detect-server interval

Function

The **radius-server detect-server interval** command configures an automatic detection interval for RADIUS servers.

The **undo radius-server detect-server interval** command restores the default settings.

The default automatic detection interval is 60 seconds.

Format

radius-server detect-server interval *interval*

undo radius-server detect-server interval

Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the automatic detection interval for RADIUS servers.	The value is an integer that ranges from 5 to 3600, in seconds.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

After the automatic detection function is enabled using the [radius-server testuser](#) command, you can run the **radius-server detect-server interval** command to adjust the automatic detection interval for RADIUS servers.

Example

Set the automatic detection interval for RADIUS servers to 100 seconds in the RADIUS server template **acs**.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template acs  
[HUAWEI-radius-acs] radius-server detect-server interval 100
```

13.2.35 radius-server format-attribute

Function

The **radius-server format-attribute** command configures the format of the NAS-Port attribute.

The **undo radius-server format-attribute** command deletes the configured attribute format.

By default, the format of the NAS-Port attribute is **new**.

Format

radius-server format-attribute nas-port *nas-port-string*

undo radius-server format-attribute nas-port

Parameters

Parameter	Description	Value
<p>nas-port <i>nas-port-string</i></p>	<p>Specifies the format of the NAS-Port attribute.</p> <ul style="list-style-type: none"> • The keywords s, t, p, o, and i stand for slot, subslot, port, out-vlan (qinqvlan)/vpi, and vlan (user-vlan)/vci respectively. The keywords n and z are used as paddings. The keyword n indicates 1 and the keyword z indicates 0. • The keywords s, t, p, o, and i must be followed by numbers, and the numbers must range from 1 to 32. The keywords s, t, p, o, and i can be present in the format string only once. • The keywords s, t, p, o, i, n, and z must range from 1 to 9. • n and z can be present multiple times at any position. They are followed by numbers. For example, n12 indicates that this position is filled by twelve 1s, and z12 indicates that this position is filled by twelve 0s. • The character string must contain 32 bits. • The format string must start with s, t, p, o, i, n, or z and end with a number. • If no VLAN exists, you can add n or z before o or i to indicate whether this position 	<p>The value is a string of 1 to 32 characters.</p>

Parameter	Description	Value
	<p>is filled by 0s or 1s. That is, n and z can be followed by numbers or o/i in this case, and the numbers must range from 1 to 32.</p> <ul style="list-style-type: none"> To specify the format string, determine the interface type, and then determine the encapsulation type of the interface. If the format string does not contain o or i, the NAS-Port attribute does not contain the QinQ VLAN or user VLAN field. If the format string contains o or i but no outer VLAN exists, the outer VLAN field is filled by 0s. If n is added before o or i, this field is filled by 1s when no outer VLAN or inner VLAN exists. 	

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

The NAS port format affects the information about the physical port. The NAS port format can be used by the RADIUS server to process services, such as binding the user name and port. This attribute is developed by Huawei, which is used to ensure connectivity and service cooperation among Huawei devices.

If the **radius-server nas-port-format** command sets the format of the NAS-Port attribute to **new** (the default format is **new**), the device will check whether the **radius-server format-attribute nas-port** command configuration exists. If yes, the device will assemble the NAS-Port attribute in the format configured by the **radius-server format-attribute nas-port** command. If no, the device will

assemble the NAS-Port attribute in the **new** format. If the **radius-server nas-port-format** command sets the format of the NAS-Port attribute to **old**, the device will assemble the NAS-Port attribute in the **old** format, regardless of whether the **radius-server format-attribute nas-port** command configuration exists.

Example

Configure the format of the NAS-Port attribute to s2t2p6no10ni12. That is, the NAS-Port attribute consists of a 2-bit slot field, a 2-bit subslot field, a 6-bit port field, a 10-bit outer VLAN field, and a 12-bit inner VLAN field. If the outer VLAN does not exist, this field is filled by ten 1s. If the inner VLAN does not exist, this field is filled by twelve 1s. Therefore, the NAS-port attribute contains 32 bits.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template template1  
[HUAWEI-radius-template1] radius-server format-attribute nas-port s2t2p6no10ni12
```

Related Topics

[13.2.39 radius-server nas-port-format](#)

13.2.36 radius-server hw-ap-info-format include-ap-ip

Function

The **radius-server hw-ap-info-format include-ap-ip** command configures the AP's IP address carried in Huawei extended attribute HW-AP-Information.

The **undo radius-server hw-ap-info-format** command restores the default setting.

By default, Huawei extended attribute HW-AP-Information does not carry AP's IP address.

NOTE

This function is supported only by S5720HI.

Format

radius-server hw-ap-info-format include-ap-ip

undo radius-server hw-ap-info-format

Parameters

None

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

RADIUS is a fully extensible protocol. Device vendors can expand the No. 26 attribute defined in the protocol to implement functions not supported by standard RADIUS attributes. Huawei defines the No. 141 sub-attribute (HW-AP-Information) in the No. 26 attribute to indicate AP information, including the MAC and IP addresses of an AP. The HW-AP-Information attribute is carried in the authentication or accounting request packet send by a device, so that the RADIUS server can use the AP's MAC and IP addresses as the filter criterion to select a policy template to be delivered.

When an AP's IP address is carried in the HW-AP-Information attribute, the encapsulation format of the attribute is AP-MAC AP-IP.

Example

#Configure the AP's IP address in Huawei extended attribute HW-AP-Information.

```
<HUAWEI> system-view
[HUAWEI] radius-server template huawei
[HUAWEI-radius-huawei] radius-server hw-ap-info-format include-ap-ip
```

13.2.37 radius-server hw-dhcp-option-format

Function

The **radius-server hw-dhcp-option-format** command sets the format of the Huawei extended attribute HW-DHCP-Option.

The **undo radius-server hw-dhcp-option-format** command restores the default setting.

By default, the format of HW-DHCP-Option is old.

Format

radius-server hw-dhcp-option-format { new | old }

undo radius-server hw-dhcp-option-format

Parameters

Parameter	Description	Value
new	Sets the format of Huawei extended attribute HW-DHCP-Option to new.	-
old	Sets the format of Huawei extended attribute HW-DHCP-Option to old.	-

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

The RADIUS protocol has good extensibility. Device vendors can expand the No. 26 RADIUS attribute to implement new functions. Huawei defines that the No.158 sub-attribute in the No.26 attribute represents DHCP option and is encapsulated through Type, Length, Value (TLV). The device adds this attribute in authentication request or accounting request packets and sends the DHCP option information to the RADIUS server.

To connect to different types of RADIUS server, the device supports two HW-DHCP-Option formats: **new** and **old**.

- **new**: When the attribute is encapsulated through TLV, the Type field length is 1 byte. This format is applicable when the device connects to most types of RADIUS servers.
- **old**: When the attribute is encapsulated through TLV, the Type field length is 2 bytes. This format is applicable when the device connects to special RADIUS servers, for example, Huawei RADIUS server.

Example

```
# Set the format of Huawei extended attribute HW-DHCP-Option to new.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template huawei  
[HUAWEI-radius-huawei] radius-server hw-dhcp-option-format new
```

13.2.38 radius-server nas-identifier-format

Function

The **radius-server nas-identifier-format** command sets the encapsulation format of the NAS-Identifier attribute.

The **undo radius-server nas-identifier-format** command restores the default encapsulation format of the NAS-Identifier attribute.

By default, the NAS-Identifier attribute encapsulation format is the device's hostname.

Format

```
radius-server nas-identifier-format { hostname | vlan-id }
```

```
undo radius-server nas-identifier-format
```

Parameters

Parameter	Description	Value
hostname	Sets the encapsulation format of NAS-Identifier to a device's host name.	-
vlan-id	Sets the encapsulation format of NAS-Identifier to a user's VLAN ID.	-

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

A RADIUS server uses the NAS-Identifier attributes to identify NASs. The NASs also use the NAS-Identifier attributes carried in the sent RADIUS packets to identify themselves.

Example

```
# Set the NAS-Identifier encapsulation format to VLAN ID.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template template1  
[HUAWEI-radius-template1] radius-server nas-identifier-format vlan-id
```

13.2.39 radius-server nas-port-format

Function

The **radius-server nas-port-format** command sets the format of the NAS port attribute.

The **undo radius-server nas-port-format** command restores the default format of the NAS port attribute.

By default, the new NAS port format is used.

Format

```
radius-server nas-port-format { new | old }
```

```
undo radius-server nas-port-format
```

Parameters

Parameter	Description	Value
new	Uses the new format of an NAS port. The new format of the NAS port attribute is slot number (8 bits) + subslot number (4 bits) + port number (8 bits) + VLAN ID (12 bits).	-
old	Uses the old format of an NAS port. The old format of the NAS port attribute is slot number (12 bits) + port number (8 bits) + VLAN ID (12 bits).	-

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The NAS port format affects the information about the physical port. The NAS port format can be used by the RADIUS server to process services, such as binding the user name and port. This attribute is developed by Huawei, which is used to ensure connectivity and service cooperation among Huawei devices.

Precautions

The difference between the two NAS port formats lies in the physical ports connected to Ethernet access users.

- The new format of the NAS port attribute is slot number (8 bits) + subslot number (4 bits) + port number (8 bits) + VLAN ID (12 bits).
- The old format of the NAS port attribute is slot number (12 bits) + port number (8 bits) + VLAN ID (12 bits).

The format of the NAS port attribute for Asymmetric Digital Subscriber Line (ADSL) access users is slot number (4 bits) + subslot number (2 bits) + port number (2 bits) + VPI (8 bits) + VCI (16 bits). This format is not affected by the command.

Example

Set the format of the NAS port attribute to **new**.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template template1  
[HUAWEI-radius-template1] radius-server nas-port-format new
```

13.2.40 radius-server nas-port-id-format

Function

The **radius-server nas-port-id-format** command sets the format of the NAS port ID attribute.

The **undo radius-server nas-port-id-format** command restores the default format of the NAS port ID attribute.

By default, the new format of the NAS port ID attribute is used.

Format

radius-server nas-port-id-format { new | old | vm }

undo radius-server nas-port-id-format

Parameters

Parameter	Description	Value
new	Uses the new format of the NAS port ID.	-
old	Uses the old format of the NAS port ID.	-
vm	Uses the NAS port ID format of the VM. NOTE Only the S5720EI supports this parameter.	-

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The NAS port format and the NAS port ID format are developed by Huawei, which are used to ensure connectivity and service cooperation among Huawei devices.

Precautions

When **new** is specified:

- For Ethernet access users, the NAS port ID format is *slot=xx; subslot=xx; port=xxx; VLAN ID=xxxx*, in which *slot* ranges from 0 to 15, *subslot* from 0 to 15, *port* from 0 to 255, and *VLAN ID* from 1 to 4094.
- For ADSL access users, the NAS port ID format is *slot=xx; subslot=x; port=x;VPI=xxx; VCI=xxxxx*, in which *slot* ranges from 0 to 15, *subslot* from 0 to 9, *port* from 0 to 9, *VPI* from 0 to 255, and *VCI* from 0 to 65535.

When **old** is specified:

- For Ethernet access users, the NAS port ID format is slot number (2 characters) + subslot number (2 bytes) + card number (3 bytes) + VLAN ID (9 characters).
- For ADSL access users, the NAS port ID format is slot number (2 characters) + subslot number (2 bytes) + card number (3 bytes) + VPI (8 characters) + VCI (16 characters). A field is prefixed with 0s if its actual value contains fewer characters.

Example

Set the format of the NAS port ID attribute to **new**.

```
<HUAWEI> system-view
[HUAWEI] radius-server template template1
[HUAWEI-radius-template1] radius-server nas-port-id-format new
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.41 radius-server retransmit timeout dead-time

Function

The **radius-server retransmit timeout dead-time** command sets the number of times that RADIUS request packets are retransmitted, timeout period, and interval for the server to revert to the active status.

The **undo radius-server retransmit timeout dead-time** command restores the default number of retransmission times, the default timeout period, and the default interval for the server to revert to the active status.

By default, the number of retransmission times is 3, timeout period is 5 seconds, and the interval for the server to revert to the active status is 5 minutes.

Format

```
radius-server { retransmit retry-times | timeout time-value | dead-time dead-time } *
```

```
undo radius-server { retransmit [ retry-times ] | timeout [ time-value ] | dead-time [ dead-time ] } *
```

Parameters

Parameter	Description	Value
retransmit <i>retry-times</i>	Specifies the number of retransmission times. The value is the total number of times a packet is transmitted.	The value is an integer that ranges from 1 to 5.
timeout <i>time-value</i>	Specifies the timeout period.	The value is an integer that ranges from 1 to 10, in seconds.
dead-time <i>dead-time</i>	Specifies the interval for the server to revert to the active status.	The value is an integer that ranges from 1 to 65535, in minutes.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The retransmission upon timeout mechanism is configured for a device to forward RADIUS Access-Request packets sourced from users to the server. The overall retransmission time depends on the retransmission interval, retransmission times, RADIUS server status, and number of servers configured in the RADIUS server template.

You can configure the number of times that RADIUS request packets are retransmitted and the timeout period using the **radius-server retransmit** *retry-times* and **radius-server timeout** *time-value* commands, respectively. If a device sends an authentication request packet to the RADIUS server and does not receive any response packet from the server during the timeout period, the device sends an authentication request packet again.

You can run the **radius-server dead-time** *dead-time* command to configure the duration for which the RADIUS server status remains Down. After the device sets the RADIUS server status to Down and the interval specified by *dead-time* expires, the device resets the server status to Force-up. If a new user needs to be authenticated in RADIUS mode and no RADIUS server is available, the device attempts to re-establish a connection with a RADIUS server in Force-up status. The Force-up status is defined to prevent servers in Down status from remaining idle.

 NOTE

If automatic detection for RADIUS servers is configured using the **radius-server testuser** command, the server status is maintained using the automatic detection function. The interval for the RADIUS server to revert to the active status configured using the **radius-server retransmit timeout dead-time** command does not take effect.

This command can improve the reliability of RADIUS authentication.

Precautions

- The request packet retransmission time (number of retransmission times x timeout period) of the RADIUS server must be shorter than the request packet retransmission time of the Portal server.
- If more than 8 authentication server IP addresses are configured in the RADIUS server template, reduce the number of retransmission times and timeout period.
- To rapidly detect whether the RADIUS server goes Down, smaller values are recommended for the timeout period and number of retransmission times when there are a small number of users.

Example

Set the number of retransmission times to 3, the timeout period to 2s, and the interval for the server to revert to the active status to 10 minutes.

```
<HUAWEI> system-view
[HUAWEI] radius-server template test1
[HUAWEI-radius-test1] radius-server retransmit 3 timeout 2 dead-time 10
```

Related Topics

- [13.2.10 display radius-server configuration](#)
- [13.2.45 radius-server template](#)

13.2.42 radius-server session-manage

Function

The **radius-server session-manage** command enables session management on the RADIUS server.

The **undo radius-server session-manage** command disables session management on the RADIUS server.

By default, session management is disabled on the RADIUS server.

Format

radius-server session-manage { *ip-address* [**vpn-instance** *vpn-instance-name*] **shared-key cipher** *share-key* | **any** }

undo radius-server session-manage [*ip-address* [**vpn-instance** *vpn-instance-name*] | **all**]

 NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the IP address of the RADIUS session management server.	The value is in dotted decimal notation.
vpn-instance <i>vpn-instance-name</i>	Specifies the name of the VPN instance bound to the RADIUS session management server.	The value must be the name of an existing VPN instance.
shared-key cipher <i>share-key</i>	Specifies the shared key of the RADIUS session management server.	The value is a string of case-sensitive characters without spaces, and question marks. <i>share-key</i> can be a string of 1-128 characters in plain text or a string of 48, 68, 88, 108, 128, 148, 168, or 188 characters in cipher text.
any	Indicates that no RADIUS session management server is specified.	-
all	Deletes all RADIUS session management servers.	-

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To improve device security, run this command to enable session management on the RADIUS server. After this function is enabled, the device checks the source IP addresses and shared keys for the received session management packets. When

the source IP addresses and shared keys match the configured values, the packets are processed; otherwise, the packets are discarded.

Precautions

- This command has been supported since V200R010C00. When a device is upgraded from a version earlier than V200R010C00 to V200R010C00 or a later version, the **radius-server session-manage any** command is configured by default.
- When the **any** parameter is specified, there is a security risk. You are advised to configure the IP address and shared key for a specified RADIUS session management server.

Example

Enable session management on the RADIUS server, and set the IP address and shared key of the RADIUS session management server to 10.1.1.1 and **Huawei@2012** respectively.

```
<HUAWEI> system-view
[HUAWEI] radius-server session-manage 10.1.1.1 shared-key cipher Huawei@2012
```

Related Topics

[13.2.13 display radius-server session-manage configuration](#)

13.2.43 radius-server shared-key (RADIUS server template view)

Function

The **radius-server shared-key** command configures the shared key of a RADIUS server.

The **undo radius-server shared-key** command deletes the shared key of a RADIUS server.

The default username and password are available in *S Series Switches Default Usernames and Passwords* ([Enterprise Network](#) or [Carrier](#)). If you have not obtained the access permission of the document, see **Help** on the website to find out how to obtain it.

Format

radius-server shared-key cipher *key-string*

undo radius-server shared-key

Parameters

Parameter	Description	Value
cipher	Indicates the shared key in cipher text.	-

Parameter	Description	Value
<i>key-string</i>	Specifies the shared key of a RADIUS server.	The value is a case-sensitive character string without spaces, single quotation marks ('), or question marks (?). <i>key-string</i> can be a string of 1-128 characters in plain text or a string of 48, 68, 88, 108, 128, 148, 168, or 188 characters in cipher text.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The shared key is used to encrypt the password and generate the response authenticator.

When exchanging authentication packets with a RADIUS server, the device uses MD5 to encrypt important data such as the password to ensure security of data transmission over the network. To ensure validity of both communication parties, the device and RADIUS server must be configured with the same shared key.

Example

Set the shared key of a RADIUS server to **Huawei@2012** in cipher text.

```
<HUAWEI> system-view
[HUAWEI] radius-server template template1
[HUAWEI-radius-template1] radius-server shared-key cipher Huawei@2012
```

Related Topics

[13.2.10 display radius-server configuration](#)

[13.2.45 radius-server template](#)

13.2.44 radius-server shared-key (system view)

Function

The **radius-server shared-key** command configures the shared key of a RADIUS server.

The **undo radius-server shared-key** command deletes the shared key of a RADIUS server.

By default, no global shared key is configured for the RADIUS server.

Format

radius-server ip-address { *ipv4-address* | *ipv6-address* } **shared-key cipher** *key-string*

undo radius-server ip-address { *ipv4-address* | *ipv6-address* } **shared-key**

Parameters

Parameter	Description	Value
ip-address { <i>ipv4-address</i> <i>ipv6-address</i> }	Specifies the IPv4 or IPv6 address of the RADIUS server.	<ul style="list-style-type: none">• <i>ipv4-address</i>: The value is in dotted decimal notation.• <i>ipv6-address</i>: The value is a 32-bit hexadecimal string in format X:X:X:X:X:X.
cipher <i>key-string</i>	Specifies the shared key in cipher text.	The value is a case-sensitive character string without spaces, single quotation marks ('), or question marks (?). <i>key-string</i> can be a string of 1-128 characters in plain text or a string of 48, 68, 88, 108, 128, 148, 168, or 188 characters in cipher text.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The shared key is used to encrypt the password and generate the response authenticator.

When exchanging authentication packets with a RADIUS server, the device uses MD5 to encrypt important data such as the password to ensure security of data

transmission over the network. To ensure validity of both communication parties, the device and RADIUS server must be configured with the same shared key.

You can run the [13.2.43 radius-server shared-key \(RADIUS server template view\)](#) command in the RADIUS server template view to configure the shared keys. However, after this command is run, all RADIUS servers in the template use the same shared key. To configure different shared keys for RADIUS servers, run the **radius-server shared-key** command in the system view.

Precautions

To improve security, it is recommended that the shared key contains at least two types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 6 characters.

When the shared keys are configured in both the RADIUS server template and system view, the configuration in the system view takes effect.

Example

```
# Set the shared key for RADIUS server to Huawei@2012.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server ip-address 10.1.1.1 shared-key cipher Huawei@2012
```

Related Topics

[13.2.43 radius-server shared-key \(RADIUS server template view\)](#)

13.2.45 radius-server template

Function

The **radius-server template** command creates a RADIUS server template and displays the RADIUS server template view.

The **undo radius-server template** command deletes a RADIUS server template.

By default, the device contains the RADIUS server template **default**. The template can be modified, but cannot be deleted.

Format

radius-server template *template-name*

undo radius-server template *template-name*

Parameters

Parameter	Description	Value
<i>template-name</i>	Specifies the name of a RADIUS server template.	The value is a string of 1 to 32 case-sensitive characters, including letters (case-sensitive), numerals (0 to 9), punctuation mark (.), underline (_), and hyphens (-). The value cannot be - or --.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

Creating a RADIUS server template is the prerequisite for configuring RADIUS authentication and accounting. You can perform RADIUS configurations, such as the configuration of authentication servers, accounting servers, and shared key only after a RADIUS server template is created.

Follow-up Procedure

Configure an authentication server, an accounting server, and shared key in the RADIUS server template view, and then run the [13.2.22 radius-server \(aaa domain view\)](#) command to apply the RADIUS server template.

Example

Create a RADIUS server template **template1** and enter the RADIUS server template view.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template template1  
[HUAWEI-radius-template1]
```

Related Topics

[13.2.10 display radius-server configuration](#)

[13.2.22 radius-server \(aaa domain view\)](#)

13.2.46 radius-server testuser

Function

The **radius-server testuser** command enables the automatic detection function and configures an automatic detection account.

The **undo radius-server testuser** command restores the default settings.

By default, the automatic detection function is disabled.

Format

radius-server testuser **username** *user-name* **password** **cipher** *password*

undo radius-server testuser

Parameters

Parameter	Description	Value
username <i>user-name</i>	Specifies a user name used for automatic detection.	The value is a string of 1 to 253 case-sensitive characters. If the user name contains spaces, you must enclose the name with double quotation marks ("), for example, "user for test".
password cipher <i>password</i>	Specifies the user password for automatic detection.	The value is a character string of 1 to 128 characters without spaces and question marks. It is case sensitive. If it is in cipher text, the password is a string of 48, 68, 88, 108, 128, 148, 168, or 188 characters.

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

After the RADIUS server status is set to Down, you can configure the automatic detection function to test the RADIUS server reachability.

After automatic detection is configured for users, the device periodically performs automatic detection on the RADIUS server in Down status. You can set the automatic detection interval using the **radius-server detect-server** command.

For the automatic status detection function, only the automatic detection user name and password need to be configured in the RADIUS server template on the device, and the automatic detection account does not need to be configured on the RADIUS server. Authentication success is not mandatory. If the device can receive the authentication failure response packet, the RADIUS server is properly working and the device sets the RADIUS server status to Up. If the device cannot receive the response packet, the RADIUS server is unavailable and the device sets the RADIUS server status to Down.

Example

Create a user account with the user name **test** and password **Huawei@2012** in RADIUS server template **acs**.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template acs  
[HUAWEI-radius-acs] radius-server testuser username test password cipher Huawei@2012
```

13.2.47 radius-server traffic-unit

Function

The **radius-server traffic-unit** command sets the traffic unit used by a RADIUS server.

The **undo radius-server traffic-unit** command restores the default traffic unit used by a RADIUS server.

The default RADIUS traffic unit is byte on the device.

Format

radius-server traffic-unit { byte | kbyte | mbyte | gbyte }

undo radius-server traffic-unit

Parameters

Parameter	Description	Value
byte	Indicates that the traffic unit is byte.	-
kbyte	Indicates that the traffic unit is kilobyte.	-
mbyte	Indicates that the traffic unit is megabyte.	-
gbyte	Indicates that the traffic unit is gigabyte.	-

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Different RADIUS servers may use different traffic units; therefore, you need to set the traffic unit for each RADIUS server group on the router and the traffic unit must be the same as that on the RADIUS server.

Example

```
# Set the traffic unit used by a RADIUS server to kilobyte.
```

```
<HUAWEI> system-view  
[HUAWEI] radius-server template template1  
[HUAWEI-radius-template1] radius-server traffic-unit kbyte
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.48 radius-server user-name domain-included

Function

The **radius-server user-name domain-included** command configures the device to encapsulate the domain name in the user name in RADIUS packets to be sent to a RADIUS server.

The **radius-server user-name original** command configures the device not to modify the user name entered by the user in the packets sent to the RADIUS server.

The **undo radius-server user-name domain-included** command configures the device not to encapsulate the domain name in the user name when sending RADIUS packets to a RADIUS server.

The **undo radius-server user-name domain-included except-eap** command configures the device not to encapsulate the domain name in the user name when sending packets to a RADIUS server (applicable to other authentication modes except EAP authentication).

By default, the device does not modify the user name entered by the user in the packets sent to the RADIUS server.

Format

radius-server user-name domain-included

radius-server user-name original

undo radius-server user-name domain-included

undo radius-server user-name domain-included except-eap

Parameters

None

Views

RADIUS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The format of a user name is user name@domain name. In the user name, @ is the domain name delimiter. The domain name delimiter can also be any of the following symbols: \ / : < > | ' %.

If the RADIUS server does not accept the user name with the domain name, run the **undo radius-server user-name domain-included** command to delete the domain name from the user name.

Precautions

If the user names in the RADIUS packets sent from the device to RADIUS server contain domain names, ensure that the total length of a user name (user name + domain name delimiter + domain name) is not longer than 253 characters; otherwise, the user name cannot be contained in RADIUS packets. As a result, authentication will fail.

Example

Configure the device not to encapsulate the domain name in the user name when sending RADIUS packets to a RADIUS server.

```
<HUAWEI> system-view  
[HUAWEI] radius-server template template1  
[HUAWEI-radius-template1] undo radius-server user-name domain-included
```

Related Topics

[13.2.10 display radius-server configuration](#)

13.2.49 reset radius-server accounting-stop-packet

Function

The **reset radius-server accounting-stop-packet** command clears statistics on the remaining buffer information of RADIUS accounting-stop packets.

Format

```
reset radius-server accounting-stop-packet { all | ip { ipv4-address | ipv6-  
address } }
```

Parameters

Parameter	Description	Value
all	Clears statistics on the remaining buffer information of RADIUS accounting-stop packets.	-
ip <i>ipv4-address</i>	Clears statistics on the remaining buffer information of RADIUS accounting-stop packets with the specified IPv4 address.	The value of <i>ipv4-address</i> is in dotted decimal notation.
ip <i>ipv6-address</i>	Clears statistics on the remaining buffer information of RADIUS accounting-stop packets with the specified IPv6 address.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X:X.

Views

User view

Default Level

3: Management level

Usage Guidelines

This command can clear statistics on the remaining buffer information of RADIUS accounting-stop packets. The deleted statistics cannot be restored.

Example

```
# Clear statistics on the remaining buffer information of all RADIUS accounting-  
stop packets.
```

```
<HUAWEI> reset radius-server accounting-stop-packet all
```

Related Topics

[13.2.8 display radius-server accounting-stop-packet](#)

13.2.50 snmp-agent trap enable feature-name radius

Function

The **snmp-agent trap enable feature-name radius** command enables the trap function for the RDS module.

The **undo snmp-agent trap enable feature-name radius** command disables the trap function for the RDS module.

By default, the trap function is disabled for the RDS module.

Format

snmp-agent trap enable feature-name radius [**trap-name**
{ **hwradiusacctserverdown** | **hwradiusacctserverup** | **hwradiusauthserverdown** |
hwradiusauthserverup }]

undo snmp-agent trap enable feature-name radius [**trap-name**
{ **hwradiusacctserverdown** | **hwradiusacctserverup** | **hwradiusauthserverdown** |
hwradiusauthserverup }]

Parameters

Parameter	Description	Value
trap-name	Enables or disables the trap function for a specified event of the RDS module.	-
hwradiusacctserver-down	Enables the device to send a Huawei proprietary trap when it detects that communication with the RADIUS accounting server is interrupted.	-
hwradiusacctserverup	Enables the device to send a Huawei proprietary trap when it detects that communication with the RADIUS accounting server is restored.	-
hwradiusauthserver-down	Enables the device to send a Huawei proprietary trap when it detects that communication with the RADIUS authentication server is interrupted.	-

Parameter	Description	Value
hwradiusauthserverup	Enables the device to send a Huawei proprietary trap when it detects that communication with the RADIUS authentication server is restored.	-

Views

System view

Default Level

3: Management level

Usage Guidelines

After the trap function is enabled, the device generates traps during operation and sends the traps to the NMS through the SNMP module. If the trap function is disabled, the device does not generate traps and the SNMP module does not send traps to the NMS.

You can specify **trap-name** to enable the trap function for one or more events.

Example

Enable the trap function for hwradiusacctserverdown of the RDS module.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name radius trap-name hwradiusacctserverdown
```

Related Topics

[13.2.14 display snmp-agent trap feature-name radius all](#)

13.2.51 test-aaa

Function

The **test-aaa** command tests the connectivity between the device and the authentication server or accounting server, and tests whether a user can be authenticated using authentication server and whether the accounting server can charge a user.

Format

```
test-aaa user-name user-password radius-template template-name [ chap | pap  
| accounting [ start | realtime | stop ] ]
```

Parameters

Parameter	Description	Value
<i>user-name</i>	Specifies a user name.	The value is a string of 1 to 253 case-insensitive characters. When the user name contains spaces, you must put the string in double quotation marks (""). NOTE When the HWTACACS, or RADIUS server is detected, the user name cannot contain spaces.
<i>user-password</i>	Specifies a user password.	The value is a string of 1 to 128 case-sensitive characters.
radius-template <i>template-name</i>	Specifies the name of a RADIUS server template.	The RADIUS server template must already exist.

Parameter	Description	Value
chap	<p>Indicates Challenge Handshake Authentication Protocol (CHAP) authentication.</p> <p>The NAS device sends the user name, password, and 16-byte random code to the RADIUS server. The RADIUS server searches for the database according to the user name and obtains the password that is the same as the encrypted password at the user side. The RADIUS server then encrypts the received 16-byte random code and compares the result with the password. If they are the same, the user is authenticated. If they are different, the user fails to be authenticated. In addition, if the user is authenticated, the RADIUS server generates a 16-byte random code to challenge the user.</p>	-
pap	<p>Indicates Password Authentication Protocol (PAP) authentication.</p> <p>The NAS device adds the user name and encrypted password to the corresponding fields of authentication request packets, and then sends the packets to the RADIUS server. The NAS device determines whether to allow the user go online based on the result returned by the RADIUS server.</p>	-
accounting	Indicates accounting. By default, an accounting-start packet is sent.	-
start	Indicates that the sent packet is an accounting-start packet.	-
realtime	Indicates that the sent packet is a real-time accounting packet.	-
stop	Indicates that the sent packet is an accounting-stop packet.	-

Views

All views

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The `test-aaa` command tests service reachability of the server. The device sends an authentication or accounting request packet to the server. If the server returns an authentication or accounting success packet, the device and server can communicate with each other. If the server's response times out, the device and server cannot communicate with each other.

Prerequisites

An authentication server template or accounting server template has been created, an authentication server or accounting server has been specified in the authentication server template or accounting server template, and the authentication server or accounting server has been configured.

Follow-up Procedure

If the test result indicates that the user fails to be authenticated by using authentication server or the accounting server fails to charge the user, check whether the configuration of the authentication server template and the authentication server is correct, and check the connectivity between the device and the authentication server.

Precautions

`chap` and `pap` are two authentication modes.

- PAP: The NAS device adds the user name and encrypted password to the corresponding fields of authentication request packets, and then sends the packets to the RADIUS server. The NAS device determines whether to allow the user go online based on the result returned by the RADIUS server.
- CHAP: The NAS device sends the user name, password, and 16-byte random code to the RADIUS server. The RADIUS server searches for the database according to the user name and obtains the password that is the same as the encrypted password at the user side. The RADIUS server then encrypts the received 16-byte random code and compares the result with the password. If they are the same, the user is authenticated. If they are different, the user fails to be authenticated. In addition, if the user is authenticated, the RADIUS server generates a 16-byte random code to challenge the user.

Before running the `test-aaa` command, you only need to create a RADIUS server template and specify an authentication server or accounting server in the RADIUS server template.

Example

Test whether the user `user1` can be authenticated using CHAP authentication in the RADIUS server template `huawei`.

```
<HUAWEI> test-aaa user1 userkey radius-template huawei chap  
Info: The server template does not exist.
```

13.3 HWTACACS Configuration Commands

13.3.1 Command Support

13.3.2 display hwtacacs-server accounting-stop-packet

13.3.3 display hwtacacs-server template

13.3.4 display hwtacacs-server template verbose

13.3.5 hwtacacs enable

13.3.6 hwtacacs-server

13.3.7 hwtacacs-server accounting

13.3.8 hwtacacs-server accounting-stop-packet resend

13.3.9 hwtacacs-server authentication

13.3.10 hwtacacs-server authorization

13.3.11 hwtacacs-server shared-key

13.3.12 hwtacacs-server source-ip

13.3.13 hwtacacs-server template

13.3.14 hwtacacs-server timer quiet

13.3.15 hwtacacs-server timer response-timeout

13.3.16 hwtacacs-server traffic-unit

13.3.17 hwtacacs-server user-name domain-included

13.3.18 hwtacacs-user change-password hwtacacs-server

13.3.19 reset hwtacacs-server accounting-stop-packet

13.3.20 reset hwtacacs-server statistics

13.3.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

13.3.2 display hwtacacs-server accounting-stop-packet

Function

The **display hwtacacs-server accounting-stop-packet** command displays information about Accounting-Stop packets sent by an HWTACACS server.

Format

display hwtacacs-server accounting-stop-packet { **all** | *number* | **ip** *ip-address* }

Parameters

Parameter	Description	Value
all	Displays information about all Accounting-Stop packets.	-
<i>number</i>	Displays information about Accounting-Stop packets starting from a specified number.	The value is an integer that ranges from 1 to 65535.
ip <i>ip-address</i>	Displays information about Accounting-Stop packets sent by the HWTACACS server with a specified IP address.	The value is in dotted decimal notation.

Views

All views

Default Level

3: Management level

Usage Guidelines

During HWTACACS troubleshooting, you can run this command to check information about Accounting-Stop packets sent by the HWTACACS server.

Example

Display information about all Accounting-Stop packets.

```
<HUAWEI> display hwtacacs-server accounting-stop-packet all
```

```
-----
NO. SendTime   IP Address           Template
1  10          192.168.1.110       tac
-----
```

Whole accounting stop packet to resend:1

Table 13-31 Description of the **display hwtacacs-server accounting-stop-packet** command output

Item	Description
NO.	Number of the Accounting-Stop packet.

Item	Description
SendTime	Number of times that Accounting-Stop packets are sent.
IP Address	IP address of the HWTACACS server.
Template	Name of the HWTACACS server template.
Whole accounting stop packet to resend	Total number of Accounting-Stop packets sent by a device.

Related Topics

[13.3.8 hwtacacs-server accounting-stop-packet resend](#)

[13.3.19 reset hwtacacs-server accounting-stop-packet](#)

13.3.3 display hwtacacs-server template

Function

The **display hwtacacs-server template** command displays the configurations of an HWTACACS server template.

Format

display hwtacacs-server template [*template-name*]

Parameters

Parameter	Description	Value
<i>template-name</i>	Specifies the name of an HWTACACS server template.	The HWTACACS server template must already exist.

Views

All views

Default Level

3: Management level

Usage Guidelines

The **display hwtacacs-server template** command output helps you check the configuration of HWTACACS server templates and isolate faults.

 **NOTE**

The device determines whether its communication with the HWTACACS server is proper based on the response timeout mechanism of HWTACACS request packets, and always marks the status of the last HWTACACS server as Up.

Example

Display the configuration of the HWTACACS server template **template0**.

```
<HUAWEI> display hwtacacs-server template template0
```

```
-----
HWTACACS-server template name : template0
Primary-authentication-server  : 10.7.66.66:49:-
Primary-authorization-server   : 10.7.66.66:49:-
Primary-accounting-server     : 10.7.66.66:49:-
Secondary-authentication-server : 10.7.66.67:49:-
Secondary-authorization-server : 10.7.66.67:49:-
Secondary-accounting-server    : 10.7.66.67:49:-
Current-authentication-server  : 10.7.66.66:49:-
Current-authorization-server   : 10.7.66.66:49:-
Current-accounting-server     : 10.7.66.66:49:-
Source-IP-address             : 0.0.0.0
Shared-key                    : *****
Quiet-interval(min)           : 5
Response-timeout-Interval(sec) : 5
Domain-included               : Yes
Traffic-unit                   : B
-----
```

Table 13-32 Description of the **display hwtacacs-server template** command output

Item	Description
HWTACACS-server template name	Name of an HWTACACS server template.
Primary-authentication-server	IP address and port number of the primary authentication server.
Primary-authorization-server	IP address and port number of the primary authorization server.
Primary-accounting-server	IP address and port number of the primary accounting server.
Secondary-authentication-server	IP address and port number of the secondary authentication server.
Secondary-authorization-server	IP address and port number of the secondary authorization server.
Secondary-accounting-server	IP address and port number of the secondary accounting server.
Current-authentication-server	IP address and port number of current authentication server.

Item	Description
Current-authorization-server	IP address and port number of current authorization server.
Current-accounting-server	IP address and port number of current accounting server.
Source-IP-address	Source IP address for communication between the device and HWTACACS server.
Shared-key	Shared key of an HWTACACS server.
Quiet-interval(min)	Interval for the primary server to return to the active state, in minutes.
Response-timeout-Interval(sec)	Response timeout interval of an HWTACACS server, in seconds.
Domain-included	Whether the user name contains an authentication domain name. <ul style="list-style-type: none"> • Yes: The user name contains the domain name. • No: The user name does not contain the domain name. • Original: The device does not modify the user name entered by the user.
Traffic-unit	Traffic unit used by the HWTACACS server. <ul style="list-style-type: none"> • B: Byte • KB: KByte • MB: MByte • GB: GByte

13.3.4 display hwtacacs-server template verbose

Function

The **display hwtacacs-server template verbose** command displays statistics on HWTACACS authentication, accounting, and authorization.

Format

display hwtacacs-server template *template-name* verbose

Parameters

Parameter	Description	Value
<i>template-name</i>	Specifies the name of an HWTACACS server template.	The HWTACACS server template must exist.

Views

All views

Default Level

3: Management level

Usage Guidelines

Usage Scenario

By viewing statistics on HWTACACS authentication, accounting, and authorization, administrators can better understand the interaction between modules, facilitating fault locating and troubleshooting.

You can run the [reset hwtacacs-server statistics](#) { **all** | **accounting** | **authentication** | **authorization** } command to delete statistics on HWTACACS authentication, accounting, and authorization.

Precautions

In the HWTACACS server template, you can query the relevant statistics only after the IP address of the authentication server, the IP address of the authorization server, or the IP address of the accounting server is configured.

Example

Display statistics on HWTACACS authentication, accounting, and authorization in the HWTACACS server template *test1*.

```
<HUAWEI> display hwtacacs-server template test1 verbose
---[HWTACACS template test1 primary
authentication]---
HWTACACS server open number:
1670281960
HWTACACS server close number: 508333868
HWTACACS authen client access request packet number:
0
HWTACACS authen client access response packet number:
0
HWTACACS authen client unknown type number:
0
HWTACACS authen client timeout number: 0
HWTACACS authen client packet dropped number:
0
HWTACACS authen client access request change password number:
0
HWTACACS authen client access request login number:
0
```

```
HWTACACS authen client access request send authentication number:
0
HWTACACS authen client access request send password number:
0
HWTACACS authen client access connect abort number:
0
HWTACACS authen client access connect packet number:
0
HWTACACS authen client access response error number:
0
HWTACACS authen client access response failure number:
0
HWTACACS authen client access response follow number:
0
HWTACACS authen client access response getdata number:
0
HWTACACS authen client access response getpassword number:
0
HWTACACS authen client access response getuser number:
0
HWTACACS authen client access response pass number:
0
HWTACACS authen client access response restart number:
0
HWTACACS authen client malformed access response number:
0
HWTACACS authen client round trip time(s): 0
---[HWTACACS template test1 primary
authorization]---
HWTACACS server open number:
1670281960
HWTACACS server close number: 508333868
HWTACACS author client request packet number:
0
HWTACACS author client response packet number:
0
HWTACACS author client timeout number: 0
HWTACACS author client packet dropped number:
0
HWTACACS author client unknown type number:
0
HWTACACS author client request EXEC number:
0
HWTACACS author client request PPP number: 0
HWTACACS author client request VPDN number:
0
HWTACACS author client response error number:
0
HWTACACS author client response EXEC number:
0
HWTACACS author client response PPP number:
0
HWTACACS author client response VPDN number:
0
HWTACACS author client round trip time(s): 0
---[HWTACACS template test1 primary
accounting]---
HWTACACS server open number:
1670281960
HWTACACS server close number: 508333868
HWTACACS account client request packet number:
0
HWTACACS account client response packet number:
0
HWTACACS account client unknown type number:
0
HWTACACS account client timeout number: 0
HWTACACS account client packet dropped number:
0
```

```
HWTACACS account client request command level number:  
0  
HWTACACS account client request connection number:  
0  
HWTACACS account client request EXEC number:  
0  
HWTACACS account client request network number:  
0  
HWTACACS account client request system event number:  
0  
HWTACACS account client request update number:  
0  
HWTACACS account client response error number:  
0  
HWTACACS account client round trip time(s): 0
```

Table 13-33 Description of the **display hwtacacs-server template verbose** command output

Item	Description
HWTACACS template test1 primary authentication	<p>Statistics on the primary authentication server in the HWTACACS server template <i>test1</i>. If the secondary and third authentication servers are configured, the relevant statistics are also displayed, including:</p> <ul style="list-style-type: none"> • HWTACACS server open number: Number of times that the socket connection of the HWTACACS server is set up • HWTACACS server close number: Number of times that the socket connection of the HWTACACS server is disconnected • HWTACACS authen client access request packet number: Number of HWTACACS client authentication request packets • HWTACACS authen client access response packet number: Number of HWTACACS client authentication response packets • HWTACACS authen client unknown type number: Number of unknown HWTACACS client authentication messages • HWTACACS authen client timeout number: Number of HWTACACS client authentication timeouts • HWTACACS authen client packet dropped number: Number of times that HWTACACS client authentication packets are dropped • HWTACACS authen client access request change password number: Number of password change requests from an HWTACACS client • HWTACACS authen client access request login number: Number of HWTACACS client login requests • HWTACACS authen client access request send authentication number: Number of authentication requests sent by an HWTACACS client • HWTACACS authen client access request send password number: Number of times that an HWTACACS client sends passwords • HWTACACS authen client access connect abort number: Number of connection-stop packets sent by an HWTACACS client • HWTACACS authen client access connect packet number: Number of continuous packets sent by an HWTACACS client • HWTACACS authen client access response error number: Number of error packets received by an HWTACACS client

Item	Description
	<ul style="list-style-type: none"><li data-bbox="667 300 1353 398">● HWTACACS authen client access response failure number: Number of authentication failure packets received by an HWTACACS client<li data-bbox="667 412 1406 510">● HWTACACS authen client access response follow number: Number of packets that an HWTACACS client receives from the server for re-authentication<li data-bbox="667 524 1406 622">● HWTACACS authen client access response getdata number: Number of packets that an HWTACACS client receives from the server for user information<li data-bbox="667 636 1406 734">● HWTACACS authen client access response getpassword number: Number of packets that an HWTACACS client receives from the server for user password<li data-bbox="667 748 1406 846">● HWTACACS authen client access response getuser number: Number of packets that an HWTACACS client receives from the server for user name<li data-bbox="667 860 1422 958">● HWTACACS authen client access response pass number: Number of authentication success packets received by an HWTACACS client<li data-bbox="667 972 1417 1070">● HWTACACS authen client access response restart number: Number of authentication restart packets that an HWTACACS client receives from the server<li data-bbox="667 1084 1433 1182">● HWTACACS authen client malformed access response number: Number of invalid response packets received by an HWTACACS client<li data-bbox="667 1196 1406 1249">● HWTACACS authen client round trip time(s): Last authentication response time of the HWTACACS server

Item	Description
<p>HWTACACS template test1 primary authorization</p>	<p>Statistics on the primary authorization server in the HWTACACS server template <i>test1</i>. If the secondary and third authorization servers are configured, the relevant statistics are also displayed, including:</p> <ul style="list-style-type: none"> ● HWTACACS server open number: Number of times that the socket connection of the HWTACACS server is set up ● HWTACACS server close number: Number of times that the socket connection of the HWTACACS server is disconnected ● HWTACACS author client request packet number: Number of HWTACACS client authorization request packets ● HWTACACS author client response packet number: Number of HWTACACS client authorization response packets ● HWTACACS author client timeout number: Number of HWTACACS client authorization timeouts ● HWTACACS author client packet dropped number: Number of times that HWTACACS client authorization packets are dropped ● HWTACACS author client unknown type number: Number of unknown authorization packets on an HWTACACS client ● HWTACACS author client request EXEC number: Number of EXEC user request packets authorized by an HWTACACS client ● HWTACACS author client request PPP number: Number of PPP user request packets authorized by an HWTACACS client ● HWTACACS author client request VPDN number: Number of VPDN user request packets authorized by an HWTACACS client ● HWTACACS author client response error number: Number of error authorization response packets received by an HWTACACS client ● HWTACACS author client response EXEC number: Number of authorized EXEC user response packets received by an HWTACACS client ● HWTACACS author client response PPP number: Number of authorized PPP user response packets received by an HWTACACS client ● HWTACACS author client response VPDN number: Number of authorized VPDN user response packets received by an HWTACACS client ● HWTACACS author client round trip time(s): Last authorization response time of the HWTACACS server

Item	Description
<p>HWTACACS template test1 primary accounting</p>	<p>Statistics on the primary accounting server in the HWTACACS server template <i>test1</i>. If the secondary and third accounting servers are configured, the relevant statistics are also displayed, including:</p> <ul style="list-style-type: none"> • HWTACACS server open number: Number of times that the socket connection of the HWTACACS server is set up • HWTACACS server close number: Number of times that the socket connection of the HWTACACS server is disconnected • HWTACACS account client request packet number: Number of HWTACACS client accounting request packets • HWTACACS account client response packet number: Number of HWTACACS client accounting response packets • HWTACACS account client unknown type number: Number of unknown HWTACACS client accounting packets • HWTACACS account client timeout number: Number of HWTACACS client accounting timeouts • HWTACACS account client packet dropped number: Number of times that HWTACACS client accounting packets are dropped • HWTACACS account client request command level number: Number of HWTACACS client accounting requests for command line packets • HWTACACS account client request connection number: Number of HWTACACS client accounting requests for connection • HWTACACS account client request EXEC number: Number of HWTACACS client accounting requests for EXEC packets • HWTACACS account client request network number: Number of HWTACACS client accounting requests for Network packets • HWTACACS account client request system event number: Number of HWTACACS client accounting requests for system event packets • HWTACACS account client request update number: Number of HWTACACS client accounting requests for update packets • HWTACACS account client response error number: Number of HWTACACS client accounting requests for error packets

Item	Description
	<ul style="list-style-type: none">HWTACACS account client round trip time(s): Response time of the last accounting packet of the HWTACACS server

13.3.5 hwtacacs enable

Function

The **hwtacacs enable** command enables Huawei Terminal Access Controller Access Control System (HWTACACS).

The **undo hwtacacs enable** command disables HWTACACS.

The **hwtacacs disable** command disables HWTACACS.

By default, HWTACACS is enabled.

Format

hwtacacs enable

undo hwtacacs enable

hwtacacs disable

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To use HWTACACS authentication, authorization, or accounting, run the **hwtacacs enable** command to enable the HWTACACS function.

Precautions

If the **undo hwtacacs enable** command is run when a user is performing HWTACACS authentication, authorization, or accounting, the command does not take effect.

Example

```
# Disable HWTACACS.  
<HUAWEI> system-view  
[HUAWEI] undo hwtacacs enable
```

13.3.6 hwtacacs-server

Function

The **hwtacacs-server** command applies an HWTACACS server template to a domain.

The **undo hwtacacs-server** command deletes an HWTACACS server template from a domain.

By default, no HWTACACS server template is applied to a domain.

Format

```
hwtacacs-server template-name  
undo hwtacacs-server
```

Parameters

Parameter	Description	Value
<i>template-name</i>	Specifies the name of an HWTACACS server template.	The HWTACACS server template must already exist.

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To perform HWTACACS authentication, authorization, and accounting for users in a domain, configure an HWTACACS server template in the domain. After the HWTACACS server template is configured in the domain, the configuration in the HWTACACS server template takes effect.

Prerequisites

An HWTACACS server template has been created by using the [13.3.13 hwtacacs-server template](#) command.

Example

Apply the HWTACACS server template **tacacs1** to the domain **tacacs1**.

```
<HUAWEI> system-view
[HUAWEI] hwtacacs-server template tacacs1
[HUAWEI-hwtacacs-tacacs1] quit
[HUAWEI] aaa
[HUAWEI-aaa] domain tacacs1
[HUAWEI-aaa-domain-tacacs1] hwtacacs-server tacacs1
```

Related Topics

[13.3.3 display hwtacacs-server template](#)

[13.3.13 hwtacacs-server template](#)

13.3.7 hwtacacs-server accounting

Function

The **hwtacacs-server accounting** command configures an HWTACACS accounting server.

The **undo hwtacacs-server accounting** command cancels the configuration.

By default, no HWTACACS accounting server is configured.

Format

hwtacacs-server accounting *ip-address* [*port*] [**public-net** | **vpn-instance** *vpn-instance-name*] [**secondary**]

undo hwtacacs-server accounting [*ip-address* [*port*] [**public-net** | **vpn-instance** [*vpn-instance-name*]]] [**secondary**]

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the IP address of an HWTACACS accounting server.	The value is a valid unicast address in dotted decimal notation.
<i>port</i>	Specifies the port number of an HWTACACS accounting server.	The value is an integer that ranges from 1 to 65535. The default value is 49.

Parameter	Description	Value
public-net	Indicates that the HWTACACS accounting server is connected to the public network.	-
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance that the HWTACACS accounting server is bound to.	The value must be an existing VPN instance name.
secondary	If this parameter is specified, the secondary HWTACACS accounting server is configured. If this parameter is not specified, the primary HWTACACS accounting server is configured.	-

Views

HWTACACS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The device does not support local accounting; therefore, you need to configure an HWTACACS accounting server to perform accounting. The device sends accounting packets to an HWTACACS accounting server only after the accounting server is specified in an HWTACACS server template.

Precautions

- You can modify this configuration only when device does not set up TCP connection with the specified accounting server.
- The IP addresses of the primary and secondary servers must be different. Otherwise, the server configuration fails.
- If the command is run for multiple times in the same HWTACACS server template to configure the servers with the same type (for example, the servers are all primary servers), only the latest configuration takes effect.

Example

```
# Configure the primary HWTACACS accounting server.
```

```
<HUAWEI> system-view  
[HUAWEI] hwtacacs-server template test1  
[HUAWEI-hwtacacs-test1] hwtacacs-server accounting 10.163.155.12 52
```

Related Topics

[13.3.3 display hwtacacs-server template](#)

13.3.8 hwtacacs-server accounting-stop-packet resend

Function

The **hwtacacs-server accounting-stop-packet resend** command enables or disables retransmission of accounting-stop packets and sets the number of accounting-stop packets that can be retransmitted each time.

The **undo hwtacacs-server accounting-stop-packet resend** command restores retransmission of accounting-stop packets and the default number of accounting-stop packets that can be retransmitted each time.

By default, 100 accounting-stop packets can be retransmitted each time.

Format

```
hwtacacs-server accounting-stop-packet resend { disable | enable number }  
undo hwtacacs-server accounting-stop-packet resend
```

Parameters

Parameter	Description	Value
disable	Disables the retransmission of accounting-stop packets.	-
enable <i>number</i>	Enables the retransmission of accounting-stop packets, and specifies the number of packets that can be retransmitted each time.	The value is an integer that ranges from 1 to 300.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After a user goes offline, the device sends an accounting-stop packet to an accounting server. After the accounting server receives the accounting-stop packet, it stops accounting for the user. If the accounting server does not receive the accounting-stop packet because of network faults, it continues to perform accounting for the user. As a result, the user is charged incorrectly. To solve this problem, configure the device to send accounting-stop packets multiple times.

Precautions

- If **disable** is configured, an accounting-stop packet is transmitted only once even when packet transmission fails.
- If **enable number** is configured, *number* specifies the number of accounting-stop packets that can be retransmitted each time when the device does not receive any response packet from the HWTACACS server or fails to receive the response packet.

Example

Enable the retransmission of accounting-stop packets and set the number of accounting-stop packets that can be retransmitted each time to 50.

```
<HUAWEI> system-view  
[HUAWEI] hwtacacs-server accounting-stop-packet resend enable 50
```

Related Topics

[13.3.2 display hwtacacs-server accounting-stop-packet](#)

13.3.9 hwtacacs-server authentication

Function

The **hwtacacs-server authentication** command configures the HWTACACS authentication server.

The **undo hwtacacs-server authentication** command deletes configurations of the HWTACACS authentication server.

By default, no HWTACACS authentication server is configured.

Format

hwtacacs-server authentication *ip-address* [*port*] [**public-net** | **vpn-instance** *vpn-instance-name*] [**secondary**]

undo hwtacacs-server authentication [*ip-address* [*port*] [**public-net** | **vpn-instance** [*vpn-instance-name*]]] [**secondary**]

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the IP address of an HWTACACS authentication server.	The value is a valid unicast address in dotted decimal notation.
<i>port</i>	Specifies the port number of an HWTACACS authentication server.	The value is an integer that ranges from 1 to 65535. The default value is 49.
public-net	Indicates that the HWTACACS authentication server is connected to the public network.	-
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance that the HWTACACS accounting server is bound to.	The value must be an existing VPN instance name.
secondary	If this parameter is specified, the secondary HWTACACS authentication server is configured. If this parameter is not specified, the primary HWTACACS authentication server is configured.	-

Views

HWTACACS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To authenticate users in HWTACACS mode, you must configure the HWTACACS authentication server. When both the primary and secondary authentication servers are configured, the device sends an authentication request packet to the secondary authentication server in any of the following situations:

- The device fails to send a request packet to the primary authentication server.

- If the device does not receive any authentication response packet from the primary server:
- The primary authentication server requires re-authentication.
- The primary authentication server considers that the received authentication request packet is incorrect.

Precautions

- You can modify this configuration only when device does not set up TCP connection with the specified accounting server.
- The IP addresses of the primary and secondary servers must be different. Otherwise, the server configuration fails.
- If the command is run for multiple times in the same HWTACACS server template to configure the servers with the same type (for example, the servers are all primary servers), only the latest configuration takes effect.

Example

Configure the primary HWTACACS authentication server.

```
<HUAWEI> system-view  
[HUAWEI] hwtacacs-server template test1  
[HUAWEI-hwtacacs-test1] hwtacacs-server authentication 10.163.155.12 49
```

Related Topics

[13.3.3 display hwtacacs-server template](#)

13.3.10 hwtacacs-server authorization

Function

The **hwtacacs-server authorization** command configures the HWTACACS authorization server.

The **undo hwtacacs-server authorization** command deletes configurations of the HWTACACS authorization server.

By default, no HWTACACS authorization server is configured.

Format

hwtacacs-server authorization *ip-address* [*port*] [**public-net** | **vpn-instance** *vpn-instance-name*] [**secondary**]

undo hwtacacs-server authorization [*ip-address* [*port*] [**public-net** | **vpn-instance** [*vpn-instance-name*]]] [**secondary**]

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the IP address of an HWTACACS authorization server.	The value is a valid unicast address in dotted decimal notation.
<i>port</i>	Specifies the port number of an HWTACACS authorization server.	The value is an integer that ranges from 1 to 65535. The default value is 49.
public-net	Indicates that the HWTACACS authorization server is connected to the public network.	-
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance that the HWTACACS authorization server is bound to.	The value must be an existing VPN instance name.
secondary	If this parameter is specified, the secondary HWTACACS authorization server is configured. If this parameter is not specified, the primary HWTACACS authorization server is configured.	-

Views

HWTACACS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To authorize users in HWTACACS mode, you must configure the HWTACACS authorization server.

Precautions

- You can modify this configuration only when device does not set up TCP connection with the specified accounting server.
- The IP addresses of the primary and secondary servers must be different. Otherwise, the server configuration fails.
- If the command is run for multiple times in the same HWTACACS server template to configure the servers with the same type (for example, the servers are all primary servers), only the latest configuration takes effect.

Example

Configure the primary HWTACACS authorization server.

```
<HUAWEI> system-view
[HUAWEI] hwtacacs-server template test1
[HUAWEI-hwtacacs-test1] hwtacacs-server authorization 10.163.155.12 49
```

Related Topics

[13.3.3 display hwtacacs-server template](#)

13.3.11 hwtacacs-server shared-key

Function

The **hwtacacs-server shared-key** command sets a shared key for an HWTACACS server.

The **undo hwtacacs-server shared-key** command cancels the configuration.

By default, the HWTACACS server is not configured with any shared key.

Format

hwtacacs-server shared-key [**cipher**] *key-string*

undo hwtacacs-server shared-key

Parameters

Parameter	Description	Value
cipher	Indicates the shared key in cipher text.	-
<i>key-string</i>	Specifies a shared key.	The value is a case-sensitive string without question marks (?) or spaces. The key is processed as cipher text no matter whether the cipher keyword is specified. The <i>key-string</i> may be a plain text consisting of 1 to 255 characters or a cipher text consisting of 20 to 392 characters.

Views

HWTACACS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The shared key is used to encrypt the password and generate the response authenticator.

When exchanging authentication packets with an HWTACACS server, the device uses MD5 to encrypt important data such as the password to ensure security of data transmission over the network. The device and HWTACACS server must use the same key to ensure their validity in the authentication.

Precautions

To improve security, it is recommended that the password contains at least two types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 6 characters.

You can modify this configuration only when the HWTACACS server template is not in use.

Example

Set the shared key of the HWTACACS server to **Admin@123**.

```
<HUAWEI> system-view  
[HUAWEI] hwtacacs-server template test1  
[HUAWEI-hwtacacs-test1] hwtacacs-server shared-key cipher Admin@123
```

Related Topics

[13.3.3 display hwtacacs-server template](#)

[13.3.13 hwtacacs-server template](#)

13.3.12 hwtacacs-server source-ip

Function

The **hwtacacs-server source-ip** command specifies the source IP address used by a device to communicate with an HWTACACS server.

The **undo hwtacacs-server source-ip** command cancels the configuration.

By default, the device uses the IP address of the actual outbound interface as the source IP address encapsulated in HWTACACS packets.

Format

hwtaacs-server source-ip *ip-address*

undo hwtaacs-server source-ip

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the source IP address for communication between the device and HWTACACS server.	The value is a valid unicast address in dotted decimal notation.

Views

HWTACACS server template view

Default Level

3: Management level

Usage Guidelines

You can configure all HWTACACS packets sent by the device to use the same source IP address. In this way, an HWTACACS server uses only one IP address to communicate with the device.

Example

Specify the source IP address 10.1.1.1 for communication between the device and HWTACACS server.

```
<HUAWEI> system-view  
[HUAWEI] hwtaacs-server template test1  
[HUAWEI-hwtaacs-test1] hwtaacs-server source-ip 10.1.1.1
```

Related Topics

[13.3.3 display hwtaacs-server template](#)

[13.3.13 hwtaacs-server template](#)

13.3.13 hwtaacs-server template

Function

The **hwtaacs-server template** command creates an HWTACACS server template and enters the HWTACACS server template view.

The **undo hwtaacs-server template** command deletes an HWTACACS server template.

By default, no HWTACACS server template is configured.

Format

hwtaacs-server template *template-name*

undo hwtaacs-server template *template-name*

Parameters

Parameter	Description	Value
<i>template-name</i>	Specifies the name of an HWTACACS server template.	The value is a string of 1 to 32 case-insensitive characters. The name contains only letters, digits (0-9), dots (.), underscores (_), and hyphens (-), and a combination of the above characters. The value cannot be - or --.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

You can perform HWTACACS configurations, such as the configuration of authentication servers, authorization servers, accounting servers, and shared key, only after an HWTACACS server template is created.

Follow-up Procedure

Configure an authentication server, accounting server, and shared key in the HWTACACS server template view, and run the [13.3.6 hwtaacs-server](#) command in the domain view to apply the HWTACACS server template.

Precautions

You can modify the content of a template or delete a template only when the template is not in use.

Example

```
# Create an HWTACACS server template template1 and enter the HWTACACS server template view.
```

```
<HUAWEI> system-view  
[HUAWEI] hwtacacs-server template template1  
[HUAWEI-hwtacacs-template1]
```

Related Topics

[13.3.3 display hwtacacs-server template](#)

[13.3.6 hwtacacs-server](#)

13.3.14 hwtacacs-server timer quiet

Function

The **hwtacacs-server timer quiet** command sets the quiet interval before the primary server reverts to the active state.

The **undo hwtacacs-server timer quiet** command restores the default quiet interval before the primary server reverts to the active state.

By default, the quiet interval before the primary HWTACACS server reverts to the active state is 5 minutes.

Format

hwtacacs-server timer quiet *interval*

undo hwtacacs-server timer quiet

Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the quiet interval before the primary server reverts to the active state.	The value is an integer ranging from 1 to 255, in minutes.

Views

HWTACACS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

If the primary server is unavailable, the device automatically switches services to the standby server and sends packets to the standby server. After the quiet interval before the primary server reverts to the active state expires, the device attempts to establish a connection with the primary server.

- If the primary server is still unavailable, the device continues to send packets to the standby server until the next interval expires. Such a process repeats.
- If the primary server is available, the device switches services to the primary server and sends packets to the primary server.

The quiet interval before the primary server reverts to the active state ensures that the primary server can be restored immediately and reduces the number of detection times during the switchover.

The default value is recommended.

Precautions

When you run the **hwtaacs-server timer quiet** command to change the quiet interval before the primary server reverts to the active state, the device does not check whether the HWTACACS server template is in use.

Example

```
# Set the quiet interval before the primary server reverts to the active state to 3 minutes.
```

```
<HUAWEI> system-view  
[HUAWEI] hwtaacs-server template template1  
[HUAWEI-hwtaacs-template1] hwtaacs-server timer quiet 3
```

Related Topics

[13.3.3 display hwtaacs-server template](#)

13.3.15 hwtaacs-server timer response-timeout

Function

The **hwtaacs-server timer response-timeout** command sets the response timeout interval of an HWTACACS server.

The **undo hwtaacs-server timer response-timeout** command restores the default response timeout interval of an HWTACACS server.

By default, the response timeout interval for an HWTACACS server is 5 seconds.

Format

hwtaacs-server timer response-timeout *interval*

undo hwtaacs-server timer response-timeout

Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the response timeout interval of an HWTACACS server.	The value is an integer ranging from 1 to 300, in seconds.

Views

HWTACACS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After the device sends a request packet to the HWTACACS server, if the device does not receive any response packet from the server within the specified response timeout interval:

- If only one HWTACACS server is configured, the device retransmits the request to this server.
- If active/standby HWTACACS servers are configured, the device retransmits the request to the standby server.

This improves reliability of HWTACACS authentication, authorization, and accounting.

The default value is recommended.

Precautions

You can modify this configuration only when the HWTACACS server template is not in use.

Example

Set the response timeout interval of an HWTACACS server to 30s.

```
<HUAWEI> system-view
[HUAWEI] hwtacacs-server template test1
[HUAWEI-hwtacacs-test1] hwtacacs-server timer response-timeout 30
```

Related Topics

[13.3.3 display hwtacacs-server template](#)

[13.3.13 hwtacacs-server template](#)

13.3.16 hwtacacs-server traffic-unit

Function

The **hwtacacs-server traffic-unit** command sets the traffic unit used by an HWTACACS server.

The **undo hwtacacs-server traffic-unit** command restores the default traffic unit used by the HWTACACS server.

By default, the traffic unit is byte on the device.

Format

```
hwtaacs-server traffic-unit { byte | kbyte | mbyte | gbyte }  
undo hwtaacs-server traffic-unit
```

Parameters

Parameter	Description	Value
byte	Indicates that the traffic unit is byte.	-
kbyte	Indicates that the traffic unit is KByte.	-
mbyte	Indicates that the traffic unit is MByte.	-
gbyte	Indicates that the traffic unit is GByte.	-

Views

HWTACACS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

Different HWTACACS servers may use different traffic units; therefore, you need to set the traffic unit for each HWTACACS server group on the device and the traffic unit must be the same as that on the HWTACACS server.

Precautions

You can modify this configuration only when the HWTACACS server template is not in use.

Example

```
# Set the traffic unit used by an HWTACACS server to KByte.
```

```
<HUAWEI> system-view  
[HUAWEI] hwtaacs-server template template1  
[HUAWEI-hwtaacs-template1] hwtaacs-server traffic-unit kbyte
```

Related Topics

[13.3.3 display hwtaacs-server template](#)

[13.3.13 hwtaacs-server template](#)

13.3.17 hwtacacs-server user-name domain-included

Function

The **hwtacacs-server user-name domain-included** command configures the device to encapsulate the domain name in the user name in HWTACACS packets to be sent to an HWTACACS server.

The **undo hwtacacs-server user-name domain-included** command configures the device not to encapsulate the domain name in the user name when sending HWTACACS packets to an HWTACACS server.

By default, the device encapsulates the domain name in the user name when sending HWTACACS packets to an HWTACACS server.

Format

hwtacacs-server user-name domain-included

undo hwtacacs-server user-name domain-included

Parameters

None

Views

HWTACACS server template view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The format of a user name is user name@domain name. In the user name, @ is the domain name delimiter.

If the HWTACACS server does not accept the user name with the domain name, run the **undo hwtacacs-server user-name domain-included** command to delete the domain name from the user name.

Precautions

You can modify this configuration only when the HWTACACS server template is not in use.

The **hwtacacs-server user-name domain-included** command in the current version does not take effect. The user names sent by the device can be either of the following: 1. By default, the user names in the packets sent from the device to the HWTACACS server are original, and the device does not modify the user names. 2. After the **undo hwtacacs-server user-name domain-included** command is executed, the user names in the packets sent from the device to the HWTACACS server do not contain domain names.

If the user names in the HWTACACS packets sent from the device to HWTACACS server contain domain names, ensure that the total length of a user name (user name + domain name delimiter + domain name) is not longer than 64 characters; otherwise, the user name cannot be contained in HWTACACS packets. As a result, authentication will fail.

Example

Configure the device to encapsulate the domain name in the user name when sending HWTACACS packets to an HWTACACS server.

```
<HUAWEI> system-view
[HUAWEI] hwtacacs-server template template1
[HUAWEI-hwtacacs-template1] hwtacacs-server user-name domain-included
```

Related Topics

[13.3.3 display hwtacacs-server template](#)

13.3.18 hwtacacs-user change-password hwtacacs-server

Function

The **hwtacacs-user change-password hwtacacs-server** command enables the device to change the passwords saved on the HWTACACS server.

Format

hwtacacs-user change-password hwtacacs-server *template-name*

Parameters

Parameter	Description	Value
<i>template-name</i>	Specifies the name of an HWTACACS server template.	The HWTACACS server template must already exist.

Views

User view

Default Level

0: Visit level

Usage Guidelines

Usage Scenario

To change the password saved on the HWTACACS server, users can run the **hwtacacs-user change-password hwtacacs-server** command on the device. You do not need to change the configuration on the HWTACACS server.

Precautions

- Users are HWTACACS authenticated and the HWTACACS server template is configured.
- Users can run this command to change the passwords only when the user names and passwords saved on the HWTACACS do not expire. When a user whose password has expired logs in to the device, the HWTACACS server does not allow the user to change the password and displays a message indicating that the authentication fails.
- The system wait period is 30 seconds. If the TACACS server does not receive the user name, new password, or confirmed password from the user within such a period, it terminates the password change process.
- Users can also press **Ctrl+C** to cancel password change.
- HWTACACS users who pass AAA authentication can use the **hwtaacacs-user change-password hwtaacacs-server** command to change the passwords before the passwords expire. If a user needs to run this command to change the passwords of other users, the user must have the system rights.

Example

Enable the user that passes HWTACACS authentication to change the password.

```
<HUAWEI> hwtaacacs-user change-password hwtaacacs-server huawei
Username:cj@huawei
Old Password:
New Password:
Re-enter New password:
Info: The password has been changed successfully.
```

13.3.19 reset hwtaacacs-server accounting-stop-packet

Function

The **reset hwtaacacs-server accounting-stop-packet** command clears statistics on Accounting Stop packets.

Format

reset hwtaacacs-server accounting-stop-packet { **all** | **ip** *ip-address* }

Parameters

Parameter	Description	Value
all	Clears the statistics about all accounting-stop packets.	-
ip <i>ip-address</i>	Clears the statistics about the Accounting-Stop packets sent by the HWTACACS server with a specified IP address.	The value is in dotted decimal notation.

Views

User view

Default Level

3: Management level

Usage Guidelines

Statistics cannot be restored once being cleared.

Example

```
# Clear statistics on all Accounting Stop packets.
```

```
<HUAWEI> reset hwtacacs-server accounting-stop-packet all
```

Related Topics

[13.3.2 display hwtacacs-server accounting-stop-packet](#)

13.3.20 reset hwtacacs-server statistics

Function

The **reset hwtacacs-server statistics** command clears the statistics on HWTACACS authentication, accounting, and authorization.

Format

```
reset hwtacacs-server statistics { all | accounting | authentication |  
authorization }
```

Parameters

Parameter	Description	Value
all	Clears all the statistics.	-
accounting	Clears the statistics on HWTACACS accounting.	-
authentication	Clears the statistics on HWTACACS authentication.	-
authorization	Clears the statistics on HWTACACS authorization.	-

Views

User view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

If statistics about HWTACACS authentication, accounting, and authorization need to be collected in a specified period of time, you must clear the original statistics first.

Precautions

- After the **reset hwtacacs-server statistics** command is run, all the statistics about HWTACACS authentication, accounting, and authorization is cleared. In addition, the statistics cannot be restored once being cleared. Therefore, exercise caution when you decide to run this command.
- You can run the **display hwtacacs-server template *template-name* verbose** command to check statistics about HWTACACS authentication, accounting, and authorization in the specified server template.

Example

```
# Clear all the statistics.
```

```
<HUAWEI> reset hwtacacs-server statistics all
```

Related Topics

[13.3.3 display hwtacacs-server template](#)

13.4 NAC Configuration Commands (Unified Mode)

[13.4.1 Command Support](#)

[13.4.2 access-context profile enable](#)

[13.4.3 access-context profile name](#)

[13.4.4 access-author policy global](#)

[13.4.5 access-author policy name](#)

[13.4.6 access-domain](#)

[13.4.7 access-user arp-detect](#)

[13.4.8 access-user arp-detect default ip-address](#)

[13.4.9 access-user dot1x-identity speed-limit](#)

[13.4.10 access-user syslog-restrain enable](#)

- 13.4.11 access-user syslog-restrain period
- 13.4.12 acl-id (service scheme view)
- 13.4.13 authentication handshake
- 13.4.14 authentication control-direction
- 13.4.15 authentication device-type voice authorize
- 13.4.16 authentication dot1x-mac-bypass
- 13.4.17 authentication event action authorize
- 13.4.18 authentication event authen-server-up action re-authen
- 13.4.19 authentication event client-no-response action authorize
- 13.4.20 authentication event portal-server-down action authorize
- 13.4.21 authentication event portal-server-up action re-authen
- 13.4.22 authentication mac-move enable
- 13.4.23 authentication mac-move detect enable
- 13.4.24 authentication mac-move detect retry-interval retry-time
- 13.4.25 authentication mac-move quiet-log enable
- 13.4.26 authentication mac-move quiet-times quiet-period
- 13.4.27 authentication mac-move quiet-user-alarm enable
- 13.4.28 authentication mac-move quiet-user-alarm percentage
- 13.4.29 authentication pre-authen-access enable
- 13.4.30 authentication timer handshake-period
- 13.4.31 authentication timer authen-fail-aging
- 13.4.32 authentication timer pre-authen-aging
- 13.4.33 authentication timer re-authen
- 13.4.34 authentication wlan-max-user
- 13.4.35 authentication mode
- 13.4.36 authentication single-access
- 13.4.37 authentication speed-limit auto
- 13.4.38 authentication unified-mode
- 13.4.39 authentication trigger-condition (802.1X authentication)
- 13.4.40 authentication trigger-condition (MAC address authentication)
- 13.4.41 authentication trigger-condition dhcp dhcp-option
- 13.4.42 authentication-profile (Interface view or VAP profile view)
- 13.4.43 authentication-profile (system view)

- 13.4.44 authentication update-ip-accounting enable
- 13.4.45 band-width share-mode
- 13.4.46 cut access-user ucl-group
- 13.4.47 device-type
- 13.4.48 device-profile
- 13.4.49 device-sensor dhcp option
- 13.4.50 device-sensor lldp tlv
- 13.4.51 display aaa statistics access-type-authenreq
- 13.4.52 display access-context profile
- 13.4.53 display access-author policy
- 13.4.54 display access-user dot1x-identity statistics
- 13.4.55 display access-user
- 13.4.56 display access-user-num
- 13.4.57 display authentication mac-move configuration
- 13.4.58 display authentication mac-move quiet-user
- 13.4.59 display authentication interface
- 13.4.60 display authentication mode
- 13.4.61 display authentication-profile configuration
- 13.4.62 display device-profile
- 13.4.63 display dot1x
- 13.4.64 display dot1x-access-profile configuration
- 13.4.65 display dot1x quiet-user
- 13.4.66 display free-rule
- 13.4.67 display free-rule-template configuration
- 13.4.68 display mac-address authen
- 13.4.69 display mac-address pre-authen
- 13.4.70 display mac-access-profile configuration
- 13.4.71 display mac-authen
- 13.4.72 display mac-authen quiet-user
- 13.4.73 display portal
- 13.4.74 display portal local-server connect
- 13.4.75 display portal local-server
- 13.4.76 display portal local-server page-information

- 13.4.77 display portal-access-profile configuration
- 13.4.78 display portal quiet-user
- 13.4.79 display portal url-encode configuration
- 13.4.80 display portal user-logout
- 13.4.81 display server-detect state
- 13.4.82 display static-user
- 13.4.83 display ucl-group all
- 13.4.84 display ucl-group ip
- 13.4.85 display url-template
- 13.4.86 display snmp-agent trap feature-name mid_aaa all
- 13.4.87 display snmp-agent trap feature-name mid_eapol all
- 13.4.88 display snmp-agent trap feature-name mid_web all
- 13.4.89 display web-auth-server configuration
- 13.4.90 domain mac-authen force
- 13.4.91 dot1x authentication-method
- 13.4.92 dot1x eap-notify-packet
- 13.4.93 dot1x handshake
- 13.4.94 dot1x handshake packet-type
- 13.4.95 dot1x mc-trigger
- 13.4.96 dot1x mc-trigger port-up-send enable
- 13.4.97 dot1x port-control
- 13.4.98 dot1x quiet-period
- 13.4.99 dot1x quiet-times
- 13.4.100 dot1x reauthenticate mac-address
- 13.4.101 dot1x reauthenticate
- 13.4.102 dot1x retry
- 13.4.103 dot1x timer
- 13.4.104 dot1x timer mac-bypass-delay
- 13.4.105 dot1x timer quiet-period
- 13.4.106 dot1x trigger dhcp-binding
- 13.4.107 dot1x timer tx-period
- 13.4.108 dot1x unicast-trigger
- 13.4.109 dot1x url

- 13.4.110 dot1x-access-profile (authentication profile view)
- 13.4.111 dot1x-access-profile (system view)
- 13.4.112 enable (terminal type identification profile view)
- 13.4.113 free-rule
- 13.4.114 free-rule-template (authentication profile view)
- 13.4.115 free-rule-template (system view)
- 13.4.116 http parse user-agent enable
- 13.4.117 http get-method enable
- 13.4.118 http-method post
- 13.4.119 force-push
- 13.4.120 if-match vlan-id
- 13.4.121 if-match
- 13.4.122 ip-static-user enable
- 13.4.123 link-down offline delay
- 13.4.124 mac-access-profile (authentication profile view)
- 13.4.125 mac-access-profile (system view)
- 13.4.126 mac-authen offline dhcp-release
- 13.4.127 mac-authen permit mac-address
- 13.4.128 mac-authen quiet-times
- 13.4.129 mac-authen reauthenticate mac-address
- 13.4.130 mac-authen reauthenticate
- 13.4.131 mac-authen reauthenticate dhcp-renew
- 13.4.132 mac-authen timer quiet-period
- 13.4.133 mac-authen timer reauthenticate-period
- 13.4.134 mac-authen username
- 13.4.135 match access-context-profile action
- 13.4.136 match access-context-profile action access-domain
- 13.4.137 parameter
- 13.4.138 port (Portal server profile view)
- 13.4.139 portal auth-network
- 13.4.140 portal captive-adaptive enable
- 13.4.141 portal captive-bypass enable
- 13.4.142 portal https-redirect enable

- 13.4.143 portal https-redirect wired enable
- 13.4.144 portal local-server ad-image load
- 13.4.145 portal local-server anonymous
- 13.4.146 portal local-server authentication-method
- 13.4.147 portal local-server background-color
- 13.4.148 portal local-server background-image load
- 13.4.149 portal local-server enable
- 13.4.150 portal local-server ip
- 13.4.151 portal local-server keep-alive
- 13.4.152 portal local-server load
- 13.4.153 portal local-server logo load
- 13.4.154 portal local-server
- 13.4.155 portal local-server page-text load
- 13.4.156 portal local-server policy-text load
- 13.4.157 portal local-server timer session-timeout
- 13.4.158 portal local-server syslog-limit enable
- 13.4.159 portal local-server syslog-limit period
- 13.4.160 portal logout different-server enable
- 13.4.161 portal logout resend timeout
- 13.4.162 portal max-user
- 13.4.163 portal quiet-period
- 13.4.164 portal quiet-times
- 13.4.165 portal timer quiet-period
- 13.4.166 portal timer offline-detect
- 13.4.167 portal url-encode enable
- 13.4.168 portal user-alarm percentage
- 13.4.169 portal web-authen-server
- 13.4.170 portal-access-profile (authentication profile view)
- 13.4.171 portal-access-profile (system view)
- 13.4.172 protocol (Portal server template view)
- 13.4.173 qos-profile (service scheme view)
- 13.4.174 reset aaa statistics access-type-authenreq
- 13.4.175 reset dot1x statistics

- 13.4.176 reset mac-authen statistics
- 13.4.177 reset access-user dot1x-identity statistics
- 13.4.178 reset access-user traffic-statistics
- 13.4.179 rule (terminal type identification profile view)
- 13.4.180 server-detect
- 13.4.181 server-ip (Portal server profile view)
- 13.4.182 shared-key (Portal server profile view)
- 13.4.183 source-ip (Portal server profile view)
- 13.4.184 source-interface (Portal server template view)
- 13.4.185 static-user
- 13.4.186 static-user password
- 13.4.187 static-user username format-include
- 13.4.188 snmp-agent trap enable feature-name mid_aaa
- 13.4.189 snmp-agent trap enable feature-name mid_eapol
- 13.4.190 snmp-agent trap enable feature-name mid_web
- 13.4.191 traffic-filter acl
- 13.4.192 traffic-redirect acl
- 13.4.193 ucl-group (service scheme view)
- 13.4.194 ucl-group ip
- 13.4.195 ucl-group
- 13.4.196 url (URL template view)
- 13.4.197 url (Portal server profile view)
- 13.4.198 url-parameter mac-address format
- 13.4.199 url-parameter
- 13.4.200 url-template name
- 13.4.201 url-template (Portal server profile view)
- 13.4.202 user-sync
- 13.4.203 vm-authen password
- 13.4.204 vm-user association-type
- 13.4.205 user-vlan (service scheme view)
- 13.4.206 voice-vlan (service scheme view)
- 13.4.207 vpn-instance (Portal server template view)
- 13.4.208 web-auth-server listening-port

[13.4.209 web-auth-server \(Portal access profile view\)](#)

[13.4.210 web-auth-server reply-message](#)

[13.4.211 web-auth-server \(system view\)](#)

[13.4.212 web-auth-server version](#)

[13.4.213 web-redirectation disable \(Portal server profile view\)](#)

13.4.1 Command Support

The S2750EI, S5700-10P-LI-AC, and S5700-10P-PWR-LI-AC support external Portal authentication only when Layer 3 hardware forwarding of IPv4 packets is enabled. To configure Layer 3 hardware forwarding of IPv4 packets, see **Configuring Layer 3 Hardware Forwarding of IPv4 Packets**.

13.4.2 access-context profile enable

Function

The **access-context profile enable** command enables the user context identification function.

The **undo access-context profile enable** command disables the user context identification function.

By default, the user context identification function is disabled.

Format

access-context profile enable

undo access-context profile enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

User context refers to association information of a user, such as the user name, user VLAN, and access interface.

To simplify the authentication server configuration, the administrator can add the users with the same network access rights to the same user context profile based

on the user context, and configure the network access rights for the users based on the user context profile. When a user goes online after the user context identification function is enabled, the device can identify the user context information and add the user to the corresponding context profile based on the identification result.

- If the user is authenticated successfully, the authentication server can assign the network access rights mapping the user context profile to the user based on the user context reported by the device.
- If the user fails to be authenticated, the device assigns the user the network access rights in each phase before authentication success, which are bound to the context profile in the user authentication event authorization policy.

For example, on some enterprise networks, VLANs are used to divide the entire network into different areas with various security levels. The administrator requires that a user should obtain different network access rights when the user connects to the network from different areas. In this case, the user context identification function can be enabled on access devices, and a group of VLANs that belong to the same area are added to the same user context profile. The administrator then assigns the mapping network access rights to different user context profiles based on the security level of each area. When a user connects to the network from different areas, the user is added to different user context profiles matching their access VLANs and therefore obtains different network access rights.

Follow-up Procedure

1. In the system view, run the **access-context profile name** *profile-name* command to create a user context profile.
2. In the user context profile view, run the **if-match vlan-id** { *start-vlan-id* [*to end-vlan-id*] } &<1-10> command to configure the user identification policy based on VLAN IDs.

Precautions

- The device can only identify user VLANs.

Example

Enable the user context identification function.

```
<HUAWEI> system-view  
[HUAWEI] access-context profile enable
```

13.4.3 access-context profile name

Function

The **access-context profile name** command creates a user context profile and displays the user context profile view.

The **undo access-context profile name** command deletes the created user context profile.

By default, no user context profile is created.

Format

access-context profile name *profile-name*

undo access-context profile name *profile-name*

Parameters

Parameter	Description	Value
<i>profile-name</i>	Specifies the name of a user context profile.	The value is a string of 1 to 32 case-sensitive characters without any space. The value cannot be set to - or --, and cannot contain the following characters: / \ : * ? " < > @ ' %.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To simplify the authentication server configuration, the administrator can add the users with the same network access rights to the same user context profile based on the user context, and assign the network access rights to the users based on the user context profile.

Follow-up Procedure

In the user context profile view, run the **if-match vlan-id** *start-vlan-id* [**to end-vlan-id**] &<1-10> command to configure the user identification policy based on VLAN IDs.

Example

Creates the user context profile **p1**.

```
<HUAWEI> system-view  
[HUAWEI] access-context profile name p1
```

13.4.4 access-author policy global

Function

The **access-author policy global** command applies a user authentication event authorization policy.

The **undo access-author policy global** command restores the default configuration.

By default, no user authentication event authorization policy is applied.

Format

access-author policy *policy-name* **global**

undo access-author policy *policy-name* **global**

Parameters

Parameter	Description	Value
<i>policy-name</i>	Specifies the name of a user authentication event authorization policy.	The value must be the name of an existing user authentication event authorization policy on the device.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Users need basic network access rights before they are authenticated. For example, the users need to download 802.1X clients and update the antivirus database. A user authentication event authorization policy can be used to bind the network access rights of users in each phase before authentication success to a user context profile. When a user goes online after a user authentication event authorization policy is applied to the device, the device adds the user to the context profile based on the user context identification result, and assigns the network access rights to the user based on the user authentication result.

Prerequisites

A user authentication event authorization policy has been created using the **access-author policy name** *policy-name* command in the system view.

Precautions

This function takes effect only for users who go online after this function is successfully configured.

Example

Globally apply the user authentication event authorization policy **a1**.

```
<HUAWEI> system-view  
[HUAWEI] access-author policy name a1  
[HUAWEI-access-author-a1] quit  
[HUAWEI] access-author policy a1 global
```

13.4.5 access-author policy name

Function

The **access-author policy name** command creates a user authentication event authorization policy and displays the user authentication event authorization policy view.

The **undo access-author policy name** command deletes the created user authentication event authorization policy.

By default, no user authentication event authorization policy is created.

Format

access-author policy name *policy-name*

undo access-author policy name *policy-name*

Parameters

Parameter	Description	Value
<i>policy-name</i>	Specifies the name of a user authentication event authorization policy.	The value is a string of 1 to 32 case-sensitive characters without any space. The value cannot be set to - or --, and cannot contain the following characters: / \ : * ? " < > @ ' %. NOTE The value of <i>profile-name</i> cannot be set to the first character or first several characters of the name, and the name itself, and it also cannot be the uppercase and lowercase combination of the first character, first several characters, and the name. This prevents the conflict with the 13.4.4 access-author policy global command.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Users need basic network access rights before they are authenticated. For example, the users need to download 802.1X clients and update the antivirus database. A user authentication event authorization policy can be used to bind the network access rights of users in each phase before authentication success to a user context profile. When a user goes online after a user authentication event authorization policy is applied to the device, the device adds the user to the context profile based on the user context identification result, and assigns the network access rights to the user based on the user authentication result.

Follow-up Procedure

1. In the user authentication event authorization policy view, run the [match access-context-profile action](#) command to configure the network access rights for users in each phase before authentication success.

2. In the system view, run the **access-author policy global** command to apply the user authentication event authorization policy.

Example

Create the user authentication event authorization policy **a1**.

```
<HUAWEI> system-view  
[HUAWEI] access-author policy name a1
```

13.4.6 access-domain

Function

The **access-domain** command configures a default or forcible domain in an authentication profile for users.

The **undo access-domain** command deletes a configured default or forcible domain in an authentication profile.

By default, no default or forcible domain is configured in an authentication profile.

Format

access-domain *domain-name* [**dot1x** | **mac-authen** | **portal**] * [**force**]

undo access-domain [**dot1x** | **mac-authen** | **portal**] * [**force**]

Parameters

Parameter	Description	Value
<i>domain-name</i>	Specifies the domain name.	The value must be the name of an existing domain.
dot1x	Specifies a default or forcible domain for 802.1X authentication users.	-
mac-authen	Specifies a default or forcible domain for MAC address authentication users.	-
portal	Specifies a default or forcible domain for Portal authentication users.	-

Parameter	Description	Value
force	Specifies the configured domain as a forcible domain. If this parameter is not specified, the configured domain is a default domain.	-

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device manages users in domains. For example, AAA schemes and authorization information are bound to domains. During user authentication, the device assigns users to specified domains based on the domain names contained in user names. However, user names entered by many users on actual networks do not contain domain names. In this case, you can configure a default domain in an authentication profile. If users using this profile enter user names that do not contain domain names, the device manages the users in the default domain.

On actual networks, user names entered by some users contain domain names and those entered by other users do not. The device uses different domains to manage the users. Because authentication, authorization and accounting (AAA) information in the domains are different, users use different AAA information. To ensure that users using the same authentication profile use the same AAA information, you can configure a forcible domain in the authentication profile for the users. The device then manages the users in the forcible domain regardless of whether entered user names contain domain names or not.

Prerequisites

A domain has been configured using the [13.1.47 domain \(AAA view\)](#) command in the AAA view.

Precautions

When you configure a default or forcible domain in an authentication profile, the domain takes effect as follows:

- If you do not specify the user authentication mode (**dot1x**, **mac-authen**, or **portal**), the domain takes effect for all access authentication users using the authentication profile.

- If both a default domain and a forcible domain are configured, the device authenticates users in the forcible domain.
- This function takes effect only for users who go online after this function is successfully configured.
- In a wireless scenario, RADIUS accounting is performed only for AAA users who do not need to pass authentication in a forcible domain, and cannot be performed for such users in the default domain.

Example

Configure the forcible domain **huawei** in the authentication profile **p1**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain huawei
[HUAWEI-aaa-domain-huawei] quit
[HUAWEI-aaa] quit
[HUAWEI] authentication-profile name p1
[HUAWEI-authen-profile-p1] access-domain huawei force
```

Related Topics

[13.4.61 display authentication-profile configuration](#)

13.4.7 access-user arp-detect

Function

The **access-user arp-detect** command sets the source IP address and source MAC address of offline detection packets in a VLAN.

The **undo access-user arp-detect** command deletes the source IP address and source MAC address of offline detection packets in a VLAN.

By default, the source IP address and source MAC address are not specified for offline detection packets in a VLAN.

Format

access-user arp-detect **vlan** *vlan-id* **ip-address** *ip-address* **mac-address** *mac-address*

undo access-user arp-detect **vlan** *vlan-id* **ip-address** *ip-address* **mac-address** *mac-address*

Parameters

Parameter	Description	Value
vlan <i>vlan-id</i>	Specifies a VLAN ID.	The value is an integer that ranges from 1 to 4094.

Parameter	Description	Value
ip-address <i>ip-address</i>	Specifies the source IP address of offline detection packets.	The value is in dotted decimal notation.
mac-address <i>mac-address</i>	Specifies the source MAC address of offline detection packets.	The value is a unicast MAC address in H-H-H format, where H can be one to four hexadecimal digits.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device sends an ARP probe packet to check the user online status. If the user does not respond within a detection period, the device considers that the user is offline.

If the VLAN to which the user belongs does not have a VLANIF interface or the VLANIF interface does not have an IP address, the device sends an offline detection packet using 0.0.0.0 as the source IP address. If a user cannot respond to an ARP probe packet with the source IP address 0.0.0.0, you can specify a source IP address for the offline detection packet.

You are advised to specify the user gateway IP address and its corresponding MAC address as the source IP address and source MAC address of offline detection packets.

Precautions

This function does not take effect for users who use Layer 3 Portal authentication.

If a user on a physical interface is online, this command takes effect only after the user goes online again or the device re-authenticates the user.

If a user on a Eth-trunk interface is online, this command takes immediately.

Example

```
# Set the source IP address and MAC address of offline detection packets for users in VLAN 10 to 192.168.1.1 and 2222-1111-1234 respectively.
```

```
<HUAWEI> system-view  
[HUAWEI] access-user arp-detect vlan 10 ip-address 192.168.1.1 mac-address 2222-1111-1234
```

13.4.8 access-user arp-detect default ip-address

Function

The **access-user arp-detect default ip-address** command sets the default source IP address of offline detection packets.

The **undo access-user arp-detect default ip-address** command restores the default setting.

By default, the default source IP address of offline detection packets is 0.0.0.0.

Format

access-user arp-detect default ip-address *ip-address*

undo access-user arp-detect default ip-address

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the default source IP address of offline detection packets.	The value is in dotted decimal notation and can be 0.0.0.0 or 255.255.255.255.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device sends an ARP probe packet to check the user online status. If the user does not respond within a detection period, the device considers that the user is offline.

Precautions

- This function does not take effect for users who use Layer 3 Portal authentication.
- In the SVF or policy association scenario, you are advised to run the **access-user arp-detect default ip-address** command to set the source IP address of offline detection packets to 0.0.0.0. In the SVF scenario, the command must be configured on the UC device and takes effect only for UC detection. The default source IP address of offline detection packets for AS detection is

0.0.0.0. In the policy association scenario, you can directly configure the command on the AS device.

- In normal situations, after a device sends an ARP probe packet with a default source IP address, online clients will immediately respond with ARP reply packets. If online clients do not respond with ARP reply packets, the device logs them out unexpectedly. To resolve this problem, use either of the following methods:
 - Run the **access-user arp-detect vlan *vlan-id* ip-address *ip-address* mac-address *mac-address*** command to specify a VLAN ID, source IP address, and source MAC address for ARP probe packets.
 - Run the **authentication timer handshake-period *handshake-period*** command to increase the handshake period so that the device can detect gratuitous ARP packets that these clients send at an irregular period. Once the device detects such packets, it does not log them out.

Example

```
# Set the default source IP address of offline detection packets to 0.0.0.0.
```

```
<HUAWEI> system-view  
[HUAWEI] access-user arp-detect default ip-address 0.0.0.0
```

13.4.9 access-user dot1x-identity speed-limit

Function

The **access-user dot1x-identity speed-limit** command configures the rate limit of Identity packets for wireless 802.1X authentication to be sent to the CPU.

The **undo access-user dot1x-identity speed-limit** command restores the default rate limit of Identity packets for wireless 802.1X authentication to be sent to the CPU.

By default, the maximum of Identity packets for wireless 802.1X authentication can be sent to the CPU every second depends on the device.

NOTE

This function is supported only by S5720HI.

Format

```
access-user dot1x-identity speed-limit value
```

```
undo access-user dot1x-identity speed-limit [ value ]
```


Parameters

Parameter	Description	Value
<i>value</i>	Specifies the rate limit of Identity packets for wireless 802.1X authentication to be sent to the CPU.	The value is an integer in the range of 5 to 40, in pps.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

If a large number of Identity packets for wireless 802.1X authentication are sent to the CPU of a switch, the CPU usage is high and other services are affected. To prevent this problem, run the **access-user dot1x-identity speed-limit** command to configure the rate limit of Identity packets for wireless 802.1X authentication to be sent to the CPU, so that the switch discards excess Identity packets.

Example

Set the rate limit of Identity packets for wireless 802.1X authentication to be sent to the CPU to 10 pps.

```
<HUAWEI> system-view  
[HUAWEI] access-user dot1x-identity speed-limit 10
```

13.4.10 access-user syslog-restrain enable

Function

The **access-user syslog-restrain enable** command enables system log suppression.

The **undo access-user syslog-restrain enable** command disables system log suppression.

By default, system log suppression is enabled.

Format

access-user syslog-restrain enable

undo access-user syslog-restrain enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When a user fails in authentication or goes offline, the device records a system log. The system log contains the MAC addresses of access device and access user and the authentication time.

If a user repeatedly attempts to go online after authentication failures or frequently goes online and offline in a short period, a lot of system logs are generated, which waste system resources and degrade system performance. System log suppression can address this problem. After the device generates a system log, it will not generate the same log within the suppression period (set by [13.4.11 access-user syslog-restrain period](#)).

NOTE

The same system logs refer to the system logs containing the same MAC addresses. For example, after the device generates a system log for a user failing in authentication, the device will not generate new system log for this user in the suppression period if the user fails in authentication again. The system logs for users logging offline are generated in the same way. If a system log has no MAC address, such system logs are suppressed based on the user name.

Example

```
# Enable system log suppression.
```

```
<HUAWEI> system-view  
[HUAWEI] access-user syslog-restrain enable
```

Related Topics

[13.4.11 access-user syslog-restrain period](#)

13.4.11 access-user syslog-restrain period

Function

The **access-user syslog-restrain period** command sets a period for system log suppression.

The **undo access-user syslog-restrain period** command restores the default period for system log suppression.

By default, the period of system log suppression is 300s.

Format

access-user syslog-restrain period *period*

undo access-user syslog-restrain period

Parameters

Parameter	Description	Value
<i>period</i>	Specifies the period for system log suppression.	The value is an integer that ranges from 60 to 604800, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the system log suppression function is enabled using the [13.4.10 access-user syslog-restrain enable](#) command, use this command to set the system log suppression period. After generating a system log, the device will not generate the same log within the suppression period.

Example

Set the period for system log suppression to 600s.

```
<HUAWEI> system-view  
[HUAWEI] access-user syslog-restrain period 600
```

Related Topics

[13.4.10 access-user syslog-restrain enable](#)

13.4.12 acl-id (service scheme view)

Function

The **acl-id** command binds an ACL to a service scheme.

The **undo acl-id** command unbinds the ACL from the service scheme.

By default, no ACL is bound to a service scheme.

NOTE

S5720EI, S5720HI, S6720EI, and S6720S-EI do not support this command.

Format

```
acl-id acl-number  
undo acl-id { acl-number | all }
```

Parameters

Parameter	Description	Value
<i>acl-number</i>	Specifies the number of an ACL bound to a service scheme.	The value is an integer that ranges from 3000 to 3999.
all	Deletes the numbers of all ACLs bound to a service scheme.	-

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After creating a service scheme using the [13.1.82 service-scheme \(AAA view\)](#) command, you can run the **acl-id** command to bind an ACL to the service scheme. The user assigned with the service scheme will have the ACL rules.

Prerequisites

An IPv4 ACL must have been created using the [14.1.5 acl \(system view\)](#) or [14.1.4 acl name](#) command.

Precautions

If all users in a group are required to have the same access rights, do not specify the source IP address in the ACL bound to the service scheme. If an ACL bound to a service scheme has defined the source IP address, only users with the same IP address as the source IP address in the ACL can match the ACL in the service scheme.

The maximum number of ACLs that can be bound to a service scheme is 4.

In the policy association scenario, if multiple ACLs are configured using this command on the authentication control device, only the first configured one takes effect on the authentication access device.

Example

```
# Bind ACL 3001 to the service scheme huawei.
```

```
<HUAWEI> system-view
[HUAWEI] acl 3001
[HUAWEI-acl-adv-3001] quit
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme huawei
[HUAWEI-aaa-service-huawei] acl-id 3001
```

13.4.13 authentication handshake

Function

The **authentication handshake** command enables the handshake with pre-connection users and authorized users.

The **undo authentication handshake** command disables the handshake with pre-connection users and authorized users.

By default, the handshake with pre-connection users and authorized users is enabled.

Format

authentication handshake

undo authentication handshake

Parameters

None

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device creates entries for pre-connection users, users who fail to be authenticated and are assigned network access rights, and users who are authenticated. After users go offline in normal situations, the system immediately deletes the corresponding user entries. However, if some users go offline due to exceptions such as network disconnections, the system cannot immediately delete the corresponding user entries. If there are too many such invalid user entries, other users may fail to access the network.

To solve this problem, run the **authentication handshake** command to enable the handshake with pre-connection users and authorized users. If a user does not respond to the handshake request from the device within the handshake interval, the device deletes the user entry.

Precautions

- The handshake interval for MAC address authentication users, Layer 3 Portal authentication users, and 802.1X authentication users is configured using the **13.4.30 authentication timer handshake-period** command. The handshake interval for Layer 2 Portal authentication users is configured using the **portal timer offline-detect** command.
- For Layer 3 Portal authentication users, only those who go online through S5720HI support this function.
- This function takes effect only for the wired users who obtain IP addresses.
- When the configuration changes, the configuration takes effect only for new online wired users.
- The handshake function is implemented using ARP probe packets or neighbor discovery (ND) probe packets.
- The handshake function can also be implemented by detecting whether there is user traffic on the access device. Assuming that the handshake interval is **3n**, the device will detect user traffic at **n** and **2n**. The following uses the **0-n** period as an example. The process during the **n-2n** period is similar to that during **0-n**. (This process applies only to authentication users who go online from the S5720EI, S5720HI, S6720EI, and S6720S-EI. Other switch models do not detect user traffic and send probe packets at **n** and **2n**.)
 - If user traffic passes the device during the **0-n** period, the device considers that the user is online at **n**, so it will not send a probe packet to the user, but resets the handshake interval.
 - If no user traffic passes the device during the **0-n** period, the device cannot determine whether the user is online at **n**, so it sends a probe packet to the user. If the device receives the reply packet from the user, it considers the user online and resets the handshake interval. If no reply packet is received, it considers the user offline.
 - If user traffic passes the device during the **2n-3n** period, the device considers that the user is online at **3n** and resets the handshake interval.
 - If no user traffic passes the device during the **2n-3n** period, the device cannot determine whether the user is online at **3n** and considers that the user is offline.

If the device considers that the user is offline at **n**, **2n**, and **3n**, the device deletes all entries related to the user. To prevent the user from going offline unexpectedly when no operation is performed on the PC, do not set a short handshake period.

Example

In the authentication profile **p1**, enable the handshake with pre-connection users and authorized users.

```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name p1  
[HUAWEI-authen-profile-p1] authentication handshake
```

13.4.14 authentication control-direction

Function

The **authentication control-direction** command configures the direction of traffic controlled by the device.

By default, the device only controls the upstream traffic.

Format

authentication control-direction { all | inbound }

Parameters

Parameter	Description	Value
all	Configures bidirectional traffic control.	-
inbound	Controls only the upstream traffic.	-

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

By default, the access authentication device discards all the traffic sent from the users who fail the 802.1x authentication or MAC address authentication. However, these users can still receive packets broadcast from network devices to successfully authenticated users in the same VLAN. To disable the users who fail the authentication from receiving the broadcast packets, run the **authentication control-direction all** command to configure bidirectional traffic control. To restore the default situation, run the **authentication control-direction inbound** command so that the device only controls the traffic sent from the users who fail the authentication.

Precaution

- This function applies only to 802.1x authentication and MAC address authentication.
- This function takes effect only when an access switch functions as the authentication device and an interface of the switch is connected to only one IP phone or PC.
- This function does not take effect when users have pre-connection entries or authentication event entries. You are advised to run the **undo authentication**

pre-authen-access enable command disable the function of keeping users who fail to be authenticated and do not have any network access rights in the pre-connection state, and do not run the **authentication event** command to configure the device to assign network access rights to users in each phase before authentication succeeds.

- When there are both successfully authenticated users and users who fail to be authenticated on the same interface in the same VLAN, bidirectional traffic control does not take effect on this interface.
- Layer 3 interfaces do not support bidirectional traffic control.
- You are advised to run the **stp edged-port enable** command to configure the interface on which the function is applied as an edge port. The interface can be added to a maximum of four VLANs.
- The SVF and policy association scenarios do not support this function.
- WLAN scenarios do not support this function.
- When this function is configured, the recommended STP mode is VBST. If the STP mode is changed after users go online, traffic will be interrupted for a short time. If the STP mode is set to MSTP or STP, run the **5.12.19 instance** command to map VLANs to different spanning tree instances (MSTIs).
- A user VLAN cannot be specified as an RRPP or ERPS control VLAN.

Example

Configure bidirectional traffic control in the authentication profile **authen1**.

```
<HUAWEI> system-view
[HUAWEI] authentication-profile name authen1
[HUAWEI-authen-profile-authen1] authentication control-direction all
```

13.4.15 authentication device-type voice authorize

Function

The **authentication device-type voice authorize** command enables voice terminals to go online without authentication.

The **undo authentication device-type voice authorize** command disables voice terminals from going online without authentication.

By default, voice terminals are disabled from going online without authentication.

Format

authentication device-type voice authorize [**service-scheme** *scheme-name*]

undo authentication device-type voice authorize [**service-scheme**]

Parameters

Parameter	Description	Value
service-scheme <i>scheme-name</i>	Specifies the name of the service scheme based on which network access rights are assigned to voice terminals.	The value must be an existing service scheme name.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When both data terminals (such as PCs) and voice terminals (such as IP phones) are connected to devices, NAC is configured on the devices to manage and control the data terminals. The voice terminals, however, only need to connect to the network without being managed and controlled. In this case, you can configure the voice terminals to go online without authentication on the devices. Then the voice terminals identified by the devices can go online without authentication.

Precautions

When a RADIUS server is used for dynamic VLAN delivery, the following RADIUS attributes must be used: (064) Tunnel-Type (which must be set to VLAN or 13), (065) Tunnel-Medium-Type (which must be set to 802 or 6), and (081) Tunnel-Private-Group-ID (which can be set to the VLAN ID , VLAN description). To ensure that the RADIUS server delivers VLAN attributes correctly, all the three RADIUS attributes must be used. In addition, the Tunnel-Type and Tunnel-Medium-Type attributes must be set to the specified values. When a voice VLAN is delivered, the RADIUS attribute (26-33) HW-Voice-Vlan must also be used.

To enable the switches to identify the voice terminals, enable LLDP or configure OUI for the voice VLAN on the switches. For details, see "Configuring Basic LLDP Functions" in "LLDP Configuration" in the *S1720, S2700, S5700, and S6720 V200R011C10 Configuration Guide - Network Management and Monitoring* or "Configuring a Voice VLAN Based on a MAC Address" in "Voice VLAN Configuration" in the *S1720, S2700, S5700, and S6720 V200R011C10 Configuration Guide - Ethernet Switching*. If a voice device supports only CDP but does not support LLDP, configure CDP-compatible LLDP on the switch using **16.3.16 lldp compliance cdp receive** command.

To identify voice terminals in a policy association scenario, the voice VLAN OUI must be configured.

After the voice VLAN function is enabled on an interface using the **voice-vlan enable** command, authenticated voice terminals are authorized to use the voice VLAN if the VLAN of the voice terminals is the same as the voice VLAN.

If an 802.1X user initiates authentication through a voice terminal, a device preferentially processes the authentication request. If the authentication succeeds, the terminal obtains the corresponding network access rights. If the authentication fails, the device identifies the terminal type and enables the terminal to go online without authentication.

If you run this command repeatedly, the latest configuration overrides the previous ones.

This function takes effect only for users who go online after this function is successfully configured.

Example

In the authentication profile **p1**, enable the device to allow voice terminals to go online without authentication and assign the service scheme **s1** to voice terminals that are not authenticated.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme s1
[HUAWEI-aaa-service-s1] quit
[HUAWEI-aaa] quit
[HUAWEI] authentication-profile name p1
[HUAWEI-authen-profile-p1] authentication device-type voice authorize service-scheme s1
```

13.4.16 authentication dot1x-mac-bypass

Function

The **authentication dot1x-mac-bypass** command enables MAC address bypass authentication.

The **undo authentication dot1x-mac-bypass** command disables MAC address bypass authentication.

By default, MAC address bypass authentication is disabled.

Format

authentication dot1x-mac-bypass

undo authentication dot1x-mac-bypass

Parameters

None

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

You can configure MAC address bypass authentication to authenticate terminals such as printers that cannot have the 802.1X client installed.

After MAC address bypass authentication is enabled in an authentication profile, the device performs 802.1X authentication for users using the authentication profile. If the user name request times out, the device starts the MAC address authentication process for the users.

Precautions

MAC address bypass authentication involves 802.1X authentication and MAC address authentication. Before enabling this function in an authentication profile, ensure that an 802.1X access profile and a MAC access profile have been bound to the authentication profile.

Example

In the authentication profile **p1**, enable MAC address bypass authentication.

```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name p1  
[HUAWEI-authen-profile-p1] authentication dot1x-mac-bypass
```

13.4.17 authentication event action authorize

Function

The **authentication event action authorize** command configures authentication event authorization information.

The **undo authentication event action authorize** command restores the default setting.

By default, authentication event authorization information is not configured.

Format

User authorization in the case of pre-connections:

```
authentication event pre-authen action authorize { vlan vlan-id | service-scheme service-scheme-name | ucl-group ucl-group-name }
```

```
undo authentication event pre-authen action authorize
```

User authorization when authentication fails:

```
authentication event authen-fail action authorize { vlan vlan-id | service-scheme service-scheme-name | ucl-group ucl-group-name } [ response-fail ]
```

```
undo authentication event authen-fail action authorize
```

User authorization when the authentication server is Down:

authentication event authen-server-down action authorize { **vlan** *vlan-id* | **service-scheme** *service-scheme-name* | **ucl-group** *ucl-group-name* } [**response-fail**]

undo authentication event authen-server-down action authorize

Parameters

Parameter	Description	Value
pre-authen	Configures the device to assign network access rights to users when the users establish pre-connections with the device.	-
authen-fail	Configures the device to assign network access rights to users when the authentication server sends authentication failure packets to the device.	-
authen-server-down	Configures the device to assign network access rights to users when the authentication server is Down.	-
response-fail	Configures the device to send authentication failure packets to users after assigning network access rights to the users. If this parameter is not specified, the device by default sends authentication success packets to users and therefore the users cannot know the fact that they fail to be authenticated. To solve this problem, specify this parameter so that the device will send authentication failure packets for the users to know their authentication results.	-

Parameter	Description	Value
vlan <i>vlan-id</i>	Specifies a VLAN ID. When this parameter is specified, users can access only the resources in the VLAN.	The value is an integer that ranges from 1 to 4094. The VLAN must exist on the device. Otherwise, the configuration does not take effect.
service-scheme <i>service-scheme-name</i>	Specifies the name of the service scheme based on which network access rights are assigned to users.	The value must be an existing service scheme name on the device.
ucl-group <i>ucl-group-name</i>	Specifies the name of the UCL group based on which network access rights are assigned to users. NOTE This parameter is supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI.	The value must be an existing UCL group name on the device.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If users establish pre-connections with the device or fail to be authenticated, they have no network access rights.

To meet these users' basic network access requirements such as updating the antivirus database and downloading the client, configure authentication event authorization information. The device will assign network access rights to these users based on the authentication phase.

Precautions

Wireless 802.1X authentication does not support this function.

If no network access right is configured for users who fail authentication or when the authentication server is Down, the users establish pre-connections with the

device after the authentication fails and then have the network access rights mapping pre-connection users.

VLAN-based authorization does not apply to the authentication users who access through VLANIF interfaces.

To use VLAN-based authorization (excluding authentication of pre-connection users), run the [13.4.29 authentication pre-authen-access enable](#) command to disable the pre-connection function first.

An authorized VLAN cannot be delivered to online Portal users.

This function takes effect only for users who go online after this function is successfully configured.

For S5720EI, S6720EI, and S6720S-EI, if the user upstream rate limit is configured in the QoS profile bound to a service scheme, do not configure the device to use the service scheme to grant network access rights to users in the pre-connection phase. Otherwise, users go offline.

When the authentication server is in Down state, user authentication fails, or the user is in pre-connection state, the redirection ACL function is not supported. For details about this function, see [13.1.72 redirect-acl](#).

In 802.1X authentication for wired users, when the RADIUS server is Down, some new clients do not have escape rights. For example, when a new Windows client receives a Success packet from the device but does not receive the authentication packets exchanged with the RADIUS server, the client will fail the authentication and cannot go online. Currently, the following clients have escape rights when they go online for the first time: H3C iNode clients using EAP-MD5 or PEAP and Cisco AnyConnect clients using EAP-FAST or PEAP. For Windows clients, for example, Windows 7, choose "Local Area Connection> Properties> Authentication> Fallback to unauthorized network access".

Authentication event authorization information cannot be configured for static users identified by IP addresses.

Example

In the authentication profile **authen1**, configure the device to assign network access rights specified in VLAN 10 to pre-connection users.

```
<HUAWEI> system-view
[HUAWEI] vlan batch 10
[HUAWEI] authentication-profile name authen1
[HUAWEI-authen-profile-authen1] authentication event pre-authen action authorize vlan 10
```

13.4.18 authentication event authen-server-up action re-authen

Function

The **authentication event authen-server-up action re-authen** command enables the device to re-authenticate users in the survival state when the authentication server changes from Down to Up.

The **undo authentication event authen-server-up action re-authen** command restores the default setting.

By default, the device does not re-authenticate users in the survival state when the authentication server changes from Down to UP.

Format

authentication event authen-server-up action re-authen

undo authentication event authen-server-up action re-authen

Parameters

None

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The users in the survival state can only access limited network resources after the device assigns specified network access rights to users who fail authentication because the authentication server is Down. To meet the users' normal network access requirements, the device needs to re-authenticate users in the survival state in real time when the authentication server turns Up.

Prerequisites

The [13.2.46 radius-server testuser](#) command has been configured in the RADIUS server template so that the device can detect that the authentication server changes from Down to Up.

NOTE

If the [13.2.46 radius-server testuser](#) command is not configured and the device sets the status of the authentication server to Down, the device will automatically set the status of the authentication server to Up after the interval (configured using the [13.2.41 radius-server retransmit timeout dead-time](#) command) for the server to restore to the active state. The device will not re-authenticate users.

Example

In the authentication profile **authen1**, enable the device to re-authenticate users when the authentication server turns Up from Down.

```
<HUAWEI> system-view
[HUAWEI] authentication-profile name authen1
[HUAWEI-authen-profile-authen1] authentication event authen-server-up action re-authen
```

13.4.19 authentication event client-no-response action authorize authorize

Function

The **authentication event client-no-response action authorize authorize** command configures network access rights for users when the 802.1X client does not respond.

The **undo authentication event client-no-response action authorize authorize** command restores the default setting.

By default, no network access right is configured for users when the 802.1X client does not respond.

Format

authentication event client-no-response action authorize { service-scheme *service-scheme-name* | ucl-group *ucl-group-name* | vlan *vlan-id* }

undo authentication event client-no-response action authorize

Parameters

Parameter	Description	Value
service-scheme <i>service-scheme-name</i>	Specifies the name of a service scheme based on which network access rights are assigned.	The value must be an existing service scheme name on the device.
ucl-group <i>ucl-group-name</i>	Specifies the name of a UCL group based on which network access rights are assigned. NOTE This parameter is only supported by the S5720EI, S5720HI, S6720EI, and S6720S-EI.	The value must be an existing UCL group name on the device.
vlan <i>vlan-id</i>	Specifies a VLAN ID. When this parameter is specified, users can access only the resources in the VLAN.	The value is an integer that ranges from 1 to 4094.

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If the 802.1X client does not respond, users cannot pass authentication and thereby have no network access right. Before being successfully authenticated, some users may need certain basic network access rights to download client software and update the antivirus database. The network access rights can be configured for the users when the 802.1X client does not respond, so that the users can access specified network resources.

Precautions

Wireless 802.1X authentication does not support this function.

This function takes effect only for users who go online after this function is successfully configured.

When an 802.1X client does not respond, the redirection ACL function is not supported. For details about the function, see [13.1.72 redirect-acl](#).

Example

In the 802.1X access profile **d1**, configure the device to assign the network access rights specified in VLAN 10 for users when the 802.1X client does not respond.

```
<HUAWEI> system-view
[HUAWEI] vlan batch 10
[HUAWEI] dot1x-access-profile name d1
[HUAWEI-dot1x-access-profile-d1] authentication event client-no-response action authorize vlan 10
```

Related Topics

[13.4.64 display dot1x-access-profile configuration](#)

13.4.20 authentication event portal-server-down action authorize

Function

The **authentication event portal-server-down action authorize** command configures network access rights for users when the Portal server is Down.

The **undo authentication event portal-server-down action authorize** command deletes the network access rights configured for users when the Portal server is Down.

By default, no network access right is configured for users when the Portal server is Down.

Format

authentication event portal-server-down action authorize { *service-scheme service-scheme-name* | *ucl-group ucl-group-name* }

undo authentication event portal-server-down action authorize

Parameters

Parameter	Description	Value
service-scheme <i>service-scheme-name</i>	Specifies the name of the service scheme based on which network access rights are assigned to users.	The value must be an existing service scheme name.
ucl-group <i>ucl-group-name</i>	Specifies the name of the UCL group based on which network access rights are assigned to users. NOTE This parameter is only supported by the S5720EI, S5720HI, S6720EI, and S6720S-EI.	The value must be an existing UCL group name.

Views

Portal access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If the Portal server is Down, users cannot pass the authentication and thereby have no network access right. Before being successfully authenticated, some users may need certain basic network access rights to download client software and update the antivirus database. The network access rights can be configured for the users when the Portal server is Down, so that the users can access specified network resources.

Prerequisites

A UCL group has been created using the **ucl-group** command in the system view.

A service scheme has been created using the **service-scheme** command in the AAA view.

Precautions

- This function takes effect only for users who go online after this function is successfully configured.
- Only HTTP messages-triggered Portal authentication users support this function.
- Before enabling the access device to assign network access rights to users when the Portal server is Down, enable the heartbeat detection function on the Portal server and run the **server-detect** command on the access device to enable the Portal server detection function.

- When the Portal server is in Down state, the redirection ACL function is not supported. For details about this function, see [13.1.72 redirect-acl](#).

Example

In the Portal access profile **p1**, configure the device to assign network access rights based on the service scheme **s1** to users when the Portal server is Down.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme s1
[HUAWEI-aaa-service-s1] quit
[HUAWEI-aaa] quit
[HUAWEI] portal-access-profile name p1
[HUAWEI-portal-access-profile-p1] authentication event portal-server-down action authorize service-
scheme s1
```

Related Topics

[13.4.77 display portal-access-profile configuration](#)

13.4.21 authentication event portal-server-up action re-authen

Function

The **authentication event portal-server-up action re-authen** command enables the device to re-authenticate users when the Portal server turns Up from Down.

The **undo authentication event portal-server-up action re-authen** command restores the default setting.

By default, the device does not re-authenticate users when the Portal server turns Up from Down.

Format

authentication event portal-server-up action re-authen

undo authentication event portal-server-up action re-authen

Parameters

None

Views

Portal access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If the device is configured to assign network access rights to users when the Portal server is Down, users can access limited network resources after the device detects that the Portal server is Down. To ensure that users can obtain normal network access rights after the Portal server goes Up, you can enable the device to re-authenticate users when the Portal server changes from Down to Up. After the Portal server goes Up, the device sets the status of users who display **web-server-down** to pre-connection. The re-authentication process starts when the users visit any web page. If the authentication succeeds, the device assigns normal network access rights to the users.

Precautions

- This command does not apply to users connected to the route main interface.
- This function takes effect only for users who go online after this function is successfully configured.
- Before enabling the access device to assign network access rights to users when the Portal server is Down, enable the heartbeat detection function on the Portal server and run the **server-detect** command on the access device to enable the Portal server detection function.

Example

In the Portal access profile **p1**, enable the device to re-authenticate users when the Portal server turns Up from Down.

```
<HUAWEI> system-view
[HUAWEI] portal-access-profile name p1
[HUAWEI-portal-access-profile-p1] authentication event portal-server-up action re-authen
```

Related Topics

[13.4.77 display portal-access-profile configuration](#)

13.4.22 authentication mac-move enable

Function

The **authentication mac-move enable** command enables MAC address migration.

The **undo authentication mac-move enable** command disables MAC address migration.

By default, MAC address migration is disabled.

Format

authentication mac-move enable vlan { **all** | { *vlan-id1* [**to** *vlan-id2*] } & <1-10> }

undo authentication mac-move enable vlan { **all** | { *vlan-id1* [**to** *vlan-id2*] } & <1-10> }

Parameters

Parameter	Description	Value
vlan	Specifies the VLAN range for enabling MAC address migration.	-
all	Enables MAC address migration in all VLANs.	-
<i>vlan-id1</i> [to <i>vlan-id2</i>]	Enables MAC address migration in the specified VLANs. <ul style="list-style-type: none">• <i>vlan-id1</i> specifies the ID of the first VLAN.• <i>vlan-id2</i> specifies the ID of the second VLAN. The value of <i>vlan-id2</i> must be greater than that of <i>vlan-id1</i>.	The value is an integer that ranges from 1 to 4094.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a user is authenticated and accesses the network from one interface of the device, the network cable is pulled out from the interface and plugged in another interface on the device. In this case, the user cannot immediately initiate authentication and access the network. The user can initiate authentication on the current interface only after the user offline detection interval expires or the authentication interface is manually enabled and shut down to clear user online entries. To improve user experience, MAC address migration is enabled so that the user can immediately initiate authentication and access the network after be switched to another access interface.

MAC address migration allows online NAC authentication users to immediately initiate authentication and access the network after they are switched to other access interfaces. If the user is authenticated successfully on the new interface, the online user entry on the original interface is deleted immediately to ensure that only one interface records the online user entry.

In addition, VLANs need to be specified for users in MAC address migration. The VLANs before and after the migration can be specified for the users, and they can be the same or different.

Precautions

- In normal case, enabling MAC address migration is not recommended. It should be enabled only when users have migration requirements during roaming. This prevents unauthorized users from forging MAC addresses of online users and sending ARP, 802.1X, or DHCP packets on other authentication control interfaces to trigger the MAC address migration function and force authorized user offline.
- In the Policy Association and SVF scenario, the device does not support MAC address migration.
- In the Layer 2 BNG scenario, the device does not support MAC address migration.
- Cascading migration through intermediate devices is not supported, because ARP and DHCP packets are not sent after the cascading migration.
- The device does not support MAC address migration for a terminal with one MAC address and multiple IP addresses.
- MAC address migration is not supported for Layer 3 Portal authentication users.
- A user is switched from an interface configured with NAC authentication to another interface not configured with NAC authentication. In this case, the user can access the network only after the original online entry is aged because the new interface cannot send authentication packets to trigger MAC migration.
- In common mode, Portal authentication is triggered only after users who go online through a VLANIF interface send ARP packets and go offline; otherwise, the users can go online again only after the original user online entries age out. Portal authentication cannot be triggered after users who go online through physical interfaces migrate. The users can go online again only after the original user online entries age out.
- After a user who goes online from a VLANIF interface is quieted because of multiple MAC address migrations, MAC address migration can be performed for the quieted user only after the quiet period expires and the ARP entry is aged out.
- After authorized VLANs are delivered to users who go online on the S5720EI, S6720EI, and S6720S-EI, some users may fail to migrate. In this scenario, the users can go online again only after the user entries on the interface before the migration are aged out.
- When an authorized VLAN is specified in the **authentication mac-move enable vlan** command, you are advised to enable the function of detecting the user status before user MAC address migration.

Example

```
# Enable MAC address migration in all VLANs.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move enable vlan all
```

13.4.23 authentication mac-move detect enable

Function

The **authentication mac-move detect enable** command enables a device to detect users' online status before user MAC address migration.

The **undo authentication mac-move detect enable** command disables a device from detecting users' online status before user MAC address migration.

By default, a device is disabled from detecting users' online status before user MAC address migration.

Format

authentication mac-move detect enable

undo authentication mac-move detect enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

To prevent unauthorized users from spoofing online users to attack a device, run the **authentication mac-move detect enable** command to enable the device to detect users' online status before user MAC address migration. If no users are online, the device permits MAC address migration and allows users to go online from a new access interface. If a user is online, the device terminates MAC address migration and does not allow the user to go online from a new access interface.

You can also run the [13.4.24 authentication mac-move detect retry-interval retry-time](#) command to set the detection interval and maximum number of detections before user MAC address migration.

After the authentication mac-move detect enable command is configured in an authentication profile, the authentication profile cannot be bound to a VAP profile.

Example

```
# Enable a device to detect users' online status before user MAC address migration.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move detect enable
```

13.4.24 authentication mac-move detect retry-interval retry-time

Function

The **authentication mac-move detect retry-interval retry-time** command sets the detection interval and maximum number of detections before user MAC address migration.

The **undo authentication mac-move detect retry-interval retry-time** command restores the default setting.

By default, a device detects users' online status once. The detection interval is 3 seconds.

Format

authentication mac-move detect { **retry-interval** *interval* | **retry-time** *times* } *

undo authentication mac-move detect { **retry-interval** | **retry-time** } *

Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the interval at which a device detects users' online status before user MAC address migration.	The value is an integer that ranges from 1 to 5, in seconds.
<i>times</i>	Specifies the maximum number of detections before user MAC address migration.	The value is an integer that ranges from 1 to 3.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After a device is enabled to detect users' online status before user MAC address migration, if no users are online, the device permits MAC address migration and allows users to go online from a new access interface. If a user is online, the device terminates MAC address migration and does not allow the user to go online from a new access interface. You can run the **authentication mac-move**

detect { **retry-interval** *interval* | **retry-time** *times* } * command to modify the default detection interval and maximum number of detections.

Example

Configure a device to detect users' online status twice at an interval of 5 seconds before user MAC address migration.

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move detect retry-interval 5 retry-time 2
```

13.4.25 authentication mac-move quiet-log enable

Function

The **authentication mac-move quiet-log enable** command enables the device to record logs about MAC address migration quiet.

The **undo authentication mac-move quiet-log enable** command disables the device from recording logs about MAC address migration quiet.

By default, the device is enabled to record logs about MAC address migration quiet.

Format

authentication mac-move quiet-log enable

undo authentication mac-move quiet-log enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device can record logs when adding or deleting MAC address migration quiet entries. This helps the administrator to find out the cause for MAC address migration failure, and improves maintainability of the MAC address migration quiet function.

Example

Enable the device to record logs about MAC address migration quiet.

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move quiet-log enable
```

13.4.26 authentication mac-move quiet-times quiet-period

Function

The **authentication mac-move quiet-times quiet-period** command configures the quiet period and the maximum number of MAC address migration times within 60 seconds before users enter the quiet state.

The **undo authentication mac-move quiet-times quiet-period** command restores the default settings.

The default quiet period is 0 seconds and the maximum number of MAC address migration times within 60 seconds before users enter the quiet state is 3.

Format

authentication mac-move { **quiet-times** *times* | **quiet-period** *quiet-value* } *

undo authentication mac-move { **quiet-times** | **quiet-period** } *

Parameters

Parameter	Description	Value
<i>times</i>	Specifies the maximum number of MAC address migration times within 60 seconds before users enter the quiet state.	The value is an integer that ranges from 1 to 10.
<i>quiet-value</i>	Specifies the quiet period for MAC address migration users.	The value is an integer that ranges from 0 to 3600. The value 0 indicates that the MAC address migration quiet function is disabled.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When users frequently switch access interfaces (especially frequent switching due to loops), the device needs to process a large number of authentication packets and entries, which results in high CPU usage. To solve this problem, configure the MAC address migration quiet function.

If the number of MAC address migration times for a user within 60 seconds exceeds the value (*times*) after the MAC address migration quiet function is enabled, the device quiets the user for a certain period (*quiet-value*). During the quiet period, the device does not allow users to perform MAC address migration.

Example

Configure the quiet period to 120 seconds and the maximum number of MAC address migration times within 60 seconds before users enter the quiet state to 5.

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move quiet-times 5 quiet-period 120
```

13.4.27 authentication mac-move quiet-user-alarm enable

Function

The **authentication mac-move quiet-user-alarm enable** command enables the device to send alarms about MAC address migration quiet.

The **undo authentication mac-move quiet-user-alarm enable** command disables the device from sending alarms about MAC address migration quiet.

By default, the device is disabled from sending alarms about MAC address migration quiet.

Format

authentication mac-move quiet-user-alarm enable

undo authentication mac-move quiet-user-alarm enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device can send alarms about MAC address migration quiet to improve maintainability of the MAC address migration quiet function. The device sends alarms when the percentage of the actual user amount in the MAC address migration quiet table against the maximum number of users exceeds the upper alarm threshold configured. If the percentage decreases to be equal to or smaller than the lower alarm threshold, the device sends a clear alarm. The upper and lower alarm thresholds are configured using the [13.4.28 authentication mac-move quiet-user-alarm percentage](#) command.

Example

```
# Enable the device to send alarms about MAC address migration quiet.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move quiet-user-alarm enable
```

13.4.28 authentication mac-move quiet-user-alarm percentage

Function

The **authentication mac-move quiet-user-alarm percentage** command configures the upper and lower alarm thresholds for the percentage of MAC address migration users in quiet state.

The **undo authentication mac-move quiet-user-alarm percentage** command restores the default setting.

By default, the lower alarm threshold is 50 and upper alarm threshold is 100.

Format

authentication mac-move quiet-user-alarm percentage *lower-threshold upper-threshold*

undo authentication mac-move quiet-user-alarm percentage

Parameters

Parameter	Description	Value
<i>lower-threshold</i>	Specifies the lower alarm threshold.	The value is an integer that ranges from 1 to 100.
<i>upper-threshold</i>	Specifies the upper alarm threshold.	The value is an integer that ranges from 1 to 100. The value must be greater than that of <i>lower-threshold</i> .

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The **13.4.27 authentication mac-move quiet-user-alarm enable** command can be run to enable the device to send alarms about MAC address migration quiet to improve maintainability of the MAC address migration quiet function. The device sends alarms when the percentage of the actual user amount in the MAC address migration quiet table against the maximum number of users exceeds the upper alarm threshold configured. If the percentage decreases to be equal to or smaller than the lower alarm threshold, the device sends a clear alarm. The upper and lower alarm thresholds are configured using the **authentication mac-move quiet-user-alarm percentage** command.

Example

Configure the upper alarm threshold to 80 and lower alarm threshold to 40.

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move quiet-user-alarm percentage 40 80
```

13.4.29 authentication pre-authen-access enable

Function

The **authentication pre-authen-access enable** command enables the function of keeping users who fail to be authenticated and do not have any network access rights in the pre-connection state.

The **undo authentication pre-authen-access enable** command disables the function of keeping users who fail to be authenticated and do not have any network access rights in the pre-connection state.

By default, the device keeps users who fail to be authenticated and do not have any network access rights in the pre-connection state.

Format

authentication pre-authen-access enable
undo authentication pre-authen-access enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When a user terminal connects to an NAC-enabled interface on the device, a pre-connection is set up between the terminal and device. If the device is not configured to grant network access rights to users in pre-connection or authentication failure state, users who fail to be authenticated remain in the pre-connection state by default. Because the device allows DHCP packets from pre-connection users to pass through, the users can still obtain IP addresses although they do not have any network access rights, wasting IP addresses and bringing network security risks.

You can run the **undo authentication pre-authen-access enable** command to disable the function of keeping users who fail to be authenticated and do not have any network access rights in the pre-connection state. This configuration ensures that the users cannot obtain IP addresses.

Precautions

This function does not take effect for users who use Portal authentication or combined authentication (including Portal authentication).

The **undo authentication pre-authen-access enable** command does not take effect for pre-connection users for whom network access permissions are configured.

To use VLAN-based authorization (excluding authentication of pre-connection users), run the **undo authentication pre-authen-access enable** command to disable the pre-connection function first.

When 802.1X authentication or MAC authentication is configured on a physical interface, the **free-rule** command configuration will not take effect after the pre-connection function is disabled.

If the device connects to some terminals such as a MacBook laptop that is not authenticated after obtaining an IP address, it is recommended that you run the **undo authentication pre-authen-access enable** command on the device to disable the pre-connection function and then connect the terminal to the network again.

If a user in pre-connection state attempts to go online using DHCP packets containing the Option 82 field but fails to go online, it is recommended that you run the **undo authentication pre-authen-access enable** command on the device to disable the function of keeping users who fail to be authenticated and do not have any network access rights in the pre-connection state.

Example

```
# Disable the function of keeping users who fail to be authenticated and do not  
have any network access rights in the pre-connection state.
```

```
<HUAWEI> system-view  
[HUAWEI] undo authentication pre-authen-access enable
```

13.4.30 authentication timer handshake-period

Function

The **authentication timer handshake-period** command sets the handshake interval of the device with pre-connection users and authorized users.

The **undo authentication timer handshake-period** command restores the default setting.

The default handshake interval of the device with pre-connection users and authorized users is 300 seconds.

Format

authentication timer handshake-period *handshake-period*

undo authentication timer handshake-period

Parameters

Parameter	Description	Value
<i>handshake-period</i>	Specifies the handshake interval.	The value is an integer that ranges from 5 to 7200, in seconds.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After enabling the handshake with pre-connection users and authorized users using the **13.4.13 authentication handshake** command, you can run this command to set the handshake interval. After that, if a user does not respond to the handshake request from the device within the handshake interval, the device deletes the user entry.

Precautions

- This command only applies to MAC address authentication, Layer 3 Portal authentication, and 802.1X authentication.
- For Layer 3 Portal authentication users, only those who go online through S5720HI support this function.
- This function takes effect only for the wired users. For wired users who do not obtain IP addresses within 30 minutes, traffic detection will be performed (detection process can be seen as the following precautions). If traffic passes through the device, users are online. If no traffic passes through the device, users go offline.
- This function takes effect only for users who go online after this function is successfully configured.

- The handshake function is implemented using ARP probe packets or neighbor discovery (ND) probe packets.
- The handshake function can also be implemented by detecting whether there is user traffic on the access device. Assuming that the handshake interval is $3n$, the device will detect user traffic at n and $2n$. The following uses the $0-n$ period as an example. The process during the $n-2n$ period is similar to that during $0-n$. (This process applies only to authentication users who go online from the S5720EI, S5720HI, S6720EI, and S6720S-EI. Other switch models do not detect user traffic and send probe packets at n and $2n$.)
 - If user traffic passes the device during the $0-n$ period, the device considers that the user is online at n , so it will not send a probe packet to the user, but resets the handshake interval.
 - If no user traffic passes the device during the $0-n$ period, the device cannot determine whether the user is online at n , so it sends a probe packet to the user. If the device receives the reply packet from the user, it considers the user online and resets the handshake interval. If no reply packet is received, it considers the user offline.
 - If user traffic passes the device during the $2n-3n$ period, the device considers that the user is online at $3n$ and resets the handshake interval.
 - If no user traffic passes the device during the $2n-3n$ period, the device cannot determine whether the user is online at $3n$ and considers that the user is offline.

If the device considers that the user is offline at n , $2n$, and $3n$, the device deletes all entries related to the user. To prevent the user from going offline unexpectedly when no operation is performed on the PC, do not set a short handshake period.

- If the configured handshake interval is less than the default value, an IP address conflict may occur between terminal detection and device ARP probe. For example, a Windows client sends a detection packet with the source address 0.0.0.0 at an interval of 10 seconds after obtaining an IP address. If the device also initiates ARP probe with the source address 0.0.0.0, a conflict occurs.
- For the models that do not support implementing the handshake function by detecting whether there is user traffic on the access device, if the number of ARP probe packets exceeds the default CAR value, the probe fails and the users are logged out (The `display cpu-defend statistics` command can be run to check whether ARP request and response packets are lost.). To resolve the problem, the following methods are recommended:
 - Increase the handshake interval based on the number of users. The default handshake interval is recommended when there are less than 8000 users; the handshake interval should be no less than 600 seconds when there are more than 8000 users.
 - Deploy the port attack defense function on the access device and limit the rate of packets sent to the CPU.

Example

```
# In the authentication profile p1, set the handshake interval of the device with pre-connection users and authorized users to 200 seconds.
```



```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name p1  
[HUAWEI-authen-profile-p1] authentication timer handshake-period 200
```

13.4.31 authentication timer authen-fail-aging

Function

The **authentication timer authen-fail-aging** command configures the aging time for entries of the users who fail to be authenticated.

The **undo authentication timer authen-fail-aging** command restores the default aging time for entries of the users who fail to be authenticated.

By default, the aging time for entries of the users who fail to be authenticated is 23 hours.

Format

authentication timer authen-fail-aging *aging-time*

undo authentication timer authen-fail-aging

Parameters

Parameter	Description	Value
<i>aging-time</i>	Specifies the aging time.	The value is an integer that ranges from 0 or 60 to 4294860, in seconds. The value 0 indicates that the entry does not age.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After network access policies are configured for users who fail to be authenticated, the device creates entries for these users. If the user still fails to be authenticated when the user aging time expires, the user entry is deleted.

The entries of the users who fail to be authenticated share device resources with the entries of the users who are authenticated. If there are excess entries of the users who fail to be authenticated, other users fail to be authenticated. To solve this problem, run the **authentication timer authen-fail-aging** command to reduce the aging time for entries of the users who fail to be authenticated. In

In addition, if the time that the users who fail to be authenticated have network access policies should be shortened, you can run this command to decrease the aging time for the user entries.

Precautions

This function takes effect only for users who go online after this function is successfully configured.

Only wired users support this function.

Example

In the authentication profile **p1**, configure the aging time for entries of the users who fail to be authenticated to 3600 seconds.

```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name p1  
[HUAWEI-authen-profile-p1] authentication timer authen-fail-aging 3600
```

13.4.32 authentication timer pre-authen-aging

Function

The **authentication timer pre-authen-aging** command configures the aging time for pre-connection user entries.

The **undo authentication timer pre-authen-aging** command restores the default aging time for pre-connection user entries.

By default, the aging time for pre-connection user entries is 23 hours.

Format

authentication timer pre-authen-aging *aging-time*

undo authentication timer pre-authen-aging

Parameters

Parameter	Description	Value
<i>aging-time</i>	Specifies the aging time.	The value is an integer that ranges from 0 or 60 to 4294860, in seconds. The value 0 indicates that the entry does not age.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When a pre-connection is established between the device and a user, the device creates the pre-connection user entry. If the user still fails to be authenticated when the user aging time expires, the user entry is deleted.

The pre-connection user entries share device resources with the entries of the users who are authenticated. If there are excess pre-connection user entries, other users fail to be authenticated. To solve this problem, run the **authentication timer pre-authen-aging** command to reduce the aging time for the pre-connection user entries. In addition, if the time that the pre-connection users have network access policies should be extended, you can run this command to increase the aging time for the pre-connection user entries.

Precautions

This function takes effect only for users who go online after this function is successfully configured.

Only wired users support this function.

Example

In the authentication profile **p1**, configure the aging time for the pre-connection user entries to 3600 seconds.

```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name p1  
[HUAWEI-authen-profile-p1] authentication timer pre-authen-aging 3600
```

13.4.33 authentication timer re-authen

Function

The **authentication timer re-authen** command configures the interval for re-authenticating pre-connection users or users who fail to be authenticated.

The **undo authentication timer re-authen** command restores the default setting.

By default, pre-connection users and users who fail to be authenticated are re-authenticated at an interval of 60 seconds.

Format

```
authentication timer re-authen { pre-authen re-authen-time | authen-fail re-authen-time }
```

```
undo authentication timer re-authen { pre-authen | authen-fail }
```

Parameters

Parameter	Description	Value
pre-authen <i>re-authen-time</i>	Specifies the interval for re-authenticating pre-connection users.	The value is an integer that ranges from 0 or 30 to 7200, in seconds. The value 0 indicates that the re-authentication function is disabled for pre-connection users.
authen-fail <i>re-authen-time</i>	Specifies the interval for re-authenticating users who fail to be authenticated.	The value is an integer that ranges from 0 or 30 to 7200, in seconds. The value 0 indicates that the re-authentication function is disabled for users who fail to be authenticated.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device creates the mapping user entries when network access policies are assigned to users who are in the pre-connection phase or fail authentication. To enable users to pass authentication in real time, the device periodically re-authenticates the users who are in the pre-connection phase or fail authentication according to the user entries. The administrator can adjust the re-authentication interval based on the actual network requirements.

Precautions

This command only applies to 802.1X authentication and MAC address authentication.

This function takes effect only for users who go online after this function is successfully configured.

The device cannot re-authenticate wireless users who are in the pre-connection phase or fail authentication. Therefore, the **authentication timer re-authen** command does not apply to wireless users.

To reduce the impact on the device performance when many users exist, the user re-authentication interval may be longer than the configured re-authentication interval.

If a static user configured with 802.1X authentication enters the pre-connection status after failing the authentication, 802.1X authentication is then performed.

During the 802.1X authentication, the **pre-authen** *re-authen-time* timer does not take effect. If the 802.1X authentication also fails, the **pre-authen** *re-authen-time* timer takes effect, and re-authentication is triggered according to this timer.

Example

In the authentication profile **authen1**, set the interval for re-authenticating users who fail to be authenticated to 300 seconds.

```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name authen1  
[HUAWEI-authen-profile-authen1] authentication timer re-authen authen-fail 300
```

Related Topics

[13.4.61 display authentication-profile configuration](#)

13.4.34 authentication wlan-max-user

Function

The **authentication wlan-max-user** command configures the maximum number of authenticated users allowed on a VAP.

The **undo authentication wlan-max-user** command restores the default setting.

By default, a maximum of 128 authenticated users are allowed on a VAP.

NOTE

This function is supported only by S5720HI.

Format

authentication wlan-max-user *max-user-number*

undo authentication wlan-max-user

Parameters

Parameter	Description	Value
<i>max-user-number</i>	Specifies the maximum number of users.	The value is an integer that ranges from 1 to 128.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

To ensure high-quality network access services for online users in high-density wireless access scenarios, the administrator needs to limit the number of authenticated users to prevent excess access users from degrading user experience. The administrator can run the **authentication wlan-max-user** command to limit the number of access users allowed on a VAP of a single AP.

NOTE

This function takes effect only when the authentication profile is bound to the VAP profile.

Example

In the authentication profile **authen1**, set the maximum number of allowed authenticated users to 100 on a VAP.

```
<HUAWEI> system-view
[HUAWEI] authentication-profile name authen1
[HUAWEI-authen-profile-authen1] authentication wlan-max-user 100
```

13.4.35 authentication mode

Function

The **authentication mode** command configures the user access mode.

The **undo authentication mode** command restores the default user access mode.

By default, the user access mode is **multi-authen**.

Format

authentication mode { **single-terminal** | **single-voice-with-data** | **multi-share** | **multi-authen** [**max-user** *max-user-number* [**dot1x** | **mac-authen** | **portal**] *] }

undo authentication mode [**multi-authen** **max-user** [**dot1x** | **mac-authen** | **portal**] *]

Parameters

Parameter	Description	Value
single-terminal	Specifies the interface to allow only one user to go online.	-
single-voice-with-data	Specifies the interface to allow only one data user and one voice user to go online. This mode applies to the scenario in which a data user connects to a network through a voice terminal.	-

Parameter	Description	Value
multi-share	Specifies the interface to allow multiple users to go online. In this mode, the device only authenticates the first user. If the first user can be authenticated, the subsequent users share the same network access rights with the first user. If the first user goes offline, other users are also offline.	-
multi-authen	Specifies the interface to allow multiple users to go online. In this mode, the device authenticates each access user. If users can be authenticated, the users have their individual network access rights. If a user goes offline, other users are not affected.	-
max-user <i>max-user-number</i>	Specifies the maximum number of access users on the interface in multi-authen mode.	The value is an integer that depends on the device.
dot1x	Specifies the maximum number of 802.1X authentication users allowed to connect to the interface in multi-authen mode.	-
mac-authen	Specifies the maximum number of MAC address authentication users allowed to connect to the interface in multi-authen mode.	-
portal	Specifies the maximum number of Portal authentication users allowed to connect to the interface in multi-authen mode.	-

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After enabling NAC authentication, you can configure a user access mode based on the user access on the interface. The user access modes include:

- **single-terminal**: applies to the scenario in which only one data terminal is connected to the network through the interface.
- **single-voice-with-data**: applies to the scenario in which only one data terminal is connected to the network on the device interface through a voice terminal.
- **multi-share**: applies to the scenario that does not require high security and in which multiple data terminals are connected to the network on the device interface.
- **multi-authen**: applies to the scenario that requires high security and in which multiple data terminals are connected to the network on the device interface. In this access mode, you can configure the maximum number of access users based on the actual user quantity on the interface. This prevents malicious users from occupying a large amount of device resources and ensures that the users on other device interfaces can normally go online.

Precautions

- VLANIF interfaces do not support this function.
- Only wired users support this function.
- If the **multi-share** mode is configured on an Eth-Trunk of the S5720HI, the upstream rate limit cannot be delivered to users who go online through this Eth-Trunk.
- If the first access user fails to be authenticated on a physical interface and sets up a pre-connection after the **multi-share** mode is configured on the physical interface, new access users will also fail to be authenticated on the interface. Therefore, the following operations are recommended if the first access user may fail to be authenticated after the **multi-share** mode is configured on a physical interface.
 - Configure users to not set up pre-connections when 802.1X authentication or MAC address authentication is used. You can run the **undo authentication pre-authen-access enable** command to configure the device to not generate entries for users who obtain rights in the pre-connection phase.
 - Do not use the **multi-share** mode with Portal authentication.
- In the policy association scenario, the **authentication mode multi-authen max-user max-user-number** command configured on an access device does not take effect. To configure the number of access users on an access device, run the **authentication access-point max-user max-user-number** command to set the maximum number of access users allowed on the interface of the access device.
- When **authentication mode** is set to **multi-authen** in the authentication profile, set the interface type to hybrid or trunk in policy association scenarios or to hybrid in other scenarios when you configure the authorization VLAN.
- In L2 BNG scenarios, the **multi-share** mode is not supported.

Example

In the authentication profile **p1**, set the user access mode to **multi-authen**.

```
<HUAWEI> system-view
[HUAWEI] authentication-profile name p1
[HUAWEI-authen-profile-p1] authentication mode multi-authen
```


13.4.36 authentication single-access

Function

The **authentication single-access** command configures the device to allow users to access in only one authentication mode.

The **undo authentication single-access** command restores the default setting.

By default, the device allows users to access in different authentication modes.

Format

authentication single-access

undo authentication single-access

Parameters

None

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

After hybrid authentication is configured, the device by default allows users to access in different authentication modes. You can run the **authentication single-access** command to disable this default function. The device then allows users to access in only one authentication mode and does not process the packets of other authentication modes.

Example

In the authentication profile **authen1**, configure the device to allow users to access in only one authentication mode.

```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name authen1  
[HUAWEI-authen-profile-authen1] authentication single-access
```

13.4.37 authentication speed-limit auto

Function

The **authentication speed-limit auto** command enables the device to dynamically adjust the rate of packets from NAC users.

The **undo authentication speed-limit auto** command disables the device from dynamically adjusting the rate of packets from NAC users.

By default, the device does not dynamically adjust the rate of packets from NAC users.

Format

authentication speed-limit auto

undo authentication speed-limit auto

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When a lot of NAC users send authentication or log off requests to the device, the CPU usage may be overloaded especially when the CPU or memory usage is already high (for example, above 80%). After the device is enabled to dynamically adjust the rate of packets from NAC users, the device limits the number of NAC packets received per second if the CPU or memory usage is high. This function reduces loads on the device CPU.

Example

Enable the device to dynamically adjust the rate of packets from NAC users.

```
<HUAWEI> system-view  
[HUAWEI] authentication speed-limit auto
```

13.4.38 authentication unified-mode

Function

The **authentication unified-mode** command switches the NAC mode to unified mode.

The **undo authentication unified-mode** command switches the NAC mode to common mode.

By default, the unified NAC configuration mode is used.

Format

authentication unified-mode

undo authentication unified-mode

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Compared with the common mode, the unified mode uses the modular configuration, making the configuration clearer and configuration model easier to understand.

Considering advantages of the unified mode, you are advised to deploy NAC in unified mode. You can run the **authentication unified-mode** command to switch the NAC mode to unified mode.

Precautions

- Starting from V200R005C00, the default NAC mode changes from common mode to unified mode. Therefore, if the system software of a switch is upgraded from a version earlier than V200R005C00 to V200R005C00 or a later version, the switch automatically runs the **undo authentication unified-mode** command to configure the NAC mode to common mode.
- After the common mode and unified mode are switched, the device automatically restarts, causing service interruption.
- In V200R008C00, some NAC commands do not differentiate the common and unified modes. Their formats and views remain unchanged after being switched from one mode to the other. After devices are switched from the common mode in V200R008C00 or later versions to the unified mode in V200R009C00 or later versions, these NAC commands can be switched to the unified mode.
- In the unified mode, only the commands of the common mode are unavailable; in the common mode, only the commands of the unified mode are unavailable. In addition, after the configuration mode is switched, the commands supported by both the common mode and unified mode still take effect.

Example

```
# Switch the NAC mode to unified mode.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication unified-mode
```

13.4.39 authentication trigger-condition (802.1X authentication)

Function

The **authentication trigger-condition** command configures the packet types that can trigger 802.1X authentication.

The **undo authentication trigger-condition** command restores the default configuration.

By default, DHCP/ARP packets can trigger 802.1X authentication.

Format

authentication trigger-condition { dhcp | arp | any-l2-packet } *

undo authentication trigger-condition [dhcp | arp | any-l2-packet] *

Parameters

Parameter	Description	Value
dhcp	Triggers 802.1X authentication through DHCP packets.	-
arp	Triggers 802.1X authentication through ARP packets.	-
any-l2-packet	Triggers 802.1X authentication through any Layer 2 packets. For multicast packets, the corresponding protocol needs to be enabled, otherwise 802.1X authentication cannot be triggered.	-

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After 802.1X authentication is enabled, the device can trigger 802.1X authentication on users by default when receiving DHCP or ARP packets. Based on user information on the actual network, the administrator can adjust the packet types that can trigger 802.1X authentication. For example, if all users on a network dynamically obtain IPv4 addresses, the device can be configured to trigger 802.1X authentication only through DHCP packets. This prevents the device from continuously sending ARP packets to trigger 802.1X authentication when

static IPv4 addresses are configured for unauthorized users on the network, and reduces device CPU occupation.

If a static IPv4 address is configured for a client, 802.1X authentication cannot be triggered because they do not exchange DHCP or ARP packets. You can run the **authentication trigger-condition any-l2-packet** command to trigger 802.1X authentication through any Layer 2 packets. To prevent unauthorized users from occupying user entries on the device maliciously, you are advised to configure the function of triggering 802.1X authentication through any packets on the access device, and run the **authentication mode max-user** *max-user-number* command in the authentication profile view to configure the maximum number of access users allowed on an interface. The recommended value is 10.

Precautions

This function takes effect only for users who go online after this function is successfully configured.

To allow BPDUs to trigger 802.1X authentication, you must enable the function corresponding to the BPDUs globally. For example, to allow LLDPDUs to trigger 802.1X authentication, run the **16.3.20 lldp enable (system view)** command to enable LLDP globally.

When **any-l2-packet** is configured and 802.1X authentication is enabled on an interface, EAP packets sent from a client trigger 802.1X authentication first.

In a policy association scenario, MAC address authentication can only be triggered by EAP or DHCP or ARP packets.

When MAC address authentication and 802.1X authentication are both enabled on an interface, packets that can trigger authentication include all the packet types that can trigger authentication in the MAC access profile and 802.1X access profile. For example, assume that ARP packets in the MAC access profile are unable to trigger authentication and ARP packets in the 802.1X access profile can trigger authentication. If MAC address authentication and 802.1X authentication are both enabled on an interface, ARP packets can trigger MAC address authentication.

Example

In the 802.1X access profile **d1**, configure the device to use DHCP packets to trigger 802.1X authentication.

```
<HUAWEI> system-view  
[HUAWEI] dot1x-access-profile name d1  
[HUAWEI-dot1x-access-profile-d1] authentication trigger-condition dhcp
```

13.4.40 authentication trigger-condition (MAC address authentication)

Function

The **authentication trigger-condition** command configures the packet types that can trigger MAC address authentication.

The **undo authentication trigger-condition** command restores the default configuration.

By default, DHCP/ARP/DHCPv6/ND packets can trigger MAC address authentication.

Format

authentication trigger-condition { dhcp | arp | dhcpv6 | nd | any-l2-packet } *

undo authentication trigger-condition [dhcp | arp | dhcpv6 | nd | any-l2-packet] *

Parameters

Parameter	Description	Value
dhcp	Triggers MAC address authentication through DHCP packets.	-
arp	Triggers MAC address authentication through ARP packets.	-
dhcpv6	Triggers MAC address authentication through DHCPv6 packets.	-
nd	Triggers MAC address authentication through ND packets.	-
any-l2-packet	Triggers MAC address authentication through any Layer 2 packets. For multicast packets, the corresponding protocol needs to be enabled, otherwise MAC authentication cannot be triggered.	-

Views

MAC access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After MAC address authentication is enabled, the device can trigger MAC address authentication on users by default when receiving DHCP/ARP/DHCPv6/ND packets. Based on user information on the actual network, the administrator can adjust the packet types that can trigger MAC address authentication. For example, if all users on a network dynamically obtain IPv4 addresses, the device can be configured to trigger MAC address authentication only through DHCP packets. This prevents the device from continuously sending ARP packets to trigger MAC address authentication when static IPv4 addresses are configured for unauthorized users on the network, and reduces device CPU occupation.

If a static IPv4 address is configured for a client, MAC address authentication cannot be triggered because they do not exchange DHCP or ARP packets. You can run the **authentication trigger-condition any-l2-packet** command to trigger MAC address authentication through any Layer 2 packets. To prevent unauthorized users from occupying user entries on the device maliciously, you are advised to configure the function of triggering MAC address authentication through any packets on the access device, and run the **authentication mode max-user *max-user-number*** command in the authentication profile view to configure the maximum number of access users allowed on an interface. The recommended value is 10.

Precautions

- MAC address authentication configured on a VLANIF interface can only be triggered by ARP packets.
- This function takes effect only for users who go online after this function is successfully configured.
- There is a situation that you should notice. A device is configured to trigger MAC address authentication through DHCP packets and DHCP options are used as the user names for MAC address authentication (for the configuration of user names in MAC address authentication, see [13.4.134 mac-authen username](#)). If the authentication server delivers Huawei extended RADIUS attribute HW-Forwarding-VLAN (No. 26-161) to the device, the user packet must carry double VLAN tags and the outer VLAN ID cannot be the same as the ID of HW-Forwarding-VLAN; otherwise, the delivered attribute cannot take effect.
- Only wired users support MAC address authentication triggered by DHCP/ARP/DHCPv6/ND/any packets. For wireless users, MAC address authentication is triggered by association packets.
- After the **authentication trigger-condition { dhcp | dhcpv6 | nd } *** command is run, static users cannot go online.
- To allow BPDUs to trigger MAC address authentication, you must enable the function corresponding to the BPDUs globally. For example, to allow LLDPDUs to trigger MAC address authentication, run the [16.3.20 lldp enable \(system view\)](#) command to enable LLDP globally.
- In a policy association scenario, MAC address authentication can only be triggered by DHCP or ARP packets.
- When MAC address authentication is performed for IP phones and the voice VLAN service is deployed, if the **authentication trigger-condition any-l2-packet** command is run to configure the device to trigger MAC address authentication through any packets, you need to run the [13.4.22 authentication mac-move enable](#) command to configure MAC address migration and run the [13.4.23 authentication mac-move detect enable](#) command to configure the device to detect users' online status before MAC address migration.
- When **any-l2-packet** is configured and 802.1X authentication is enabled on an interface, EAP packets sent from a client trigger 802.1X authentication first.
- When MAC address authentication and 802.1X authentication are both enabled on an interface, packets that can trigger authentication include all the packet types that can trigger authentication in the MAC access profile and

802.1X access profile. For example, assume that ARP packets in the MAC access profile are unable to trigger authentication and ARP packets in the 802.1X access profile can trigger authentication. If MAC address authentication and 802.1X authentication are both enabled on an interface, ARP packets can trigger MAC address authentication.

Example

In the MAC access profile **m1**, configure the device to trigger MAC address authentication only through ARP packets.

```
<HUAWEI> system-view  
[HUAWEI] mac-access-profile name m1  
[HUAWEI-mac-access-profile-m1] authentication trigger-condition arp
```

13.4.41 authentication trigger-condition dhcp dhcp-option

Function

The **authentication trigger-condition dhcp dhcp-option** command enables the device to send DHCP option information to the authentication server when triggering MAC address authentication through DHCP packets.

The **undo authentication trigger-condition dhcp dhcp-option** command restores the default configuration.

By default, the device does not send DHCP option information to the authentication server when triggering MAC address authentication through DHCP packets.

Format

authentication trigger-condition dhcp dhcp-option *option-code*

undo authentication trigger-condition dhcp dhcp-option *option-code*

Parameters

Parameter	Description	Value
<i>option-code</i>	Specifies the option that the device sends to the authentication server.	The value is fixed as 82.

Views

MAC access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Option82 records information about DHCP user locations and services (voice and data services). After this command is run, if the device can trigger MAC address authentication through DHCP packets, it sends Option82 information to the authentication server when triggering MAC address authentication through DHCP packets. Based on the user information recorded in Option82, the authentication server then assigns different network access rights to users with different services in different locations. This implements accurate control on the network access rights of each user.

Precautions

- MAC address authentication users who go online through VLANIF interfaces do not support this function.
- This function takes effect only for users who go online after this function is successfully configured.
- Only wired users support MAC address authentication triggered by DHCP/ARP/DHCPv6/ND/any packets. For wireless users, MAC address authentication is triggered by association packets.

Example

In the MAC access profile **m1**, enable the device to send Option82 information to the authentication server when triggering MAC address authentication through DHCP packets.

```
<HUAWEI> system-view  
[HUAWEI] mac-access-profile name m1  
[HUAWEI-mac-access-profile-m1] authentication trigger-condition dhcp dhcp-option 82
```

13.4.42 authentication-profile (Interface view or VAP profile view)

Function

The **authentication-profile** command applies an authentication profile to the interface or VAP profile.

The **undo authentication-profile** command restores the default setting.

By default, no authentication profile is applied to the interface or VAP profile.

Format

authentication-profile *authentication-profile-name*

undo authentication-profile

Parameters

Parameter	Description	Value
<i>authentication-profile-name</i>	Specifies the name of an authentication profile.	The value must be an existing authentication profile name.

Views

Interface view, or VAP profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

An authentication profile uniformly manages NAC configuration. The authentication profile is bound to the interface or VAP profile view to enable NAC, implementing access control on the users in the interface or VAP profile. The authentication type of the users in the interface or VAP profile is determined by the access profile bound to the authentication profile.

Prerequisites

An authentication profile has been created using the [13.4.43 authentication-profile \(system view\)](#) command in the system view.

Precautions

When configuring NAC, pay attention to the following points:

- VLANIF interfaces, Ethernet interfaces, GE interfaces, MultiGE interfaces, XGE interfaces, 40GE interfaces, Eth-Trunks, port groups, and VAP profiles support NAC. The support for NAC on different interfaces is as follows:
 - 802.1X authentication does not take effect on a VLANIF interface.
 - Layer 2 interfaces and VLANIF interfaces support MAC address authentication. (Only S5720EI, S1720X, S1720X-E, S5720HI, S5720S-SI, S5720SI, S5730S-EI, S5730SI, S6720LI, S6720S-LI, S6720S-SI, S6720SI, S6720EI, and S6720S-EI support configuration of MAC address authentication on VLANIF interfaces.)
 - The support for Portal authentication varies depending on different interfaces, routed main interfaces (Only S5720EI, S5720HI, S6720EI, and S6720S-EI) support only Layer 3 Portal authentication, Layer 2 interfaces support only Layer 2 Portal authentication, and VLANIF interfaces support both Layer 2 and Layer 3 Portal authentication.
 - The VLANIF interface corresponding to the super VLAN does not support Portal authentication.
- For the access of wireless users through APs, ensure that the APs can be authenticated (for example, adding the APs to static users) when NAC authentication is deployed for users. Otherwise, the wireless users cannot be authenticated.
- NAC authentication cannot be enabled both on a Layer 2 Ethernet interface and the VLANIF interface mapping the VLAN of the Ethernet interface. Otherwise, the users have no network access rights after connecting to the network. In wireless scenarios, NAC authentication cannot be enabled both in

VAP profiles and on VLANIF interfaces. In direct forwarding mode, NAC authentication configured on a VLANIF interface takes effect only when the device is connected in off-path mode.

- After enabling NAC on an interface, you cannot run the following commands on the interface. Similarly, after running the following commands on an interface, you cannot enable NAC on the interface.

Command	Function
mac-limit	Sets the maximum number of MAC addresses that can be learned by an interface.
mac-address learning disable	Disables MAC address learning on an interface.
port link-type dot1q-tunnel	Sets the link type of an interface to QinQ.
port vlan-mapping vlan map-vlan port vlan-mapping vlan inner-vlan	Configures VLAN mapping on an interface.
port vlan-stacking	Configures selective QinQ.
port-security enable	Enables interface security.
mac-vlan enable	Enables MAC address-based VLAN assignment on an interface.
ip-subnet-vlan enable	Enables IP subnet-based VLAN assignment on an interface.
user-bind ip sticky-mac NOTE This command conflicts with only 802.1X authentication and MAC address authentication.	Enables the device to generate snooping MAC entries.

- After the encapsulation mode of packets allowed to pass a Layer 2 sub-interface is set to default using the **18.1.18 encapsulation (Layer 2 sub-interface view)** command, NAC cannot be configured on the main interface of the Layer 2 sub-interface.

Example

Apply the authentication profile **m1** to VLANIF10.

```
<HUAWEI> system-view
[HUAWEI] authentication-profile name m1
[HUAWEI-authen-profile-m1] quit
[HUAWEI] interface vlanif 10
[HUAWEI-Vlanif10] authentication-profile m1
```

13.4.43 authentication-profile (system view)

Function

The **authentication-profile** command creates an authentication profile and displays the authentication profile view.

The **undo authentication-profile** command deletes the authentication profile.

By default, the device has six built-in authentication profiles:
default_authen_profile, dot1x_authen_profile, mac_authen_profile,
portal_authen_profile, dot1xmac_authen_profile, and multi_authen_profile.

Format

authentication-profile name *authentication-profile-name*

undo authentication-profile name *authentication-profile-name*

Parameters

Parameter	Description	Value
name <i>authentication-profile-name</i>	Specifies the name of an authentication profile.	The value is a string of 1-31 case-sensitive characters, which cannot be configured to - and --. It cannot contain spaces and the following symbols: / \ : * ? " < > @ ' %.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

NAC can implement access control on users. The device uses authentication profiles to uniformly manage NAC configuration so that users can easily configure NAC functions. The parameters (for example, the bound access profile and authentication type) in the authentication profile can be configured to provide various access control modes for different users. After the configuration is complete, the authentication profile is applied to the interface or VAP profile to enable NAC.

Follow-up Procedure

1. Configuring authentication profiles: Configure the access profile, and authorization information in the authentication profiles.
2. Applying authentication profiles: Run the [13.4.42 authentication-profile \(Interface view or VAP profile view\)](#) command to apply the authentication profiles to the interface or VAP profile.

Precautions

- The built-in authentication profile **default_authen_profile** and the compatibility profile converted after an upgrade are not counted in the configuration specification. The six built-in authentication profiles (default_authen_profile, dot1x_authen_profile, mac_authen_profile, portal_authen_profile, dot1xmac_authen_profile, and multi_authen_profile) can be modified and applied, but cannot be deleted.
- Before deleting an authentication profile, ensure that this profile is not bound to any interface or VAP profile. You can run the [13.4.61 display authentication-profile configuration](#) command to check whether the authentication profile is bound to an interface or VAP profile

Example

```
# Create the authentication profile named mac_authen_profile1.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name mac_authen_profile1
```

Related Topics

[13.4.110 dot1x-access-profile \(authentication profile view\)](#)

[13.4.124 mac-access-profile \(authentication profile view\)](#)

[13.4.170 portal-access-profile \(authentication profile view\)](#)

[13.4.61 display authentication-profile configuration](#)

13.4.44 authentication update-ip-accounting enable

Function

The **authentication update-ip-accounting enable** command enables a device to send accounting packets for address updating.

The **undo authentication update-ip-accounting enable** command disables a device from sending accounting packets for address updating.

By default, the device is enabled to send accounting packets for address updating.

Format

authentication update-ip-accounting enable

undo authentication update-ip-accounting enable

Parameters

None

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

By default, the device sends accounting packets for address updating to the accounting server. Some accounting servers may not require the accounting packets. In this case, resources on the device are occupied. You can run the **undo authentication update-ip-accounting enable** command to disable the device from sending accounting packets for address updating, saving resources on the device. After address updating are complete, the device sends accounting packets again and the accounting function is not affected.

- **update-info-accounting** indicates that accounting packets are immediately sent during address updating.
- If the terminal information (including the DHCP Option, UA, or LLDP information) is updated for the first time, the device immediately triggers real-time accounting. If the terminal information is not updated for the first time, the device only updates the user entry and reports the new terminal information through subsequent accounting messages.
- After the **undo authentication update-ip-accounting enable** command is configured, the device does not send the accounting packet immediately after obtaining the packet, and waits until the real-time accounting timer expires.

Example

Disable a device from sending accounting packets for address updating.

```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name test  
[HUAWEI-authen-profile-test] undo authentication update-ip-accounting enable
```

13.4.45 band-width share-mode

Function

The **band-width share-mode** command enable the bandwidth share mode.

The **undo band-width share-mode** command restores the default configuration.

By default, the bandwidth share mode is disabled.

NOTE

This command is only supported by the S5720HI.

Format

band-width share-mode

undo band-width share-mode

Parameters

None

Views

System view, AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

On a home network, all family members go online using the same account. To improve service experience of family members, you can enable the bandwidth share mode so that all members can share the bandwidth.

Precautions

- This function does not apply to users who are connected through the inter-card Eth-Trunk interface.
- If this command is run in the system view, it takes effect for all new online users who connected to the device. If this command is run in the AAA domain view, it takes effect only for new online users in the domain.
- If the local or remote RADIUS server does not assign CAR settings to the users who will go online and the online users, the share mode is invalid to the users.
- If the bandwidth share mode is enabled and different users use the same account for authentication, the users going online with no CAR settings assigned will not be affected when CAR settings are assigned to the users who go online later.

Example

Enable the bandwidth share mode in the system view.

```
<HUAWEI> system-view  
[HUAWEI] band-width share-mode
```

Enable the bandwidth share mode in the AAA domain view.

```
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] domain huawei  
[HUAWEI-aaa-domain-huawei] band-width share-mode
```

13.4.46 cut access-user ucl-group

Function

The **cut access-user ucl-group** command forces UCL group users offline.

 NOTE

This command is supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI.

Format

cut access-user ucl-group { *group-index* | **name** *group-name* }

Parameters

Parameter	Description	Value
<i>group-index</i>	Specifies the index of a UCL group.	The UCL group must exist.
name <i>group-name</i>	Specifies the name of a UCL group.	The UCL group must exist.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

After a user goes online, if you want to modify the user's network access rights or detect that the user is unauthorized, run this command to force the user offline.

Example

```
# Force UCL group users offline.  
  
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] cut access-user ucl-group name huawei
```

13.4.47 device-type

Function

The **device-type** command sets a terminal type identifier.

The **undo device-type** command deletes a terminal type identifier that has been set.

By default, no terminal type identifier exists in the system.

 NOTE

This function is supported only by S5720HI.

Format

device-type *device-name*

undo device-type

Parameters

Parameter	Description	Value
<i>device-name</i>	Specifies a terminal type identifier.	The value is a string of 1 to 31 case-sensitive characters without spaces. The value cannot be - or --, and cannot contain ?, ', ".

Views

Terminal type identification profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a terminal type identifier is configured in a terminal type identification profile, the terminal type can be identified in the profile. Assume that the terminal type identifier is set to **huawei**. If the MAC address, UA, or DHCP Option information that an AC receives from a terminal matches the identification rule configured in the terminal type profile, the terminal type is **huawei**. This helps administrators to perform access control and rights management for the terminal based on the identified terminal type.

Precautions

The **device-type** command is cyclic in nature, and only the latest configuration takes effect.

Example

In the terminal type identification profile **huawei**, configure the terminal type identifier **huawei_1**.

```
<HUAWEI> system-view  
[HUAWEI] device-profile profile-name huawei  
[HUAWEI-device-profile-huawei] device-type huawei_1
```

Related Topics

[13.4.62 display device-profile](#)

13.4.48 device-profile

Function

The **device-profile** command creates a terminal type identification profile and enters the terminal type identification profile view, or directly enters the view of a terminal type identification profile that has already been created.

The **undo device-profile** command deletes a terminal type identification profile that has been created.

By default, no terminal type identification profile is created.

NOTE

This function is only supported by the S5720HI and the function takes effect only for wireless access users.

The AP3010DN-AGN does not support terminal type identification.

Format

device-profile *profile-name* *profile-name*

undo device-profile { **all** | *profile-name* *profile-name* }

Parameters

Parameter	Description	Value
profile-name <i>profile-name</i>	Specifies the name of a terminal type identification profile.	The value is a string of 1 to 31 case-sensitive characters without characters including spaces and the following: / \ : * ? " < > @ ' % . The value cannot be - or --.
all	Deletes all terminal type identification profiles.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

With the development of Internet, many enterprises allow employees to wirelessly access the enterprise intranet using their own intelligent devices such as

cellphones, tablets, and laptops, which satisfies employees' pursuit of new technology and desire of being unique, and improves their efficiency as well. This is called Bring Your Own Device (BYOD). However, access to enterprise intranet through PCs may cause potential security risks, and traditional security technology based on user identity authentication and authorization can no longer guarantee network security. It is in such a background that the terminal type identification technology comes out. With this technology, the types of the devices that employees use to access the intranet can be identified, facilitating access control. During the implementation of BYOD, administrators can limit intranet access rights to specified types of mobile devices and perform authentication and authorization based on users, device types, access time, access points, and environment information about the devices.

A terminal type identification profile is configured with terminal types that can be identified by devices, and identification rules. With the configured identification rules, the types of devices using which employees access the intranet can be identified, helping administrators to control employees' access rights.

Example

```
# Create a terminal type identification profile named huawei.
```

```
<HUAWEI> system-view  
[HUAWEI] device-profile profile-name huawei
```

Related Topics

[13.4.62 display device-profile](#)

13.4.49 device-sensor dhcp option

Function

The **device-sensor dhcp option** command enables the DHCP-based terminal type awareness function.

The **undo device-sensor dhcp option** command disables the DHCP-based terminal type awareness function.

By default, the DHCP-based terminal type awareness function is disabled.

Format

device-sensor dhcp option *option-code* &<1-6>

undo device-sensor dhcp option *option-code* &<1-6>

Parameters

Parameter	Description	Value
<i>option-code</i>	<p>Specifies the DHCP option field that the device needs to resolve.</p> <p>The option fields in a DHCP packet carry the control information and parameters, for example, terminal type.</p>	The value is an integer that ranges from 1 to 254.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A device usually connects to many types of terminals. You may need to assign different network access rights or packet processing priorities to the terminals of different types. For example, the voice devices, such as IP phones, should be assigned a high packet processing priority because voice signals require low delay and jitter.

After the DHCP-based terminal type awareness function is enabled, the device can resolve the option fields that carry terminal type information in the received DHCP Request packets. The device then sends the option information to the RADIUS server through RADIUS accounting packets. Through the option information, the RADIUS server knows the terminal types and controls the network access rights and packet processing priorities of the terminals.

Precautions

- The command takes effect only when the authentication or accounting mode in the AAA scheme is RADIUS.
- To make this command take effect, you must run the [14.8.20 dhcp snooping enable](#) command on the interfaces or in VLANs.

Example

```
# Set the option fields to be resolved by the device to option 60.  
<HUAWEI> system-view  
[HUAWEI] device-sensor dhcp option 60
```

13.4.50 device-sensor lldp tlv

Function

The **device-sensor lldp tlv** command enables the LLDP-based terminal type awareness function.

The **undo device-sensor lldp tlv** command disables the LLDP-based terminal type awareness function.

By default, the LLDP-based terminal type awareness function is disabled.

Format

device-sensor lldp tlv *tlv-type* &<1-4>

undo device-sensor lldp tlv

Parameters

Parameter	Description	Value
<i>tlv-type</i>	Specifies the LLDP TLV type as the terminal type to be aware of the device.	The value is an integer that can be 1, 2, 5, 6, 7, 8, and 127. The values are as follows: <ul style="list-style-type: none">• 1: Chassis ID TLV, indicating the bridge MAC address of the device• 2: Port ID TLV, indicating the port identifying the LLD PDU sending end• 5: System Name TLV, indicating the device name• 6: System Description TLV, indicating the system description• 7: System Capabilities TLV, indicating the system capabilities• 8: Management Address TLV, indicating the management address• 127: Organization Specific TLV, indicating the user-defined organization information. You can run the lldp tlv-enable med-tlv command on the physical interface for user access to set this parameter.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A device usually connects to many types of terminals. You may need to assign different network access rights or packet processing priorities to the terminals of different types. For example, the voice devices, such as IP phones, should be assigned a high packet processing priority because voice signals require low delay and jitter.

Using the LLDP-based terminal type awareness function, the device parses the required TLV type containing terminal type information from the received LLDP packets. The device then sends the TLV type information to the RADIUS server through a RADIUS accounting packet. Through the TLV type information, the RADIUS server knows the terminal types and controls the network access rights and packet processing priorities of the terminals.

Precautions

- The command takes effect only when the authentication or accounting mode in the AAA scheme is RADIUS.
- The command takes effect only when the LLDP function is enabled on the device and the connected peer device.

Example

```
# Enable the terminal type awareness function based on LLDP TLV type 5.  
<HUAWEI> system-view  
[HUAWEI] device-sensor lldp tlv 5
```

Related Topics

[13.4.49 device-sensor dhcp option](#)

13.4.51 display aaa statistics access-type-authenreq

Function

The **display aaa statistics access-type-authenreq** command displays the number of requests for MAC, Portal, or 802.1X authentication.

Format

```
display aaa statistics access-type-authenreq
```

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

When users send authentication requests, the device collects statistics on the number of initiating MAC, Portal, or 802.1X authentications.

To view the number of requests for MAC, Portal, or 802.1X authentication, run the **display aaa statistics access-type-authenreq** command.

Example

Display the number of requests for MAC, Portal, or 802.1X authentication.

```
<HUAWEI> display aaa statistics access-type-authenreq
mac authentication request :2
portal authentication request :0
dot1x authentication request :0
```

Table 13-34 Description of the **display aaa statistics access-type-authenreq** command output

Item	Description
mac authentication request	Number of MAC authentication requests.
portal authentication request	Number of Portal authentication requests.
dot1x authentication request	Number of 802.1X authentication requests.

13.4.52 display access-context profile

Function

The **display access-context profile** command displays the configuration of a user context profile.

Format

```
display access-context profile [ name profile-name ]
```

Parameters

Parameter	Description	Value
name <i>profile-name</i>	Displays the configuration of the user context profile with a specified name. If name <i>profile-name</i> is not specified, all user context profiles configured on the device are displayed.	The value must be the name of an existing user context profile on the device.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring a user context profile, you can run this command to check whether the configuration is correct.

Example

Display all user context profiles configured on the device.

```
<HUAWEI> display access-context profile
```

```
-----
ID      Access-context profile name
-----
0       p1
1       aA
-----
Total 2, printed 2
```

Display the configuration of the user context profile **p1**.

```
<HUAWEI> display access-context profile name p1
```

```
Profile name      : p1
if-match vlan-id : 13 to 20
```

Table 13-35 Description of the **display access-context profile** command output

Item	Description
ID	Index of a user context profile.
Access-context profile name or Profile name	Name of a user context profile. To configure the parameter, run the 13.4.3 access-context profile name command.

Item	Description
if-match vlan-id	VLAN matching a user context profile. To configure the parameter, run the 13.4.120 if-match vlan-id command.

13.4.53 display access-author policy

Function

The **display access-author policy** command displays the configuration of a user authentication event authorization policy.

Format

display access-author policy [name *policy-name*]

Parameters

Parameter	Description	Value
name <i>policy-name</i>	Displays the configuration of the user authentication event authorization policy with a specified name. If name <i>policy-name</i> is not specified, all user authentication event authorization policies configured on the device are displayed.	The value must be the name of an existing user authentication event authorization policy on the device.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring a user authentication event authorization policy, you can run this command to check whether the configuration is correct.

Example

Display all user authentication event authorization policies configured on the device.

```
<HUAWEI> display access-author policy
```

ID	Access-author policy name
0	a1
1	a2
Total 2, printed 2	

Display the configuration of the user authentication event authorization policy **a1**.

```
<HUAWEI> display access-author policy name a1
Policy name          : a1
match access-context-profile p1 action authen-fail service-scheme s1
```

Table 13-36 Description of the **display access-author policy** command output

Item	Description
ID	Index of a user authentication event authorization policy.
Access-author policy name or Policy name	Name of a user authentication event authorization policy. To configure the parameter, run the 13.4.5 access-author policy name command.
match access-context-profile <i>profile-name</i> action authen-fail service-scheme <i>scheme-name</i>	User authorization information specified based on a user context profile. To configure the parameter, run the 13.4.135 match access-context-profile action command.

13.4.54 display access-user dot1x-identity statistics

Function

The **display access-user dot1x-identity statistics** command displays statistics about Identity packets for wireless 802.1X authentication on a switch.

NOTE

This function is supported only by S5720HI.

Format

display access-user dot1x-identity statistics

Parameters

None

Views

All views

Default Level

3: Management level

Usage Guidelines

You can run this command to view the statistics about Identity packets for wireless 802.1X authentication on a switch.

Example

Display statistics about Identity packets for wireless 802.1X authentication on the switch.

```
<HUAWEI> display access-user dot1x-identity statistics
-----
Receive(Packet)  Pass(Packet)  Drop(Packet)  Last-dropping-time
-----
0                0            0             -
-----
```

Table 13-37 Description of the **display access-user dot1x-identity statistics** command output

Item	Description
Receive(Packet)	Total number of Identity packets for wireless 802.1X authentication received by the switch.
Pass(Packet)	Number of Identity packets for wireless 802.1X authentication sent to and processed by the CPU of the switch.
Drop(Packet)	Number of Identity packets for wireless 802.1X authentication discarded by the switch.
Last-dropping-time	Latest time when the switch discarded Identity packets for wireless 802.1X authentication. If no packet loss record exists on the switch, this field displays -.

13.4.55 display access-user

Function

The **display access-user** command displays information about NAC access users.

Format

display access-user service-scheme *service-scheme*

display access-user access-type { **dot1x** | **mac-authen** | **portal** | **none** | **static** }

display access-user event { **pre-authen** | **authen-fail** | **client-no-response** | **authen-server-down** }

display access-user ucl-group { *group-index* | **name** *ucl-group-name* } [**detail**]
(This command is only supported by S5720EI, S5720HI, S6720EI, and S6720S-EI.)

display access-user option82 { **circuit-id** *text* | **remote-id** *text* }

Parameters

Parameter	Description	Value
service-scheme <i>service-scheme</i>	Displays information about users assigned with a specified service scheme.	The value must be the name of an existing service scheme.
access-type	Displays information about users using a specified authentication mode.	-
dot1x	Displays information about users who pass 802.1X authentication.	-
mac-authen	Displays information about users who pass MAC address authentication.	-
portal	Displays information about users who pass Portal authentication.	-
none	Displays information about users whose AAA scheme is non-authentication.	-
static	Displays static user information.	-
event	Displays information about users in a specified authentication phase.	-
pre-authen	Displays information about users in the pre-connection phase.	-

Parameter	Description	Value
authen-fail	Displays information about users who fail to be authenticated and are assigned network access policies when the authentication server sends authentication failure packets to the device.	-
client-no-response	Displays information about 802.1X authentication users who fail to be authenticated and are assigned network access policies when the 802.1X client does not respond.	-
authen-server-down	Displays information about users who fail to be authenticated due to the Down status of the authentication server and are assigned network access policies.	-
ucl-group	Displays information about users in a specified UCL group.	-
<i>group-index</i>	Specifies the index of a UCL group.	The value must be an existing UCL group index.
name <i>ucl-group-name</i>	Specifies the name of a UCL group.	The value must be an existing UCL group name.
detail	Displays detailed user information.	-
option82	Displays information about MAC address authentication users who use the Option 82 field as user names.	-
circuit-id <i>text</i>	Displays information about MAC address authentication users who specify the circuit ID as user names.	The value must be existing circuit-id information.

Parameter	Description	Value
remote-id <i>text</i>	Displays information about MAC address authentication users who specify the remote ID as user names.	The value must be existing remote-id information.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run this command to check information about online NAC users.

Example

Display information about users who are assigned the service scheme **huawei**.

```
<HUAWEI> display access-user service-scheme huawei
```

```
-----  
UserID Username      IP address   MAC          Status  
-----  
16018  zqm             10.12.12.254  78ac-c0c2-0175 Pre-authen  
-----  
Total: 1, printed: 1
```

Display information about users in the pre-connection phase.

```
<HUAWEI> display access-user event pre-authen
```

```
-----  
UserID Username      IP address   MAC          Status  
-----  
16018  zqm             10.12.12.254  78ac-c0c2-0175 Pre-authen  
-----  
Total: 1, printed: 1
```

NOTE

Only letters, digits, and special characters can be displayed for **username**.

When the value of **username** contains special characters or characters in other languages except English, the device displays dots (.) for these characters. If there are more than three such consecutive characters, three dots (.) are displayed. Here, the special characters are the ASCII codes smaller than 32 (space) or larger than 126 (~).

When the value of **username** is longer than 20 characters, the device displays up to three dots (.) for the characters following 19; that is, only 22 characters are displayed.

Table 13-38 Description of the **display access-user** command output

Item	Description
UserID	ID automatically allocated to an online user by the device.
Username	User name.
IP address	User IP address. When both IPv4 and IPv6 addresses exist, only the IPv4 address is recorded. When only IPv6 addresses exist, only the latest updated IPv6 address is recorded.
MAC	User MAC address.
Status	User status. <ul style="list-style-type: none"> • Open: For a wired user, the user goes online through the open function upon authentication failure. For wireless users, no authentication is performed. • Success: authentication is successful • Pre-authen: pre-authentication • Client-no-resp: the client does not respond • Fail-authorized: authorization upon authentication failure • Web-server-down: web server is Down • Aaa-server-down: AAA server is Down

13.4.56 display access-user-num

Function

The **display access-user-num** command displays the maximum number of concurrent users and the number of current online users on a virtual access point (VAP).

NOTE

This function is supported only by S5720HI.

Format

display access-user-num [**interface wlan-dbss** *wlan-dbss-interface-id*]

Parameters

Parameter	Description	Value
interface wlan-dbss wlan-dbss-interface-id	Displays the maximum number of concurrent users and the number of current online users on a VAP. If this parameter is not specified, the maximum number of concurrent users and the number of current online users on all VAPs are displayed.	The value is an existing WLAN-DBSS interface id.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring the maximum number of authenticated users allowed in a VAP profile, you can run the **display access-user-num** command to view the maximum number of concurrent users and the number of current online users.

Example

Display the maximum number of concurrent users and the number of current online users on all VAPs.

```
<HUAWEI> display access-user-num
2016-09-30 11:09:27.790
-----
Interface name      max-user-num      online-user-num
-----
Wlan-Dbss0          30                 10
Wlan-Dbss1          2                  0
-----
Total: 8, printed: 2
```

Table 13-39 Description of the **display access-user-num** command output

Item	Description
Interface name	WLAN-DBSS interface id.
max-user-num	Maximum number of concurrent users.
online-user-num	Number of current online users.
Total	Total number of interfaces.
printed	Number of printed entries.

13.4.57 display authentication mac-move configuration

Function

The **display authentication mac-move configuration** command displays the MAC address migration configuration.

Format

display authentication mac-move configuration

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display authentication mac-move configuration** command to view the MAC address migration configuration. The configuration includes the number of times that MAC address migration users are allowed to migrate their MAC addresses 60s before they enter the quiet state, the period that MAC address migration users stay in the quiet state, the interval at which a device detects users' online status before user MAC address migration, and the number of detections before user MAC address migration.

Example

Display the MAC address migration configuration.

```
<HUAWEI> display authentication mac-move configuration  
Mac-move vlan config:all  
Mac-move quiet times:1  
Mac-move quiet period(s):120  
Mac-move quiet log:ENABLE  
Mac-move quiet user alarm:ENABLE  
Mac-move quiet user alarm lower percentage(%):  
50  
Mac-move quiet user alarm upper percentage(%)  
:100  
Mac-move detect:DISABLE  
Mac-move detect retry-interval(s):3  
Mac-move detect retry-time:1
```

Table 13-40 Description of the **display authentication mac-move configuration** command output

Item	Description
Mac-move vlan config	<p>VLAN ID range in which MAC address migration is enabled.</p> <p>For details, see the 13.4.22 authentication mac-move enable command.</p>
Mac-move quiet times	<p>Number of times that MAC address migration users are allowed to migrate their MAC addresses 60s before they enter the quiet state.</p> <p>For details, see the 13.4.26 authentication mac-move quiet-times quiet-period command.</p>
Mac-move quiet period(s)	<p>Period that MAC address migration users stay in the quiet state.</p> <p>For details, see the 13.4.26 authentication mac-move quiet-times quiet-period command.</p>
Mac-move quiet log	<p>Whether a device is enabled to record logs about user quietness triggered by MAC address migration:</p> <ul style="list-style-type: none"> • ENABLE • DISABLE <p>For details, see the 13.4.25 authentication mac-move quiet-log enable command.</p>
Mac-move quiet user alarm	<p>Whether a device is enabled to send alarms about user quietness triggered by MAC address migration:</p> <ul style="list-style-type: none"> • ENABLE • DISABLE <p>For details, see the 13.4.27 authentication mac-move quiet-user-alarm enable command.</p>
Mac-move quiet user alarm lower percentage(%)	<p>Lower alarm threshold for the percentage of MAC address migration users in quiet state.</p> <p>For details, see the 13.4.28 authentication mac-move quiet-user-alarm percentage command.</p>

Item	Description
Mac-move quiet user alarm upper percentage(%)	Upper alarm threshold for the percentage of MAC address migration users in quiet state. For details, see the 13.4.28 authentication mac-move quiet-user-alarm percentage command.
Mac-move detect	Whether a device is enabled to detect users' online status before user MAC address migration: <ul style="list-style-type: none"> • ENABLE • DISABLE For details, see the 13.4.23 authentication mac-move detect enable command.
Mac-move detect retry-interval(s)	Interval at which a device detects users' online status before user MAC address migration. For details, see the 13.4.24 authentication mac-move detect retry-interval retry-time command.
Mac-move detect retry-time	Number of detections before user MAC address migration. For details, see the 13.4.24 authentication mac-move detect retry-interval retry-time command.

13.4.58 display authentication mac-move quiet-user

Function

The **display authentication mac-move quiet-user** command displays information about MAC address migration users in quiet state.

Format

display authentication mac-move quiet-user { all | mac-address *mac-address* }

Parameters

Parameter	Description	Value
all	Displays information about all MAC address migration users in quiet state.	-
mac-address <i>mac-address</i>	Displays information about MAC address migration users in quiet state with a specified MAC address.	The value is in the H-H-H format. An H contains 1 to 4 hexadecimal digits.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Run this command to view information about MAC address migration users in quiet state.

Example

Display information about all MAC address migration users in quiet state.

```
<HUAWEI> display authentication mac-move quiet-user all
Quiet MAC Information
-----
Quiet MAC                               Quiet Remain Time(Sec)
-----
0001-0002-0003                          143
-----
1 quiet MAC found, 1 printed.
```

Table 13-41 Description of the **display authentication mac-move quiet-user all** command output

Item	Description
Quiet MAC	MAC address of MAC address migration users in quiet state.
Quiet Remain Time(Sec)	Remaining quiet time of MAC address migration users in quiet state, in seconds.

13.4.59 display authentication interface

Function

The **display authentication interface** command displays the configuration of the NAC authentication mode on an interface.

Format

display authentication interface *interface-type interface-number*

Parameters

Parameter	Description	Value
<i>interface-type interface-number</i>	Displays the configuration of the NAC authentication mode on a specified interface. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring the NAC authentication mode, you can run this command to check the configuration.

Example

```
# Display the configuration of the NAC authentication mode on GE0/0/1.
<HUAWEI> display authentication interface gigabitethernet 0/0/1
Authentication profile: p1
Authentication access-point: Enable
Authentication access-point max-user: 10
Port authentication order:
    MAC
    DOT1X
    WEB
```

Table 13-42 Description of the **display authentication interface** command output

Item	Description
Authentication profile	Name of the authentication profile applied to the interface.
Authentication access-point	Whether the interface functions as an access control point. NOTE This field is displayed only on access devices used in policy association solutions.
Authentication access-point max-user	Maximum number of users who are allowed to log in through an access point NOTE This field is displayed only on access devices used in policy association solutions.
Port authentication order	Authentication mode configured in the authentication profile applied to the interface. Authentication modes include: <ul style="list-style-type: none"> • MAC: indicates the MAC address authentication mode. • DOT1X: indicates the 802.1X authentication mode. • WEB: indicates the Portal authentication mode. NOTE <ul style="list-style-type: none"> • On a standalone device, if MAC address bypass authentication is enabled in the authentication profile using the 13.4.16 authentication dot1x-mac-bypass command, DOT1X is displayed before MAC. If MAC address bypass authentication is disabled, MAC is displayed before DOT1X. • On an AS device in an SVF system or a policy association scenario, this item only indicates authentication modes configured in the authentication profile, and does not indicate the authentication sequence.

13.4.60 display authentication mode

Function

The **display authentication mode** command displays the current NAC configuration mode and the mode after restart.

Format

display authentication mode

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display authentication mode** command to view the current NAC configuration mode.

Example

```
# Display the current NAC configuration mode and the mode after restart.
<HUAWEI> display authentication mode
Current authentication mode is unified-mode
Next authentication mode is unified-mode
```

Table 13-43 Description of the **display authentication mode** command output

Item	Description
Current authentication mode is unified-mode	Current NAC configuration mode.
Next authentication mode is unified-mode	NAC configuration mode after the device restarts. Run the authentication unified-mode command to switch the NAC mode to unified mode. Run the undo authentication unified-mode command to switch the NAC mode to common mode.

13.4.61 display authentication-profile configuration

Function

The **display authentication-profile configuration** command displays the configuration of an authentication profile.

Format

```
display authentication-profile configuration [ name authentication-profile-name ]
```

Parameters

Parameter	Description	Value
name <i>authentication-profile-name</i>	Displays the configuration of a specified authentication profile. If name <i>authentication-profile-name</i> is not specified, the device displays all the authentication profiles configured on the device.	The value must be the name of an existing authentication profile.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring an authentication profile, you can run this command to check whether the configuration is correct.

NOTE

The built-in authentication profile **default_authen_profile** is not counted in the configuration specification. The name of the compatibility profile converted after an upgrade begins with the at sign (@) and the profile is also not counted in the configuration specification.

Example

Display all the authentication profiles configured on the device.

```
<HUAWEI> display authentication-profile configuration
```

```
-----  
ID      Auth-profile name  
-----  
0       default_authen_profile  
1       dot1x_authen_profile  
2       mac_authen_profile  
3       portal_authen_profile  
4       dot1xmac_authen_profile  
5       multi_authen_profile  
-----  
Total 6, printed 6
```


Table 13-44 Description of the **display authentication-profile configuration** command output

Item	Description
ID	Authentication profile ID.
Auth-profile name	Authentication profile name.

Display the configuration of the authentication profile **p1**.

<HUAWEI> **display authentication-profile configuration name p1**

```

Profile name                : p1
Dot1x access profile name   : -
Mac access profile name     : -
Portal access profile name  : testdel
Free rule template         : -
Force domain                : -
Dot1x force domain          : -
Mac-authen force domain     : -
Portal force domain         : -
Default domain              : 110
Dot1x default domain        : -
Mac-authen default domain   : -
Portal default domain       : -
Permit domain               : -
Authentication handshake    : Enable
Authentication handshake period : 300s
Auth-fail re-auth period    : 60s
Pre-auth Re-auth period     : 60s
Auth-fail aging time        : 82800s
Pre-auth aging time         : 82800s
Dot1x-mac-bypass            : Disable
Single-access                : Disable
Device-type authorize service-scheme : -
Authentication mode         : multi-authen
Authen-fail authorize service-scheme : -
Authen-server-down authorize service-scheme : -
Pre-authen authorize service-scheme : -
Security-name-delimiter     : -
Domain-name-delimiter       : -
Domain-location             : -
Domainname-parse-direction  : -
WLAN max user number        : 128
Bound vap profile           : -
SVF flag                     : Disable
Ip-static-user               : Disable
Roam-realtime-accounting     : Enable
Update-IP-realtime-accounting : Enable
Linkdown offline delay time : 10

```

Table 13-45 Description of the **display authentication-profile configuration name** command output

Item	Description
Profile name	Authentication profile name.

Item	Description
Dot1x access profile name	802.1X access profile bound to the authentication profile. To configure an 802.1X access profile, run the 13.4.110 dot1x-access-profile (authentication profile view) command.
Mac access profile name	MAC access profile bound to the authentication profile. To configure a MAC access profile, run the 13.4.124 mac-access-profile (authentication profile view) command.
Portal access profile name	Portal access profile bound to the authentication profile. To configure a Portal access profile, run the 13.4.170 portal-access-profile (authentication profile view) command.
Free rule template	Authentication-free rule profile bound to the authentication profile. To configure an authentication-free rule profile, run the 13.4.114 free-rule-template (authentication profile view) command.
Force domain	Forcible domain for users. To configure a forcible domain, run the 13.4.6 access-domain command.
Dot1x force domain	Forcible domain for 802.1X authentication users. To configure a forcible domain for 802.1X authentication users, run the 13.4.6 access-domain command.
Mac-authen force domain	Forcible domain for MAC address authentication users. To configure a forcible domain for MAC address authentication users, run the 13.4.6 access-domain command.
Portal force domain	Forcible domain for Portal authentication users. To configure a forcible domain for Portal authentication users, run the 13.4.6 access-domain command.
Default domain	Default domain for users. To configure a default domain for users, run the 13.4.6 access-domain command.

Item	Description
Dot1x default domain	<p>Default domain for 802.1X authentication users.</p> <p>To configure a default domain for 802.1X authentication users, run the 13.4.6 access-domain command.</p>
Mac-authen default domain	<p>Default domain for MAC address authentication users.</p> <p>To configure a default domain for MAC address authentication users, run the 13.4.6 access-domain command.</p>
Portal default domain	<p>Default domain for Portal authentication users.</p> <p>To configure a default domain for Portal authentication users, run the 13.4.6 access-domain command.</p>
Permit domain	<p>Permitted domain for users.</p> <p>To configure a permitted domain, run the 13.1.69 permit-domain command.</p>
Authentication handshake	<p>Whether the handshake function is enabled.</p> <ul style="list-style-type: none"> • Enable • Disable <p>To enable the handshake function, run the 13.4.13 authentication handshake command.</p>
Authentication handshake period	<p>Handshake interval.</p> <p>To configure the handshake interval, run the 13.4.30 authentication timer handshake-period command.</p>
Auth-fail re-auth period	<p>Interval for re-authenticating users who fail to be authenticated.</p> <p>To configure the interval, run the 13.4.33 authentication timer re-authen command.</p>
Pre-auth re-auth period	<p>Interval for re-authenticating pre-connection users.</p> <p>To configure the interval, run the 13.4.33 authentication timer re-authen command.</p>

Item	Description
Auth-fail aging Time	<p>Aging time for entries of the users who fail to be authenticated.</p> <p>To configure the aging time, run the 13.4.31 authentication timer authen-fail-aging command.</p>
Pre-auth aging Time	<p>Aging time for pre-connection user entries.</p> <p>To configure the aging time, run the 13.4.32 authentication timer pre-authen-aging command.</p>
Dot1x-mac-bypass	<p>Whether MAC address bypass authentication is enabled.</p> <ul style="list-style-type: none"> • Enable • Disable <p>To configure the function, run the 13.4.16 authentication dot1x-mac-bypass command.</p>
Single-access	<p>Whether the device allows users to access in only one authentication mode.</p> <p>To configure the function, run the 13.4.36 authentication single-access command.</p>
Device-type authorize service-scheme	<p>Name of the service scheme based on which the device assigns network access rights to voice terminals that are not authenticated.</p> <p>To configure the name, run the 13.4.15 authentication device-type voice authorize command.</p>
Authentication mode	<p>User access mode.</p> <p>To configure the mode, run the 13.4.35 authentication mode command.</p>
Authen-fail authorize service-scheme	<p>Name of the service scheme based on which the device assigns network access rights to users who fail to be authenticated.</p> <p>To configure the name, run the 13.4.17 authentication event action authorize command.</p>

Item	Description
Authen-server-down authorize service-scheme	<p>Name of the service scheme based on which the device assigns network access rights to users when the authentication server is Down.</p> <p>To configure the name, run the 13.4.17 authentication event action authorize command.</p>
Pre-authen authorize service-scheme	<p>Name of the service scheme based on which the device assigns network access rights to users who are in the pre-connection state.</p> <p>To configure the name, run the 13.4.17 authentication event action authorize command.</p>
Security-name-delimiter	<p>Security string delimiter.</p> <p>To configure the delimiter, run the 13.1.80 security-name-delimiter command.</p>
Domain-name-delimiter	<p>Domain name delimiter.</p> <p>To configure the delimiter, run the 13.1.50 domain-name-delimiter command.</p>
Domain-location	<p>Domain name location.</p> <p>To configure the location, run the 13.1.49 domain-location command.</p>
Domainname-parse-direction	<p>Domain name resolution direction.</p> <p>To configure the direction, run the 13.1.51 domainname-parse-direction command.</p>
WLAN max user number	<p>Maximum number of authenticated users allowed in a VAP profile.</p>
Bound vap profile	<p>VAP profile to which the authentication profile is bound.</p> <p>To configure the VAP profile, run the 13.4.42 authentication-profile (Interface view or VAP profile view) command.</p>
SVF flag	<p>The flag of SVF status.</p>
Ip-static-user	<p>Whether the function of identifying static users through IP addresses is enabled.</p> <ul style="list-style-type: none"> • Enable • Disable <p>To configure the function, run the 13.4.122 ip-static-user enable command.</p>

Item	Description
Roam-realtime-accounting	Whether a device is enabled to send accounting packets for roaming. <ul style="list-style-type: none"> • Enable • Disable
Update-IP-realtime-accounting	Whether a device is enabled to send accounting packets for address updating. <ul style="list-style-type: none"> • Enable • Disable To configure the function, run the 13.4.44 authentication update-ip-accounting enable command.
Linkdown offline delay time	User logout delay when an interface link is faulty. <p>To configure the delay, run the 13.4.123 link-down offline delay command.</p>

13.4.62 display device-profile

Function

The **display device-profile** command displays the configuration of a specified terminal type identification profile or all terminal type identification profiles.

NOTE

This function is supported only by S5720HI.

Format

display device-profile { **all** | **profile-name** *profile-name* }

Parameters

Parameter	Description	Value
all	Displays summary of all terminal type identification profiles.	-
profile-name <i>profile-name</i>	Displays detailed information about a specified terminal type identification profile.	The value must be the name of an existing terminal type identification profile.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring terminal type identification, you can run the **display device-profile** command to view the terminal type identification profile configuration, including the profile name, terminal type identifier, and ACL rule.

Example

Display summary of all terminal type identification profiles.

```
<HUAWEI> display device-profile all
-----
Name           Device type      Rule num
test           huawei           1
-----
Total count : 1
```

Display detailed information about the terminal type identification profile **test**.

```
<HUAWEI> display device-profile profile-name test
-----
Name       : test
Device type : huawei
State      : disabled
Rule       :
  rule 1 mac 0006-0045-0078 mask 12
Match      :
  if-match rule id 1
-----
```

Table 13-46 Description of the **display device-profile** command output

Item	Description
Name	Name of a terminal type identification profile. To set a terminal type identification profile name, run the 13.4.48 device-profile command.
Device type	Terminal type identifier. To set a terminal type identifier, run the 13.4.47 device-type command.
Rule num	Number of ACL rules.

Item	Description
State	<p>Whether to enable terminal type identification:</p> <ul style="list-style-type: none"> • enable: Terminal type identification is enabled. • disabled: Terminal type identification is disabled. <p>To enable terminal type identification, run the enable command.</p>
Rule	<p>Terminal identification rule.</p> <p>To set a terminal identification rule, run the rule command.</p>
Match	<p>Matching mode of terminal type identification rules.</p> <p>To set a matching mode of terminal type identification rules, run the 13.4.121 if-match command.</p>

13.4.63 display dot1x

Function

The **display dot1x** command displays 802.1X authentication information.

Format

display dot1x [**statistics**] [**interface** { *interface-type interface-number1* [**to** *interface-number2*] } &<1-10>]

Parameters

Parameter	Description	Value
statistics	<p>Displays statistics on 802.1X authentication.</p> <p>The statistics about 802.1X authentication is displayed only when this parameter is specified.</p>	-

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	<p>Displays 802.1X authentication information of a specified interface.</p> <ul style="list-style-type: none"> • <i>interface-type</i> specifies the interface type. • <i>interface-number</i> specifies the interface number. <p>If this parameter is not specified, 802.1X authentication information of all interfaces is displayed.</p>	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

You can run the **display dot1x** command to view configuration results of all configuration commands in 802.1X authentication and statistics about 802.1X packets.

The command output helps you to check whether the current 802.1X authentication configuration is correct and isolate faults accordingly.

Follow-up Procedure

The **display dot1x** command displays the statistics on 802.1X packets. You can locate the fault according to the packet statistics. When the fault is rectified, run the **reset dot1x statistics** command to clear the packet statistics. After a period of time, run the **display dot1x** command again to check the packet statistics. If no error packet is found, the fault is rectified.

Example

```
# Display 802.1X authentication information.
<HUAWEI> display dot1x
Max users: 1024
Current users: 0
Global default domain is huawei
Quiet function is Enabled
```

```

Mc-trigger port-up-send is Disabled
Parameter set:Quiet Period      600s Quiet-times      2
          Tx Period            30s Mac-By-Pass Delay  30s
dot1x URL: http://www.***.com.cn

GigabitEthernet0/0/3 status: UP 802.1x protocol is Enabled
Dot1x access profile is dot
Authentication mode is multi-authen
Authentication method is CHAP
Reauthentication is disabled
Dot1x retry times: 2
Authenticating users: 1
Maximum users: 1024
Current users: 0

Authentication Success: 1      Failure: 0
Enter Enquence      : 0
EAPOL Packets: TX   : 16      RX   : 8
Sent   EAPOL Request/Identity Packets   : 10
        EAPOL Request/Challenge Packets  : 1
        Multicast Trigger Packets        : 0
        EAPOL Success Packets            : 1
        EAPOL Failure Packets            : 4
Received EAPOL Start Packets            : 1
        EAPOL Logoff Packets             : 1
        EAPOL Response/Identity Packets  : 1
        EAPOL Response/Challenge Packets : 1
    
```

Display 802.1X statistics.

```

<HUAWEI> display dot1x statistics
Max users: 1024
Current users: 0
Global default domain is yx
Quiet function is Enabled
Mc-trigger port-up-send is Enabled
Parameter set:Quiet Period      600s Quiet-times      2
          Tx Period            30s Mac-By-Pass Delay  30s
dot1x URL: http://www.***.com.cn

GigabitEthernet0/0/1 status: DOWN 802.1x protocol is Enabled
Controlled User(s) amount to 0

Authentication Success: 0      Failure: 0
Enter Enquence      : 0
EAPOL Packets: TX   : 1      RX   : 0
Sent   EAPOL Request/Identity Packets   : 0
        EAPOL Request/Challenge Packets  : 0
        Multicast Trigger Packets        : 1
        EAPOL Success Packets            : 0
        EAPOL Failure Packets            : 0
Received EAPOL Start Packets            : 0
        EAPOL Logoff Packets             : 0
        EAPOL Response/Identity Packets  : 0
        EAPOL Response/Challenge Packets : 0
    
```

Table 13-47 Description of the **display dot1x** command output

Item	Description
Max users	Maximum number of global online users, the value varies according to device models.
Current users	Number of current online users.

Item	Description
Global default domain is	Global default authentication domain. To configure the global default authentication domain, run the 13.1.48 domain (system view) command.
Quiet function is	Whether the quiet function is enabled. <ul style="list-style-type: none"> • Enabled. • Disabled. To configure the quiet function, run the dot1x quiet-period command.
Mc-trigger port-up-send is	Whether the function of triggering 802.1X authentication through multicast packets immediately after an interface goes Up is enabled. <ul style="list-style-type: none"> • Enabled. • Disabled. To configure the function, run the dot1x mc-trigger port-up-send enable command.
Parameter set	Settings of 802.1X parameters: <ul style="list-style-type: none"> • Quiet Period: specifies the quiet period set by the quiet timer. To configure the quiet period, run the dot1x timer quiet-period command. • Quiet-times: specifies the maximum number of authentication failures before the device quiets a user. To configure the maximum value, run the dot1x quiet-times command. • Tx Period: specifies the interval for sending authentication requests. To configure the interval, run the dot1x timer tx-period command.
dot1x URL	Redirect-to URL for HTTP access of 802.1X users. To configure the redirect-to URL, run the dot1x url command.
<i>interface</i> status	Interface status: <ul style="list-style-type: none"> • UP: The interface is enabled. • DOWN: The interface is shut down.
802.1x protocol is	Whether 802.1X authentication is enabled on the interface. <ul style="list-style-type: none"> • Enabled. • Disabled.
Dot1x access profile is	802.1X access profile name. To configure the 802.1X access profile name, run the 13.4.111 dot1x-access-profile (system view) command.

Item	Description
Authentication mode is	User access mode. To configure the user access mode, run the 13.4.35 authentication mode command.
Authentication method is	Authentication mode of 802.1X users. To configure the authentication mode of 802.1X users, run the 13.4.91 dot1x authentication-method command.
Reauthentication is	Whether re-authentication is enabled for online 802.1X users. To configure the function, run the 13.4.101 dot1x reauthenticate command.
Dot1x retry times	Maximum number of attempts to send authentication requests to 802.1X users. To configure maximum number of attempts to send authentication requests to 802.1X users, run the 13.4.102 dot1x retry command.
Authenticating users	Number of users who are being authenticated.
Maximum users	Maximum number of online users on the interface. The value depends on device types.
Current users	Number of online users on the interface.
Authentication Success Failure	Number of successful and failed authentications. The statistics include statistics on online 802.1X users but not on the users using MAC address bypass authentication.
Enter Enqueue	Number of packets entering the queue.
EAPOL Packets: TX RX	Number of globally received and sent EAPOL packets.
EAPOL Request/ Identity Packets	Number of globally received and sent EAPOL Request/ Identity packets.
EAPOL Request/ Challenge Packets	Number of globally received and sent EAPOL Request/ Challenge packets.
Multicast Trigger Packets	Number of globally received and sent multicast packets that trigger authentication.
EAPOL Success Packets	Number of globally received and sent EAPOL Success packets.
EAPOL Failure Packets	Number of globally received and sent EAPOL Failure packets.

Item	Description
EAPOL Start Packets	Number of globally received and sent EAPOL Start packets.
EAPOL Logoff Packets	Number of globally received and sent EAPOL LogOff packets.
EAPOL Response/Identity Packets	Number of globally received and sent EAPOL Response/Identity packets.
EAPOL Response/Challenge Packets	Number of globally received and sent EAPOL Response/Challenge packets.
Controlled User(s) amount to	Number of users who pass authentication successfully.

13.4.64 display dot1x-access-profile configuration

Function

The **display dot1x-access-profile configuration** command displays the configuration of an 802.1X access profile.

Format

display dot1x-access-profile configuration [**name** *access-profile-name*]

Parameters

Parameter	Description	Value
name <i>access-profile-name</i>	Displays the configuration of an 802.1X access profile with a specified name. If name <i>access-profile-name</i> is not specified, the device displays all the 802.1X access profiles configured on the device. If name <i>access-profile-name</i> is specified, the device displays the configuration of a specified 802.1X access profile.	The value must be the name of an existing 802.1X access profile.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring an 802.1X access profile, you can run this command to check whether the configuration is correct.

NOTE

The name of the compatibility profile converted after an upgrade begins with the at sign (@) and the profile is not counted in the configuration specification.

Example

Display all the 802.1X access profiles configured on the device.

```
<HUAWEI> display dot1x-access-profile configuration
```

```
-----  
ID      Dot1x-Access-Profile Name  
-----  
0       dot1x_access_profile  
1       d1  
2       d2  
3       d3  
4       d4  
-----  
Total: 5 printed: 5.
```

Table 13-48 Description of the **display dot1x-access-profile configuration** command output

Item	Description
ID	802.1X access profile ID.
Dot1x-Access-Profile Name	802.1X access profile name.

Display the configuration of the 802.1X access profile **d1**.

```
<HUAWEI> display dot1x-access-profile configuration name d1
```

```
Profile Name      : d1  
Authentication method : EAP  
Port control      : authorized-force  
Re-authen        : Enable  
Client-no-response authorize : -  
Trigger condition : arp  
Unicast trigger   : Enable  
Trigger dhcp-bind : Enable  
Handshake         : Disable  
Handshake packet-type : request-identity  
Max retry value   : 2  
Reauthen Period   : 3600s  
Client Timeout    : 5s
```

```
Handshake Period      : 60s
Eth-trunk handshake period : 120s
Bound authentication profile : -
```

Table 13-49 Description of the **display dot1x-access-profile configuration name** command output

Item	Description
Profile Name	802.1X access profile name.
Authentication method	<p>Authentication mode of 802.1X users:</p> <ul style="list-style-type: none"> • CHAP • PAP • EAP <p>To configure the authentication mode, run the 13.4.91 dot1x authentication-method command.</p>
Port control	<p>802.1X authentication interface's authorization status:</p> <ul style="list-style-type: none"> • auto • authorized-force • unauthorized-force <p>To set an authorization state for an interface, run the 13.4.97 dot1x port-control command.</p>
Re-authen	<p>Whether re-authentication for online 802.1X users is enabled:</p> <ul style="list-style-type: none"> • Enable • Disable <p>To configure the re-authentication function, run the 13.4.101 dot1x reauthenticate command.</p>
Client-no-response authorize	<p>Network access rights granted to users when the 802.1X client does not respond.</p> <ul style="list-style-type: none"> • service-scheme: The name of a service scheme based on which network access rights are assigned. • ucl-group: The name of a UCL group based on which network access rights are assigned. • vlan: The VLAN based on which network access rights are assigned. <p>To configure the network access rights, run the 13.4.19 authentication event client-no-response action authorize command.</p>

Item	Description
Trigger condition	<p>Packet type that can trigger 802.1X authentication:</p> <ul style="list-style-type: none"> • dhcp • arp • any-l2-packet <p>To configure the packet type, run the 13.4.39 authentication trigger-condition (802.1X authentication) command.</p>
Unicast trigger	<p>Whether 802.1X authentication triggered by unicast packets is enabled:</p> <ul style="list-style-type: none"> • Enable • Disable <p>To configure the function, run the 13.4.108 dot1x unicast-trigger command.</p>
Trigger dhcp-bind	<p>Whether the device is enabled to automatically generate DHCP snooping binding entries for users with static IP addresses:</p> <ul style="list-style-type: none"> • Enable • Disable <p>To configure the function, run the 13.4.106 dot1x trigger dhcp-binding command.</p>
Handshake	<p>Whether handshake with online 802.1X authentication users is enabled:</p> <ul style="list-style-type: none"> • Enable • Disable <p>To configure the function, run the 13.4.93 dot1x handshake command.</p>
Handshake packet-type	<p>Type of 802.1X authentication handshake packets:</p> <ul style="list-style-type: none"> • request-identity • srp-sha1-part2 <p>To configure the type, run the 13.4.94 dot1x handshake packet-type command.</p>
Max retry value	<p>Maximum number of attempts to send authentication requests to 802.1X users.</p> <p>To configure the maximum value, run the 13.4.102 dot1x retry command.</p>

Item	Description
Reauthen Period	Re-authentication interval for online 802.1X users. To configure the re-authentication interval, run the 13.4.103 dot1x timer command.
Client Timeout	Authentication timeout period for 802.1X clients. To configure the authentication timeout period, run the 13.4.103 dot1x timer command.
Handshake Period	Interval at which the device handshakes with an 802.1X client on a non-Eth-Trunk interface. To configure the interval, run the 13.4.103 dot1x timer command.
Eth-trunk handshake period	Interval at which the device handshakes with an 802.1X client on an Eth-Trunk. To configure the interval, run the 13.4.103 dot1x timer command.
Bound authentication profile	Authentication profile to which the 802.1X access profile is bound. To configure the authentication profile, run the 13.4.110 dot1x-access-profile (authentication profile view) command.

13.4.65 display dot1x quiet-user

Function

The **display dot1x quiet-user** command displays information about 802.1X authentication users who are quieted.

Format

```
display dot1x quiet-user { all | mac-address mac-address }
```

Parameters

Parameter	Description	Value
all	Displays information about all 802.1X authentication users who are quieted.	-
mac-address <i>mac-address</i>	Displays information about a quiet 802.1X authentication user with a specified MAC address.	The value is in H-H-H format. Each H is a hexadecimal number of 1 to 4 digits.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run this command to view information about 802.1X authentication users who are quieted.

Example

Display information about all 802.1X authentication users who are quieted.

```
<HUAWEI> display dot1x quiet-user all
-----
MacAddress                Quiet Remain Time(Sec)
-----
0001-0002-0003           50
-----
1 silent mac address(es) found, 1 printed.
```

Table 13-50 Description of the **display dot1x quiet-user all** command output

Item	Description
MacAddress	MAC address of an 802.1X authentication user who is quieted.
Quiet Remain Time(Sec)	Remaining quiet time of an 802.1X authentication user who is quieted, in seconds.

13.4.66 display free-rule

Function

The **display free-rule** command displays whether an authentication-free rule defined by ACL is delivered.

Format

```
display free-rule
```

Parameters

None.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display free-rule** command to view the delivery status of an authentication-free rule defined by ACL.

Example

```
# Display whether an authentication-free rule defined by ACL is delivered.
```

```
<HUAWEI> display free-rule
```

```
-----  
Slot-ID          Acl-ID          Status  
-----  
0                6000           SUCCESS  
-----
```

```
Total 1 free-rule(s)
```

Table 13-51 Description of the **display free-rule** command output

Item	Description
Slot-ID	Slot ID.
Acl-ID	ACL number.
Status	Whether an authentication-free rule defined by ACL is successfully delivered to a slot.

13.4.67 display free-rule-template configuration

Function

The **display free-rule-template configuration** command displays the configuration of an authentication-free rule profile.

Format

display free-rule-template configuration [**name** *free-rule-name*]

Parameters

Parameter	Description	Value
name <i>free-rule-name</i>	Displays the configuration of an authentication-free rule profile with a specified name. If name <i>free-rule-name</i> is not specified, the device displays all the authentication-free rule profiles configured on the device. If name <i>free-rule-name</i> is specified, the device displays the configuration of a specified authentication-free rule profile.	The value must be the name of an existing authentication-free rule profile.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring an authentication-free rule profile, you can run this command to check whether the configuration is correct.

Example

Display all the authentication-free rule profiles configured on the device.

```
<HUAWEI> display free-rule-template configuration
```

ID	Free-rule-template Name
0	default_free_rule
Total: 1 printed: 1.	

Table 13-52 Description of the **display free-rule-template configuration** command output

Item	Description
ID	ID of an authentication-free rule profile.
Free-rule-template Name	Name of an authentication-free rule profile.

13.4.68 display mac-address authen

Function

The **display mac-address authen** command displays the current authen MAC address entries in the system.

Format

display mac-address authen [*interface-type interface-number* | **vlan** *vlan-id*] *
[**verbose**]

Parameters

Parameter	Description	Value
vlan <i>vlan-id</i>	Displays MAC address entries in a specified VLAN. If no VLAN is specified, MAC address entries in all VLANs of the device are displayed.	The value is an integer that ranges from 1 to 4094.
<i>interface-type interface-number</i>	Displays MAC address entries on a specified interface. If no interface is specified, MAC address entries on all interfaces of the device are displayed.	-
verbose	Displays detailed information about MAC address entries.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After MAC address authentication or 802.1X authentication is configured successfully, the administrator can run this command to check the existing **authen** MAC address entries on the device. The administrator can check information about user access based on these MAC address entries to locate user access faults. The **authen** entry is generated after a user passes MAC address authentication or 802.1X authentication.

Precautions

If there are a lot of **authen** MAC address entries, you can specify a VLAN or use a pipe operator (|) to filter the output information. Otherwise, the following problems may occur due to excessive output information:

- The displayed information is refreshed repeatedly on the terminal screen and the administrator cannot obtain the required information.
- The device traverses and retrieves information for a long time, and does not respond to any request.

Example

Display all **authen** MAC address entries in the system.

```
<HUAWEI> display mac-address authen
-----
MAC Address  VLAN/VSI/BD                Learned-From  Type
-----
0000-0000-0100 3000/-/                   GE0/0/1      authen
0000-0000-0400 3000/-/                   GE0/0/1      authen
0000-0000-0200 3000/-/                   GE0/0/1      authen
-----
Total items displayed = 3
```

Table 13-53 Description of the **display mac-address authen** command output

Item	Description
MAC Address	MAC address of a user to be authenticated.
VLAN/VSI/BD	VLAN/VSI/BD that the outbound interface belongs to.
Learned-From	Interface on which a MAC address is learned.
Type	Type of a MAC address entry.
Total items displayed	Total number of MAC address entries that match the filter condition.

13.4.69 display mac-address pre-authen

Function

The **display mac-address pre-authen** command displays the current pre-authen MAC address entries in the system.

Format

display mac-address pre-authen [*interface-type interface-number* | **vlan** *vlan-id*] * [**verbose**]

Parameters

Parameter	Description	Value
vlan <i>vlan-id</i>	Displays MAC address entries in a specified VLAN. If no VLAN is specified, MAC address entries in all VLANs of the device are displayed.	The value is an integer that ranges from 1 to 4094.
<i>interface-type interface-number</i>	Displays MAC address entries on a specified interface. If no interface is specified, MAC address entries on all interfaces of the device are displayed.	-
verbose	Displays detailed information about MAC address entries.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

You can run this command to check the existing MAC address entries of the pre-connection type to obtain access information about pre-connection users and locate faults.

Precautions

If there are a lot of pre-authen MAC address entries, you can specify a VLAN or use a pipe operator (|) to filter the output information. Otherwise, the following problems may occur due to excessive output information:

- The displayed information is refreshed repeatedly on the terminal screen and the administrator cannot obtain the required information.
- The device traverses and retrieves information for a long time, and does not respond to any request.

Example

Display all pre-authen MAC address entries in the system.

```
<HUAWEI> display mac-address pre-authen
-----
MAC Address  VLAN/VSI/BD          Learned-From  Type
-----
0000-0000-0100 3000/-/-          GE0/0/1      pre-authen
0000-0000-0400 3000/-/-          GE0/0/1      pre-authen
0000-0000-0200 3000/-/-          GE0/0/1      pre-authen
-----
Total items displayed = 3
```

Table 13-54 Description of the **display mac-address pre-authen** command output

Item	Description
MAC Address	MAC address of a user to be authenticated.
VLAN/VSI/BD	VLAN/VSI/BD that the interface belongs to.
Learned-From	Interface on which a MAC address of a user to be authenticated is learned.
Type	Type of a MAC address entry.
Total items displayed	Total number of MAC address entries that match the filter condition.

13.4.70 display mac-access-profile configuration

Function

The **display mac-access-profile configuration** command displays the configuration of a MAC access profile.

Format

display mac-access-profile configuration [name *access-profile-name*]

Parameters

Parameter	Description	Value
name <i>access-profile-name</i>	<p>Displays the configuration of a MAC access profile with a specified name.</p> <p>If name <i>access-profile-name</i> is not specified, the device displays all the MAC access profiles configured on the device.</p> <p>If name <i>access-profile-name</i> is specified, the device displays the configuration of a specified MAC access profile.</p>	The value must be the name of an existing MAC access profile.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring a MAC access profile, you can run this command to check whether the configuration is correct.

NOTE

The name of the compatibility profile converted after an upgrade begins with the at sign (@) and the profile is not counted in the configuration specification.

Example

Display all the MAC access profiles configured on the device.

```
<HUAWEI> display mac-access-profile configuration
```

```
-----
ID      Mac-Access-Profile Name
-----
0       mac_access_profile
1       m1
2       m2
3       m3
4       m4
-----
```

```
Total: 5 printed: 5.
```

Table 13-55 Description of the **display mac-access-profile configuration** command output

Item	Description
ID	MAC access profile ID.
Mac-Access-Profile Name	MAC access profile name.

Display the configuration of the MAC access profile **m1** (the MAC address authentication user configures a password).

```
<HUAWEI> display mac-access-profile configuration name m1
Profile Name           : m1
Username format        : fixed username: a1
Password type          : cipher
Re-authen              : Disable
Trigger condition      : arp dhcp nd dhcpv6
Offline dhcp-release   : Disable
Re-authen dhcp-renew   : Disable
Reauthen Period       : 1800s
Bound authentication profile : -
```

Display the configuration of the MAC access profile **m2** (the MAC address authentication user does not configure a password).

```
<HUAWEI> display mac-access-profile configuration name m2
Profile Name           : m2
Username format        : fixed username: a1
Password               : not configured
Re-authen              : Disable
Trigger condition      : arp dhcp nd dhcpv6
Offline dhcp-release   : Disable
Re-authen dhcp-renew   : Disable
Reauthen Period       : 1800s
Bound authentication profile : -
```

Table 13-56 Description of the **display mac-access-profile configuration name** command output

Item	Description
Profile Name	MAC access profile name.

Item	Description
Username format	<p>User name format for MAC address authentication.</p> <ul style="list-style-type: none"> ● use MAC address without-hyphen as username: A user name is a MAC address that does not contain hyphens (-), for example, 0005e01c02e3. ● use MAC address with-hyphen as username: A user name is a MAC address that contains hyphens (-) and the hyphens are inserted between every four digits, for example, 0005-e01c-02e3. ● use MAC address with-hyphen normal as username: A user name is a MAC address that contains hyphens (-) and the hyphens are inserted between every two digits, for example, 00-05-e0-1c-02-e3. ● use MAC address without-hyphen upper as username: A user name is a MAC address in the uppercase format that does not contain hyphens (-), for example, 0005E01C02E3. ● use MAC address with-hyphen upper as username: A user name is a MAC address in the uppercase format that contains hyphens (-) and the hyphens are inserted between every four digits, for example, 0005-E01C-02E3. ● use MAC address with-hyphen normal upper as username: A user name is a MAC address in the uppercase format that contains hyphens (-) and the hyphens are inserted between every two digits, for example, 00-05-E0-1C-02-E3. ● fixed username: The user name is fixed. ● use option82 as username: The content of the Option 82 field is used as the user name. ● not configured: The user name format is not configured. <p>To configure the user name format, run the 13.4.134 mac-authen username command.</p>

Item	Description
Password type	<p>Password display mode for MAC address authentication.</p> <ul style="list-style-type: none"> • cipher <p>To configure the password display mode, run the 13.4.134 mac-authen username command.</p>
password	<p>Password of the MAC address authentication user. This field has the following fixed value:</p> <ul style="list-style-type: none"> • not configured: indicates that the MAC address authentication user does not configure a password.
Re-authen	<p>Whether re-authentication for online MAC address authentication users is enabled:</p> <ul style="list-style-type: none"> • Enable: indicates that re-authentication is enabled. • Disable: indicates that re-authentication is disabled. <p>To configure the re-authentication function, run the 13.4.130 mac-authen reauthenticate command.</p>
Trigger condition	<p>Packet type that can trigger MAC address authentication.</p> <p>To configure the packet type, run the 13.4.40 authentication trigger-condition (MAC address authentication) command.</p>
Offline dhcp-release	<p>Whether the device is enabled to clear user entries when receiving DHCP release packets from MAC address authentication users.</p> <ul style="list-style-type: none"> • Enable • Disable <p>To configure the function, run the 13.4.126 mac-authen offline dhcp-release command.</p>

Item	Description
Re-authen dhcp-renew	Whether the device is enabled to re-authenticate MAC address authentication users when receiving DHCP lease renewal packets from the users. <ul style="list-style-type: none">• Enable• Disable To configure the function, run the 13.4.131 mac-authen reauthenticate dhcp-renew command.
Reauthen Period	Re-authentication interval for online MAC address authentication users. To configure the re-authentication interval, run the 13.4.133 mac-authen timer reauthenticate-period command.
Bound authentication profile	Authentication profile to which the MAC access profile is bound. To configure the authentication profile, run the 13.4.124 mac-access-profile (authentication profile view) command.

13.4.71 display mac-authen

Function

The **display mac-authen** command displays information about MAC address authentication.

Format

```
display mac-authen [ interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10> | configuration ]
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	<p>Displays MAC authentication information of a specified interface.</p> <ul style="list-style-type: none"> • <i>interface-type</i> specifies the interface type. • <i>interface-number</i> specifies the interface number. <p>If this parameter is not specified, MAC authentication information of all interfaces is displayed.</p>	-
configuration	Displays the global information about MAC address authentication.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

You can run the **display mac-authen** command to view configuration results of all configuration commands in MAC address authentication. The command output helps you to check whether the MAC address authentication configuration is correct and isolate faults accordingly.

Follow-up Procedure

You can locate the fault according to the packet statistics that is displayed using the **display mac-authen** command. When the fault is rectified, run the **reset mac-authen statistics** command to clear the packet statistics. After a period of time, run the **display mac-authen** command again to check the packet statistics. If no error packet is found, the fault is rectified.

Example

```
# Display the configuration of MAC address authentication.
```

```
<HUAWEI> display mac-authen
Quiet period is 60s
Authentication fail times before quiet is 1
Maximum users: 16384
Current users: 1
Global default domain is default

GigabitEthernet0/0/1 state: UP. MAC address authentication is enabled
MAC access profile is mac_access_profile
Reauthentication is disabled
Maximum users: 16384
Current users: 1
Username format: fixed username: gcs
Password type: cipher
Fixed password: %^%#2)*{%bMY.D*Kw3HxDgU3CW7g|54H&<]S,Zfu;%^%#
Authentication Success: 22, Failure: 85

Online user(s) info:
-----
Userld  MAC/VLAN          AccessTime      UserName
-----
37223  a088-b44d-573c/2003  2014/09/28 15:45:45  gcs
-----
Total: 1, printed: 1
```

Table 13-57 Description of the **display mac-authen** command output

Item	Description
Quiet period	Quiet period during which the device quiets a user who fails to be authenticated. The default value of the quiet timer is 60 seconds. To configure the quiet period, run the 13.4.132 mac-authen timer quiet-period command.
Authentication fail times before quiet	Maximum number of authentication failures before the device quiets a user. To configure the maximum value, run the 13.4.128 mac-authen quiet-times command.
Maximum users	Maximum number of users allowed on the device.
Current users	Number of online users, the value varies according to device models.
Global default domain	Global default authentication domain. To configure the global default authentication domain, run the 13.1.48 domain (system view) command.
<i>interface</i> state	Interface status: <ul style="list-style-type: none"> UP: The interface is enabled. DOWN: The interface is shut down.

Item	Description
MAC address authentication	Whether MAC address authentication is enabled on the interface. <ul style="list-style-type: none">• enabled• disabled
MAC access profile	MAC access profile name. To configure the MAC access profile name, run the 13.4.125 mac-access-profile (system view) command.
Reauthentication	Whether re-authentication for MAC address authentication users is enabled. <ul style="list-style-type: none">• enabled• disabled To configure whether re-authentication for MAC address authentication users is enabled, run the 13.4.130 mac-authen reauthenticate command.
Current users	Number of current online users on the interface.

Item	Description
Username format	<p>User name format for MAC address authentication.</p> <ul style="list-style-type: none">• use MAC address without-hyphen as username: A user name is a MAC address that does not contain hyphens (-), for example, 0005e01c02e3.• use MAC address with-hyphen as username: A user name is a MAC address that contains hyphens (-) and the hyphens are inserted between every four digits, for example, 0005-e01c-02e3.• use MAC address with-hyphen normal as username: A user name is a MAC address that contains hyphens (-) and the hyphens are inserted between every two digits, for example, 00-05-e0-1c-02-e3.• use MAC address without-hyphen upper as username: A user name is a MAC address in the uppercase format that does not contain hyphens (-), for example, 0005E01C02E3.• use MAC address with-hyphen upper as username: A user name is a MAC address in the uppercase format that contains hyphens (-) and the hyphens are inserted between every four digits, for example, 0005-E01C-02E3.• use MAC address with-hyphen normal upper as username: A user name is a MAC address in the uppercase format that contains hyphens (-) and the hyphens are inserted between every two digits, for example, 00-05-E0-1C-02-E3.• fixed username: The user name is fixed.• use option82 as username: The content of the Option 82 field is used as the user name.• not configured: The user name format is not configured. <p>To configure the user name format for MAC address authentication, run the</p>

Item	Description
	13.4.134 mac-authen username command.
Password type	Password display mode for MAC address authentication. <ul style="list-style-type: none"> • cipher To configure the password display mode for MAC address authentication, run the 13.4.134 mac-authen username command.
Fixed password	Password for MAC address authentication. <p>To configure the password for MAC address authentication, run the 13.4.134 mac-authen username command.</p>
Authentication Success: <i>m</i> , Failure: <i>n</i>	Numbers of successful authentications (<i>m</i>) and failed authentications (<i>n</i>) on the interface.
Online user(s) info	Online user information. <ul style="list-style-type: none"> • UserId: ID of an online user. • MAC/VLAN: MAC address and VLAN of an online user. • AccessTime: access time of an online user. • UserName: name of an online user. • Total: total number of online users. • printed: number of displayed online users.

13.4.72 display mac-authen quiet-user

Function

The **display mac-authen quiet-user** command displays information about MAC address authentication users who are quieted.

Format

```
display mac-authen quiet-user { all | mac-address mac-address }
```

Parameters

Parameter	Description	Value
all	Displays information about all MAC address authentication users who are quieted.	-
mac-address <i>mac-address</i>	Displays information about a specified MAC address authentication user who is quieted.	The value is in the H-H-H format. Each H is a hexadecimal number of 1 to 4 digits.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run this command to view information about MAC address authentication users who are quieted.

Example

Display information about all MAC address authentication users who are quieted.

```
<HUAWEI> display mac-authen quiet-user all
-----
MacAddress                Quiet Remain Time(Sec)
-----
0001-0002-0003           50
-----
1 silent mac address(es) found, 1 printed.
```

Table 13-58 Description of the **display mac-authen quiet-user all** command output

Item	Description
MacAddress	MAC address of a MAC address authentication user who is quieted.
Quiet Remain Time(Sec)	Remaining quiet time of a MAC address authentication user who is quieted, in seconds.

13.4.73 display portal

Function

The **display portal** command displays the Portal authentication configuration.

Format

display portal [**interface** *interface-type interface-number* | **configuration**]

Parameters

Parameter	Description	Value
interface <i>interface-type interface-number</i>	Displays Portal authentication information of a specified interface. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number. If this parameter is not specified, Portal authentication information of all interfaces is displayed.	-
configuration	Displays the global Portal authentication information.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display portal** command to view the Portal authentication configuration and check whether the configuration is correct.

Example

```
# Display the Portal authentication configuration.
```

```
<HUAWEI> display portal
Portal max-user number:16384
Quiet function is Enabled
Different-server is Enabled
Parameter set:Quiet Period      60s Quiet-times      3
Logout packets resend: Resend-times 3 Timeout 5s
Portal Https Redirect: Enable

Vlanif10 protocol status: down, web-auth-server layer2(direct)
```

Table 13-59 Description of the **display portal** command output

Item	Description
Portal max-user number	<p>Maximum number of concurrent Portal authentication users allowed to access the device, the value varies according to device models.</p> <p>To set the maximum number of concurrent Portal authentication users allowed to access the device, run the 13.4.162 portal max-user command.</p>
Quiet function is Enabled or Quiet function is Disabled	<p>Whether the quiet function in Portal authentication is enabled:</p> <ul style="list-style-type: none"> ● Enabled ● Disabled <p>To enable the quiet function, run the 13.4.163 portal quiet-period command.</p>
Different-server is Enabled or Different-server is Disabled	<p>Whether a device is enabled to process user logout requests sent by a Portal server other than the one from which users log in:</p> <ul style="list-style-type: none"> ● Enabled ● Disabled <p>To configure a device to process user logout requests sent by a Portal server other than the one from which users log in, run the 13.4.160 portal logout different-server enable command.</p>

Item	Description
Parameter set	<p>Parameter settings of the quiet function in Portal authentication.</p> <ul style="list-style-type: none"> • Quiet Period: indicates the quiet period in Portal authentication. To set the quiet period in Portal authentication, run the 13.4.165 portal timer quiet-period command. • Quiet-times: indicates the maximum number of authentication failures within 60 seconds before a Portal authentication user enters the quiet state. To set the maximum number of authentication failures, run the 13.4.164 portal quiet-times command.
Logout packets resend	<p>Configuration of the logout packet re-transmission function for Portal authentication users.</p> <ul style="list-style-type: none"> • Resend-times: indicates the number of re-transmission times for Portal authentication user logout packets. • Timeout: indicates the re-transmission interval of Portal authentication user logout packets. <p>To set the re-transmission interval, run the 13.4.161 portal logout resend timeout command.</p>
Portal Https Redirect	<p>Whether HTTPS redirection of Portal authentication is enabled:</p> <ul style="list-style-type: none"> • Enable • Disable <p>To enable this function, run the 13.4.142 portal https-redirect enable command.</p>

Item	Description
<i>interface</i> protocol status	<p>Link layer protocol state of the interface and the enabled Portal authentication mode.</p> <ul style="list-style-type: none"> • up: indicates that the interface is running properly. • down: indicates that the interface is disabled. • web-auth-server layer3: indicates that the authentication mode is set to Layer 3 Portal authentication on a specified interface. • web-auth-server layer2(direct): indicates that the authentication mode is set to Layer 2 Portal authentication on a specified interface.

13.4.74 display portal local-server connect

Function

The **display portal local-server connect** command displays the connection status of users to be authenticated on a built-in Portal server.

Format

display portal local-server connect [**user-ip** *ip-address*]

Parameters

Parameter	Description	Value
user-ip <i>ip-address</i>	<p>Displays the connection entry of a user with a specified IP address on a built-in Portal server.</p> <p>The connection entries of all users on the built-in Portal server are displayed if this parameter is not specified.</p>	The value of <i>ip-address</i> is in dotted decimal notation.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display portal local-server connect** command to check the authentication mode and status of users to be authenticated on a built-in Portal server.

Example

Display the connection status of the user with the IP address 10.1.1.10 on a built-in Portal server.

```
<HUAWEI> display portal local-server connect user-ip 10.1.1.10
```

```
-----
CID IP Address  AuthMode  State   Session-timeout(hours)
-----
1   10.1.1.10   CHAP     ONLINE 8
-----
```

Table 13-60 Description of the **display portal local-server connect** command output

Item	Description
CID	User table index.
IP Address	IP address of a user.
AuthMode	<p>Authentication mode:</p> <ul style="list-style-type: none"> ● CHAP: The built-in Portal server uses CHAP to authenticate the user. ● PAP: The built-in Portal server uses PAP to authenticate the user. <p>To set the authentication method, run the 13.4.146 portal local-server authentication-method command.</p>
State	<p>User status:</p> <ul style="list-style-type: none"> ● WAIT_CHALLENGE: waiting for the challenge ● WAIT_AUTHACK: waiting for the authentication response ● ONLINE: online ● WAIT_LOGOUTACK: waiting for logout
Session-timeout(hours)	<p>The session timeout interval.</p> <p>To set the session timeout interval, run the 13.4.157 portal local-server timer session-timeout.</p>

13.4.75 display portal local-server

Function

The **display portal local-server** command displays the configurations of a built-in Portal server.

Format

display portal local-server

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring the built-in Portal authentication, run this command to view the configurations of a built-in Portal server.

Example

Display the configurations of a built-in Portal server.

```
<HUAWEI> display portal local-server
Portal local-server config:
server status          : disable
Heartbeat-check status : auto
Heartbeat-timeout value : 60(s)
server ip              : 10.1.1.1
authentication method  : chap
protocol               : -
https ssl-policy       : -
server port            : 0
session-timeout        : 8(h)
syslog-limit           : enable
syslog-limit period    : 300(s)
server pagename        : -
server page-text       : -
server policy-text     : -
server background-image : default-image0
server background-color : -
server logo            : -
server ad-image        : -
```

Table 13-61 Description of the **display portal local-server** command output

Item	Description
server status	<p>Status of a built-in Portal server. To enable the built-in Portal server function, run the portal local-server command.</p> <ul style="list-style-type: none"> • disable: Portal authentication is disabled. • enable: Portal authentication is enabled.
Heartbeat-check status	<p>Heartbeat detection status of the built-in Portal server. To set the heartbeat detection status, run the 13.4.151 portal local-server keep-alive command.</p> <ul style="list-style-type: none"> • disable: indicates that the heartbeat detection function is disabled. • enable: indicates the forcible detection mode. • auto: indicates the automatic detection mode.
Heartbeat-timeout value	<p>Heartbeat detection interval of the built-in Portal server. To set the heartbeat detection interval, run the 13.4.151 portal local-server keep-alive command.</p> <p>This parameter is unavailable when the value of Heartbeat-check status is disable.</p>
server ip	<p>IP address of a built-in Portal server. To set the server IP address, run the portal local-server ip command.</p>
authentication method	<p>Authentication method used by a built-in Portal server for web users. To set the authentication method, run the portal local-server authentication-method command.</p> <ul style="list-style-type: none"> • chap: CHAP-based authentication (CHAP stands for Challenge Handshake Authentication Protocol.) • pap: PAP-based authentication (PAP stands for Password Authentication Protocol.)

Item	Description
protocol	Protocol used for authentication information exchange between a built-in Portal server and users. To enable the built-in Portal server function, run the portal local-server command.
https ssl-policy	SSL policy used for authentication information exchange between a built-in Portal server and users. To enable the built-in Portal server function, run the portal local-server command.
server port	TCP port number used by HTTPS. To specify a TCP port number used by HTTPS, run the portal local-server command.
session-timeout	User session timeout interval configured on the built-in Portal server. To set the session timeout interval, run the portal local-server timer session-timeout command.
syslog-limit	<p>Status of the log suppression function for built-in Portal authentication users. To enable or disable the log suppression function, run the 13.4.158 portal local-server syslog-limit enable command.</p> <ul style="list-style-type: none"> • disable: indicates that the log suppression function is disabled for built-in Portal authentication users. • enable: indicates that the log suppression function is enabled for built-in Portal authentication users.
syslog-limit period	Log suppression duration for built-in Portal authentication users. To set the log suppression duration, run the 13.4.159 portal local-server syslog-limit period command.
server pagename	Name of the page file package loaded to the built-in Portal server. To set the package name, run the 13.4.152 portal local-server load command.
server page-text	Loaded use instruction page file of the built-in Portal server. To load a use instruction page file, run the 13.4.155 portal local-server page-text load command.

Item	Description
server policy-text	Disclaimer page loaded to the built-in Portal server. To load a disclaimer page, run the 13.4.156 portal local-server policy-text load command.
server background-image	Background image of the built-in Portal server login page. To set the background image, run the 13.4.148 portal local-server background-image load command.
server background-color	Background color of the built-in Portal server login page. To set the background color, run the 13.4.147 portal local-server background-color command.
server logo	Logo file of the built-in Portal server login page. To load a logo file, run the 13.4.153 portal local-server logo load command.
server ad-image	Advertisement image file of the built-in Portal server login page. To load an advertisement image file, run the 13.4.144 portal local-server ad-image load command.

13.4.76 display portal local-server page-information

Function

The **display portal local-server page-information** command displays the page files loaded to the memory of a built-in Portal server.

Format

display portal local-server page-information

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display portal local-server page-information** command to check the page files loaded to the memory of a built-in Portal server.

Example

Display the page files loaded to the memory of a built-in Portal server.

```
<HUAWEI> display portal local-server page-information
```

```
-----  
Number of backup pages:35  
Size of backup pages:94438 byte  
-----
```

```
Name:/logout_success.html  
Size:4042 byte  
Last-Modified-Time:2011-12-16 20:24:46  
-----
```

Table 13-62 Description of the **display portal local-server page-information** command output

Item	Description
Number of backup pages	Number of page files loaded.
Size of backup pages	Total size of the loaded page files.
Name	Name of a page file.
Size	Size of a page file.
Last-Modified-Time	Last modification time.

Related Topics

[13.4.152 portal local-server load](#)

13.4.77 display portal-access-profile configuration

Function

The **display portal-access-profile configuration** command displays the configuration of a Portal access profile.

Format

```
display portal-access-profile configuration [ name access-profile-name ]
```

Parameters

Parameter	Description	Value
name <i>access-profile-name</i>	Displays the configuration of a Portal access profile with a specified name. If name <i>access-profile-name</i> is not specified, the device displays all the Portal access profiles configured on the device. If name <i>access-profile-name</i> is specified, the device displays the configuration of a specified Portal access profile.	The value must be the name of an existing Portal access profile.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring a Portal access profile, you can run this command to check whether the configuration is correct.

NOTE

The name of the compatibility profile converted after an upgrade begins with the at sign (@) and the profile is not counted in the configuration specification.

Example

Display all the Portal access profiles configured on the device.

```
<HUAWEI> display portal-access-profile configuration
```

```
-----
ID      Portal-access-profile Name
-----
0       portal_access_profile
1       p1
2       p2
-----
```

```
Total: 3 printed: 3.
```

Table 13-63 Description of the **display portal-access-profile configuration** command output

Item	Description
ID	Portal access profile ID.
Portal-access-profile Name	Portal access profile name.

Display the configuration of the Portal access profile **p1**.

```
<HUAWEI> display portal-access-profile configuration name p1
Profile name          : p1
Portal timer offline-detect length: 300
Service-scheme name  : -
Ucl-group name       : -
Re-auth              : Disable
Network IP Num       : 1
Network IP List      : 10.1.1.0 255.255.255.0
Web-auth-server Name : abc
Layer                : Layer two portal
Local-server         : Disable
Local-server anonymous : Disable
Pushed URL for anonymous users : http://www.huawei.com
Bound authentication profile : p1
```

Table 13-64 Description of the **display portal-access-profile configuration name** command output

Item	Description
Profile name	Portal access profile name.
Portal timer offline-detect length	Offline detection interval for Portal authentication users. To configure the interval, run the 13.4.166 portal timer offline-detect command.
Service-scheme name	Name of the service scheme based on which the device assigns network access rights to users when the Portal server is Down. To configure the service scheme name, run the 13.4.20 authentication event portal-server-down action authorize command.
Ucl-group name	Name of the UCL group based on which the device assigns network access rights to users when the Portal server is Down. To configure the UCL group name, run the 13.4.20 authentication event portal-server-down action authorize command.

Item	Description
Re-auth	<p>Whether the device is enabled to re-authenticate users when the Portal server changes from Down to Up.</p> <ul style="list-style-type: none"> • Enable • Disable <p>To configure the function, run the 13.4.21 authentication event portal-server-up action re-authen command.</p>
Network IP Num	<p>Number of source IP address segments for Portal authentication.</p> <p>To configure the number, run the 13.4.139 portal auth-network command.</p>
Network IP List	<p>Source IP address segment for Portal authentication.</p> <p>To configure the source IP address segment, run the 13.4.139 portal auth-network command.</p>
Web-auth-server Name	<p>Portal server profile bound to the Portal access profile.</p> <p>To configure the Portal server profile, run the 13.4.209 web-auth-server (Portal access profile view) command.</p>
Layer	<p>Portal authentication mode.</p> <ul style="list-style-type: none"> • Layer two portal: Layer 2 authentication mode. • Layer three portal: Layer 3 authentication mode. <p>To configure the Portal authentication mode, run the 13.4.209 web-auth-server (Portal access profile view) command.</p>
Local-server	<p>Whether the built-in Portal server function is enabled.</p> <ul style="list-style-type: none"> • Enable • Disable <p>To configure the built-in Portal server function, run the 13.4.149 portal local-server enable command.</p>

Item	Description
Local-server anonymous	Whether the anonymous login function is enabled for users authenticated through the built-in Portal server. <ul style="list-style-type: none"> • Enable • Disable To configure the anonymous login function, run the 13.4.145 portal local-server anonymous command.
Pushed URL for anonymous users	Redirection URL specified during configuration of the anonymous login function for users authenticated through the built-in Portal server. <p>To configure the URL, run the 13.4.145 portal local-server anonymous command.</p>
Bound authentication profile	Authentication profile to which the portal access profile is bound. <p>To configure the authentication profile, run the 13.4.170 portal-access-profile (authentication profile view) command.</p>

13.4.78 display portal quiet-user

Function

The **display portal quiet-user** command displays information about Portal authentication users in quiet state.

Format

display portal quiet-user { **all** | **user-ip** *ip-address* | **server-ip** *ip-address* }

Parameters

Parameter	Description	Value
all	Displays information about all Portal authentication users in quiet state.	-
user-ip <i>ip-address</i>	Displays information about the quiet user with the specified IP address.	The value is in dotted decimal notation.

Parameter	Description	Value
server-ip <i>ip-address</i>	Displays information about all the users in quiet state authenticated by the Portal authentication server with a specified IP address.	The value is in dotted decimal notation.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After the quiet timer is enabled, you can run the **display portal quiet-user** command to view information about Portal authentication users in quiet state.

Example

Display information about all Portal authentication users in quiet state.

```
<HUAWEI> display portal quiet-user all
Quiet IP information
-----
Quiet ip                               Quiet Remain Time(Sec)
-----
192.168.1.1                             10
192.168.1.2                             20
-----
2 quiet IP found, 2 printed.
```

Display information about all the users in quiet state authenticated by the Portal authentication server with IP address 192.168.2.1.

```
<HUAWEI> display portal quiet-user server-ip 192.168.2.1
Quiet IP information
-----
Quiet ip                               Quiet Remain Time(Sec)
-----
192.168.1.3                             10
192.168.1.4                             20
-----
2 quiet IP found, 2 printed.
```

Display information about the user in quiet state at 192.168.1.1.

```
<HUAWEI> display portal quiet-user user-ip 192.168.1.1
Quiet remain second    100
```

Table 13-65 Description of the **display portal quiet-user** command output

Item	Description
Quiet IP information	Information about the user in quiet state.

Item	Description
Quiet ip	IP address of the user in quiet state.
Quiet Remain Time(Sec)	Remaining quiet time of the user in quiet state, in seconds.
Quiet remain second	Remaining quiet period of the user in quiet state.

13.4.79 display portal url-encode configuration

Function

The **display portal url-encode configuration** command displays the configuration of URL encoding and decoding.

Format

display portal url-encode configuration

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring URL encoding and decoding, you can run the **display portal url-encode configuration** command to check the configuration.

Example

Display the configuration of URL encoding and decoding.

```
<HUAWEI> display portal url-encode configuration  
Portal URL Encode : Disable
```

Table 13-66 Description of the **display portal url-encode configuration** command output

Item	Description
Portal URL Encode	<p>Whether URL encoding and decoding are enabled:</p> <ul style="list-style-type: none"> • Disable • Enable <p>To configure the function, run the 13.4.167 portal url-encode enable command.</p>

Related Topics

[13.4.167 portal url-encode enable](#)

13.4.80 display portal user-logout

Function

The **display portal user-logout** command displays temporary logout entries of Portal authentication users.

Format

display portal user-logout [**ip-address** *ip-address* [**vpn-instance** *vpn-instance-name*]]

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
ip-address <i>ip-address</i>	Displays temporary logout entries of the Portal authentication user with a specified IP address.	The value is in dotted decimal notation.
vpn-instance <i>vpn-instance-name</i>	Displays temporary logout entries of the Portal authentication user with a specified VPN instance.	The value must be an existing VPN instance name.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After a Portal authentication user goes offline, the device sends an offline request packet to the Portal server. If the device does not receive an ACK packet from the Portal server, it records a temporary logout entry of the user. You can run the **display portal user-logout** command to check temporary logout entries of Portal authentication users.

If the parameter **ip-address** *ip-address* [**vpn-instance** *vpn-instance-name*] is not specified, the temporary logout entries of all Portal authentication users are displayed.

Example

Display the temporary logout entries of all Portal authentication users.

```
<HUAWEI> display portal user-logout
```

```
-----  
UserIP      Vrf      Resend Times TableID  
-----  
192.168.111.100 1        3         0
```

```
-----  
Total: 1, printed: 1
```

Table 13-67 Description of the **display portal user-logout** command output

Item	Description
UserIP	IP address of the Portal authentication user.
Vrf	VPN instance that the Portal authentication user belongs to.
Resend Times	Number of logout packet re-transmission times. To set the number of logout packet re-transmission times, run the 13.4.161 portal logout resend timeout command.
TableID	Index of the temporary logout entry.
Total: <i>m</i> , printed: <i>n</i>	Total number of temporary logout entries and number of displayed entries.

13.4.81 display server-detect state

Function

The **display server-detect state** command displays the status of a Portal server.

Format

display server-detect state [**web-auth-server** *server-name*]

Parameters

Parameter	Description	Value
web-auth-server <i>server-name</i>	Displays information about the Portal server status configured in the specified Portal server profile. If this parameter is not specified, status of all Portal servers is displayed.	The Portal server profile name must exist.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

When an external Portal server is used for Portal authentication, you can run the **display server-detect state** command to check information about the Portal server status.

Example

Display information about the Portal server status configured in the Portal server profile **abc**.

```
<HUAWEI> display server-detect state web-auth-server abc
Web-auth-server : abc
Total-servers   : 4
Live-servers    : 1
Critical-num    : 0
Status          : Normal
Ip-address      Status
192.168.2.1    UP
192.168.2.2    DOWN
192.168.2.3    DOWN
192.168.2.4    DOWN
```

Table 13-68 Description of the **display server-detect state** command output

Item	Description
Web-auth-server	Name of the Portal server profile.
Total-servers	Number of Portal servers configured.
Live-servers	Number of Portal servers in Up state.
Critical-num	Minimum number of Portal servers in Up state. If the number of Portal servers is less than this value, enable the survival function in the corresponding Portal server profile view.
Status	<p>Status of the Portal server. The values are as follows:</p> <ul style="list-style-type: none"> • Normal: indicates that the Portal server is in normal state. When <i>Total-servers</i> in the command output is larger than <i>Critical-num</i>, <i>Status</i> is displayed as Normal. If the server-ip server-ip-address <1-10> command is not run in the Portal server template view to configure an IP address for the Portal server, <i>Status</i> is displayed as Normal. • Abnormal: indicates that the Portal server is in abnormal state. When <i>Total-servers</i> in the command output is less than or equal to <i>Critical-num</i>, <i>Status</i> is displayed as Abnormal.
Ip-address	IP address of the Portal server.
Status	<p>Whether the Portal server with the specified IP address is reachable. The values are as follows:</p> <ul style="list-style-type: none"> • UP: reachable • DOWN: unreachable

Related Topics

[13.4.181 server-ip \(Portal server profile view\)](#)

[13.4.180 server-detect](#)

13.4.82 display static-user

Function

The **display static-user** command displays static user information.

Format

display static-user [**domain-name** *domain-name* | **interface** *interface-type interface-number* | **ip-address** *start-ip-address* [*end-ip-address*] | **vpn-instance** *vpn-instance-name*] *

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
domain-name <i>domain-name</i>	Displays static user information in a specified domain.	The value must be an existing domain name on the device.
interface <i>interface-type interface-number</i>	Displays static user information on a specified interface. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-
ip-address <i>start-ip-address</i> [<i>end-ip-address</i>]	Displays static user information in a specified IP address range.	The value is in dotted decimal notation.
vpn-instance <i>vpn-instance-name</i>	Displays static user information in a specified VPN instance.	The value must be an existing VPN instance name on the device.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After a static user is configured, you can run the **display static-user** command to view the static user information.

Example

Display information about all static users configured.

```
<HUAWEI> display static-user
IP-address      Interface      MAC-address    VPN
-----
10.1.1.6        GE0/0/1       0001-0001-0001 -
10.1.1.7        GE0/0/1       0001-0001-0001 -
10.1.1.8        GE0/0/1       0001-0001-0001 -
10.1.1.10       -             0002-0002-0002 -
10.1.1.11       -             0002-0002-0002 -
10.1.1.12       -             0002-0002-0002 -
-----
Total item(s) number= 6, displayed number= 6

Ip-static-user enable status:
-----
Vlanif10 : success
-----
Total item(s) number= 1, displayed number= 1
```

Table 13-69 Description of the **display static-user** command output

Item	Description
IP-address	IP address of a static user.
Interface	Interface connected to a static user.
MAC-address	MAC address of a static user.
VPN	VPN instance to which a static user belongs.
Total item(s) number= <i>m</i> , displayed number= <i>n</i>	The total number of entries is <i>m</i> and the number of displayed entries is <i>n</i> .
Ip-static-user enable status	Whether the function of identifying static users through IP addresses is enabled. To configure the function, run the 13.4.122 ip-static-user enable command.
<i>if-n</i> : success	The function of identifying static users through IP addresses is enabled on interface <i>if-n</i> .

Related Topics

[13.4.185 static-user](#)

[13.4.187 static-user username format-include](#)

[13.4.186 static-user password](#)

13.4.83 display ucl-group all

Function

The **display ucl-group all** command displays information about all UCL groups that are created.

 **NOTE**

This command is supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI.

Format

display ucl-group all

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After creating UCL groups using the [13.4.195 ucl-group](#) command, you can run the **display ucl-group all** command to check information about the UCL groups.

Example

```
# Display information about all UCL groups.
<HUAWEI> display ucl-group all
ID      UCL group name
-----
10      huawei
-----
Total : 1
```

Table 13-70 Description of the **display ucl-group all** command output

Item	Description
ID	Index of a UCL group.
UCL group name	Name of a UCL group.

13.4.84 display ucl-group ip

Function

The **display ucl-group ip** command displays IP address information of static UCL groups.

 **NOTE**

This command is supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI.

Format

display ucl-group ip *ip-address* { *mask-length* | *ip-mask* }

display ucl-group ip { *group-index* | **name** *group-name* | **static** | **local-access-user** | **all** } [**verbose**]

Parameters

Parameter	Description	Value
<i>ip-address</i>	Displays information about the static UCL group with a specified IP address.	The value must be the IP address of an existing static UCL group.
<i>mask-length</i>	Specifies the mask length of the IP address.	The value must be the IP address mask length of an existing static UCL group.
<i>ip-mask</i>	Specifies the mask of the IP address.	The value must be the IP address mask of an existing static UCL group.
<i>group-index</i>	Displays information about the static UCL group with a specified index.	The value must be the index of an existing static UCL group.
name <i>group-name</i>	Displays information about the static UCL group with a specified name.	The value must be the name of an existing static UCL group.
static	Displays information about static UCL groups.	-
local-access-user	Displays information about dynamic UCL groups.	-

Parameter	Description	Value
all	Displays information about all static UCL groups.	-
verbose	Displays detailed information about the static UCL group.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can view UCL groups' IP addresses that are manually added (using the [13.4.194 ucl-group ip](#) command) and dynamically generated when users go online and are granted UCL groups. When a user goes online successfully, the device grants a UCL group to the user and adds the user's IP address (with a 32-bit mask) to the UCL group. When the user goes offline or the user's IP address changes, the device deletes the corresponding IP address from the UCL group.

Example

Display IP address information of all UCL groups.

```
<HUAWEI> display ucl-group ip all
S : static L : local-access-user
IP/Mask      ID  UCL group name      Type
-----
10.9.9.4/32  1  g1                   S
10.10.0.0/16 2  g2                   S
10.9.9.6/32  1  g1                   L
-----
Total : 3      Static : 2      Local-access-user : 1
```

Display detailed information about all static UCL groups.

```
<HUAWEI> display ucl-group ip static verbose
-----
IP/Mask      : 10.9.9.4/32
UCL group ID : 1
UCL group name : g1
Type         : static
Status on slot 0 : Success

IP/Mask      : 10.10.0.0/16
UCL group ID : 2
UCL group name : g2
Type         : static
Status on slot 0 : Success
-----
Total : 2      Static : 2      Local-access-user : 0
```

Display detailed information about all dynamic UCL groups.

```
<HUAWEI> display ucl-group ip local-access-user verbose
```

```
-----
IP/Mask       : 10.9.9.6/32
UCL group ID  : 1
UCL group name : g1
Type          : local-access-user
Status on slot 0 : Success
-----
```

```
Total : 1      Static : 0      Local-access-user : 1
```

Table 13-71 Description of the **display ucl-group ip** command output

Item	Description
IP/Mask	IP address and mask of a UCL group.
ID	Index of a UCL group.
UCL group ID	Index of a UCL group.
UCL group name	Name of a UCL group.
Type	UCL group types, including: <ul style="list-style-type: none"> • static: static UCL group • local-access-user: UCL group to which local users belong
Status on slot <i>n</i>	UCL group status on slot <i>n</i> .

13.4.85 display url-template

Function

The **display url-template** command displays information about URL templates.

Format

```
display url-template { all | name template-name }
```

Parameters

Parameter	Description	Value
all	Displays information about all configured URL templates.	-
name <i>template-name</i>	Displays information about the URL template with a specified name.	The value must be the name of an existing URL template.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After a URL template is configured, run the **display url-template** command to view information about the URL template.

Example

Display information about all configured URL templates.

```
<HUAWEI> display url-template all
```

Name	URL Number	Start Mark	Assignment Mark	Isolate Mark
huawei	0	?	=	&
huawei2	0	?	=	&
huawei3	0	?	=	&
Total 3				

Display information about the URL template **huawei**.

```
<HUAWEI> display url-template name huawei
```

```
Name : huawei
URL :
Start mark : ?
Assignment mark : =
Isolate mark : &

AC IP :
AC MAC :
AP IP :
AP MAC :
SSID :
User MAC :
Redirect URL :
User IP address :
Sysname :
Delimiter :
Format :
Login URL Key : logiurl
Login URL : http:\\huawei.com
```

Table 13-72 Description of the **display url-template** command output

Item	Description
Name	Name of a URL template.
URL Number	Number of URLs.
URL	URL of the Portal server. To configure this parameter, run the 13.4.196 url (URL template view) command.

Item	Description
Start mark/Start Mark	Start character in the URL. To configure this parameter, run the 13.4.137 parameter command.
Assignment mark/Assignment Mark	Assignment character in the URL. To configure this parameter, run the 13.4.137 parameter command.
Isolate mark/Isolate Mark	Delimiter between URLs. To configure this parameter, run the 13.4.137 parameter command.
AC IP	Name of ac-ip in the URL. To configure this parameter, run the 13.4.199 url-parameter command.
AC MAC	Name of ac-mac in the URL. To configure this parameter, run the 13.4.199 url-parameter command.
AP IP	Name of ap-ip in the URL. To configure this parameter, run the 13.4.199 url-parameter command.
AP MAC	Name of ap-mac in the URL. To configure this parameter, run the 13.4.199 url-parameter command.
SSID	Name of ssid in the URL. To configure this parameter, run the 13.4.199 url-parameter command.
User MAC	Name of user-mac in the URL. To configure this parameter, run the 13.4.199 url-parameter command.
Redirect URL	Name of redirect-url in the URL. To configure this parameter, run the 13.4.199 url-parameter command.
User IP address	Name of user-mac in the URL. To configure this parameter, run the 13.4.199 url-parameter command.
Sysname	Name of sysname in the URL. To configure this parameter, run the 13.4.199 url-parameter command.
Delimiter	Delimiter between MAC addresses in the URL. To configure this parameter, run the 13.4.198 url-parameter mac-address format command.

Item	Description
Format	Format of MAC addresses in the URL. To configure this parameter, run the 13.4.198 url-parameter mac-address format command.
Login URL Key	Identification keyword for the login URL sent to the Portal server during redirection. To configure this parameter, run the 13.4.199 url-parameter command.
Login URL	Device login URL. To configure this parameter, run the 13.4.199 url-parameter command.

13.4.86 display snmp-agent trap feature-name mid_aaa all

Function

The **display snmp-agent trap feature-name mid_aaa all** command displays the status of all traps on the AAA module.

Format

```
display snmp-agent trap feature-name mid_aaa all
```

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After enabling the trap function for the AAA module, you can run this command to check the status of all traps on the AAA module. To enable the trap function for the AAA module, run the [snmp-agent trap enable feature-name mid_aaa](#) command.

Prerequisites

The SNMP function has been enabled on the device. For details, see [snmp-agent](#).

Example

Display the status of all traps on the AAA module.

```
<HUAWEI> display snmp-agent trap feature-name mid_aaa all
-----
Feature name: MID_AAA
Trap number : 2
-----
Trap name           Default switch status  Current switch status
hwMacMovedQuietMaxUserAlarm  on                    on
hwMacMovedQuietUserClearAlarm on                    on
```

Table 13-73 Description of the **display snmp-agent trap feature-name mid_aaa all** command output

Item	Description
Feature name	Name of the module to which a trap belongs.
Trap number	Number of traps.
Trap name	Name of a trap. Traps on the AAA module include: <ul style="list-style-type: none"> hwMacMovedQuietMaxUserAlarm: A Huawei proprietary trap message is sent when the percentage of current MAC address migration users in quiet state against the maximum number of users exceeds the upper alarm threshold. hwMacMovedQuietUserClearAlarm: A Huawei proprietary trap message is sent when the percentage of current MAC address migration users in quiet state against the maximum number of users decreases to be equal to or smaller than the lower alarm threshold.
Default switch status	Default status of the trap function: <ul style="list-style-type: none"> on: The trap function is enabled by default. off: The trap function is disabled by default.
Current switch status	Trap status: <ul style="list-style-type: none"> on: The trap is enabled. off: The trap is disabled.

Related Topics

[13.4.188 snmp-agent trap enable feature-name mid_aaa](#)

13.4.87 display snmp-agent trap feature-name mid_eapol all

Function

The **display snmp-agent trap feature-name mid_eapol all** command displays the status of all traps on the DOT1X module.

Format

```
display snmp-agent trap feature-name mid_eapol all
```

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After enabling the trap function for the DOT1X module, you can run this command to check the status of all traps on the DOT1X module. To enable the trap function for the DOT1X module, run the [snmp-agent trap enable feature-name mid_eapol](#) command.

Prerequisites

The SNMP function has been enabled on the device. For details, see [snmp-agent](#).

Example

```
# Display the status of all traps on the DOT1X module.
```

```
<HUAWEI> display snmp-agent trap feature-name mid_eapol all
-----
Feature name: MID_EAPOL
Trap number : 2
-----
Trap name           Default switch status  Current switch status
hwSrvcfgEapMaxUserAlarm   on                    on
hwMacAuthenMaxUserAlarm   on                    on
```

Table 13-74 Description of the **display snmp-agent trap feature-name mid_eapol all** command output

Item	Description
Feature name	Name of the module to which a trap belongs.
Trap number	Number of traps.

Item	Description
Trap name	Name of a trap. Traps on the DOT1X module include: <ul style="list-style-type: none">• hwSrvcfgEapMaxUserAlarm: The device sends a Huawei proprietary trap when the number of 802.1X authentication users reaches the maximum number allowed on an interface.• hwMacAuthenMaxUserAlarm: The device sends a Huawei proprietary trap when the number of MAC address authentication users reaches the maximum number allowed on an interface.
Default switch status	Default status of the trap function: <ul style="list-style-type: none">• on: The trap function is enabled by default.• off: The trap function is disabled by default.
Current switch status	Trap status: <ul style="list-style-type: none">• on: The trap is enabled.• off: The trap is disabled.

Related Topics

[13.4.189 snmp-agent trap enable feature-name mid_eapol](#)

13.4.88 display snmp-agent trap feature-name mid_web all

Function

The **display snmp-agent trap feature-name mid_web all** command displays the status of all traps on the web authentication module.

Format

```
display snmp-agent trap feature-name mid_web all
```

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After enabling the trap function for the web authentication module, you can run this command to check the status of all traps on the web authentication module. To enable the trap function for the web authentication module, run the **snmp-agent trap enable feature-name mid_web** command.

Prerequisites

The SNMP function has been enabled on the device. For details, see [snmp-agent](#).

Example

Display the status of all traps on the web authentication module.

```
<HUAWEI> display snmp-agent trap feature-name mid_web all
```

```
-----  
Feature name: MID_WEB  
Trap number : 4  
-----
```

Trap name	Default switch status	Current switch status
hwPortalServerUp	on	on
hwPortalServerDown	on	on
hwPortalMaxUserAlarm	on	on
hwPortalUserClearAlarm	on	on

Table 13-75 Description of the **display snmp-agent trap feature-name mid_web all** command output

Item	Description
Feature name	Name of the module to which a trap belongs.
Trap number	Number of traps.
Trap name	Name of a trap. Traps on the web authentication module include: <ul style="list-style-type: none"> hwPortalServerUp: The device sends a Huawei proprietary trap when it detects that the Portal server changes from Down to Up. hwPortalServerDown: The device sends a Huawei proprietary trap when it detects that the Portal server changes from Up to Down. hwPortalMaxUserAlarm: The device sends a Huawei proprietary trap when the number of online Portal authentication users exceeds the upper threshold. hwPortalUserClearAlarm: The device sends a Huawei proprietary trap when the number of online Portal authentication users falls below the lower threshold.
Default switch status	Default status of the trap function: <ul style="list-style-type: none"> on: The trap function is enabled by default. off: The trap function is disabled by default.

Item	Description
Current switch status	Trap status: <ul style="list-style-type: none">• on: The trap is enabled.• off: The trap is disabled.

Related Topics

[13.4.190 snmp-agent trap enable feature-name mid_web](#)

13.4.89 display web-auth-server configuration

Function

The **display web-auth-server configuration** command displays the Portal server configuration.

Format

display web-auth-server configuration

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After the Portal server template is configured, the **display web-auth-server configuration** displays the Portal server configuration.

Example

Display the Portal server configuration.

```
<HUAWEI> display web-auth-server configuration
Listening port      : 2000
Portal              : version 1, version 2
Include reply message : enabled

-----
Enabled protocol    : https
Listening port      : 8443
SSL policy          : default_policy
-----
```

```

Web-auth-server Name : huawei
IP-address           :
Shared-key           :
Source-IP            : -
Port / PortFlag      : 50100 / NO
URL                  : https://192.168.2.10:8443/webauth
URL Template         :
URL Template ParaName:
URL Template IVName  :
URL Template Key     :
Redirection          : Enable
Sync                 : Disable
Sync Seconds         : 300
Sync Max-times       : 3
Detect               : Disable
Detect Seconds       : 60
Detect Max-times     : 3
Detect Critical-num  : 0
Detect Action        :
VPN Instance         :
Bound Portal profile :

Protocol             : http
Http Get-method      : disable
Password Encrypt     : none
Cmd ParseKey         : cmd
Username ParseKey    : username
Password ParseKey    : password
MAC Address ParseKey : macaddress
IP Address ParseKey  : ipaddress
Initial URL ParseKey : initurl
Login Cmd            : login
Logout Cmd           : logout
Login Success
  Reply Type         : redirect initial URL
  Redirect URL       :
  Message            : LoginSuccess!
Login Fail
  Reply Type         : redirect login URL
  Redirect URL       :
  Message            : LoginFail!
Logout Success
  Reply Type         : message
  Redirect URL       :
  Message            : LogoutSuccess!
Logout Fail
  Reply Type         : message
  Redirect URL       :
  Message            : LogoutFail!

```

1 Web authentication server(s) in total

Table 13-76 Description of the **display web-auth-server configuration** command output

Item	Description
Listening port	Listening port for Portal protocol packets. To configure a listening port, run the 13.4.208 web-auth-server listening-port command.

Item	Description
Portal	<p>Portal protocol version.</p> <ul style="list-style-type: none"> version 1, version 2: The device supports both the versions V1.0 and V2.0. version 2: The device supports the versions V2.0. <p>To configure the Portal protocol version, run the 13.4.212 web-auth-server version command.</p>
Include reply message	<p>Whether the packets sent from the device to the Portal server contain authentication responses.</p> <ul style="list-style-type: none"> enabled disabled <p>To enable the device to transparently transmit authentication responses of users sent by the authentication server to the Portal server, run the 13.4.210 web-auth-server reply-message command.</p>
Enabled protocol	<p>Enabled HTTP or HTTPS protocol.</p> <ul style="list-style-type: none"> http https <p>To enable the HTTP or HTTPS protocol, run the 13.4.169 portal web-auth-server command.</p>
Listening port	<p>HTTP or HTTPS port number.</p> <p>To configure the HTTP or HTTPS port number, run the 13.4.169 portal web-auth-server command.</p>
SSL policy	<p>SSL policy referenced by the HTTPS protocol.</p> <p>To configure the SSL policy referenced by the HTTPS protocol, run the 13.4.169 portal web-auth-server command.</p>
Web-auth-server Name	<p>Name of the Portal server template.</p> <p>To configure the Portal server template name, run the 13.4.211 web-auth-server (system view) command.</p>
IP-address	<p>IP address of the Portal server.</p> <p>To configure the IP address of the Portal server, run the 13.4.181 server-ip (Portal server profile view) command.</p>

Item	Description
Shared-key	<p>Shared key of the Portal server.</p> <p>To configure the shared key of the Portal server, run the 13.4.182 shared-key (Portal server profile view) command.</p>
Source-IP	<p>IP address used for communication with the Portal server.</p> <p>To configure the IP address used for communication with the Portal server, run the 13.4.183 source-ip (Portal server profile view) command.</p>
Port / PortFlag	<ul style="list-style-type: none"> ● Port: indicates the port number of the Portal server. ● PortFlag: indicates whether packets are always sent through this port. <p>To configure the port number of the Portal server, run the 13.4.138 port (Portal server profile view) command.</p>
URL	<p>URL of the Portal server.</p> <p>To configure the URL of the Portal server, run the 13.4.197 url (Portal server profile view) command.</p>
URL Template	<p>URL template bound to the Portal server template.</p> <p>To configure the URL template, run the 13.4.201 url-template (Portal server profile view) command.</p>
URL Template ParaName	<p>Encrypted URL parameter name.</p> <p>To configure the URL template, run the 13.4.201 url-template (Portal server profile view) command.</p>
URL Template IVName	<p>Initialization vector (IV) used in URL parameter encryption.</p> <p>To configure the URL template, run the 13.4.201 url-template (Portal server profile view) command.</p>
URL Template Key	<p>Key used in URL parameter encryption.</p> <p>To configure the URL template, run the 13.4.201 url-template (Portal server profile view) command.</p>

Item	Description
Redirection	<p>Redirection status of Portal authentication.</p> <ul style="list-style-type: none"> • Disable: Redirection of Portal authentication is disabled. • Enable: Redirection of Portal authentication is enabled. <p>To configure redirection of Portal authentication, run the 13.4.213 web-redirection disable (Portal server profile view) command.</p>
Sync	<p>User information synchronization.</p> <p>To enable user information synchronization, run the 13.4.202 user-sync command.</p>
Sync Seconds	<p>User information synchronization interval.</p> <p>To set the user information synchronization interval, run the 13.4.202 user-sync command.</p>
Sync Max-times	<p>Maximum number of times that user information synchronization fails.</p> <p>To set the maximum number of times that user information synchronization fails, run the 13.4.202 user-sync command.</p>
Detect	<p>Portal server detection function.</p> <p>To configure Portal server detection function, run the 13.4.180 server-detect command.</p>
Detect Seconds	<p>Detection interval of the Portal server.</p> <p>To set the detection interval of the Portal server, run the 13.4.180 server-detect command.</p>
Detect Max-times	<p>Maximum number of detection failures.</p> <p>To set the maximum number of detection failures, run the 13.4.180 server-detect command.</p>
Detect Critical-num	<p>Minimum number of Portal servers in Up state.</p> <p>To configure this function, run the 13.4.180 server-detect command.</p>

Item	Description
Detect Action	<p>Action taken after the number of detection failures exceeds the maximum.</p> <ul style="list-style-type: none"> ● log: The device sends logs after the number of detection failures exceeds the maximum. ● trap: The device sends traps after the number of detection failures exceeds the maximum. <p>To configure an action taken after the number of detection failures exceeds the maximum, run the 13.4.180 server-detect command.</p>
VPN Instance	<p>VPN instance used in Portal authentication.</p> <p>To configure the VPN instance, run the 13.4.207 vpn-instance (Portal server template view) command.</p>
Bound Portal profile	<p>Portal access profile to which the Portal server template is bound.</p> <p>To configure the Portal access profile, run the 13.4.209 web-auth-server (Portal access profile view) command.</p>
Http Get-method	<p>Whether users submit user name and password information to the device in GET mode:</p> <ul style="list-style-type: none"> ● disable: GET mode is not used. ● enable: GET mode is used. <p>To configure the GET mode, run the 13.4.117 http get-method enable command.</p>
Protocol	<p>Protocol used in Portal authentication.</p> <ul style="list-style-type: none"> ● Portal ● http <p>To configure the protocol used in Portal authentication, run the 13.4.172 protocol (Portal server template view) command.</p>

Item	Description
Password Encrypt	Password encoding mode: <ul style="list-style-type: none"> • none: The password is not encoded. • uam: The password is encoded using ASCII characters. To configure the password encoding mode, run the 13.4.172 protocol (Portal server template view) command.
Cmd ParseKey	Command identification keyword. To configure the command identification keyword, run the 13.4.118 http-method post command.
Username ParseKey	User name identification keyword. To configure the user name identification keyword, run the 13.4.118 http-method post command.
Password ParseKey	User password identification keyword. To configure the user password identification keyword, run the 13.4.118 http-method post command.
MAC Address ParseKey	User MAC address identification keyword. To configure the user MAC address identification keyword, run the 13.4.118 http-method post command.
IP Address ParseKey	User IP address identification keyword. To configure the user IP address identification keyword, run the 13.4.118 http-method post command.
Initial URL ParseKey	User initial login URL identification keyword. To configure the user initial login URL identification keyword, run the 13.4.118 http-method post command.
Login Cmd	User login identification keyword. To configure the user login identification keyword, run the 13.4.118 http-method post command.
Logout Cmd	User logout identification keyword. To configure the user logout identification keyword, run the 13.4.118 http-method post command.
Login Success	User login success.

Item	Description
Reply Type	<p>Redirection response type.</p> <ul style="list-style-type: none"> • redirect initial URL: A user is redirected to the initial login URL after successful login. • redirect login URL: A user is redirected to the login URL after a login failure. • message: specifies the displayed message. • redirect URL: A user is redirected to a specified URL. <p>To configure the redirection response type, run the 13.4.118 http-method post command.</p>
Redirect URL	<p>Redirection URL.</p> <p>To configure the redirection URL, run the 13.4.118 http-method post command.</p>
Message	<p>Displayed message.</p> <p>To configure the displayed message, run the 13.4.118 http-method post command.</p>
Login Fail	User login failure.
Logout Success	User logout success.
Logout Fail	User logout failure.

13.4.90 domain mac-authen force

Function

The **domain mac-authen force** command configures a forcible domain for MAC address authentication users.

The **undo domain mac-authen force** command deletes a configured forcible domain for MAC address authentication users.

By default, no forcible domain is configured for MAC address authentication users.

Format

domain *domain-name* **mac-authen force** **mac-address** *mac-address* **mask** *mask*
undo domain *domain-name* **mac-authen force** **mac-address** *mac-address*

Parameters

Parameter	Description	Value
<i>domain-name</i>	Specifies the forcible domain name.	The value must be an existing domain name on the device.
mac-address <i>mac-address</i> mask <i>mask</i>	<p>Specifies a MAC address range within which the MAC address authentication users use the forcible domain.</p> <ul style="list-style-type: none">• mac-address <i>mac-address</i>: specifies the user MAC address.• mask <i>mask</i>: specifies the MAC address mask. <p>NOTE A maximum of 16 MAC address ranges can be specified.</p>	Both the MAC address and mask are in the H-H-H format. Each H is a hexadecimal number of 1 to 4 digits.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

You can configure a forcible domain for MAC address authentication users within a specified MAC address range in the system view.

Prerequisites

A domain has been created using the [13.1.47 domain \(AAA view\)](#) command.

Precautions

The priorities of the forcible domain, domain carried in the user name, and default domain in different views are as follows in descending order: forcible domain with a specified authentication mode in an authentication profile > forcible domain in an authentication profile > authentication domain carried in the user name > default domain with a specified authentication mode in an authentication profile > default domain in an authentication profile > global default domain. Note that a forcible domain specified for MAC address authentication users within a MAC address range has the highest priority and takes precedence over that configured in an authentication profile.

This function takes effect only for users who go online after this function is successfully configured.

Example

In the system view, configure the forcible domain **huawei** for MAC address authentication users within the MAC address range specified using MAC address E024-7F95-7231 and mask FFFF-FFFF-FF00.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain huawei
[HUAWEI-aaa-domain-huawei] quit
[HUAWEI-aaa] quit
[HUAWEI] domain huawei mac-authen force mac-address e024-7f95-7231 mask ffff-ffff-ff00
```

13.4.91 dot1x authentication-method

Function

The **dot1x authentication-method** command configures an 802.1X authentication mode.

The **undo dot1x authentication-method** command restores the default configuration.

The default 802.1X authentication mode is **eap**, which indicates Extensible Authentication Protocol (EAP) relay authentication.

Format

dot1x authentication-method { chap | pap | eap }

undo dot1x authentication-method

Parameters

Parameter	Description	Value
chap	Specifies EAP termination authentication using the Challenge Handshake Authentication Protocol (CHAP).	-
pap	Specifies EAP termination authentication using the Password Authentication Protocol (PAP).	-
eap	Specifies Extensible Authentication Protocol (EAP) relay authentication.	-

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

During 802.1X authentication, users exchange authentication information with the device using EAP packets. The device uses two modes to exchange authentication information with the RADIUS server.

- EAP termination: The device directly parses EAP packets, encapsulates user authentication information into a RADIUS packet, and sends the packet to the RADIUS server for authentication. EAP termination is classified into PAP or CHAP authentication.
 - PAP: The device arranges the MAC address, shared key, and random value in sequence, performs hash processing on them using the MD5 algorithm, and encapsulates the hash result into the User-Password attribute.
 - CHAP: The device arranges the CHAP ID, MAC address, and random value in sequence, performs hash processing on them using the MD5 algorithm, and encapsulates the hash result into the CHAP-Password and CHAP-Challenge attributes.
- EAP relay (specified by **eap**): The device encapsulates EAP packets into RADIUS packets and sends the RADIUS packets to the RADIUS server. The device does not parse the received EAP packets but encapsulates them into RADIUS packets. This mechanism is called EAP over Radius (EAPoR).

The processing capability of the RADIUS server determines whether EAP termination or EAP relay is used. If the RADIUS server has a higher processing capability and can parse a large number of EAP packets before authentication, the EAP relay mode is recommended. If the RADIUS server has a processing capability not good enough to parse a large number of EAP packets and complete authentication, the EAP termination mode is recommended and the device parses EAP packets for the RADIUS server. When the authentication packet processing method is configured, ensure that the client and server both support this method; otherwise, the users cannot pass authentication.

 NOTE

- The EAP relay can be configured for 802.1X users only when RADIUS authentication is used.
- If AAA local authentication is used, the authentication mode for 802.1X users can only be set to EAP termination.
- Because mobile phones do not support EAP termination mode (PAP and CHAP), the 802.1X authentication + local authentication mode cannot be configured for mobile phones. Terminals such as laptop computers support EAP termination mode only after having third-party clients installed.
- If the 802.1X client uses the MD5 encryption mode, the user authentication mode on the device can be set to EAP or CHAP; if the 802.1X client uses the PEAP authentication mode, the authentication mode on the device can be set to EAP.
- In a wireless access scenario, if WPA or WPA2 authentication mode is configured in the security policy profile, 802.1X authentication does not support pre-authentication domain-based authorization.
- If an interface has online 802.1X users and the authentication mode is changed between EAP termination and EAP relay in the 802.1X access profile bound to the interface, the online 802.1X users will be logged out. If the authentication mode is changed between CHAP and PAP in EAP termination mode, the online 802.1X users will not be logged out.

Example

In the 802.1X access profile **d1**, configure the device to use PAP authentication for 802.1X users.

```
<HUAWEI> system-view
[HUAWEI] dot1x-access-profile name d1
[HUAWEI-dot1x-access-profile-d1] dot1x authentication-method pap
```

Related Topics

[13.4.64 display dot1x-access-profile configuration](#)

13.4.92 dot1x eap-notify-packet

Function

The **dot1x eap-notify-packet** command configures the device to send EAP packets with a code number to 802.1X users.

The **undo dot1x eap-notify-packet** command restores the default configuration.

By default, the device does not send EAP packets with a code number to users.

Format

dot1x eap-notify-packet eap-code *code-number* **data-type** *type-number*

undo dot1x eap-notify-packet [**eap-code** *code-number* **data-type** *type-number*]

Parameters

Parameter	Description	Value
eap-code <i>code-number</i>	Specifies the code number in EAP packets sent by the device.	The value is an integer that ranges from 5 to 255, the default value is 255.
data-type <i>type-number</i>	Specifies the data type in EAP packets sent by the device.	The value is an integer that ranges from 1 to 255, the default value is 255.

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When a non-Huawei device used as the RADIUS server sends RADIUS packets with attribute 61, EAP packet code number 0xa (hexadecimal notation, 10 in decimal notation), and data type being 0x19 (hexadecimal notation, 25 in decimal notation) to the device, run the **dot1x eap-notify-packet** command on the device so that the device can send EAP packets with code number 0xa and data type 0x19 to users. If the **dot1x eap-notify-packet** command is not executed, the device does not process EAP packets of this type and users are disconnected.

Precautions

The device can only send EAP packets with code number 10 and data type 25.

Example

In the 802.1X access profile **d1**, configure the device to send EAP packets with code number 10 and data type 25 to users.

```
<HUAWEI> system-view
[HUAWEI] dot1x-access-profile name d1
[HUAWEI-dot1x-access-profile-d1] dot1x eap-notify-packet eap-code 10 data-type 25
```

13.4.93 dot1x handshake

Function

The **dot1x handshake** command enables the device to send handshake packets to online 802.1X users.

The **undo dot1x handshake** command disables the device from sending handshake packets to online 802.1X users.

By default, the device handshake function is disabled for online 802.1X users.

Format

dot1x handshake

undo dot1x handshake

Parameters

None

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To check whether an 802.1X user is online in real time, run the [13.4.13 authentication handshake](#) command to enable the device to send handshake packets to the 802.1X user. If some clients support handshake with online 802.1X users, run the **dot1x handshake** command to enable handshake with online 802.1X users. Then the device sends EAP handshake request packets to the user. If the user sends a response packet within the handshake interval (configured using the [13.4.103 dot1x timer](#) command), the device considers that the user is online. If the user does not send any response packet within the interval, the device considers that the user is offline.

Precautions

Currently, most clients do not support this function, for example, the Windows built-in client, AnyConnect client, and iOS built-in client. If a client does not support the handshake function, the device will not receive handshake response packets within the handshake interval and considers that the user is offline. Therefore, you need to disable the device from sending handshake packets to an online 802.1X user when the user's client does not support the handshake function.

After the **dot1x handshake** command is run, the [13.4.13 authentication handshake](#) command does not take effect.

This function takes effect only for the wired users.

Example

```
# In the 802.1X access profile d1, enable the device to send handshake packets to online 802.1X users.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x-access-profile name d1  
[HUAWEI-dot1x-access-profile-d1] dot1x handshake
```

13.4.94 dot1x handshake packet-type

Function

The **dot1x handshake packet-type** command sets the type of 802.1X authentication handshake packets.

The **undo dot1x handshake packet-type** command restores the default type of 802.1X authentication handshake packets.

By default, the type of 802.1X authentication handshake packets is request-identity.

Format

dot1x handshake packet-type { **request-identity** | **srp-sha1-part2** }

undo dot1x handshake packet-type

Parameters

Parameter	Description	Value
request-identity	Indicates that the type of 802.1X authentication handshake packets is request-identity .	-
srp-sha1-part2	Indicates that the type of 802.1X authentication handshake packets is srp-sha1-part2 .	-

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

During 802.1X authentication, different vendors' devices support different handshake packet types. By default, the device uses 802.1X authentication handshake packets of the **request-identity** type. If a device connected to the switch uses the 802.1X authentication handshake packets of the **srp-sha1-part2** type, run the **dot1x handshake packet-type** command to set the type of 802.1X authentication handshake packets to **srp-sha1-part2**.

NOTE

The **dot1x handshake packet-type** command takes effect only for users that log in after the command is run.

This function takes effect only for the wired users.

Example

In the 802.1X access profile **d1**, set the type of 802.1X authentication handshake packets to **srp-sha1-part2**.

```
<HUAWEI> system-view  
[HUAWEI] dot1x-access-profile name d1  
[HUAWEI-dot1x-access-profile-d1] dot1x handshake packet-type srp-sha1-part2
```

13.4.95 dot1x mc-trigger

Function

The **dot1x mc-trigger** command enables multicast-triggered 802.1X authentication.

The **undo dot1x mc-trigger** command disables multicast-triggered 802.1X authentication.

By default, multicast-triggered 802.1X authentication is enabled.

Format

dot1x mc-trigger

undo dot1x mc-trigger

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

If a client (for example, the built-in 802.1X client of the Windows operating system) cannot send an EAPOL-Start packet to perform 802.1X authentication, you can enable multicast-triggered 802.1X authentication. After that, the device multicasts an EAP-Request/Identity packet to the client to trigger authentication.

Example

Enable multicast-triggered 802.1X authentication.

```
<HUAWEI> system-view  
[HUAWEI] dot1x mc-trigger
```

13.4.96 dot1x mc-trigger port-up-send enable

Function

The **dot1x mc-trigger port-up-send enable** command enables the function of triggering 802.1X authentication through multicast packets immediately after an interface goes Up.

The **undo dot1x mc-trigger port-up-send enable** command disables the function of triggering 802.1X authentication through multicast packets immediately after an interface goes Up.

By default, the function of triggering 802.1X authentication through multicast packets immediately after an interface goes Up is disabled.

Format

dot1x mc-trigger port-up-send enable

undo dot1x mc-trigger port-up-send enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

By default, the device periodically multicasts EAP-Request/Identity packets to clients so that the clients are triggered to send EAPOL-Start packets for 802.1X authentication. If the device interface connecting to a client changes from Down to Up, the client needs to send EAPOL-Start packets again for 802.1X authentication, which takes a long time. You can run the **dot1x mc-trigger port-up-send enable** command on the device to enable the device interface to multicast EAP-Request/Identity packets to the client to trigger 802.1X authentication immediately after the interface goes Up. This configuration shortens the re-authentication time.

Example

```
# Enable the function of triggering 802.1X authentication through multicast  
packets immediately after an interface goes Up.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x mc-trigger port-up-send enable
```

13.4.97 dot1x port-control

Function

The **dot1x port-control** command sets the authorization state of an interface.

The **undo dot1x port-control** command restores the default authorization state of an interface.

By default, the authorization state of an interface is **auto**.

Format

dot1x port-control { **auto** | **authorized-force** | **unauthorized-force** }

undo dot1x port-control

Parameters

Parameter	Description	Value
auto	Indicates the auto identification mode. In this mode, an interface is initially in Unauthorized state and only allows users to send and receive EAPOL packets. Users cannot access network resources. After the users are authenticated, the interface becomes authorized and allows the users to access network resources.	-

Parameter	Description	Value
authorized-force	Indicates the forcible authorization mode. In this mode, the interface is always in Authorized state, does not handle EAPOL packets, and allows users to access network resources without authentication or authorization. Indicates the forcible unauthorized mode. In this mode, the interface is always in Unauthorized state, does not handle EAPOL packets, and prohibits users from accessing network resources.	-
unauthorized-force	Indicates the forcible authorization mode. In this mode, the interface is always in Authorized state, does not handle EAPOL packets, and allows users to access network resources without authentication or authorization. Indicates the forcible unauthorized mode. In this mode, the interface is always in Unauthorized state, does not handle EAPOL packets, and prohibits users from accessing network resources.	-

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The **auto** mode is recommended. Only authenticated users can access network resources. To trust all users on an interface without authentication, configure the **authorized-force** mode. To disable access rights of all users on an interface to ensure security, configure the **unauthorized-force** mode.

Precautions

If 802.1X users on an interface have gone online, changing the authorization state in the 802.1X access profile bound to the interface will make the online 802.1X users go offline.

It is recommended that you set the authorization state of an interface in the early stage of network deployment. When the network is running properly, run the **cut access-user** command to disconnect all users from the interface before changing the authorization state.

Example

Configure the authorization state of an interface as **unauthorized-force** in 802.1X access profile **d1**.

```
<HUAWEI> system-view  
[HUAWEI] dot1x-access-profile name d1  
[HUAWEI-dot1x-access-profile-d1] dot1x port-control unauthorized-force
```

Related Topics

[13.4.64 display dot1x-access-profile configuration](#)

13.4.98 dot1x quiet-period

Function

The **dot1x quiet-period** command enables the quiet function for 802.1X authentication users.

The **undo dot1x quiet-period** command disables the quiet function for 802.1X authentication users.

By default, the quiet function is enabled for 802.1X authentication users.

Format

dot1x quiet-period

undo dot1x quiet-period

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the quiet timer function is enabled, if the number of authentication failures of an 802.1X user exceeds a specified value (set using the [13.4.99 dot1x quiet-times](#) command) within 60 seconds, the user enters a quiet period. During the quiet period, the device discards the 802.1X authentication request packets from the user. This prevents the impact on the system due to frequent user authentication.

The value of the quiet timer is set using the [13.4.105 dot1x timer quiet-period](#) command. When the quiet timer expires, the device re-authenticates the user.

Example

```
# Enable the quiet timer.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x quiet-period
```

13.4.99 dot1x quiet-times

Function

The **dot1x quiet-times** command sets the maximum number of authentication failures within 60 seconds before an 802.1X user enters the quiet state.

The **undo dot1x quiet-times** command restores the default setting.

By default, an 802.1X user enters the quiet state after 10 authentication failures within 60 seconds.

Format

dot1x quiet-times *fail-times*

undo dot1x quiet-times

Parameters

Parameter	Description	Value
<i>fail-times</i>	Specifies the maximum number of authentication failures before the 802.1X user enters the quiet state.	The value is an integer that ranges from 1 to 10.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the quiet timer function of the device is enabled using the [13.4.98 dot1x quiet-period](#) command, if the number of authentication failures of an 802.1X user exceeds the value that is set using the **dot1x quiet-times** command within 60 seconds, the user enters the quiet state. This prevents the impact on the system due to frequent user authentication.

Example

Set the maximum number of authentication failures within 60 seconds before an 802.1X user enters the quiet state to 4.

```
<HUAWEI> system-view  
[HUAWEI] dot1x quiet-times 4
```

13.4.100 dot1x reauthenticate mac-address

Function

The **dot1x reauthenticate mac-address** command enables re-authentication for an online 802.1X user with the specified MAC address.

By default, re-authentication is disabled for an online 802.1X user with the specified MAC address.

Format

dot1x reauthenticate mac-address *mac-address*

Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies the MAC address of an 802.1X user to be re-authenticated.	The value is a unicast MAC address in H-H-H format, where H can be one to four hexadecimal digits.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

For details, see [dot1x reauthenticate](#).

The **dot1x reauthenticate mac-address** and **dot1x reauthenticate** commands re-authenticate online 802.1X users and their difference is as follows:

- The **dot1x reauthenticate mac-address** command configures the device to re-authenticate a specified user for once.
- The **dot1x reauthenticate** command configures the device to re-authenticate all users at intervals.

Example

```
# Enable re-authentication for an 802.1X user with the MAC address of 00e0-  
fc01-0005.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x reauthenticate mac-address 00e0-fc01-0005
```

13.4.101 dot1x reauthenticate

Function

The **dot1x reauthenticate** command configures re-authentication for online 802.1X authentication users.

The **undo dot1x reauthenticate** command restores the default configuration.

By default, re-authentication is not configured for online 802.1X authentication users.

Format

dot1x reauthenticate

undo dot1x reauthenticate

Parameters

None

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After modifying the authentication parameters of a user on the authentication server, the administrator must re-authenticate the user in real time to ensure user validity if the user has been online.

After the user goes online, the device saves authentication parameters of the user. After re-authentication is configured for online 802.1X authentication users using the **dot1x reauthenticate** command in the 802.1X access profile, the device automatically sends the user authentication parameters in the 802.1X access profile to the authentication server at an interval (specified using the [13.4.103 dot1x timer reauthenticate-period reauthenticate-period-value](#) command) for re-authentication. If the user authentication information on the authentication server remains unchanged, the users are kept online. If the information has been changed, the users are disconnected and need to be re-authenticated based on the changed authentication parameters.

Precautions

After re-authentication is configured for online 802.1X authentication users, a large number of 802.1X authentication logs are generated.

If the device is connected to a server for re-authentication and the server replies with a re-authentication deny message that makes an online user go offline, it is recommended that you locate the cause of the re-authentication failure on the server or disable the re-authentication function on the device.

Example

In the 802.1X access profile **d1**, configure re-authentication for online 802.1X authentication users.

```
<HUAWEI> system-view  
[HUAWEI] dot1x-access-profile name d1  
[HUAWEI-dot1x-access-profile-d1] dot1x reauthenticate
```

Related Topics

[13.4.64 display dot1x-access-profile configuration](#)

13.4.102 dot1x retry

Function

The **dot1x retry** command configures the number of times an authentication request or handshake packet is retransmitted to an 802.1X user.

The **undo dot1x retry** command restores the default configuration.

By default, the device can retransmit an authentication request or handshake packet to an 802.1X user twice.

Format

dot1x retry *max-retry-value*

undo dot1x retry

Parameters

Parameter	Description	Value
<i>max-retry-value</i>	Specifies the number of times an authentication request or handshake packet is retransmitted to an 802.1X user.	The value is an integer that ranges from 1 to 10.

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If the device does not receive any response from a user within a specified time after sending an authentication request or handshake packet to the user, the device sends the authentication request or handshake packet again. If the authentication request or handshake packet has been sent for the maximum retransmission times and no response is received, the user authentication or handshake fails. In this process, the total number of authentication requests or handshake packets sent by the device is *max-retry-value* plus 1.

Precautions

Repeated authentication requests occupy a lot of system resources. When using the **dot1x retry** command, you can set the maximum number of times according to user requirements and device resources. The default value is recommended.

The following table lists the intervals at which the device retransmits different types of packets and related commands.

Packet Type	Interval for Retransmitting Packets	Command
EAP-Request/Identity packet (MAC address bypass authentication is disabled)	<i>tx-period-value</i>	13.4.107 dot1x timer <i>tx-period tx-period-value</i>

Packet Type	Interval for Retransmitting Packets	Command
EAP-Request/Identity packet (MAC address bypass authentication is enabled)	Integer part of the value calculated using the following formula: $delay-time-value / (max-retry-value + 1)$	13.4.104 dot1x timer mac-bypass-delay <i>delay-time-value</i>
EAP-Request/MD5 Challenge packet	<i>client-timeout-value</i>	13.4.103 dot1x timer client-timeout <i>client-timeout-value</i>
Handshake packet	<i>handshake-period-value</i>	13.4.103 dot1x timer handshake-period <i>handshake-period-value</i>

Example

In the 802.1X access profile **d1**, configure the number of times an authentication request or handshake packet can be retransmitted to 802.1X users to 4.

```
<HUAWEI> system-view
[HUAWEI] dot1x-access-profile name d1
[HUAWEI-dot1x-access-profile-d1] dot1x retry 4
```

Related Topics

[13.4.64 display dot1x-access-profile configuration](#)

13.4.103 dot1x timer

Function

The **dot1x timer** command configures the parameters of each 802.1X timer.

The **undo dot1x timer** command restores the default settings.

For the default parameter settings of each 802.1X timer, see the parameter description.

Format

dot1x timer { **client-timeout** *client-timeout-value* | **reauthenticate-period** *reauthenticate-period-value* | **handshake-period** *handshake-period-value* | **eth-trunk-access handshake-period** *handshake-period-value* }

undo dot1x timer { **client-timeout** | **reauthenticate-period** | **handshake-period** | **eth-trunk-access handshake-period** }

Parameters

Parameter	Description	Value
client-timeout <i>client-timeout-value</i>	Specifies the client authentication timeout interval. You are advised to set this parameter to 30 seconds for wired users. NOTE On the network, some terminals may delay in responding to EAP-Request/MD5 Challenge packets sent from the device. If the delay is long, you can increase client-timeout client-timeout-value so that these terminals can go online. The adjustment rule is as follows: $3 \times \text{client-timeout client-timeout-value} > \text{Terminal response delay}$.	The value is an integer that ranges from 1 to 120, in seconds. By default, the client authentication timeout interval is 5 seconds.
reauthenticate-period <i>reauthenticate-period-value</i>	Specifies the periodic re-authentication period for online 802.1X users.	The value is an integer that ranges from 60 to 7200, in seconds. By default, the periodic re-authentication period is 3600 seconds for online 802.1X users.
handshake-period <i>handshake-period-value</i>	Specifies the interval at which the device handshakes with an 802.1X client on a non-Eth-Trunk interface. For details, see 13.4.93 dot1x handshake .	The value is an integer that ranges from 5 to 7200, in seconds. By default, the interval for sending handshake packets is 15s.
eth-trunk-access handshake-period <i>handshake-period-value</i>	Specifies the interval at which the device handshakes with an 802.1X client on an Eth-Trunk. For details, see 13.4.93 dot1x handshake .	The value is an integer that ranges from 30 to 7200, in seconds. By default, the interval for sending handshake packets is 120s.

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

During 802.1X authentication, multiple timers are started to implement proper and orderly interactions between access users, access devices, and the authentication server. You can change the values of timers by running the **dot1x timer** command to adjust the interaction process. (The values of some timers cannot be changed.) This command is necessary in special network environments. It is recommended that you retain the default settings of the timers.

This command only sets the values of the timers. To enable the timers, perform corresponding configurations or use default settings.

- The client authentication timeout timer and the interval for sending authentication requests are enabled by default. You can run the [13.4.102 dot1x retry](#) command to configure the number of retransmissions of authentication request packets when the client authentication times out.
- The re-authentication timer for online 802.1X users is disabled by default. To enable this timer, run the [13.4.101 dot1x reauthenticate](#) command.
- The online 802.1X user handshake function is disabled by default. You can run the [13.4.93 dot1x handshake](#) command to enable the online 802.1X user handshake function. The handshake function takes effect only for the wired users.

NOTE

It is recommended that the re-authentication interval be set to the default value. If multiple ACLs need to be delivered during user authorization, you are advised to disable the re-authentication function or set a longer re-authentication interval to improve the device's processing performance.

In remote authentication and authorization, if the re-authentication interval is set to a shorter time, the CPU usage may be higher.

To reduce the impact on the device performance when many users exist, the user re-authentication interval may be longer than the configured re-authentication interval.

Example

In the 802.1X access profile **d1**, set the client authentication timeout interval to 90 seconds.

```
<HUAWEI> system-view
[HUAWEI] dot1x-access-profile name d1
[HUAWEI-dot1x-access-profile-d1] dot1x timer client-timeout 90
```

Related Topics

[13.4.64 display dot1x-access-profile configuration](#)

13.4.104 dot1x timer mac-bypass-delay

Function

The **dot1x timer mac-bypass-delay** command configures the 802.1X authentication timeout timer after which MAC address authentication is performed.

The **undo dot1x timer mac-bypass-delay** command restores the default configuration.

By default, the device performs MAC address authentication if 802.1X authentication is not successful within 30 seconds.

Format

dot1x timer mac-bypass-delay *delay-time-value*

undo dot1x timer mac-bypass-delay

Parameters

Parameter	Description	Value
<i>delay-time-value</i>	Specifies the value of the 802.1X authentication timeout timer after which MAC address authentication is performed.	The value is an integer in the range 1 to 300, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After MAC address bypass authentication is configured, the device performs 802.1X authentication first and starts the timer configured using the **dot1x timer mac-bypass-delay** *delay-time-value* command. If 802.1X authentication is not successful before the timer expires, the device performs MAC address authentication on users. You can run the [13.4.102 dot1x retry](#) *max-retry-value* command to set the number of times an authentication request is retransmitted to an 802.1X user. The retransmission interval is the integer part of the value calculated using the following formula: $delay-time-value / (max-retry-value + 1)$

Example

Configure the device to perform MAC address authentication if 802.1X authentication is not successful within 60 seconds.

```
<HUAWEI> system-view  
[HUAWEI] dot1x timer mac-bypass-delay 60
```

13.4.105 dot1x timer quiet-period

Function

The **dot1x timer quiet-period** command configures the quiet period for 802.1X users who fail to be authenticated.

The **undo dot1x timer quiet-period** command restores the default quiet period.

By default, the quiet period is 60 seconds for 802.1X users who fail to be authenticated.

Format

dot1x timer quiet-period *quiet-period-times*

undo dot1x timer quiet-period

Parameters

Parameter	Description	Value
<i>quiet-period-times</i>	Sets the quiet period for 802.1X users who fail to be authenticated.	The value is an integer that ranges from 1 to 3600, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

If an 802.1X authentication user fails to be authenticated consecutively within a short period, the system is affected and a large number of duplicated authentication failure logs are generated.

After the quiet function is enabled using the [13.4.98 dot1x quiet-period](#) command, if the number of times that an 802.1X user fails to be authenticated within 60s exceeds the upper limit (configured using the [13.4.99 dot1x quiet-times](#) command), the device discards the user's 802.1X authentication request packets for a period to avoid frequent authentication failures.

Example

Set the quiet period to 100 seconds for 802.1X users who fail to be authenticated.

```
<HUAWEI> system-view  
[HUAWEI] dot1x timer quiet-period 100
```

13.4.106 dot1x trigger dhcp-binding

Function

The **dot1x trigger dhcp-binding** command enables the device to automatically generate the DHCP snooping binding table after static IP users pass 802.1X authentication or when the users are at the pre-connection phase.

The **undo dot1x trigger dhcp-binding** command restores the default setting.

By default, the device does not automatically generate the DHCP snooping binding table after static IP users pass 802.1X authentication or when the users are at the pre-authentication phase.

Format

dot1x trigger dhcp-binding

undo dot1x trigger dhcp-binding

Parameters

None

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

Scenario

There are unauthorized users who modify their MAC addresses to those of authorized users. After authorized users are connected through 802.1X authentication, the unauthorized users can obtain the same identities as the authorized users and connect to the network without authentication. This results in security risks of authentication and accounting. After accessing the network, unauthorized users can also initiate ARP spoofing attacks by sending bogus ARP packets. In this case, the device records incorrect ARP entries, greatly affecting normal communication between authorized users. To prevent the previous attacks, configure IPSG and DAI. These two functions are implemented based on binding tables. For static IP users, you can run the **user-bind static** command to configure the static binding table. However, if there are many static IP users, it takes more time to configure static binding entries one by one.

To reduce the workload, you can configure the device to automatically generate the DHCP snooping binding table for static IP users. After the static IP users who pass 802.1X authentication or are at the pre-authentication phase send EAP packets to trigger generation of the user information table, the device automatically generates the DHCP snooping binding table based on the MAC address, IP address, and interface recorded in the table.

You can run the **display dhcp snooping user-bind** command to check the DHCP snooping binding table that is generated by the device for static IP users who pass 802.1X authentication or are at the pre-authentication phase. The DHCP snooping binding table generated using this function will be deleted after the users are disconnected.

Follow-up Procedure

Configure IPSG and DAI after the DHCP snooping binding table is generated, prevent attacks from unauthorized users.

- In the interface view, run the **ip source check user-bind enable** command to enable IPSG.
- In the interface view, run the **arp anti-attack check user-bind enable** command to enable DAI.

Precautions

- To make this function take effect, you must run the **dhcp snooping enable** command on the interface to which the 802.1X access profile is bound to enable the DHCP snooping function on the interface and globally.
- The EAP protocol does not specify a standard attribute to carry IP address information. Therefore, if the EAP request packet sent by a static IP user does not contain an IP address, the IP address information in the DHCP snooping binding table is obtained from the user's first ARP request packet with the same MAC address as the user information table after the user passes authentication. On a network, unauthorized users may forge authorized users' MAC addresses to initiate ARP snooping attacks to devices, and the DHCP snooping binding table generated accordingly may be unreliable. Therefore, the **dot1x trigger dhcp-binding** command is not recommended and you are advised to run the **user-bind static** command to configure the static binding table.
- For users who are assigned IP addresses using DHCP, you do not need to run the **dot1x trigger dhcp-binding** command on the device. The DHCP snooping binding table is generated through the DHCP snooping function.
- The IP address in the DHCP snooping binding table is extracted from the ARP request packet (the first ARP request packet sent by the user after the user is authenticated or in the pre-connection state that has the same MAC address in the user information table). If the static IP address of a user is changed, the user needs to be authenticated again.

Example

```
# In the 802.1X access profile d1, enable the device to automatically generate the DHCP snooping binding table after static IP users pass 802.1X authentication or when the users are at the pre-authentication phase.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x-access-profile name d1  
[HUAWEI-dot1x-access-profile-d1] dot1x trigger dhcp-binding
```

13.4.107 dot1x timer tx-period

Function

The **dot1x timer tx-period** command sets the interval at which the device sends authentication requests.

The **undo dot1x timer tx-period** command restores the default configuration.

By default, the device sends authentication requests at an interval of 30 seconds.

Format

dot1x timer tx-period *tx-period-value*

undo dot1x timer tx-period

Parameters

Parameter	Description	Value
<i>tx-period-value</i>	Specifies the interval for sending authentication requests.	The value is an integer that ranges from 1 to 120, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device starts the **tx-period** timer in either of the following situations:

- When the client initiates authentication and MAC address bypass authentication is not configured, the device sends a unicast Request/Identity packet to the client and starts the **tx-period** timer. If the client does not respond within the period set by the timer, the device retransmits the authentication request.
- To authenticate the 802.1X clients that cannot initiate authentication, the device periodically sends multicast Request/Identity packets through the 802.1X-enabled interface to the clients at the interval set by the **tx-period** timer.

After MAC address bypass authentication is enabled on a device, the interval at which the device sends unicast Request/Identity packets to clients is determined

by *delay-time-value* configured in the [13.4.104 dot1x timer mac-bypass-delay](#) command and *max-retry-value* configured in the [13.4.102 dot1x retry](#) command. The retransmission interval is the integer part of the value calculated using the following formula: $delay-time-value / (max-retry-value + 1)$

Normally, it is recommended that you retain the default setting of the timer.

Example

Set the interval at which the device sends authentication requests to 90 seconds.

```
<HUAWEI> system-view  
[HUAWEI] dot1x timer tx-period 90
```

13.4.108 dot1x unicast-trigger

Function

The **dot1x unicast-trigger** command enables 802.1X authentication triggered by unicast packets.

The **undo dot1x unicast-trigger** command disables 802.1X authentication triggered by unicast packets.

By default, 802.1X authentication triggered by unicast packets is disabled.

Format

```
dot1x unicast-trigger  
undo dot1x unicast-trigger
```

Parameters

None

Views

802.1X access profile view

Default Level

2: Configuration level

Usage Guidelines

After the **dot1x unicast-trigger** command is used on the device, the device sends a unicast packet to respond to the received ARP or DHCP Request packet from a client. If the client does not respond within the timeout interval (set by the [13.4.103 dot1x timer client-timeout](#) *client-timeout-value* command), the device retransmits the unicast packet (the maximum of retransmission times is set by the [13.4.102 dot1x retry](#) *max-retry-value* command). This function allows users to use the 802.1X client provided by the operating system for authentication, helping quickly deploy an 802.1X network.

After receiving a packet that triggers 802.1X authentication from a client, the device sends a unicast packet to the client. For clients that cannot send packets to trigger 802.1X authentication, configure multicast packets to trigger 802.1X authentication.

Example

In the 802.1X access profile **d1**, enable 802.1X authentication triggered by unicast packets.

```
<HUAWEI> system-view  
[HUAWEI] dot1x-access-profile name d1  
[HUAWEI-dot1x-access-profile-d1] dot1x unicast-trigger
```

13.4.109 dot1x url

Function

The **dot1x url** command configures the redirect-to URL in 802.1X authentication.

The **undo dot1x url** command cancels the redirect-to URL configuration in 802.1X authentication.

By default, no redirect-to URL is configured in 802.1X authentication.

Format

dot1x url *url-string*

undo dot1x url

Parameters

Parameter	Description	Value
<i>url-string</i>	Specifies the redirect-to URL.	It is a string of 1 to 200 case-sensitive characters that do not contain spaces and question marks (?). When double quotation marks are used around the string, spaces are allowed in the string.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In the early stage of network deployment, 802.1X client deployment is difficult with heavy workload. You can run the **dot1x url** command to set the redirect-to

URL to the 802.1X client download web page address. When a user attempts to access a non-free IP subnet, the device redirects the user to the redirect-to URL where the user can download and install the 802.1X client software.

Follow-up Procedure

Run the [13.4.113 free-rule](#) command to configure a free IP subnet where the redirect URL used in 802.1X authentication belongs.

Precautions

Wireless users do not support the redirect URL configuration in 802.1X authentication.

The device does not support the triggering of a redirect URL through HTTPS packets.

Example

```
# Set the redirect-to URL in 802.1X authentication to http://www.***.com.cn.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x url http://www.***.com.cn
```

13.4.110 dot1x-access-profile (authentication profile view)

Function

The **dot1x-access-profile** command binds an authentication profile to an 802.1X access profile.

The **undo dot1x-access-profile** command unbinds an authentication profile from an 802.1X access profile.

By default, an authentication profile is not bound to an 802.1X access profile.

Format

dot1x-access-profile *access-profile-name*

undo dot1x-access-profile

Parameters

Parameter	Description	Value
<i>access-profile-name</i>	Specifies the name of an 802.1X access profile.	The value must be the name of an existing 802.1X access profile.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The authentication type used by an authentication profile is determined by the access profile bound to the authentication profile. After being bound to an 802.1X access profile, the authentication profile is enabled with 802.1X authentication. After the authentication profile is applied to the interface or VAP profile, 802.1X authentication can be performed on online users.

Prerequisites

An 802.1X access profile has been created using the [13.4.111 dot1x-access-profile \(system view\)](#) command.

Follow-up Procedure

Run the [13.4.42 authentication-profile \(Interface view or VAP profile view\)](#) command to apply the authentication profile to the interface or VAP profile.

Precautions

An authentication profile can be bound to only one 802.1X access profile.

Example

Bind the authentication profile **dot1x_authen_profile1** to the 802.1X access profile **dot1x_access_profile1**.

```
<HUAWEI> system-view
[HUAWEI] dot1x-access-profile name dot1x_access_profile1
[HUAWEI-dot1x-access-profile-dot1x_access_profile1] quit
[HUAWEI] authentication-profile name dot1x_authen_profile1
[HUAWEI-authen-profile-dot1x_authen_profile1] dot1x-access-profile dot1x_access_profile1
```

Related Topics

[13.4.61 display authentication-profile configuration](#)

13.4.111 dot1x-access-profile (system view)

Function

The **dot1x-access-profile** command creates an 802.1X access profile and displays the 802.1X access profile view.

The **undo dot1x-access-profile** command deletes an 802.1X access profile.

By default, the device has a built-in 802.1X access profile named **dot1x_access_profile**.

Format

dot1x-access-profile name *access-profile-name*

undo dot1x-access-profile name *access-profile-name*

Parameters

Parameter	Description	Value
name <i>access-profile-name</i>	Specifies the name of an 802.1X access profile.	The value is a string of 1-31 case-sensitive characters, which cannot be configured to - and --. It cannot contain spaces and the following symbols: / \ : * ? " < > @ ' %.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device uses 802.1X access profiles to uniformly manage all 802.1X users access configurations. To perform 802.1X authentication for the users in the interface or VAP profile, bind the authentication profile applied to the interface or VAP profile to an 802.1X access profile.

Follow-up Procedure

Run the [13.4.110 dot1x-access-profile \(authentication profile view\)](#) command in the authentication profile view to bind the authentication profile to an 802.1X access profile.

Precautions

- The compatibility profile converted after an upgrade is not counted in the configuration specification. The built-in 802.1X access profile dot1x_access_profile can be modified and applied, but cannot be deleted.
- Before deleting an 802.1X access profile, ensure that this profile is not bound to any authentication profile.

Example

```
# Create the 802.1X access profile named dot1x_access_profile1.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x-access-profile name dot1x_access_profile1
```

Related Topics

[13.4.64 display dot1x-access-profile configuration](#)

13.4.112 enable (terminal type identification profile view)

Function

The **enable** command enables terminal type identification.

The **undo enable** command disables terminal type identification.

By default, terminal type identification is disabled.

NOTE

This function is supported only by S5720HI.

Format

enable

undo enable

Parameters

None

Views

Terminal type identification profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The terminal type identification profile takes effect immediately when terminal type identification is enabled. The AC analyzes the terminal's MAC address, DHCP Option, and UA information. If the information matches the rules configured in the profile, the AC identifies the terminal type.

Prerequisite

A terminal type identifier has been configured using the [13.4.47 device-type](#) command.

Example

Enable terminal type identification.

```
<HUAWEI> system-view  
[HUAWEI] device-profile profile-name huawei
```

[HUAWEI-device-profile-huawei] **device-type huawei**
[HUAWEI-device-profile-huawei] **enable**

Related Topics

[13.4.47 device-type](#)

[13.4.62 display device-profile](#)

13.4.113 free-rule

Function

The **free-rule** command configures authentication-free rules for NAC authentication users.

The **undo free-rule** command restores the default settings.

By default, no authentication-free rule is configured for NAC authentication users.

Format

Common authentication-free rule:

```
free-rule rule-id { destination { any | ip { ip-address mask { mask-length | ip-mask } [ tcp destination-port port | udp destination-port port ] | any } } | source { any | { interface interface-type interface-number | ip { ip-address mask { mask-length | ip-mask } | any } | vlan vlan-id } * } } *
```

```
undo free-rule { rule-id | all }
```

Authentication-free rule defined by ACL:

```
free-rule acl { acl-id | acl-name acl-name }
```

```
undo free-rule { acl { acl-id | acl-name acl-name } | all }
```

NOTE

Only the S5720EI, S5720HI, S6720EI, and S6720S-EI support the authentication-free rule defined by ACL.

Parameters

Parameter	Description	Value
<i>rule-id</i>	Specifies the number of an authentication-free rule for NAC authentication users.	The value is an integer that ranges from 0 to 511.
destination	Specifies the destination network resource that NAC authentication users can access without authentication.	-

Parameter	Description	Value
source	Specifies source information for NAC authentication users without authentication.	-
any	Indicates any condition. When any is used together with different keywords, the effect of the command is different.	-
interface <i>interface-type</i> <i>interface-number</i>	Specifies the source interface in the rule. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. NOTE The source interface cannot be a management interface.	-
ip <i>ip-address</i>	Specifies the source or destination IP address depending on the keyword.	The value is in dotted decimal notation.
mask <i>mask-length</i>	Specifies the mask length of the source or destination IP address depending on the keyword.	The value is an integer that ranges from 1 to 32.
mask <i>ip-mask</i>	Specifies the mask of the source or destination IP address depending on the keyword.	The value is in dotted decimal notation.
tcp destination-port <i>port</i>	Specifies a TCP destination port number.	The value is an integer that ranges from 1 to 65535.
udp destination-port <i>port</i>	Specifies the UDP destination port number.	The value is an integer that ranges from 1 to 65535.
vlan <i>vlan-id</i>	Specifies the VLAN ID of source packets.	The value is an integer that ranges from 1 to 4094.
acl	Specifies an authentication-free rule defined by ACL.	-

Parameter	Description	Value
<i>acl-id</i>	Specifies the number of an IPv4 ACL.	The value is an integer that ranges from 6000 to 6031.
acl-name <i>acl-name</i>	Specifies the name of an IPv4 ACL.	The value must be an existing IPv4 ACL name. The value of the named ACL ranges from 6000 to 6031.
all	Specifies all rules.	-

Views

Authentication-free rule profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To meet basic network access requirements of users who have not passed authentication, the users need to obtain some network access rights without authentication, for example, download 802.1X client software and update the antivirus database. After running the [13.4.115 free-rule-template \(system view\)](#) command to create an authentication-free rule profile, run the **free-rule** command to configure authentication-free rules in the profile. The users then can obtain some network access rights without authentication.

An authentication-free rule can be a common authentication-free rule or defined by an ACL. A common authentication-free rule is determined by parameters such as IP address, MAC address, interface, and VLAN. An authentication-free rule defined by an ACL is determined by the ACL rule (configured using the [rule](#) command). The destination IP address that users can access without authentication can be specified in an authentication-free rule defined by either of the two methods. In addition, the destination domain name that users can access without authentication can be specified in an authentication-free rule defined by an ACL.

Compared with the authentication-free rule defined by IP address, the one defined by domain name is sometimes simple and convenient. For example, some authentication users who do not have an authentication account must first log in to the official website of a carrier and apply for a member account, or log in using the account of a third party such as Twitter or Facebook. This requires that the users can access specified websites before successful authentication. The domain name of a website is easier to remember than the IP address; therefore, the authentication-free rule defined by ACL can be configured to enable the users to access the domain names of websites without authentication.

Prerequisites

To use the authentication-free rule defined by ACL: an ACL rule has been configured using the **rule** command. This ACL rule can be based on an IP address or a domain name. If the rule is defined by IP address, the **source** and **destination** parameters can be configured; if the rule is defined by domain name, only the **destination** parameter can be configured.

NOTE

If the user ACL is created using a name (specified by *acl-name*), a name-based ACL has been created and the ACL number (6000-6031) has been specified using the **acl name** *acl-name* *acl-number* command.

Follow-up Procedure

The domain name specified in an ACL only supports dynamic DNS resolution. Therefore, when you define the authentication-free rule by domain name, configure dynamic DNS resolution on the device and enable users to access the DNS server without authentication. The steps are as follows:

1. Run the **dns resolve** command in the system view to enable dynamic DNS resolution.
2. Run the **dns server** *ip-address* command in the system view to specify an IP address for the DNS server.
3. Run the **free-rule** *rule-id* **destination ip** *ip-address* **mask** { *mask-length* | *ip-mask* } command in the authentication-free rule profile to enable users to access the DNS server without authentication.

Precautions

Wireless 802.1X authentication does not support this function.

When 802.1X authentication or MAC authentication is configured on a physical interface, the **free-rule** command configuration will not take effect after the **undo authentication pre-authen-access enable** command is configured to disable the prec-connection function.

Pay attention to the following when you use common authentication-free rules:

- When multiple authentication-free rules are configured simultaneously, the system matches the rules one by one.
- In a wireless scenario or an SVF system, only the authentication-free rules with IDs in the range of 0 to 127 on the AP or AS can take effect. On the AC or parent, all configured authentication-free rules take effect.
- In a wireless scenario, the VLAN ID and interface number cannot be specified in authentication-free rules configured on an AP. You are advised to set the authentication-free rule ID to 128 or a larger value when specifying the VLAN ID and interface number. If the ID of an authentication-free rule is less than 128, Portal redirection cannot be performed.
- In an SVF system, interface information in an authentication-free rule is invalid.
- If you specify both the VLAN ID and interface number in an authentication-free rule, the interface must belong to the VLAN. Otherwise, the rule is invalid.
- If the destination port number is configured in an authentication-free rule, fragments cannot match the rule and packets cannot be forwarded.

- No authentication-free rule needs to be configured for DHCP, CAPWAP, ARP, and HTTP packets before user authentication, the DHCP, CAPWAP, ARP, and HTTP packets can be directly forwarded. Authentication-free rules must be configured for other packets that need to be forwarded. When the packets need to be processed locally, authentication-free rules need to be configured on only the S5720HI.
 - DHCP packet: If authentication and DHCP are enabled on an interface, authentication can be triggered by DHCP packets and the switch acts as the DHCP relay or DHCP server to forward or process DHCP packets. If only authentication is configured on the interface and the DHCP function is not configured, authentication can be triggered by DHCP packets and the switch broadcasts the DHCP packets.
 - CAPWAP packet: CAPWAP packets are classified into control packets and data packets. Generally, NAC is still effective for CAPWAP data packets after they are decapsulated, and the authentication-free rule takes effect (except for ARP and DHCP packets that are encapsulated in CAPWAP data packets). CAPWAP control packets are sent to the CPU for processing (such as SVF and wireless scenarios). If authentication is enabled on the physical interface connected to an AP, you need to configure the authentication-free rule to transmit packets from the management VLAN. In this scenario, the server may be overloaded due to multiple times of re-authentication. Therefore, this scenario is not recommended.
 - ARP packet: No authentication-free rule needs to be configured for ARP packets, which can be directly processed or forwarded.
 - HTTP packet: If Portal authentication is enabled on an interface and the destination URL of HTTP packets is not the URL of the Portal server, the switch redirects HTTP packets to the Portal server for authentication.

Pay attention to the following when you define authentication free rules by ACL:

- Authentication-free rules based on domain names are valid for only wireless users.
- When SVF is enabled, authentication-free rules cannot be delivered to an AS.
- When multiple authentication-free rules are configured at the same time, only the last one takes effect.
- An authentication-free rule can be dynamically modified. The authentication-free rule does not differentiate the **deny** or **permit** action of the ACL rule (configured using the **rule** command) and uniformly performs the **permit** action. The ACL rule number ranges from 0 to 127.
- If multiple domain names correspond to the same IP address and one matches the authentication-free rule, other domain names also match the authentication-free rule.

The **free-rule** command configures a rule for specifying the resources accessible to users before authentication. However, this command does not mean that users matching the rule do not need to be authenticated. To free specified users from authentication, run the **access-context profile enable** command to enable the user context identification function, and run the **if-match vlan-id { start-vlan-id [to end-vlan-id] }** &<1-10> command in the user context profile to configure the VLAN ID-based user identification policy. In addition, run the **authentication-mode none** command to enable non-configuration in the authentication scheme bound in the authentication domain of the users.

The priority of the ACL rule delivered by the RADIUS server is higher than that of the authentication-free rule configured on the device.

Example

In the authentication-free rule profile **default_free_rule**, allow all NAC authentication users to access the network with the IP address 10.1.1.1/24 without authentication.

```
<HUAWEI> system-view  
[HUAWEI] free-rule-template name default_free_rule  
[HUAWEI-free-rule-default_free_rule] free-rule 1 destination ip 10.1.1.1 mask 24 source ip any
```

13.4.114 free-rule-template (authentication profile view)

Function

The **free-rule-template** command binds an authentication-free rule profile to an authentication profile.

The **undo free-rule-template** command unbinds an authentication-free rule profile from an authentication profile.

By default, no authentication-free rule profile is bound to an authentication profile.

NOTE

This function is supported only by S5720HI.

Format

free-rule-template *free-rule-template-name*

undo free-rule-template

Parameters

Parameter	Description	Value
<i>free-rule-template-name</i>	Specifies the name of an authentication-free rule profile.	The value must be the name of an existing authentication-free rule profile.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Before being authenticated, users need to obtain some network access rights to meet basic network access requirements such as downloading the 802.1X client and updating antivirus database. The device uses an authentication-free rule profile to uniformly manage authorization information for authentication-free users. You can define some network access rules in the profile to determine network access rights that can be obtained by authentication-free users. You need to bind a configured authentication-free rule profile to an authentication profile. Users using the authentication profile then can obtain authentication-free authorization information.

Prerequisites

An authentication-free rule profile has been created using the [13.4.115 free-rule-template \(system view\)](#) command.

When a large number of APs are online, do not run the **free-rule-template** or **undo free-rule-template** command repeatedly because the device takes time to execute the command. Otherwise, users cannot go online or offline properly in a short period of time.

Example

Bind the authentication-free rule profile **default_free_rule** to the authentication profile **p1**.

```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name p1  
[HUAWEI-authen-profile-p1] free-rule-template default_free_rule
```

Related Topics

[13.4.61 display authentication-profile configuration](#)

[13.4.67 display free-rule-template configuration](#)

13.4.115 free-rule-template (system view)

Function

The **free-rule-template** command creates an authentication-free rule profile and displays the authentication-free rule profile view.

By default, the device has a built-in authentication-free rule profile named `default_free_rule`.

Format

free-rule-template name *free-rule-template-name*

Parameters

Parameter	Description	Value
name <i>free-rule-template-name</i>	Specifies the name of an authentication-free rule profile.	Currently, the device supports only one authentication-free rule profile, that is, the built-in profile default_free_rule .

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To meet basic network access requirements of users who have not passed authentication, the users need to obtain some network access rights without authentication, for example, download 802.1X client software and update the antivirus database. After creating an authentication-free rule profile using the **free-rule-template** command, you can configure authentication-free rules in the profile to allow the users to access the specified network resources without authentication.

Follow-up Procedure

Run the [13.4.113 free-rule](#) command in the authentication-free rule profile view to configure authentication-free rules for users.

Precautions

Currently, the device supports only one authentication-free rule profile, that is, the built-in profile **default_free_rule**.

For wireless users, the configured authentication-free rule in an authentication-free rule profile takes effect only after the profile is bound to an authentication profile using the [13.4.114 free-rule-template \(authentication profile view\)](#) command in the authentication profile view.

For wired users, an authentication-free rule profile takes effect for all wired users after it is created in the system view. The authentication-free rule profile does not need to be bound to an authentication profile using the [13.4.114 free-rule-template \(authentication profile view\)](#) command in the authentication profile view.

Example

```
# Display the view of the authentication-free rule profile default_free_rule.
```

```
<HUAWEI> system-view  
[HUAWEI] free-rule-template name default_free_rule  
[HUAWEI-free-rule-default_free_rule]
```

Related Topics

[13.4.67 display free-rule-template configuration](#)

13.4.116 http parse user-agent enable

Function

The **http parse user-agent enable** command enables the UA function.

The **undo http parse user-agent enable** command disables the UA function.

By default, the UA function is disabled.

NOTE

This function is supported only by S5720HI.

Format

http parse user-agent enable

undo http parse user-agent enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

User Agent (UA) is a field in the HTTP packet header. The UA field carries information including the operating system used by the device and device version, the CPU type, the browser and browser version, the language used by the browser, and the browser plug-in.

If the UA function is enabled, the AC extracts the UA field from the HTTP Get packet sent from the terminal that has passed 802.1X or Portal authentication, and analyzes the UA information and combines it with the MAC address and DHCP Option information to finally identify the terminal type.

Precautions

Currently, the device supports the UA of a maximum of 247 characters.

Example

```
# Enable the UA function.
```

```
<HUAWEI> system-view  
[HUAWEI] http parse user-agent enable
```

13.4.117 http get-method enable

Function

The **http get-method enable** command configures the device to allow users to submit user name and password information to the device in GET mode during Portal authentication.

The **undo http get-method enable** command restores the default setting.

By default, the device does not allow users to submit user name and password information to the device in GET mode during Portal authentication.

Format

http get-method enable

undo http get-method enable

Parameters

None

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

By default, the device does not allow users to submit user name and password information to the device in GET mode during Portal authentication. You can run the **http get-method enable** command to configure the device to allow users to submit user name and password information to the device in GET mode during Portal authentication.

Precautions

The GET mode has the risk of password disclosure. Therefore, the POST mode is recommended.

This command only applies to scenarios in which HTTP or HTTPS is used for Portal connection establishment.

Example

Configure the device to allow users to submit user name and password information to the device in GET mode during Portal authentication.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server abc
[HUAWEI-web-auth-server-abc] http get-method enable
```

13.4.118 http-method post

Function

The **http-method post** command configures parameters for parsing and replying to POST or GET request packets of the HTTP or HTTPS protocol.

The **undo http-method post** command restores the default configuration.

By default, the system has configured parameters for parsing and replying to POST or GET request packets of the HTTP or HTTPS protocol. For details, see the "Parameters" table.

Format

```
http-method post { cmd-key cmd-key [ login login-key | logout logout-key ] * |
init-url-key init-url-key | login-fail response { err-msg { authserve-reply-
message | msg msg } | redirect-login-url | redirect-url redirect-url [ append-
reply-message msgkey ] } | login-success response { msg msg | redirect-init-url
| redirect-url redirect-url } | logout-fail response { msg msg | redirect-url
redirect-url } | logout-success response { msg msg | redirect-url redirect-url } |
password-key password-key | user-mac-key user-mac-key | userip-key userip-key
| username-key username-key } *
```

```
undo http-method post { all | { cmd-key | init-url-key | login-fail | login-
success | logout-fail | logout-success | password-key | user-mac-key | userip-
key | username-key } * }
```

Parameters

Parameter	Description	Value
cmd-key <i>cmd-key</i>	Specifies the command identification keyword. The default value is cmd .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
login <i>login-key</i>	Specifies the user login identification keyword. The default value is login .	The value is a string of 1 to 15 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).

Parameter	Description	Value
logout <i>logout-key</i>	Specifies the user logout identification keyword. The default value is logout .	The value is a string of 1 to 15 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
init-url-key <i>init-url-key</i>	Specifies the identification keyword for the user initial login URL. The default value is initurl .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
login-fail response { err-msg { authenserve-reply- message msg <i>msg</i> } redirect-login-url redirect-url <i>redirect-url</i> [append-reply- message <i>msgkey</i>] }	Specifies the response message upon a user login failure. <ul style="list-style-type: none"> • err-msg authenserve-reply-message: The authentication server response message is displayed after a user login failure. • err-msg msg <i>msg</i>: A specified message is displayed after a user login failure. • redirect-login-url: A user is redirected to the login URL after a login failure. This mode is the default mode. • redirect-url <i>redirect-url</i>: A user is redirected to a specified URL after a login failure. • append-reply-message <i>msgkey</i>: specifies the identification keyword for the authentication server response message carried in the redirection URL. 	<ul style="list-style-type: none"> • <i>msg</i>: The value is a string of 1 to 200 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=). • <i>redirect-url</i>: The value is a string of 1 to 200 case-sensitive characters without spaces. • <i>msgkey</i>: The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).

Parameter	Description	Value
login-success response { msg <i>msg</i> redirect-init-url redirect-url <i>redirect-url</i> }	<p>Specifies the response message upon successful user login.</p> <ul style="list-style-type: none"> • msg <i>msg</i>: A specified message is displayed after successful user login. • redirect-init-url: A user is redirected to the initial login URL after successful login. This mode is the default mode. • redirect-url <i>redirect-url</i>: A user is redirected to a specified URL after successful login. 	<ul style="list-style-type: none"> • <i>msg</i>: The value is a string of 1 to 200 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=). • <i>redirect-url</i>: The value is a string of 1 to 200 case-sensitive characters without spaces.
logout-fail response { msg <i>msg</i> redirect-url <i>redirect-url</i> }	<p>Specifies the response message upon a user logout failure.</p> <ul style="list-style-type: none"> • msg <i>msg</i>: A specified message is displayed after a user logout failure. The default value is LogoutFail!. • redirect-url <i>redirect-url</i>: A user is redirected to a specified URL after a logout failure. 	<ul style="list-style-type: none"> • <i>msg</i>: The value is a string of 1 to 200 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=). • <i>redirect-url</i>: The value is a string of 1 to 200 case-sensitive characters without spaces.
logout-success response { msg <i>msg</i> redirect-url <i>redirect-url</i> }	<p>Specifies the response message upon successful user logout.</p> <ul style="list-style-type: none"> • msg <i>msg</i>: A specified message is displayed after successful user logout. The default value is LogoutSuccess!. • redirect-url <i>redirect-url</i>: A user is redirected to a specified URL after successful logout. 	<ul style="list-style-type: none"> • <i>msg</i>: The value is a string of 1 to 200 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=). • <i>redirect-url</i>: The value is a string of 1 to 200 case-sensitive characters without spaces.

Parameter	Description	Value
password-key <i>password-key</i>	Specifies the password identification keyword. The default value is password .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
user-mac-key <i>user-mac-key</i>	Specifies the identification keyword for the user MAC address. The default value is macaddress .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
userip-key <i>userip-key</i>	Specifies the identification keyword for the user IP address. The default value is ipaddress .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
username-key <i>username-key</i>	Specifies the user name identification keyword. The default value is username .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
all	Indicates all parameters.	-

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

When the device uses the HTTP or HTTPS protocol to communicate with the Portal server, a user sends POST or GET request packets (carrying parameters such as the user name and MAC address) to the device as required by the Portal server. After receiving the POST or GET request packets, the device parses parameters in the packets. If identification keywords of the parameters differ from those configured on the device, the user authentication fails. Therefore, you need to run the **http-method post** command to configure the identification keywords based on the Portal server configuration.

After successful user login or logout, or a user login or logout failure, the device sends the login or logout result to the user based on the **http-method post**

command configuration. For example, the device sends the **LogoutSuccess!** message to a user who logs out successfully by default.

Example

Set the command identification keyword to **cmd1** for parsing POST or GET request packets of the HTTP or HTTPS protocol.

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server abc  
[HUAWEI-web-auth-server-abc] http-method post cmd-key cmd1
```

13.4.119 force-push

Function

The **force-push** command enables the forcible URL template or URL push function.

The **undo force-push** command disables the forcible URL template or URL push function.

By default, the forcible URL template or URL push function is disabled.

Format

force-push { **url-template** *template-name* | **url** *url-address* }

undo force-push

Parameters

Parameter	Description	Value
url-template <i>template-name</i>	Specifies the name of a pushed URL template.	The value must be the name of an existing URL template.
url <i>url-address</i>	Specifies a pushed URL.	It is a string of 1 to 200 case-sensitive characters that do not contain spaces and question marks (?). When double quotation marks are used around the string, spaces are allowed in the string.

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After a user is successfully authenticated, the device forcibly redirect the user to a web page when receiving the HTTP or HTTPS packet from the user who accesses web pages for the first time. In addition to pushing advertisement pages, the device can obtain user terminal information through the HTTP or HTTPS packets sent by the users, and apply the information to other services. There are two ways to push web pages:

1. URL: pushes the URL corresponding to the web page.
2. URL template: pushes the URL template. A URL template must be created. The URL template contains the URL of the pushed web page and URL parameters.

Prerequisites

The URL configured using the [13.4.196 url \(URL template view\)](#) command in the URL template view cannot be a redirection URL; otherwise, the command does not take effect.

Precautions

For the S5720HI, the forcible push function takes effect only for the first HTTP or HTTPS packet received from the user. If an application program that actively sends HTTP or HTTPS packets is installed on the user terminal, the terminal has sent the HTTP or HTTPS packet before the user accesses a web page. Therefore, the user is unaware of the web page push process.

The forcible push function takes effect only when a redirection ACL is configured for switches excluding the S5720HI. If a redirection ACL exists in the user table, a web page is forcibly pushed when HTTP packets from users match the redirection ACL rule. Usually, you can configure the RADIUS server to authorize the Huawei extended RADIUS attribute **HW-Redirect-ACL** to users for redirection ACL implementation, or run the [13.1.72 redirect-acl](#) command to configure a redirection ACL.

For HTTP and HTTPS packets, the forcible push function takes effect only when a redirection ACL is used. If the user table always contains redirection ACLs, a web page is forcibly pushed when HTTPS packets from users match redirection ACL rules.

If the switch functions as an AC and the direct forwarding mode is used in a wireless scenario, the forcible web page push function is not supported.

A pushed URL configured in a domain need to be used together with a redirect ACL or push flag attribute. The redirect ACL has a higher priority than the push flag attribute. By default, a pushed URL configured in a domain carries the push flag attribute. Users will be redirected to the pushed URL when they are successfully authenticated.

When an IPv4 redirect ACL is configured for an IPv6 user or an IPv6 redirect ACL is configured for an IPv4 user, the **Push URL content** field in the [13.4.55 display access-user](#) command output displays the pushed URL, but the browser of the user cannot redirect to the pushed URL .

Switches except the S5720HI do not support concurrent use of the pushed URL and redirection ACL6 functions. If both functions are configured, the **Push URL**

content field in the [13.4.55 display access-user](#) command output displays the pushed URL; however, the terminal browser cannot be redirected to the pushed URL.

Example

Push the URL template **abc** in the domain **huawei**.

```
<HUAWEI> system-view
[HUAWEI] url-template name abc
[HUAWEI-url-template-abc] quit
[HUAWEI] aaa
[HUAWEI-aaa] domain huawei
[HUAWEI-aaa-domain-huawei] force-push url-template abc
```

13.4.120 if-match vlan-id

Function

The **if-match vlan-id** command configures the VLAN ID-based user identification policy.

The **undo if-match vlan-id** command deletes the VLAN ID-based user identification policy.

By default, no VLAN ID-based user identification policy is configured.

Format

if-match vlan-id { *start-vlan-id* [**to** *end-vlan-id*] } &<1-10>

undo if-match vlan-id { *start-vlan-id* [**to** *end-vlan-id*] } &<1-10>

Parameters

Parameter	Description	Value
<i>start-vlan-id</i> [to <i>end-vlan-id</i>]	Specifies the start and end user VLAN IDs. The value of <i>end-vlan-id</i> must be greater than that of <i>start-vlan-id</i> . If the parameter to <i>end-vlan-id</i> is not specified, users are classified based on the VLAN ID specified by <i>start-vlan-id</i> .	The value of <i>start-vlan-id</i> or <i>end-vlan-id</i> is an integer that ranges from 1 to 4094.

Views

User context profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

On some enterprise networks, VLANs are used to divide the entire network into different areas with various security levels. The administrator requires that a user should obtain different network access rights when the user connects to the network from different areas. In this case, the user context identification function can be enabled on access devices, and a group of VLANs that belong to the same area are added to the same user context profile. The administrator then assigns the mapping network access rights to different user context profiles based on the security level of each area. When a user connects to the network from different areas, the user is added to different user context profiles matching their access VLANs and therefore obtains different network access rights.

Prerequisites

A user context profile has been created using the [access-context profile name profile-name](#) command in the system view.

Precautions

This function takes effect only for users who go online after this function is successfully configured.

Example

In the user context profile **p1**, configure the user identification policy of matching users in VLAN 10 to VLAN 20.

```
<HUAWEI> system-view  
[HUAWEI] access-context profile name p1  
[HUAWEI-access-context-p1] if-match vlan-id 10 to 20
```

13.4.121 if-match

Function

The **if-match** command configures the matching mode of terminal type identification rules.

The **undo if-match** command deletes the matching mode of terminal type identification rules.

By default, no matching mode of terminal type identification rules is configured.

NOTE

This function is supported only by S5720HI.

Format

if-match rule *rule-id* [{ **and** | **or** } **rule** *rule-id*] &<1-7>

undo if-match

Parameters

Parameter	Description	Value
rule <i>rule-id</i>	Specifies the ID of a terminal type identification rule.	The value is an integer that ranges from 0 to 7.
and	Specifies the matching mode as "and" (that is, a terminal type can be identified only when the terminal information matches all rules configured).	-
or	Specifies the matching mode as "or" (that is, a terminal type can be identified when the terminal information matches any of the rules).	-

Views

Terminal type identification profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The **if-match** command allows you to flexibly combine terminal type identification rules.

Prerequisite

The specified terminal type identification rules have been configured using the **rule** command.

Precautions

If the parameter is specified as **and** and the terminal information does not match the first rule, the AC sends a matching failure response and stops matching the following rules.

The priority of **and** is higher than that of **or**. For example, you run the **if-match rule 1 or rule 2 and rule 3 or rule 4 and rule 5 or rule 6 and rule 7 or rule 0** command. If the terminal information matches any of the five rule combinations, which are rule 1, rule 2 and rule 3, rule 4 and rule 5, rule 6 and rule 7, and rule 0, the matching operation succeeds.

Example

Specify that terminal information must match terminal type identification rule 1.

```
<HUAWEI> system-view  
[HUAWEI] device-profile profile-name huawei  
[HUAWEI-device-profile-huawei] if-match rule 1
```

Related Topics

[13.4.179 rule \(terminal type identification profile view\)](#)

[13.4.62 display device-profile](#)

13.4.122 ip-static-user enable

Function

The **ip-static-user enable** command enables the function of identifying static users through IP addresses.

The **undo ip-static-user enable** command restores the default setting.

By default, the function of identifying static users through IP addresses is disabled, and the device identifies static users through MAC addresses.

NOTE

This command is only supported by the S5720HI.

Format

ip-static-user enable

undo ip-static-user enable

Parameters

None

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

By default, the device identifies static users through MAC addresses. However, a terminal may have one MAC address and multiple IP addresses, for example, a firewall has multiple valid IP addresses that correspond to only one MAC address. The terminal goes online only after the multiple IP addresses pass authentication.

If the device identifies terminals through MAC addresses, entry information about IP addresses that are authenticated later continuously overwrites entry information about IP addresses that are authenticated earlier. As a result, the terminal cannot go online. You can run the **ip-static-user enable** command to enable the function of identifying static users through IP addresses so that terminals with one MAC address and multiple IP addresses can go online.

Prerequisites

A static user has been configured before this function is enabled.

1. A static user has been configured using the **static-user** *start-ip-address* [*end-ip-address*] [**vpn-instance** *vpn-instance-name*] [**ip-user**] [**domain-name** *domain-name* | **interface** *interface-type interface-number* [**detect**] | **mac-address** *mac-address* | **vlan** *vlan-id*] * command.
2. The authentication user name has been configured for the static user using the **static-user username format-include** { **ip-address** | **mac-address** | **system-name** } command.
3. The authentication password has been configured for the static user using the **static-user password cipher** *password* command.

Precautions

- For a terminal with one MAC address and multiple IP addresses, you must configure the terminal as a static user and enable the function of identifying static users through IP addresses so that the terminal can pass authentication and go online. If **ip-user** is not specified when you configure static users, all static users are processed by assuming they have one MAC address and multiple IP addresses. To precisely identify and process static users with one MAC address and multiple IP addresses, specify **ip-user** when configuring these static users.
- The device does not support traffic statistics collection for a terminal with one MAC address and multiple IP addresses.
- Configure wired users before enabling this function.
- This function takes effect only for users who go online after it is configured. After the configuration on an interface is modified, online users on the interface go offline.
- The device supports this function only when the user access mode is **multi-authen**. For details on how to configure the user access mode, see [13.4.35 authentication mode](#).
- Static users who are identified through IP addresses directly go offline after they fail to pass authentication. In this case, the **display access-user (all views)** command cannot display any information about these users, including their states: pre-authentication or authentication failure.
- Static users identified through IP addresses do not support MAC address flapping.
- Static users identified through IP addresses do not support right control during Layer 2 forwarding.
- Static users identified through IP addresses support only IP address-based upstream authorization services (such as authorization UCL, isolation between Layer 3 groups, CAR, and priority for upstream traffic), and do not support downstream authorization services (such as CAR, re-marking action, dynamic authorization VLAN, and HQoS for downstream traffic).

- In the policy association scenario, if the control point mode is set to **open** using the **authentication control-point open** command, the device does not support the function of identifying static users through IP addresses.
- For a terminal with one MAC address and multiple IP addresses, only ARP packets can be used to trigger authentication. Therefore, ensure that the device can perform authentication triggered by ARP packets; for example, the types of packets that can trigger authentication must include ARP.
- If user A with multiple IP addresses and one MAC address is online and then web user B with the same MAC address is successfully authenticated, the entry of user A is overwritten by that of user B. In this case, user A still has network access rights.

Example

Enable the function of identifying static users through IP addresses in the authentication profile **p1**.

```
<HUAWEI> system-view  
[HUAWEI] authentication-profile name p1  
[HUAWEI-authen-profile-p1] ip-static-user enable
```

Related Topics

[13.4.185 static-user](#)

[13.4.187 static-user username format-include](#)

[13.4.186 static-user password](#)

[13.4.82 display static-user](#)

[13.4.61 display authentication-profile configuration](#)

13.4.123 link-down offline delay

Function

The **link-down offline delay** command configures the user logout delay when an interface link is faulty.

The **undo link-down offline delay** command restores the default configuration.

By default, the user logout delay is 10 seconds when an interface link is faulty.

Format

link-down offline delay { *delay-value* | **unlimited** }

undo link-down offline delay

Parameters

Parameter	Description	Value
<i>delay-value</i>	Specifies the user logout delay when an interface link is faulty.	The value is an integer that ranges from 0 to 60, in seconds. If the value is 0, users are logged out immediately when an interface link is faulty.
unlimited	Indicates that users are not logged out when an interface link is faulty.	-

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If a link is faulty, the interface is interrupted and users are directly logged out. To solve this problem, you can configure the user logout delay function. When the interface link is faulty, the users remain online within the delay. In this case, if the link is restored, the users do not need to be re-authenticated. If the users are disconnected after the delay and the link is restored, the users need to be re-authenticated.

Precautions

- This function takes effect only for wired users who go online on Layer 2 physical interfaces that have been configured with NAC authentication.
- To make the function take effect, it is recommended that the configured interval be greater than the time during which the interface is in Up state.

Example

In the authentication profile **p1**, set the user logout delay to 5 seconds when the link is faulty.

```
<HUAWEI> system-view
[HUAWEI] authentication-profile name p1
[HUAWEI-authen-profile-p1] link-down offline delay 5
```

13.4.124 mac-access-profile (authentication profile view)

Function

The **mac-access-profile** command binds an authentication profile to a MAC access profile.

The **undo mac-access-profile** command unbinds an authentication profile from a MAC access profile.

By default, an authentication profile is not bound to a MAC access profile.

Format

mac-access-profile *access-profile-name*

undo mac-access-profile

Parameters

Parameter	Description	Value
<i>access-profile-name</i>	Specifies the name of a MAC access profile.	The value must be the name of an existing MAC access profile.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The authentication type used by an authentication profile is determined by the access profile bound to the authentication profile. After being bound to a MAC access profile, the authentication profile is enabled with MAC address authentication. After the authentication profile is applied to the interface or VAP profile, MAC address authentication can be performed on online users.

Prerequisites

A MAC access profile has been created using the [13.4.125 mac-access-profile \(system view\)](#) command.

Follow-up Procedure

Run the [13.4.42 authentication-profile \(Interface view or VAP profile view\)](#) command to apply the authentication profile to the interface or VAP profile.

Precautions

An authentication profile can be bound to only one MAC access profile.

Example

Bind the authentication profile **mac_authen_profile1** to the MAC access profile **mac_access_profile**.

```
<HUAWEI> system-view
[HUAWEI] mac-access-profile name mac_access_profile
[HUAWEI-mac-access-profile-mac_access_profile] quit
[HUAWEI] authentication-profile name mac_authen_profile1
[HUAWEI-authen-profile-mac_authen_profile1] mac-access-profile mac_access_profile
```

Related Topics

[13.4.61 display authentication-profile configuration](#)

13.4.125 mac-access-profile (system view)

Function

The **mac-access-profile** command creates a MAC access profile and displays the MAC access profile view.

The **undo mac-access-profile** command deletes the MAC access profile.

By default, the device has a built-in MAC access profile named **mac_access_profile**.

Format

mac-access-profile name *access-profile-name*

undo mac-access-profile name *access-profile-name*

Parameters

Parameter	Description	Value
name <i>access-profile-name</i>	Specifies the name of a MAC access profile.	The value is a string of 1-31 case-sensitive characters, which cannot be configured to - and --. It cannot contain spaces and the following symbols: / \ : * ? " < > @ ' %.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device uses MAC access profiles to uniformly manage all MAC users access configurations. To perform MAC address authentication for the users in the interface or VAP profile, bind the authentication profile applied to the interface or VAP profile to a MAC access profile.

Follow-up Procedure

Run the [13.4.124 mac-access-profile \(authentication profile view\)](#) command in the authentication profile view to bind the authentication profile to a MAC access profile.

Precautions

- The compatibility profile converted after an upgrade is not counted in the configuration specification. The built-in MAC access profile **mac_access_profile** can be modified and applied, but cannot be deleted.
- Before deleting a MAC access profile, ensure that this profile is not bound to any authentication profile.

Example

```
# Create the MAC access profile named mac_access_profile.
```

```
<HUAWEI> system-view  
[HUAWEI] mac-access-profile name mac_access_profile
```

Related Topics

[13.4.70 display mac-access-profile configuration](#)

13.4.126 mac-authen offline dhcp-release

Function

The **mac-authen offline dhcp-release** command enables the device to clear user entries when receiving DHCP Release packets from MAC address authentication users.

The **undo mac-authen offline dhcp-release** command restores the default configuration.

By default, the device does not clear user entries when receiving DHCP Release packets from MAC address authentication users.

Format

mac-authen offline dhcp-release

undo mac-authen offline dhcp-release

Parameters

None

Views

MAC access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After MAC address authentication users who send DHCP Release packets go offline, the corresponding user entries on the device cannot be deleted immediately. This occupies device resources and possibly prevents other users from going online. You can run this command to enable the device to clear the user entries in real time when MAC address authentication users go offline.

Precautions

MAC address authentication users who go online through VLANIF interfaces do not support this function.

If the device functions as a DHCP relay agent, configure the DHCP snooping function on the device; otherwise, this command does not take effect.

This function takes effect only in L2 BNG scenarios.

Example

In the MAC access profile **m1**, enable the device to clear user entries when receiving DHCP Release packets from MAC address authentication users.

```
<HUAWEI> system-view
[HUAWEI] mac-access-profile name m1
[HUAWEI-mac-access-profile-m1] mac-authen offline dhcp-release
```

13.4.127 mac-authen permit mac-address

Function

The **mac-authen permit mac-address** command specifies the MAC address range allowed for MAC address authentication.

The **undo mac-authen permit mac-address** command deletes the MAC address range allowed for MAC address authentication.

By default, no MAC address range is specified for MAC address authentication.

NOTE

Only S5720EI, S1720X, S1720X-E, S5720HI, S5720S-SI, S5720SI, S5730S-EI, S5730SI, S6720LI, S6720S-LI, S6720S-SI, S6720SI, S6720EI, and S6720S-EI support this command.

Format

mac-authen permit mac-address *mac-address* **mask** { *mask* | *mask-length* }

undo mac-authen permit mac-address *mac-address* **mask** { *mask* | *mask-length* }

Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies a MAC address for MAC address authentication.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.
mask <i>mask</i>	Specifies the MAC address mask.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.
mask <i>mask-length</i>	Specifies the MAC address mask length.	The value is an integer that ranges from 1 to 48.

Views

MAC access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If a new MAC address entry is generated on the device after MAC address authentication is enabled on a VLANIF interface, MAC address authentication will be performed for the corresponding user. To actually control the users who can be authenticated using MAC addresses on the VLANIF interface, use this command to specify a MAC address range for MAC address authentication.

Precautions

Only MAC address authentication users who go online through VLANIF interfaces support this function.

A maximum of eight MAC address ranges are allowed for MAC address authentication on a VLANIF interface.

Example

In the MAC access profile **m1**, set the MAC address to 0002-0002-0002 and the MAC address mask length to 24 for MAC address authentication.

```
<HUAWEI> system-view  
[HUAWEI] mac-access-profile name m1  
[HUAWEI-mac-access-profile-m1] mac-authen permit mac-address 0002-0002-0002 mask 24
```

13.4.128 mac-authen quiet-times

Function

The **mac-authen quiet-times** command configures the maximum number of authentication failures within 60 seconds before a MAC address authentication user enters the quiet state.

The **undo mac-authen quiet-times** command restores the maximum number of authentication failures to the default value.

By default, the maximum number of authentication failures is 10.

Format

mac-authen quiet-times *fail-times*

undo mac-authen quiet-times

Parameters

Parameter	Description	Value
<i>fail-times</i>	Specifies the maximum number of authentication failures before a MAC address authentication user enters the quiet state.	The value is an integer that ranges from 1 to 10.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The quiet function for MAC address authentication is enabled on a device by default. When the maximum number of authentication failures exceeds 10 within 60 seconds, the device quiets a MAC address authentication user and does not process authentication requests from the user, reducing impact on the system caused by attackers.

Precautions

After the maximum number of authentication failures is set to a value larger than the configured value, the user in quiet state can initiate reauthentication only after the quiet period expires. If the user enters an incorrect user name or password again, the user authentication fails. The device does not quiet the user but allows the user to initiate reauthentication immediately.

The quiet function for MAC address authentication users takes effect only after the pre-connection function is disabled using the **undo authentication pre-authen-access enable** command and the device is disabled from assigning network access rights to users in each phase before authentication succeeds using the **undo authentication event action authorize** command. In multi-mode authentication of MAC address authentication users, the quiet function for MAC address authentication users does not take effect.

Example

```
# Set the maximum number of authentication failures within 60 seconds to 4.
```

```
<HUAWEI> system-view  
[HUAWEI] mac-authen quiet-times 4
```

13.4.129 mac-authen reauthenticate mac-address

Function

The **mac-authen reauthenticate mac-address** command enables re-authentication for an online MAC address authentication user with a specified MAC address.

By default, re-authentication for an online MAC address authentication user with a specified MAC address is disabled.

Format

mac-authen reauthenticate mac-address *mac-address*

Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies all valid unicast MAC addresses.	The value is a unicast MAC address in H-H-H format, where H can be one to four hexadecimal digits.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

For details, see [13.4.130 mac-authen reauthenticate](#).

The **mac-authen reauthenticate mac-address** and [13.4.130 mac-authen reauthenticate](#) commands re-authenticate online MAC address authentication users and their difference is as follows:

- The **mac-authen reauthenticate mac-address** command configures the device to immediately re-authenticate a user with a specified MAC address for once.
- The [13.4.130 mac-authen reauthenticate](#) command configures the device to re-authenticate all online MAC address authentication users at intervals.

Example

```
# Enable re-authentication for an online MAC address authentication user with  
the MAC address 0001-0002-0003.
```

```
<HUAWEI> system-view  
[HUAWEI] mac-authen reauthenticate mac-address 0001-0002-0003
```

13.4.130 mac-authen reauthenticate

Function

The **mac-authen reauthenticate** command enables re-authentication for online MAC address authentication users.

The **undo mac-authen reauthenticate** command restores the default configuration.

By default, re-authentication for online MAC address authentication users is disabled.

Format

mac-authen reauthenticate

undo mac-authen reauthenticate

Parameters

None

Views

MAC access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the administrator modifies the authentication parameters of an online user on the authentication server, the user must be re-authenticated to ensure user validity.

After the user goes online, the device saves authentication parameters of the user. After re-authentication is configured for online MAC address authentication users, the device automatically sends the user authentication parameters in the MAC access profile to the authentication server at an interval (specified using the **13.4.133 mac-authen timer reauthenticate-period** command) for re-authentication. If the user authentication information on the authentication server remains unchanged, the users are kept online. If the information has been changed, the users are disconnected and need to be re-authenticated based on the changed authentication parameters.

Precautions

After periodic re-authentication is configured for online MAC address authentication users, a large number of MAC address authentication logs are generated.

MAC address authentication users who go online through a VLANIF interface do not support re-authentication.

If the device is connected to a server for re-authentication and the server replies with a re-authentication deny message that makes an online user go offline, it is recommended that you locate the cause of the re-authentication failure on the server or disable the re-authentication function on the device.

Example

In the MAC access profile **mac_access_profile**, configure re-authentication for online MAC address authentication users.

```
<HUAWEI> system-view
[HUAWEI] mac-access-profile name mac_access_profile
[HUAWEI-mac-access-profile-mac_access_profile] mac-authen reauthenticate
```

Related Topics

[13.4.70 display mac-access-profile configuration](#)

13.4.131 mac-authen reauthenticate dhcp-renew

Function

The **mac-authen reauthenticate dhcp-renew** command enables the device to re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users.

The **undo mac-authen reauthenticate dhcp-renew** command restores the default setting.

By default, the device does not re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users.

Format

mac-authen reauthenticate dhcp-renew
undo mac-authen reauthenticate dhcp-renew

Parameters

None

Views

MAC access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After users go online, the administrator may modify the users' authentication parameters or network access rights on the authentication server. To ensure user validity or update the users' network access rights in real time, you can run this command to enable the device to re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users.

Precautions

MAC address authentication users who go online through a VLANIF interface do not support re-authentication.

This function applies only to Layer 2 BNG scenarios.

Example

In the MAC access profile **m1**, enable the device to re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users.

```
<HUAWEI> system-view  
[HUAWEI] mac-access-profile name m1  
[HUAWEI-mac-access-profile-m1] mac-authen reauthenticate dhcp-renew
```

13.4.132 mac-authen timer quiet-period

Function

The **mac-authen timer quiet-period** command configures the quiet period for MAC address authentication users who fail to be authenticated.

The **undo mac-authen timer quiet-period** command restores the default quiet period.

By default, the quiet period is 60 seconds for MAC address authentication users who fail to be authenticated.

Format

mac-authen timer quiet-period *quiet-period-value*

undo mac-authen timer quiet-period

Parameters

Parameter	Description	Value
<i>quiet-period-value</i>	Sets the quiet period for MAC address authentication users who fail to be authenticated.	The value is an integer that ranges from 0 to 3600, in seconds. NOTE If the value of <i>quiet-period-value</i> is 0, the quiet function is disabled for MAC address authentication users.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

If a MAC address authentication user fails to be authenticated consecutively within a short period, the system is affected and a large number of duplicated authentication failure logs are generated.

After the quiet function is enabled, if the number of times that a MAC address authentication user fails to be authenticated within 60s exceeds the upper limit (configured using the [13.4.128 mac-authen quiet-times](#) command), the device discards the user's MAC address authentication request packets for a period to avoid frequent authentication failures.

NOTE

The quiet function for MAC address authentication users takes effect only after the pre-connection function is disabled using the [undo authentication pre-authen-access enable](#) command and the device is disabled from assigning network access rights to users in each phase before authentication succeeds using the [undo authentication event action authorize](#) command. In multi-mode authentication of MAC address authentication users, the quiet function for MAC address authentication users does not take effect.

Example

```
# Set the quiet period to 100 seconds for MAC address authentication users who fail to be authenticated.
```

```
<HUAWEI> system-view  
[HUAWEI] mac-authen timer quiet-period 100
```

13.4.133 mac-authen timer reauthenticate-period

Function

The **mac-authen timer reauthenticate-period** command configures the re-authentication interval for online MAC address authentication users.

The **undo mac-authen timer reauthenticate-period** command restores the default setting.

By default, the re-authentication period is 1800 seconds for online MAC address authentication users.

Format

mac-authen timer reauthenticate-period *reauthenticate-period-value*

undo mac-authen timer reauthenticate-period

Parameters

Parameter	Description	Value
<i>reauthenticate-period-value</i>	Specifies the interval for re-authenticating online MAC address authentication users.	The value is an integer that ranges from 60 to 7200, in seconds.

Views

MAC access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After configuring the re-authentication function for online MAC address authentication users using the [13.4.130 mac-authen reauthenticate](#) command, run the **mac-authen timer reauthenticate-period** command to configure the re-authentication interval. The device then re-authenticates online users at the specified interval, ensuring that only authorized users can keep online.

Precautions

Generally, the default re-authentication interval is recommended. If many ACL rules need to be delivered during user authorization, to improve the device processing performance, you are advised to disable re-authentication or increase

the re-authentication interval. When remote authentication and authorization are used and a short re-authentication interval is used, the CPU usage may become high.

MAC address authentication users who go online through a VLANIF interface do not support re-authentication.

To reduce the impact on the device performance when many users exist, the user re-authentication interval may be longer than the configured re-authentication interval.

Example

In the MAC access profile **mac_access_profile**, configure the re-authentication interval for online MAC address authentication users to 2000 seconds.

```
<HUAWEI> system-view  
[HUAWEI] mac-access-profile name mac_access_profile  
[HUAWEI-mac-access-profile-mac_access_profile] mac-authen timer reauthenticate-period 2000
```

Related Topics

[13.4.130 mac-authen reauthenticate](#)

[13.4.70 display mac-access-profile configuration](#)

13.4.134 mac-authen username

Function

The **mac-authen username** command configures the user name for MAC address authentication.

The **undo mac-authen username** command restores the default setting.

By default, the MAC address without hyphens (-) is used as the user name and password for MAC address authentication.

Format

```
mac-authen username { fixed username [ password cipher password ] |  
macaddress [ format { with-hyphen [ normal ] | without-hyphen }  
[ uppercase ] [ password cipher password ] ] | dhcp-option option-code  
{ circuit-id | remote-id } * [ separate separate ] [ format-hex ] password cipher  
password }
```

```
undo mac-authen username [ fixed username [ password cipher password ] |  
macaddress [ format { with-hyphen [ normal ] | without-hyphen }  
[ uppercase ] [ password cipher password ] ] | dhcp-option option-code  
[ circuit-id | remote-id ] * [ password cipher password ] ]
```

Parameters

Parameter	Description	Value
fixed <i>username</i>	Specifies a fixed user name for MAC address authentication.	The value is a string of 1 to 64 case-sensitive characters without spaces. When double quotation marks are used around the string, spaces are allowed in the string.

Parameter	Description	Value
<p>password cipher <i>password</i></p>	<p>Specifies the password in cipher text for MAC address authentication.</p> <ul style="list-style-type: none"> • If no password is set when a fixed user name is used, the user can log in without a password. This brings a security risk and is not recommended. • If no password is set when the MAC address is used as the user name, the user can log in using the MAC address as the password. A password must be configured when local authentication is used in the AAA scheme. • The password must be configured when the user name for MAC address authentication is in the DHCP option format. 	<p>The value is a string of case-sensitive characters without spaces. The password is either a plain-text string of 1 to 128 characters or a cipher-text string of 48 to 188 characters. When double quotation marks are used around the string, spaces are allowed in the string.</p> <p>NOTE For security purposes, change the default password in real time. The new password must be a combination of at least two of the following: digits, lowercase letters, uppercase letters, and special characters. In addition, the password must consist of six or more than six characters.</p>

Parameter	Description	Value
macaddress	Specifies the MAC address as the user name for MAC address authentication.	-
format { with-hyphen [normal] without-hyphen }	Specifies the MAC address format. <ul style="list-style-type: none"> • with-hyphen: indicates that the MAC address contains hyphens (-), for example, 0005-e01c-02e3. • with-hyphen normal: indicates that the MAC address contains hyphens (-), for example, 00-05-e0-1c-02-e3. • without-hyphen: indicates that the MAC address does not contain hyphens (-), for example, 0005e01c02e3. 	-
uppercase	Indicates that the name of a MAC address authentication user is in uppercase.	-
dhcp-option <i>option-code</i>	Specifies the name of the MAC address authentication user to a specified DHCP option. <ul style="list-style-type: none"> • circuit-id: Specifies the circuit ID in the DHCP Option82 field as the user name in MAC address authentication. • remote-id: Specifies the remote ID in the DHCP Option82 field as the user name in MAC address authentication. <p>If both circuit-id and remote-id are configured, the user name for MAC address authentication can be set to a character string that is a combination of the circuit-id and remote-id in the DHCP Option82 field.</p>	The value is an integer. In the current version, the value is fixed as 82.
separate <i>separate</i>	Specifies the delimiter in the user name for MAC address authentication. This parameter is configured when the user name for MAC address authentication is set to a character string that is a combination of the circuit-id and remote-id in the DHCP Option82 field.	The value is a character and can be set to a letter, digit, or another valid character.

Parameter	Description	Value
format-hex	Indicates that the user name for MAC address authentication is in hexadecimal format.	-

Views

MAC access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The following user name formats are available for MAC address authentication:

- Fixed user name: A user uses the fixed user name and password configured by the administrator for authentication.
- MAC address: A user uses the MAC address as the user name for authentication. In addition, the MAC address or user-defined character string can be used as the password.
- When the DHCP option format is used for MAC address authentication, the device uses the DHCP option it obtains and password set by the administrator for authentication. In this mode, ensure that the device supports MAC address authentication triggered through DHCP packets.

By default, the device sends the user MAC address as the user name and password to the authentication server for authentication. However, the users cannot be easily identified and managed in this case. To flexibly identify and manage users, run the **mac-authen username** command to configure fixed user names and passwords for MAC address authentication users.

Precautions

- When configuring the user name format for MAC address authentication, ensure that the authentication server supports the user name format.
- If MAC address authentication is enabled on a VLANIF interface, on an Eth-Trunk, in a port group, or in a VAP profile, and MAC address authentication users use fixed user names, passwords must be configured. If MAC address authentication is enabled in a port group and MAC addresses are used as user names, passwords cannot be configured. If MAC address authentication is enabled on a VLANIF interface or in a VAP profile, user names for MAC address authentication cannot be set to specified DHCP option information.
- When the user names for MAC address authentication are in the DHCP option format, the DHCP Option82 cannot be configured in the extend format or a customized format (non character string) by using the [14.8.6 dhcp option82 format](#) command.

Example

In the MAC access profile **mac_access_profile**, configure the device to use the MAC address containing hyphens (-) as the user name.

```
<HUAWEI> system-view
[HUAWEI] mac-access-profile name mac_access_profile
[HUAWEI-mac-access-profile-mac_access_profile] mac-authen username macaddress format with-hyphen
```

Related Topics

[13.4.70 display mac-access-profile configuration](#)

13.4.135 match access-context-profile action

Function

The **match access-context-profile action** command configures the network access rights for specified users in each phase before authentication success based on user context profiles.

The **undo match access-context-profile action** command deletes the configured network access rights.

By default, no network access right is configured for specified users in each phase before authentication success.

Format

match access-context-profile *profile-name* **action** { **authen-fail** **service-scheme** *service-scheme-name* | **authen-server-down** **service-scheme** *service-scheme-name* | **authen-server-up** **re-authen** | **client-no-response** **service-scheme** *service-scheme-name* | **portal-server-down** **service-scheme** *service-scheme-name* | **portal-server-up** **re-authen** | **pre-authen** **service-scheme** *service-scheme-name* } *

undo match access-context-profile *profile-name* **action** { **authen-fail** | **authen-server-down** | **authen-server-up** | **client-no-response** | **portal-server-down** | **portal-server-up** | **pre-authen** } *

Parameters

Parameter	Description	Value
<i>profile-name</i>	Specifies the name of a user context profile.	The value must be the name of an existing user context profile.
authen-fail	Configures the device to assign network access rights to users when the authentication server sends authentication failure packets to the device.	-

Parameter	Description	Value
authen-server-down	Configures the device to assign network access rights to users when the authentication server is unreachable and thereby the users fail to be authenticated.	-
authen-server-up	Re-authenticates users when the authentication server can be reachable again.	-
client-no-response	Configures the device to assign network access rights to users when clients do not respond and thereby the users fail to be authenticated.	-
portal-server-down	Configures the device to assign network access rights to users when the Portal server is unreachable and thereby the users fail to be authenticated.	-
portal-server-up	Re-authenticates users when the Portal server can be reachable again.	-
pre-authen	Configures the device to assign network access rights to users when the users establish pre-connections with the device.	-
re-authen	Re-initializes user rights.	-
service-scheme <i>service-scheme-name</i>	Specifies the name of the service scheme based on which network access rights are assigned to users.	The value must be the name of an existing service scheme name on the device.

Views

User authentication event authorization policy view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Users need basic network access rights before they are authenticated. For example, the users need to download 802.1X clients and update the antivirus database. A user authentication event authorization policy can be used to bind the network access rights of users in each phase before authentication success to a user context profile. When a user goes online after a user authentication event authorization policy is applied to the device, the device adds the user to the context profile based on the user context identification result, and assigns the network access rights to the user based on the user authentication result. The **match access-context-profile action** command can be used to configure the network access rights for users in each phase (including an authentication failure, an authentication server fault, and no response from the users) before authentication success.

Prerequisites

- A service scheme has been created using the **service-scheme** command in the AAA view.
- A user context profile has been created using the **access-context profile name profile-name** command in the system view.

Follow-up Procedure

In the global view, run the **access-author policy global** command to apply the user authentication event authorization policy.

Precautions

The priority of user authorization based on a user context profile is higher than that of user authorization in an authentication profile.

This function takes effect only for users who go online after this function is successfully configured.

Example

Match the user authentication event authorization policy **a1** with the identification result of the user context profile **p1**, and use the service scheme **s1** to authorize the users who fail to be authenticated.

```
<HUAWEI> system-view
[HUAWEI] access-context profile name p1
[HUAWEI-access-context-p1] quit
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme s1
[HUAWEI-aaa-service-s1] quit
[HUAWEI-aaa] quit
[HUAWEI] access-author policy name a1
[HUAWEI-access-author-a1] match access-context-profile p1 action authen-fail service-scheme s1
```

13.4.136 match access-context-profile action access-domain

Function

The **match access-context-profile action access-domain** command configures the access user's authentication domain based on the user context profile.

The **undo match access-context-profile action access-domain** command deletes the access user's authentication domain based on the user context profile.

By default, no access user's authentication domain is configured based on the user context profile.

Format

match access-context-profile *profile-name* **action access-domain** *domain-name*
[**dot1x** | **mac-authen** | **portal**] * [**force**]

undo match access-context-profile *profile-name* **action access-domain** *domain-name*
[**dot1x** | **mac-authen** | **portal**] * [**force**]

Parameters

Parameter	Description	Value
<i>profile-name</i>	Specifies the name of the matching user context profile.	The value must be the name of an existing user context profile.
<i>domain-name</i>	Specifies the domain name.	The value must be the name of an existing domain on the device.
dot1x	Specifies a default or forcible domain for 802.1X authentication users.	-
mac-authen	Specifies a default or forcible domain for MAC address authentication users.	-
portal	Specifies a default or forcible domain for Portal authentication users.	-
force	Specifies the configured domain as a forcible domain. If this parameter is not specified, the configured domain is a default domain.	-

Views

User authentication event authorization policy view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In some enterprise networks, VLAN is divided into multiple areas with different security levels. The administrator assigns different network access rights to access users in different areas. The device uses the domain to manage users, so the access user's authentication domain can be configured based on the user context profile. Based on different context profiles matching with access VLANs, users in different areas have different authentication domains and are assigned different network access rights.

Prerequisites

- A domain has been configured using the [13.1.47 domain \(AAA view\)](#) command in the AAA view.
- A user context profile has been configured using the [access-context profile name profile-name](#) command in the system view.

Precautions

The priorities of the forcible domain, domain carried in the user name, and default domain in different views are as follows in descending order: forcible domain with a specified authentication mode in an authentication profile > forcible domain in an authentication profile > forcible domain with a specified authentication mode based on a user context profile > forcible domain based on a user context profile > domain carried in the user name > default domain with a specified authentication mode in an authentication profile > default domain in an authentication profile > default domain with a specified authentication mode based on a user context profile > default domain based on a user context profile > global default domain.

Example

In the user authentication event authorization policy view, configure the user's forcible domain **huawei** based on the user context profile **p1**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain huawei
[HUAWEI-aaa-domain-huawei] quit
[HUAWEI-aaa] quit
[HUAWEI] access-context profile name p1
[HUAWEI-access-context-p1] quit
[HUAWEI] access-author policy name a1
[HUAWEI-access-author-a1] match access-context-profile p1 action access-domain huawei force
```

13.4.137 parameter

Function

The **parameter** command sets the characters used in URL.

The **undo parameter** command restores the default settings.

By default, the start character is ?, assignment character is =, and delimiter is &.

Format

parameter { **start-mark** *parameter-value* | **assignment-mark** *parameter-value* | **isolate-mark** *parameter-value* } *

undo parameter { **start-mark** *parameter-value* | **assignment-mark** *parameter-value* | **isolate-mark** *parameter-value* } *

Parameters

Parameter	Description	Value
start-mark <i>parameter-value</i>	Changes the specified start character to ?.	The value is one case-sensitive character without spaces.
assignment-mark <i>parameter-value</i>	Specifies the assignment character of the URL parameters.	The value is one case-sensitive character without spaces.
isolate-mark <i>parameter-value</i>	Specifies the delimiter between URL parameters.	The value is one case-sensitive character without spaces.

Views

URL template view

Default Level

2: Configuration level

Usage Guidelines

The **parameter** command allows you to customize the characters in URL.

For example, if the URL configured using the [13.4.196 url \(URL template view\)](#) command in the URL template bound to a Portal server profile is http://10.1.1.1, you can run the [13.4.199 url-parameter](#) command to add the user MAC address, user IP address, and device system name to the URL by specifying the **user_mac**, **user_ip**, and **device** parameters.

When a user with IP address 10.1.1.11 and MAC address 0002-0002-0002 connects to an access device **huawei**, the access device redirects the user to http://10.1.1.1?user_mac=0002-0002-0002&user_ip=10.1.1.11&device=huawei for Portal authentication. In the redirection URL, ? is the default start character, = is the default assignment character, & is the delimiter between parameters.

NOTE

If *parameter-value* is set to a question mark (?) in the URL, the command cannot be executed.

Example

Change the start character in a URL from # to ?.

```
<HUAWEI> system-view
[HUAWEI] url-template name huawei
[HUAWEI-url-template-huawei] parameter start-mark #
```

13.4.138 port (Portal server profile view)

Function

The **port** command sets the port number that a Portal server uses to receive notification packets from the device.

The **undo port** command restores the default port number.

By default, a Portal server uses port number 50100 to receive packets from the device.

Format

port *port-number* [all]

undo port [all]

Parameters

Parameter	Description	Value
<i>port-number</i>	Specifies the port number that the Portal server uses to receive and encapsulate UDP packets from the device.	The value is an integer that ranges from 1 to 65535. By default, the value is 50100.
all	Indicates that the device always uses the destination port number specified by <i>port-number</i> to encapsulate UDP packets. NOTE After this keyword is specified, when receiving UDP packets from a Portal server, the device does not obtain the source port number in the UDP packets as the destination port number of UDP packets to be sent to the Portal server. If the value of <i>port-number</i> is different from the source port number of the Portal server, the Portal server cannot receive the UDP packets sent by the device. Therefore, this keyword is not recommended.	-

Views

Portal server profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After creating a Portal server profile on the device using the [13.4.211 web-auth-server \(system view\)](#) command, configure parameters for the template.

Run the **port** command to set the port number that a Portal server uses to receive notification packets from the device. After receiving a Portal authentication request packet from a user, the device sends the packet to the Portal server using the specified destination port number.

Precautions

Ensure that the port number configured on the device is the same as that used by the Portal server.

Example

Set the port number that a Portal server uses to receive packets from the device to 10000 in the Portal server profile **huawei**.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] port 10000
```

Related Topics

[13.4.89 display web-auth-server configuration](#)

[13.4.211 web-auth-server \(system view\)](#)

13.4.139 portal auth-network

Function

The **portal auth-network** command configures the source subnet for Portal authentication.

The **undo portal auth-network** command restores the default setting.

By default, the source subnet for Portal authentication is 0.0.0.0/0, indicating that users in all subnets must pass Portal authentication.

Format

portal auth-network *network-address* { *mask-length* | *mask-address* }

undo portal auth-network { *network-address* { *mask-length* | *mask-address* } | **all** }

Parameters

Parameter	Description	Value
<i>network-address</i>	Specifies a Portal authentication subnet.	The value is in dotted decimal notation.
<i>mask-length</i> <i>mask-address</i>	Specifies the mask length or mask of the Portal authentication subnet. <ul style="list-style-type: none"> <i>mask-length</i>: specifies the mask length. <i>mask-address</i>: specifies the mask. 	<ul style="list-style-type: none"> The value of <i>mask-length</i> is an integer that ranges from 1 to 32. The value of <i>mask-address</i> is in dotted decimal notation.
all	Deletes all Portal authentication subnets.	-

Views

Portal access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the source subnet for Portal authentication is configured, only user packets from the subnet can trigger Portal authentication. If an unauthenticated user is not on a Portal authentication subnet and packets from the user do not match any Portal authentication-free rule, the device discards the user's packets.

Precautions

The command takes effect only for Layer 3 Portal authentication. In Layer 2 Portal authentication, users on all subnets must be authenticated.

Example

In the Portal access profile **p1**, set the source authentication subnet to 10.1.1.0/24.

```
<HUAWEI> system-view
[HUAWEI] portal-access-profile name p1
[HUAWEI-portal-access-profile-p1] portal auth-network 10.1.1.0 24
```

Related Topics

[13.4.77 display portal-access-profile configuration](#)

13.4.140 portal captive-adaptive enable

Function

The **portal captive-adaptive enable** command enables the Captive Network Assistant (CNA) adaptive function for iOS terminals.

The **undo portal captive-adaptive enable** command disables the CNA adaptive function for iOS terminals.

By default, the CNA adaptive function is disabled for iOS terminals.

NOTE

This function is supported only by S5720HI.

Format

portal captive-adaptive enable

undo portal captive-adaptive enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Since WLANs are widely provided, users have a demand for quick and convenient authentication by using applications on mobile terminals, without entering user names and passwords. In such authentication mode, mobile terminals need to automatically display the application-based Portal authentication page and the applications need to communicate with the background server. Therefore, the mobile terminals must be connected to the WLANs during authentication.

iOS terminals such as iPhones, iPads, and iMac computers provide the CNA function. This function automatically detects the network connection status after iOS terminals connect to WLANs. If the network is disconnected, the iOS terminals display a page prompting users to enter user names and passwords. If users do not enter the user names and passwords, the iOS terminals automatically disconnect from the WLANs. As a result, users cannot use applications on iOS terminals for authentication.

To solve the problem, enable the CNA adaptive function so that iOS terminals are redirected to the application-based Portal authentication page when they connect

to WLANs. Users can click the link on the page to start specified applications to perform Portal authentication. If users do not start applications to perform authentication, they can still access authentication-free resources on the WLANs.

Precautions

When applications on iOS mobile terminals are used to perform Portal authentication, you can run only the **portal captive-bypass enable** command to enable the CNA bypass function. After this function is enabled, users who have logged in to the applications can be automatically authenticated and connect to networks, without entering their user names and passwords.

If you run both the **portal captive-adaptive enable** and **portal captive-bypass enable** commands, the command executed later takes effect.

Due to restrictions of iOS 9.3.1, mobile terminals using iOS 9.3.1 cannot connect to WLANs after the CNA adaptive function is enabled. To solve this problem, run the **portal captive-bypass enable** command to enable the CNA bypass function. Terminal users then can be redirected to the application-based Portal authentication page after they open the browser and access a web page.

Authentication-free resources accessed by users cannot contain the URL `captive.apple.com`; otherwise, terminals cannot automatically display the Portal authentication page.

If the Portal authentication page is of the HTTPS type, terminals can automatically display the Portal authentication page only when an HTTPS URL is used and the domain name certificate is valid.

Example

```
# Enable the CNA adaptive function for iOS terminals.
```

```
<HUAWEI> system-view  
[HUAWEI] portal captive-adaptive enable
```

13.4.141 portal captive-bypass enable

Function

The **portal captive-bypass enable** command enables the CNA bypass function for iOS terminals.

The **undo portal captive-bypass enable** command disables the CNA bypass function.

By default, the CNA bypass function is disabled for iOS terminals.

NOTE

This function is supported only by S5720HI.

Format

portal captive-bypass enable

undo portal captive-bypass enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The iOS operating system provides the Captive Network Assistant (CNA) function. With the CNA function, the iOS terminals (including iPhone, iPad, and iMAC) automatically detects wireless network connectivity after associating with a wireless network. If the network connection cannot be set up, the iOS terminals ask users to enter user names and passwords. If users do not enter the user names and passwords, the iOS terminals automatically disconnect from the wireless network.

However, Portal authentication allows users to access certain resources before authentication is successful. If the iOS terminals are disconnected, users cannot access the specified resources. The CNA bypass function addresses this problem. If the users do not enter user names and passwords immediately, the CNA bypass function keeps the iOS terminals online before the Portal authentication is successful. Therefore, the iOS users are allowed to access authentication-free resources.

Precautions

After the CNA bypass function is enabled for iOS terminals, the Portal authentication page will not be automatically displayed for iOS terminals.

Example

Enable the CNA bypass function for iOS terminals.

```
<HUAWEI> system-view  
[HUAWEI] portal captive-bypass enable
```

13.4.142 portal https-redirect enable

Function

The **portal https-redirect enable** command enables HTTPS redirection of Portal authentication.

The **undo portal https-redirect enable** command disables HTTPS redirection of Portal authentication.

By default, HTTPS redirection is disabled for Portal authentication users.

Format

portal https-redirect enable

undo portal https-redirect enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Many well-known websites such as Google and Baidu use Hypertext Transfer Protocol Secure (HTTPS). When users visit these websites, it is required that users should be redirected to the Portal authentication page so that Portal authentication can be performed and the users can normally access the network. If unauthenticated Portal users visit websites using HTTPS after HTTPS redirection of Portal authentication is enabled, the device can redirect the users to the Portal authentication page.

Precautions

- If Portal authentication is triggered when a user visits a website using HTTPS, the browser displays a security prompt. The user needs to click **Continue** to complete Portal authentication.
- Redirection cannot be performed for browsers or websites using HTTP Strict Transport Security (HSTS).
- If the destination port in HTTPS request packets sent by users is an unknown port (443), redirection cannot be performed.
- This function takes effect only for new Portal authentication users.
- This function takes effect only after the Portal server template is created or the IP address of the built-in Portal server is configured.

Example

Enable HTTPS redirection of Portal authentication.

```
<HUAWEI> system-view  
[HUAWEI] portal https-redirect enable
```


13.4.143 portal https-redirect wired enable

Function

The **portal https-redirect wired enable** command enables HTTPS redirection for wired Portal authentication users.

The **undo portal https-redirect wired enable** command disables HTTPS redirection for wired Portal authentication users.

By default, HTTPS redirection is disabled for wired Portal authentication users.

NOTE

This command applies only to test environments, but not commercial environments.

Format

portal https-redirect wired enable

undo portal https-redirect wired enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

To use the function supported by this command, upgrade the switch to V200R013C00SPC500 or a later version.

Example

Enable HTTPS redirection for wired Portal authentication users.

```
<HUAWEI> system-view  
[HUAWEI] portal https-redirect wired enable
```

13.4.144 portal local-server ad-image load

Function

The **portal local-server ad-image load** command loads an advertisement image file to the built-in Portal server login page.

The **undo portal local-server ad-image load** command deletes the advertisement image file loaded to the built-in Portal server login page.

By default, no advertisement image file is loaded to the built-in Portal server login page.

Format

portal local-server ad-image load *ad-image-file*

undo portal local-server ad-image load

Parameters

Parameter	Description	Value
<i>ad-image-file</i>	<p>Specifies the name of an advertisement image file to be loaded to the built-in Portal server login page.</p> <p>The size of the advertisement image file must be equal to or less than 256 KB. A file of 670 x 405 pixels is recommended.</p>	<p>The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i>.</p> <ul style="list-style-type: none"> • <i>drive</i>: indicates the storage device name. • <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~, *, /, \, :, ', and ". • <i>filename</i>: indicates the file name. The jpg and png formats are supported, and the file name extension must be .jpg, .jpeg, or .png. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

There is a blank area on the login page of the default page package used by the built-in Portal server. Users can customize this area by loading an advertisement image file. When the login page needs to be customized based on special requirements, the administrator can upload the user-defined advertisement image file to the device and run the **portal local-server ad-image load** command. After the advertisement image file is loaded, the user-defined advertisement images are displayed on the built-in Portal server login page for authentication.

Prerequisites

The user-defined advertisement image file has been uploaded to the device.

Example

Load the advertisement image file **ad.png** to the built-in Portal server login page.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server ad-image load flash:/ad.png  
Info: The loading process may take a few seconds.Please wait for a moment.  
Info: Load web file successfully.
```

Related Topics

[13.4.75 display portal local-server](#)

13.4.145 portal local-server anonymous

Function

The **portal local-server anonymous** command enables the anonymous login function for users authenticated through the built-in Portal server.

The **undo portal local-server anonymous** command disables the anonymous login function for users authenticated through the built-in Portal server.

By default, the anonymous login function is disabled for users authenticated through the built-in Portal server.

Format

portal local-server anonymous [**redirect-url** *url*]

undo portal local-server anonymous [**redirect-url**]

Parameters

Parameter	Description	Value
redirect-url <i>url</i>	Specifies the redirection URL. The URL is generally used to push advertisement information.	The value is a string of 1 to 200 case-sensitive characters without spaces and question marks (?). If the string is enclosed in double quotation marks (" "), the string can contain spaces.

Views

Portal access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In places such as airports, hotels, cafes, and public recreation places, the anonymous login function allows users to access the network without entering the user name and password, facilitating network service provisioning.

After the anonymous login function is enabled, users are redirected to the login page the first time they access a web page. To connect to the network, users only need to accept terms in the license agreement and click **Login**.

If the **redirect-url** *url* parameter is specified, the web page corresponding to the specified URL will be automatically displayed when anonymous login users access web pages for the first time. This function can be used for advertisement push and users are unaware of the anonymous login process, improving user experience.

Precautions

When anonymous login is configured, it is recommended that you set AAA authentication mode to none authentication.

Example

In the Portal access template **p1**, configure the anonymous login function for users authenticated through the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal-access-profile name p1  
[HUAWEI-portal-access-profile-p1] portal local-server anonymous
```

Related Topics

[13.4.77 display portal-access-profile configuration](#)

13.4.146 portal local-server authentication-method

Function

The **portal local-server authentication-method** command configures the authentication mode for Portal users on the built-in Portal server.

The **undo portal local-server authentication-method** command restores the default authentication mode for Portal users on the built-in Portal server.

By default, the built-in Portal server uses CHAP to authenticate Portal users.

Format

portal local-server authentication-method { chap | pap }

undo portal local-server authentication-method

Parameters

Parameter	Description	Value
chap	Indicates that the built-in Portal server uses CHAP to authenticate Portal users.	-
pap	Indicates that the built-in Portal server uses PAP to authenticate Portal users.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Password Authentication Protocol (PAP) is a two-way handshake authentication protocol. It transmits passwords in plain text format in RADIUS packets.

Challenge Handshake Authentication Protocol (CHAP) is a three-way handshake authentication protocol. It transmits only user names using RADIUS packets, but

does not transmit passwords. CHAP is more secure and reliable than PAP. If high security is required, CHAP is recommended.

Prerequisites

The built-in Portal server function has been enabled globally using the **portal local-server** command.

Example

Configure the built-in Portal server to use PAP to authenticate Portal users.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server authentication-method pap
```

13.4.147 portal local-server background-color

Function

The **portal local-server background-color** command configures the background color of the built-in Portal server login page.

The **undo portal local-server background-color** command cancels the background color configured for the built-in Portal server login page.

By default, no background color of the built-in Portal server login page is configured.

Format

portal local-server background-color *background-color-value*

undo portal local-server background-color

Parameters

Parameter	Description	Value
<i>background-color-value</i>	Specifies the background color of the built-in Portal server login page.	The value is a string that ranges from #000000 to #FFFFFF in the RGB format. The hexadecimal code is used to indicate the page color, and the format is always #DEFABC (A-F and 0-9).

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Users can customize the login page of the default page package used by the built-in Portal server. The administrator can configure the background color of the login page.

Example

Configure the user-defined background color of the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server background-color #AABBCC
```

13.4.148 portal local-server background-image load

Function

The **portal local-server background-image load** command loads a background image file to the built-in Portal server login page.

The **undo portal local-server background-image load** command deletes the background image file loaded to the built-in Portal server login page.

By default, the device has two background images **default-image0** and **default-image1**. The built-in Portal server uses **default-image0** as the background image by default.

Format

```
portal local-server background-image load { background-image-file | default-image1 }
```

```
undo portal local-server background-image load
```

Parameters

Parameter	Description	Value
<i>background-image-file</i>	<p>Specifies the name of the background image file to be loaded to the built-in Portal server login page.</p> <p>The size of the background image file must be equal to or less than 512 KB. A file of 1366 x 768 pixels is recommended.</p>	<p>The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i>.</p> <ul style="list-style-type: none"> • <i>drive</i>: indicates the storage device name. • <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~, *, /, \, :, ', and ". • <i>filename</i>: indicates the file name. The jpg and png formats are supported, and the file name extension must be .jpg, .jpeg, or .png. If you enter only the file name, the system considers that the file is stored in the default directory.
default-image1	Loads the background image default-image1 to the built-in Portal server login page.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Users can customize the login page of the default page package used by the built-in Portal server. Users can customize background images or select the default

ones. When the background image of the login page needs to be customized based on special requirements, the administrator can upload the user-defined background image file to the device and run the **portal local-server background-image load** command. After the image is loaded, the user-defined background image file is displayed on the built-in Portal server login page for authentication.

Prerequisites

The user-defined background image has been uploaded to the device.

Example

Load the background image file **bg.png** to the built-in Portal server login page.

```
<HUAWEI> system-view
[HUAWEI] portal local-server background-image load flash:/bg.png
Info: The loading process may take a few seconds.Please wait for a moment.
Info: Load web file successfully.
```

13.4.149 portal local-server enable

Function

The **portal local-server enable** command enables the built-in Portal server function in a Portal access profile.

The **undo portal local-server enable** command restores the default setting.

By default, the built-in Portal server function is disabled in a Portal access profile.

Format

```
portal local-server enable
undo portal local-server enable
```

Parameters

None

Views

Portal access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In Portal authentication, the device needs to provide the IP address of the Portal server. The device supports external and built-in Portal servers. When the built-in Portal server is required to authenticate users, enable the built-in Portal server function globally and then run the **portal local-server enable** command in the

Portal access profile. Then the built-in Portal server can be used to authenticate the users who use the Portal access profile.

Prerequisites

The built-in Portal server function has been enabled globally using the [13.4.154 portal local-server](#) command.

Example

In the Portal access profile **p1**, enable the built-in Portal server function.

```
<HUAWEI> system-view
[HUAWEI] interface loopback 1
[HUAWEI-LoopBack1] ip address 10.1.1.1 24
[HUAWEI-LoopBack1] quit
[HUAWEI] portal local-server ip 10.1.1.1
[HUAWEI] ssl policy s1
[HUAWEI-ssl-policy-s1] quit
[HUAWEI] portal local-server https ssl-policy s1
[HUAWEI] portal-access-profile name p1
[HUAWEI-portal-access-profile-p1] portal local-server enable
```

Related Topics

[13.4.77 display portal-access-profile configuration](#)

13.4.150 portal local-server ip

Function

The **portal local-server ip** command configures an IP address for the built-in Portal server.

The **undo portal local-server ip** command deletes an IP address of the built-in Portal server.

By default, no IP address is configured for the built-in Portal server.

Format

portal local-server ip *ip-address*

undo portal local-server ip

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies an IP address for the built-in Portal server.	The value is in dotted decimal notation.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When the device is used as a built-in Portal server, you can run the **portal local-server ip** command to configure an IP address for the built-in Portal server. Users are then redirected to the Portal server if they enter URLs that are not located in the free IP subnet.

NOTE

- The IP address assigned to the built-in Portal server must have a reachable route to the user.
- It is recommended that a loopback interface address be assigned to the built-in Portal server because the loopback interface is stable. Additionally, packets destined for loopback interfaces are not sent to other interfaces on the network; therefore, system performance is not deteriorated even if many users request to go online.
- After users go online through the built-in Portal server, if the interface address or interface (non-physical interface) matching the built-in Portal server's IP address is deleted, online users cannot go offline and offline users cannot go online. Therefore, exercise caution when you delete the interface address or interface.

Example

Assign the IP address 10.1.1.1 to the built-in Portal server.

```
<HUAWEI> system-view
[HUAWEI] interface loopback 1
[HUAWEI-LoopBack1] ip address 10.1.1.1 24
[HUAWEI-LoopBack1] quit
[HUAWEI] portal local-server ip 10.1.1.1
```

13.4.151 portal local-server keep-alive

Function

The **portal local-server keep-alive** command configures the heartbeat detection interval and mode of the built-in Portal server.

The **undo portal local-server keep-alive** command cancels the configured heartbeat detection interval and mode of the built-in Portal server.

By default, the heartbeat detection function of the built-in Portal server is not configured.

Format

portal local-server keep-alive interval *interval-value* [**auto**]

undo portal local-server keep-alive

Parameters

Parameter	Description	Value
interval <i>interval-value</i>	Specifies the heartbeat detection interval of the built-in Portal server.	The value is an integer that ranges from 30 to 7200, in seconds.
auto	Specifies the automatic detection mode. If this parameter is not configured, the forcible detection mode is specified.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When a user closes the browser or an exception occurs, the device can detect the user's online state to determine whether to make the user go offline. The administrator can configure the heartbeat detection function of the built-in Portal server. If the device does not receive a heartbeat packet from the client within a specified period, the user is specified to go offline. The heartbeat detection mode of the built-in Portal server can be either of the following modes:

- Forcible detection mode: This mode is valid for all users. If the device does not receive a heartbeat packet from a user within a specified period, the device specifies the user to go offline.
- Automatic detection mode: The device checks whether the client browser supports the heartbeat program. If yes, the forcible detection mode is used for the user; if no, the device does not detect the user. You are advised to configure this mode to prevent users from going offline because the browser does not support the heartbeat program.

NOTE

Currently, the heartbeat program is supported by Internet Explorer 8, FireFox 3.5.2, Chrome 28.0.1500.72, and Opera 12.00 on Windows 7. A Java program must be installed and configured on the operating system.

Browsers using Java1.7 and later versions do not support the heartbeat program.

Precautions

When the forcible detection mode is configured, the device specifies users to go offline to prevent from failing to receive heartbeat packets for a long time during network congestion. In this scenario, the heartbeat detection interval must be increased.

If you run this command multiple times in the same view, only the latest configuration takes effect.

Example

Configure the automatic detection function of the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server keep-alive interval 60 auto
```

13.4.152 portal local-server load

Function

The **portal local-server load** command loads a page file package to the built-in Portal server.

The **undo portal local-server load** command restores the default configuration.

By default, the built-in Portal server loads the default page file package **portalpage.zip**.

Format

portal local-server load *string*

undo portal local-server load

Parameters

Parameter	Description	Value
<i>string</i>	Specifies the name of the page file package to be loaded to the built-in Portal server.	The value is a string of 1 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i> . <ul style="list-style-type: none">• <i>drive</i>: indicates the storage device name.• <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~, *, /, \, :, ', and ".• <i>filename</i>: indicates the file name. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Customized page file packages can be loaded to the built-in Portal server.

Prerequisites

The page file (.zip) has been uploaded from the PC to the device storage media.

Precautions

The default page file package can be modified but cannot be deleted. If it is deleted, the built-in Portal server fails to load the pages after startup.

This function is used by technical support personnel to develop limited page customization based on customer requirements and does not apply to customization by customers themselves.

Example

Load the page file **portalpage_01.zip** on the built-in Portal server.

```
<HUAWEI> system-view
[HUAWEI] portal local-server load portalpage_01.zip
Warning: Portal local server has been enabled, and this operation will affect online user, continue?[Y/N]:y
```

Related Topics

[13.4.76 display portal local-server page-information](#)

[13.4.75 display portal local-server](#)

13.4.153 portal local-server logo load

Function

The **portal local-server logo load** command loads a logo file to the built-in Portal server login page.

The **undo portal local-server logo load** command deletes the logo file loaded to the built-in Portal server login page.

By default, no logo file is loaded to the built-in Portal server login page.

Format

portal local-server logo load *logo-file*

undo portal local-server logo load

Parameters

Parameter	Description	Value
<i>logo-file</i>	<p>Specifies the name of the logo file to be loaded to the built-in Portal server login page.</p> <p>The size of the logo file must be equal to or less than 128 KB. A file of 591 x 80 pixels is recommended.</p>	<p>The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i>.</p> <ul style="list-style-type: none"> • <i>drive</i>: indicates the storage device name. • <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~, *, /, \, :, ', and ". • <i>filename</i>: indicates the file name. The jpg and png formats are supported, and the file name extension must be .jpg, .jpeg, or .png. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

There is a blank area on the login page of the default page package used by the built-in Portal server. Users can customize this area by loading a logo file. When the login page needs to be customized based on special requirements, the administrator can upload the user-defined logo file to the device and run the **portal local-server logo load** command. After the logo file is loaded, the user-defined logo is displayed on the built-in Portal server login page for authentication.

Prerequisites

The user-defined logo file has been uploaded to the device.

Example

Load the logo file **logo.png** to the built-in Portal server login page.

```
<HUAWEI> system-view
[HUAWEI] portal local-server logo load flash:/logo.png
Info: The loading process may take a few seconds.Please wait for a moment.
Info: Load web file successfully.
```

Related Topics

[13.4.75 display portal local-server](#)

13.4.154 portal local-server

Function

The **portal local-server** command enables the built-in Portal server function.

The **undo portal local-server** command disables the built-in Portal server function.

By default, the built-in Portal server function is disabled.

Format

portal local-server https ssl-policy *policy-name* [port *port-num*]

undo portal local-server https

Parameters

Parameter	Description	Value
https	Configures the built-in Portal server to exchange authentication messages with users using the Hypertext Transfer Protocol Secure (HTTPS) protocol.	-
ssl-policy <i>policy-name</i>	Specifies the Secure Sockets Layer (SSL) policy used by the built-in Portal server.	The value must be the name of an existing SSL policy.
port <i>port-num</i>	Specifies the TCP port number used. If you do not specify a port number, the default port number is used.	The value can be 443 or any integer in the range of 1025 to 55535. By default, the port number is 443.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Compared with an external Portal server, a built-in Portal server is easy to use, cost-effective, and easy to maintain. After a built-in Portal server is configured, Portal authentication can be implemented for users without an external Portal server. When using the **portal local-server** command to enable the built-in Portal server function, configure the built-in Portal server to exchange authentication messages with users using the HTTPS protocol. HTTPS is a secure extension of HTTP and uses the SSL protocol to guarantee secure communication. To enable the built-in Portal server to exchange authentication messages using HTTPS, you need to configure an SSL policy and load a digital certificate to the server.

Prerequisites

- The IP address of the built-in Portal server has been configured using the **13.4.150 portal local-server ip** command.
- An SSL policy has been configured using the **ssl policy policy-name** command in the system view, and a certificate has been loaded using the **certificate load** command in the SSL policy view.
- You have obtained a digital certificate for the SSL policy from an authorized certificate authority.

Precautions

When there are Portal authentication users online, you cannot disable the built-in Portal server function or change the SSL policy for the built-in Portal server.

Example

Enable the built-in Portal server function and configure the server to use the SSL policy **s1**.

```
<HUAWEI> system-view
[HUAWEI] interface loopback 1
[HUAWEI-LoopBack1] ip address 10.1.1.1 24
[HUAWEI-LoopBack1] quit
[HUAWEI] portal local-server ip 10.1.1.1
[HUAWEI] ssl policy s1
[HUAWEI-ssl-policy-s1] quit
[HUAWEI] portal local-server https ssl-policy s1
```

13.4.155 portal local-server page-text load

Function

The **portal local-server page-text load** command loads the use instruction page file of the built-in Portal server.

The **undo portal local-server page-text load** command deletes the loaded use instruction page file of the built-in Portal server.

By default, no use instruction page file of the built-in Portal server is loaded.

Format

portal local-server page-text load *string*

undo portal local-server page-text load

Parameters

Parameter	Description	Value
<i>string</i>	Specifies the use instruction page file of the built-in Portal server.	<p>The value is a string of 1 to 64 case-insensitive characters without spaces, in the format of [drive] [path] filename.</p> <ul style="list-style-type: none">• drive indicates the storage device name.• path indicates the directory or sub-directory. The directory name cannot contain the following characters: ~ * / \ : ' "• filename indicates the file name. The file name extension must be .txt or .html. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If you need to customize the use instruction page, you can upload the customized use instruction page file to the device, and run this command to load the file. After the file is loaded, the hyperlink **Instruction for Use** is generated on the login page of the built-in Portal server, and users can click the hyperlink to access the use instruction page.

Prerequisite

The page file to be loaded has been uploaded to the device.

Precautions

When the to-be-loaded page is customized, the page length and width are fixed. After adjusting the page, the administrator must upload and load the modified page again.

Currently, only Chinese or English page files can be loaded on the device.

Example

Load the use instruction page file **page.html** to the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server page-text load flash:/page.html  
Info: The loading process may take a few seconds.Please wait for a moment.  
Info: Load web file successfully.
```

Related Topics

[13.4.75 display portal local-server](#)

13.4.156 portal local-server policy-text load

Function

The **portal local-server policy-text load** command loads a disclaimer page file to the built-in Portal server.

The **undo portal local-server policy-text load** command deletes the loaded disclaimer page file.

By default, no disclaimer page file is loaded to the built-in Portal server.

Format

portal local-server policy-text load *string*

undo portal local-server policy-text load

Parameters

Parameter	Description	Value
<i>string</i>	Specifies the name of the disclaimer page file to be loaded to the built-in Portal server.	The value is a string of 1 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i> . <ul style="list-style-type: none">• <i>drive</i>: indicates the storage device name.• <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~, *, /, \, :, ', and ".• <i>filename</i>: indicates the file name. The file name extension must be .txt or .html. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To customize a disclaimer page, upload the disclaimer page file to the device and run this command to load the file. After the file is loaded, the hyperlink **Disclaimer** will be displayed on the login page. You can click the link to visit the disclaimer page.

Prerequisite

The disclaimer page file to be loaded has been uploaded to the device.

Precautions

Currently, only Chinese and English disclaimer page files can be loaded on the device.

Example

```
# Load the disclaimer page file policy.html to the built-in Portal server.
```

```
<HUAWEI> system-view  
[HUAWEI] portal local-server policy-text load policy.html  
Info: The loading process may take a few seconds.Please wait for a moment.  
Info: Load web file successfully.
```

Related Topics

[13.4.75 display portal local-server](#)

13.4.157 portal local-server timer session-timeout

Function

The **portal local-server timer session-timeout** command configures the session timeout interval for built-in Portal authentication users.

The **undo portal local-server timer session-timeout** command restores the default session timeout interval for built-in Portal authentication users.

By default, the session timeout interval is 8 hours for built-in Portal authentication users.

Format

```
portal local-server timer session-timeout interval
```

```
undo portal local-server timer session-timeout
```

Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the session timeout interval for built-in Portal authentication users.	The value is an integer that ranges from 1 to 720, in hours.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Scenario

When built-in Portal authentication is used for users and the device functions as a built-in Portal server, you can configure the session timeout interval for the users. The users are disconnected after the specified session timeout interval. To connect to the network again, the users need to be re-authenticated.

Precautions

The session timeout interval for built-in Portal authentication users is calculated based on the device time. For example, if the session timeout interval is 6 hours and the device time is 2014-09-01 02:00:00 when a user was connected, the user should be disconnected at 2014-09-01 08:00:00. Therefore, ensure that the device time and time zone are correct after the session timeout interval is configured for users. If the device time is incorrect, users may fail to be connected or disconnected properly. You can run the **display clock** command to check the device time and the time zone.

Example

```
# Set the session timeout interval to 10 hours for built-in Portal authentication users.
```

```
<HUAWEI> system-view  
[HUAWEI] portal local-server timer session-timeout 10
```

Related Topics

[13.4.75 display portal local-server](#)

13.4.158 portal local-server syslog-limit enable

Function

The **portal local-server syslog-limit enable** command enables the log suppression function for users authenticated through the built-in Portal server.

The **undo portal local-server syslog-limit enable** command disables the log suppression function for users authenticated through the built-in Portal server.

By default, the log suppression function is enabled for users authenticated through the built-in Portal server.

Format

portal local-server syslog-limit enable

undo portal local-server syslog-limit enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device generates logs when users authenticated through the built-in Portal server fail to go online or offline. If a user fails to go online or offline, the user attempts to go online or offline repeatedly, and the device generates a large number of logs within a short time. This results in a high failure rate in the statistics and degrades the system performance. You can run the **portal local-server syslog-limit enable** command to enable the log suppression function for users authenticated through the built-in Portal server. The device then only generates one log if a user fails to go online or offline within a suppression period (configured using the [13.4.159 portal local-server syslog-limit period](#) command).

Example

```
# Enable the log suppression function for users authenticated through the built-in Portal server.
```

```
<HUAWEI> system-view  
[HUAWEI] portal local-server syslog-limit enable
```

13.4.159 portal local-server syslog-limit period

Function

The **portal local-server syslog-limit period** command configures the log suppression period for users authenticated through the built-in Portal server.

The **undo portal local-server syslog-limit period** command restores the default log suppression period.

By default, the log suppression period is 300 seconds for users authenticated through the built-in Portal server.

Format

portal local-server syslog-limit period *value*

undo portal local-server syslog-limit period

Parameters

Parameter	Description	Value
<i>value</i>	Specifies the log suppression period for users authenticated through the built-in Portal server.	The value is an integer that ranges from 60 to 604800, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device generates logs when users authenticated through the built-in Portal server fail to go online or offline. If a user fails to go online or offline, the user attempts to go online or offline repeatedly, and the device generates a large number of logs within a short time. This results in a high failure rate in the statistics and degrades the system performance. You can enable the log suppression function (configured using the [13.4.158 portal local-server syslog-limit enable](#) command) for users authenticated through the built-in Portal server. The device then only generates one log if a user fails to go online or offline within a suppression period.

Example

Set the log suppression period to 1000 seconds for users authenticated through the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server syslog-limit period 1000
```

13.4.160 portal logout different-server enable

Function

The **portal logout different-server enable** command configures a device to process user logout requests sent by a Portal server other than the one from which users log in.

The **undo portal logout different-server enable** command restores the default configuration.

By default, a device does not process user logout requests sent by Portal servers other than the one from which users log in.

Format

portal logout different-server enable

undo portal logout different-server enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In a scenario where Portal server load balancing is configured, by default, a device does not process user logout requests sent by Portal servers other than the one from which users log in and responds ACK messages only to the Portal server from which users log in. Users in arrears then can still stay online. To prevent this problem, run **portal logout different-server enable** command to configure the device to process user logout requests sent by a Portal server other than the one from which users log in. Upon receipt of a user logout request from such a Portal server, the device starts a user logout process. After completing the logout event, the device responds an ACK message to the Portal server, thereby ensuring that the user logs out properly.

Precautions

The user logout requests that a device can process must be sent by Portal servers bound to an access interface. These servers include all the Portal servers configured in the master and backup Portal server templates bound to the interface.

Example

```
# Enable a device to process user logout requests a Portal server other than the one from which users log in.
```

```
<HUAWEI> system-view  
[HUAWEI] portal logout different-server enable
```

Related Topics

[13.4.73 display portal](#)

13.4.161 portal logout resend timeout

Function

The **portal logout resend timeout** command configures the re-transmission times and interval for the Portal authentication user logout packet.

The **undo portal logout resend timeout** command restores the default setting.

By default, the Portal authentication user logout packet can be re-transmitted three times within five seconds.

Format

```
portal logout resend times timeout period
```

```
undo portal logout { resend | timeout } *
```

Parameters

Parameter	Description	Value
<i>times</i>	Specifies the number of re-transmission times for the Portal authentication user logout packet.	The value is an integer that ranges from 0 to 15. The value 0 indicates that the re-transmission function is disabled.
<i>period</i>	Specifies the re-transmission interval of the Portal authentication user logout packet.	The value is an integer that ranges from 1 to 300, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After disconnecting a Portal authentication user, the device sends a user logout packet (NTF-LOGOUT) to instruct the Portal server to delete the user information. If the network between the device and Portal server is not stable or packets are lost, the Portal server may fail to receive the user logout packet from the device after the Portal authentication user is disconnected. In this case, the user is displayed as disconnected on the device but still as online on the Portal server. To enable the Portal server to receive the user logout packet and ensure that the online user information on the Portal server is correct, the administrator can enable the user logout packet re-transmission function on the device and configure the re-transmission times and interval.

Example

Configure the re-transmission times to 5 and interval to 10 seconds for the Portal authentication user logout packet.

```
<HUAWEI> system-view  
[HUAWEI] portal logout resend 5 timeout 10
```

Related Topics

[13.4.73 display portal](#)

[13.4.80 display portal user-logout](#)

13.4.162 portal max-user

Function

The **portal max-user** command sets the maximum number of concurrent Portal authentication users allowed to access the device.

The **undo portal max-user** command restores the default maximum number of concurrent Portal authentication users.

By default, the number of Portal authentication users is the maximum number of Portal authentication users supported by the device.

Format

portal max-user *user-number*

undo portal max-user

Parameters

Parameter	Description	Value
<i>user-number</i>	Specifies the maximum number of concurrent Portal users.	The value is an integer that varies depending on product models.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

You can run the **portal max-user** command to set the maximum number of concurrent Portal authentication users.

Example

Set the maximum number of concurrent Portal authentication users to 25.

```
<HUAWEI> system-view  
[HUAWEI] portal max-user 25
```

13.4.163 portal quiet-period

Function

The **portal quiet-period** command enables the quiet timer for Portal authentication.

The **undo portal quiet-period** command disables the quiet timer of Portal authentication.

By default, the quiet timer for Portal authentication is enabled.

Format

portal quiet-period

undo portal quiet-period

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the **portal quiet-period** command is used to enable the quiet timer for Portal authentication. If the number of Portal authentication failures exceeds the value specified by the [13.4.164 portal quiet-times](#) command, the device keeps the Portal authentication user in quiet state for a period of time. During the quiet period, the device discards Portal authentication requests from the user. This prevents the impact of frequent authentications on the system.

The quiet period for Portal authentication can be set using the [13.4.165 portal timer quiet-period](#) command. After the quiet period is reached, the device re-authenticates the user.

Example

```
# Enable the quiet timer for Portal authentication.
```

```
<HUAWEI> system-view  
[HUAWEI] portal quiet-period
```

13.4.164 portal quiet-times

Function

The **portal quiet-times** command sets the maximum number of authentication failures within 60s before a Portal authentication user is kept in quiet state.

The **undo portal quiet-times** command restores the default maximum number of authentication failures within 60s before a Portal authentication user enters the quiet state.

By default, the device allows a maximum of ten authentication failures within 60s before a Portal authentication user enters the quiet state.

Format

portal quiet-times *fail-times*

undo portal quiet-times

Parameters

Parameter	Description	Value
<i>fail-times</i>	Specifies the maximum number of authentication failures before a Portal authentication user enters the quiet state.	The value is an integer that ranges from 1 to 10.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the [13.4.163 portal quiet-period](#) command is used to enable the quiet timer, if the number of Portal authentication failures exceeds the value specified by the **portal quiet-times** command, the device keeps the Portal authentication user in quiet state for a period of time. This prevents the impact of frequent authentications on the system.

Example

```
# Set the maximum number of Portal authentication failures within 60 seconds to 4.
```

```
<HUAWEI> system-view  
[HUAWEI] portal quiet-times 4
```

13.4.165 portal timer quiet-period

Function

The **portal timer quiet-period** command configures the quiet period for Portal authentication users who fail to be authenticated.

The **undo portal timer quiet-period** command restores the default quiet period.

By default, the quiet period is 60 seconds for Portal authentication users who fail to be authenticated.

Format

portal timer quiet-period *quiet-period-value*

undo portal timer quiet-period

Parameters

Parameter	Description	Value
<i>quiet-period-value</i>	Sets the quiet period for Portal authentication users who fail to be authenticated.	The value is an integer that ranges from 10 to 3600, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

If a Portal authentication user fails to be authenticated consecutively within a short period, the system is affected and a large number of duplicated authentication failure logs are generated.

After the quiet function is enabled using the [13.4.163 portal quiet-period](#) command, if the number of times that a Portal authentication user fails to be authenticated within 60s exceeds the upper limit (configured using the [13.4.164 portal quiet-times](#) command), the device discards the user's Portal authentication request packets for a period to avoid frequent authentication failures.

Example

Set the quiet period to 100 seconds for Portal authentication users who fail to be authenticated.

```
<HUAWEI> system-view  
[HUAWEI] portal timer quiet-period 100
```

13.4.166 portal timer offline-detect

Function

The **portal timer offline-detect** command sets the Portal user offline detection interval.

The **undo portal timer offline-detect** command restores the default Portal user offline detection interval.

By default, the Portal user offline detection interval is 300 seconds.

Format

portal timer offline-detect *time-length*

undo portal timer offline-detect

Parameters

Parameter	Description	Value
<i>time-length</i>	Specifies the Portal user offline detection interval.	The value is 0 or an integer that ranges from 30 to 7200, in seconds. The default value is 300. The value 0 indicates that offline detection is not performed.

Views

Portal access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If a Portal user goes offline due to power failure or network interruption, the device and Portal server may still store the user information, which causes incorrect accounting. Additionally, a limit number of users can access the device. If a user goes offline improperly but the device still stores user information, other users cannot access the network.

After the Portal user offline detection interval is set, if the user does not respond within the interval, the device considers the Portal user offline. The device and Portal server then delete the user information and release resources to ensure an efficient resource use.

Precautions

This command only applies to Layer 2 Portal authentication.

The heartbeat detection function of the authentication server can be used to ensure the normal online status of PC users for whom Layer 3 Portal authentication is used. If the authentication server detects that a user goes offline, it instructs the device to disconnect the user.

If the number of offline detection packets (ARP packets) exceeds the default CAR value, the detection fails and the users are logged out (The [display cpu-defend statistics](#) command can be run to check whether ARP request and response packets are lost.). To resolve the problem, the following methods are recommended:

- Increase the detection interval based on the number of users. The default detection interval is recommended when there are less than 8000 users; the detection interval should be no less than 600 seconds when there are more than 8000 users.
- Deploy the port attack defense function on the access device and limit the rate of packets sent to the CPU.

If user traffic (such as service packets) passes through the device within the Portal user offline detection period, the device does not consider the user offline even if the user does not respond.

Example

In the Portal access profile **p1**, set the offline detection interval of Portal authentication users to 400s.

```
<HUAWEI> system-view  
[HUAWEI] portal-access-profile name p1  
[HUAWEI-portal-access-profile-p1] portal timer offline-detect 400
```

13.4.167 portal url-encode enable

Function

The **portal url-encode enable** command enables URL encoding and decoding.

The **undo portal url-encode enable** command disables URL encoding and decoding.

By default, URL encoding and decoding are enabled.

NOTE

If the system software is upgraded from a version earlier than V200R009C00SPC500 to V200R009C00SPC500 or a later version, the switch automatically runs the **undo portal url-encode enable** command to disable URL encoding and decoding.

Format

portal url-encode enable

undo portal url-encode enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To improve web application security, data from untrustworthy sources must be encoded before being sent to clients. URL encoding is most commonly used in web applications. To enable URL encoding and decoding, run the **portal url-encode enable** command. Some special characters in redirected URLs are then converted to secure formats, preventing clients from mistaking them for syntax signs or instructions and unexpectedly modifying the original syntax. In this way, cross-site scripting attacks and injection attacks are prevented.

Precautions

After the URL encoding and decoding function is enabled, some servers may not support the escape characters converted from special characters in redirect URLs. Therefore, check whether servers support the escape characters before configuring special characters in redirect URLs.

Example

```
# Enable URL encoding and decoding.
```

```
<HUAWEI> system-view  
[HUAWEI] portal url-encode enable
```

Related Topics

[13.4.79 display portal url-encode configuration](#)

13.4.168 portal user-alarm percentage

Function

The **portal user-alarm percentage** command sets alarm thresholds for the Portal authentication user count percentage.

The **undo portal user-alarm percentage** command restores the default alarm thresholds for the Portal authentication user count percentage.

By default, the lower alarm threshold for the Portal authentication user count percentage is 50, and the upper alarm threshold for the Portal authentication user count percentage is 100.

Format

portal user-alarm percentage *percent-lower-value percent-upper-value*

undo portal user-alarm percentage

Parameters

Parameter	Description	Value
<i>percent-lower-value</i>	Specifies the lower alarm threshold for the Portal authentication user count percentage.	The value is an integer that ranges from 1 to 100.
<i>percent-upper-value</i>	Specifies the upper alarm threshold for the Portal authentication user count percentage.	The value is an integer that ranges from 1 to 100, but must be greater than or equal to the lower alarm threshold.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After running the [13.4.162 portal max-user](#) command to set the maximum number of online Portal authentication users allowed on a device, you can run the **portal user-alarm percentage** command to set alarm thresholds for the Portal authentication user count percentage.

When the percentage of online Portal authentication users against the maximum number of users allowed by the device exceeds the upper alarm threshold, the device generates an alarm. When the percentage of online Portal authentication users against the maximum number of users allowed by the device reaches or falls below the lower alarm threshold later, the device generates a clear alarm.

If the configured upper alarm threshold for the Portal authentication user count percentage is 100, the device generates an alarm when the number of online users reaches the maximum number of users allowed by the device.

Example

```
# Set the lower alarm threshold for the Portal authentication user count  
percentage to 30, and the upper alarm threshold for the Portal authentication  
user count percentage to 80.
```

```
<HUAWEI> system-view  
[HUAWEI] portal user-alarm percentage 30 80
```

Related Topics

[13.4.162 portal max-user](#)

13.4.169 portal web-authen-server

Function

The **portal web-authen-server** command enables the Portal interconnection function of the HTTP or HTTPS protocol.

The **undo portal web-authen-server** command disables the Portal interconnection function of the HTTP or HTTPS protocol.

By default, the Portal interconnection function of the HTTP or HTTPS protocol is disabled.

Format

portal web-authen-server { **http** | **https ssl-policy** *policy-name* } [**port** *port-number*]

undo portal web-authen-server [**port**]

Parameters

Parameter	Description	Value
http	Sets the HTTP protocol for Portal authentication. NOTE The HTTP protocol poses security risks. The HTTPS protocol is recommended.	-
https	Sets the HTTPS protocol for Portal authentication.	-
ssl-policy <i>policy-name</i>	Specifies the name of an SSL policy.	The value must be the name of an existing SSL policy.
port <i>port-number</i>	Specifies a port number.	The value is an integer that ranges from 1025 to 55535. The default HTTP port number is 8000 and the default HTTPS port number is 8443.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If the device is connected to the Portal server that only supports the HTTP or HTTPS protocol, you need to run the **portal web-authen-server** command on the device to enable the Portal interconnection function of the HTTP or HTTPS protocol.

Follow-up Procedure

Run the [13.4.172 protocol \(Portal server template view\)](#) command to set the protocol used in Portal authentication to HTTP or HTTPS.

Precautions

Modifying the **port** parameter causes the pre-connected user to go offline.

Example

```
# Enable the Portal interconnection function of the HTTPS protocol.
```

```
<HUAWEI> system-view  
[HUAWEI] ssl policy huawei  
[HUAWEI-ssl-policy-huawei] quit  
[HUAWEI] portal web-authen-server https ssl-policy huawei port 8443
```

Related Topics

[13.4.89 display web-auth-server configuration](#)

13.4.170 portal-access-profile (authentication profile view)

Function

The **portal-access-profile** command binds a Portal access profile to an authentication profile.

The **undo portal-access-profile** command unbinds a Portal access profile from an authentication profile.

By default, an authentication profile is not bound to a Portal access profile.

Format

portal-access-profile *access-profile-name*

undo portal-access-profile

Parameters

Parameter	Description	Value
<i>access-profile-name</i>	Specifies the name of a Portal access profile.	The value must be the name of an existing Portal access profile.

Views

Authentication profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The authentication type used by an authentication profile is determined by the access profile bound to the authentication profile. After being bound to a Portal access profile, the authentication profile is enabled with Portal authentication. After the authentication profile is applied to the interface or VAP profile, Portal authentication can be performed on online users.

Prerequisites

The Portal server has been configured for the Portal access profile:

- If the external Portal server is used, the Portal server profile used by the Portal access profile has been configured using the [13.4.209 web-auth-server \(Portal access profile view\)](#) command.
- If the built-in Portal server is used, the built-in Portal server function of the Portal access profile has been enabled using the [13.4.149 portal local-server enable](#) command.

Follow-up Procedure

Run the [13.4.42 authentication-profile \(Interface view or VAP profile view\)](#) command to apply the authentication profile to the interface or VAP profile.

Precautions

An authentication profile can be bound to only one Portal access profile.

Example

Bind the authentication profile **portal_authen_profile1** to the Portal access profile **portal_access_profile1**. The IP address of the Portal server is 192.168.10.1, and Layer 2 Portal authentication is used.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server server1
[HUAWEI-web-auth-server-server1] server-ip 192.168.10.1
[HUAWEI-web-auth-server-server1] quit
[HUAWEI] portal-access-profile name portal_access_profile1
[HUAWEI-portal-access-profile-portal_access_profile1] web-auth-server server1 direct
[HUAWEI-portal-access-profile-portal_access_profile1] quit
[HUAWEI] authentication-profile name portal_authen_profile1
[HUAWEI-authen-profile-portal_authen_profile1] portal-access-profile portal_access_profile1
```

Related Topics

[13.4.61 display authentication-profile configuration](#)

13.4.171 portal-access-profile (system view)

Function

The **portal-access-profile** command creates a portal access profile and displays the portal access profile view.

The **undo portal-access-profile** command deletes the portal access profile.

By default, the device has a built-in portal access profile named **portal_access_profile**.

Format

portal-access-profile name *access-profile-name*

undo portal-access-profile name *access-profile-name*

Parameters

Parameter	Description	Value
name <i>access-profile-name</i>	Specifies the name of a portal access profile.	The value is a string of 1-31 case-sensitive characters, which cannot be configured to - and --. It cannot contain spaces and the following symbols: / \ : * ? " < > @ ' %.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device uses portal access profiles to uniformly manage all portal users access configurations. To perform portal authentication for the users in an interface or VAP profile, bind the authentication profile applied to the interface or VAP profile to a portal access profile.

Follow-up Procedure

Configure the portal server used by the portal access profile:

- If the external portal server is used, run the [13.4.209 web-auth-server \(Portal access profile view\)](#) command to configure the portal server profile for the portal access profile.
- If the built-in portal server is used, run the [13.4.149 portal local-server enable](#) command to configure the built-in portal server function for the portal access profile.

Precautions

- The compatibility profile converted after an upgrade is not counted in the configuration specification. The built-in portal access profile **portal_access_profile** can be modified and applied, but cannot be deleted.
- Before deleting a portal access profile, ensure that this profile is not bound to any authentication profile.

Example

Create portal access profile named **portal_access_profile1**.

```
<HUAWEI> system-view  
[HUAWEI] portal-access-profile name portal_access_profile1
```

Related Topics

[13.4.77 display portal-access-profile configuration](#)

13.4.172 protocol (Portal server template view)

Function

The **protocol** command configures the protocol used in Portal authentication.

The **undo protocol** command restores the default configuration.

By default, the Portal protocol is used in Portal authentication.

Format

protocol { **http** [**password-encrypt** { **none** | **uam** }] | **portal** }

undo protocol

Parameters

Parameter	Description	Value
http	Sets the protocol used in Portal authentication to HTTP or HTTPS.	-

Parameter	Description	Value
password-encrypt { none uam }	Specifies the password encoding mode. <ul style="list-style-type: none"> • none: The password is not encoded. • uam: The password is encoded using ASCII characters. 	-
portal	Sets the protocol used in Portal authentication to Portal.	-

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

In Portal authentication, the device can use the following protocols to communicate with the Portal server. You can set the protocol according to the protocol supported by the Portal server.

- Portal protocol
- HTTP or HTTPS protocol

Example

```
# Set the protocol used in Portal authentication to HTTP or HTTPS.
<HUAWEI> system-view
[HUAWEI] web-auth-server abc
[HUAWEI-web-auth-server-abc] protocol http password-encrypt uam
```

13.4.173 qos-profile (service scheme view)

Function

The **qos-profile** command binds a QoS profile to a service scheme.

The **undo qos-profile** command unbinds the QoS profile from the service scheme.

By default, no QoS profile is bound to a service scheme.

NOTE

Only S5720EI, S5720HI, S6720EI, and S6720S-EI support this command.

Format

qos-profile *profile-name*

undo qos-profile *profile-name*

Parameters

Parameter	Description	Value
<i>profile-name</i>	Specifies the name of the QoS profile bound to the service scheme.	The value must be the name of an existing QoS profile.

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After creating a service scheme using the [13.1.82 service-scheme \(AAA view\)](#) command, you can run the **qos-profile** command to bind a QoS profile to the service scheme. The user assigned with the service scheme will have the attributes in the QoS profile.

Precautions

For S5720EI, S6720EI, and S6720S-EI, if the user upstream rate limit is configured in the QoS profile bound to a service scheme, do not configure the device to use the service scheme to grant network access rights to users in the pre-connection phase. Otherwise, users go offline.

The authorized downlink bandwidth limit delivered by the server has a low priority, and will not take effect when it is configured together with an authorization QoS attribute.

Example

Bind the QoS profile **abc** to the service scheme **huawei**.

```
<HUAWEI> system-view
[HUAWEI] qos-profile name abc
[HUAWEI-qos-abc] quit
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme huawei
[HUAWEI-aaa-service-huawei] qos-profile abc
```

13.4.174 reset aaa statistics access-type-authenreq

Function

The **reset aaa statistics access-type-authenreq** command clears the number of requesting for MAC, Portal, or 802.1X authentication.

Format

reset aaa statistics access-type-authenreq

Parameters

None

Views

All views

Default Level

3: Management level

Usage Guidelines

When users send authentication requests, the device collects statistics on the number of initiating MAC, Portal, and 802.1X authentications.

To clear the number of requesting for MAC, Portal, or 802.1X authentication, run the **reset aaa statistics access-type-authenreq** command.

Example

Clear the number of requesting for MAC, Portal, or 802.1X authentication.

```
<HUAWEI> reset aaa statistics access-type-authenreq
```

13.4.175 reset dot1x statistics

Function

The **reset dot1x statistics** command clears 802.1X authentication statistics.

Format

reset dot1x statistics [**interface** { *interface-type interface-number1* [**to** *interface-number2*] } &<1-10>]

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	<p>Clears 802.1X authentication statistics on a specified interface.</p> <ul style="list-style-type: none"> • <i>interface-type</i> specifies the interface type. • <i>interface-number</i> specifies the interface number. <p>If this parameter is not specified, 802.1X authentication statistics on the device are cleared.</p>	-

Views

User view

Default Level

3: Management level

Usage Guidelines

The 802.1X authentication statistics contain the number of times that the authentication succeeded and failed and the number of sent and received packets.

The **reset dot1x statistics** command is used in the following scenarios:

- Redeploy services. After the statistics are cleared, collect the 802.1X authentication statistics again, and run the **13.4.63 display dot1x** command to check whether the authentication function works properly and whether packets are correctly sent and received.
- Rectify a fault. After the fault is rectified, run the **reset dot1x statistics** command to clear the statistics, collect the statistics on 802.1X authentication again, and then run the **13.4.63 display dot1x** command to verify the authentication result and check whether packets are correctly sent and received. If the authentication is successful and packets are correctly sent and received, the fault is rectified.

Example

Clear 802.1X authentication statistics.

```
<HUAWEI> reset dot1x statistics
```

Related Topics

[13.4.63 display dot1x](#)

13.4.176 reset mac-authen statistics

Function

The **reset mac-authen statistics** command clears MAC address authentication statistics.

Format

reset mac-authen statistics [**interface** { *interface-type interface-number1* [**to interface-number2**] } &<1-10>]

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to interface-number2] }	<p>Clears MAC address authentication statistics on a specified interface.</p> <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number. <p>If this parameter is not specified, MAC address authentication statistics on the device are cleared.</p>	-

Views

User view

Default Level

3: Management level

Usage Guidelines

The **reset mac-authen statistics** command is used in the following scenarios:

- Re-deploy services. After the statistics are cleared, collect the MAC address authentication statistics again, and run the [13.4.71 display mac-authen](#) command to check whether the authentication function is normal.

- Rectify a fault. After the fault is rectified, run the **reset mac-authen statistics** command to clear statistics, collect MAC address authentication statistics again, and run the [13.4.71 display mac-authen](#) command to check the authentication result. If the authentication is successful, the fault is rectified.

Example

```
# Clear MAC address authentication statistics.
```

```
<HUAWEI> reset mac-authen statistics
```

Related Topics

[13.4.71 display mac-authen](#)

13.4.177 reset access-user dot1x-identity statistics

Function

The **reset access-user dot1x-identity statistics** command clears statistics about Identity packets for wireless 802.1X authentication on a switch.

NOTE

This function is supported only by S5720HI.

Format

```
reset access-user dot1x-identity statistics
```

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

To display statistics about Identity packets for wireless 802.1X authentication on a switch within a specified period of time, run the **reset access-user dot1x-identity statistics** command to clear the existing statistics first, and then run the [13.4.54 display access-user dot1x-identity statistics](#) command to display the new statistics.

Example

```
# Clear statistics about Identity packets for wireless 802.1X authentication on the switch.
```

```
<HUAWEI> system-view  
[HUAWEI] reset access-user dot1x-identity statistics
```

13.4.178 reset access-user traffic-statistics

Function

The **reset access-user traffic-statistics** command clears statistics on traffic of users.

 **NOTE**

Only the S5720EI, S5720HI, S6720EI, and S6720S-EI support this command.

Format

```
reset access-user traffic-statistics { user-id begin-id [ end-id ] | mac-address  
mac-address | ip-address ip-address [ vpn-instance vpn-instance ] }
```

Parameters

Parameter	Description	Value
user-id <i>begin-id</i> [<i>end-id</i>]	Specifies IDs of online users. <ul style="list-style-type: none">• <i>begin-id</i>: indicates the ID of the start user.• <i>end-id</i>: indicates the ID of the end user. The value of <i>end-id</i> must be equal to or greater than that of <i>begin-id</i>.	The value is an integer that varies depending on the product model.
mac-address <i>mac-address</i>	Specifies the MAC address of an online user.	The value is in the format of H-H-H, in which H is a hexadecimal number of 1 to 4 digits.
ip-address <i>ip-address</i>	Specifies the IP address of an online user.	The value is in dotted decimal notation.
vpn-instance <i>vpn-instance</i>	Specifies the name of a VPN instance that an online user belongs to.	The value must be an existing VPN instance name.

Views

User view

Default Level

3: Management level

Usage Guidelines

After traffic policing is configured in a service scheme, the device collects traffic statistics for the users assigned with the service scheme. You can run the **reset access-user traffic-statistics** command to clear traffic statistics of online users.

Example

```
# Clear statistics on traffic of the user with the IP address 10.1.1.1.
```

```
<HUAWEI> reset access-user traffic-statistics ip-address 10.1.1.1
```

13.4.179 rule (terminal type identification profile view)

Function

The **rule** command configures a terminal type identification rule.

The **undo rule** command deletes a terminal type identification rule.

By default, a terminal type identification rule is not configured.

NOTE

This function is supported only by S5720HI.

Format

```
rule rule-id { mac mac-address mask { mask-length | mask } | dhcp-option  
option-id { sub-match | all-match } { ascii option-text | hex option-hex-string } |  
user-agent { sub-match | all-match } user-agent-text }
```

```
undo rule rule-id
```

Parameters

Parameter	Description	Value
<i>rule-id</i>	Specifies the ID of a terminal type identification rule.	The value is an integer that ranges from 0 to 7.
mac <i>mac-address</i>	Specifies a terminal MAC address.	The value is in H-H-H format. An H is a hexadecimal number of 4 digits.

Parameter	Description	Value
mask { <i>mask-length</i> <i>mask</i> }	Indicates the mask or mask length of a terminal MAC address.	The value of <i>mask</i> is in H-H-H format. An H is a hexadecimal number of 4 digits. The value of <i>mask-length</i> is an integer that ranges from 1 to 48.
dhcp-option <i>option-id</i>	Identifies the terminal type using a DHCP option. <i>option-id</i> specifies the ID of a DHCP option.	The value is an integer that ranges from 1 to 254. NOTE Currently, the identification rule takes effect only when the value is set to 12, 55, or 60.
sub-match	Indicates partial match. The UA or Option information detected by the AC must be the same as or contain the value of <i>option-text</i> or <i>user-agent-text</i> .	-
all-match	Indicates exact match. The UA or Option information detected by the AC must be the same as the value of <i>option-text</i> or <i>user-agent-text</i> .	-
ascii <i>option-text</i>	Specifies the Option information that a terminal must match as an ASCII string.	The value is a string of 1 to 247 case-sensitive characters without spaces.
hex <i>option-hex-string</i>	Specifies the Option information that a terminal must match as a hexadecimal string.	The value is a string of 1 to 254 case-insensitive characters without spaces.
user-agent	Identifies the terminal type using UA information.	-
<i>user-agent-text</i>	Specifies the UA information that a terminal must match.	The value is a string of 1 to 247 case-sensitive characters.

Views

Terminal type identification profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A terminal type identification rule is set based on the terminal's MAC address, UA, and DHCP Option information.

- Match the first 24 bits of a terminal's MAC address, which is known as the Organizationally Unique Identifier (OUI), to identify the corresponding manufacturer.
- Use the UA information carried in HTTP packets from a terminal to identify the operating system and its version, the CPU type, browser type, and browser version.
- Use the manufacturer information carried in Option12, Option55, and Option60 in DHCP packets from a terminal to identify the terminal's host name and manufacturer type.

A terminal type can be identified by checking whether the terminal information matches the identification rule configured. Once the identification is performed, user rights can be delivered or access control can be implemented based on terminal types.

Precautions

- To match an identification rule, the terminal information must be the same with all the configuration items in the rule.
- If the specified *rule-id* already exists and the new rule conflicts with the original rule, the new rule replaces the original one in the conflicting part, which is the same as editing an existing rule.
- To modify a rule that already contains *rule-id*, delete the old rule and create a rule. Otherwise, the configuration result may be incorrect.

Example

Configure terminal type identification rule 1 in the terminal type identification profile **huawei**.

```
<HUAWEI> system-view  
[HUAWEI] device-profile profile-name huawei  
[HUAWEI-device-profile-huawei] rule 1 mac 0046-4b59-1ee0 mask 12
```

Related Topics

[13.4.62 display device-profile](#)

13.4.180 server-detect

Function

The **server-detect** command enables the Portal server detection function.

The **undo server-detect** command disables the Portal server detection function.

By default, the Portal server detection function is disabled.

Format

server-detect [**interval** *interval-period* | **max-times** *times* | **critical-num** *critical-num* | **action** { **log** | **trap** } *] *

undo server-detect [**interval** | **max-times** | **critical-num** | **action** { **log** | **trap** } *]

Parameters

Parameter	Description	Value
interval <i>interval-period</i>	Specifies the detection interval of the Portal server.	The value is an integer that ranges from 30 to 65535, in seconds. The default value is 60.
max-times <i>times</i>	Specifies the maximum number of times that the detection fails.	The value is an integer that ranges from 1 to 255. The default value is 3.
critical-num <i>critical-num</i>	Specifies the minimum number of Portal servers in Up state.	The value is an integer that ranges from 0 to 128. The default value is 0. The default value is recommended.
action	Specifies the action to be taken after the number of detection failures exceeds the maximum.	-
log	Indicates that the device sends a log after the number of detection failures exceeds the maximum.	-
trap	Indicates that the device sends a trap after the number of detection failures exceeds the maximum.	-

Views

Portal server profile view

Default Level

2: Configuration level

Usage Guidelines

If the communication is interrupted because the network between the device and Portal server is faulty or the Portal server is faulty, new Portal authentication users cannot go online. This brings great inconvenience to users.

After the Portal server detection function is enabled in the Portal server profile, the device detects all Portal servers configured in the Portal server profile. If the number of times that the device fails to detect a Portal server exceeds the upper limit, the status of the Portal server is changed from Up to Down. If the number of Portal servers in Up state is less than or equal to the minimum number (specified by the **critical-num** parameter), the device performs the corresponding operation to allow the administrator to obtain the real-time Portal server status or ensure that the users have certain network access rights.

NOTE

The detection interval of the Portal server multiplied by the maximum number of detection failures cannot be less than the keepalive heartbeat interval of the Portal server. It is recommended that the configured detection interval of the Portal server be greater than the keepalive heartbeat interval of the Portal server.

Example

Enable the Portal server detection and keepalive function in the Portal server profile **abc**, set the detection interval to 100s, set the maximum number of failures to 5, and specify the log sent after the number of failures exceeds the limit.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server abc
[HUAWEI-web-auth-server-abc] server-detect interval 100 max-times 5 action log
```

Related Topics

[13.4.202 user-sync](#)

13.4.181 server-ip (Portal server profile view)

Function

The **server-ip** command configures an IP address for a Portal server.

The **undo server-ip** command deletes an IP address for a Portal server.

By default, no IP address is configured for a Portal server.

Format

server-ip *server-ip-address* &<1-10>

undo server-ip { *server-ip-address* | **all** }

Parameters

Parameter	Description	Value
<i>server-ip-address</i>	Specifies an IP address of a Portal server.	The value is in dotted decimal notation.
all	Deletes all IP addresses of a Portal server.	-

Views

Portal server profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After creating a Portal server profile on the device using the [13.4.211 web-auth-server \(system view\)](#) command, configure parameters for the template.

Run the **server-ip** command to configure an IP address for the Portal server in the Portal server profile view. When receiving a Portal authentication request packet from a user, the device sends a response packet to the Portal server with the configured IP address. Multiple IP addresses can be configured in a Portal server profile. This configuration allows Portal authentication users to access the same Portal authentication page using multiple IP addresses, making the authentication process more flexible.

Precautions

- After the IP address corresponding to a Portal server is configured in the Portal server profile, users are allowed to access the IP address.
- If multiple IP addresses are configured for a Portal server in the Portal server profile, you are advised to run the [13.4.197 url \(Portal server profile view\)](#) command to configure a URL for the Portal server. If no URL is configured, the device uses the first IP address as the URL by default, and the other IP addresses do not take effect. When the switch functions as the AC, server IP addresses are automatically delivered to the AP and authentication-free rules are generated. Currently, only four server IP addresses take effect on the AP.

Example

Set the Portal server IP address in the Portal server profile **huawei** to 10.10.10.1.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] server-ip 10.10.10.1
```

Related Topics

[13.4.89 display web-auth-server configuration](#)

13.4.182 shared-key (Portal server profile view)

Function

The **shared-key** command configures the shared key that the device uses to exchange information with a Portal server.

The **undo shared-key** command restores the default setting.

By default, no shared key that the device uses to exchange information with a Portal server is configured.

Format

shared-key cipher *key-string*

undo shared-key

Parameters

Parameter	Description	Value
cipher	Displays a shared key in cipher text.	-
<i>key-string</i>	Specifies the shared key.	The value is a string of case-sensitive characters without spaces. It can be a string of 1 to 16 characters in plain text, or a string of 48 characters in cipher text. When double quotation marks are used around the string, spaces are allowed in the string.

Views

Portal server profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a shared key is configured using the **shared-key** command, the Portal packet exchanged between the device and Portal server carries an authenticator generated according to the shared key, and the authenticator is used to check whether the Portal packet at the receiver is correct. This effectively improves the information exchange security.

Precautions

For security purposes, it is recommended that the password contains at least two types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 6 characters.

Example

Configure the shared key in the Portal server profile **huawei** to **huawei@123**.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] shared-key cipher huawei@123
```

Related Topics

[13.4.89 display web-auth-server configuration](#)

13.4.183 source-ip (Portal server profile view)

Function

The **source-ip** command configures the source IP address for the device to communicate with a Portal server.

The **undo source-ip** command restores the default setting.

By default, no source IP address is configured for the device to communicate with a Portal server.

Format

source-ip *ip-address*

undo source-ip

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the source IP address for communication with a Portal server.	The value is in dotted decimal notation.

Views

Portal server profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To ensure normal communication between the device and Portal server, run the **source-ip** command to configure a source IP address on the device.

If the device is configured with a loopback IP address and a common IP address, the device can communicate with the Portal server only when the loopback IP address and common IP address are the same. The **source-ip** command configures a source IP address on the device in the Portal server profile view to allow communication between the device and a Portal server.

Precautions

Ensure that the configured source IP address is the device IP address. The source IP address cannot be all 0s, all 1s, class D address, class E address, or loopback address.

Example

Set the source IP address for communication between the device and a Portal server to 192.168.1.100 in the Portal server profile **huawei**.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] source-ip 192.168.1.100
```

13.4.184 source-interface (Portal server template view)

Function

The **source-interface** command configures an IP address of a specified interface as the source IP address used by the device to communicate with the Portal server.

The **undo source interface** command restores the default configuration.

By default, no source IP address is configured for the device.

Format

source-interface *interface-type interface-number*

undo source-interface

Parameters

Parameter	Description	Value
<i>interface-type</i> <i>interface-number</i>	<p>Configures an IP address of a specified interface as the source IP address used by the device to communicate with the Portal server:</p> <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <p>NOTE The interface must be a loopback interface.</p> <ul style="list-style-type: none"> <i>interface-number</i> specifies the interface number. 	-

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To enable the device to communicate with the Portal server normally, ensure that the source IP address in the packets sent by the device to the Portal server is consistent with the device IP address configured on the Portal server. By default, the device uses the IP address of an outbound interface as the source IP address to communicate with the Portal server. When there are multiple outbound interfaces and the outbound interface sending packets changes, the source IP address in the packets sent by the device to the Portal server becomes inconsistent with the device IP address configured on the Portal server. In this situation, communication between the device and Portal server is interrupted. To address this problem, run the **source-interface** command on the device to specify the IP address of a loopback interface as the source IP address used by the device to communicate with the Portal server.

Precautions

The specified interface must be a Layer 3 interface with an IP address configured.

Example

Configure an IP address of a specified interface as the source IP address used by the device to communicate with the Portal server.

```
<HUAWEI> system-view
[HUAWEI] interface loopback 1
[HUAWEI-LoopBack1] ip address 10.1.2.25 24
[HUAWEI-LoopBack1] quit
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] source-interface loopback 1
```

13.4.185 static-user

Function

The **static-user** command configures a static user.

The **undo static-user** command deletes the configured static user.

By default, no static user is configured.

Format

static-user *start-ip-address* [*end-ip-address*] [**vpn-instance** *vpn-instance-name*] [**ip-user**] [**domain-name** *domain-name* | **interface** *interface-type interface-number* [**detect**] | **mac-address** *mac-address* | **vlan** *vlan-id*] *

undo static-user *start-ip-address* [*end-ip-address*] [**vpn-instance** *vpn-instance-name*]

 NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
<i>start-ip-address</i> [<i>end-ip-address</i>]	Specifies the IP address range to which a static user belongs. If <i>end-ip-address</i> is not specified, the static user is specified by <i>start-ip-address</i> .	The value is in dotted decimal notation.
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance to which a static user belongs.	The value must be an existing VPN instance name.
ip-user	Identifies a static user using an IP address. NOTE This parameter is only supported by the S5720HI.	-
domain-name <i>domain-name</i>	Specifies the domain to which a static user belongs. If this parameter is specified, the user name of the static user is in the format of user name@domain name. In this case, @ is the default domain name delimiter. The location of delimiter and domain name can be set as required.	The value must be an existing domain name.

Parameter	Description	Value
interface <i>interface-type</i> <i>interface-number</i>	Specifies the interface connected to a static user. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. NOTE A management interface cannot be configured as the interface to which a static user belongs.	-
detect	Permits the device to send ARP packets to trigger MAC address authentication for offline static users.	-
mac-address <i>mac-address</i>	Specifies the MAC address for a static user.	The value is in the format of H-H-H, in which H is a hexadecimal number of 1 to 4 digits.
vlan <i>vlan-id</i>	Specifies the VLAN to which a static user belongs.	The value is an integer that ranges from 1 to 4094.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In network deployment, static IP addresses are assigned to dumb terminals such as printers and servers. These users can be configured as static users for flexible authentication.

After static users are configured, the device can use static user information such as their IP addresses as the user names to authenticate the users only if one of the 802.1X authentication, MAC address authentication, and Portal authentication modes is enabled on the interfaces connected to the static users.

When **ip-user** is specified, IP addresses are used to identify static users and control their permission.

- When some terminals have multiple IP addresses and one MAC address, and they can access the network only after each IP address is authenticated, specify the **ip-user** parameter to identify these users and configure the **ip-static-user enable** command in the authentication template bound to the user access interfaces.
- When all terminals have multiple IP addresses and can access the network only after each IP address is authenticated, only configure the **ip-static-user enable** command in the authentication template bound to the user access interfaces.

Precautions

When the interface (**interface interface-type interface-number**) mapping static users is specified, the VLAN (**vlan vlan-id**) to which the interface belongs must be configured.

This function takes effect only for users who go online after this function is successfully configured.

Static users are not allowed to update the IP address, otherwise the users will go offline.

Only when static users have the **ip-user** parameter configured and connect to the interfaces bound to the authentication template in which the **ip-static-user enable** command configured, IP addresses can be used to identify these users and control their permission.

After this command is configured to specify the VLAN to which a static user belongs, and the user is authenticated and the VLAN is authorized, if the authorized VLAN is different from the previously specified VLAN, the user is added to the new authorized VLAN and is no longer a static user.

When the command is configured on the UC device and directly delivered to the ASs in the SVF scenario, the command must be in the following format: **static-user start-ip-address [end-ip-address] { vlan vlan-id | mac-address mac-address }** or **static-user start-ip-address [end-ip-address] vlan vlan-id mac-address mac-address**.

Example

Configure the IP address range of 10.1.1.1 to 10.1.1.10, authentication domain **huawei**, and VLAN 10 for static users.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain huawei
[HUAWEI-aaa-domain-huawei] quit
[HUAWEI-aaa] quit
[HUAWEI] static-user 10.1.1.1 10.1.1.10 domain-name huawei vlan 10
```

Related Topics

- [13.4.187 static-user username format-include](#)
- [13.4.186 static-user password](#)
- [13.4.82 display static-user](#)

13.4.186 static-user password

Function

The **static-user password** command sets the password for a static user in authentication.

The **undo static-user password** command restores the default password for the static user.

The default username and password are available in *S Series Switches Default Usernames and Passwords* ([Enterprise Network](#) or [Carrier](#)). If you have not obtained the access permission of the document, see **Help** on the website to find out how to obtain it.

Format

static-user password cipher *password*

undo static-user password

Parameters

Parameter	Description	Value
cipher	Indicates that the password is displayed in cipher text.	-
<i>password</i>	Specifies the password of a static user.	The value is a case-sensitive string without question marks (?) or spaces. The password contains 1 to 128 characters in plain text or 48 to 188 characters in cipher text. When double quotation marks are used around the string, spaces are allowed in the string.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When a static user triggers authentication through an ARP packet, you can run the **static-user password** command to set the password for the static user. The access device then sends the password to the authentication server.

Precautions

To improve security, change the default password immediately and update the password periodically. It is recommended that the new password contains at least two types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 6 characters.

This function takes effect only for users who go online after this function is successfully configured.

Example

```
# Set huawei@123 as the static user password for authentication.
```

```
<HUAWEI> system-view  
[HUAWEI] static-user password cipher huawei@123
```

Related Topics

[13.4.185 static-user](#)

[13.4.187 static-user username format-include](#)

[13.4.82 display static-user](#)

13.4.187 static-user username format-include

Function

The **static-user username format-include** command sets the user name for a static user in authentication.

The **undo static-user username format-include** command restores the default user name for the static user.

By default, the name of a static user consists of **system-name** and **ip-address**. For example, if the access device name is **huawei** and user IP address is 1.1.1.1, the static user name is **huawei1.1.1.1**.

Format

```
static-user username format-include { ip-address | mac-address | system-name }
```

```
undo static-user username format-include
```

Parameters

Parameter	Description	Value
ip-address	Specifies the user IP address as the static user name.	-

Parameter	Description	Value
mac-address	Specifies the user MAC address as the static user name.	-
system-name	Specifies the access device name as the static user name. To configure the device name, run the sysname command.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When a static user triggers authentication through an ARP packet, you can run the **static-user username format-include** command to set the user name for the static user. The access device then sends the user name to the authentication server.

NOTE

If the user name of a static user contains a device name whose length exceeds 16 bytes, the system uses only the first 16 bytes of the device name.

This function takes effect only for users who go online after this function is successfully configured.

Example

Set the user IP address as the static user name for authentication.

```
<HUAWEI> system-view  
[HUAWEI] static-user username format-include ip-address
```

Related Topics

- [13.4.185 static-user](#)
- [13.4.186 static-user password](#)
- [13.4.82 display static-user](#)

13.4.188 snmp-agent trap enable feature-name mid_aaa

Function

The **snmp-agent trap enable feature-name mid_aaa** command enables the trap function for the AAA module.

The **undo snmp-agent trap enable feature-name mid_aaa** command disables the trap function for the AAA module.

By default, the trap function is enabled for the AAA module.

Format

```
snmp-agent trap enable feature-name mid_aaa [ trap-name  
{ hwmacmovedquietmaxuseralarm | hwmacmovedquietuserclearalarm } ]
```

```
undo snmp-agent trap enable feature-name mid_aaa [ trap-name  
{ hwmacmovedquietmaxuseralarm | hwmacmovedquietuserclearalarm } ]
```

Parameters

Parameter	Description	Value
trap-name	Enables or disables the trap function for a specified event of the AAA module.	-
hwmacmovedquiet-maxuseralarm	Sends a Huawei proprietary trap message when the percentage of current MAC address migration users in quiet state against the maximum number of users exceeds the upper alarm threshold.	-
hwlpStaticUserMixe-dInsertAlarm	A Huawei proprietary trap message is sent when an exception occurs during the login attempt of a user with one MAC address and multiple IP addresses through an Eth-Trunk interface to which interfaces on different types of boards are added.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the trap function is enabled, the device generates traps during operation and sends the traps to the NMS through the SNMP module. If the trap function is disabled, the device does not generate traps and the SNMP module does not send traps to the NMS.

You can specify **trap-name** to enable the trap function for one or more events.

Example

Enable the trap function for hwmacmovedquietmaxuseralarm of the AAA module.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent trap enable feature-name mid_aaa trap-name
hwmacmovedquietmaxuseralarm
```

Related Topics

[13.4.86 display snmp-agent trap feature-name mid_aaa all](#)

13.4.189 snmp-agent trap enable feature-name mid_eapol

Function

The **snmp-agent trap enable feature-name mid_eapol** command enables the trap function for the DOT1X module.

The **undo snmp-agent trap enable feature-name mid_eapol** command disables the trap function for the DOT1X module.

By default, the trap function is enabled for the DOT1X module.

Format

```
snmp-agent trap enable feature-name mid_eapol [ trap-name  
{ hwmacauthenmaxuseralarm | hwsrvcfgeapmaxuseralarm } ]
```

```
undo snmp-agent trap enable feature-name mid_eapol [ trap-name  
{ hwmacauthenmaxuseralarm | hwsrvcfgeapmaxuseralarm } ]
```

Parameters

Parameter	Description	Value
trap-name	Enables or disables the trap function for a specified event of the DOT1X module.	-
hwmacauthenmaxuser-alarm	Enables the device to send a Huawei proprietary trap when the number of MAC address authentication users reaches the maximum number allowed on an interface.	-
hwsrvcfgeapmaxusera-larm	Enables the device to send a Huawei proprietary trap when the number of 802.1X authentication users reaches the maximum number allowed on an interface.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the trap function is enabled, the device generates traps during operation and sends the traps to the NMS through the SNMP module. If the trap function is disabled, the device does not generate traps and the SNMP module does not send traps to the NMS.

You can specify **trap-name** to enable the trap function for one or more events.

Example

Enable the trap function for hwmacauthenmaxuseralarm of the DOT1X module.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name mid_eapol trap-name hwmacauthenmaxuseralarm
```

Related Topics

[13.4.87 display snmp-agent trap feature-name mid_eapol all](#)

13.4.190 snmp-agent trap enable feature-name mid_web

Function

The **snmp-agent trap enable feature-name mid_web** command enables the trap function for the web authentication module.

The **undo snmp-agent trap enable feature-name mid_web** command disables the trap function for the web authentication module.

By default, the trap function is enabled for the web authentication module.

Format

```
snmp-agent trap enable feature-name mid_web [ trap-name  
{ hwportalmaxuseralarm | hwportaluserclearalarm | hwportalserverdown |  
hwportalserverup } ]
```

```
undo snmp-agent trap enable feature-name mid_web [ trap-name  
{ hwportalmaxuseralarm | hwportaluserclearalarm | hwportalserverdown |  
hwportalserverup } ]
```

Parameters

Parameter	Description	Value
trap-name	Enables or disables the trap function for a specified event of the web authentication module.	-
hwportalmaxuseralarm	Enables the device to send a Huawei proprietary trap when the number of online Portal authentication users exceeds the upper threshold.	-
hwportaluserclearalarm	Enables the device to send a Huawei proprietary trap when the number of online Portal authentication users falls below the lower threshold.	-
hwportalserverdown	Enables the device to send a Huawei proprietary trap when it detects that the Portal server changes from Up to Down.	-

Parameter	Description	Value
hwportalserverup	Enables the device to send a Huawei proprietary trap when it detects that the Portal server changes from Down to Up.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the trap function is enabled, the device generates traps during operation and sends the traps to the NMS through the SNMP module. If the trap function is disabled, the device does not generate traps and the SNMP module does not send traps to the NMS.

You can specify **trap-name** to enable the trap function for one or more events.

Example

Enable the trap function for hwportalmaxuseralarm of the web authentication module.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name mid_web trap-name hwportalmaxuseralarm
```

Related Topics

[13.4.88 display snmp-agent trap feature-name mid_web all](#)

13.4.191 traffic-filter acl

Function

The **traffic-filter acl** command configures ACL-based packet filtering.

The **undo traffic-filter acl** command deletes the ACL configured for packet filtering.

By default, ACL-based packet filtering is not configured.

NOTE

This command is supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI.

Format

```
traffic-filter inbound acl { acl-number | name acl-name }  
undo traffic-filter inbound acl { acl-number | name acl-name }
```

Parameters

Parameter	Description	Value
inbound	Configures packet filtering in the inbound direction of the interface.	-
<i>acl-number</i>	Specifies the ID of the user ACL configured for packet filtering.	The user ACL must exist.
name <i>acl-name</i>	Specifies the name of the user ACL configured for packet filtering.	The user ACL must exist.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In NAC network deployment, you can run the **13.4.195 ucl-group** command to classify users and configure user ACL rules numbered from 6000 to 9999. You can then implement intra-group isolation (users in a group cannot communicate with each other) and inter-group isolation (users in the user group cannot communicate with users in other user groups.), and control network access rights based on the UCL group.

After configuring ACL rules 6000 to 9999, you must run the **traffic-filter acl** command to configure ACL-based packet filtering. The ACL rules then can take effect for the users in the UCL group.

Precautions

If the user ACL specified in the **traffic-filter inbound acl** command or the user ACL delivered by the authentication server is incorrectly configured to block all user traffic, the switch cannot be connected and network-side protocols such as OSPF and BGP are interrupted.

Example

```
# Configure the device to filter the packets in the inbound direction of the  
interface based on ACL 6001.
```

```
<HUAWEI> system-view  
[HUAWEI] traffic-filter inbound acl 6001
```

Related Topics

- [13.4.195 ucl-group](#)
- [14.1.5 acl \(system view\)](#)
- [14.1.22 rule \(user ACL view\)](#)

13.4.192 traffic-redirect acl

Function

The **traffic-redirect acl** command configures ACL-based packet redirection.

The **undo traffic-redirect acl** command deletes the ACL configured for packet redirection.

By default, ACL-based packet redirection is not configured.

NOTE

This command is supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI.

Format

traffic-redirect inbound acl { *acl-number* | **name** *acl-name* } [**vpn-instance** *vpn-instance-name*] **ip-nexthop** *nexthop-address*

undo traffic-redirect inbound acl { *acl-number* | **name** *acl-name* }

Parameters

Parameter	Description	Value
inbound	Configures packet redirection in the inbound direction of the interface.	-
acl <i>acl-number</i>	Specifies the ID of the ACL configured for packet redirection.	The value is an integer that ranges from 6000 to 9999.
name <i>acl-name</i>	Filters packets based on a specified named ACL. <i>acl-name</i> specifies the name of the ACL.	The value must be the name of an existing user ACL.
vpn-instance <i>vpn-instance-name</i>	Redirects packets to a VPN instance.	The value must be the name of an existing VPN instance.

Parameter	Description	Value
ip-nexthop <i>nexthop-address</i>	Redirects packets to a next-hop IPv4 address.	The value is in dotted decimal notation.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In NAC network deployment, you can run the [13.4.195 ucl-group](#) command to classify users and configure user ACL rules numbered from 6000 to 9999. You can then implement intra-group isolation (users in a group cannot communicate with each other) and inter-group isolation (users in the user group cannot communicate with users in other user groups.), and control network access rights based on the UCL group.

After configuring ACL rules 6000 to 9999, you can run the **traffic-redirect acl** command to configure ACL-based packet redirection. The ACL rules then can take effect for the users in the UCL group.

When the **traffic-redirect** command and the [traffic-filter acl](#) command are used simultaneously, and the two commands are associated with the same ACL rule:

- If the deny action is configured in the ACL rule, traffic is discarded.
- If the permit action is configured in the ACL rule, traffic is redirected.

Precautions

If the destination address information about the packets to be filtered based on a user ACL rule contains UCL group, the ACL rule takes effect only for S5720HI.

Example

Configure the device to redirect the packets in the inbound direction of the interface based on ACL 6001.

```
<HUAWEI> system-view  
[HUAWEI] traffic-redirect inbound acl 6001 ip-nexthop 192.168.1.1
```

Related Topics

- [13.4.195 ucl-group](#)
- [14.1.5 acl \(system view\)](#)
- [14.1.22 rule \(user ACL view\)](#)

13.4.193 ucl-group (service scheme view)

Function

The **ucl-group** command binds a UCL group to a service scheme.

The **undo ucl-group** command unbinds the UCL group from the service scheme.

By default, no UCL group is bound to a service scheme.

NOTE

This command is supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI.

Format

ucl-group { *group-index* | **name** *group-name* }

undo ucl-group

Parameters

Parameter	Description	Value
<i>group-index</i>	Specifies the index of a UCL group.	The UCL group must exist.
name <i>group-name</i>	Specifies the name of a UCL group.	The UCL group must exist.

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After creating a service scheme using the [13.1.82 service-scheme \(AAA view\)](#) command, you can run the **ucl-group** command to bind a UCL group to the service scheme. The user assigned with the service scheme will have the functions of the UCL group.

Prerequisites

A UCL group has been created using the [13.4.195 ucl-group](#) command.

Example

```
# Bind the UCL group abc to the service scheme huawei.
```



```
<HUAWEI> system-view
[HUAWEI] ucl-group 10 name abc
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme huawei
[HUAWEI-aaa-service-huawei] ucl-group name abc
```

Related Topics

[13.1.82 service-scheme \(AAA view\)](#)

13.4.194 ucl-group ip

Function

The **ucl-group ip** command configures a static UCL group. The static UCL group is also called the static resource group.

The **undo ucl-group ip** command deletes the configured static UCL group.

By default, no static UCL group is configured.

NOTE

The static UCL group is only supported by S5720EI, S5720HI, S6720EI, and S6720S-EI.

Format

ucl-group ip *ip-address* { *mask-length* | *ip-mask* } { *group-index* | **name** *group-name* }

undo ucl-group ip { *ip-address* { *mask-length* | *ip-mask* } | *group-index* | **name** *group-name* | **all** }

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the IP address of a static UCL group. NOTE You can specify the IP address configured for the local device.	The value is in dotted decimal notation.
<i>mask-length</i>	Specifies the mask length of an IP address.	The value is an integer that ranges from 1 to 32.
<i>ip-mask</i>	Specifies the mask of the IP address.	The value is in dotted decimal notation.

Parameter	Description	Value
<i>group-index</i>	Specifies the index of a static UCL group.	The value is an integer that ranges from 1 to 64000 for S5720HI, and from 1 to 48 for S5720EI, S6720EI, and S6720S-EI.
name <i>group-name</i>	Specifies the name of a static UCL group.	The value must be an existing UCL group name on the device.
all	Specifies all static UCL groups.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In an enterprise network, a server that provides resources has a fixed IP address. The administrator can identify this server using a UCL group and associate the server IP address with the UCL group to form a static UCL group.

After a static UCL group is created for a resource server, the user access policies can be managed based on the static UCL group to simplify network deployment.

Prerequisites

A UCL group has been created using the [13.4.195 ucl-group](#) command.

Precautions

In the agile network ubiquitous service solution, this command does not need to be run on the device, and it is configured on the controller and delivered to the device.

UCL groups do not support IP address overlapping. The device cannot allocate users or resources with the same IP addresses in different VPNs to different UCL groups, and can only allocate these users or resources to the same UCL group.

Example

Configure the static UCL group named **email** with the IP address 10.1.1.1/24.

```
<HUAWEI> system-view
[HUAWEI] ucl-group 1 name email
[HUAWEI] ucl-group ip 10.1.1.1 24 name email
```

13.4.195 ucl-group

Function

The **ucl-group** command creates a UCL group.

The **undo ucl-group** command deletes the configured UCL group.

By default, no UCL group is created.

NOTE

UCL group is only supported by the S5720EI, S5720HI, S6720EI, and S6720S-EI.

Format

ucl-group *group-index* [**name** *group-name*]

undo ucl-group { **all** | *group-index* | **name** *group-name* }

Parameters

Parameter	Description	Value
<i>group-index</i>	Specifies the index of a UCL group.	The value is an integer that ranges from 1 to 48 for S5720EI, S6720EI, and S6720S-EI, and from 1 to 64000 for S5720HI.
name <i>group-name</i>	Specifies the name of a UCL group.	The value is a string of 1 to 31 case-sensitive characters without spaces. The value cannot be -, --, a, an, or any, and cannot contain the following special characters: / \ : * ? " < > @ ' %
all	Specifies the all UCL group.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In NAC network deployment, there are a large number of users and each user may be configured with many ACL rules. The ACL resources on the device are limited and therefore are insufficient to meet the demand of each user. If ACL rules are independently deployed for each user, the workload is heavy.

In actual NAC application, there are a large number of access users but the user types (users of a type have the same network access rights) are limited. The users can be classified using UCL groups (identify user types), and a group of ACL groups are deployed for users of the same type.

After you create UCL groups on the device and configure a UCL group for a user on the authentication server, the authentication server delivers the user's UCL group to the device when authenticating the user. In this way, the device obtains the mapping between users and UCL groups, and accordingly adds users to different UCL groups so that the users in each group can share the same ACL rules.

Follow-up Procedure

A UCL group only identifies a user type and does not control users' network access rights. To control the network access rights, you must first configure ACL rules numbered from 6000 to 9999 and then configure ACL-based packet filtering.

1. Run the [14.1.5 acl \(system view\)](#) command to create an ACL with the number range of 6000 to 9999.
2. Run the [14.1.22 rule \(user ACL view\)](#) to create rules for the ACL.
3. Run the [13.4.191 traffic-filter acl](#) command to configure ACL-based packet filtering.

Precautions

Example

Create a UCL group named **abc** with the group ID 10.

```
<HUAWEI> system-view  
[HUAWEI] ucl-group 10 name abc
```

Related Topics

- [14.1.5 acl \(system view\)](#)
- [14.1.22 rule \(user ACL view\)](#)
- [13.4.191 traffic-filter acl](#)

13.4.196 url (URL template view)

Function

The **url** command configures the redirection URL or pushed URL.

The **undo url** command cancels the redirection URL or pushed URL.

By default, no redirection URL or pushed URL is configured.

Format

url [**push-only** | **redirect-only**] *url-string* [**ssid** *ssid*]

undo url [**push-only** | **redirect-only**] [**ssid** *ssid*]

 NOTE

Only the S5720HI supports **ssid** *ssid*.

Parameters

Parameter	Description	Value
<i>url-string</i>	Specifies the redirection URL or pushed URL.	It is a string of 1 to 200 case-sensitive characters without spaces. When double quotation marks are used around the string, spaces are allowed in the string.
push-only	Specifies the URL as a pushed URL.	-
redirect-only	Specifies the URL as a redirection URL.	-
ssid <i>ssid</i>	Specifies the SSID that users associate with. This parameter is only valid for wireless access users. The SSID that users associate with must be the same as that configured on the device; otherwise, the device cannot push URLs to users.	The SSID must already exist.

Views

URL template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a URL template is created using the [13.4.200 url-template name](#) command, you can run this command to configure the redirection URL or pushed URL. The difference between redirection URL and pushed URL is as follows.

- Redirection URL: When a user without network access right connects to the network, the Portal authentication device redirects the user to the redirection URL for authentication.
- Pushed URL: After an authenticated user accesses the network through web for the first time, the access device pushes the web page corresponding to the URL to the user. The web access request from the user is redirected to the specified URL, and then the user is allowed to access network resources.

When configuring a URL on the device, you cannot enter a question mark (?). If a URL contains a question mark (?), you can run the **parameter start-mark #** command in the URL template view to replace the question mark (?) with the number sign (#).

Precautions

If the **push-only** and **redirect-only** parameters are not specified, the configured URL is used as both redirection URL and pushed URL. You can configure pushed URL using the **13.4.119 force-push** command, or use the **13.4.201 url-template (Portal server profile view)** command to bind a URL template to the Portal server profile to configure redirection URL.

Example

```
# Set the redirection URL to http://10.1.1.1.
```

```
<HUAWEI> system-view  
[HUAWEI] url-template name huawei  
[HUAWEI-url-template-huawei] url http://10.1.1.1
```

13.4.197 url (Portal server profile view)

Function

The **url** command configures the URL for a Portal server.

The **undo url** command restores the default setting.

By default, no URL is configured for a Portal server.

Format

url *url-string*

undo url

Parameters

Parameter	Description	Value
<i>url-string</i>	Specifies the URL of a portal server.	It is a string of 1 to 200 case-sensitive characters that do not contain spaces and question marks (?). When double quotation marks are used around the string, spaces are allowed in the string.

Views

Portal server profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the Portal server IP address is configured using the [13.4.181 server-ip \(Portal server profile view\)](#) command, the Portal server URL is generated by default on the device. If the existing Portal server URL is inconsistent with the default one or the domain name needs to be used, you need to run the **url** command to specify the Portal server URL.

Precautions

A Portal server only has one URL.

Example

```
# Set the URL of a Portal server to http://www.***.com in the Portal server profile huawei.
```

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server huawei  
[HUAWEI-web-auth-server-huawei] url http://www.***.com
```

Related Topics

[13.4.89 display web-auth-server configuration](#)

13.4.198 url-parameter mac-address format

Function

The **url-parameter mac-address format** command configures the MAC address format in URL.

The **undo url-parameter mac-address format** command restores the default MAC address format in URL.

By default, the MAC address format in URL is XXXXXXXXXXXX.

Format

```
url-parameter mac-address format delimiter delimiter { normal | compact }
```

```
undo url-parameter mac-address format
```

Parameters

Parameter	Description	Value
delimiter <i>delimiter</i>	Specifies the delimiter in MAC address.	The value is one case-sensitive character without spaces.
normal	Sets the MAC address format to XX-XX-XX-XX-XX-XX.	-

Parameter	Description	Value
compact	Sets the MAC address format to XXXX-XXXX-XXXX.	-

Views

URL template view

Default Level

2: Configuration level

Usage Guidelines

Portal servers or websites may require different MAC address formats. You can run the **url-parameter mac-address format** command to set MAC address formats in URL to meet the requirements of Portal servers or website.

Example

Set the delimiter to - and format to XXXX-XXXX-XXXX.

```
<HUAWEI> system-view
[HUAWEI] url-template name huawei
[HUAWEI-url-template-huawei] url-parameter mac-address format delimiter - compact
```

13.4.199 url-parameter

Function

The **url-parameter** command sets parameters in a URL.

The **undo url-parameter** command deletes parameters in a URL.

By default, a URL does not carry parameters.

Format

url-parameter { **ac-ip** *ac-ip-value* | **ac-mac** *ac-mac-value* | **ap-ip** *ap-ip-value* | **ap-mac** *ap-mac-value* | **ssid** *ssid-value* | **login-url** *url-key url* | **redirect-url** *redirect-url-value* | **sysname** *sysname-value* | **user-ipaddress** *user-ipaddress-value* | **user-mac** *user-mac-value* } *

undo url-parameter

NOTE

The **ac-ip** *ac-ip-value*, **ac-mac** *ac-mac-value*, **ap-ip** *ap-ip-value*, **ap-mac** *ap-mac-value*, and **ssid** *ssid-value* parameters are only supported by the S5720HI.

Parameters

Parameter	Description	Value
ac-ip <i>ac-ip-value</i>	Specifies the IP address of the AC carried in the URL and sets the parameter name displayed in the URL. This parameter applies only to wireless users. By default, the value of device-ip carried in the URL is the CAPWAP gateway address.	The value is a string of 1 to 16 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.
ac-mac <i>ac-mac-value</i>	Specifies the MAC address of the AC carried in the URL and sets the parameter name displayed in the URL.	The value is a string of 1 to 16 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.
ap-ip <i>ap-ip-value</i>	Specifies the AP IP address carried in the URL and sets the parameter name. This parameter is only valid for wireless access users.	The value is a string of 1 to 16 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.
ap-mac <i>ap-mac-value</i>	Specifies the AP MAC address carried in the URL and sets the parameter name. This parameter is only valid for wireless access users.	The value is a string of 1 to 16 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.
ssid <i>ssid-value</i>	Specifies the SSID associated that users associate with carried in the URL and sets the parameter name. This parameter is only valid for wireless access users.	The value is a string of 1 to 16 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.

Parameter	Description	Value
login-url <i>url-key url</i>	<p>Specifies the login URL of the access device.</p> <ul style="list-style-type: none"> • <i>url-key</i>: specifies the identification keyword for the login URL sent to the Portal server during redirection. • <i>url</i>: is a specified URL on the access device. 	<ul style="list-style-type: none"> • <i>url-key</i>: The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=). • <i>url</i>: The value is a string of 1 to 200 case-sensitive characters without spaces.
redirect-url <i>redirect-url-value</i>	<p>Specifies the original URL that a user accesses carried in the URL and sets the parameter name.</p>	<p>The value is a string of 1 to 16 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.</p>
sysname <i>sysname-value</i>	<p>Specifies the device system name carried in the URL and sets the parameter name.</p>	<p>The value is a string of 1 to 16 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.</p>
user-ipaddress <i>user-ipaddress-value</i>	<p>Specifies the user IP address carried in the URL and sets the parameter name.</p>	<p>The value is a string of 1 to 16 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.</p>

Parameter	Description	Value
user-mac <i>user-mac-value</i>	Specifies the user MAC address carried in the URL and sets the parameter name.	The value is a string of 1 to 16 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.

Views

URL template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a URL template is created using the [13.4.200 url-template name](#) command and URL is configured using the [13.4.196 url \(URL template view\)](#) command, you can use the **url-parameter** command to set the parameters in the URL. When a user accesses the Portal server according to the URL, the Portal server obtains user terminal information through the parameters in the URL. The Portal server then provides the corresponding web authentication page for the user according to user terminal information.

In addition, when users are pushed to a website rather than the Portal server according to the URL, the website provides the different web pages for the users according to user terminal information carried in the URL.

Precautions

URL parameter names configured on the device must be the same as those supported by the server. In this example, the device is connected to the Agile Controller-Campus.

URL Parameter	URL Parameter Name Supported by the Agile Controller-Campus
ac-ip	ac-ip
ap-mac	apmac
ssid	ssid
redirect-url	url
user-ipaddress	userip

URL Parameter	URL Parameter Name Supported by the Agile Controller-Campus
user-mac	usermac

Example

Set the user MAC address and access device system name in the URL.

```
<HUAWEI> system-view
[HUAWEI] url-template name huawei
[HUAWEI-url-template-huawei] url-parameter user-mac usermac sysname huawei
```

13.4.200 url-template name

Function

The **url-template name** command creates a URL template or displays an existing URL template view.

The **undo url-template name** command deletes a URL template.

By default, no URL template exists on the device.

Format

url-template name *template-name*

undo url-template name *template-name*

Parameters

Parameter	Description	Value
<i>template-name</i>	Specifies the name of a URL template.	The value is a string of 1 to 31 case-sensitive characters. It cannot contain spaces or the following symbols: / \ : * ? " < > @ ' %. The value cannot be - or --.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After a Portal authentication server template is created using the [13.4.211 web-auth-server \(system view\)](#) command, you can bind a URL template to the Portal authentication server template. The URL template contains the redirection URL and redirection URL parameters.

The **url-template name** command creates a URL template or displays an existing URL template view.

Example

```
# Create a URL template named huawei and enter the template view.
```

```
<HUAWEI> system-view  
[HUAWEI] url-template name huawei
```

13.4.201 url-template (Portal server profile view)

Function

The **url-template** command binds a URL template to a Portal server profile.

The **undo url-template** command unbinds a URL template from a Portal server profile.

By default, no URL template is bound to a Portal server profile.

Format

url-template *url-template* [**ciphered-parameter-name** *ciphered-parameter-name* **iv-parameter-name** *iv-parameter-name* **key cipher** *key-string*]

undo url-template

Parameters

Parameter	Description	Value
<i>url-template</i>	Specifies the name of a URL template.	The value must be an existing URL template name.
ciphered-parameter-name <i>ciphered-parameter-name</i>	Specifies the name of the encrypted URL template parameter.	The value is a string of 1 to 16.
iv-parameter-name <i>iv-parameter-name</i>	Specifies the encryption vector name of the URL template parameter.	The value is a string of 1 to 16.

Parameter	Description	Value
key cipher <i>key-string</i>	Specifies the shared key for encrypting the URL template parameter.	The value is a string of 1 to 16 plain-text characters or 48 cipher-text characters.

Views

Portal server profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the parameters of a URL template are configured, the URL template must be bound to a Portal authentication server template so that users can be authenticated on the Portal authentication server corresponding to the redirection URL.

To ensure security, you can encrypt the parameter information in the URL template bound to the Portal server profile.

Prerequisites

A URL template has been created using the [13.4.200 url-template name](#) command.

Precautions

If a URL template is bound to the Portal authentication server template and the [13.4.197 url \(Portal server profile view\)](#) command is executed to configure the redirection URL corresponding to the Portal authentication server, only the parameters in the URL template take effect.

The URL configured using the [13.4.196 url \(URL template view\)](#) command in the URL template view cannot be a pushed URL; otherwise, the command does not take effect.

The device support encryption of parameter information in the URL template only when it connects to the Huawei Agile Controller-Campus.

Example

Bind the URL template **abc** to the Portal authentication server template.

```
<HUAWEI> system-view
[HUAWEI] url-template name abc
[HUAWEI-url-template-abc] quit
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] url-template abc
```

13.4.202 user-sync

Function

The **user-sync** command enables Portal authentication user information synchronization.

The **undo user-sync** command disables Portal authentication user information synchronization.

By default, Portal authentication user information synchronization is disabled.

Format

user-sync [**interval** *interval-period* | **max-times** *times*] *

undo user-sync

Parameters

Parameter	Description	Value
interval <i>interval-period</i>	Specifies the user information synchronization interval.	The value is an integer that ranges from 30 to 65535, in seconds. The default value is 300.
max-times <i>times</i>	Specifies the maximum number of user information synchronization failures.	The value is an integer that ranges from 2 to 255. The default value is 3.

Views

Portal server profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If communication is interrupted because the network between the device and Portal server is disconnected or the Portal server is faulty, online Portal authentication users cannot go offline. Therefore, user information on the device and on the Portal server may be inconsistent and accounting may be inaccurate.

The **user-sync** command enables user information synchronization so that user information on the device and Portal server is synchronized at intervals to ensure user information consistency.

During information synchronization, the device does not disconnect the user immediately after detecting that the device has certain user information while the

server does not have such information. Instead, the device disconnects the user when the maximum number of user information synchronization failures is reached.

Precautions

If users go online during the keepalive interval of the Portal server, the Portal server does not have their entries. After the Portal server goes Up and starts synchronizing user information, the device does not disconnect these users even if synchronization fails. The device retains these users until next time these users go online and performs Portal authentication, ensuring good user experience.

The value of *interval-period*times* configured on the device must be greater than the interval for the Portal server to send synchronization packets. Otherwise, the device may force users offline when it cannot receive any synchronization packet from the Portal server after the maximum failure number is reached.

When you run the **user-sync** command, make sure that the Portal server supports this function. Otherwise, the users will go offline.

Example

Enable user information synchronization in the Portal server profile **abc**, set the interval for user information synchronization to 100s, and set the maximum number of synchronization failures to 5.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server abc
[HUAWEI-web-auth-server-abc] user-sync interval 100 max-times 5
```

13.4.203 vm-authen password

Function

The **vm-authen password** command configures a password for virtual users during RADIUS authentication.

The **undo vm-authen password** command restores the default password for virtual users during RADIUS authentication.

The default username and password are available in *S Series Switches Default Usernames and Passwords* ([Enterprise Network](#) or [Carrier](#)). If you have not obtained the access permission of the document, see [Help](#) on the website to find out how to obtain it.

NOTE

Only the S5720EI supports this command.

Format

vm-authen password cipher *password*

undo vm-authen password

Parameters

Parameter	Description	Value
cipher	Displays a password in cipher text.	-
<i>password</i>	Specifies the password for virtual users during RADIUS authentication.	The value is a case-sensitive string without question marks (?) or spaces. The password contains 1 to 16 characters in plain text or 32 characters in cipher text.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

You can run the **vm-authen password** command to configure a password for virtual users during RADIUS authentication.

Precautions

To improve security, change the default password immediately. It is recommended that the new password contains at least two types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 6 characters.

Example

```
# Set the password huawei for virtual users during RADIUS authentication.  
<HUAWEI> system-view  
[HUAWEI] vm-authen password cipher huawei
```

13.4.204 vm-user association-type

Function

The **vm-user association-type** command configures the association type of a virtual user.

NOTE

Only the S5720EI supports this command.

Format

vm-user association-type { **online** | **pre-online** | **offline** } **mac-address** *mac-address* **interface** *interface-type interface-number* **vlan** *vlan-id* [**ip-address** *ip-address* | **profile** *profile-name* | **vsi** *vsi-name*] *

Parameters

Parameter	Description	Value
online	Indicates that the association type of the virtual user is online.	-
pre-online	Indicates that the association type of the virtual user is pre-online.	-
offline	Indicates that the association type of the virtual user is offline.	-
mac-address <i>mac-address</i>	Specifies the MAC address of the virtual user.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.
interface <i>interface-type interface-number</i>	Specifies the number or name of an interface for associating with a virtual user. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-
vlan <i>vlan-id</i>	Specifies the VLAN to which the virtual user belongs.	The value is an integer that ranges from 0 to 4094.
ip-address <i>ip-address</i>	Specifies the IP address of the virtual user.	The value is in dotted decimal notation.
profile <i>profile-name</i>	Specifies the profile to which the virtual user belongs.	The value is a string of 1 to 64 case-sensitive characters without spaces.
vsi <i>vsi-name</i>	Specifies the name of the virtual site interface.	The value is a string of 1 to 64 case-sensitive characters without spaces.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In virtual network management, you must configure the function specified by the **vm-user association-type** command on the network management system (NMS) so that virtual users can access the network. The NMS then delivers the function configuration to the device. After receiving the related function configuration, the device automatically runs the **vm-user association-type** command to configure the association type of the virtual user.

Precautions

This command should be configured by the network administrator on the NMS and delivered to the device. You are not advised to directly run this command on the device.

Example

```
# Set the association type of the virtual user with the MAC address 1-1-1 in VLAN  
10 on GE0/0/1 to pre-online.  
<HUAWEI> system-view  
[HUAWEI] vm-user association-type pre-online mac-address 1-1-1 interface gigabitethernet 0/0/1 vlan  
10
```

13.4.205 user-vlan (service scheme view)

Function

The **user-vlan** command configures a user VLAN in a service scheme.

The **undo user-vlan** command deletes the user VLAN configured in the service scheme.

By default, no user VLAN is configured in the service scheme.

Format

user-vlan *vlan-id*

undo user-vlan

Parameters

Parameter	Description	Value
<i>vlan-id</i>	Specifies the VLAN ID.	The value is an integer that ranges from 1 to 4094.

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After creating a service scheme using the [13.1.82 service-scheme \(AAA view\)](#) command, you can run the **vlan** command to configure a user VLAN in the service scheme. The user assigned with the service scheme will be added to the user VLAN and obtain network resources in the VLAN.

Precautions

An authorized VLAN cannot be delivered to online Portal users.

If the user access mode is not **multi-share**, you must configure the link type of the interface connected to users to hybrid and configure user packets to pass through the interface in untagged mode. After the configuration, this command can take effect.

Example

Configure user VLAN 100 in the service scheme **huawei**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme huawei
[HUAWEI-aaa-service-huawei] user-vlan 100
```

Related Topics

[13.1.82 service-scheme \(AAA view\)](#)

13.4.206 voice-vlan (service scheme view)

Function

The **voice-vlan** command enables the voice VLAN in a service scheme.

The **undo voice-vlan** command restores the default setting.

By default, the voice VLAN is disabled in the service scheme.

Format

voice-vlan

undo voice-vlan

Parameters

None

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After creating a service scheme using the [13.1.82 service-scheme \(AAA view\)](#) command, you can run the **voice-vlan** command to enable the voice VLAN in the service scheme. The voice user assigned with the service scheme will be added to the voice VLAN and obtain network resources in the VLAN.

Precautions

- An authorized VLAN cannot be delivered to online Portal users.
- To make this command take effect, you must have run the [5.7.4 voice-vlan enable](#) command to configure a specified VLAN as the voice VLAN and enable the voice VLAN on the interface.
- If the user access mode is set to **multi-share**, authorized voice VLANs are not supported.
- This command takes effect only to authorization of users who fail to be authenticated or voice terminals who can go online without authentication (configured using the [13.4.15 authentication device-type voice authorize](#) command).

Example

Enable the voice VLAN in the service scheme **huawei**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme huawei
[HUAWEI-aaa-service-huawei] voice-vlan
```

Related Topics

[13.1.82 service-scheme \(AAA view\)](#)

13.4.207 vpn-instance (Portal server template view)

Function

The **vpn-instance** command configures a VPN instance used for communication between the device and Portal server.

The **undo vpn-instance** command restores the default setting.

By default, no VPN instance is configured for communication between the device and Portal server.

NOTE

Only S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support the command.

Format

vpn-instance *vpn-instance-name*

undo vpn-instance

Parameters

Parameter	Description	Value
<i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The value must be an existing VPN instance name.

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A VPN implements interconnection within the same department and between different departments in an enterprise. To enable the Portal authentication service in the VPN, run the **vpn-instance** command to bind a Portal server template to a VPN instance.

Prerequisites

A VPN instance has been created using the **ip vpn-instance** command.

Precautions

The VPN instance bound to the Portal server template must be the same as that bound to the Portal server.

The users in VPN instances bound to different Portal server templates cannot use the same IP addresses because users with the same IP addresses cannot go online or offline.

Example

Bind the Portal server template **abc** to the VPN instance **vpn1**.

```
<HUAWEI> system-view
[HUAWEI] ip vpn-instance vpn1
[HUAWEI-vpn-instance-vpn1] ipv4-family
[HUAWEI-vpn-instance-vpn1-af-ipv4] quit
[HUAWEI-vpn-instance-vpn1] quit
[HUAWEI] web-auth-server abc
[HUAWEI-web-auth-server-abc] vpn-instance vpn1
```

13.4.208 web-auth-server listening-port

Function

The **web-auth-server listening-port** command sets the number of the port through which a device listens on Portal protocol packets.

The **undo web-auth-server listening-port** command restores the default listening port.

By default, the device uses port 2000 to listen on Portal protocol packets.

Format

web-auth-server listening-port *port-number*

undo web-auth-server listening-port

Parameters

Parameter	Description	Value
<i>port-number</i>	Specifies the number of the listening port.	The value is an integer that ranges from 1024 to 55535.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When the device exchanges user authentication information with the Portal server using the Portal protocol, you must configure the listening port on the device to receive Portal packets.

You can run the **web-auth-server listening-port** command to set the number of the port through which the device listens on Portal packets. The port number must be the same as the destination port number in Portal packets sent by the Portal server and must be unique.

NOTE

If a specified port is occupied by another service or is a reserved port, the configuration fails. Ensure that the specified port is available when running this command.

Example

```
# Set the number of the port through which a device listens on Portal protocol packets to 3000.
```

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server listening-port 3000
```

Related Topics

[13.4.89 display web-auth-server configuration](#)

13.4.209 web-auth-server (Portal access profile view)

Function

The **web-auth-server** command configures the Portal server profile used by a Portal access profile.

The **undo web-auth-server** command restores the default setting.

By default, a Portal access profile does not use any Portal server profile.

Format

```
web-auth-server server-name [ bak-server-name ] { direct | layer3 }
```

```
undo web-auth-server
```

Parameters

Parameter	Description	Value
<i>server-name</i>	Specifies the name of a Portal server profile.	The value must be an existing Portal server profile name.

Parameter	Description	Value
<i>bak-server-name</i>	Specifies the name of a backup Portal server profile. NOTE The name of the backup Portal server profile cannot be configured to the command-line keywords direct and layer3 .	The value must be an existing Portal server profile name.
direct	Sets the Portal authentication mode to Layer 2 authentication.	-
layer3	Sets the Portal authentication mode to Layer 3 authentication.	-

Views

Portal access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a Portal server profile is configured on the device, this profile must be bound to a Portal access profile. When users who use the Portal access profile attempt to access charged network resources, the HTTP requests are forcibly redirected to the authentication page of the Portal server to implement Portal authentication.

To improve Portal authentication reliability, the backup Portal server profile can also be bound to the Portal access profile. When the primary Portal server is disconnected, the users are redirected to the backup Portal server for authentication. This function can take effect only when the Portal server detection function is enabled using the [13.4.180 server-detect](#) command and heartbeat detection is enabled on the Portal server.

The following Portal authentication modes are available:

- **direct**: When there is no Layer 3 forwarding device between the device and a user, the device can learn the user's MAC address. You can configure the Layer 2 authentication mode so that the device can identify the user using the IP address and MAC address.
- **layer3**: When there is a Layer 3 forwarding device between the device and a user, the device cannot learn the user's MAC address and can only identify the user using the IP address. You need to configure the Layer 3 authentication mode.

Prerequisites

A Portal server profile has been created using [13.4.211 web-auth-server \(system view\)](#) and the IP address of the Portal server has been configured using [13.4.181 server-ip \(Portal server profile view\)](#).

Precautions

- After a Portal access profile is bound to an authentication profile, the Portal server profile used in the Portal access profile cannot be deleted, but can be modified.
- The support for Portal authentication varies depending on different interfaces, routed main interfaces (Only S5720EI, S5720HI, S6720EI, and S6720S-EI) support only Layer 3 Portal authentication, Layer 2 interfaces support only Layer 2 Portal authentication, and VLANIF interfaces support both Layer 2 and Layer 3 Portal authentication.
- This command does not take effect on the VLANIF interface corresponding to the super VLAN.
- When the direct forwarding mode is used for wireless users and Portal authentication is enabled on the VLANIF interface, the branched networking must be used for the device to make Portal authentication take effect.

Example

Bind the Portal access profile **p1** to the Portal server profiles **server1** and **server2** (backup Portal server profile), and configure the Layer 2 authentication mode.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server server1
[HUAWEI-web-auth-server-server1] server-ip 10.10.1.1
[HUAWEI-web-auth-server-server1] quit
[HUAWEI] web-auth-server server2
[HUAWEI-web-auth-server-server2] server-ip 10.10.2.1
[HUAWEI-web-auth-server-server2] quit
[HUAWEI] portal-access-profile name p1
[HUAWEI-portal-access-profile-p1] web-auth-server server1 server2 direct
```

Related Topics

- [13.4.211 web-auth-server \(system view\)](#)
- [13.4.181 server-ip \(Portal server profile view\)](#)
- [13.4.89 display web-auth-server configuration](#)
- [13.4.61 display authentication-profile configuration](#)

13.4.210 web-auth-server reply-message

Function

The **web-auth-server reply-message** command enables the device to transparently transmit users' authentication responses sent by the authentication server to the Portal server.

The **undo web-auth-server reply-message** command disables the device from transparently transmitting users' authentication responses sent by the authentication server to the Portal server.

By default, the device transparently transmits users' authentication responses sent by the authentication server to the Portal server.

Format

web-auth-server reply-message
undo web-auth-server reply-message

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The AAA server requires that the authentication messages sent to the Portal server contain the authentication reply; therefore, the **web-auth-server reply-message** command is required. In certain situations, the authentication messages are not required to carry the reply. In this case, run the **undo web-auth-server reply-message** command.

By default, the device directly forwards the authentication result message from the RADIUS server to the Portal server without processing. This is called transparent transmission.

Example

Disable the device from transparently transmitting users' authentication responses to the Portal server.

```
<HUAWEI> system-view  
[HUAWEI] undo web-auth-server reply-message
```

Related Topics

[13.4.89 display web-auth-server configuration](#)

13.4.211 web-auth-server (system view)

Function

The **web-auth-server** command creates a portal server profile or displays the portal server profile view.

The **undo web-auth-server** command deletes a portal server profile.

By default, no portal server template exists.

Format

web-auth-server *server-name*

undo web-auth-server *server-name*

Parameters

Parameter	Description	Value
<i>server-name</i>	Specifies the name of a portal server.	The value is a string of 1 to 31 case-sensitive characters. It cannot contain spaces or the following symbols: / \ : * ? " < > @ ' %. The value cannot be - or --. NOTE <i>server-name</i> cannot be set to listening-port, reply-message, version, or the first character or several leftmost characters of these character strings.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When an unauthenticated portal user goes online, the device forces the user to log in to a specified website (also called the portal website). The user can access resources in the portal website for free. When the user attempts to access charged network resources, the user must pass authentication on the portal website. The specific process is as follows:

1. The unauthorized user opens Internet Explorer and enters a URL in the address box. When receiving the HTTP request sent by the user, the device redirects it to the portal authentication page of the portal server.
2. The user enters user information on the authentication page or in the authentication dialog box, and the portal server forwards the user information to the device.
3. After receiving the user information from the portal server, the device sends the information to the authentication server for authentication and accounting.
4. After the user is authenticated, the device allows the user to access the Internet if no security policy is enforced.

After a portal server profile is created on the device by using the **web-auth-server** command, run other commands to create a route from the device to the portal server.

Follow-up Procedure

Run the following commands to configure related attributes of the portal server profile:

- Run the [13.4.181 server-ip \(Portal server profile view\)](#) command to configure an IP address for the portal server.
- Run the [13.4.197 url \(Portal server profile view\)](#) command to configure a URL of the portal server.
- Run the [13.4.138 port \(Portal server profile view\)](#) command to set the port number that a portal server uses to receive notification packets from the device.
- Run the [13.4.182 shared-key \(Portal server profile view\)](#) command configures the shared key that the device uses to exchange information with the portal server.

Precautions

You are advised to back up the portal server data to prevent authentication failure caused by the portal server fault.

Example

```
# Create portal server profile named huawei.
```

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server huawei
```

Related Topics

- [13.4.89 display web-auth-server configuration](#)
- [13.4.197 url \(Portal server profile view\)](#)
- [13.4.181 server-ip \(Portal server profile view\)](#)
- [13.4.138 port \(Portal server profile view\)](#)
- [13.4.182 shared-key \(Portal server profile view\)](#)

13.4.212 web-auth-server version

Function

The **web-auth-server version** command sets the Portal protocol version supported by the device.

The **undo web-auth-server version** command restores the default setting.

By default, the device supports both the versions V1.0 and V2.0.

Format

```
web-auth-server version v2 [ v1 ]
```

undo web-auth-server version

Parameters

Parameter	Description	Value
v2	Indicates that the device supports the Portal protocol version V2.0. The major version currently used is V2.0.	-
v1	Indicates that the device supports the Portal protocol version V1.0.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Currently, the Portal protocol has two versions: V1.0 and V2.0. The device and Portal server must use the Portal protocol of the same version to ensure normal communication. You can run the **web-auth-server version** command to set the Portal protocol version supported by the device.

NOTE

The version V2.0 is widely used currently.

To ensure smooth communication, the device supports both versions by default.

Example

Configure the device to use only the Portal protocol V2.0.

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server version v2
```

Related Topics

[13.4.89 display web-auth-server configuration](#)

13.4.213 web-redirectation disable (Portal server profile view)

Function

The **web-redirectation disable** command disables the Portal authentication redirection function.

The **undo web-redirectation disable** command enables the Portal authentication redirection function.

By default, the Portal authentication redirection function is enabled.

Format

web-redirection disable
undo web-redirection disable

Parameters

None

Views

Portal server profile view

Default Level

2: Configuration level

Usage Guidelines

The device redirects all unauthenticated users to the Portal authentication page when the users send access requests to external networks. For example, when the user needs to enter the URL of the authentication page manually, the **web-redirection disable** command can be executed so that unauthorized users are not forcibly redirected to the Portal authentication page.

Example

Disable the Portal authentication redirection function.

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server nac  
[HUAWEI-web-auth-server-nac] web-redirection disable
```

Related Topics

[13.4.89 display web-auth-server configuration](#)

13.5 NAC Configuration Commands (Common Mode)

[13.5.1 Command Support](#)

[13.5.2 access-user arp-detect](#)

[13.5.3 access-user arp-detect default ip-address](#)

[13.5.4 access-user syslog-restrain enable](#)

[13.5.5 access-user syslog-restrain period](#)

[13.5.6 acl-id \(user group view\)](#)

[13.5.7 authentication critical eapol-success](#)

[13.5.8 authentication critical-vlan](#)

[13.5.9 authentication device-type voice authorize](#)

- 13.5.10 authentication event
- 13.5.11 authentication event response-fail
- 13.5.12 authentication event session-timeout
- 13.5.13 authentication guest-vlan
- 13.5.14 authentication mac-move enable
- 13.5.15 authentication mac-move detect enable
- 13.5.16 authentication mac-move detect retry-interval retry-time
- 13.5.17 authentication mac-move quiet-log enable
- 13.5.18 authentication mac-move quiet-times quiet-period
- 13.5.19 authentication mac-move quiet-user-alarm enable
- 13.5.20 authentication mac-move quiet-user-alarm percentage
- 13.5.21 authentication max-reauth-req
- 13.5.22 authentication open
- 13.5.23 authentication restrict-vlan
- 13.5.24 authentication speed-limit auto
- 13.5.25 authentication timer re-authen
- 13.5.26 band-width share-mode
- 13.5.27 car (user group view)
- 13.5.28 cut access-user
- 13.5.29 display aaa statistics access-type-authenreq
- 13.5.30 display authentication mode
- 13.5.31 display access-user
- 13.5.32 display authentication mac-move configuration
- 13.5.33 display authentication mac-move quiet-user
- 13.5.34 display dot1x
- 13.5.35 display dot1x quiet-user
- 13.5.36 display mac-address authen
- 13.5.37 display mac-address pre-authen
- 13.5.38 display mac-authen
- 13.5.39 display mac-authen quiet-user
- 13.5.40 display port connection-type access all
- 13.5.41 display portal
- 13.5.42 display portal free-rule

- 13.5.43 display portal local-server
- 13.5.44 display portal local-server connect
- 13.5.45 display portal local-server page-information
- 13.5.46 display portal quiet-user
- 13.5.47 display portal user-logout
- 13.5.48 display portal url-encode configuration
- 13.5.49 display server-detect state
- 13.5.50 display snmp-agent trap feature-name mid_aaa all
- 13.5.51 display snmp-agent trap feature-name mid_eapol all
- 13.5.52 display snmp-agent trap feature-name mid_web all
- 13.5.53 display static-user
- 13.5.54 display url-template
- 13.5.55 display user-group
- 13.5.56 display web-auth-server configuration
- 13.5.57 device-sensor dhcp option
- 13.5.58 device-sensor lldp tlv
- 13.5.59 dot1x authentication-method
- 13.5.60 dot1x dhcp-trigger
- 13.5.61 dot1x domain
- 13.5.62 dot1x eap-notify-packet
- 13.5.63 dot1x enable
- 13.5.64 dot1x free-ip
- 13.5.65 dot1x handshake
- 13.5.66 dot1x handshake packet-type
- 13.5.67 dot1x mac-bypass
- 13.5.68 dot1x mac-bypass access-port
- 13.5.69 dot1x mac-bypass mac-auth-first
- 13.5.70 dot1x max-user
- 13.5.71 dot1x mc-trigger
- 13.5.72 dot1x mc-trigger port-up-send enable
- 13.5.73 dot1x port-control
- 13.5.74 dot1x port-method
- 13.5.75 dot1x quiet-period

- 13.5.76 dot1x quiet-times
- 13.5.77 dot1x reauthenticate
- 13.5.78 dot1x reauthenticate mac-address
- 13.5.79 dot1x retry
- 13.5.80 dot1x timer
- 13.5.81 dot1x timer reauthenticate-period
- 13.5.82 dot1x trigger dhcp-binding
- 13.5.83 dot1x unicast-trigger
- 13.5.84 dot1x url
- 13.5.85 force-push
- 13.5.86 http get-method enable
- 13.5.87 http-method post
- 13.5.88 mac-authen
- 13.5.89 mac-authen trigger
- 13.5.90 mac-authen dhcp-trigger dhcp-option
- 13.5.91 mac-authen domain
- 13.5.92 mac-authen max-user
- 13.5.93 mac-authen offline dhcp-release
- 13.5.94 mac-authen permit mac-address
- 13.5.95 mac-authen quiet-times
- 13.5.96 mac-authen reauthenticate
- 13.5.97 mac-authen reauthenticate dhcp-renew
- 13.5.98 mac-authen reauthenticate mac-address
- 13.5.99 mac-authen timer
- 13.5.100 mac-authen timer reauthenticate-period
- 13.5.101 mac-authen username
- 13.5.102 parameter
- 13.5.103 port connection-type access
- 13.5.104 port (Portal server template view)
- 13.5.105 portal auth-network
- 13.5.106 portal domain
- 13.5.107 portal free-rule
- 13.5.108 portal local-server

- 13.5.109 portal local-server ad-image load
- 13.5.110 portal local-server anonymous
- 13.5.111 portal local-server authentication-method
- 13.5.112 portal local-server background-color
- 13.5.113 portal local-server background-image load
- 13.5.114 portal local-server enable
- 13.5.115 portal local-server ip
- 13.5.116 portal local-server keep-alive
- 13.5.117 portal local-server load
- 13.5.118 portal local-server logo load
- 13.5.119 portal local-server page-text load
- 13.5.120 portal local-server policy-text load
- 13.5.121 portal local-server syslog-limit enable
- 13.5.122 portal local-server syslog-limit period
- 13.5.123 portal local-server timer session-timeout
- 13.5.124 portal logout different-server enable
- 13.5.125 portal logout resend timeout
- 13.5.126 portal max-user
- 13.5.127 portal quiet-period
- 13.5.128 portal quiet-times
- 13.5.129 portal timer offline-detect
- 13.5.130 portal timer quiet-period
- 13.5.131 portal url-encode enable
- 13.5.132 portal user-alarm percentage
- 13.5.133 portal web-authen-server
- 13.5.134 protocol (Portal server template view)
- 13.5.135 remark
- 13.5.136 reset aaa statistics access-type-authenreq
- 13.5.137 reset access-user traffic-statistics
- 13.5.138 reset dot1x statistics
- 13.5.139 reset mac-authen statistics
- 13.5.140 server-detect
- 13.5.141 server-ip (Portal server template view)

- 13.5.142 shared-key (Portal server template view)
- 13.5.143 snmp-agent trap enable feature-name mid_aaa
- 13.5.144 snmp-agent trap enable feature-name mid_eapol
- 13.5.145 snmp-agent trap enable feature-name mid_web
- 13.5.146 source-ip (Portal server template view)
- 13.5.147 static-user
- 13.5.148 static-user password
- 13.5.149 static-user username format-include
- 13.5.150 url (Portal server template view)
- 13.5.151 url (URL template view)
- 13.5.152 url-parameter
- 13.5.153 url-parameter mac-address format
- 13.5.154 url-template (Portal server template view)
- 13.5.155 url-template name
- 13.5.156 user-group
- 13.5.157 user-group enable
- 13.5.158 user-sync
- 13.5.159 user-vlan (user group view)
- 13.5.160 vm-authen password
- 13.5.161 vm-user association-type
- 13.5.162 vpn-instance (Portal server template view)
- 13.5.163 web-auth-server version
- 13.5.164 web-auth-server (interface view)
- 13.5.165 web-auth-server listening-port
- 13.5.166 web-auth-server reply-message
- 13.5.167 web-auth-server (system view)
- 13.5.168 web-redirectation disable (Portal server template view)

13.5.1 Command Support

The S2750EI, S5700-10P-LI-AC, and S5700-10P-PWR-LI-AC support external Portal authentication only when Layer 3 hardware forwarding of IPv4 packets is enabled. To configure Layer 3 hardware forwarding of IPv4 packets, see **Configuring Layer 3 Hardware Forwarding of IPv4 Packets**.

13.5.2 access-user arp-detect

Function

The **access-user arp-detect** command sets the source IP address and source MAC address of offline detection packets in a VLAN.

The **undo access-user arp-detect** command deletes the source IP address and source MAC address of offline detection packets in a VLAN.

By default, the source IP address and source MAC address are not specified for offline detection packets in a VLAN.

Format

access-user arp-detect vlan *vlan-id* **ip-address** *ip-address* **mac-address** *mac-address*

undo access-user arp-detect vlan *vlan-id* **ip-address** *ip-address* **mac-address** *mac-address*

Parameters

Parameter	Description	Value
vlan <i>vlan-id</i>	Specifies a VLAN ID.	The value is an integer that ranges from 1 to 4094.
ip-address <i>ip-address</i>	Specifies the source IP address of offline detection packets.	The value is in dotted decimal notation.
mac-address <i>mac-address</i>	Specifies the source MAC address of offline detection packets.	The value is a unicast MAC address in H-H-H format, where H can be one to four hexadecimal digits.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device sends an ARP probe packet to check the user online status. If the user does not respond within a detection period, the device considers that the user is offline.

If the VLAN to which the user belongs does not have a VLANIF interface or the VLANIF interface does not have an IP address, the device sends an offline detection packet using 0.0.0.0 as the source IP address. If a user cannot respond to an ARP probe packet with the source IP address 0.0.0.0, you can specify a source IP address for the offline detection packet.

In addition, a Windows client sends an ARP probe packet with the source IP address 0.0.0.0 after obtaining an IP address. In this case, if the device also sends an ARP probe packet with the source IP address 0.0.0.0, an IP address conflict occurs. In this case, you can specify an IP address as the source IP address of ARP probe packets sent by the device.

You are advised to specify the user gateway IP address and its corresponding MAC address as the source IP address and source MAC address of ARP probe packets sent by the device. If the gateway device changes, update the source MAC address of the ARP probe packets sent by the device in a timely manner. Otherwise, the gateway ARP entry on terminals may be incorrect, causing network disconnection.

Precautions

This function does not take effect for users who use Layer 3 Portal authentication.

If a user on a physical interface is online, this command takes effect only after the user goes online again or the device re-authenticates the user.

If a user on a Eth-trunk interface is online, this command takes immediately.

Example

```
# Set the source IP address and MAC address of offline detection packets for users  
in VLAN 10 to 192.168.1.1 and 2222-1111-1234 respectively.
```

```
<HUAWEI> system-view  
[HUAWEI] access-user arp-detect vlan 10 ip-address 192.168.1.1 mac-address 2222-1111-1234
```

Related Topics

[13.5.99 mac-authen timer](#)

13.5.3 access-user arp-detect default ip-address

Function

The **access-user arp-detect default ip-address** command sets the default source IP address of offline detection packets.

The **undo access-user arp-detect default ip-address** command restores the default setting.

By default, the default source IP address of offline detection packets is 0.0.0.0.

Format

access-user arp-detect default ip-address *ip-address*

undo access-user arp-detect default ip-address

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the default source IP address of offline detection packets.	The value is in dotted decimal notation and can be 0.0.0.0 or 255.255.255.255.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device sends an ARP probe packet to check the user online status. If the user does not respond within a detection period, the device considers that the user is offline.

Precautions

This function does not take effect for users who use Layer 3 Portal authentication.

Example

```
# Set the default source IP address of offline detection packets to 0.0.0.0.
```

```
<HUAWEI> system-view  
[HUAWEI] access-user arp-detect default ip-address 0.0.0.0
```

13.5.4 access-user syslog-restrain enable

Function

The **access-user syslog-restrain enable** command enables system log suppression.

The **undo access-user syslog-restrain enable** command disables system log suppression.

By default, system log suppression is enabled.

Format

access-user syslog-restrain enable

undo access-user syslog-restrain enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When a user fails in authentication or goes offline, the device records a system log. The system log contains the MAC addresses of access device and access user and the authentication time.

If a user repeatedly attempts to go online after authentication failures or frequently goes online and offline in a short period, a lot of system logs are generated, which waste system resources and degrade system performance. System log suppression can address this problem. After the device generates a system log, it will not generate the same log within the suppression period (set by [13.5.5 access-user syslog-restrain period](#)).

NOTE

The same system logs refer to the system logs containing the same MAC addresses. For example, after the device generates a system log for a user failing in authentication, the device will not generate new system log for this user in the suppression period if the user fails in authentication again. The system logs for users logging offline are generated in the same way.

Example

```
# Enable system log suppression.
```

```
<HUAWEI> system-view  
[HUAWEI] access-user syslog-restrain enable
```

Related Topics

[13.5.5 access-user syslog-restrain period](#)

13.5.5 access-user syslog-restrain period

Function

The **access-user syslog-restrain period** command sets a period for system log suppression.

The **undo access-user syslog-restrain period** command restores the default period for system log suppression.

By default, the period of system log suppression is 300s.

Format

access-user syslog-restrain period *period*

undo access-user syslog-restrain period

Parameters

Parameter	Description	Value
<i>period</i>	Specifies the period for system log suppression.	The value is an integer that ranges from 60 to 604800, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the system log suppression function is enabled using the [13.5.4 access-user syslog-restrain enable](#) command, use this command to set the system log suppression period. After generating a system log, the device will not generate the same log within the suppression period.

Example

Set the period for system log suppression to 600s.

```
<HUAWEI> system-view  
[HUAWEI] access-user syslog-restrain period 600
```

Related Topics

[13.5.4 access-user syslog-restrain enable](#)

13.5.6 acl-id (user group view)

Function

The **acl-id** command binds an ACL to a user group.

The **undo acl-id** command unbinds an ACL from a user group.

By default, no ACL is bound to a user group.

Format

acl-id *acl-number*

undo acl-id { *acl-number* | **all** }

Parameters

Parameter	Description	Value
<i>acl-number</i>	Specifies the number of an ACL bound to a user group.	The value is an integer that ranges from 3000 to 3999.
all	Deletes all ACL rules bound to a user group.	-

Views

User group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a user group is created using the [13.5.156 user-group](#) command, you can run the **acl-id** *acl-number* command to bind an ACL to the user group, so that users in the user group share an ACL.

NOTE

Before an ACL is bound to the user group, do not run the [13.5.157 user-group enable](#) command to enable the user group; otherwise, the ACL cannot be bound to the user group.

When the user group function is enabled on models except the S5720EI, S5720HI, S6720EI, and S6720S-EI, ACL rules are delivered to each user and the user group function cannot be used to save ACL resources.

Prerequisites

The ACL has been created using the [14.1.5 acl \(system view\)](#) or [14.1.4 acl name](#) command and ACL rules have been configured using the [rule](#) command.

Precautions

- The ACL bound to a user group cannot be modified or deleted in the system view.
- If no ACL rule is configured for a user group, the device does not restrict the network access rights of users in the user group.
- When configuring ACL rules in a user group, create a rule that rejects all network access requests and ensure that the rule can take effect.

- If all users in a group are required to have the same access rights, do not specify the source IP address in the ACL bound to the user group. If an ACL bound to a user group has defined the source IP address, only users with the same IP address as the source IP address in the ACL can match the ACL in the user group.

Example

Bind ACL 3001 to the user group **abc**.

```
<HUAWEI> system-view
[HUAWEI] acl 3001
[HUAWEI-acl-adv-3001] rule 5 deny ip destination 192.168.5.0 0.0.0.255
[HUAWEI-acl-adv-3001] quit
[HUAWEI] user-group abc
[HUAWEI-user-group-abc] acl-id 3001
```

Related Topics

- [14.1.5 acl \(system view\)](#)
- [13.5.156 user-group](#)
- [13.5.157 user-group enable](#)
- [13.5.55 display user-group](#)

13.5.7 authentication critical eapol-success

Function

The **authentication critical eapol-success** command configures the device to send an Eapol-Success packet to a user after the user is added to the critical VLAN.

The **undo authentication critical eapol-success** command configures the device to send an Eapol-Fail packet to a user after the user is added to the critical VLAN.

By default, an Eapol-Fail packet is sent to a user after the user is added to the critical VLAN.

Format

In the system view:

```
authentication critical eapol-success interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

```
undo authentication critical eapol-success interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

In the interface view:

```
authentication critical eapol-success
```

```
undo authentication critical eapol-success
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number1</i> specifies the number of the first interface.• <i>interface-number2</i> specifies the number of the last interface.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

After a user is added to the critical VLAN because the authentication server does not respond, the device can be configured to send an Eapol-Success or Eapol-Fail packet to the user to prevent the user from continuously sending access request packets. After receiving the Eapol-Success packet or Eapol-Fail packet, the user stops attempting to go online by sending the access request packet repeatedly, which prevents the device performance from degrading.

The user receiving the Eapol-Success packet can still obtain the IP address through a DHCP packet, while the user receiving the Eapol-Fail packet fails to do so. The administrator can configure the device to send an Eapol-Success or Eapol-Fail packet as required.

Example

Configure the device to send an Eapol-Success packet to a user after the user is added to the critical VLAN on GE0/0/1.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] authentication critical eapol-success
```

13.5.8 authentication critical-vlan

Function

The **authentication critical-vlan** command configures a critical VLAN on an interface.

The **undo authentication critical-vlan** command deletes a critical VLAN from an interface.

By default, no critical VLAN is configured on an interface.

Format

In the system view:

```
authentication critical-vlan vlan-id interface { interface-type interface-number1
[ to interface-number2 ] } &<1-10>
```

```
undo authentication critical-vlan [ vlan-id ] interface { interface-type interface-
number1 [ to interface-number2 ] } &<1-10>
```

In the interface view:

```
authentication critical-vlan vlan-id
```

```
undo authentication critical-vlan [ vlan-id ]
```

Parameters

Parameter	Description	Value
<i>vlan-id</i>	Specifies the VLAN ID of a critical VLAN.	The value is an integer that ranges from 1 to 4094.
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number1</i> specifies the number of the first interface. <i>interface-number2</i> specifies the number of the last interface. 	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A critical VLAN is authorized for users when the authentication server does not respond.

When the access device cannot communicate with the RADIUS server or the RADIUS server fails, the authentication process on the network is interrupted and users cannot pass the authentication. After the critical VLAN function of the device is enabled, the device sets the state flag of the authentication server to Down and adds the users to the critical VLAN. In this way, the users can access resources in the critical VLAN without being authenticated.

Precautions

- This command is only valid for 802.1X authentication and MAC address authentication.
- If the free-ip function is configured, the critical VLAN function becomes invalid immediately.
- To make the VLAN authorization function take effect, the link type and access control mode of the authentication interface must meet the following requirements:
 - When the link type is hybrid in untagged mode, the access control mode can be based on the MAC address or interface.
 - When the link type is access or trunk, the access control mode can only be based on the interface.

Example

In the system view, configure 802.1X authentication for the users using Port address-based access method on GE0/0/1 and set the critical VLAN to VLAN 20.

```
<HUAWEI> system-view
[HUAWEI] vlan batch 20
[HUAWEI] dot1x enable
[HUAWEI] interface gigabitEthernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] port link-type hybrid
[HUAWEI-GigabitEthernet0/0/1] quit
[HUAWEI] dot1x enable interface gigabitEthernet 0/0/1
[HUAWEI] dot1x port-method port interface gigabitEthernet 0/0/1
[HUAWEI] authentication critical-vlan 20 interface gigabitEthernet 0/0/1
```

In the interface view, enable MAC address authentication on GE0/0/1 and set the critical VLAN to VLAN 20.

```
<HUAWEI> system-view
[HUAWEI] vlan batch 20
[HUAWEI] mac-authen
[HUAWEI] interface gigabitEthernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] port link-type hybrid
[HUAWEI-GigabitEthernet0/0/1] mac-authen
[HUAWEI-GigabitEthernet0/0/1] authentication critical-vlan 20
```

13.5.9 authentication device-type voice authorize

Function

The **authentication device-type voice authorize** command enables voice terminals to go online without authentication.

The **undo authentication device-type voice authorize** command disables voice terminals from going online without authentication.

By default, voice terminals are disabled from going online without authentication.

Format

authentication device-type voice authorize [**user-group** *group-name*]

undo authentication device-type voice authorize [**user-group**]

Parameters

Parameter	Description	Value
user-group <i>group-name</i>	Specifies the name of the user group based on which network access rights are assigned to voice terminals.	The value must be an existing user group name.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When both data terminals (such as PCs) and voice terminals (such as IP phones) are connected to switches, NAC is configured on the switches to manage and control the data terminals. The voice terminals, however, only need to connect to the network without being managed and controlled. In this case, you can configure the voice terminals to go online without authentication on the switches. Then the voice terminals identified by the switches can go online without authentication.

Precautions

To enable the switches to identify the voice terminals, enable LLDP or configure OUI for the voice VLAN on the switches. For details, see "Configuring Basic LLDP Functions" in "LLDP Configuration" in the *S1720, S2700, S5700, and S6720*

V200R011C10 Configuration Guide - Network Management and Monitoring or "Configuring a Voice VLAN Based on a MAC Address" in "Voice VLAN Configuration" in the *S1720, S2700, S5700, and S6720 V200R011C10 Configuration Guide - Ethernet Switching*. If a voice device supports only CDP but does not support LLDP, configure CDP-compatible LLDP on the switch using [16.3.16 lldp compliance cdp receive](#) command.

If an 802.1X user initiates authentication through a voice terminal, a switch preferentially processes the authentication request. If the authentication succeeds, the terminal obtains the corresponding network access rights. If the authentication fails, the switch identifies the terminal type and enables the terminal to go online without authentication.

Voice terminals can obtain the corresponding network access rights after they pass authentication and go online, when **user-group** *group-name* is not specified. When **user-group** *group-name* is specified, voice terminals can obtain the network access rights specified by the user group after they go online. To use a user group to define network access rights for voice terminals, run the [13.5.156 user-group](#) *group-name* command to create a user group and configure network authorization information for the users in the group. Note that the user group takes effect only after it is enabled.

If you run this command repeatedly, the latest configuration overrides the previous ones.

This function takes effect only for users who go online after this function is successfully configured.

Example

```
# Enable voice terminals to go online without authentication.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication device-type voice authorize
```

13.5.10 authentication event

Function

The **authentication event** command grants network access rights to users in different authentication stages.

The **undo authentication event** command cancels network access rights of users in different authentication stages.

By default, no network access right is granted to users in different authentication stages.

Format

- Command for 802.1X authentication:
System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view:
authentication event { **pre-authen** | **authen-fail** | **authen-server-down** | **client-no-response** } { **vlan** *vlan-id* | **user-group** *group-name* }

undo authentication event { pre-authen | authen-fail | authen-server-down | client-no-response }

- Command for MAC address authentication:

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view:

authentication event { pre-authen | authen-fail | authen-server-down } { vlan *vlan-id* | user-group *group-name* }

undo authentication event { pre-authen | authen-fail | authen-server-down }

VLANIF interface view:

authentication event { authen-fail | authen-server-down } user-group *group-name*

undo authentication event { authen-fail | authen-server-down }

- Command for external portal authentication:

System view:

authentication event { pre-authen | authen-fail | authen-server-down } user-group *group-name*

undo authentication event { pre-authen | authen-fail | authen-server-down }

VLANIF interface view:

authentication event { authen-fail | authen-server-down } user-group *group-name*

undo authentication event { authen-fail | authen-server-down }

- Command for built-in portal authentication:

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view:

authentication event { pre-authen | authen-fail | authen-server-down } { vlan *vlan-id* | user-group *group-name* }

undo authentication event { pre-authen | authen-fail | authen-server-down }

VLANIF interface view:

authentication event { authen-fail | authen-server-down } user-group *group-name*

undo authentication event { authen-fail | authen-server-down }

Parameters

Parameter	Description	Value
pre-authen	<p>Specifies the network access rights granted to users before authentication starts.</p> <p>In an 802.1X authentication, when a device receives an ARP or DHCP request packet sent from a user terminal, but not an authentication request packet from an 802.1X client, the device grants the pre-authen right to the user. If only this parameter is specified but the network access rights are not configured for other events, the device grants the pre-authen right to the users failing in authentication.</p> <p>In a MAC address or Portal authentication, if only this parameter is specified but the network access rights are not configured for other events, the device grants the pre-authen right to the users failing in authentication.</p>	-
authen-fail	<p>Specifies the network access rights granted to users when authentication fails.</p> <p>The device grants this right to all users who have failed in authentication.</p>	-
authen-server-down	<p>Specifies the network access rights granted to users when the authentication server does not respond.</p> <p>If both the authen-server-down and authen-fail parameters are specified, the authen-server-down parameter takes effect if the authentication server does not respond.</p>	-
client-no-response	<p>Specifies the network access rights granted to users when the 802.1X client does not respond.</p> <p>If both the client-no-response and authen-fail parameters are specified, the client-no-response parameter takes effect if the 802.1X client does not respond.</p>	-
vlan <i>vlan-id</i>	<p>Specifies a VLAN ID. When this parameter is specified, the user can access only the resources in the VLAN.</p>	The value is an integer that ranges from 1 to 4094.

Parameter	Description	Value
user-group <i>group-name</i>	Specifies a user group. When this parameter is specified, the user can access the resources defined for the user group.	The value must be an existing service scheme name.

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To grant different network access rights to users in different stages, you can use this command.

Prerequisites

The 802.1X authentication, MAC address authentication, or Portal authentication has been enabled.

Precautions

- If the command is executed in both the interface view and system view, the configuration in interface view takes effect.
- This function takes effect only for users who go online after this function is successfully configured.
- If the **user-group** parameter is specified in the command, only the network access rights (that is, the ACL and VLAN bound to the user group) configured for the user group take effect.
- If the network access rights specified in the **authentication event** command were defined by a user group, the **13.5.64 dot1x free-ip** command configured in the system view cannot take effect and the **13.5.64 dot1x free-ip** command configured in the interface view does not take effect for the interface.
- If the **user-group** parameter is specified in the command and the destination network access rights in the authentication-free rule configured by **13.5.107 portal free-rule** is the same as that defined for the user group, the authentication-free rule does not take effect.

Example

On GE0/0/1, allow users to access resources in VLAN 10 when authentication fails.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] authentication event authen-fail vlan 10
```

Related Topics

- [13.5.63 dot1x enable](#)
- [13.5.88 mac-authen](#)
- [13.5.167 web-auth-server \(system view\)](#)
- [13.5.156 user-group](#)

13.5.11 authentication event response-fail

Function

The **authentication event response-fail** command configures the device to return an authentication failure packet when a user fails in authentication or the authentication server does not respond.

The **undo authentication event response-fail** command restores the default configuration.

By default, the device returns an authentication success packet when a user fails in authentication or the authentication server does not respond.

Format

authentication event { authen-fail | authen-server-down } response-fail

undo authentication event { authen-fail | authen-server-down } response-fail

Parameters

Parameter	Description	Value
authen-fail	Specifies that the device returns an authentication failure packet to the 802.1X client or portal server when a user fails in authentication.	-
authen-server-down	Specifies that the device returns an authentication failure packet to the 802.1X client or portal server when the authentication server does not respond.	-

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the [13.5.10 authentication event](#) command is executed to configure the network access right used when a user fails in authentication or the authentication server does not respond, the device returns an authentication success packet to the 802.1X client or portal server by default. Therefore, the user does not know the authentication failure and only limited network resources can be accessed. The user cannot use the expected service.

You can use this command to configure the device to return an authentication failure packet to the 802.1X client or portal server. In 802.1X authentication, the 802.1X client notifies the user of authentication failure. In portal authentication, the portal server pushes an authentication failure message to the user. The user then choose whether to perform reauthentication.

Precautions

- If the command is executed in both the interface view and system view, the configuration in interface view takes effect.
- This function takes effect only for users who go online after this function is successfully configured.
- This command is only applicable to the 802.1X authentication and Portal authentication.

Example

Configure GE0/0/1 to return an authentication failure packet to the 802.1X client or portal server when a user fails in authentication.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] authentication event authen-fail response-fail
```

Related Topics

[13.5.10 authentication event](#)

13.5.12 authentication event session-timeout

Function

The **authentication event session-timeout** command sets the timeout period of network access rights granted to users in different authentication stages.

The **undo authentication event session-timeout** command restores the default timeout period.

By default, the timeout period of network access rights granted to users is 15 minutes.

Format

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view

authentication event { pre-authen | authen-fail | authen-server-down | client-no-response } session-timeout *session-time*

undo authentication event { pre-authen | authen-fail | authen-server-down | client-no-response } session-timeout

VLANIF interface view

authentication event { pre-authen | authen-fail | authen-server-down } session-timeout *session-time*

undo authentication event { pre-authen | authen-fail | authen-server-down } session-timeout

Parameters

Parameter	Description	Value
pre-authen	Specifies the timeout period of the network access rights granted to users before authentication starts.	-
authen-fail	Specifies the timeout period of the network access rights granted to users when authentication fails.	-
authen-server-down	Specifies the timeout period of the network access rights granted to users when the authentication server does not respond.	-
client-no-response	Specifies the timeout period of the network access rights granted to users when the 802.1X client does not respond. This parameter is only valid for 802.1X authentication.	-
<i>session-time</i>	Specifies the value of timeout period. If the user still fails to be authenticated when the user aging time expires, the user entry is deleted.	The value is an integer that ranges from 0 to 71581, in minutes.

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After you run the [13.5.10 authentication event](#) command to grant the network access rights to users in different authentication stages, you can run the **authentication event session-timeout** command to specify the timeout period for the network access rights. Users can access the authorized resources within the timeout period, and will be forced to go offline after the timeout period expires.

If the aging time is set to 0, the network access rights granted to the user will not expire. To disconnect the user from the network, run the [cut access-user](#) command on the device or configure the authentication server to deliver an offline message to the user.

Precautions

The timeout period set in the VLANIF interface view is not applicable to 802.1X authentication.

If this command is only run in the system view, the configuration takes effect on all interfaces. If this command is run in both the system view and interface view, the configuration on interfaces takes precedence over the global configuration.

This function takes effect only for users who go online after this function is successfully configured.

Example

On interface GE0/0/1, set the timeout period of the network access rights granted to users when authentication fails to 100 minutes.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] authentication event authen-fail session-timeout 100
```

Related Topics

[13.5.10 authentication event](#)

13.5.13 authentication guest-vlan

Function

The **authentication guest-vlan** command configures a guest VLAN on an interface.

The **undo authentication guest-vlan** command deletes a guest VLAN from an interface.

By default, no guest VLAN is configured on an interface.

Format

In the system view:

```
authentication guest-vlan vlan-id interface { interface-type interface-number1  
[ to interface-number2 ] } &<1-10>
```

```
undo authentication guest-vlan [ vlan-id ] interface { interface-type interface-  
number1 [ to interface-number2 ] } &<1-10>
```

In the interface view:

```
authentication guest-vlan vlan-id
```

```
undo authentication guest-vlan [ vlan-id ]
```

Parameters

Parameter	Description	Value
<i>vlan-id</i>	Specifies the ID of a guest VLAN.	The value is an integer that ranges from 1 to 4094.
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number1</i> specifies the number of the first interface.• <i>interface-number2</i> specifies the number of the last interface.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

During 802.1X authentication and MAC address authentication, a guest VLAN allows users to access limited resources without authentication. The device supports the guest VLAN function.

Users in the guest VLAN can access resources in the guest VLAN without authentication but must be authenticated when they access external resources.

 **NOTE**

- The restrict VLAN is for the users who fail the authentication, while the guest VLAN is for the users who are not authenticated.
- If only a guest VLAN is configured but no restrict VLAN is configured, the users who fail the authentication are added to the guest VLAN.

Prerequisites

The VLAN to be configured as the guest VLAN must have been created.

802.1X authentication has been enabled globally and on the interface using the **dot1x enable** command, or MAC address authentication has been enabled globally and on the interface using the **mac-authen** command.

Precautions

- The guest VLAN function can take effect only in 802.1X and MAC address authentication.
- A super VLAN cannot be configured as a guest VLAN.
- When free IP subnets are configured, the guest VLAN function becomes invalid immediately.
- If the authentication function of the built-in Portal server is enabled, the guest VLAN cannot be configured on interfaces.
- The guest VLAN function takes effect only when a user sends untagged packets to the device.
- Different interfaces can be configured with different guest VLANs. After a guest VLAN is configured on an interface, the guest VLAN cannot be deleted.
- To make the VLAN authorization function take effect, the link type and access control mode of the authentication interface must meet the following requirements:
 - When the link type is hybrid in untagged mode, the access control mode can be based on the MAC address or interface.
 - When the link type is access or trunk, the access control mode can only be based on the interface.

Example

In the system view, configure 802.1X authentication for the users using Port-based access method on GE0/0/1 and set the guest VLAN to VLAN 20.

```
<HUAWEI> system-view
[HUAWEI] vlan batch 20
[HUAWEI] dot1x enable
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] port link-type hybrid
[HUAWEI-GigabitEthernet0/0/1] quit
[HUAWEI] dot1x enable interface gigabitethernet 0/0/1
[HUAWEI] dot1x port-method port interface gigabitethernet 0/0/1
[HUAWEI] authentication guest-vlan 20 interface gigabitethernet 0/0/1
```

In the interface view, enable MAC address authentication on GE0/0/1 and set the guest VLAN to VLAN 20.

```
<HUAWEI> system-view
[HUAWEI] vlan batch 20
[HUAWEI] mac-authen
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] port link-type hybrid
[HUAWEI-GigabitEthernet0/0/1] mac-authen
[HUAWEI-GigabitEthernet0/0/1] authentication guest-vlan 20
```

Related Topics

[13.5.63 dot1x enable](#)

[13.5.34 display dot1x](#)

[13.5.79 dot1x retry](#)

[13.5.88 mac-authen](#)

[13.5.38 display mac-authen](#)

13.5.14 authentication mac-move enable

Function

The **authentication mac-move enable** command enables MAC address migration.

The **undo authentication mac-move enable** command disables MAC address migration.

By default, MAC address migration is disabled.

Format

authentication mac-move enable vlan { **all** | { *vlan-id1* [**to** *vlan-id2*] } & <1-10> }

undo authentication mac-move enable vlan { **all** | { *vlan-id1* [**to** *vlan-id2*] } & <1-10> }

Parameters

Parameter	Description	Value
vlan	Specifies the VLAN range for enabling MAC address migration.	-
all	Enables MAC address migration in all VLANs.	-

Parameter	Description	Value
<i>vlan-id1</i> [to <i>vlan-id2</i>]	Enables MAC address migration in the specified VLANs. <ul style="list-style-type: none">• <i>vlan-id1</i> specifies the ID of the first VLAN.• <i>vlan-id2</i> specifies the ID of the second VLAN. The value of <i>vlan-id2</i> must be greater than that of <i>vlan-id1</i>.	The value is an integer that ranges from 1 to 4094.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a user is authenticated and accesses the network from one interface of the device, the network cable is pulled out from the interface and plugged in another interface on the device. In this case, the user cannot immediately initiate authentication and access the network. The user can initiate authentication on the current interface only after the user offline detection interval expires or the authentication interface is manually enabled and shut down to clear user online entries. To improve user experience, MAC address migration is enabled so that the user can immediately initiate authentication and access the network after be switched to another access interface.

MAC address migration allows online NAC authentication users to immediately initiate authentication and access the network after they are switched to other access interfaces. If the user is authenticated successfully on the new interface, the online user entry on the original interface is deleted immediately to ensure that only one interface records the online user entry.

In addition, VLANs need to be specified for users in MAC address migration. The VLANs before and after the migration can be specified for the users, and they can be the same or different.

Precautions

- In normal case, enabling MAC address migration is not recommended. It should be enabled only when users have migration requirements during roaming. This prevents unauthorized users from forging MAC addresses of online users and sending ARP, 802.1X, or DHCP packets on other

authentication control interfaces to trigger the MAC address migration function and force authorized user offline.

- Cascading migration through intermediate devices is not supported, because ARP and DHCP packets are not sent after the cascading migration.
- MAC address migration is not supported for Layer 3 Portal authentication users.
- In the Layer 2 BNG scenario, the device does not support MAC address migration.
- A user is switched from an interface configured with NAC authentication to another interface not configured with NAC authentication. In this case, the user can access the network only after the original online entry is aged because the new interface cannot send authentication packets to trigger MAC migration.
- In common mode, Portal authentication is triggered only after users who go online through a VLANIF interface send ARP packets and go offline; otherwise, the users can go online again only after the original user online entries age out. Portal authentication cannot be triggered after users who go online through physical interfaces migrate. The users can go online again only after the original user online entries age out.
- After a user who goes online from a VLANIF interface is quieted because of multiple MAC address migrations, MAC address migration can be performed for the quieted user only after the quiet period expires and the ARP entry is aged out.
- When an authorized VLAN is specified in the **authentication mac-move enable vlan** command, you are advised to enable the function of detecting the user status before user MAC address migration.

Example

```
# Enable MAC address migration in all VLANs.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move enable vlan all
```

13.5.15 authentication mac-move detect enable

Function

The **authentication mac-move detect enable** command enables a device to detect users' online status before user MAC address migration.

The **undo authentication mac-move detect enable** command disables a device from detecting users' online status before user MAC address migration.

By default, a device is disabled from detecting users' online status before user MAC address migration.

Format

authentication mac-move detect enable

undo authentication mac-move detect enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

To prevent unauthorized users from spoofing online users to attack a device, run the **authentication mac-move detect enable** command to enable the device to detect users' online status before user MAC address migration. If no users are online, the device permits MAC address migration and allows users to go online from a new access interface. If a user is online, the device terminates MAC address migration and does not allow the user to go online from a new access interface.

You can also run the [13.5.16 authentication mac-move detect retry-interval retry-time](#) command to set the detection interval and maximum number of detections before user MAC address migration.

Example

```
# Enable a device to detect users' online status before user MAC address migration.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move detect enable
```

13.5.16 authentication mac-move detect retry-interval retry-time

Function

The **authentication mac-move detect retry-interval retry-time** command sets the detection interval and maximum number of detections before user MAC address migration.

The **undo authentication mac-move detect retry-interval retry-time** command restores the default setting.

By default, a device detects users' online status once. The detection interval is 3 seconds.

Format

```
authentication mac-move detect { retry-interval interval | retry-time times } *  
undo authentication mac-move detect { retry-interval | retry-time } *
```

Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the interval at which a device detects users' online status before user MAC address migration.	The value is an integer that ranges from 1 to 5, in seconds.
<i>times</i>	Specifies the maximum number of detections before user MAC address migration.	The value is an integer that ranges from 1 to 3.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After a device is enabled to detect users' online status before user MAC address migration, you can run the **authentication mac-move detect { retry-interval *interval* | retry-time *times* }** * command to modify the default detection interval and maximum number of detections.

Example

Configure a device to detect users' online status twice at an interval of 5 seconds before user MAC address migration.

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move detect retry-interval 5 retry-time 2
```

13.5.17 authentication mac-move quiet-log enable

Function

The **authentication mac-move quiet-log enable** command enables the device to record logs about MAC address migration quiet.

The **undo authentication mac-move quiet-log enable** command disables the device from recording logs about MAC address migration quiet.

By default, the device is enabled to record logs about MAC address migration quiet.

Format

authentication mac-move quiet-log enable
undo authentication mac-move quiet-log enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device can record logs when adding or deleting MAC address migration quiet entries. This helps the administrator to find out the cause for MAC address migration failure, and improves maintainability of the MAC address migration quiet function.

Example

Enable the device to record logs about MAC address migration quiet.

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move quiet-log enable
```

13.5.18 authentication mac-move quiet-times quiet-period

Function

The **authentication mac-move quiet-times quiet-period** command configures the quiet period and the maximum number of MAC address migration times within 60 seconds before users enter the quiet state.

The **undo authentication mac-move quiet-times quiet-period** command restores the default settings.

The default quiet period is 0 seconds and the maximum number of MAC address migration times within 60 seconds before users enter the quiet state is 3.

Format

authentication mac-move { quiet-times *times* | quiet-period *quiet-value* } *
undo authentication mac-move { quiet-times | quiet-period } *

Parameters

Parameter	Description	Value
<i>times</i>	Specifies the maximum number of MAC address migration times within 60 seconds before users enter the quiet state.	The value is an integer that ranges from 1 to 10.
<i>quiet-value</i>	Specifies the quiet period for MAC address migration users.	The value is an integer that ranges from 0 to 3600. The value 0 indicates that the MAC address migration quiet function is disabled.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When users frequently switch access interfaces (especially frequent switching due to loops), the device needs to process a large number of authentication packets and entries, which results in high CPU usage. To solve this problem, configure the MAC address migration quiet function.

If the number of MAC address migration times for a user within 60 seconds exceeds the value (*times*) after the MAC address migration quiet function is enabled, the device quiets the user for a certain period (*quiet-value*). During the quiet period, the device does not allow users to perform MAC address migration.

Example

Configure the quiet period to 120 seconds and the maximum number of MAC address migration times within 60 seconds before users enter the quiet state to 5.

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move quiet-times 5 quiet-period 120
```

13.5.19 authentication mac-move quiet-user-alarm enable

Function

The **authentication mac-move quiet-user-alarm enable** command enables the device to send alarms about MAC address migration quiet.

The **undo authentication mac-move quiet-user-alarm enable** command disables the device from sending alarms about MAC address migration quiet.

By default, the device is disabled from sending alarms about MAC address migration quiet.

Format

authentication mac-move quiet-user-alarm enable

undo authentication mac-move quiet-user-alarm enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device can send alarms about MAC address migration quiet to improve maintainability of the MAC address migration quiet function. The device sends alarms when the percentage of the actual user amount in the MAC address migration quiet table against the maximum number of users exceeds the upper alarm threshold configured. If the percentage decreases to be equal to or smaller than the lower alarm threshold, the device sends a clear alarm. The upper and lower alarm thresholds are configured using the [13.5.20 authentication mac-move quiet-user-alarm percentage](#) command.

Example

```
# Enable the device to send alarms about MAC address migration quiet.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication mac-move quiet-user-alarm enable
```

13.5.20 authentication mac-move quiet-user-alarm percentage

Function

The **authentication mac-move quiet-user-alarm percentage** command configures the upper and lower alarm thresholds for the percentage of MAC address migration users in quiet state.

The **undo authentication mac-move quiet-user-alarm percentage** command restores the default setting.

By default, the lower alarm threshold is 50 and upper alarm threshold is 100.

Format

authentication mac-move quiet-user-alarm percentage *lower-threshold upper-threshold*

undo authentication mac-move quiet-user-alarm percentage

Parameters

Parameter	Description	Value
<i>lower-threshold</i>	Specifies the lower alarm threshold.	The value is an integer that ranges from 1 to 100.
<i>upper-threshold</i>	Specifies the upper alarm threshold.	The value is an integer that ranges from 1 to 100. The value must be greater than that of <i>lower-threshold</i> .

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The **13.5.19 authentication mac-move quiet-user-alarm enable** command can be run to enable the device to send alarms about MAC address migration quiet to improve maintainability of the MAC address migration quiet function. The device sends alarms when the percentage of the actual user amount in the MAC address migration quiet table against the maximum number of users exceeds the upper alarm threshold configured. If the percentage decreases to be equal to or smaller than the lower alarm threshold, the device sends a clear alarm. The upper and lower alarm thresholds are configured using the **authentication mac-move quiet-user-alarm percentage** command.

Example

Configure the upper alarm threshold to 80 and lower alarm threshold to 40.

```
<HUAWEI> system-view
[HUAWEI] authentication mac-move quiet-user-alarm percentage 40 80
```

13.5.21 authentication max-reauth-req

Function

The **authentication max-reauth-req** command sets the maximum number of re-authentication attempts for users in a critical VLAN.

The **undo authentication max-reauth-req** command restores the default setting.

By default, the maximum number of re-authentication attempts is 20 for users in a critical VLAN.

Format

In the system view:

```
authentication max-reauth-req times interface { interface-type interface-number1 [ to interface-number2 ] } <1-10>
```

```
undo authentication max-reauth-req [ times ] interface { interface-type interface-number1 [ to interface-number2 ] } <1-10>
```

In the interface view:

```
authentication max-reauth-req times
```

```
undo authentication max-reauth-req [ times ]
```

Parameters

Parameter	Description	Value
<i>times</i>	Specifies the maximum number of re-authentication attempts.	The value is an integer that ranges from 1 to 20. The default value is 20.
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none"> • <i>Interface-type</i> specifies the interface type. • <i>interface-number1</i> specifies the number of the first interface. • <i>interface-number2</i> specifies the number of the last interface. 	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

When the authentication server maintained by the device turns to the Up state, the device triggers re-authentication for users already added to the critical VLAN. If the authentication is successful, the users exit the critical VLAN. However, if the re-authentication fails due to reasons such as the fault of the access user's client, the repeated re-authentication degrades the device performance. After the maximum number of re-authentication attempts is set for users in the critical VLAN, the device forces the user to exit the critical VLAN if the user fails the authentication the specified number of times.

Example

Set the maximum number of re-authentication attempts for users in the critical VLAN to 5 on GE0/0/1.

```
<HUAWEI> system-view  
[HUAWEI] authentication max-reauth-req 5 interface gigabitethernet 0/0/1
```

13.5.22 authentication open

Function

The **authentication open** command enables the NAC open function.

The **undo authentication open** command disables the NAC open function.

By default, the NAC open function is disabled on an interface.

Format

In the system view:

```
authentication open interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

```
undo authentication open interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

In the interface view:

```
authentication open
```

```
undo authentication open
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number1</i> specifies the number of the first interface.• <i>interface-number2</i> specifies the number of the last interface.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a new NAC network is set up, the network administrator should pay attention to the number of potential access users and authentication method but does not need to control user access, because the administrator needs to configure user names, passwords, and authorization information on the authentication server. After 802.1X or MAC address authentication is configured on the access device, only authenticated users can access the network, so the administrator cannot obtain information about the users who do not have user names and passwords on the authentication server.

The NAC open function allows the users who failed in authentication to access the network.

Precautions

- The NAC open function is only applied to 802.1X and MAC address authentication.
- The NAC open function is only applied to RADIUS remote authentication.
- The NAC open function is valid only when the MAC address-based mode is used as the access control mode of the interface. After this function is enabled, users can be added to VLANs except a guest VLAN after they log in.
- After NAC open is enabled on an interface and fixed user names are used for MAC address authentication, the users on the interface are allowed to access the network even if they have used incorrect user names or passwords.

Example

```
# Enable the NAC open function on GE0/0/1.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication open interface gigabitethernet 0/0/1
```

Related Topics

[13.5.63 dot1x enable](#)

13.5.23 authentication restrict-vlan

Function

The **authentication restrict-vlan** command configures a restrict VLAN on an interface.

The **undo authentication restrict-vlan** command deletes the restrict VLAN from an interface.

By default, no restrict VLAN is configured on an interface.

Format

In the system view:

```
authentication restrict-vlan vlan-id interface { interface-type interface-number1  
[ to interface-number2 ] } &<1-10>
```

```
undo authentication restrict-vlan [ vlan-id ] interface { interface-type interface-  
number1 [ to interface-number2 ] } &<1-10>
```

In the interface view:

```
authentication restrict-vlan vlan-id
```

```
undo authentication restrict-vlan [ vlan-id ]
```

Parameters

Parameter	Description	Value
<i>vlan-id</i>	Specifies the ID of a restrict VLAN.	The value is an integer that ranges from 1 to 4094.

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	<p>Specifies the interface type and number.</p> <ul style="list-style-type: none"> • <i>interface-type</i> specifies the interface type. • <i>interface-number1</i> specifies the number of the first interface. • <i>interface-number2</i> specifies the number of the last interface. 	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

You can configure the restrict VLAN on the device interface, so that the users can still access some network resources (for example, update the virus library) when the users fail the authentication. The users who fail the authentication are added to the restrict VLAN to access the resources in the restrict VLAN. Note that, the user fails the authentication because the authentication server rejects the user for some reasons, for example, the user enters an incorrect user password, not because the authentication times out or the network is disconnected.

NOTE

- The restrict VLAN is for the users who fail the authentication, while the guest VLAN is for the users who are not authenticated.
- If only a guest VLAN is configured but no restrict VLAN is configured, the users who fail the authentication are added to the guest VLAN.

Prerequisites

The VLAN to be configured as the restrict VLAN must have been created.

Precautions

- A super VLAN cannot be configured as a restrict VLAN.
- When free IP subnets are configured, the restrict VLAN function becomes invalid immediately.

- If the authentication function of the built-in Portal server is enabled, the restrict VLAN cannot be configured on interfaces.
- The restrict VLAN function takes effect only when a user sends untagged packets to the device.
- To make the VLAN authorization function take effect, the link type and access control mode of the authentication interface must meet the following requirements:
 - When the link type is hybrid in untagged mode, the access control mode can be based on the MAC address or interface.
 - When the link type is access or trunk, the access control mode can only be based on the interface.

Example

In the system view, configure 802.1X authentication for the users using Port-based access method on GE0/0/1 and set the restrict VLAN to VLAN 20.

```
<HUAWEI> system-view
[HUAWEI] vlan batch 20
[HUAWEI] dot1x enable
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] port link-type hybrid
[HUAWEI-GigabitEthernet0/0/1] quit
[HUAWEI] dot1x enable interface gigabitethernet 0/0/1
[HUAWEI] dot1x port-method port interface gigabitethernet 0/0/1
[HUAWEI] authentication restrict-vlan 20 interface gigabitethernet 0/0/1
```

Related Topics

[13.5.63 dot1x enable](#)

[13.5.34 display dot1x](#)

[13.5.79 dot1x retry](#)

13.5.24 authentication speed-limit auto

Function

The **authentication speed-limit auto** command enables the device to dynamically adjust the rate of packets from NAC users.

The **undo authentication speed-limit auto** command disables the device from dynamically adjusting the rate of packets from NAC users.

By default, the device does not dynamically adjust the rate of packets from NAC users.

Format

authentication speed-limit auto

undo authentication speed-limit auto

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When a lot of NAC users send authentication or log off requests to the device, the CPU usage may be overloaded especially when the CPU or memory usage is already high (for example, above 80%).

After this command is executed, the device limits the number of NAC packets received per second if the CPU or memory usage is high. This function reduces loads on the device CPU.

Example

Enable the device to dynamically adjust the rate of packets from NAC users.

```
<HUAWEI> system-view  
[HUAWEI] authentication speed-limit auto
```

13.5.25 authentication timer re-authen

Function

The **authentication timer re-authen** command configures the interval for re-authenticating pre-connection users or users who fail to be authenticated.

The **undo authentication timer re-authen** command restores the default setting.

By default, pre-connection users and users who fail to be authenticated are re-authenticated at an interval of 60 seconds.

Format

authentication timer re-authen { **pre-authen** *re-authen-time* | **authen-fail** *re-authen-time* }

undo authentication timer re-authen { **pre-authen** | **authen-fail** }

Parameters

Parameter	Description	Value
pre-authen <i>re-authen-time</i>	Specifies the interval for re-authenticating pre-connection users.	The value is an integer that ranges from 0 or 30 to 7200, in seconds. The value 0 indicates that the re-authentication function is disabled for pre-connection users.

Parameter	Description	Value
authen-fail <i>re-authen-time</i>	Specifies the interval for re-authenticating users who fail to be authenticated.	The value is an integer that ranges from 30 to 7200, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The device creates the mapping user entries when network access policies are assigned to users who are in the pre-connection phase or fail authentication. To enable users to pass authentication in real time, the device periodically re-authenticates the users who are in the pre-connection phase or fail authentication according to the user entries. The administrator can adjust the re-authentication interval based on the actual network requirements.

Precautions

This command only applies to 802.1X authentication and MAC address authentication.

This function takes effect only for users who go online after this function is successfully configured.

To reduce the impact on the device performance when many users exist, the user re-authentication interval may be longer than the configured re-authentication interval.

Example

Configures the interval for re-authenticating users who fail to be authenticated to 300 seconds.

```
<HUAWEI> system-view  
[HUAWEI] authentication timer re-authen authen-fail 300
```

13.5.26 band-width share-mode

Function

The **band-width share-mode** command enable the bandwidth share mode.

The **undo band-width share-mode** command restores the default configuration.

By default, the bandwidth share mode is disabled.

 NOTE

This command is only supported by the S5720HI.

Format

band-width share-mode

undo band-width share-mode

Parameters

None

Views

System view, AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

On a home network, all family members go online using the same account. To improve service experience of family members, you can enable the bandwidth share mode so that all members can share the bandwidth.

Precautions

- This function does not apply to users who are connected through the inter-card Eth-Trunk interface.
- If this command is run in the system view, it takes effect for all new online users who connected to the device. If this command is run in the AAA domain view, it takes effect only for new online users in the domain.
- If the local or remote RADIUS server does not assign CAR settings to the users who will go online and the online users, the share mode is invalid to the users.
- If the bandwidth share mode is enabled and different users use the same account for authentication, the users going online with no CAR settings assigned will not be affected when CAR settings are assigned to the users who go online later.

Example

Enable the bandwidth share mode in the system view.

```
<HUAWEI> system-view  
[HUAWEI] band-width share-mode
```

Enable the bandwidth share mode in the AAA domain view.

```
<HUAWEI> system-view  
[HUAWEI] aaa
```

[HUAWEI-aaa] **domain huawei**
[HUAWEI-aaa-domain-huawei] **band-width share-mode**

13.5.27 car (user group view)

Function

The **car** command enables traffic control for users in a user group.

The **undo car** command disables traffic control for users in a user group.

By default, traffic control is disabled for users in a user group.

NOTE

Only the S5720EI, S5720HI, S6720EI, and S6720S-EI support this command, and the user group CAR can only be applied in the interface outbound direction (**outbound**) on the S5720EI, S6720EI, and S6720S-EI.

Format

car { **outbound** | **inbound** } **cir** *cir-value* [**pir** *pir-value* | **cbs** *cbs-value* | **pbs** *pbs-value*] *

undo car { **outbound** | **inbound** }

Parameters

Parameter	Description	Value
outbound	Applies the user group CAR to the outgoing packets on an interface to restrict the outgoing packet rate.	-
inbound	Applies the user group CAR to the incoming packets on an interface to restrict the incoming packet rate.	-
cir <i>cir-value</i>	Specifies the committed information rate (CIR), which is the average rate of traffic that can pass through an interface.	The value is an integer that ranges from 64 to 4294967295, in kbit/s.

Parameter	Description	Value
pir <i>pir-value</i>	Specifies the peak information rate (PIR), which is the maximum rate of traffic that can pass through an interface.	The value is an integer that ranges from 64 to 4294967295, in kbit/s. The PIR value must be greater than or equal to the CIR value. The default PIR value is equal to the CIR value.
cbs <i>cbs-value</i>	Specifies the committed burst size (CBS), which is the average volume of burst traffic that can pass through an interface.	The value is an integer that ranges from 10000 to 4294967295, in bytes. The default value of <i>cbs-value</i> is 188 x <i>cir-value</i> .
pbs <i>pbs-value</i>	Specifies the peak burst size (PBS), which is the maximum volume of burst traffic that can pass through an interface.	The value is an integer that ranges from 10000 to 4294967295, in bytes. The value of <i>pbs-value</i> must be larger than that of <i>cbs-value</i> and is equal to 188 times of the value of <i>pir-value</i> by default.

Views

User group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After user groups are created using the **user-group** command, you can run the **car outbound** command to configure traffic control for users in a user group so that users in different groups are allocated different bandwidths.

Precautions

- The **car** command takes effect on each user in a user group.
- This function takes effect only for users who go online after this function is successfully configured.

Example

```
# Set the CIR to 10000 Kbit/s and the CBS to 50000 bytes for outgoing packets of users in a user group.
```

```
<HUAWEI> system-view  
[HUAWEI] user-group huawei  
[HUAWEI-user-group-huawei] car outbound cir 10000 cbs 50000
```

Related Topics

[13.5.137 reset access-user traffic-statistics](#)

13.5.28 cut access-user

Function

The **cut access-user** command forces users offline.

Format

```
cut access-user open
```

```
cut access-user user-group group-name
```

Parameters

Parameter	Description	Value
open	Forces open users offline.	-
user-group <i>group-name</i>	Specifies the user group based on which the users are forced offline.	The value must be an existing user group name.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

After a user goes online, if you want to modify the user's network access rights or detect that the user is unauthorized, run this command to force the user offline.

Example

```
# Force open users offline.  
<HUAWEI> system-view  
[HUAWEI] aaa  
[HUAWEI-aaa] cut access-user open
```

Related Topics

[13.5.31 display access-user](#)

13.5.29 display aaa statistics access-type-authenreq

Function

The **display aaa statistics access-type-authenreq** command displays the number of requests for MAC, Portal, or 802.1X authentication.

Format

```
display aaa statistics access-type-authenreq
```

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

When users send authentication requests, the device collects statistics on the number of initiating MAC, Portal, or 802.1X authentications.

To view the number of requests for MAC, Portal, or 802.1X authentication, run the **display aaa statistics access-type-authenreq** command.

Example

Display the number of requests for MAC, Portal, or 802.1X authentication.

```
<HUAWEI> display aaa statistics access-type-authenreq
mac authentication request :2
portal authentication request :0
dot1x authentication request :0
```

Table 13-77 Description of the **display aaa statistics access-type-authenreq** command output

Item	Description
mac authentication request	Number of MAC authentication requests.
portal authentication request	Number of Portal authentication requests.
dot1x authentication request	Number of 802.1X authentication requests.

13.5.30 display authentication mode

Function

The **display authentication mode** command displays the current NAC configuration mode and the mode after restart.

Format

display authentication mode

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display authentication mode** command to view the current NAC configuration mode.

Example

```
# Display the current NAC configuration mode and the mode after restart.
<HUAWEI> display authentication mode
Current authentication mode is unified-mode
Next authentication mode is unified-mode
```

Table 13-78 Description of the **display authentication mode** command output

Item	Description
Current authentication mode is unified-mode	Current NAC configuration mode.
Next authentication mode is unified-mode	NAC configuration mode after the device restarts. Run the authentication unified-mode command to switch the NAC mode to unified mode. Run the undo authentication unified-mode command to switch the NAC mode to common mode.

13.5.31 display access-user

Function

The **display access-user** command displays information about online NAC users.

Format

display access-user open

display access-user option82 { **circuit-id** *text* | **remote-id** *text* }

display access-user user-group *group-name* [**detail**]

 **NOTE**

The **detail** parameter is only supported by the S5720HI.

Parameters

Parameter	Description	Value
open	Displays open user information.	-
option82	Displays information about MAC address authentication users who use the Option 82 field as user names.	-
circuit-id <i>text</i>	Displays information about MAC address authentication users who specify the circuit ID as user names.	The value must be existing circuit-id information.
remote-id <i>text</i>	Displays information about MAC address authentication users who specify the remote ID as user names.	The value must be existing remote-id information.
user-group <i>group-name</i>	Displays information about users in a specified user group.	The value must be an existing user group index.
detail	Displays detailed information about users.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run this command to check information about online NAC users.

Example

Display open user information.

```
<HUAWEI> display access-user open
-----
UserID Username      IP address  MAC          Status
-----
16016 1@radius         10.8.7.5   0011-0904-2f61 Success
-----
Total: 1, printed: 1, Open: 1, printed: 1
```

NOTE

Only letters, digits, and special characters can be displayed for **username**.

When the value of **username** contains special characters or characters in other languages except English, the device displays dots (.) for these characters. If there are more than three such consecutive characters, three dots (.) are displayed. Here, the special characters are the ASCII codes smaller than 32 (space) or larger than 126 (~).

When the value of **username** is longer than 20 characters, the device displays up to three dots (.) for the characters following 19; that is, only 22 characters are displayed.

Table 13-79 Description of the display access-user command output

Item	Description
UserID	ID that is assigned to a user after the user goes online.
Username	User name.
IP address	User IP address.
MAC	User MAC address.

Item	Description
Status	<p>User access status.</p> <ul style="list-style-type: none">• Open: For a wired user, the user goes online through the open function upon authentication failure. For wireless users, no authentication is performed.• Success: authentication is successful• Pre-authen: pre-authentication• Client-no-resp: the client does not respond• Fail-authorized: authorization upon authentication failure• Web-server-down: web server is Down• Aaa-server-down: AAA server is Down

13.5.32 display authentication mac-move configuration

Function

The **display authentication mac-move configuration** command displays the MAC address migration configuration.

Format

display authentication mac-move configuration

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display authentication mac-move configuration** command to view the MAC address migration configuration. The configuration includes the number of times that MAC address migration users are allowed to migrate their MAC addresses 60s before they enter the quiet state, the period that MAC address

migration users stay in the quiet state, the interval at which a device detects users' online status before user MAC address migration, and the number of detections before user MAC address migration.

Example

Display the MAC address migration configuration.

```
<HUAWEI> display authentication mac-move configuration
Mac-move vlan config:all
Mac-move quiet times:1
Mac-move quiet period(s):120
Mac-move quiet log:ENABLE
Mac-move quiet user alarm:ENABLE
Mac-move quiet user alarm lower percentage(%):
50
Mac-move quiet user alarm upper percentage(%):100
Mac-move detect:DISABLE
Mac-move detect retry-interval(s):3
Mac-move detect retry-time:1
```

Table 13-80 Description of the **display authentication mac-move configuration** command output

Item	Description
Mac-move vlan config	VLAN ID range in which MAC address migration is enabled. For details, see the 13.5.14 authentication mac-move enable command.
Mac-move quiet times	Number of times that MAC address migration users are allowed to migrate their MAC addresses 60s before they enter the quiet state. For details, see the 13.5.18 authentication mac-move quiet-times quiet-period command.
Mac-move quiet period(s)	Period that MAC address migration users stay in the quiet state. For details, see the 13.5.18 authentication mac-move quiet-times quiet-period command.
Mac-move quiet log	Whether a device is enabled to record logs about user quietness triggered by MAC address migration: <ul style="list-style-type: none"> • ENABLE • DISABLE For details, see the 13.5.17 authentication mac-move quiet-log enable command.

Item	Description
Mac-move quiet user alarm	<p>Whether a device is enabled to send alarms about user quietness triggered by MAC address migration:</p> <ul style="list-style-type: none"> • ENABLE • DISABLE <p>For details, see the 13.5.19 authentication mac-move quiet-user-alarm enable command.</p>
Mac-move quiet user alarm lower percentage(%)	<p>Lower alarm threshold for the percentage of MAC address migration users in quiet state.</p> <p>For details, see the 13.5.20 authentication mac-move quiet-user-alarm percentage command.</p>
Mac-move quiet user alarm upper percentage(%)	<p>Upper alarm threshold for the percentage of MAC address migration users in quiet state.</p> <p>For details, see the 13.5.20 authentication mac-move quiet-user-alarm percentage command.</p>
Mac-move detect	<p>Whether a device is enabled to detect users' online status before user MAC address migration:</p> <ul style="list-style-type: none"> • ENABLE • DISABLE <p>For details, see the 13.5.15 authentication mac-move detect enable command.</p>
Mac-move detect retry-interval(s)	<p>Interval at which a device detects users' online status before user MAC address migration.</p> <p>For details, see the 13.5.16 authentication mac-move detect retry-interval retry-time command.</p>
Mac-move detect retry-time	<p>Number of detections before user MAC address migration.</p> <p>For details, see the 13.5.16 authentication mac-move detect retry-interval retry-time command.</p>

13.5.33 display authentication mac-move quiet-user

Function

The **display authentication mac-move quiet-user** command displays information about MAC address migration users in quiet state.

Format

display authentication mac-move quiet-user { **all** | **mac-address** *mac-address* }

Parameters

Parameter	Description	Value
all	Displays information about all MAC address migration users in quiet state.	-
mac-address <i>mac-address</i>	Displays information about MAC address migration users in quiet state with a specified MAC address.	The value is in the H-H-H format. An H contains 1 to 4 hexadecimal digits.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Run this command to view information about MAC address migration users in quiet state.

Example

Display information about all MAC address migration users in quiet state.

```
<HUAWEI> display authentication mac-move quiet-user all
Quiet MAC Information
-----
Quiet MAC                               Quiet Remain Time(Sec)
-----
0001-0002-0003                           143
-----
1 quiet MAC found, 1 printed.
```

Table 13-81 Description of the **display authentication mac-move quiet-user all** command output

Item	Description
Quiet MAC	MAC address of MAC address migration users in quiet state.
Quiet Remain Time(Sec)	Remaining quiet time of MAC address migration users in quiet state, in seconds.

13.5.34 display dot1x

Function

The **display dot1x** command displays 802.1X authentication information.

Format

display dot1x [**statistics**] [**interface** { *interface-type interface-number1* [*to interface-number2*] } &<1-10>]

Parameters

Parameter	Description	Value
statistics	Displays statistics on 802.1X authentication. The statistics about 802.1X authentication is displayed only when this parameter is specified.	-
interface { <i>interface-type interface-number1</i> [<i>to interface-number2</i>] }	Displays 802.1X authentication information on a specified interface. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 802.1X authentication information on all device interfaces is displayed if this parameter is not specified.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

You can run the **display dot1x** command to view configuration results of all configuration commands in 802.1X authentication and statistics about 802.1X packets.

The command output helps you to check whether the current 802.1X authentication configuration is correct and isolate faults accordingly.

Follow-up Procedure

The **display dot1x** command displays the statistics on 802.1X packets. You can locate the fault according to the packet statistics. When the fault is rectified, run the **reset dot1x statistics** command to clear the packet statistics. After a period of time, run the **display dot1x** command again to check the packet statistics. If no error packet is found, the fault is rectified.

Example

Display 802.1X authentication information.

```
<HUAWEI> display dot1x
Global 802.1x is Enabled
Authentication method is CHAP
Max users: 1024
Current users: 1
DHCP-trigger is Disabled
Handshake is Enabled
Quiet function is Enabled
Mc-trigger port-up-send is Disabled
Parameter set:Dot1x Handshake Period    16s Reauthen Period    60s
      Arp Handshake Period    0s Client Timeout    10s
      Quiet Period            600s Quiet-times        2
      Eth-Trunk Handshake Period 120s Tx Period        30
      Mac-By-Pass Delay        30s
dot1x URL: www.***.com.cn
Free-ip configuration(IP/mask):
192.168.1.0 /255.255.255.0

GigabitEthernet0/0/3 status: UP 802.1x protocol is Enabled
Port control type is Auto
Authentication mode is MAC-based
Authentication method is CHAP
Reauthentication is disabled
Dot1x retry times: 2
Authenticating users: 1
Maximum users: 1024
Current users: 1

Authentication Success: 1      Failure: 0
Enter Enquence         : 0
EAPOL Packets: TX      : 19    RX      : 0
Sent EAPOL Request/Identity Packets : 1
```



```

EAPOL Request/Challenge Packets : 0
Multicast Trigger Packets      : 18
EAPOL Success Packets         : 0
EAPOL Failure Packets         : 0
Received EAPOL Start Packets   : 0
EAPOL Logoff Packets          : 0
EAPOL Response/Identity Packets : 0
EAPOL Response/Challenge Packets : 0

Online user(s) info:
-----
UserId  MAC/VLAN      AccessTime      UserName
-----
17487   000c-2952-fd80/34  2018/07/30 09:49:15  lss
-----
Total: 1, printed: 1

```

Display 802.1X statistics.

```

<HUAWEI> display dot1x statistics
Global 802.1x is Enabled
Authentication method is CHAP
Max users: 1024
Current users: 0
DHCP-trigger is Disabled
Handshake is Enabled
Quiet function is Enabled
Mc-trigger port-up-send is Disabled
Parameter set:Dot1x Handshake Period    16s Reauthen Period    60s
                Arp Handshake Period      0s Client Timeout    10s
                Quiet Period              600s Quiet-times      2
                Eth-Trunk Handshake Period 120s Tx Period      30
                Mac-By-Pass Delay         30s
dot1x URL: http://www.***.com.cn
Free-ip configuration(IP/mask):
192.168.1.0 /255.255.255.0

GigabitEthernet0/0/3 status: UP 802.1x protocol is Enabled
Controlled User(s) amount to 0

Authentication Success: 0      Failure: 0
Enter Enquence : 0
EAPOL Packets: TX : 20      RX : 0
Sent EAPOL Request/Identity Packets : 2
      EAPOL Request/Challenge Packets : 0
      Multicast Trigger Packets : 18
      EAPOL Success Packets : 0
      EAPOL Failure Packets : 0
Received EAPOL Start Packets : 0
      EAPOL Logoff Packets : 0
      EAPOL Response/Identity Packets : 0
      EAPOL Response/Challenge Packets : 0

```

Table 13-82 Description of the **display dot1x** command output

Item	Description
Global 802.1x is Enabled	802.1X authentication is enabled globally. To enable 802.1X authentication, run the dot1x enable command.
Authentication method is CHAP	CHAP authentication is enabled. The authentication methods include EAP, CHAP, and PAP To enable CHAP authentication, run the dot1x authentication-method command.

Item	Description
Max users	Maximum number of global online users, the value varies according to device models. To set the maximum number of global online users, run the dot1x max-user command.
Current users	Number of current online users.
DHCP-trigger is Disabled	Authentication triggering through DHCP packets is disabled. To trigger authentication using DHCP packets, run the dot1x dhcp-trigger command.
Handshake is Enabled	The handshake function is enabled for online users. To enable the handshake function, run the dot1x handshake command.
Quiet function is Disabled	The quiet function is disabled for users. To enable the quiet function function, run the dot1x quiet-period command.
Mc-trigger port-up-send is Disabled	The function of triggering 802.1X authentication through multicast packets immediately after an interface goes Up is disabled. To configure the function, run the dot1x mc-trigger port-up-send enable command.
Parameter set	Settings of 802.1X authentication parameters.
Dot1x Handshake Period	Handshake interval between the device and 802.1X authentication client connected to a non-Eth-Trunk interface. To set the handshake interval, run the dot1x timer command.
Arp Handshake Period	Handshake interval of the device with pre-connection users and authorized users.
Eth-Trunk Handshake Period	Handshake interval between the device and 802.1X authentication client connected to an Eth-Trunk. To set the handshake interval, run the dot1x timer command.
Reauthen Period	Re-authentication interval. To set the re-authentication interval, run the dot1x timer command.
Client Timeout	Timeout interval of a client. To set the timeout interval of a client, run the dot1x timer command.

Item	Description
Quiet Period	Value of the quiet timer. To set the value of the quiet timer, run the dot1x timer command.
Quiet-times	Maximum number of authentication failures before an 802.1X user enters the quiet state. To set the maximum number of authentication failures, run the dot1x quiet-times command.
Tx Period	The interval for sending authentication requests. To set the timeout interval of a client, run the dot1x timer command.
Mac-By-Pass Delay	The value of the delay timer for MAC address bypass authentication. To set the timeout interval of a client, run the dot1x timer command.
Free-ip configuration(IP/mask)	Free IP subnet. To set the free IP subnet, run the dot1x free-ip command.
dot1x URL	Redirect-to URL. To set the redirect-to URL, run the dot1x url command.
GigabitEthernet0/0/1 state	State of an interface. <ul style="list-style-type: none"> UP: The interface is started. DOWN: The interface is shut down.
802.1x protocol is Enabled[mac-bypass]	802.1X authentication is enabled on the interface. To enable 802.1X authentication, run the dot1x enable command. To configure MAC address bypass authentication, run the dot1x mac-bypass command. If MAC address bypass authentication is configured, [mac-bypass] is displayed.
Port control type is Auto	The control mode on the interface is auto for 802.1X authentication user access. The access control modes include auto , authorized-force , and unauthorized-force . To set the control mode, run the dot1x port-control command.
Authentication mode is MAC-based	The MAC address-based authentication method is used on the interface. To set the authentication method on the interface, run the dot1x port-method command.

Item	Description
Reauthentication is disabled	802.1x user re-authentication is disabled on the interface. To enable 802.1X user re-authentication, run the dot1x reauthenticate command.
Dot1x retry times	Maximum number of times an authentication request is sent to an 802.1X user. To set the maximum number of times an authentication request is sent to an 802.1X user, run the dot1x retry command.
Authenticating users	Number of users who are being authenticated.
Maximum users	Maximum number of online users on the interface. To set the maximum number of online users on the interface, run the dot1x max-user command.
Current users	Number of current online users on the interface.
Authentication Success Failure	Number of successful and failed authentications. The statistics include statistics on online 802.1X users but not on the users using MAC address bypass authentication.
Enter Enqueue	Number of packets entering the queue.
EAPOL Packets: TX RX	Number of globally received and sent EAPOL packets.
EAPOL Request/ Identity Packets	Number of globally received and sent EAPOL Request/ Identity packets.
EAPOL Request/ Challenge Packets	Number of globally received and sent EAPOL Request/ Challenge packets.
Multicast Trigger Packets	Number of received and sent multicast packets that trigger authentication.
EAPOL Success Packets	Number of globally received and sent EAPOL Success packets.
EAPOL Failure Packets	Number of globally received and sent EAPOL Failure packets.
EAPOL Start Packets	Number of globally received and sent EAPOL Start packets.
EAPOL Logoff Packets	Number of globally received and sent EAPOL LogOff packets.
EAPOL Response/ Identity Packets	Number of globally sent and received EAPOL Response/ Identity packets.

Item	Description
EAPOL Response/Challenge Packets	Number of globally sent and received EAPOL Response/Challenge packets.
Controlled User(s) amount to	Number of users who pass authentication successfully.
Online user(s) info	Online user information: <ul style="list-style-type: none"> • UserId: User ID. • MAC/VLAN: MAC address/VLAN ID. • AccessTime: Access time. • UserName: User name. • Total: Total number of online users. • printed: Number of displayed online users.

13.5.35 display dot1x quiet-user

Function

The **display dot1x quiet-user** command displays information about 802.1X authentication users who are quieted.

Format

display dot1x quiet-user { **all** | **mac-address** *mac-address* }

Parameters

Parameter	Description	Value
all	Displays information about all 802.1X authentication users who are quieted.	-
mac-address <i>mac-address</i>	Displays information about a quiet 802.1X authentication user with a specified MAC address.	The value is in H-H-H format. Each H is a hexadecimal number of 1 to 4 digits.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run this command to view information about 802.1X authentication users who are quieted.

Example

Display information about all 802.1X authentication users who are quieted.

```
<HUAWEI> display dot1x quiet-user all
-----
MacAddress                               Quiet Remain Time(Sec)
-----
0001-0002-0003                           50
-----
1 silent mac address(es) found, 1 printed.
```

Table 13-83 Description of the **display dot1x quiet-user all** command output

Item	Description
MacAddress	MAC address of an 802.1X authentication user who is quieted.
Quiet Remain Time(Sec)	Remaining quiet time of an 802.1X authentication user who is quieted, in seconds.

13.5.36 display mac-address authen

Function

The **display mac-address authen** command displays the current authen MAC address entries in the system.

Format

display mac-address authen [*interface-type interface-number* | **vlan** *vlan-id*] *
[**verbose**]

Parameters

Parameter	Description	Value
vlan <i>vlan-id</i>	Displays MAC address entries in a specified VLAN. If no VLAN is specified, MAC address entries in all VLANs of the device are displayed.	The value is an integer that ranges from 1 to 4094.

Parameter	Description	Value
<i>interface-type</i> <i>interface-number</i>	Displays MAC address entries on a specified interface. If no interface is specified, MAC address entries on all interfaces of the device are displayed.	-
verbose	Displays detailed information about MAC address entries.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

The authen MAC address entries are generated for pre-connection users or after users pass authentication. The administrator can run this command to check the existing authen or guest MAC address entries on the device. The administrator can check information about user access based on these MAC address entries to locate user access faults.

Precautions

If there are a lot of authen MAC address entries, you can specify a VLAN or use a pipe operator (|) to filter the output information. Otherwise, the following problems may occur due to excessive output information:

- The displayed information is refreshed repeatedly on the terminal screen and the administrator cannot obtain the required information.
- The device traverses and retrieves information for a long time, and does not respond to any request.

Example

Display all authen MAC address entries in the system.

```
<HUAWEI> display mac-address authen
-----
MAC Address  VLAN/VSI/BD          Learned-From  Type
-----
0000-0000-0100 3000/-/-          GE0/0/1      authen
0000-0000-0400 3000/-/-          GE0/0/1      authen
0000-0000-0200 3000/-/-          GE0/0/1      authen
-----
Total items displayed = 3
```

Table 13-84 Description of the **display mac-address authen** command output

Item	Description
MAC Address	MAC address of a user to be authenticated.
VLAN/VSI/BD	VLAN/VSI/BD that the outbound interface belongs to.
Learned-From	Interface on which a MAC address is learned.
Type	Type of MAC addresses.
Total items displayed	Total number of MAC address entries that match the filter condition.

13.5.37 display mac-address pre-authen

Function

The **display mac-address pre-authen** command displays the current pre-authen MAC address entries in the system.

Format

display mac-address pre-authen [*interface-type interface-number* | **vlan** *vlan-id*] * [**verbose**]

Parameters

Parameter	Description	Value
vlan <i>vlan-id</i>	Displays MAC address entries in a specified VLAN. If no VLAN is specified, MAC address entries in all VLANs of the device are displayed.	The value is an integer that ranges from 1 to 4094.
<i>interface-type interface-number</i>	Displays MAC address entries on a specified interface. If no interface is specified, MAC address entries on all interfaces of the device are displayed.	-
verbose	Displays detailed information about MAC address entries.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

You can run this command to check the existing MAC address entries of the pre-connection type to obtain access information about pre-connection users and locate faults.

Precautions

If there are a lot of pre-authen MAC address entries, you can specify a VLAN or use a pipe operator (|) to filter the output information. Otherwise, the following problems may occur due to excessive output information:

- The displayed information is refreshed repeatedly on the terminal screen and the administrator cannot obtain the required information.
- The device traverses and retrieves information for a long time, and does not respond to any request.

Example

Display all pre-authen MAC address entries in the system.

```
<HUAWEI> display mac-address pre-authen
-----
MAC Address  VLAN/VSI/BD          Learned-From  Type
-----
0000-0000-0100 3000/-/-          GE0/0/1      pre-authen
0000-0000-0400 3000/-/-          GE0/0/1      pre-authen
0000-0000-0200 3000/-/-          GE0/0/1      pre-authen
-----
Total items displayed = 3
```

Table 13-85 Description of the **display mac-address pre-authen** command output

Item	Description
MAC Address /BD	MAC address of a user to be authenticated.
VLAN/VSI	VLAN/VSI/BD that the outbound interface belongs to.
Learned-From	Interface on which a MAC address is learned.
Type	Type of a MAC address entry.
Total items displayed	Total number of MAC address entries that match the filter condition.

13.5.38 display mac-authen

Function

The **display mac-authen** command displays information about MAC address authentication.

Format

display mac-authen [**interface** { *interface-type interface-number1* [**to** *interface-number2*] } <1-10> | **configuration**]

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Displays information about MAC address authentication on a specified interface. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number. MAC address authentication information on all device interfaces is displayed if this parameter is not specified.	-
configuration	Displays the global information about MAC address authentication.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

You can run the **display mac-authen** command to view configuration results of all configuration commands in MAC address authentication. The command output

helps you to check whether the MAC address authentication configuration is correct and isolate faults accordingly.

Follow-up Procedure

You can locate the fault according to the packet statistics that is displayed using the **display mac-authen** command. When the fault is rectified, run the **reset mac-authen statistics** command to clear the packet statistics. After a period of time, run the **display mac-authen** command again to check the packet statistics. If no error packet is found, the fault is rectified.

Example

View all information about MAC address authentication.

```
<HUAWEI> display mac-authen
MAC address authentication is Enabled.
Username format: use MAC address without-hyphen as username
Quiet period is 60s
Authentication fail times before quiet is 1
Offline detect period is 300s
Reauthenticate period is 1000s
Guest user reauthenticate period is 60s
Maximum users: 100
Current users: 1
Global domain is not configured
Trigger condition: dhcp arp dhcpv6 nd

GigabitEthernet0/0/1 state : UP. MAC address authentication is enabled
Reauthentication is enabled
Reauthen Period: 1000s
Maximum users: 100
Current users: 1
Authentication Success: 0, Failure: 0

Online user(s) info:
-----
Userld  MAC/VLAN      AccessTime      UserName
-----
16016  5489-9801-583d/2003 2014/01/26 09:22:49 wlan
-----
Total 1,1 printed
```

Table 13-86 Description of the **display mac-authen** command output

Item	Description
Mac address authentication is Enabled	MAC address authentication is enabled. To enable MAC address authentication, run the mac-authen command.

Item	Description
Username format	<p>User name format for MAC address authentication.</p> <ul style="list-style-type: none">• use MAC address without-hyphen as username: A user name is a MAC address that does not contain hyphens (-), for example, 0005e01c02e3.• use MAC address with-hyphen as username: A user name is a MAC address that contains hyphens (-) and the hyphens are inserted between every four digits, for example, 0005-e01c-02e3.• use MAC address with-hyphen normal as username: A user name is a MAC address that contains hyphens (-) and the hyphens are inserted between every two digits, for example, 00-05-e0-1c-02-e3.• use MAC address without-hyphen upper as username: A user name is a MAC address in the uppercase format that does not contain hyphens (-), for example, 0005E01C02E3.• use MAC address with-hyphen upper as username: A user name is a MAC address in the uppercase format that contains hyphens (-) and the hyphens are inserted between every four digits, for example, 0005-E01C-02E3.• use MAC address with-hyphen normal upper as username: A user name is a MAC address in the uppercase format that contains hyphens (-) and the hyphens are inserted between every two digits, for example, 00-05-E0-1C-02-E3.• fixed username: The user name is fixed.• use option82 as username: The content of the Option 82 field is used as the user name.• not configured: The user name format is not configured.

Item	Description
	To configure a user name, run the mac-authen username command.
Quiet period	<p>Quiet timer value, during which the user waits for re-authentication after the maximum number of authentication failures is exceeded. The default value of the quiet timer is 60 seconds.</p> <p>To set the quiet period, run the mac-authen timer command.</p>
Authentication fail times before quiet	Maximum number of authentication failures before a MAC address authentication user enters the quiet state.
Offline detect period	<p>Interval for detecting online users. The timer is used to periodically check whether a user is offline. The default interval is 300 seconds.</p> <p>To set the interval for detecting online users, run the mac-authen timer command.</p>
Reauthenticate period is 1000s	<p>Interval at which users are re-authenticated. The default interval is 1800 seconds.</p> <p>To set the re-authentication period, run the mac-authen timer command.</p>
Guest user reauthenticate period is 60s	<p>Interval at which users in a guest VLAN are re-authenticated. The default interval is 60 seconds.</p> <p>To set the guest VLAN user re-authentication period, run the mac-authen timer command.</p>
Maximum users	<p>Maximum number of online users allowed by the device, the value varies according to devices.</p> <p>To set the maximum number of MAC address authentication users on an interface, run the mac-authen max-user command.</p>
Current users	Number of current online users.

Item	Description
Global domain	<p>Current authentication domain. By default, no authentication domain is specified for users. If you do not specify any domain for users, the default domain in the system is used.</p> <p>To configure an authentication domain, run the mac-authen domain command.</p>
Trigger condition	<p>Packet type that can trigger MAC address authentication.</p> <p>To configure the packet type, run the 13.5.89 mac-authen trigger command.</p>
GigabitEthernet0/0/1 current state	<p>Interface state.</p> <ul style="list-style-type: none"> ● UP: The interface is started. ● DOWN: The interface is shut down.
MAC address authentication is Enabled	<p>MAC address authentication is enabled on the interface. To enable MAC address authentication, run the mac-authen command.</p>
Reauthentication is enabled	<p>MAC address reauthentication is enabled. To enable the MAC address reauthentication, run the 13.5.96 mac-authen reauthenticate command.</p>
Reauthen Period	<p>Interval at which users are re-authenticated. The default interval is 1800 seconds. To set the re-authentication period, run the 13.5.100 mac-authen timer reauthenticate-period command.</p>
Maximum users	<p>Maximum number of MAC address authentication users on the interface.</p> <p>To set the maximum number of MAC address authentication users on an interface, run the mac-authen max-user command.</p>
Current users	<p>Number of current online users on the interface.</p>
Authentication Success: 0, Failure: 0	<p>Numbers of successful and failed authentications on the interface.</p>
UserId	<p>ID of an online user.</p>

Item	Description
MAC/VLAN	MAC address and VLAN of a user. NOTE If the AAA server delivers an authorized VLAN, information about the authorized VLAN is displayed.
AccessTime	Access time of a user.
UserName	Name of a user.

13.5.39 display mac-authen quiet-user

Function

The **display mac-authen quiet-user** command displays information about MAC address authentication users who are quieted.

Format

```
display mac-authen quiet-user { all | mac-address mac-address }
```

Parameters

Parameter	Description	Value
all	Displays information about all MAC address authentication users who are quieted.	-
mac-address <i>mac-address</i>	Displays information about a specified MAC address authentication user who is quieted.	The value is in the H-H-H format. Each H is a hexadecimal number of 1 to 4 digits.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run this command to view information about MAC address authentication users who are quieted.

Example

Display information about all MAC address authentication users who are quieted.

```
<HUAWEI> display mac-authen quiet-user all
-----
MacAddress                Quiet Remain Time(Sec)
-----
0001-0002-0003           50
-----
1 silent mac address(es) found, 1 printed.
```

Table 13-87 Description of the **display mac-authen quiet-user all** command output

Item	Description
MacAddress	MAC address of a MAC address authentication user who is quieted.
Quiet Remain Time(Sec)	Remaining quiet time of a MAC address authentication user who is quieted, in seconds.

13.5.40 display port connection-type access all

Function

The **display port connection-type access all** command displays all current downlink interfaces on the device.

Format

```
display port connection-type access all
```

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run this command to check all current downlink interfaces on the device.

Example

Display all current downlink interfaces on the device.

```
<HUAWEI> display port connection-type access all
Slot 0:
GigabitEthernet0/0/1   GigabitEthernet0/0/2   GigabitEthernet0/0/3
GigabitEthernet0/0/4   GigabitEthernet0/0/5   GigabitEthernet0/0/6
GigabitEthernet0/0/7   GigabitEthernet0/0/8   GigabitEthernet0/0/9
GigabitEthernet0/0/10  GigabitEthernet0/0/11  GigabitEthernet0/0/12
GigabitEthernet0/0/13  GigabitEthernet0/0/14  GigabitEthernet0/0/15
GigabitEthernet0/0/16  GigabitEthernet0/0/17  GigabitEthernet0/0/18
GigabitEthernet0/0/19  GigabitEthernet0/0/20  GigabitEthernet0/0/21
GigabitEthernet0/0/22  GigabitEthernet0/0/23  GigabitEthernet0/0/24
```

Table 13-88 Description of the display port connection-type access all command output

Item	Description
Slot 0	Slot ID.
GigabitEthernet0/0/1	Interface name.

13.5.41 display portal

Function

The **display portal** command displays the Portal authentication configuration.

Format

display portal [**interface** *interface-type interface-number* | **configuration**]

Parameters

Parameter	Description	Value
interface <i>interface-type interface-number</i>	Displays Portal authentication configuration on a specified interface. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. Portal authentication configuration in the system view or on all interfaces is displayed if this parameter is not specified.	-
configuration	Displays the global Portal authentication configuration.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display portal** command to view the Portal authentication configuration and check whether the configuration is correct.

Example

Display the Portal authentication configuration.

```
<HUAWEI> display portal
Portal timer offline-detect length:500
Portal max-user number:100
Quiet function is Disabled
Different-server is Disabled
Parameter set: Quiet Period 60s Quiet-times 3
Logout packets resend: Resend-times 3 Timeout 5s
Portal user(s) on slot 0:1

Vlanif10 protocol status: up, web-auth-server layer2(direct)
Portal domain: tsm
Auth-network:
 10.3.3.3 255.255.255.255
 10.8.0.0 255.255.0.0
```

Display the Portal authentication configuration on VLANIF10.

```
<HUAWEI> display portal interface vlanif 10

Vlanif10 protocol status: up, web-auth-server layer2(direct)
Portal domain: tsm
Auth-network:
 10.3.3.3 255.255.255.255
 10.8.0.0 255.255.0.0
```

Table 13-89 Description of the **display portal** command output

Item	Description
Portal timer offline-detect length	Portal authentication user offline detection interval. To set the user offline detection interval, run the 13.5.129 portal timer offline-detect command.

Item	Description
Portal max-user number	<p>Maximum number of concurrent Portal authentication users allowed to access the device, the value varies according to device models.</p> <p>To set the maximum number of concurrent Portal authentication users allowed to access the device, run the 13.5.126 portal max-user command.</p>
Quiet function is Enabled or Quiet function is Disabled	<p>Whether the quiet function in Portal authentication is enabled.</p> <ul style="list-style-type: none"> • Enabled • Disabled <p>To enable the quiet function, run the 13.5.127 portal quiet-period command.</p>
Different-server is Enabled or Different-server is Disabled	<p>Whether a device is enabled to process user logout requests sent by a Portal server other than the one from which users log in:</p> <ul style="list-style-type: none"> • Enabled • Disabled <p>To configure a device to process user logout requests sent by a Portal server other than the one from which users log in, command, run the 13.5.124 portal logout different-server enable command.</p>
Parameter set	<p>Parameter settings of the quiet function in Portal authentication.</p> <ul style="list-style-type: none"> • Quiet Period: indicates the quite period in Portal authentication. To set the quite period in Portal authentication, run the 13.5.130 portal timer quiet-period command. • Quiet-times: indicates the maximum number of authentication failures within 60 seconds before a Portal authentication user enters the quiet state. To set the maximum number of authentication failures, run the 13.5.128 portal quiet-times command.

Item	Description
Logout packets resend	<p>Configuration of the logout packet re-transmission function for Portal authentication users.</p> <ul style="list-style-type: none"> Resend-times: indicates the number of re-transmission times for Portal authentication user logout packets. Timeout: indicates the re-transmission interval of Portal authentication user logout packets. <p>To set the re-transmission interval, run the 13.5.125 portal logout resend timeout command.</p>
Portal user(s) on slot 0	<p>Statistics on Portal authentication users on the device.</p> <p>NOTE This parameter is unavailable when no Portal authentication user is online.</p> <p>When Portal authentication users go online through an Eth-Trunk, the number of Portal authentication users on the device where Eth-Trunk member interfaces are located is the same as the actual number of Portal authentication users on the device.</p>
Vlanif10 protocol status	<p>Link layer protocol state of the VLANIF interface.</p> <ul style="list-style-type: none"> up: indicates that the interface is running properly. down: indicates that the interface is disabled. web-auth-server layer2(direct): indicates that the authentication mode is set to Layer 2 Portal authentication on a specified interface.
Portal domain	<p>Name of a forcible Portal authentication domain.</p> <p>To set a forcible Portal authentication domain, run the 13.5.106 portal domain command.</p>
Auth-network	<p>Portal authentication subnet.</p> <p>To set the Portal authentication subnet, run the 13.5.105 portal auth-network command.</p>

13.5.42 display portal free-rule

Function

The **display portal free-rule** command displays authentication-free rules for Portal authentication users.

Format

display portal free-rule [*rule-id*]

Parameters

Parameter	Description	Value
<i>rule-id</i>	Displays the ID of an authentication-free rule. If the rule ID is not specified, the configuration of all authentication-free rules is displayed.	The value is an integer of which the range depends on product models.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

The **display portal free-rule** command shows the configuration of authentication-free rules. You can locate faults according to the command output.

Example

Display the configuration of authentication-free rules.

```
<HUAWEI> display portal free-rule
portal free-rule 0 destination ip 10.1.1.1 mask 255.255.255.255
portal free-rule 10 destination ip 10.1.1.2 mask 255.255.255.255
Total 2 free-rules
```

Display the configuration of authentication-free rule 10.

```
<HUAWEI> display portal free-rule 10
portal free-rule 10 destination ip 10.1.1.1 mask 255.255.255.255
```

Related Topics

[13.5.107 portal free-rule](#)

13.5.43 display portal local-server

Function

The **display portal local-server** command displays the configurations of a built-in Portal server.

Format

display portal local-server

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring the built-in Portal authentication, run this command to view the configurations of a built-in Portal server.

Example

Display the configurations of a built-in Portal server.

```
<HUAWEI> display portal local-server
Portal local-server config:
server status      : disable
Heartbeat-check status : disable
server ip         : -
authentication method : chap
protocol          : -
https ssl-policy  : -
server port       : 0
session-timeout   : 8(h)
syslog-limit      : enable
syslog-limit period : 300(s)
server pagename   : -
server page-text  : -
server policy-text : -
server background-image : default-image0
server background-color : -
server logo       : -
server ad-image   : -
```

Table 13-90 Description of the **display portal local-server** command output

Item	Description
server status	<p>Status of a built-in Portal server. To enable the built-in Portal server function, run the portal local-server command.</p> <ul style="list-style-type: none"> • disable: Portal authentication is disabled. • enable: Portal authentication is enabled.
Heartbeat-check status	<p>Heartbeat detection status of the built-in Portal server. To set the heartbeat detection status, run the 13.5.116 portal local-server keep-alive command.</p> <ul style="list-style-type: none"> • disable: indicates that the heartbeat detection function is disabled. • enable: indicates the forcible detection mode. • auto: indicates the automatic detection mode.
Heartbeat-timeout value	<p>Heartbeat detection interval of the built-in Portal server. To set the heartbeat detection interval, run the 13.5.116 portal local-server keep-alive command.</p> <p>This parameter is unavailable when the value of Heartbeat-check status is disable.</p>
server ip	<p>IP address of a built-in Portal server. To set the server IP address, run the portal local-server ip command.</p>
authentication method	<p>Authentication method used by a built-in Portal server for Portal users. To set the authentication method, run the portal local-server authentication-method command.</p> <ul style="list-style-type: none"> • chap: CHAP-based authentication (CHAP stands for Challenge Handshake Authentication Protocol.) • pap: PAP-based authentication (PAP stands for Password Authentication Protocol.)

Item	Description
protocol	<p>Protocol used for authentication information exchange between a built-in Portal server and users. To enable the built-in Portal server function, run the portal local-server command.</p> <ul style="list-style-type: none"> • http: Hypertext Transfer Protocol (HTTP) • https: Hypertext Transfer Protocol Secure (HTTPS)
https ssl-policy	<p>SSL policy used for authentication information exchange between a built-in Portal server and users. To enable the built-in Portal server function, run the portal local-server command.</p>
server port	<p>TCP port number used by HTTPS. To specify a TCP port number used by HTTPS, run the portal local-server command.</p>
session-timeout	<p>User session timeout interval configured on the built-in Portal server. To set the session timeout interval, run the portal local-server timer session-timeout command.</p>
syslog-limit	<p>Status of the log suppression function for built-in Portal authentication users. To enable or disable the log suppression function, run the 13.5.121 portal local-server syslog-limit enable command.</p> <ul style="list-style-type: none"> • disable: indicates that the log suppression function is disabled for built-in Portal authentication users. • enable: indicates that the log suppression function is enabled for built-in Portal authentication users.
syslog-limit period	<p>Log suppression duration for built-in Portal authentication users. To set the log suppression duration, run the 13.5.122 portal local-server syslog-limit period command.</p>
server pagename	<p>Name of the page file package loaded to the built-in Portal server, run the 13.5.117 portal local-server load command.</p>

Item	Description
server page-text	Loaded use instruction page file of the built-in Portal server. To load a use instruction page file, run the 13.5.119 portal local-server page-text load command.
server policy-text	Disclaimer page loaded to the built-in Portal server. To set the disclaimer page, run the 13.5.120 portal local-server policy-text load command.
server background-image	Background image of the built-in Portal server login page. To set the background image, run the 13.5.113 portal local-server background-image load command.
server background-color	Background color of the built-in Portal server login page. To set the background color, run the 13.5.112 portal local-server background-color command.
server logo	Logo file of the built-in Portal server login page. To configure the logo file, run the 13.5.118 portal local-server logo load command.
server ad-image	Advertisement image file of the built-in Portal server login page. To configure the advertisement image file, run the 13.5.109 portal local-server ad-image load command.

13.5.44 display portal local-server connect

Function

The **display portal local-server connect** command displays the connection status of users to be authenticated on a built-in Portal server.

Format

display portal local-server connect [*user-ip ip-address*]

Parameters

Parameter	Description	Value
user-ip <i>ip-address</i>	Displays the connection entry of a user with a specified IP address on a built-in Portal server. The connection entries of all users on the built-in Portal server are displayed if this parameter is not specified.	The value of <i>ip-address</i> is in dotted decimal notation.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display portal local-server connect** command to check the authentication mode and status of users to be authenticated on a built-in Portal server.

Example

Display the connection status of the user with the IP address 9.8.7.6 on a built-in Portal server.

```
<HUAWEI> display portal local-server connect user-ip 10.1.1.10
```

```
-----  
CID IP Address  AuthMode State  
1  10.1.1.10   CHAP   ONLINE  
-----
```

Display the connection status of all users on the built-in Portal server.

```
<HUAWEI> display portal local-server connect
```

```
-----  
CID IP Address  AuthMode State  
1  10.1.1.10   CHAP   ONLINE  
2  10.1.1.11   PAP    ONLINE  
-----
```

Table 13-91 Description of the **display portal local-server connect** command output

Item	Description
CID	User table index.
IP Address	IP address of a user.
AuthMode	Authentication mode: <ul style="list-style-type: none">● CHAP: The built-in Portal server uses CHAP to authenticate the user.● PAP: The built-in Portal server uses PAP to authenticate the user. To set the authentication method, run the 13.5.111 portal local-server authentication-method command.
State	User status: <ul style="list-style-type: none">● WAIT_CHALLENGE: waiting for the challenge● WAIT_AUTHACK: waiting for the authentication response● ONLINE: online● WAIT_LOGOUTACK: waiting for logout

Related Topics

[13.5.111 portal local-server authentication-method](#)

[13.5.108 portal local-server](#)

[13.5.114 portal local-server enable](#)

13.5.45 display portal local-server page-information

Function

The **display portal local-server page-information** command displays the page files loaded to the memory of a built-in Portal server.

Format

display portal local-server page-information

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display portal local-server page-information** command to check the page files loaded to the memory of a built-in Portal server.

Example

Display the page files loaded to the memory of a built-in Portal server.

```
<HUAWEI> display portal local-server page-information
```

```
-----  
Number of backup pages:35  
Size of backup pages:94438 byte
```

```
-----  
Name:/logout_success.html  
Size:4042 byte  
Last-Modified-Time:2011-12-16 20:24:46  
-----
```

Table 13-92 Description of the **display portal local-server page-information** command output

Item	Description
Number of backup pages	Number of page files loaded.
Size of backup pages	Total size of the loaded page files.
Name	Name of a page file.
Size	Size of a page file.
Last-Modified-Time	Last modification time.

Related Topics

[13.5.117 portal local-server load](#)

13.5.46 display portal quiet-user

Function

The **display portal quiet-user** command displays information about Portal authentication users in quiet state.

Format

```
display portal quiet-user { all | server-ip ip-address | user-ip ip-address }
```

Parameters

Parameter	Description	Value
all	Displays information about all Portal authentication users in quiet state.	-
user-ip <i>ip-address</i>	Displays information about the quiet user with the specified IP address.	The value is in dotted decimal notation.
server-ip <i>ip-address</i>	Displays information about all the users in quiet state authenticated by the Portal authentication server with a specified IP address.	The value is in dotted decimal notation.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After the quiet timer is enabled, you can run the **display portal quiet-user** command to view information about Portal authentication users in quiet state.

Example

Display information about all Portal authentication users in quiet state.

```
<HUAWEI> display portal quiet-user all
Quiet IP information
```

```
-----
Quiet ip                               Quiet Remain Time(Sec)
-----
192.168.1.1                             10
192.168.1.2                             20
-----
```

2 quiet IP found, 2 printed.

Display information about all the users in quiet state authenticated by the Portal authentication server with IP address 192.168.2.1.

```
<HUAWEI> display portal quiet-user server-ip 192.168.2.1
Quiet IP information
```

```
-----
Quiet ip                               Quiet Remain Time(Sec)
-----
192.168.1.3                             10
192.168.1.4                             20
-----
```

2 quiet IP found, 2 printed.

Display information about the user in quiet state at 192.168.1.1.

```
<HUAWEI> display portal quiet-user user-ip 192.168.1.1  
Quiet remain second 100
```

Table 13-93 Description of the **display portal quiet-user** command output

Item	Description
Quiet IP information	Information about the user in quiet state.
Quiet ip	IP address of the user in quiet state.
Quiet Remain Time(Sec)	Remaining quiet time of the user in quiet state, in seconds.
Quiet remain second	Remaining quiet period of the user in quiet state.

Related Topics

[13.5.127 portal quiet-period](#)

[13.5.128 portal quiet-times](#)

[13.5.130 portal timer quiet-period](#)

13.5.47 display portal user-logout

Function

The **display portal user-logout** command displays temporary logout entries of Portal authentication users.

Format

```
display portal user-logout [ ip-address ip-address [ vpn-instance vpn-instance-name ] ]
```

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
ip-address <i>ip-address</i>	Displays temporary logout entries of the Portal authentication user with a specified IP address.	The value is in dotted decimal notation.

Parameter	Description	Value
vpn-instance <i>vpn-instance-name</i>	Displays temporary logout entries of the Portal authentication user with a specified VPN instance.	The value must be an existing VPN instance name.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

The device records temporary entries after Portal authentication users are disconnected. The network administrator can run this command to check temporary logout entries to locate faults.

If the parameter **ip-address** *ip-address* [**vpn-instance** *vpn-instance-name*] is not specified, the temporary logout entries of all Portal authentication users are displayed.

Example

Display the temporary logout entries of all Portal authentication users.

```
<HUAWEI> display portal user-logout
```

```
-----
UserIP      Vrf      Resend Times TableID
-----
192.168.111.100 1      3      0
-----
Total: 1, printed: 1
```

Table 13-94 Description of the **display portal user-logout** command output

Item	Description
UserIP	IP address of the Portal authentication user.
Vrf	VPN instance that the Portal authentication user belongs to.

Item	Description
Resend Times	Number of logout packet re-transmission times. To set the number of logout packet re-transmission times, run the 13.5.125 portal logout resend timeout command.
TableID	Index of the temporary logout entry.
Total: <i>m</i> , printed: <i>n</i>	Total number of temporary logout entries and number of displayed entries.

13.5.48 display portal url-encode configuration

Function

The **display portal url-encode configuration** command displays the configuration of URL encoding and decoding.

Format

display portal url-encode configuration

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After configuring URL encoding and decoding, you can run the **display portal url-encode configuration** command to check the configuration.

Example

Display the configuration of URL encoding and decoding.

```
<HUAWEI> display portal url-encode configuration
Portal URL Encode : Disable
```


Table 13-95 Description of the **display portal url-encode configuration** command output

Item	Description
Portal URL Encode	Whether URL encoding and decoding are enabled: <ul style="list-style-type: none">• Disable• Enable To configure the function, run the 13.5.131 portal url-encode enable command.

Related Topics

[13.5.131 portal url-encode enable](#)

13.5.49 display server-detect state

Function

The **display server-detect state** command displays the status of a Portal server.

Format

display server-detect state [**web-auth-server** *server-name*]

Parameters

Parameter	Description	Value
web-auth-server <i>server-name</i>	Displays information about the Portal server status configured in the specified Portal server template. If this parameter is not specified, status of all Portal servers is displayed.	The Portal server template name must exist.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

When an external Portal server is used for Portal authentication, you can run the **display server-detect state** command to check information about the Portal server status.

Example

Display information about the Portal server status configured in the Portal server template **abc**.

```
<HUAWEI> display server-detect state web-auth-server abc
Web-auth-server : abc
Total-servers   : 4
Live-servers    : 1
Critical-num    : 0
Status          : Normal
Ip-address      : Status
192.168.2.1    : UP
192.168.2.2    : DOWN
192.168.2.3    : DOWN
192.168.2.4    : DOWN
```

Table 13-96 Description of the **display server-detect state** command output

Item	Description
Web-auth-server	Name of the Portal server template.
Total-servers	Number of Portal servers configured.
Live-servers	Number of Portal servers in Up state.
Critical-num	Minimum number of Portal servers in Up state. If the number of Portal servers is less than this value, enable the survival function in the corresponding Portal server template view.
Status	Status of the Portal server. The values are as follows: <ul style="list-style-type: none"> • Normal: normal state • Permit-all: survival state
Ip-address	IP address of the Portal server.
Status	Whether the Portal server with the specified IP address is reachable. The values are as follows: <ul style="list-style-type: none"> • UP: reachable • DOWN: unreachable

Related Topics

- [13.5.141 server-ip \(Portal server template view\)](#)
- [13.5.140 server-detect](#)

13.5.50 display snmp-agent trap feature-name mid_aaa all

Function

The **display snmp-agent trap feature-name mid_aaa all** command displays the status of all traps on the AAA module.

Format

```
display snmp-agent trap feature-name mid_aaa all
```

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After enabling the trap function for the AAA module, you can run this command to check the status of all traps on the AAA module. To enable the trap function for the AAA module, run the [snmp-agent trap enable feature-name mid_aaa](#) command.

Prerequisites

The SNMP function has been enabled on the device. For details, see [snmp-agent](#).

Example

```
# Display the status of all traps on the AAA module.
```

```
<HUAWEI> display snmp-agent trap feature-name mid_aaa all
-----
Feature name: MID_AAA
Trap number : 2
-----
Trap name           Default switch status  Current switch status
hwMacMovedQuietMaxUserAlarm  on                    on
hwMacMovedQuietUserClearAlarm on                    on
```

Table 13-97 Description of the **display snmp-agent trap feature-name mid_aaa all** command output

Item	Description
Feature name	Name of the module to which a trap belongs.

Item	Description
Trap number	Number of traps.
Trap name	Name of a trap. Traps on the AAA module include: <ul style="list-style-type: none">• hwMacMovedQuietMaxUserAlarm: A Huawei proprietary trap message is sent when the percentage of current MAC address migration users in quiet state against the maximum number of users exceeds the upper alarm threshold.• hwMacMovedQuietUserClearAlarm: A Huawei proprietary trap message is sent when the percentage of current MAC address migration users in quiet state against the maximum number of users decreases to be equal to or smaller than the lower alarm threshold.
Default switch status	Default status of the trap function: <ul style="list-style-type: none">• on: The trap function is enabled by default.• off: The trap function is disabled by default.
Current switch status	Trap status: <ul style="list-style-type: none">• on: The trap is enabled.• off: The trap is disabled.

Related Topics

[13.5.143 snmp-agent trap enable feature-name mid_aaa](#)

13.5.51 display snmp-agent trap feature-name mid_eapol all

Function

The **display snmp-agent trap feature-name mid_eapol all** command displays the status of all traps on the DOT1X module.

Format

```
display snmp-agent trap feature-name mid_eapol all
```

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After enabling the trap function for the DOT1X module, you can run this command to check the status of all traps on the DOT1X module. To enable the trap function for the DOT1X module, run the [snmp-agent trap enable feature-name mid_eapol](#) command.

Prerequisites

The SNMP function has been enabled on the device. For details, see [snmp-agent](#).

Example

Display the status of all traps on the DOT1X module.

```
<HUAWEI> display snmp-agent trap feature-name mid_eapol all
-----
Feature name: MID_EAPOL
Trap number : 2
-----
Trap name           Default switch status  Current switch status
hwSrvcfgEapMaxUserAlarm  on                    on
hwMacAuthenMaxUserAlarm  on                    on
```

Table 13-98 Description of the [display snmp-agent trap feature-name mid_eapol all](#) command output

Item	Description
Feature name	Name of the module to which a trap belongs.
Trap number	Number of traps.
Trap name	Name of a trap. Traps on the DOT1X module include: <ul style="list-style-type: none"> hwSrvcfgEapMaxUserAlarm: The device sends a Huawei proprietary trap when the number of 802.1X authentication users reaches the maximum number allowed on an interface. hwMacAuthenMaxUserAlarm: The device sends a Huawei proprietary trap when the number of MAC address authentication users reaches the maximum number allowed on an interface.
Default switch status	Default status of the trap function: <ul style="list-style-type: none"> on: The trap function is enabled by default. off: The trap function is disabled by default.
Current switch status	Trap status: <ul style="list-style-type: none"> on: The trap is enabled. off: The trap is disabled.

Related Topics

[13.5.144 snmp-agent trap enable feature-name mid_eapol](#)

13.5.52 display snmp-agent trap feature-name mid_web all

Function

The **display snmp-agent trap feature-name mid_web all** command displays the status of all traps on the web authentication module.

Format

display snmp-agent trap feature-name mid_web all

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After enabling the trap function for the web authentication module, you can run this command to check the status of all traps on the web authentication module. To enable the trap function for the web authentication module, run the [snmp-agent trap enable feature-name mid_web](#) command.

Prerequisites

The SNMP function has been enabled on the device. For details, see [snmp-agent](#).

Example

Display the status of all traps on the web authentication module.

```
<HUAWEI> display snmp-agent trap feature-name mid_web all
-----
Feature name: MID_WEB
Trap number : 4
-----
Trap name           Default switch status  Current switch status
hwPortalServerUp    on                     on
hwPortalServerDown  on                     on
hwPortalMaxUserAlarm on                      on
hwPortalUserClearAlarm on                      on
```

Table 13-99 Description of the **display snmp-agent trap feature-name mid_web all** command output

Item	Description
Feature name	Name of the module to which a trap belongs.
Trap number	Number of traps.
Trap name	Name of a trap. Traps on the web authentication module include: <ul style="list-style-type: none"> • hwPortalServerUp: The device sends a Huawei proprietary trap when it detects that the Portal server changes from Down to Up. • hwPortalServerDown: The device sends a Huawei proprietary trap when it detects that the Portal server changes from Up to Down. • hwPortalMaxUserAlarm: The device sends a Huawei proprietary trap when the number of online Portal authentication users exceeds the upper threshold. • hwPortalUserClearAlarm: The device sends a Huawei proprietary trap when the number of online Portal authentication users falls below the lower threshold.
Default switch status	Default status of the trap function: <ul style="list-style-type: none"> • on: The trap function is enabled by default. • off: The trap function is disabled by default.
Current switch status	Trap status: <ul style="list-style-type: none"> • on: The trap is enabled. • off: The trap is disabled.

Related Topics

[13.5.145 snmp-agent trap enable feature-name mid_web](#)

13.5.53 display static-user

Function

The **display static-user** command displays static user information.

Format

```
display static-user [ domain-name domain-name | interface interface-type
interface-number | ip-address start-ip-address [ end-ip-address ] | vpn-instance
vpn-instance-name ] *
```

 NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
domain-name <i>domain-name</i>	Displays static user information in a specified domain.	The value is a string of 1 to 64 case-sensitive characters without spaces, asterisk (*), question mark (?), and double quotation marks ("). The value cannot be - or --.
interface <i>interface-type interface-number</i>	Displays static user information on a specified interface. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-
ip-address <i>start-ip-address [end-ip-address]</i>	Displays static user information in a specified IP address range.	The value is in dotted decimal notation.
vpn-instance <i>vpn-instance-name</i>	Displays static user information in a specified VPN instance.	The value must be an existing VPN instance name.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After a static user is configured, you can run the **display static-user** command to view the static user information.

Example

Display information about all static users configured.

```
<HUAWEI> display static-user
IP-address      Interface      MAC-address    VPN
-----
10.1.1.1        GE0/0/3        -              -
10.1.1.2        GE0/0/3        -              -
10.1.1.3        GE0/0/3        -              -
10.1.1.5        GE0/0/5        0001-0001-0001 -
10.1.1.6        GE0/0/5        0001-0001-0001 -
10.1.1.7        GE0/0/5        0001-0001-0001 -
10.1.1.8        GE0/0/5        0001-0001-0001 -
10.1.1.10       -              0002-0002-0002 -
10.1.1.11       -              0002-0002-0002 -
10.1.1.12       -              0002-0002-0002 -
-----
```

Total item(s) displayed = 10

Table 13-100 Description of the **display static-user** command output

Item	Description
IP-address	IP address of a static user.
Interface	Interface connected to a static user.
MAC-address	MAC address of a static user.
VPN	VPN instance to which a static user belongs.
Total item(s) number= m , displayed number= n	The total number of entries is m and the number of displayed entries is n .

Related Topics

[13.5.147 static-user](#)

[13.5.149 static-user username format-include](#)

[13.5.148 static-user password](#)

13.5.54 display url-template

Function

The **display url-template** command displays information about URL templates.

Format

```
display url-template { all | name template-name }
```

Parameters

Parameter	Description	Value
all	Displays information about all configured URL templates.	-
name <i>template-name</i>	Displays information about the URL template with a specified name.	The value is a string of 1 to 31 case-sensitive characters. It cannot contain spaces or the following symbols: / \ : * ? " < > @ ' %. The value cannot be - or --.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After a URL template is configured, run the **display url-template** command to view information about the URL template.

Example

Display information about all configured URL templates.

```
<HUAWEI> display url-template all
```

```
-----
Name                URL   Start Assignment Isolate
Number Mark  Mark   Mark
-----
huawei               0    ?    =    &
huawei2              0    ?    =    &
huawei3              0    ?    =    &
-----
Total 3
```

Display information about the URL template **huawei**.

```
<HUAWEI> display url-template name huawei
```

```
Name : huawei
URL :
  1. http://10.1.1.1
Start mark   : !
Assignment mark : j
Isolate mark  : =
User MAC     :
Redirect URL  :
User IP address :
Sysname     :
```

```
Delimiter      : %
Format         : normal
Login URL Key  : logiurl
Login URL      : http:\\huawei.com
```

Table 13-101 Description of the **display url-template** command output

Item	Description
Name	Name of a URL template.
URL	URL of the Portal server. For details, see 13.5.151 url (URL template view) .
Start mark	Start character in the URL address. For details, see 13.5.102 parameter .
Assignment mark	Assignment character in the URL address. For details, see 13.5.102 parameter .
Isolate mark	Delimiter between URL addresses. For details, see 13.5.102 parameter .
User MAC	MAC address of a user. For details, see 13.5.152 url-parameter .
Redirect URL	URL in the original user packet. For details, see 13.5.152 url-parameter .
User IP address	User IP address. For details, see 13.5.152 url-parameter .
Sysname	Device name. For details, see 13.5.152 url-parameter .
Delimiter	Delimiter between MAC addresses in URL. For details, see 13.5.153 url-parameter mac-address format .
Format	Format MAC addresses in URL. For details, see 13.5.153 url-parameter mac-address format .
Login URL Key	Identification keyword for the login URL sent to the Portal server during redirection. For details, see 13.5.152 url-parameter .
Login URL	Device login URL. For details, see 13.5.152 url-parameter .

13.5.55 display user-group

Function

The **display user-group** command displays the configuration of a user group.

Format

display user-group [*group-name*]

Parameters

Parameter	Description	Value
<i>group-name</i>	Displays the configuration of a specified user group. The configurations of all user groups are displayed if this parameter is not specified.	The value is a string of 1 to 64 case-sensitive characters without spaces.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display user-group** command to obtain the user group configuration and locate faults according to the command output.

Example

Display the configuration of all user groups.

```
<HUAWEI> display user-group
-----
ID   Group name           Rule-num  User-num  Status
-----
0   abc                   0         0         disabled
-----
Total 1
```

NOTE

When the length of **Group name** exceeds 14 characters, the name is displayed in abridged mode.

Display the configuration about the user group **test1**.

```
<HUAWEI> display user-group abc
User group ID       : 0
Group name          : abc
ACL ID              :
ACL rule number     : 0
User-num            : 0
VLAN                :
Remark dscp         :
Remark 8021p        :
Status              : disabled
```

Table 13-102 Description of the **display user-group** command output

Item	Description
ID	ID of the user group.
Rule-num	Number of ACL rules.
User group ID	ID of the user group.
Group name	Name of the user group.
ACL ID	ID of the ACL bound to the user group. To set the ACL ID, run the 13.5.6 acl-id (user group view) command.
ACL rule number	Number of ACL rules.
User-num	Number of online users bound to the user group.
VLAN	VLAN of the user group. To set the VLAN, run the 13.5.159 user-vlan (user group view) command.
Remark dscp	Priorities for processing IP packets. To set the priorities, run the 13.5.135 remark command.
Remark 8021p	Priorities for processing Ethernet Layer 2 packets. To set the priorities, run the 13.5.135 remark command.
Status	Status of the user group. <ul style="list-style-type: none"> disabled: The user group is disabled. enabled: The user group is enabled.

Related Topics

[13.5.6 acl-id \(user group view\)](#)

[13.5.156 user-group](#)

[13.5.157 user-group enable](#)

13.5.56 display web-auth-server configuration

Function

The **display web-auth-server configuration** command displays the Portal server configuration.

Format

display web-auth-server configuration

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

After the Portal server template is configured, the **display web-auth-server configuration** displays the Portal server configuration.

Example

Display the Portal server configuration.

```
<HUAWEI> display web-auth-server configuration
Listening port      : 2000
Portal              : version 1, version 2
Include reply message : enabled

-----

Enabled protocol    : https
Listening port      : 8443
SSL policy          : default_policy

-----

Web-auth-server Name : huawei
IP-address           :
Shared-key           :
Source-IP            : -
Port / PortFlag      : 50100 / NO
URL                  : https://192.168.2.10:8443/webauth
URL Template         :
URL Template ParaName:
URL Template IVName  :
URL Template Key     :
Redirection          : Enable
Sync                 : Disable
Sync Seconds         : 300
Sync Max-times       : 3
Detect               : Disable
Detect Seconds       : 60
Detect Max-times     : 3
Detect Critical-num  : 0
Detect Action        :
VPN Instance         :
Bound Vlanif         :
Bound Interface      :

Protocol            : http
Http Get-method     : disable
Password Encrypt    : none
```

```

Cmd ParseKey      : cmd
Username ParseKey : username
Password ParseKey : password
MAC Address ParseKey : macaddress
IP Address ParseKey : ipaddress
Initial URL ParseKey : initurl
Login Cmd         : login
Logout Cmd        : logout
Login Success
  Reply Type      : redirect initial URL
  Redirect URL    :
  Message         : LoginSuccess!
Login Fail
  Reply Type      : redirect login URL
  Redirect URL    :
  Message         : LoginFail!
Logout Success
  Reply Type      : message
  Redirect URL    :
  Message         : LogoutSuccess!
Logout Fail
  Reply Type      : message
  Redirect URL    :
  Message         : LogoutFail!
    
```

 1 Web authentication server(s) in total

Table 13-103 Description of the **display web-auth-server configuration** command output

Item	Description
Listening port	Listening port for Portal protocol packets. To configure a listening port, run the 13.5.165 web-auth-server listening-port command.
Portal	Portal protocol version. <ul style="list-style-type: none"> version 1, version 2: The device supports both the versions V1.0 and V2.0. version 2: The device supports the versions V2.0. To configure the Portal protocol version, run the 13.5.163 web-auth-server version command.
Include reply message	Whether the packets sent from the device to the Portal server contain authentication responses. <ul style="list-style-type: none"> enabled disabled To enable the device to transparently transmit authentication responses of users sent by the authentication server to the Portal server, run the 13.5.166 web-auth-server reply-message command.

Item	Description
Enabled protocol	<p>Enabled HTTP or HTTPS protocol.</p> <ul style="list-style-type: none"> • http • https <p>To enable the HTTP or HTTPS protocol, run the 13.5.133 portal web-authen-server command.</p>
Listening port	<p>HTTP or HTTPS port number.</p> <p>To configure the HTTP or HTTPS port number, run the 13.5.133 portal web-authen-server command.</p>
SSL policy	<p>SSL policy referenced by the HTTPS protocol.</p> <p>To configure the SSL policy referenced by the HTTPS protocol, run the 13.5.133 portal web-authen-server command.</p>
Web-auth-server Name	<p>Name of the Portal server template.</p> <p>To configure the Portal server template name, run the 13.5.167 web-auth-server (system view) command.</p>
IP-address	<p>IP address of the Portal server.</p> <p>To configure the IP address of the Portal server, run the 13.5.141 server-ip (Portal server template view) command.</p>
Shared-key	<p>Shared key of the Portal server.</p> <p>To configure the shared key of the Portal server, run the 13.5.142 shared-key (Portal server template view) command.</p>
Source-IP	<p>IP address used for communication with the Portal server.</p> <p>To configure the IP address used for communication with the Portal server, run the 13.5.146 source-ip (Portal server template view) command.</p>
Port / PortFlag	<ul style="list-style-type: none"> • Port: indicates the port number of the Portal server. • PortFlag: indicates whether packets are always sent through this port. <p>To configure the port number of the Portal server, run the 13.5.104 port (Portal server template view) command.</p>

Item	Description
URL	<p>URL of the Portal server.</p> <p>To configure the URL of the Portal server, run the 13.5.150 url (Portal server template view) command.</p>
URL Template	<p>URL template bound to the Portal server template.</p> <p>To configure the URL template, run the 13.5.154 url-template (Portal server template view) command.</p>
Redirection	<p>Redirection status of Portal authentication.</p> <ul style="list-style-type: none"> ● Disable: Redirection of Portal authentication is disabled. ● Enable: Redirection of Portal authentication is enabled. <p>To configure redirection of Portal authentication, run the 13.5.168 web-redirection disable (Portal server template view) command.</p>
Sync	<p>User information synchronization.</p> <ul style="list-style-type: none"> ● Disable ● Enable <p>To enable user information synchronization, run the 13.5.158 user-sync command.</p>
Sync Seconds	<p>User information synchronization interval.</p> <p>To set the user information synchronization interval, run the 13.5.158 user-sync command.</p>
Sync max-times	<p>Maximum number of times that user information synchronization fails.</p> <p>To set the maximum number of times that user information synchronization fails, run the 13.5.158 user-sync command.</p>
Detect	<p>Portal server detection and keepalive functions.</p> <ul style="list-style-type: none"> ● Disable ● Enable <p>To configure Portal server detection and keepalive functions, run the 13.5.140 server-detect command.</p>

Item	Description
Detect Seconds	<p>Detection interval of the Portal server.</p> <p>To set the detection interval of the Portal server, run the 13.5.140 server-detect command.</p>
Detect max-times	<p>Maximum number of detection failures.</p> <p>To set the maximum number of detection failures, run the 13.5.140 server-detect command.</p>
Detect Critical-num	<p>Minimum number of Portal servers in Up state. If the number of running Portal servers is less than the minimum, enable the survival function in the corresponding Portal server template view.</p> <p>To configure this function, run the 13.5.140 server-detect command.</p>
Detect Action	<p>Action taken after the number of detection failures exceeds the maximum.</p> <ul style="list-style-type: none"> ● log: The device sends logs after the number of detection failures exceeds the maximum. ● trap: The device sends traps after the number of detection failures exceeds the maximum. ● permit-all: Portal authentication on the interface is disabled after the number of detection failures exceeds the maximum. <p>To configure an action taken after the number of detection failures exceeds the maximum, run the 13.5.140 server-detect command.</p>
Bound Vlanif	<p>VLANIF interface to which the Portal server template is bound.</p> <p>To bind the Portal server template to a VLANIF interface, run the 13.5.164 web-auth-server (interface view).</p>
VPN instance	<p>VPN instance used for Portal authentication.</p> <p>To configure a VPN instance, run the 13.5.162 vpn-instance (Portal server template view) command.</p>

Item	Description
Bound Interface	<p>Ethernet interface or Eth-Trunk to which the Portal server template is bound.</p> <p>To bind the Portal server template to an Ethernet interface or Eth-Trunk, run the 13.5.164 web-auth-server (interface view) command.</p>
Http Get-method	<p>Whether users submit user name and password information to the device in GET mode:</p> <ul style="list-style-type: none"> • disable: GET mode is not used. • enable: GET mode is used. <p>To configure the GET mode, run the 13.5.86 http get-method enable command.</p>
Protocol	<p>Protocol used in Portal authentication.</p> <ul style="list-style-type: none"> • Portal • http <p>To configure the protocol used in Portal authentication, run the 13.5.134 protocol (Portal server template view) command.</p>
Password Encrypt	<p>Password encoding mode:</p> <ul style="list-style-type: none"> • none: The password is not encoded. • uam: The password is encoded using ASCII characters. <p>To configure the password encoding mode, run the 13.5.134 protocol (Portal server template view) command.</p>
Cmd ParseKey	<p>Command identification keyword.</p> <p>To configure the command identification keyword, run the 13.5.87 http-method post command.</p>
Username ParseKey	<p>User name identification keyword.</p> <p>To configure the user name identification keyword, run the 13.5.87 http-method post command.</p>
Password ParseKey	<p>User password identification keyword.</p> <p>To configure the user password identification keyword, run the 13.5.87 http-method post command.</p>

Item	Description
MAC Address ParseKey	User MAC address identification keyword. To configure the user MAC address identification keyword, run the 13.5.87 http-method post command.
IP Address ParseKey	User IP address identification keyword. To configure the user IP address identification keyword, run the 13.5.87 http-method post command.
Initial URL ParseKey	User initial login URL identification keyword. To configure the user initial login URL identification keyword, run the 13.5.87 http-method post command.
Login Cmd	User login identification keyword. To configure the user login identification keyword, run the 13.5.87 http-method post command.
Logout Cmd	User logout identification keyword. To configure the user logout identification keyword, run the 13.5.87 http-method post command.
Login Success	User login success.
Reply Type	Redirection response type. <ul style="list-style-type: none"> ● redirect initial URL: A user is redirected to the initial login URL after successful login. ● redirect login URL: A user is redirected to the login URL after a login failure. ● message: specifies the displayed message. ● redirect URL: A user is redirected to a specified URL. To configure the redirection response type, run the 13.5.87 http-method post command.
Redirect URL	Redirection URL. To configure the redirection URL, run the 13.5.87 http-method post command.
Message	Displayed message. To configure the displayed message, run the 13.5.87 http-method post command.

Item	Description
Login Fail	User login failure.
Logout Success	User logout success.
Logout Fail	User logout failure.

13.5.57 device-sensor dhcp option

Function

The **device-sensor dhcp option** command enables the DHCP-based terminal type awareness function.

The **undo device-sensor dhcp option** command disables the DHCP-based terminal type awareness function.

By default, the DHCP-based terminal type awareness function is disabled.

Format

device-sensor dhcp option *option-code* <1-6>

undo device-sensor dhcp option *option-code* <1-6>

Parameters

Parameter	Description	Value
<i>option-code</i>	Specifies the DHCP option field that the device needs to resolve. The option fields in a DHCP packet carry the control information and parameters, for example, terminal type.	The value is an integer that ranges from 1 to 254.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A device usually connects to many types of terminals. You may need to assign different network access rights or packet processing priorities to the terminals of

different types. For example, the voice devices, such as IP phones, should be assigned a high packet processing priority because voice signals require low delay and jitter.

After the DHCP-based terminal type awareness function is enabled, the device can resolve the option fields that carry terminal type information in the received DHCP Request packets. The device then sends the option information to the RADIUS server through RADIUS accounting packets. Through the option information, the RADIUS server knows the terminal types and controls the network access rights and packet processing priorities of the terminals.

Precautions

- The command takes effect only when the authentication or accounting mode in the AAA scheme is RADIUS.
- To make this command take effect, you must run the [14.8.20 dhcp snooping enable](#) command on the interfaces or in VLANs.

Example

```
# Set the option fields to be resolved by the device to option 60.  
<HUAWEI> system-view  
[HUAWEI] device-sensor dhcp option 60
```

Related Topics

[14.8.20 dhcp snooping enable](#)

13.5.58 device-sensor lldp tlv

Function

The **device-sensor lldp tlv** command enables the LLDP-based terminal type awareness function.

The **undo device-sensor lldp tlv** command disables the LLDP-based terminal type awareness function.

By default, the LLDP-based terminal type awareness function is disabled.

Format

device-sensor lldp tlv *tlv-type* &<1-4>

undo device-sensor lldp tlv

Parameters

Parameter	Description	Value
<i>tlv-type</i>	Specifies the LLDP TLV type as the terminal type to be aware of the device.	The value is an integer that can be 1, 2, 5, 6, 7, 8, and 127. The values are as follows: <ul style="list-style-type: none">• 1: Chassis ID TLV, indicating the bridge MAC address of the device• 2: Port ID TLV, indicating the port identifying the LLD PDU sending end• 5: System Name TLV, indicating the device name• 6: System Description TLV, indicating the system description• 7: System Capabilities TLV, indicating the system capabilities• 8: Management Address TLV, indicating the management address• 127: Organization Specific TLV, indicating the user-defined organization information. You can run the lldp tlv-enable med-tlv command on the physical interface for user access to set this parameter.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A device usually connects to many types of terminals. You may need to assign different network access rights or packet processing priorities to the terminals of different types. For example, the voice devices, such as IP phones, should be assigned a high packet processing priority because voice signals require low delay and jitter.

Using the LLDP-based terminal type awareness function, the device parses the required TLV type containing terminal type information from the received LLDP packets. The device then sends the TLV type information to the RADIUS server through a RADIUS accounting packet. Through the TLV type information, the RADIUS server knows the terminal types and controls the network access rights and packet processing priorities of the terminals.

Precautions

- The command takes effect only when the authentication or accounting mode in the AAA scheme is RADIUS.
- The command takes effect only when the LLDP function is enabled on the device and the connected peer device.

Example

```
# Enable the terminal type awareness function based on LLDP TLV type 5.
```

```
<HUAWEI> system-view  
[HUAWEI] device-sensor lldp tlv 5
```

Related Topics

[13.5.57 device-sensor dhcp option](#)

13.5.59 dot1x authentication-method

Function

The **dot1x authentication-method** command sets the authentication mode for 802.1X users.

The **undo dot1x authentication-method** command restores the default authentication mode for 802.1X users.

By default, the global 802.1X user authentication mode is CHAP authentication and the 802.1X user authentication mode on interfaces is the same as the mode globally configured.

Format

```
dot1x authentication-method { chap | pap | eap }
```

```
undo dot1x authentication-method
```

Parameters

Parameter	Description	Value
chap	Indicates the CHAP-based EAP termination authentication mode.	-
pap	Indicates the PAP-based EAP termination authentication mode.	-
eap	Indicates that the EAP relay mode.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

During 802.1X authentication, users exchange authentication information with the device using EAP packets. The device uses two modes to exchange authentication information with the RADIUS server.

- EAP termination: The device directly parses EAP packets, encapsulates user authentication information into a RADIUS packet, and sends the RADIUS packet to the RADIUS server for authentication. In EAP termination authentication mode, the device and RADIUS server exchange information using PAP or CHAP.
 - PAP: The device arranges the MAC address, shared key, and random value in sequence, performs hash processing on them using the MD5 algorithm, and encapsulates the hash result into the User-Password attribute.
 - CHAP: The device arranges the CHAP ID, MAC address, and random value in sequence, performs hash processing on them using the MD5 algorithm, and encapsulates the hash result into the CHAP-Password and CHAP-Challenge attributes.

After the device directly parses EAP packets, user information in the EAP packets is authenticated by a local AAA module, or sent to the RADIUS or HWTACACS server for authentication.

- EAP relay (specified by **eap**): The device encapsulates EAP packets into RADIUS packets and sends the RADIUS packets to the RADIUS server, but does not parse the received EAP packets that include user authentication information. This mechanism is called EAP over Radius (EAPOR).

The EAP relay mechanism requires that the RADIUS server be capable of parsing a lot of EAP packets and carrying out authentication; therefore, if the RADIUS server has high processing capabilities, the EAP relay is used. If the RADIUS server is incapable of parsing a lot of EAP packets and carrying out authentication, EAP termination is recommended, and the device helps the RADIUS server to parse EAP packets.

NOTE

- The authentication mode can be set to EAP relay for 802.1X authentication users only when the RADIUS authentication is used.
- If the 802.1X client uses the MD5 encryption mode, the user authentication mode on the device can be set to EAP or CHAP; if the 802.1X client uses the PEAP authentication mode, the authentication mode on the device can be set to EAP.

Example

```
# Set the authentication mode to EAP for 802.1X users in the device in the system view.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x authentication-method eap
```

Set the authentication mode to EAP for 802.1X users on GE0/0/1.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] dot1x authentication-method eap
```

Related Topics

[13.5.34 display dot1x](#)

13.5.60 dot1x dhcp-trigger

Function

The **dot1x dhcp-trigger** command enables DHCP-triggered 802.1X authentication.

The **undo dot1x dhcp-trigger** command disables DHCP-triggered 802.1X authentication.

By default, DHCP-triggered 802.1X authentication is disabled.

Format

dot1x dhcp-trigger

undo dot1x dhcp-trigger

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After DHCP-triggered 802.1X authentication is enabled using the **dot1x dhcp-trigger** command, the device sends an 802.1X authentication-start packet to the user when receiving a DHCP Request message from the user. When the user receives the 802.1X authentication-start packet from the device, the 802.1X authentication page is displayed on the client device and prompts the user to enter the user name and password for authentication. During 802.1X network deployment, DHCP-triggered 802.1X authentication enables 802.1X users to start 802.1X authentication without dial-up using the client software, which facilitates network deployment.

 NOTE

After receiving the request packet from an 802.1X user, the device starts authenticating the user. If the user is authenticated, the device allocates an IP address to the user through a DHCP server; if the user fails the authentication, the user cannot obtain a dynamic IP address from the DHCP server.

Prerequisites

802.1X authentication has been enabled globally and on an interface using the [13.5.63 dot1x enable](#) command.

Precautions

The **dot1x dhcp-trigger** command can be used only when the client supports DHCP and 802.1X authentication.

Example

```
# Enable DHCP-triggered 802.1X authentication.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x dhcp-trigger
```

Related Topics

[13.5.63 dot1x enable](#)

[13.5.34 display dot1x](#)

13.5.61 dot1x domain

Function

The **dot1x domain** command configures a forcible domain for 802.1X authentication users.

The **undo dot1x domain** command restores the default setting of a forcible domain for 802.1X authentication users.

By default, no forcible domain is configured for 802.1X authentication users.

Format

dot1x domain *domain-name*

undo dot1x domain

Parameters

Parameter	Description	Value
<i>domain-name</i>	Specifies the name of a forcible domain.	The value must be an existing domain name on the device.

Views

Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

During authentication, if the user name entered by a user does not contain a domain name, the user will be authenticated in the default domain; if the user name contains a domain name, the user will be authenticated in the specified domain.

If the user names entered by many users do not contain domain names, excess users are authenticated in the default domain, making the authentication scheme inflexible. If all users on an interface need to use the same AAA scheme when the user names entered by some users contain domain name and those entered by other users do not, the device also cannot meet such requirement. To address this issue, you can configure a forcible domain. Then all users on the interface will be authenticated in the forcible domain no matter whether the user names entered by the users contain domain names.

Prerequisites

A domain has been created using the [13.1.47 domain \(AAA view\)](#) command.

Example

Configure the forcible domain **huawei** for 802.1X authentication users on the interface GE0/0/1.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain huawei
[HUAWEI-aaa-domain-huawei] quit
[HUAWEI-aaa] quit
[HUAWEI] interface gigabitethernet0/0/1
[HUAWEI-GigabitEthernet0/0/1] dot1x domain huawei
```

Related Topics

[13.1.47 domain \(AAA view\)](#)

13.5.62 dot1x eap-notify-packet

Function

The **dot1x eap-notify-packet** command enables the device to send an EAP packet code number to users.

The **undo dot1x eap-notify-packet** command disables the device from sending an EAP packet code number to users.

By default, the device is disabled from sending an EAP packet code number to users.

Format

dot1x eap-notify-packet eap-code *code-number* **data-type** *type-number*

undo dot1x eap-notify-packet [**eap-code** *code-number* **data-type** *type-number*]

Parameters

Parameter	Description	Value
eap-code <i>code-number</i>	Specifies an EAP packet code number sent to users.	The value is an integer that ranges from 5 to 255.
data-type <i>type-number</i>	Specifies the data type in EAP packets sent to users.	The value is an integer that ranges from 1 to 255.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When a non-Huawei device used as the RADIUS server sends RADIUS packets with attribute 61, EAP packet code number 0xa (hexadecimal notation, 10 in decimal notation), and data type 0x19 (hexadecimal notation, 25 in decimal notation) to the device, run the **dot1x eap-notify-packet** command on the device so that the device can send EAP packets with code number 0xa and data type 0x19 to users. If the **dot1x eap-notify-packet** command is not executed, the device does not process EAP packets of this type and users are disconnected.

Precautions

The device can only process EAP packets with code number 10 and data type 25.

Example

Allow the device to send EAP packets with code number 10 and data type 25 to users.

```
<HUAWEI> system-view
[HUAWEI] dot1x eap-notify-packet eap-code 10 data-type 25
```

Related Topics

[13.5.63 dot1x enable](#)

13.5.63 dot1x enable

Function

The **dot1x enable** command enables 802.1X authentication on a device.

The **undo dot1x enable** command disables 802.1X authentication on a device.

By default, 802.1X authentication is disabled on a device.

Format

In the system view:

```
dot1x enable [ interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10> ]
```

```
undo dot1x enable [ interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10> ]
```

In the interface view:

```
dot1x enable
```

```
undo dot1x enable
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Enables 802.1X authentication on the specified interface of the device. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number. Global 802.1X authentication is enabled if this parameter is not specified.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The IEEE 802.1X standard (802.1X for short) is a port-based network access control protocol. You can run the **dot1x enable** command to enable 802.1X authentication globally and on an interface.

To make the 802.1X configuration effective on an interface, enable the global 802.1X authentication function and perform either of the following operations:

- Run the **dot1x enable** command in the interface view.
- Run the **dot1x enable interface** { *interface-type interface-number1* [*to interface-number2*] } &<1-10> command in the system view.

Precautions

- All users have been disconnected before the **undo** operation is executed.
- After the static MAC address entry is configured using the **mac-address static** *mac-address interface-type interface-number vlan vlan-id* command, the user corresponding to the entry cannot pass 802.1X authentication.
- If 802.1X authentication is enabled on an interface, the following commands cannot be used on the same interface.

Command	Function
mac-limit	Sets the maximum number of MAC addresses that can be learned by an interface.
mac-address learning disable	Disables MAC address learning on an interface.
port link-type dot1q-tunnel	Sets the link type of an interface to QinQ.
port vlan-mapping vlan map-vlan port vlan-mapping vlan inner-vlan	Configures VLAN mapping on an interface.
port vlan-stacking	Configures selective QinQ.
port-security enable	Enables interface security.
mac-vlan enable	Enables MAC address-based VLAN assignment on an interface.
ip-subnet-vlan enable	Enables IP subnet-based VLAN assignment on an interface.
user-bind ip sticky-mac	Enables the device to generate snooping MAC entries.

Example

Enable 802.1X authentication on GE0/0/1 in the system view.

```
<HUAWEI> system-view
[HUAWEI] dot1x enable
[HUAWEI] dot1x enable interface gigabitethernet 0/0/1
```

Enable 802.1X authentication on GE0/0/1 in the interface view.

```
<HUAWEI> system-view
[HUAWEI] dot1x enable
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] dot1x enable
```

Related Topics

[13.5.34 display dot1x](#)

13.5.64 dot1x free-ip

Function

The **dot1x free-ip** command configures a free IP subnet.

The **undo dot1x free-ip** command deletes the configured free IP subnet.

By default, no free IP subnet is configured.

Format

dot1x free-ip *ip-address* { *mask-length* | *mask-address* }

undo dot1x free-ip { *ip-address* { *mask-length* | *mask-address* } | **all** }

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies a free IP subnet.	The value is in dotted decimal notation.
<i>mask-length</i>	Specifies the mask length of an IP address.	The value is an integer that ranges from 1 to 32.
<i>mask-address</i>	Specifies the mask of the IP address.	The value is in dotted decimal notation.
all	Deletes all free IP subnets.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

802.1X users can access networks only after being authenticated. You can configure a free IP subnet, so that users can access network resources in the free IP subnet before being authenticated.

Precautions

- 802.1X authentication has been enabled globally and on an interface using the [13.5.63 dot1x enable](#) command.
- To ensure that pre-connection users can be aged out normally, you need to run the [13.5.80 dot1x timer free-ip-timeout](#) command to set the aging time of authentication-free user entries.
- After the free-ip function is configured, the guest VLAN, critical VLAN, and restrict VLAN are no longer effective.
- The free IP subnet takes effect only when the interface authorization state is auto.
- If a user who does not pass 802.1X authentication wants to obtain an IP address dynamically through the DHCP server, the network segment of the DHCP server needs to be configured to a free IP subnet so that the user can access the DHCP server.
- After 802.1X users go offline, they are not allowed to access network resources on free IP subnets within a specified period to prevent malicious attacks.
- After users succeed in 802.1X-based fast deployment, they can only access resources in the IP free subnets and some resources on the device.

Example

Configure 192.168.1.0/24 as a free IP subnet that users can access before they pass 802.1X authentication.

```
<HUAWEI> system-view  
[HUAWEI] dot1x free-ip 192.168.1.0 24
```

Related Topics

[13.5.84 dot1x url](#)

[13.5.34 display dot1x](#)

13.5.65 dot1x handshake

Function

The **dot1x handshake** command enables the device to send handshake packets to online 802.1X users.

The **undo dot1x handshake** command disables the device from sending handshake packets to online 802.1X users.

By default, the device handshake function is disabled for online 802.1X users.

Format

dot1x handshake
undo dot1x handshake

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

To check whether an 802.1X user is online in real time, you can run the **dot1x handshake** command to enable the device to send handshake packets to the 802.1X user. The device sends handshake request packets to the user. If the user sends a response packet within the handshake interval (set using the [13.5.80 dot1x timer](#) command), the device considers that the user is online. If the user does not send any response packet within the interval, the device considers that the user is offline.

NOTE

If a client does not support the handshake function, the device will not receive handshake response packets within the handshake interval and considers that the user is offline. Therefore, disable the device from sending handshake packets to an online 802.1X user when the user's client does not support the handshake function.

After the [13.5.80 dot1x timer arp-detect](#) *arp-detect-value* command is executed to configure ARP detection, the handshake function between the device and online 802.1X users does not take effect.

Example

```
# Enable the device to send handshake packets to online 802.1X users.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x handshake
```

Related Topics

[13.5.63 dot1x enable](#)
[13.5.34 display dot1x](#)

13.5.66 dot1x handshake packet-type

Function

The **dot1x handshake packet-type** command sets the type of 802.1X authentication handshake packets.

The **undo dot1x handshake packet-type** command restores the default type of 802.1X authentication handshake packets.

By default, the type of 802.1X authentication handshake packets is request-identity.

Format

dot1x handshake packet-type { **request-identity** | **srp-sha1-part2** }

undo dot1x handshake packet-type

Parameters

Parameter	Description	Value
request-identity	Indicates that the type of 802.1X authentication handshake packets is request-identity .	-
srp-sha1-part2	Indicates that the type of 802.1X authentication handshake packets is srp-sha1-part2 .	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

During 802.1X authentication, different vendors' devices support different handshake packet types. By default, the device uses 802.1X authentication handshake packets of the **request-identity** type. If a device connected to the non-Huawei device uses the 802.1X authentication handshake packets of the **srp-sha1-part2** type, run the **dot1x handshake packet-type** command to set the type of 802.1X authentication handshake packets to **srp-sha1-part2**.

NOTE

The **dot1x handshake packet-type** command takes effect only for users that log in after the command is run.

Example

Set the type of 802.1X authentication handshake packets to **srp-sha1-part2**.

```
<HUAWEI> system-view  
[HUAWEI] dot1x handshake packet-type srp-sha1-part2
```

Related Topics

[13.5.65 dot1x handshake](#)

13.5.67 dot1x mac-bypass

Function

The **dot1x mac-bypass** command enables MAC address bypass authentication on an interface.

The **undo dot1x mac-bypass** command disables MAC address bypass authentication on an interface.

By default, MAC address bypass authentication is disabled on an interface.

Format

In the system view:

```
dot1x mac-bypass { interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10> }
```

```
undo dot1x mac-bypass { interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10> }
```

In the interface view:

```
dot1x mac-bypass
```

```
undo dot1x mac-bypass
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Enables MAC address bypass authentication on the specified interface. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

You can enable MAC address bypass authentication for terminals (for example, printers) on which the 802.1X client software cannot be installed or used.

After MAC address bypass authentication is enabled on the interface using the **dot1x mac-bypass** command, the device first performs 802.1X authentication on users. If the user name request times out, the device starts the MAC address authentication process for the users. When 802.1X authentication fails, the device does not start the MAC address authentication process.

NOTE

Running the **dot1x mac-bypass** command also enables 802.1X authentication on an interface, and running the **undo dot1x mac-bypass** command also disables 802.1X authentication on an interface. When you run the **dot1x mac-bypass** command on an interface that has been enabled with 802.1X authentication, the authentication mode on the interface changes to MAC address bypass authentication.

Prerequisites

802.1X authentication has been enabled globally using the [13.5.63 dot1x enable](#) command.

Example

Enable MAC address bypass authentication on GE0/0/1 in the system view.

```
<HUAWEI> system-view  
[HUAWEI] dot1x mac-bypass interface gigabitethernet 0/0/1
```

Enable MAC address bypass authentication on GE0/0/1 in the interface view.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] dot1x mac-bypass
```

Related Topics

[13.5.63 dot1x enable](#)

[13.5.34 display dot1x](#)

13.5.68 dot1x mac-bypass access-port

Function

The **dot1x mac-bypass access-port** command enables MAC address bypass authentication on all downlink interfaces of the device.

The **undo dot1x mac-bypass access-port** command disables MAC address bypass authentication on all downlink interfaces of the device.

By default, MAC address bypass authentication is disabled on all downlink interfaces of the device.

Format

```
dot1x mac-bypass access-port all
undo dot1x mac-bypass access-port all
```

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

You can enable MAC address bypass authentication for terminals (such as printers) on which the 802.1X client software cannot be installed or used.

After MAC address bypass authentication is enabled, the device performs 802.1X authentication on a user. Once 802.1X authentication fails, the device sends the user's MAC address as the user name and password to the authentication server.

NOTE

MAC address bypass authentication involves 802.1X authentication. That is, the **dot1x mac-bypass access-port all** command also enables 802.1X authentication on the interfaces; the **undo dot1x mac-bypass access-port all** command also disables 802.1X authentication on the interfaces. If 802.1X authentication has been enabled on the interfaces, the authentication mode on the interfaces is changed to MAC address bypass authentication after you run the **dot1x mac-bypass access-port all** command.

Prerequisites

802.1X authentication has been enabled globally and on the interfaces using the [13.5.63 dot1x enable](#) command.

Example

In the system view, enable MAC address bypass authentication on all downlink interfaces of the device.

```
<HUAWEI> system-view
[HUAWEI] dot1x mac-bypass access-port all
```

13.5.69 dot1x mac-bypass mac-auth-first

Function

The **dot1x mac-bypass mac-auth-first** command enables the device to perform MAC address authentication first during MAC address bypass authentication.

The **undo dot1x mac-bypass mac-auth-first** command disables the device from performing MAC address authentication first during MAC address bypass authentication.

By default, the MAC address authentication is not performed first during MAC address bypass authentication.

Format

In the system view:

dot1x mac-bypass mac-auth-first interface { *interface-type interface-number1* [*to interface-number2*] } &<1-10>

undo dot1x mac-bypass mac-auth-first interface { *interface-type interface-number1* [*to interface-number2*] } &<1-10>

In the interface view:

dot1x mac-bypass mac-auth-first

undo dot1x mac-bypass mac-auth-first

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [<i>to interface-number2</i>] }	<p>Enables the device to perform MAC address authentication first on a specified interface during MAC address bypass authentication.</p> <ul style="list-style-type: none"> • <i>interface-type</i> specifies the interface type. • <i>interface-number</i> specifies the interface number. 	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When both the clients that do not support 802.1X authentication (such as printers) and the clients that support 802.1X authentication (such as PCs) are connected to the interface enabled with MAC address bypass authentication, you can run the **dot1x mac-bypass mac-auth-first** command to enable the device to perform MAC address authentication first during MAC address bypass authentication. After that, the device first starts the MAC address authentication process for users, and triggers 802.1X authentication only if MAC address authentication fails.

Prerequisites

802.1X authentication has been enabled globally and on an interface using the [13.5.63 dot1x enable](#) command.

Follow-up Procedure

Run the [dot1x mac-bypass](#) command to enable MAC address bypass authentication on the interface.

Example

Enable the device to first perform MAC address authentication on GE0/0/1 during MAC address bypass authentication in the system view.

```
<HUAWEI> system-view  
[HUAWEI] dot1x mac-bypass mac-auth-first interface gigabitethernet 0/0/1
```

Enable the device to first perform MAC address authentication on GE0/0/1 during MAC address bypass authentication in the interface view.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] dot1x mac-bypass mac-auth-first
```

Related Topics

[13.5.63 dot1x enable](#)

[13.5.67 dot1x mac-bypass](#)

13.5.70 dot1x max-user

Function

The **dot1x max-user** command sets the maximum number of 802.1X authentication users allowed on an interface.

The **undo dot1x max-user** command restores the default maximum number of 802.1X authentication users allowed on an interface.

By default, the number of 802.1X authentication users is the maximum number of 802.1X authentication users supported by the device.

Format

In the system view:

```
dot1x max-user user-number interface { interface-type interface-number1 [ to  
interface-number2 ] } &<1-10>
```


undo dot1x max-user [*user-number*] **interface** { *interface-type interface-number1* [**to** *interface-number2*] } &<1-10>

In the interface view:

dot1x max-user *user-number*

undo dot1x max-user [*user-number*]

Parameters

Parameter	Description	Value
<i>user-number</i>	Specifies the maximum number of 802.1X authentication users on an interface.	The value is an integer that varies depending on the product model.
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To limit the maximum number of 802.1X authentication users allowed on an interface, run the **dot1x max-user** command.

Prerequisites

The 802.1X authentication function has been enabled globally and on an interface using the [13.5.63 dot1x enable](#) command.

Precautions

If the user access mode on an interface is interface-based (configured using the [dot1x port-method](#) command), the maximum number of 802.1X authentication users allowed on the interface is 1. Before running the **dot1x max-user** command to set the maximum number of 802.1X authentication users allowed on the

interface, run the **undo dot1x port-method** command to restore the user access mode on the interface to MAC address-based.

Example

In the system view, set the maximum number of 802.1X authentication users allowed on GE0/0/1 to 7.

```
<HUAWEI> system-view  
[HUAWEI] dot1x max-user 7 interface gigabitethernet 0/0/1
```

In the interface view, set the maximum number of 802.1X authentication users allowed on GE0/0/1 to 7.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] dot1x max-user 7
```

Related Topics

[13.5.63 dot1x enable](#)

[13.5.74 dot1x port-method](#)

[13.5.34 display dot1x](#)

13.5.71 dot1x mc-trigger

Function

The **dot1x mc-trigger** enables multicast-triggered 802.1X authentication.

The **undo dot1x mc-trigger** disables multicast-triggered 802.1X authentication.

By default, multicast-triggered 802.1X authentication is enabled.

Format

dot1x mc-trigger

undo dot1x mc-trigger

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If a client (for example, the built-in 802.1X client of the Windows operating system) cannot send an EAPOL-Start packet to perform 802.1X authentication, you can enable multicast-triggered 802.1X authentication. After that, the device multicasts an Identity EAP-Request frame to the client to trigger authentication.

Prerequisites

802.1X authentication has been enabled globally and on the interface using the **dot1x enable** command.

Example

```
# Enable multicast-triggered 802.1X authentication.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x mc-trigger
```

Related Topics

[13.5.63 dot1x enable](#)

13.5.72 dot1x mc-trigger port-up-send enable

Function

The **dot1x mc-trigger port-up-send enable** command enables the function of triggering 802.1X authentication through multicast packets immediately after an interface goes Up.

The **undo dot1x mc-trigger port-up-send enable** command disables the function of triggering 802.1X authentication through multicast packets immediately after an interface goes Up.

By default, the function of triggering 802.1X authentication through multicast packets immediately after an interface goes Up is disabled.

Format

dot1x mc-trigger port-up-send enable

undo dot1x mc-trigger port-up-send enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

By default, the device periodically multicasts EAP-Request/Identity packets to clients so that the clients are triggered to send EAPOL-Start packets for 802.1X authentication. If the device interface connecting to a client changes from Down to Up, the client needs to send EAPOL-Start packets again for 802.1X authentication, which takes a long time. You can run the **dot1x mc-trigger port-up-send enable** command on the device to enable the device interface to multicast EAP-Request/Identity packets to the client to trigger 802.1X authentication immediately after the interface goes Up. This configuration shortens the re-authentication time.

Precautions

When the access control mode on the device interface is based on the MAC address, the **dot1x mc-trigger port-up-send enable** command does not take effect.

Example

Enable the function of triggering 802.1X authentication through multicast packets immediately after an interface goes Up.

```
<HUAWEI> system-view  
[HUAWEI] dot1x mc-trigger port-up-send enable
```

13.5.73 dot1x port-control

Function

The **dot1x port-control** command sets the authorization state of an interface.

The **undo dot1x port-control** command restores the default authorization state of an interface.

By default, the authorization state of an interface is **auto**.

Format

In the system view:

```
dot1x port-control { auto | authorized-force | unauthorized-force } interface  
{ interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

```
undo dot1x port-control interface { interface-type interface-number1 [ to  
interface-number2 ] } &<1-10>
```

In the interface view:

```
dot1x port-control { auto | authorized-force | unauthorized-force }
```

```
undo dot1x port-control
```

Parameters

Parameter	Description	Value
auto	Indicates the auto identification mode. In this mode, an interface is initially in Unauthorized state and only allows users to send and receive EAPOL packets. Users cannot access network resources. After the users are authenticated, the interface becomes authorized and allows the users to access network resources.	-
authorized-force	Indicates the forcible authorization mode. In this mode, the interface is always in Authorized state, does not handle EAPOL packets, and allows users to access network resources without authentication or authorization. Indicates the forcible unauthorized mode. In this mode, the interface is always in Unauthorized state, does not handle EAPOL packets, and prohibits users from accessing network resources.	-

Parameter	Description	Value
unauthorized-force	Indicates the forcible authorization mode. In this mode, the interface is always in Authorized state, does not handle EAPOL packets, and allows users to access network resources without authentication or authorization. Indicates the forcible unauthorized mode. In this mode, the interface is always in Unauthorized state, does not handle EAPOL packets, and prohibits users from accessing network resources.	-
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The **auto** mode is recommended. Only authenticated users can access network resources. To trust all users on an interface without authentication, configure the **authorized-force** mode. To disable access rights of all users on an interface to ensure security, configure the **unauthorized-force** mode.

Prerequisites

802.1X authentication has been enabled globally and on an interface using the [13.5.63 dot1x enable](#) command.

Precautions

When there are online 802.1X users on an interface, the **dot1x port-control** command must not be run; otherwise, the system displays alarm information.

It is recommended that you set the authorization state of an interface in the early stage of network deployment. When the network is running properly, run the [cut access-user](#) command to disconnect all users from the interface before changing the authorization state.

Example

Set the authorization state of GE0/0/1 to **unauthorized-force** in the system view.

```
<HUAWEI> system-view  
[HUAWEI] dot1x port-control unauthorized-force interface gigabitethernet 0/0/1
```

Set the authorization state of GE0/0/1 to **unauthorized-force** in the interface view.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] dot1x port-control unauthorized-force
```

Related Topics

[13.5.63 dot1x enable](#)

[13.5.34 display dot1x](#)

13.5.74 dot1x port-method

Function

The **dot1x port-method** command sets the 802.1X access control method of an interface.

The **undo dot1x port-method** command sets the default 802.1X access control method of an interface.

By default, 802.1X access control on an interface is based on MAC addresses.

Format

In the system view:

```
dot1x port-method { mac | port } interface { interface-type interface-number1  
[ to interface-number2 ] } &<1-10>
```

```
undo dot1x port-method interface { interface-type interface-number1 [ to  
interface-number2 ] } &<1-10>
```

In the interface view:

```
dot1x port-method { mac | port }
```

undo dot1x port-method

Parameters

Parameter	Description	Value
mac	Indicates that users are authenticated based on their MAC addresses.	-
port	Indicates that users are authenticated based on their access interfaces.	-
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Indicates the interface type and number. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

802.1X access control can be based on MAC addresses or interfaces.

- When the **mac** method is used, all 802.1X users on an interface are authenticated one by one. If a user goes offline, other users on this interface are not affected. The **mac** method is applicable to individual users.
- When the **port** method is used, all the other 802.1X users on an interface can use network resources as long as one user is authenticated successfully. When the authenticated user goes offline, other users cannot use network resources. The **port** method is applicable to group users.

Prerequisites

802.1X authentication has been enabled globally and on an interface using the [13.5.63 dot1x enable](#) command.

Precautions

- When there are online 802.1X users on an interface, do not run the **dot1x port-method** command to change the access control method on the interface.
- If the access control method of an interface is set to **port**, only one 802.1X users can access the interface. After you run the **undo dot1x port-method** command, MAC address-based access control is enabled, but still only one user can access the interface. You can run the [13.5.70 dot1x max-user](#) command to increase the maximum number of 802.1X users as required.

Example

Set the 802.1X access control method on GE0/0/1 in the system view to **port**.

```
<HUAWEI> system-view  
[HUAWEI] dot1x port-method port interface gigabitethernet 0/0/1
```

Set the 802.1X access control method on GE0/0/1 in the interface view to **port**.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] dot1x port-method port
```

Related Topics

[13.5.63 dot1x enable](#)

[13.5.70 dot1x max-user](#)

[13.5.34 display dot1x](#)

13.5.75 dot1x quiet-period

Function

The **dot1x quiet-period** command enables the quiet timer function.

The **undo dot1x quiet-period** command disables the quiet timer function.

By default, the quiet timer function is enabled.

Format

dot1x quiet-period

undo dot1x quiet-period

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the quiet timer function is enabled, if the number of authentication failures of an 802.1X user exceeds a specified value (set using the [13.5.76 dot1x quiet-times](#) command) within 60 seconds, the user enters a quiet period. During the quiet period, the device discards the 802.1X authentication request packets from the user. This prevents the impact on the system due to frequent user authentication.

The value of the quiet timer is set using the [13.5.80 dot1x timer](#) command. When the quiet timer expires, the device re-authenticates the user.

Precautions

To make the configuration take effect, run the [13.5.63 dot1x enable](#) command twice to enable global and interface-based 802.1X user authentication.

Example

```
# Enable the quiet timer.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x quiet-period
```

Related Topics

[13.5.76 dot1x quiet-times](#)

13.5.76 dot1x quiet-times

Function

The **dot1x quiet-times** command sets the maximum number of authentication failures within 60 seconds before an 802.1X user enters the quiet state.

The **undo dot1x quiet-times** command restores the default setting.

By default, an 802.1X user enters the quiet state after ten authentication failures within 60 seconds.

Format

dot1x quiet-times *fail-times*

undo dot1x quiet-times

Parameters

Parameter	Description	Value
<i>fail-times</i>	Specifies the maximum number of authentication failures before the 802.1X user enters the quiet state.	The value is an integer that ranges from 1 to 10.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the quiet timer function of the device is enabled using the [13.5.75 dot1x quiet-period](#) command, if the number of authentication failures of an 802.1X user exceeds the value that is set using the **dot1x quiet-times** command within 60 seconds, the user enters the quiet state. This prevents the impact on the system due to frequent user authentication.

Example

Set the maximum number of authentication failures within 60 seconds to 4.

```
<HUAWEI> system-view  
[HUAWEI] dot1x quiet-times 4
```

Related Topics

[13.5.75 dot1x quiet-period](#)

13.5.77 dot1x reauthenticate

Function

The **dot1x reauthenticate** command enables periodic 802.1X re-authentication on an interface.

The **undo dot1x reauthenticate** command disables periodic 802.1X re-authentication on an interface.

By default, periodic 802.1X re-authentication is disabled on an interface.

Format

In the system view:

dot1x reauthenticate interface { *interface-type interface-number1* [**to** *interface-number2*] } &<1-10>

undo dot1x reauthenticate interface { *interface-type interface-number1* [**to** *interface-number2*] } &<1-10>

In the interface view:

dot1x reauthenticate

undo dot1x reauthenticate

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After modifying the authentication information of an online user on the authentication server, the administrator needs to re-authenticate the user in real time to ensure user validity.

After the user goes online, the device saves user authentication information. After 802.1X re-authentication is enabled using the **dot1x reauthenticate** command, the device sends the stored authentication information of the online user to the authentication server for re-authentication at an interval. If the authentication information of the user does not change on the authentication server, the user is online normally. If the authentication information has been changed, the user is forced to go offline. The user then needs to be re-authenticated according to the changed authentication information.

 NOTE

The re-authentication interval is set using the [13.5.81 dot1x timer reauthenticate-period](#) command.

This function takes effect only for users who go online after this function is successfully configured.

If the device is connected to a server for re-authentication and the server replies with a re-authentication deny message that makes an online user go offline, it is recommended that you locate the cause of the re-authentication failure on the server or disable the re-authentication function on the device.

Precautions

If periodic 802.1X re-authentication is enabled, a large number of 802.1X authentication logs are generated.

If the device is connected to a server for re-authentication and the server replies with a re-authentication deny message that makes an online user go offline, it is recommended that you locate the cause of the re-authentication failure on the server or disable the re-authentication function on the device.

Example

Enable periodic 802.1X re-authentication on GE0/0/1 in the system view.

```
<HUAWEI> system-view  
[HUAWEI] dot1x reauthenticate interface gigabitethernet 0/0/1
```

Enable periodic 802.1X re-authentication on GE0/0/1 in the interface view.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] dot1x reauthenticate
```

Related Topics

[13.5.80 dot1x timer](#)

[13.5.34 display dot1x](#)

13.5.78 dot1x reauthenticate mac-address

Function

The **dot1x reauthenticate mac-address** command enables re-authentication for an online 802.1X user with the specified MAC address.

By default, re-authentication is disabled for an online 802.1X user with the specified MAC address.

Format

dot1x reauthenticate mac-address *mac-address*

Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies the MAC address of an 802.1X user to be re-authenticated.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

For details, see [dot1x reauthenticate](#).

The **dot1x reauthenticate mac-address** and **dot1x reauthenticate** commands re-authenticate online 802.1X users and their difference is as follows:

- The **dot1x reauthenticate mac-address** command configures the device to re-authenticate a specified user for once.
- The **dot1x reauthenticate** command configures the device to re-authenticate all users on a specified interface at intervals.

Example

```
# Enable re-authentication for an 802.1X user with the MAC address of 00e0-fc01-0005.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x reauthenticate mac-address 00e0-fc01-0005
```

Related Topics

[13.5.34 display dot1x](#)

[13.5.63 dot1x enable](#)

[13.5.77 dot1x reauthenticate](#)

[13.5.80 dot1x timer](#)

13.5.79 dot1x retry

Function

The **dot1x retry** command configures the number of times an authentication request or handshake packet is retransmitted to an 802.1X user.

The **undo dot1x retry** command restores the default configuration.

By default, the device can retransmit an authentication request or handshake packet to an 802.1X user twice.

Format

dot1x retry *max-retry-value*

undo dot1x retry

Parameters

Parameter	Description	Value
<i>max-retry-value</i>	Specifies the number of times an authentication request or handshake packet is retransmitted to an 802.1X user.	The value is an integer that ranges from 1 to 10. By default, the device can retransmit an authentication request or handshake packet to an 802.1X user twice. The default value is recommended.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

If the device does not receive any response from a user within a specified time after sending an authentication request or handshake packet to the user, the device sends the authentication request or handshake packet again. If the authentication request or handshake packet has been sent for the maximum retransmission times and no response is received, the user authentication or handshake fails. In this process, the total number of authentication requests or handshake packets sent by the device is *max-retry-value* plus 1.

 NOTE

- After you run the **dot1x retry** command, the setting takes effect on all interfaces enabled with 802.1X authentication.
- Repeated authentication requests occupy a lot of system resources. When using the **dot1x retry** command, you can set the maximum number of times according to user requirements and device resources. The default value is recommended.
- The interval for sending authentication requests is set using the [13.5.80 dot1x timer](#) command. The interval for sending authentication requests to offline users is controlled by the **tx-period** and **client-timeout** timer, and the interval for sending authentication requests to online users is controlled by the **handshake-period** timer.
- The **dot1x retry** command is used together with the guest VLAN function (for details, see [13.5.13 authentication guest-vlan](#)). If a user does not respond within the specified maximum number of times, the user is added to the guest VLAN so that the user can access resources in the guest VLAN without being authenticated.

Example

Set the number of times an authentication request or handshake packet can be retransmitted to 802.1X users to 4.

```
<HUAWEI> system-view  
[HUAWEI] dot1x retry 4
```

Related Topics

[13.5.63 dot1x enable](#)

[13.5.34 display dot1x](#)

[13.5.80 dot1x timer](#)

[13.5.65 dot1x handshake](#)

13.5.80 dot1x timer

Function

The **dot1x timer** command sets values of timers used in 802.1X authentication.

The **undo dot1x timer** command restores the default settings of timers used in 802.1X authentication.

By default, the values of timers used in 802.1X authentication are not set.

Format

dot1x timer { **arp-detect** *arp-detect-value* | **client-timeout** *client-timeout-value* | **handshake-period** *handshake-period-value* | **eth-trunk-access handshake-period** *handshake-period-value* | **quiet-period** *quiet-period-value* | **tx-period** *tx-period-value* | **mac-bypass-delay** *delay-time-value* | **free-ip-timeout** *free-ip-time-value* }

undo dot1x timer { **arp-detect** | **client-timeout** | **handshake-period** | **eth-trunk-access handshake-period** | **quiet-period** | **tx-period** | **mac-bypass-delay** | **free-ip-timeout** }

Parameters

Parameter	Description	Value
arp-detect <i>arp-detect-value</i>	Specifies the timeout interval of the ARP detect. You are advised to set this parameter to 30 seconds.	The value is an integer that ranges from 5 to 7200, in seconds. By default, the device does not support the ARP detect.
client-timeout <i>client-timeout-value</i>	Specifies the timeout interval of the authentication response from the client. NOTE On the network, some terminals may delay in responding to EAP-Request/MD5 Challenge packets sent from the device. If the delay is long, you can increase client-timeout <i>client-timeout-value</i> so that these terminals can go online. The adjustment rule is as follows: $3 \times \text{client-timeout } \textit{client-timeout-value} > \text{Terminal response delay}$	The value is an integer that ranges from 1 to 120, in seconds. By default, the timeout interval of the authentication response from the client is 5 seconds.
handshake-period <i>handshake-period-value</i>	Specifies the handshake interval between the device and 802.1X authentication client connected to a non-Eth-Trunk interface. For details, see 13.5.65 dot1x handshake .	The value is an integer that ranges from 5 to 7200, in seconds. By default, the interval for sending handshake packets is 15 seconds.
eth-trunk-access handshake-period <i>handshake-period-value</i>	Specifies the handshake interval between the device and 802.1X authentication client connected to an Eth-Trunk. For details, see 13.5.65 dot1x handshake .	The value is an integer that ranges from 30 to 7200, in seconds. By default, the interval for sending handshake packets is 120 seconds.

Parameter	Description	Value
quiet-period <i>quiet-period-value</i>	<p>Specifies the quiet period.</p> <p>For details, see 13.5.75 dot1x quiet-period.</p>	<p>The value is an integer that ranges from 1 to 3600, in seconds.</p> <p>By default, the quiet period of a user who fails authentication is 60 seconds.</p>
tx-period <i>tx-period-value</i>	<p>Specifies the interval for sending authentication requests.</p> <p>The device starts the tx-period timer in either of the following situations:</p> <ul style="list-style-type: none">• When the client initiates authentication, the device sends a unicast Request/Identity request packet to the client and starts the tx-period timer. If the client does not respond within the period set by the timer, the device retransmits the authentication request packet.• To authenticate the 802.1X clients that cannot initiate authentication, the device sends multicast Request/Identity packets through the 802.1X-enabled interface to the clients at the interval set by the tx-period timer.	<p>The value is an integer that ranges from 1 to 120, in seconds.</p> <p>By default, the interval for sending authentication requests is 30 seconds.</p>

Parameter	Description	Value
mac-bypass-delay <i>delay-time-value</i>	Specifies the value of the delay timer for MAC address bypass authentication. After MAC address bypass authentication is configured, the device performs 802.1X authentication and starts the delay timer for MAC address bypass authentication. If 802.1X authentication fails after the value of the delay timer is reached, the device performs MAC address bypass authentication.	The value is an integer that ranges from 1 to 300, in seconds. By default, the value of the delay timer for MAC address bypass authentication is 30s.
free-ip-timeout <i>free-ip-time-value</i>	Specifies the aging time of authentication-free user entries. When the 802.1X free IP subnet is configured, the device creates authentication-free user entries after receiving ARP/DHCP packets from 802.1X users. If users go offline abnormally, the authentication-free user entries cannot be deleted. To prevent this problem, the aging time of authentication-free user entries can be configured.	The value is an integer that ranges from 0 to 71581, in minutes. The value 0 indicates that authentication-free user entries do not age. By default, authentication-free user entries do not age.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

During 802.1X authentication, multiple timers implement systematic interactions between access users, access devices, and the authentication server. You can

change the values of the timers using the **dot1x timer** command to adjust the interaction process. (The values of some timers cannot be changed.) This command is necessary in special network environments. Generally, the default settings of the timers are recommended.

The ARP probe function can also be implemented by detecting whether there is user traffic on the access device. If the ARP probe interval is **n**, the device detects user traffic at **n** and **2n**. The following uses the **0-n** period as an example. The process during the **n-2n** period is the same as that during **0-n**. (This process applies only to users who go online from the S5720EI, S5720HI, S6720EI, and S6720S-EI. Other device models do not support user traffic detection, and they send ARP probe packets at **n** and **2n**.)

- If user traffic passes through the device within the **0-n** period, the device considers that the user is online at **n**, and will not send ARP probe packets. Additionally, the device resets the ARP probe interval.
- If no user traffic passes through the device within the **0-n** period, the device cannot determine whether the user is online at **n**. In this case, the device sends an ARP probe packet. If the device receives an ARP reply packet from the user, it considers the user online and resets the ARP probe interval. If no ARP reply packet is received, the device considers the user offline.
- If user traffic passes through the device or the device receives an ARP reply packet from the user within the **2n-3n** period, the device considers that the user is online at **3n** and resets the ARP probe interval.
- If no user traffic passes through the device and the device receives no ARP reply packet from the user within the **2n-3n** period, the device cannot determine whether the user is online at **3n** and considers the user offline.

If the device considers that the user is offline at **n**, **2n**, and **3n**, the device deletes all entries related to the user. To prevent the user from going offline unexpectedly when no operation is performed on the PC, do not set a short ARP probe interval.

Example

```
# Set the timeout interval of the authentication response from the client to 90s.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x timer client-timeout 90
```

Related Topics

- [13.5.63 dot1x enable](#)
- [13.5.65 dot1x handshake](#)
- [13.5.75 dot1x quiet-period](#)
- [13.5.34 display dot1x](#)

13.5.81 dot1x timer reauthenticate-period

Function

The **dot1x timer reauthenticate-period** command sets the re-authentication interval for 802.1X authentication users.

The **undo dot1x timer reauthenticate-period** command restores the default re-authentication interval.

By default, the re-authentication interval is 3600 seconds.

Format

dot1x timer reauthenticate-period *reauthenticate-period-value*

undo dot1x timer reauthenticate-period

Parameters

Parameter	Description	Value
<i>reauthenticate-period-value</i>	Specifies the re-authentication interval for 802.1X address authentication users. To reduce the impact on the device performance when many users exist, the user re-authentication interval may be longer than the configured re-authentication interval.	The value is an integer that ranges from 60 to 7200, in seconds.

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

After enabling the re-authentication function for online 802.1X authentication users using the [13.5.77 dot1x reauthenticate](#) command, run the **dot1x timer reauthenticate-period** command to set the re-authentication interval. The device then authenticates online users at the specified interval, ensuring that only authorized users can keep online.

If the command is executed in the system view, the function takes effect on all interfaces. If the command is executed in both system view and interface view, the function takes effect on the interface.

NOTE

It is recommended that the re-authentication interval be set to the default value. If multiple ACLs need to be delivered during user authorization, you are advised to disable the re-authentication function or set a longer re-authentication interval to improve the device's processing performance.

In remote authentication and authorization, if the re-authentication interval is set to a shorter time, the CPU usage may be higher.

To reduce the impact on the device performance when many users exist, the user re-authentication interval may be longer than the configured re-authentication interval.

Example

```
# Set the 802.1X re-authentication interval to 7200 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x timer reauthenticate-period 7200
```

Related Topics

[13.5.77 dot1x reauthenticate](#)

13.5.82 dot1x trigger dhcp-binding

Function

The **dot1x trigger dhcp-binding** command enables the device to automatically generate the DHCP snooping binding table after static IP users pass 802.1X authentication.

The **undo dot1x trigger dhcp-binding** command restores the default setting.

By default, the device does not automatically generate the DHCP snooping binding table after static IP users pass 802.1X authentication.

Format

dot1x trigger dhcp-binding

undo dot1x trigger dhcp-binding

Parameters

None

Views

Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

Scenario

There are unauthorized users who modify their MAC addresses to those of authorized users. After authorized users are connected through 802.1X authentication, the unauthorized users can obtain the same identities as the authorized users and connect to the network without authentication. This results in security risks of authentication and accounting. After accessing the network, unauthorized users can also initiate ARP spoofing attacks by sending bogus ARP packets. In this case, the device records incorrect ARP entries, greatly affecting normal communication between authorized users. To prevent the previous attacks,

configure IPSPG and DAI. These two functions are implemented based on binding tables. For static IP users, you can run the **user-bind static** command to configure the static binding table. However, if there are many static IP users, it takes more time to configure static binding entries one by one.

To reduce the workload, you can configure the device to automatically generate the DHCP snooping binding table for static IP users. After the static IP users who pass 802.1X authentication send EAP packets to trigger generation of the user information table, the device automatically generates the DHCP snooping binding table based on the MAC address, IP address, and interface recorded in the table.

You can run the **display dhcp snooping user-bind** command to check the DHCP snooping binding table that is generated by the device for static IP users who pass 802.1X authentication. The DHCP snooping binding table generated using this function will be deleted after the users are disconnected.

Follow-up Procedure

Configure IPSPG and DAI after the DHCP snooping binding table is generated, prevent attacks from unauthorized users.

- In the interface view, run the **ip source check user-bind enable** command to enable IPSPG.
- In the interface view, run the **arp anti-attack check user-bind enable** command to enable DAI.

Precautions

- Before configuring the device to generate the DHCP snooping binding table for static IP users, you must have enabled 802.1X authentication and DHCP snooping globally and on interfaces using the **dot1x enable** and **dhcp snooping enable** commands.
- The EAP protocol does not specify a standard attribute to carry IP address information. Therefore, if the EAP request packet sent by a static IP user does not contain an IP address, the IP address information in the DHCP snooping binding table is obtained from the user's first ARP request packet with the same MAC address as the user information table after the user passes authentication. On a network, unauthorized users may forge authorized users' MAC addresses to initiate ARP spoofing attacks to devices, and the DHCP snooping binding table generated accordingly may be unreliable. Therefore, the **dot1x trigger dhcp-binding** command is not recommended and you are advised to run the **user-bind static** command to configure the static binding table.
- For users who are assigned IP addresses using DHCP, you do not need to run the **dot1x trigger dhcp-binding** command on the device. The DHCP snooping binding table is generated through the DHCP snooping function.

Example

Enable the device to automatically generate the DHCP snooping binding table after static IP users pass 802.1X authentication.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] dot1x trigger dhcp-binding
```

13.5.83 dot1x unicast-trigger

Function

The **dot1x unicast-trigger** command enables 802.1X authentication triggered by unicast packets.

The **undo dot1x unicast-trigger** command disables 802.1X authentication triggered by unicast packets.

By default, 802.1X authentication triggered by unicast packets is disabled.

Format

In the system view:

```
dot1x unicast-trigger interface { interface-type interface-number1 [ to interface-number2 ] } <1-10>
```

```
undo dot1x unicast-trigger interface { interface-type interface-number1 [ to interface-number2 ] } <1-10>
```

In the interface view:

```
dot1x unicast-trigger
```

```
undo dot1x unicast-trigger
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

After the **dot1x unicast-trigger** command is used on the device, the device sends a unicast packet to respond to the received ARP or DHCP Request packet from a

client. If the client does not respond within the timeout interval (set by the [13.5.80 dot1x timer](#) command), the device retransmits the unicast packet (the maximum of retransmission count is set by the [13.5.79 dot1x retry](#) command). During 802.1X-based network deployment, 802.1X users can start 802.1X authentication without installing specified client dial-in software, which facilitates network deployment.

 NOTE

The **dot1x unicast-trigger** command has the same function as the [13.5.60 dot1x dhcp-trigger](#) command.

Example

Enable 802.1X authentication triggered by unicast packets on GE0/0/1 in the system view.

```
<HUAWEI> system-view  
[HUAWEI] dot1x unicast-trigger interface gigabitethernet 0/0/1
```

Related Topics

[13.5.60 dot1x dhcp-trigger](#)

13.5.84 dot1x url

Function

The **dot1x url** command configures the redirect-to URL in 802.1X authentication.

The **undo dot1x url** command cancels the redirect-to URL configuration in 802.1X authentication.

By default, no redirect-to URL is configured in 802.1X authentication.

Format

dot1x url *url-string*

undo dot1x url

Parameters

Parameter	Description	Value
<i>url-string</i>	Specifies the redirect-to URL.	The value is a string of 1 to 200 case-sensitive characters.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In the early stage of network deployment, 802.1X client deployment is difficult with heavy workload. You can run the **dot1x url** command to set the redirect-to URL to the 802.1X client download web page address. When a user uses a web browser to access websites other than the free IP subnet, the device redirects the user to the redirect-to URL where the user can download and install the 802.1X client software after receiving the HTTP packet from the user.

Follow-up Procedure

Run the **dot1x free-ip** command to configure a free IP subnet where the redirect-to URL of the 802.1X user is located. To ensure that pre-connection users can be aged out normally, you need to run the **13.5.80 dot1x timer free-ip-timeout** command to set the aging time of authentication-free user entries.

Precautions

The redirect-to URL must be within the free IP subnet. Otherwise, the URL is inaccessible.

When 802.1X-based fast deployment is configured, the device supports redirection triggered only by HTTP packets with HTTP port 80.

Example

```
# Configure the redirect-to URL in 802.1X authentication to http://www.***.com.cn.
```

```
<HUAWEI> system-view  
[HUAWEI] dot1x url http://www.***.com.cn
```

Related Topics

[13.5.64 dot1x free-ip](#)

[13.5.34 display dot1x](#)

13.5.85 force-push

Function

The **force-push** command enables the forcible URL template or URL push function.

The **undo force-push** command disables the forcible URL template or URL push function.

By default, the forcible URL template or URL push function is disabled.

Format

```
force-push { url-template template-name | url url-address }
```

```
undo force-push
```

Parameters

Parameter	Description	Value
url-template <i>template-name</i>	Specifies the name of a pushed URL template.	The value must be the name of an existing URL template.
url <i>url-address</i>	Specifies a pushed URL.	It is a string of 1 to 200 case-sensitive characters that do not contain spaces and question marks (?). When double quotation marks are used around the string, spaces are allowed in the string.

Views

AAA domain view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After a user is successfully authenticated, the device forcibly redirect the user to a web page when receiving the HTTP packet from the user who accesses web pages for the first time. In addition to pushing advertisement pages, the device can obtain user terminal information through the HTTP packets sent by the users, and apply the information to other services. There are two ways to push web pages:

1. URL: pushes the URL corresponding to the web page.
2. URL template: pushes the URL template. A URL template must be created. The URL template contains the URL of the pushed web page and URL parameters.

Prerequisites

The URL configured using the [13.5.151 url \(URL template view\)](#) command in the URL template view cannot be a redirection URL; otherwise, the command does not take effect.

Precautions

For the S5720HI, the forcible push function takes effect only for the first HTTP or HTTPS packet received from the user. If an application program that actively sends HTTP or HTTPS packets is installed on the user terminal, the terminal has sent the HTTP or HTTPS packet before the user accesses a web page. Therefore, the user is unaware of the web page push process.

The forcible push function takes effect only when a redirection ACL is configured for switches excluding the S5720HI. If a redirection ACL exists in the user table, a

web page is forcibly pushed when HTTP packets from users match the redirection ACL rule. Usually, you can configure the RADIUS server to authorize the Huawei extended RADIUS attribute **HW-Redirect-ACL** to users for redirection ACL implementation, or run the [13.1.72 redirect-acl](#) command to configure a redirection ACL.

A pushed URL configured in a domain need to be used together with a redirect ACL or push flag attribute. The redirect ACL has a higher priority than the push flag attribute. By default, a pushed URL configured in a domain carries the push flag attribute. Users will be redirected to the pushed URL when they are successfully authenticated.

When an IPv4 redirect ACL is configured for an IPv6 user or an IPv6 redirect ACL is configured for an IPv4 user, the **Push URL content** field in the [13.5.31 display access-user](#) command output displays the pushed URL, but the browser of the user cannot redirect to the pushed URL.

Switches except the S5720HI do not support concurrent use of the pushed URL and redirection ACL6 functions. If both functions are configured, the **Push URL content** field in the [13.4.55 display access-user](#) command output displays the pushed URL; however, the terminal browser cannot be redirected to the pushed URL.

Example

Push the URL template **abc** in the domain **huawei**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] domain huawei
[HUAWEI-aaa-domain-huawei] force-push url-template abc
```

Related Topics

[13.5.151 url \(URL template view\)](#)

13.5.86 http get-method enable

Function

The **http get-method enable** command configures the device to allow users to submit user name and password information to the device in GET mode during Portal authentication.

The **undo http get-method enable** command restores the default setting.

By default, the device does not allow users to submit user name and password information to the device in GET mode during Portal authentication.

Format

http get-method enable

undo http get-method enable

Parameters

None

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

By default, the device does not allow users to submit user name and password information to the device in GET mode during Portal authentication. You can run the **http get-method enable** command to configure the device to allow users to submit user name and password information to the device in GET mode during Portal authentication.

Precautions

The GET mode has the risk of password disclosure. Therefore, the POST mode is recommended.

This command only applies to scenarios in which HTTP or HTTPS is used for Portal connection establishment.

Example

Configure the device to allow users to submit user name and password information to the device in GET mode during Portal authentication.

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server abc  
[HUAWEI-web-auth-server-abc] http get-method enable
```

13.5.87 http-method post

Function

The **http-method post** command configures parameters for parsing and replying to POST request packets of the HTTP or HTTPS protocol.

The **undo http-method post** command restores the default configuration.

By default, the system has configured parameters for parsing and replying to POST request packets of the HTTP or HTTPS protocol. For details, see the "Parameters" table.

Format

```
http-method post { cmd-key cmd-key [ login login-key | logout logout-key ] * |  
init-url-key init-url-key | login-fail response { err-msg { authserve-reply-
```

message | **msg** *msg* } | **redirect-login-url** | **redirect-url** *redirect-url* [**append-reply-message** *msgkey*] } | **login-success** response { **msg** *msg* | **redirect-init-url** | **redirect-url** *redirect-url* } | **logout-fail** response { **msg** *msg* | **redirect-url** *redirect-url* } | **logout-success** response { **msg** *msg* | **redirect-url** *redirect-url* } | **password-key** *password-key* | **user-mac-key** *user-mac-key* | **userip-key** *userip-key* | **username-key** *username-key* } *

undo http-method post { **all** | { **cmd-key** | **init-url-key** | **login-fail** | **login-success** | **logout-fail** | **logout-success** | **password-key** | **user-mac-key** | **userip-key** | **username-key** } * }

Parameters

Parameter	Description	Value
cmd-key <i>cmd-key</i>	Specifies the command identification keyword. The default value is cmd .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
login <i>login-key</i>	Specifies the user login identification keyword. The default value is login .	The value is a string of 1 to 15 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
logout <i>logout-key</i>	Specifies the user logout identification keyword. The default value is logout .	The value is a string of 1 to 15 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
init-url-key <i>init-url-key</i>	Specifies the identification keyword for the user initial login URL. The default value is initurl .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).

Parameter	Description	Value
<p>login-fail response { err-msg { authenserve-reply- message msg <i>msg</i> } redirect-login-url redirect-url <i>redirect-url</i> [append-reply- message <i>msgkey</i>] }</p>	<p>Specifies the response message upon a user login failure.</p> <ul style="list-style-type: none"> • err-msg authenserve-reply-message: The authentication server response message is displayed after a user login failure. • err-msg msg <i>msg</i>: A specified message is displayed after a user login failure. • redirect-login-url: A user is redirected to the login URL after a login failure. This mode is the default mode. • redirect-url <i>redirect-url</i>: A user is redirected to a specified URL after a login failure. • append-reply-message <i>msgkey</i>: specifies the identification keyword for the authentication server response message carried in the redirection URL. 	<ul style="list-style-type: none"> • <i>msg</i>: The value is a string of 1 to 200 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=). • <i>redirect-url</i>: The value is a string of 1 to 200 case-sensitive characters without spaces. • <i>msgkey</i>: The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).

Parameter	Description	Value
login-success response { msg <i>msg</i> redirect-init-url redirect-url <i>redirect-url</i> }	<p>Specifies the response message upon successful user login.</p> <ul style="list-style-type: none"> • msg <i>msg</i>: A specified message is displayed after successful user login. • redirect-init-url: A user is redirected to the initial login URL after successful login. This mode is the default mode. • redirect-url <i>redirect-url</i>: A user is redirected to a specified URL after successful login. 	<ul style="list-style-type: none"> • <i>msg</i>: The value is a string of 1 to 200 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=). • <i>redirect-url</i>: The value is a string of 1 to 200 case-sensitive characters without spaces.
logout-fail response { msg <i>msg</i> redirect-url <i>redirect-url</i> }	<p>Specifies the response message upon a user logout failure.</p> <ul style="list-style-type: none"> • msg <i>msg</i>: A specified message is displayed after a user logout failure. The default value is LogoutFail!. • redirect-url <i>redirect-url</i>: A user is redirected to a specified URL after a logout failure. 	<ul style="list-style-type: none"> • <i>msg</i>: The value is a string of 1 to 200 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=). • <i>redirect-url</i>: The value is a string of 1 to 200 case-sensitive characters without spaces.
logout-success response { msg <i>msg</i> redirect-url <i>redirect-url</i> }	<p>Specifies the response message upon successful user logout.</p> <ul style="list-style-type: none"> • msg <i>msg</i>: A specified message is displayed after successful user logout. The default value is LogoutSuccess!. • redirect-url <i>redirect-url</i>: A user is redirected to a specified URL after successful logout. 	<ul style="list-style-type: none"> • <i>msg</i>: The value is a string of 1 to 200 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=). • <i>redirect-url</i>: The value is a string of 1 to 200 case-sensitive characters without spaces.

Parameter	Description	Value
password-key <i>password-key</i>	Specifies the password identification keyword. The default value is password .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
user-mac-key <i>user-mac-key</i>	Specifies the identification keyword for the user MAC address. The default value is macaddress .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
userip-key <i>userip-key</i>	Specifies the identification keyword for the user IP address. The default value is ipaddress .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
username-key <i>username-key</i>	Specifies the user name identification keyword. The default value is username .	The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).
all	Indicates all parameters.	-

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

When the device uses the HTTP or HTTPS protocol to communicate with the Portal server, a user sends POST request packets (carrying parameters such as the user name and MAC address) to the device as required by the Portal server. After receiving the POST request packets, the device parses parameters in the packets. If identification keywords of the parameters differ from those configured on the device, the user authentication fails. Therefore, you need to run the **http-method post** command to configure the identification keywords based on the Portal server configuration.

After successful user login or logout, or a user login or logout failure, the device sends the login or logout result to the user based on the **http-method post**

command configuration. For example, the device sends the **LogoutSuccess!** message to a user who logs out successfully by default.

Example

Set the command identification keyword to **cmd1** for parsing POST request packets of the HTTP or HTTPS protocol.

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server abc  
[HUAWEI-web-auth-server-abc] http-method post cmd-key cmd1
```

13.5.88 mac-authen

Function

The **mac-authen** command enables MAC address authentication globally or on an interface.

The **undo mac-authen** command disables MAC address authentication globally or on an interface.

By default, MAC address authentication is disabled globally and on an interface.

NOTE

Only S5720EI, S1720X, S1720X-E, S5720HI, S5720S-SI, S5720SI, S5730S-EI, S5730SI, S6720LI, S6720S-LI, S6720S-SI, S6720SI, S6720EI, and S6720S-EI support configuration of MAC address authentication on VLANIF interfaces.

Format

In the system view:

```
mac-authen [ interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10> ]
```

```
undo mac-authen [ interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10> ]
```

In the interface view:

```
mac-authen
```

```
undo mac-authen
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number.	-

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

MAC address authentication controls network access rights of a user based on the user's access interface and MAC address. During MAC address authentication, the user name and password are the user's MAC address. MAC address authentication is applicable to the scenario where MAC addresses are unchanged and high security is not required, and is used to authenticate terminals such as printers where the authentication client cannot be installed.

If you run the **mac-authen** command in the system view without any interfaces specified, MAC address authentication is enabled globally. The configurations of MAC address authentication take effect only after global MAC address authentication is enabled. MAC address bypass authentication is not controlled by this command.

To enable MAC address authentication on an interface, you can perform either of the following operations:

- Run the **mac-authen** command in the interface view.
- Run the **mac-authen interface** { *interface-type interface-number1* [**to** *interface-number2*] } &<1-10> command in the system view.

Precautions

- Before running the **undo mac-authen** command, ensure that there is no online MAC address authentication user; otherwise, you cannot run this command. Online MAC address authentication users do not include online users using MAC address bypass authentication.

- After MAC address authentication is enabled on a VLANIF interface, the guest VLAN, critical VLAN, or dynamic VLAN authorization is invalid to the MAC address authentication users on the VLANIF interface.
- Before enabling MAC address authentication on the VLANIF interface, ensure that the strict ARP entry learning function is disabled using the **undo arp learning strict** command. If the function is enabled, the users cannot go online.
- After the static MAC address entry is configured using the **mac-address static mac-address interface-type interface-number vlan vlan-id** command, the user corresponding to the entry cannot pass MAC address authentication.
- If MAC address authentication is enabled on an interface, the following commands cannot be used on the same interface. If the following commands are configured on an interface, MAC address authentication cannot be enabled on the same interface.

Command	Function
mac-limit	Sets the maximum number of MAC addresses that can be learned by an interface.
mac-address learning disable	Disables MAC address learning on an interface.
port link-type dot1q-tunnel	Sets the link type of an interface to QinQ.
port vlan-mapping vlan map-vlan port vlan-mapping vlan inner-vlan	Configures VLAN mapping on an interface.
port vlan-stacking	Configures selective QinQ.
port-security enable	Enables interface security.
mac-vlan enable	Enables MAC address-based VLAN assignment on an interface.
ip-subnet-vlan enable	Enables IP subnet-based VLAN assignment on an interface.
user-bind ip sticky-mac	Enables the device to generate snooping MAC entries.

Example

Enable global MAC address authentication.

```
<HUAWEI> system-view
[HUAWEI] mac-authen
```

Enable MAC address authentication on GE0/0/1 in the system view.

```
<HUAWEI> system-view
[HUAWEI] mac-authen
[HUAWEI] mac-authen interface gigabitethernet 0/0/1
```

Enable MAC address authentication on GE0/0/1 in the interface view.

```
<HUAWEI> system-view
[HUAWEI] mac-authen
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] mac-authen
```

Related Topics

- [13.5.63 dot1x enable](#)
- [13.5.38 display mac-authen](#)
- [13.5.91 mac-authen domain](#)
- [13.5.92 mac-authen max-user](#)
- [13.5.96 mac-authen reauthenticate](#)
- [13.5.99 mac-authen timer](#)
- [13.5.101 mac-authen username](#)

13.5.89 mac-authen trigger

Function

The **mac-authen trigger** command configures the packet types that can trigger MAC address authentication.

The **undo mac-authen trigger** command restores the default configuration.

By default, DHCP/ARP/DHCPv6/ND packets can trigger MAC address authentication.

Format

In the system view:

```
mac-authen { dhcp-trigger | arp-trigger | dhcpv6-trigger | nd-trigger } *
[ interface { interface-type interface-number1 [ to interface-number2 ] }
&<1-10> ]
```

```
undo mac-authen { dhcp-trigger | arp-trigger | dhcpv6-trigger | nd-trigger } *
[ interface { interface-type interface-number1 [ to interface-number2 ] }
&<1-10> ]
```

In the interface view:

```
mac-authen { dhcp-trigger | arp-trigger | dhcpv6-trigger | nd-trigger } *
```

```
undo mac-authen { dhcp-trigger | arp-trigger | dhcpv6-trigger | nd-trigger } *
```

Parameters

Parameter	Description	Value
dhcp-trigger	Triggers MAC address authentication through DHCP packets.	-

Parameter	Description	Value
arp-trigger	Triggers MAC address authentication through ARP packets.	-
dhcpv6-trigger	Triggers MAC address authentication through DHCPv6 packets.	-
nd-trigger	Triggers MAC address authentication through ND packets.	-
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. <p>If this parameter is not specified, the command takes effect on all interfaces.</p>	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After MAC address authentication is enabled, the device can trigger MAC address authentication on users by default when receiving DHCP/ARP/DHCPv6/ND packets. Based on user information on the actual network, the administrator can adjust the packet types that can trigger MAC address authentication. For example, if all users on a network dynamically obtain IPv4 addresses, the device can be configured to trigger MAC address authentication only through DHCP packets. This prevents the device from continuously sending ARP packets to trigger MAC address authentication when static IPv4 addresses are configured for unauthorized users on the network, and reduces device CPU occupation.

Precautions

If the command is configured globally, the configuration takes effect on multiple interfaces. If the command is configured globally and on an interface, the configuration on the interface takes precedence.

The **mac-authen trigger** command also enables MAC address authentication. When both the **mac-authen trigger** and **mac-authen** commands are configured on an interface, the last configured one takes effect. If the **mac-authen** configuration takes effect on the interface, DHCP, ARP, DHCPv6, and ND packets can trigger MAC address authentication.

Example

Configure the device to trigger MAC address authentication only through DHCP packets in the system view.

```
<HUAWEI> system-view  
[HUAWEI] mac-authen dhcp-trigger
```

Related Topics

[13.5.88 mac-authen](#)

13.5.90 mac-authen dhcp-trigger dhcp-option

Function

The **mac-authen dhcp-trigger dhcp-option** command enables the device to send DHCP option information to the authentication server when triggering MAC address authentication through DHCP packets.

The **undo mac-authen dhcp-trigger dhcp-option** command restores the default configuration.

By default, the device does not send DHCP option information to the authentication server when triggering MAC address authentication through DHCP packets.

Format

In the system view:

```
mac-authen dhcp-trigger dhcp-option option-code [ interface { interface-type  
interface-number1 [ to interface-number2 ] } &<1-10> ]
```

```
undo mac-authen dhcp-trigger dhcp-option option-code [ interface { interface-  
type interface-number1 [ to interface-number2 ] } &<1-10> ]
```

In the interface view:

```
mac-authen dhcp-trigger dhcp-option option-code
```

```
undo mac-authen dhcp-trigger dhcp-option option-code
```

Parameters

Parameter	Description	Value
<i>option-code</i>	Specifies the option that the device sends to the authentication server.	The value is fixed as 82.
interface { <i>interface-type interface-number1</i> [<i>to interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Option82 record information about DHCP user locations and services (voice and data services). After this command is run, if the device supports the function of triggering MAC address authentication through DHCP packets, it sends Option82 information to the authentication server when triggering MAC address authentication through DHCP packets. Based on the user information recorded in Option82, the authentication server then assigns different network access rights to users with different services in different locations. This implements accurate control on the network access right of each user.

Example

Globally enable the device to send Option82 information to the authentication server when triggering MAC address authentication through DHCP packets.

```
<HUAWEI> system-view
[HUAWEI] mac-authen dhcp-trigger dhcp-option 82
```

Related Topics

[13.5.88 mac-authen](#)

13.5.91 mac-authen domain

Function

The **mac-authen domain** command configures an authentication domain for MAC address authentication users.

The **undo mac-authen domain** command restores the global default authentication domain for MAC address authentication users.

The default authentication domain for MAC address authentication users is the global default domain.

 **NOTE**

Only S5720EI, S1720X, S1720X-E, S5720HI, S5720S-SI, S5720SI, S5730S-EI, S5730SI, S6720LI, S6720S-LI, S6720S-SI, S6720SI, S6720EI, and S6720S-EI support configuration of MAC address authentication on VLANIF interfaces.

Format

In the system view:

mac-authen domain *isp-name* [**mac-address** *mac-address* **mask** *mask*]

undo mac-authen domain [*isp-name* [**mac-address** *mac-address*]] [**mac-address** { *mac-address* | **all** }]]

In the interface view:

mac-authen domain *isp-name*

undo mac-authen domain

Parameters

Parameter	Description	Value
<i>isp-name</i>	Specifies the ISP domain name.	The value is a string of 1 to 64 case-insensitive characters without any space, asterisk (*), question mark (?), quotation mark ("), hyphen (-) or consecutive hyphens (--).
mac-address <i>mac-address</i>	Specifies an authentication domain for the MAC address authentication user with a specified MAC address.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.
mask <i>mask</i>	Specifies the mask of a MAC address.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.
all	Restores the global default domain for all MAC address authentication users.	-

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When user names for MAC address authentication do not contain domain names, the device authenticates users using the **default** domain if no authentication domain is configured on the device or interface. The authentication scheme is not flexible because all users are authenticated in the **default** domain. The **mac-authen domain** command specifies the authentication domains for MAC address authentication users. Different interfaces can be located in different authentication domains. This command can specify the authentication domains for the specified MAC addresses. Therefore, this command allows users with different authentication requirements to adopt various authentication schemes.

NOTE

- If the user name contains a domain name (configured using [13.5.101 mac-authen username](#)), the user is authenticated in this domain.
- The specified user names and domain names must be the same as those configured in the AAA view.
- The authentication schemes in the domains are configured in the AAA view.

Prerequisites

The domain to be configured as an authentication domain has been created using the [domain \(AAA view\)](#) command.

MAC address authentication has been enabled globally and on an interface using the [13.5.88 mac-authen](#) command.

Precautions

If authentication domains are configured in both the system view and interface view, the domain configured in the interface view takes effect. If no authentication domain is configured in the interface view, the domain configured in the system view takes effect.

You must specify a unicast MAC address in the **mac-authen domain** command. A user with an all-0 MAC address is not authenticated.

The configured authentication domain is applied to the MAC addresses calculated with the mask. Therefore, the **undo mac-authen domain** command will delete the authentication domain of the calculated MAC addresses. Before running the **undo mac-authen domain** command, run the [display this](#) command to view the calculated MAC addresses.

On a network configured with both 802.1X authentication and MAC address bypass authentication, an 802.1X user failing the 802.1X authentication will be

authenticated in the manner of MAC address bypass authentication. If the authentication scheme of MAC address bypass authentication is none authentication, the user can go online successfully without being authenticated. To prevent such unauthorized authentication, use the **mac-authen domain** command to specify different domains for the two authentication methods.

Example

Configure the **cams** domain as the authentication domain for MAC address authentication users in the system view.

```
<HUAWEI> system-view
[HUAWEI] mac-authen domain cams
# Configure the cams domain as the authentication domain for MAC address
authentication users in the interface view.
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] mac-authen domain cams
```

Related Topics

- [13.5.88 mac-authen](#)
- [13.1.47 domain \(AAA view\)](#)
- [13.5.38 display mac-authen](#)
- [13.5.101 mac-authen username](#)

13.5.92 mac-authen max-user

Function

The **mac-authen max-user** command sets the maximum number of MAC address authentication users on an interface.

The **undo mac-authen max-user** command restores the default value of the maximum number of MAC address authentication users on an interface.

By default, the number of MAC address authentication users is the maximum number of MAC address authentication users supported by the device.

Format

In the system view:

```
mac-authen max-user user-number interface { interface-type interface-number1  
[ to interface-number2 ] } &<1-10>
```

```
undo mac-authen max-user [ user-number ] interface { interface-type interface-  
number1 [ to interface-number2 ] } &<1-10>
```

In the interface view:

```
mac-authen max-user user-number
```

```
undo mac-authen max-user [ user-number ]
```

Parameters

Parameter	Description	Value
<i>user-number</i>	Specifies the maximum number of MAC address authentication users on an interface.	The value is an integer that varies depending on the product model.
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To limit the number of MAC address authentication users on an interface, run the **mac-authen max-user** command. When the number of access users on an interface reaches the limit, the device will not trigger authentication for the users newly connected to the interface; therefore, these users cannot access the network.

Prerequisites

MAC address authentication has been enabled globally and on an interface using the [13.5.88 mac-authen](#) command.

Example

Set the maximum number of MAC address authentication users on GE0/0/1 to 8 in the system view.

```
<HUAWEI> system-view
[HUAWEI] mac-authen max-user 8 interface gigabitethernet 0/0/1
```

Set the maximum number of MAC address authentication users on GE0/0/1 to 8 in the interface view.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] mac-authen max-user 8
```

Related Topics

- [13.5.88 mac-authen](#)
- [13.5.38 display mac-authen](#)

13.5.93 mac-authen offline dhcp-release

Function

The **mac-authen offline dhcp-release** command enables the device to clear user entries when receiving DHCP Release packets from MAC address authentication users.

The **undo mac-authen offline dhcp-release** command restores the default configuration.

By default, the device does not clear user entries when receiving DHCP Release packets from MAC address authentication users.

Format

In the system view:

```
mac-authen offline dhcp-release interface { interface-type interface-number1  
[ to interface-number2 ] } <1-10>
```

```
undo mac-authen offline dhcp-release interface { interface-type interface-  
number1 [ to interface-number2 ] } <1-10>
```

In the interface view:

```
mac-authen offline dhcp-release
```

```
undo mac-authen offline dhcp-release
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	<p>Specifies the type and number of an interface.</p> <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number1</i> specifies the number of the first interface.• <i>interface-number2</i> specifies the number of the last interface. The value of <i>interface-number2</i> must be greater than the value of <i>interface-number1</i>. <i>interface-number2</i> and <i>interface-number1</i> together specify an interface range.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After MAC address authentication users who send DHCP Release packets go offline, the corresponding user entries on the device cannot be deleted immediately. This occupies device resources and possibly prevents other users from going online. You can run this command to enable the device to clear the user entries in real time when MAC address authentication users go offline.

Precautions

If the device functions as a DHCP relay agent, configure the DHCP snooping function on the device; otherwise, this command does not take effect.

This function takes effect only in L2 BNG scenarios.

Example

In the system view, enable the device to clear user entries when receiving DHCP Release packets from MAC address authentication users on GE0/0/1.

```
<HUAWEI> system-view  
[HUAWEI] mac-authen offline dhcp-release interface gigabitethernet 0/0/1
```

In the interface view, enable the device to clear user entries when receiving DHCP Release packets from MAC address authentication users on GE0/0/1.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] mac-authen offline dhcp-release
```

Related Topics

[13.5.88 mac-authen](#)

13.5.94 mac-authen permit mac-address

Function

The **mac-authen permit mac-address** command specifies the MAC address range allowed for MAC address authentication.

The **undo mac-authen permit mac-address** command deletes the MAC address range allowed for MAC address authentication.

By default, no MAC address range is specified for MAC address authentication.

NOTE

Only S5720EI, S1720X, S1720X-E, S5720HI, S5720S-SI, S5720SI, S5730S-EI, S5730SI, S6720LI, S6720S-LI, S6720S-SI, S6720SI, S6720EI, and S6720S-EI support this command.

Format

mac-authen permit mac-address *mac-address* **mask** { *mask* | *mask-length* }

undo mac-authen permit mac-address *mac-address* **mask** { *mask* | *mask-length* }

Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies a MAC address for MAC address authentication.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.
mask <i>mask</i>	Specifies the MAC address mask.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.
mask <i>mask-length</i>	Specifies the MAC address mask length.	The value is an integer that ranges from 1 to 48.

Views

VLANIF interface view

Default Level

2: Configuration level

Usage Guidelines

By default, any new MAC address is allowed for MAC address authentication after MAC address authentication is enabled on a VLANIF interface. To actually control the users that can be authenticated using MAC addresses on the VLANIF interface, use this command to specify a MAC address range for MAC address authentication.

Example

Set the MAC address to 1011-1111-1111 and the MAC address mask length to 24 for MAC address authentication.

```
<HUAWEI> system-view  
[HUAWEI] interface Vlanif 10  
[HUAWEI-Vlanif10] mac-authen permit mac-address 1011-1111-1111 mask 24
```

Related Topics

[13.5.38 display mac-authen](#)

[13.5.91 mac-authen domain](#)

13.5.95 mac-authen quiet-times

Function

The **mac-authen quiet-times** command configures the maximum number of authentication failures within 60 seconds before a MAC authentication user enters the quiet state.

The **undo mac-authen quiet-times** command restores the maximum number of authentication failures to the default value.

By default, the maximum number of authentication failures is 10.

Format

mac-authen quiet-times *fail-times*

undo mac-authen quiet-times

Parameters

Parameter	Description	Value
<i>fail-times</i>	Specifies the maximum number of authentication failures before a MAC authentication user enters the quiet state.	The value is an integer that ranges from 1 to 10.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The quiet function for MAC address authentication is enabled on a device by default. When the maximum number of authentication failures exceeds 1, the device quiets a MAC authentication user and does not process authentication requests from the user, reducing impact on the system caused by attackers.

Precautions

After the maximum number of authentication failures is set to a value larger than the configured value, the user in quiet state can initiate reauthentication only after the quiet period expires. If the user enters an incorrect user name or password again, the user authentication fails. The device does not quiet the user but allows the user to initiate reauthentication immediately.

Example

```
# Set the maximum number of authentication failures within 60 seconds to 4.
```

```
<HUAWEI> system-view  
[HUAWEI] mac-authen quiet-times 4
```

13.5.96 mac-authen reauthenticate

Function

The **mac-authen reauthenticate** command enables periodic MAC address re-authentication on a specified interface.

The **undo mac-authen reauthenticate** command disables periodic MAC address re-authentication on a specified interface.

By default, periodic MAC address re-authentication is enabled on a specified interface.

Format

In the system view:

```
mac-authen reauthenticate interface { interface-type interface-number1 [ to interface-number2 ] } <1-10>
```

```
undo mac-authen reauthenticate interface { interface-type interface-number1 [ to interface-number2 ] } <1-10>
```

In the interface view:

```
mac-authen reauthenticate
```

```
undo mac-authen reauthenticate
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

After modifying the authentication information of an online user on the authentication server, the administrator needs to re-authenticate the user in real time to ensure user validity.

After the user goes online, the device saves user authentication information. After periodic re-authentication for all online MAC address authentication users on a specified interface is enabled using the **mac-authen reauthenticate** command, the device sends the stored authentication information of the online user on the interface to the authentication server for re-authentication at an interval. If the user's authentication information does not change on the authentication server,

the user is online normally. If the authentication information has been changed, the user is forced to go offline. The user then needs to be re-authenticated according to the changed authentication information.

 **NOTE**

The re-authentication interval is set using the [13.5.100 mac-authen timer reauthenticate-period](#) command.

This function takes effect only for users who go online after this function is successfully configured.

If the device is connected to a server for re-authentication and the server replies with a re-authentication deny message that makes an online user go offline, it is recommended that you locate the cause of the re-authentication failure on the server or disable the re-authentication function on the device.

Example

Enable periodic MAC address re-authentication on GE0/0/1 in the system view.

```
<HUAWEI> system-view  
[HUAWEI] mac-authen reauthenticate interface gigabitethernet 0/0/1
```

Enable periodic MAC address re-authentication on GE0/0/1 in the interface view.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] mac-authen reauthenticate
```

Related Topics

[13.5.38 display mac-authen](#)

13.5.97 mac-authen reauthenticate dhcp-renew

Function

The **mac-authen reauthenticate dhcp-renew** command enables the device to re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users.

The **undo mac-authen reauthenticate dhcp-renew** command restores the default setting.

By default, the device does not re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users.

Format

In the system view:

```
mac-authen reauthenticate dhcp-renew interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

```
undo mac-authen reauthenticate dhcp-renew interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

In the interface view:

```
mac-authen reauthenticate dhcp-renew
```

undo mac-authen reauthenticate dhcp-renew

Parameters

Parameter	Description	Value
<code>interface { interface-type interface-number1 [to interface-number2] }</code>	<p>Specifies the type and number of an interface.</p> <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number1</i> specifies the number of the first interface.• <i>interface-number2</i> specifies the number of the last interface. The value of <i>interface-number2</i> must be greater than the value of <i>interface-number1</i>. <i>interface-number2</i> and <i>interface-number1</i> together specify an interface range.	-

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

After users go online, the administrator may modify the users' authentication parameters or network access rights on the authentication server. To ensure user validity or update the users' network access rights in real time, you can run this command to enable the device to re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users.

NOTE

This function applies only to Layer 2 BNG scenarios.

Example

In the system view, enable the device to re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users on GE0/0/1.

```
<HUAWEI> system-view  
[HUAWEI] mac-authen reauthenticate dhcp-renew interface gigabitethernet 0/0/1
```

In the interface view, enable the device to re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users on GE0/0/1.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] mac-authen reauthenticate dhcp-renew
```

Related Topics

[13.5.88 mac-authen](#)

13.5.98 mac-authen reauthenticate mac-address

Function

The **mac-authen reauthenticate mac-address** command enables re-authentication for an online MAC address authentication user with a specified MAC address.

By default, re-authentication for an online MAC address authentication user with a specified MAC address is disabled.

Format

mac-authen reauthenticate mac-address *mac-address*

Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies all valid unicast MAC addresses.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

For details, see [13.5.96 mac-authen reauthenticate](#).

The **mac-authen reauthenticate mac-address** and [13.5.96 mac-authen reauthenticate](#) commands re-authenticate online MAC address authentication users and their difference is as follows:

- The **mac-authen reauthenticate mac-address** command configures the device to immediately re-authenticate a user with a specified MAC address for once.
- The [13.5.96 mac-authen reauthenticate](#) command configures the device to re-authenticate all online MAC address authentication users on a specified interface at intervals.

Example

```
# Enable re-authentication for an online MAC address authentication user with  
the MAC address 0001-0002-0003.
```

```
<HUAWEI> system-view  
[HUAWEI] mac-authen reauthenticate mac-address 0001-0002-0003
```

Related Topics

[13.5.38 display mac-authen](#)

13.5.99 mac-authen timer

Function

The **mac-authen timer** command configures parameters of timers for MAC address authentication.

The **undo mac-authen timer** command restores the default parameter values of timers for MAC address authentication.

Format

```
mac-authen timer { guest-vlan reauthenticate-period interval | offline-detect  
offline-detect-value | quiet-period quiet-value }
```

```
undo mac-authen timer { guest-vlan reauthenticate-period | offline-detect |  
quiet-period }
```

Parameters

Parameter	Description	Value
guest-vlan reauthenticate-period <i>interval</i>	Specifies the interval for re-authenticating users in the Guest VLAN.	The value is an integer that ranges from 60 to 3600, in seconds. The default value is 60.

Parameter	Description	Value
offline-detect <i>offline-detect-value</i>	Specifies the interval for detecting online users. The timer is used to periodically check whether a user is offline. NOTE The timer takes effect for both MAC address authentication users and static users.	The value is an integer that ranges from 30 to 7200, and 0, in seconds. The default value is 300. 0 means disable detecting online users.
quiet-period <i>quiet-value</i>	Specifies the value of the quiet timer. If a user fails authentication, the device does not process the user's authentication requests until the quiet timer expires. During the quiet period, the device does not process the user's authentication requests.	The value is an integer that ranges from 0 to 3600, in seconds. By default, the quiet period of a user who fails authentication is 60 seconds. NOTE When the quiet timer is set to 0, the quiet function is disabled.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

During MAC address authentication, multiple timers implement systematic interactions between access users or devices and the authentication server. You can change the values of the timers by running the **mac-authen timer** command to adjust the interaction process. (The values of some timers cannot be changed.) This command is necessary in special network environments. Generally, the default settings of the timers are recommended.

NOTE

If the number of offline detection packets (ARP packets) exceeds the default CAR value, the detection fails and the users are logged out. (The [display cpu-defend statistics](#) command can be run to check whether ARP request and response packets are lost.) To resolve the problem, the following methods are recommended:

- Increase the detection interval based on the number of users. The default detection interval is recommended when there are less than 8000 users; the detection interval should be no less than 600 seconds when there are more than 8000 users.
- Deploy the port attack defense function on the access device and limit the rate of packets sent to the CPU.

Example

```
# Set the value of the quiet timer to 60 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] mac-authen timer quiet-period 60
```

Related Topics

[13.5.88 mac-authen](#)

[13.5.38 display mac-authen](#)

13.5.100 mac-authen timer reauthenticate-period

Function

The **mac-authen timer reauthenticate-period** command sets the re-authentication interval for MAC address authentication users.

The **undo mac-authen timer reauthenticate-period** command restores the default re-authentication interval.

The default re-authentication interval for MAC address authentication users in the system view is 1800 seconds, and the re-authentication interval in the interface view is the same as the re-authentication interval configured in the system view.

Format

mac-authen timer reauthenticate-period *reauthenticate-period-value*

undo mac-authen timer reauthenticate-period

Parameters

Parameter	Description	Value
<i>reauthenticate-period-value</i>	Specifies the re-authentication interval for MAC address authentication users.	The value is an integer that ranges from 60 to 7200, in seconds.

Views

System view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

After enabling the re-authentication function for online MAC address authentication users using the [13.5.96 mac-authen reauthenticate](#) command,

run the **mac-authen timer reauthenticate-period** command to set the re-authentication interval. The device then authenticates online users at the specified interval, ensuring that only authorized users can keep online.

If the command is executed in the system view, the function takes effect on all interfaces. If the command is executed in both system view and interface view, the function takes effect on the interface.

NOTE

It is recommended that the re-authentication interval be set to the default value. If multiple ACLs need to be delivered during user authorization, you are advised to disable the re-authentication function or set a longer re-authentication interval to improve the device's processing performance.

In remote authentication and authorization, if the re-authentication interval is set to a shorter time, the CPU usage may be higher.

To reduce the impact on the device performance when many users exist, the user re-authentication interval may be longer than the configured re-authentication interval.

Example

```
# Set the re-authentication interval for online MAC address authentication users to 3600 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] mac-authen timer reauthenticate-period 3600
```

Related Topics

[13.5.88 mac-authen](#)

[13.5.96 mac-authen reauthenticate](#)

13.5.101 mac-authen username

Function

The **mac-authen username** command configures the user name format for MAC address authentication.

The **undo mac-authen username** restores the default user name format.

By default, the MAC address without hyphens (-) is used as the user name and password for MAC address authentication.

NOTE

Only S5720EI, S1720X, S1720X-E, S5720HI, S5720S-SI, S5720SI, S5730S-EI, S5730SI, S6720LI, S6720S-LI, S6720S-SI, S6720SI, S6720EI, and S6720S-EI support configuration of MAC address authentication on VLANIF interfaces.

Format

```
mac-authen username { fixed username [ password cipher password ] |  
macaddress [ format { with-hyphen [ normal ] | without-hyphen }  
[ uppercase ] [ password cipher password ] } | dhcp-option option-code  
{ circuit-id | remote-id } * [ separate separate ] [ format-hex ] password cipher  
password }
```

```
undo mac-authen username [ fixed username [ password cipher password ] |  
macaddress [ format { with-hyphen [ normal ] | without-hyphen }  
[ uppercase ] [ password cipher password ] ] | dhcp-option option-code  
[ password cipher password ] ]
```

Parameters

Parameter	Description	Value
fixed <i>username</i>	Specifies the fixed user name for MAC address authentication.	The value is a string of 1 to 64 case-sensitive characters without spaces. When double quotation marks are used around the string, spaces are allowed in the string.

Parameter	Description	Value
<p>password cipher <i>password</i></p>	<p>Specifies the password displayed in cipher text for MAC address authentication.</p> <ul style="list-style-type: none"> • The user with a fixed name can log in without a password if no password is set. This brings a security risk and is not recommended. • When a MAC address is used as the user name, the MAC address can be used as the password if no password is set. When local authentication is specified in the AAA authentication scheme, you must set a password. • If the DHCP option is used as the user name, you must set a password. <p>NOTE If fixed user names are configured in the VLANIF interface view, Eth-Trunk interface view or port group view, the password must be set.</p> <p>If a MAC address is configured as the user name in the port group view, the password cannot be set.</p>	<p>The value is a case-sensitive string without question marks (?) or spaces. The password contains 1 to 128 characters in plain text or 48 to 188 characters in cipher text. When double quotation marks are used around the string, spaces are allowed in the string.</p> <p>NOTE For security purposes, it is recommended that the password contains at least two types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 6 characters.</p>
<p>macaddress</p>	<p>Specifies that the user name in MAC address authentication is the MAC address.</p>	<p>-</p>

Parameter	Description	Value
format { with-hyphen [normal] without-hyphen }	Specifies the MAC address format. <ul style="list-style-type: none"> • with-hyphen: indicates that the MAC address contains hyphens (-), for example, 0005-e01c-02e3. • with-hyphen normal: indicates that the MAC address contains hyphens (-), for example, 00-05-e0-1c-02-e3. • without-hyphen: indicates that the MAC address does not contain hyphens (-), for example, 0005e01c02e3. 	-
uppercase	Indicates that the name of a MAC address authentication user is in uppercase.	-

Parameter	Description	Value
dhcp-option <i>option-code</i>	<p>Specifies the name of the MAC address authentication user to a specified DHCP option.</p> <ul style="list-style-type: none"> • circuit-id: Specifies the circuit ID in the DHCP Option82 field as the user name in MAC address authentication. • remote-id: Specifies the remote ID in the DHCP Option82 field as the user name in MAC address authentication. <p>If both circuit-id and remote-id are configured, the user name for MAC address authentication can be set to a character string that is a combination of the circuit-id and remote-id in the DHCP Option82 field.</p> <p>NOTE In VLANIF interface view, the parameter does not support.</p>	The value is an integer. In the current version, the value is fixed as 82.
separate <i>separate</i>	<p>Specifies the delimiter in the user name for MAC address authentication. This parameter is configured when the user name for MAC address authentication is set to a character string that is a combination of the circuit-id and remote-id in the DHCP Option82 field.</p>	The value is a character and can be set to a letter, digit, or another valid character.
format-hex	<p>Indicates that the user name for MAC address authentication is in hexadecimal format.</p>	-

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

MAC address authentication uses three user name formats:

- When the MAC address is used as the user name for MAC address authentication, the password can be the MAC address or a self-defined character string.
- When the fixed user name is used for MAC address authentication, the user uses the fixed user name and password set by the administrator for authentication.
- When the DHCP option format is used for MAC address authentication, the device uses the DHCP option it obtains and password set by the administrator for authentication. In this mode, ensure that the device supports MAC address authentication triggered through DHCP packets.

By default, the device uses the user's MAC address as the user name and password, and sends the MAC address to the authentication server for authentication. Therefore, it is inconvenient to identify and manage users. You can run the **mac-authen username** command to configure the fixed name and password for MAC address authentication users, which facilitates user identification and management.

NOTE

When the user names for MAC address authentication are in the DHCP option format, the DHCP Option82 cannot be configured in the extend format or a customized format (non-character string) by using the [14.8.6 dhcp option82 format](#) command.

When the user name format in MAC address authentication is configured, ensure that the authentication server supports this format.

Example

Configure the user name to **vipuser** and the password to **pass123** for MAC address authentication.

```
<HUAWEI> system-view  
[HUAWEI] mac-authen username fixed vipuser password cipher pass123
```

Related Topics

[13.5.38 display mac-authen](#)

[13.5.91 mac-authen domain](#)

13.5.102 parameter

Function

The **parameter** command sets the characters used in URL.

The **undo parameter** command restores the default characters.

By default, the start character is ?, assignment character is =, and delimiter is &.

Format

parameter { **start-mark** *parameter-value* | **assignment-mark** *parameter-value* | **isolate-mark** *parameter-value* } *

undo parameter { **start-mark** *parameter-value* | **assignment-mark** *parameter-value* | **isolate-mark** *parameter-value* } *

Parameters

Parameter	Description	Value
start-mark <i>parameter-value</i>	Changes the specified start character to ?.	The value is one case-sensitive character, with spaces and double quotation marks (") not supported.
assignment-mark <i>parameter-value</i>	Specifies the assignment character of the URL parameters.	The value is one case-sensitive character, with spaces and double quotation marks (") not supported.
isolate-mark <i>parameter-value</i>	Specifies the delimiter between URL parameters.	The value is one case-sensitive character, with spaces and double quotation marks (") not supported.

Views

URL template view

Default Level

2: Configuration level

Usage Guidelines

The **parameter** command allows you to customize the characters in URL.

For example, if the URL configured by the [13.5.151 url \(URL template view\)](#) command in the URL template bound to a Portal server template is http://10.1.1.1, you can add the user MAC address, user IP address, and device system name to the URL by specifying the `user_mac`, `user_ip`, and `device` parameters.

When a user with IP address 10.1.1.11 and MAC address 0002-0002-0002 connects to an access device **huawei**, the access device redirects the user to http://10.1.1.1?user_mac=0002-0002-0002&user_ip=10.1.1.11&device=huawei for Portal authentication. In the redirection URL, ? is the default start character, = is the default assignment character, & is the delimiter between parameters.

Example

Change the start character in a URL from # to ?.

```
<HUAWEI> system-view  
[HUAWEI] url-template name huawei  
[HUAWEI-url-template-huawei] parameter start-mark #
```

13.5.103 port connection-type access

Function

The **port connection-type access** command configures the specified interfaces as downlink interfaces.

The **undo port connection-type access** command configures the specified interfaces as uplink interfaces.

Format

port { *interface-type start-interface-number* [**to** *interface-type end-interface-number*] } &<1-10> **connection-type access**

undo port { *interface-type start-interface-number* [**to** *interface-type end-interface-number*] } &<1-10> **connection-type access**

Parameters

Parameter	Description	Value
<i>interface-type start-interface-number</i> [to <i>interface-type end-interface-number</i>]	<p>Specifies interfaces.</p> <ul style="list-style-type: none"> • <i>interface-type</i> specifies the interface type. • <i>start-interface-number</i> specifies the number of the first interface. • <i>end-interface-number</i> specifies the number of the last interface. <p>If the to <i>interface-type end-interface-number</i> parameter is not specified, only the interfaces specified by <i>start-interface-number</i> are created. You can specify 10 interface ranges at one time.</p>	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

By default, downlink interfaces are access ones and uplink interfaces are non-access ones. You can run the **port connection-type access** or **undo port connection-type access** command to modify the interface access type. For example, you can batch configure the downlink interfaces supported by the device, and run the [13.5.68 dot1x mac-bypass access-port](#) command to enable MAC address bypass authentication on all the downlink interfaces.

After the default interface access type is modified, the device generates the interface buildrun information in the system view.

Precautions

If stack interface information exists within the interface range, the command does not take effect. Therefore, there should be no interface with stack configuration in the interface range. If the access type of an interface is changed, stack

configuration cannot be performed for the interface. That is, if an interface needs to be configured as a stack interface, the default interface access type cannot be modified.

Example

```
# Configure interfaces as downlink interfaces in the system view.
```

```
<HUAWEI> system-view  
[HUAWEI] port GigabitEthernet 0/0/1 to GigabitEthernet 0/0/6 connection-type access
```

Related Topics

[13.5.40 display port connection-type access all](#)

13.5.104 port (Portal server template view)

Function

The **port** command sets the port number that a Portal server uses to receive notification packets from the device.

The **undo port** command restores the default port number.

By default, a Portal server uses port number 50100 to receive packets from the device.

Format

```
port port-number [ all ]
```

```
undo port [ all ]
```

Parameters

Parameter	Description	Value
<i>port-number</i>	Specifies the port number that the Portal server uses to receive and encapsulate UDP packets from the device.	The value is an integer that ranges from 1 to 65535. By default, the value is 50100.

Parameter	Description	Value
all	<p>Indicates that the device always uses the destination port number specified by port-number to encapsulate UDP packets.</p> <p>NOTE</p> <p>After this keyword is specified, when receiving UDP packets from a Portal server, the device does not obtain the source port number in the UDP packets as the destination port number of UDP packets to be sent to the Portal server. If the value of <i>port-number</i> is different from the source port number of the Portal server, the Portal server cannot receive the UDP packets sent by the device. Therefore, this keyword is not recommended.</p>	-

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After creating a Portal server template on the device using the [13.5.167 web-auth-server \(system view\)](#) command, configure parameters for the template.

Run the **port** command to set the port number that a Portal server uses to receive notification packets from the device. After receiving a Portal authentication request packet from a user, the device sends the packet to the Portal server using the specified destination port number.

Precautions

Ensure that the port number configured on the device is the same as that used by the Portal server.

Example

Set the port number that a Portal server uses to receive packets from the device to 10000 in the Portal server template **huawei**.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] port 10000
```

Related Topics

[13.5.56 display web-auth-server configuration](#)

[13.5.167 web-auth-server \(system view\)](#)

13.5.105 portal auth-network

Function

The **portal auth-network** command configures a source subnet for Portal authentication.

The **undo portal auth-network** command restores the default source subnet for Portal authentication.

By default, the source subnet for Portal authentication is 0.0.0.0/0, indicating that users in all subnets must pass Portal authentication.

Format

portal auth-network *network-address* { *mask-length* | *mask-address* }

undo portal auth-network { *network-address* { *mask-length* | *mask-address* } | **all** }

Parameters

Parameter	Description	Value
<i>network-address</i>	Specifies the IP address of the source subnet for Portal authentication.	The value is in dotted decimal notation.
<i>mask-length</i>	Specifies the mask length.	The value is an integer that ranges from 1 to 32.
<i>mask-address</i>	Specifies the mask of the source subnet for Portal authentication.	The value is in dotted decimal notation.
all	Deletes all Portal authentication subnets.	-

Views

GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, VLANIF interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the source subnet for Portal authentication is configured, only user packets from the source subnet can trigger Portal authentication. If an unauthenticated user is not on the source subnet for Portal authentication, the device discards the user's packets that do not match Portal authentication free rules.

 NOTE

The command cannot be run on Layer 2 interfaces.

The **portal auth-network** command takes effect only for Layer 3 Portal authentication. In Layer 2 authentication, users on all network segments must be authenticated.

Prerequisites

Before running this command on an interface, ensure that the Portal service template is bound to the interface.

Example

Set the source subnet for Portal authentication to 192.168.1.0/24 on VLANIF10.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] server-ip 10.1.1.1
[HUAWEI-web-auth-server-huawei] quit
[HUAWEI] interface vlanif 10
[HUAWEI-Vlanif10] web-auth-server huawei layer3
[HUAWEI-Vlanif10] portal auth-network 192.168.1.0 24
```

Set the source subnet for Portal authentication to 192.168.1.0/24 on Layer 3 interface GE0/0/1.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] server-ip 10.1.1.1
[HUAWEI-web-auth-server-huawei] quit
[HUAWEI] interface gigabitethernet0/0/1
[HUAWEI-GigabitEthernet0/0/1] undo portswitch
[HUAWEI-GigabitEthernet0/0/1] web-auth-server huawei layer3
[HUAWEI-GigabitEthernet0/0/1] portal auth-network 192.168.1.0 24
```

13.5.106 portal domain

Function

The **portal domain** specifies a forcible Portal authentication domain.

The **undo portal domain** command deletes a forcible Portal authentication domain.

By default, no forcible Portal authentication domain is specified.

Format

portal domain *domain-name*

undo portal domain

Parameters

Parameter	Description	Value
<i>domain-name</i>	Specifies the forcible Portal authentication domain.	The value is a string of 1 to 64 case-insensitive characters without any space, asterisk (*), question mark (?), or quotation mark (").

Views

GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, VLANIF interface view

Default Level

2: Configuration level

Usage Guidelines

To flexibly deploy access policies for Portal authentication users, the administrator can run the **portal domain** command to configure a forcible Portal authentication domain.

After a forcible Portal authentication domain is configured on an interface, the device uses the specified authentication domain to authenticate, authorize, and charge Portal authentication users on the interface, ignoring the domain names carried in the user names. The administrator can specify different authentication domains for different interfaces as needed.

NOTE

The command cannot be run on Layer 2 interfaces.

Example

```
# Set the forcible Portal authentication domain to abc on VLANIF 10.
<HUAWEI> system-view
[HUAWEI] interface vlanif 10
[HUAWEI-Vlanif10] portal domain abc

# Set the forcible Portal authentication domain to abc on Layer 3 interface
GEO/0/1.
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet0/0/1
[HUAWEI-GigabitEthernet0/0/1] undo portswitch
[HUAWEI-GigabitEthernet0/0/1] portal domain abc
```

13.5.107 portal free-rule

Function

The **portal free-rule** command configures the Portal authentication-free rule for users.

The **undo portal free-rule** command restores the default configuration.

By default, no Portal authentication-free rule is configured.

Format

```
portal free-rule rule-id { destination { any | ip { ip-address mask { mask-length | ip-mask } } [ tcp destination-port port | udp destination-port port ] | any } } | source { any | { interface interface-type interface-number | ip { ip-address mask { mask-length | ip-mask } } | any } | vlan vlan-id } * } }
```

portal free-rule *rule-id* **source ip** *ip-address* **mask** { *mask-length* | *ip-mask* }
[**mac** *mac-address*] [**interface** *interface-type interface-number*] **destination**
user-group *group-name*

undo portal free-rule { *rule-id* | **all** }

Parameters

Parameter	Description	Value
<i>rule-id</i>	Specifies the ID of the Portal authentication-free rule.	The value is an integer of which the range depends on product models.
destination	Specifies the destination network resources that the authentication-free users can access.	-
source	Specifies the source information of the authentication-free users.	-
any	Specifies any condition. When any is used together with different keywords, the effect of the command is different.	-
ip <i>ip-address</i>	Specifies the IP address in the rule. This parameter can specify the source or destination address depending on the keyword.	The value is in dotted decimal notation.
mask <i>mask-length</i>	Specifies the mask length of an IP address. This parameter can specify the source or destination address mask depending on the keyword.	The value is an integer that ranges from 1 to 32.
mask <i>ip-mask</i>	Specifies the IP address mask. This parameter can specify the source or destination address mask depending on the keyword.	The value is in dotted decimal notation.
tcp destination-port <i>port</i>	Specifies the TCP destination port number.	The value is an integer that ranges from 1 to 65535.
udp destination-port <i>port</i>	Specifies the UDP destination port number.	The value is an integer that ranges from 1 to 65535.

Parameter	Description	Value
interface <i>interface-type</i> <i>interface-number</i>	Specifies the type and number of the source interface in the rule. <ul style="list-style-type: none"> • <i>interface-type</i> specifies the interface type. • <i>interface-number</i> specifies the interface number. 	-
vlan <i>vlan-id</i>	Specifies the VLAN ID of the source packet in the rule.	The value is an integer that ranges from 1 to 4094.
all	Specifies all rules.	-
mac <i>mac-address</i>	Specifies the MAC address of the Portal authentication user who is allowed to access destination network resources without authentication.	The value is in H-H-H format. An H is a hexadecimal number of 1 to 4 digits.
user-group <i>group-name</i>	Allows Portal authentication users to access the network resources in the user group.	It is a string of 1 to 64 case-sensitive characters without spaces.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A user cannot access the network before being authenticated successfully. You can configure an authentication-free rule for specified users to access certain network resources without passing the Portal authentication. An authentication-free rule can be determined by parameters such as the IP address, MAC address, interface, and VLAN. An authentication-free rule can also be determined by ACL rules. The destination IP address that users can access without authentication can be specified in an authentication-free rule defined by either of the two methods. In addition, the destination domain name that users can access without authentication can be specified in an authentication-free rule defined by ACL.

For example, some authentication users who do not have an authentication account must first log in to the official website of a carrier and apply for a member account, or log in using the account of a third party such as Twitter or

Facebook. This requires that the users can access specified websites before successful authentication. The domain name of a website is easier to remember than the IP address; therefore, the authentication-free rule defined by ACL can be configured to enable the users to access the domain names of websites without authentication.

Precautions

- When multiple authentication-free rules are configured, the system matches the rules one by one.
- If the **vlan** parameter determines where users reside for an authentication-free rule, the Portal server must have been bound to the VLANIF interface of the VLAN using the **13.5.164 web-auth-server (interface view)** command; otherwise, the configured authentication-free rule does not take effect for users in the VLAN.
- If you specify both VLAN and interface when running the **portal free-rule** command, the interface must belong to the VLAN; otherwise, the configuration is invalid.
- If you specify the destination port number in an authentication-free rule, fragmented packets cannot match the rule and cannot be forwarded.
- You can only add or delete rules, but cannot modify the created rules. To modify a rule with a certain *rule-id*, run the **undo portal free-rule** command to delete the rule and re-configure it.
- To allow Portal authentication users to access the network resources in the user group, pay attention to the following points:
 - The user group has been created before it is referenced by the Portal authentication-free rule.
 - The Portal authentication-free rule takes effect only after the referenced user group is enabled.
 - A user can only join one user group. If multiple rules are configured, the rule with the smallest *rule-id* has the highest priority.
 - If multiple rules are applied to a user, the Portal authentication-free rule referencing the user group has the highest priority.
 - The rule of the user group can only contain whitelists. That is, the deny action cannot be used.
 - After configuring authorization for a user using the **destination user-group *group-name*** command, you cannot configure authorization in other modes for the user.
- If a user fails built-in Portal authentication on a Layer 2 interface of the device (excluding the S5720HI), the user cannot obtain network access rights defined by the Portal authentication-free rule.

Example

Enable all Portal users to access the network 10.1.1.1/24 without authentication.

```
<HUAWEI> system-view  
[HUAWEI] portal free-rule 1 destination ip 10.1.1.1 mask 24 source ip any
```

Add the devices on network segment 10.2.100.0/24 to the user group static-user and allow the devices to access all network resources without authentication.

```
<HUAWEI> system-view
[HUAWEI] acl number 3100
[HUAWEI-acl-adv-3100] rule 5 permit ip source 10.2.100.0 255.255.255.0
[HUAWEI-acl-adv-3100] quit
[HUAWEI] user-group static-user
[HUAWEI-user-group-static-user] acl-id 3100
[HUAWEI-user-group-static-user] quit
[HUAWEI] user-group static-user enable
[HUAWEI] portal free-rule 0 source ip 10.2.100.0 mask 24 destination user-group static-user
```

Related Topics

- [13.5.42 display portal free-rule](#)
- [13.5.164 web-auth-server \(interface view\)](#)
- [13.5.156 user-group](#)
- [13.5.157 user-group enable](#)

13.5.108 portal local-server

Function

The **portal local-server** command enables the built-in Portal server function.

The **undo portal local-server** command disables the built-in Portal server function.

By default, the built-in Portal server function is disabled.

Format

portal local-server https ssl-policy *policy-name* [port *port-num*]

undo portal local-server https

Parameters

Parameter	Description	Value
https	Configures the built-in Portal server to use HTTPS to exchange authentication information with users.	-
ssl-policy <i>policy-name</i>	Specifies the SSL policy used by the built-in Portal server. NOTE <i>policy-name</i> indicates an existing SSL policy.	The value of <i>policy-name</i> is a string of 1 to 23 case-sensitive characters without spaces.

Parameter	Description	Value
port <i>port-num</i>	Specifies the TCP port number used by HTTPS. The default port number is used if the parameter is not specified.	The value is an integer that ranges from 443 or 1025 to 55535. The default port number is 443.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Compared with the external Portal server, the built-in Portal server is easy to use, cost-effective, and easy to maintain. After the built-in Portal server is configured, the external Portal authentication server is not required. When you run the **portal local-server** command to enable the built-in Portal server function, configure the built-in Portal server to use HTTPS to exchange authentication information with users. HTTPS is a combination of the HTTP and Secure Sockets Layer (SSL) protocols. If the built-in Portal server is configured to use HTTPS to exchange authentication information with users, an SSL policy must be configured and the digital certificate must be loaded.

NOTE

You can run the [13.5.114 portal local-server enable](#) command to enable the Portal authentication function on the interface only after the built-in Portal server function is enabled.

Prerequisites

- The IP address for the built-in Portal server has been configured using the [13.5.115 portal local-server ip](#) command.
- An SSL policy has been created using the [ssl policy policy-name](#) command in the system view and the digital certificate has been loaded using the [certificate load](#) command in the SSL policy view.
- Apply to a trusted certificate authority for the certificate that needs to be loaded for the SSL policy.

Precautions

- When there are online Portal authentication users, the built-in Portal server function cannot be disabled globally and the SSL policy of the built-in Portal server cannot be modified.
- The SSL policy referenced by the built-in Portal server cannot be deleted.

- After the built-in Portal server function is enabled globally, the guest VLAN, critical VLAN, or restrict VLAN cannot be created.

Example

Enable the built-in Portal server function and set the SSL policy used by the built-in Portal server to abc.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server https ssl-policy abc
```

Related Topics

[13.5.43 display portal local-server](#)

13.5.109 portal local-server ad-image load

Function

The **portal local-server ad-image load** command loads an advertisement image file to the built-in Portal server login page.

The **undo portal local-server ad-image load** command deletes the advertisement image file loaded to the built-in Portal server login page.

By default, no advertisement image file is loaded to the built-in Portal server login page.

Format

portal local-server ad-image load *ad-image-file*

undo portal local-server ad-image load

Parameters

Parameter	Description	Value
<i>ad-image-file</i>	<p>Specifies the name of an advertisement image file to be loaded to the built-in Portal server login page.</p> <p>The size of the advertisement image file must be equal to or less than 256 KB. A file of 670 x 405 pixels is recommended.</p>	<p>The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i>.</p> <ul style="list-style-type: none">• <i>drive</i>: indicates the storage device name.• <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~, *, /, \, :, ', and ".• <i>filename</i>: indicates the file name. The jpg and png formats are supported, and the file name extension must be .jpg, .jpeg, or .png. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

There is a blank area on the login page of the default page package used by the built-in Portal server. Users can customize this area by loading an advertisement image file. When the login page needs to be customized based on special requirements, the administrator can upload the user-defined advertisement image file to the device and run the **portal local-server ad-image load** command. After the advertisement image file is loaded, the user-defined advertisement images are displayed on the built-in Portal server login page for authentication.

Prerequisites

The user-defined advertisement image file must have been uploaded to the device.

Example

Load the advertisement image file **ad.png** to the built-in Portal server login page.

```
<HUAWEI> system-view
[HUAWEI] portal local-server ad-image load flash:/ad.png
Info: The loading process may take a few seconds.Please wait for a moment.
Info: Load web file successfully.
```

13.5.110 portal local-server anonymous

Function

The **portal local-server anonymous** command enables anonymous login for users in built-in Portal authentication.

The **undo portal local-server anonymous** command disables anonymous login for users in built-in Portal authentication.

By default, anonymous login for users in built-in Portal authentication is disabled.

Format

portal local-server anonymous
undo portal local-server anonymous

Parameters

None

Views

VLANIF interface view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To provide convenient network services for users in airports, hotels, cafes, or civil entertainment squares, the anonymous login function can be enabled so that the users can access the network without entering user names and passwords.

After anonymous login for users in built-in Portal authentication is enabled, users are redirected to the login page when they log in to the web page for the first

time. To connect to the network, the users only need to accept the agreements, and click **Login**.

Precautions

When anonymous login is configured, it is recommended that you set AAA authentication mode to none authentication.

Example

```
# Enable anonymous login for users in built-in Portal authentication on VLANIF10.
```

```
<HUAWEI> system-view  
[HUAWEI] interface vlanif 10  
[HUAWEI-Vlanif10] portal local-server anonymous
```

Related Topics

[13.5.114 portal local-server enable](#)

13.5.111 portal local-server authentication-method

Function

The **portal local-server authentication-method** command configures the authentication mode for Portal users on the built-in Portal server.

The **undo portal local-server authentication-method** command restores the default authentication mode for Portal users on the built-in Portal server.

By default, the built-in Portal server uses CHAP to authenticate Portal users.

Format

```
portal local-server authentication-method { chap | pap }
```

```
undo portal local-server authentication-method
```

Parameters

Parameter	Description	Value
chap	Indicates that the built-in Portal server uses CHAP to authenticate Portal users.	-
pap	Indicates that the built-in Portal server uses PAP to authenticate Portal users.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Password Authentication Protocol (PAP) is a two-way handshake authentication protocol. It transmits passwords in plain text format in RADIUS packets.

Challenge Handshake Authentication Protocol (CHAP) is a three-way handshake authentication protocol. It transmits only user names using RADIUS packets, but does not transmit passwords. CHAP is more secure and reliable than PAP. If high security is required, CHAP is recommended.

Prerequisites

The built-in Portal server function has been enabled globally using the [portal local-server](#) command.

Example

Configure the built-in Portal server to use PAP to authenticate Portal users.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server authentication-method pap
```

Related Topics

[13.5.43 display portal local-server](#)

13.5.112 portal local-server background-color

Function

The **portal local-server background-color** command configures the background color of the built-in Portal server login page.

The **undo portal local-server background-color** command cancels the background color configured for the built-in Portal server login page.

By default, no background color of the built-in Portal server login page is configured.

Format

portal local-server background-color *background-color-value*

undo portal local-server background-color

Parameters

Parameter	Description	Value
<i>background-color-value</i>	Specifies the background color of the built-in Portal server login page.	The value is a string that ranges from #000000 to #FFFFFF in the RGB format. The hexadecimal code is used to indicate the page color, and the format is always #DEFABC (A-F and 0-9).

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Users can customize the login page of the default page package used by the built-in Portal server. The administrator can configure the background color of the login page.

Example

Configure the user-defined background color of the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server background-color #AABBCC
```

13.5.113 portal local-server background-image load

Function

The **portal local-server background-image load** command loads a background image file to the built-in Portal server login page.

The **undo portal local-server background-image load** command deletes the background image file loaded to the built-in Portal server login page.

By default, the device has two background images **default-image0** and **default-image1**. The built-in Portal server uses **default-image0** as the background image by default.

Format

```
portal local-server background-image load { background-image-file | default-image1 }
```

undo portal local-server background-image load

Parameters

Parameter	Description	Value
<i>background-image-file</i>	<p>Specifies the name of the background image file to be loaded to the built-in Portal server login page.</p> <p>The size of the background image file must be equal to or less than 512 KB. A file of 1366 x 768 pixels is recommended.</p>	<p>The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i>.</p> <ul style="list-style-type: none"> • <i>drive</i>: indicates the storage device name. • <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~, *, /, \, :, ', and ". • <i>filename</i>: indicates the file name. The jpg and png formats are supported, and the file name extension must be .jpg, .jpeg, or .png. If you enter only the file name, the system considers that the file is stored in the default directory.
default-image1	<p>Loads the background image default-image1 to the built-in Portal server login page.</p>	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Users can customize the login page of the default page package used by the built-in Portal server. Users can customize background images or select the default ones. When the background image of the login page needs to be customized based on special requirements, the administrator can upload the user-defined background image file to the device and run the **portal local-server background-image load** command. After the image is loaded, the user-defined background image file is displayed on the built-in Portal server login page for authentication.

Prerequisites

The user-defined background image must have been uploaded to the device.

Example

Load the background image file **bg.png** to the built-in Portal server login page.

```
<HUAWEI> system-view
[HUAWEI] portal local-server background-image load flash:/bg.png
Info: The loading process may take a few seconds.Please wait for a moment.
Info: Load web file successfully.
```

13.5.114 portal local-server enable

Function

The **portal local-server enable** command enables built-in Portal authentication on an interface.

The **undo portal local-server enable** command disables built-in Portal authentication on an interface.

By default, built-in Portal authentication is disabled on an interface.

Format

In the system view:

```
portal local-server enable interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

```
undo portal local-server enable interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

In the interface view:

```
portal local-server enable
```

```
undo portal local-server enable
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number.	-

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Compared with the external Portal server, the built-in Portal server is easy to use, cost-effective, and easy to maintain. After built-in Portal authentication is enabled, the external Portal server is not required. After the built-in Portal server function is enabled using the [13.5.108 portal local-server](#) command, built-in Portal authentication must be enabled on the interface using the **portal local-server enable** command to authenticate users on the interface.

Prerequisites

Portal authentication has been enabled globally using the [portal local-server](#) command.

Precautions

It is recommended that you enable built-in Portal authentication on a VLANIF interface. The VLANIF interface of a super-VLAN does not support built-in Portal authentication.

Built-in Portal authentication of Layer 3 interfaces cannot be configured using this command in the system view.

If 802.1X authentication, MAC address authentication, MAC address bypass authentication or built-in Portal authentication is enabled on a Layer 2 interface, this command cannot be executed on the VLANIF interface of a VLAN to which the Layer 2 interface is added.

The **portal local-server enable** command cannot be used together with the following commands on the same interface.

Command	Function
mac-vlan enable	Enables MAC address-based VLAN assignment on an interface.
ip-subnet-vlan enable	Enables IP subnet-based VLAN assignment on an interface.

Example

Enable built-in Portal authentication on VLANIF 10.

```
<HUAWEI> system-view
[HUAWEI] interface loopback 1
[HUAWEI-LoopBack1] ip address 10.1.1.1 24
[HUAWEI-LoopBack1] quit
[HUAWEI] portal local-server ip 10.1.1.1
[HUAWEI] ssl policy s1
[HUAWEI-ssl-policy-s1] pki-realm default
[HUAWEI-ssl-policy-s1] quit
[HUAWEI] http secure-server ssl-policy s1
[HUAWEI] portal local-server https ssl-policy s1 port 1025
[HUAWEI] vlan batch 10
[HUAWEI] interface vlanif 10
[HUAWEI-Vlanif10] portal local-server enable
```

Related Topics

[13.5.43 display portal local-server](#)

13.5.115 portal local-server ip

Function

The **portal local-server ip** command configures an IP address for the built-in Portal server.

The **undo portal local-server ip** command deletes an IP address of the built-in Portal server.

By default, no IP address is configured for the built-in Portal server.

Format

portal local-server ip *ip-address*

undo portal local-server ip

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies an IP address for the built-in Portal server.	The value is in dotted decimal notation.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When the device is used as a built-in Portal server, you can run the **portal local-server ip** command to configure an IP address for the built-in Portal server. Users are then redirected to the Portal server if they enter URLs that are not located in the free IP subnet.

NOTE

- The IP address assigned to the built-in Portal server must have a reachable route to the user.
- It is recommended that a loopback interface address be assigned to the built-in Portal server because the loopback interface is stable. Additionally, packets destined for loopback interfaces are not sent to other interfaces on the network; therefore, system performance is not deteriorated even if many users request to go online.
- After users go online through the built-in Portal server, if the interface address or interface (non-physical interface) matching the built-in Portal server's IP address is deleted, online users cannot go offline and offline users cannot go online. Therefore, exercise caution when you delete the interface address or interface.

Example

Assign the IP address 10.1.1.1 to the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server ip 10.1.1.1
```

Related Topics

[13.5.43 display portal local-server](#)

13.5.116 portal local-server keep-alive

Function

The **portal local-server keep-alive** command configures the heartbeat detection interval and mode of the built-in Portal server.

The **undo portal local-server keep-alive** command cancels the configured heartbeat detection interval and mode of the built-in Portal server.

By default, the heartbeat detection function of the built-in Portal server is not configured.

Format

portal local-server keep-alive interval *interval-value* [**auto**]
undo portal local-server keep-alive

Parameters

Parameter	Description	Value
interval <i>interval-value</i>	Specifies the heartbeat detection interval of the built-in Portal server.	The value is an integer that ranges from 30 to 7200, in seconds.
auto	Specifies the automatic detection mode. If this parameter is not configured, the forcible detection mode is specified.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When a user closes the browser or an exception occurs, the device can detect the user's online state to determine whether to make the user go offline. The administrator can configure the heartbeat detection function of the built-in Portal server. If the device does not receive a heartbeat packet from the client within a specified period, the user is specified to go offline. The heartbeat detection mode of the built-in Portal server can be either of the following modes:

- Forcible detection mode: This mode is valid for all users. If the device does not receive a heartbeat packet from a user within a specified period, the device specifies the user to go offline.
- Automatic detection mode: The device checks whether the client browser supports the heartbeat program. If yes, the forcible detection mode is used for the user; if no, the device does not detect the user. You are advised to configure this mode to prevent users from going offline because the browser does not support the heartbeat program.

 NOTE

Currently, the heartbeat program is supported by Internet Explorer 8, FireFox 3.5.2, Chrome 28.0.1500.72, and Opera 12.00 on Windows 7.

Browsers using Java1.7 and later versions do not support the heartbeat program.

Precautions

When the forcible detection mode is configured, the device specifies users to go offline to prevent from failing to receive heartbeat packets for a long time during network congestion. In this scenario, the heartbeat detection interval must be increased.

If you run this command multiple times in the same view, only the latest configuration takes effect.

Example

Configure the automatic detection function of the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server keep-alive interval 60 auto
```

13.5.117 portal local-server load

Function

The **portal local-server load** command loads a page file package to the built-in Portal server.

The **undo portal local-server load** command restores the default configuration.

By default, the built-in Portal server loads the default page file package **portalpage.zip**.

Format

portal local-server load *string*

undo portal local-server load

Parameters

Parameter	Description	Value
<i>string</i>	Specifies the name of the page file package to be loaded to the built-in Portal server.	The value is a string of 1 to 64 case-insensitive characters without any space, asterisk (*), question mark (?), or quotation mark (").

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Customized page file packages can be loaded to the built-in Portal server.

Prerequisites

The page file (.zip) has been uploaded from the PC to the device storage media.

Precautions

The default page file package can be modified but cannot be deleted. If it is deleted, the built-in Portal server fails to load the pages after startup.

This function is used by technical support personnel to develop limited page customization based on customer requirements and does not apply to customization by customers themselves.

Example

Load the page file **portalpage_01.zip** on the built-in Portal server.

```
<HUAWEI> system-view
[HUAWEI] portal local-server load portalpage_01.zip
Warning: Portal local server has been enabled, and this operation will affect online user, continue?[Y/N]:y
Info: The loading process may take a few seconds.Please wait for a moment
Info: Load web file successfully.
```

Related Topics

[13.5.45 display portal local-server page-information](#)

13.5.118 portal local-server logo load

Function

The **portal local-server logo load** command loads a logo file to the built-in Portal server login page.

The **undo portal local-server logo load** command deletes the logo file loaded to the built-in Portal server login page.

By default, no logo file is loaded to the built-in Portal server login page.

Format

portal local-server logo load *logo-file*

undo portal local-server logo load

Parameters

Parameter	Description	Value
<i>logo-file</i>	<p>Specifies the name of the logo file to be loaded to the built-in Portal server login page.</p> <p>The size of the logo file must be equal to or less than 128 KB. A file of 591 x 80 pixels is recommended.</p>	<p>The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i>.</p> <ul style="list-style-type: none"> • <i>drive</i>: indicates the storage device name. • <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~, *, /, \, :, ', and ". • <i>filename</i>: indicates the file name. The jpg and png formats are supported, and the file name extension must be .jpg, .jpeg, or .png. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

There is a blank area on the login page of the default page package used by the built-in Portal server. Users can customize this area by loading a logo file. When the login page needs to be customized based on special requirements, the administrator can upload the user-defined logo file to the device and run the **portal local-server logo load** command. After the logo file is loaded, the user-defined logo is displayed on the built-in Portal server login page for authentication.

Prerequisites

The user-defined logo file must have been uploaded to the device.

Example

Load the logo file **logo.png** to the built-in Portal server login page.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server logo load flash:/logo.png  
Info: The loading process may take a few seconds.Please wait for a moment.  
Info: Load web file successfully.
```

13.5.119 portal local-server page-text load

Function

The **portal local-server page-text load** command loads the use instruction page file of the built-in Portal server.

The **undo portal local-server page-text load** command deletes the loaded use instruction page file of the built-in Portal server.

By default, no use instruction page file of the built-in Portal server is loaded.

Format

portal local-server page-text load *string*

undo portal local-server page-text load

Parameters

Parameter	Description	Value
<i>string</i>	Specifies the use instruction page file of the built-in Portal server.	<p>The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [drive] [path] filename.</p> <ul style="list-style-type: none"> • drive indicates the storage device name. • path indicates the directory or sub-directory. The directory name cannot contain the following characters: ~ * / \ : ' " • filename indicates the file name. The file name extension must be .txt or .html. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If you need to customize the use instruction page, you can upload the customized use instruction page file to the device, and run this command to load the file. After the file is loaded, the hyperlink **Instruction for Use** is generated on the login page of the built-in Portal server, and users can click the hyperlink to access the use instruction page.

Prerequisite

The page file to be loaded has been uploaded to the device.

Precautions

When the to-be-loaded page is customized, the page length and width are fixed. After adjusting the page, the administrator must upload and load the modified page again.

Currently, only Chinese or English page files can be loaded on the device.

Example

Load the use instruction page file **page.html** to the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server page-text load flash:/page.html  
Info: The loading process may take a few seconds.Please wait for a moment.  
Info: Load web file successfully.
```

13.5.120 portal local-server policy-text load

Function

The **portal local-server policy-text load** command loads a disclaimer page file to the built-in Portal server.

The **undo portal local-server policy-text load** command deletes the loaded disclaimer page file.

By default, no disclaimer page file is loaded to the built-in Portal server.

Format

portal local-server policy-text load *string*

undo portal local-server policy-text load

Parameters

Parameter	Description	Value
<i>string</i>	Specifies the name of the disclaimer page file to be loaded to the built-in Portal server.	The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i> . <ul style="list-style-type: none">• <i>drive</i>: indicates the storage device name.• <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~, *, /, \, :, ', and ".• <i>filename</i>: indicates the file name. The file name extension must be .txt or .html. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To customize a disclaimer page, upload the disclaimer page file to the device and run this command to load the file. After the file is loaded, the hyperlink **Disclaimer** will be displayed on the login page. You can click the link to visit the disclaimer page.

Prerequisite

The disclaimer page file to be loaded has been uploaded to the device.

Precautions

Currently, only Chinese and English disclaimer page files can be loaded on the device.

Example

```
# Load the disclaimer page file policy.html to the built-in Portal server.
```

```
<HUAWEI> system-view  
[HUAWEI] portal local-server policy-text load policy.html  
Info: The loading process may take a few seconds.Please wait for a moment.  
Info: Load web file successfully.
```

13.5.121 portal local-server syslog-limit enable

Function

The **portal local-server syslog-limit enable** command enables the log suppression function for users authenticated through the built-in Portal server.

The **undo portal local-server syslog-limit enable** command disables the log suppression function for users authenticated through the built-in Portal server.

By default, the log suppression function is enabled for users authenticated through the built-in Portal server.

Format

```
portal local-server syslog-limit enable
```

```
undo portal local-server syslog-limit enable
```

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device generates logs when users authenticated through the built-in Portal server fail to go online or offline. If a user fails to go online or offline, the user attempts to go online or offline repeatedly, and the device generates a large number of logs within a short time. This results in a high failure rate in the statistics and degrades the system performance. You can run the **portal local-server syslog-limit enable** command to enable the log suppression function for users authenticated through the built-in Portal server. The device then only generates one log if a user fails to go online or offline within a suppression period (configured using the [13.4.159 portal local-server syslog-limit period](#) command).

Example

```
# Enable the log suppression function for users authenticated through the built-in  
Portal server.
```

```
<HUAWEI> system-view  
[HUAWEI] portal local-server syslog-limit enable
```

13.5.122 portal local-server syslog-limit period

Function

The **portal local-server syslog-limit period** command configures the log suppression period for users authenticated through the built-in Portal server.

The **undo portal local-server syslog-limit period** command restores the default log suppression period.

By default, the log suppression period is 300 seconds for users authenticated through the built-in Portal server.

Format

portal local-server syslog-limit period *value*

undo portal local-server syslog-limit period

Parameters

Parameter	Description	Value
<i>value</i>	Specifies the log suppression period for users authenticated through the built-in Portal server.	The value is an integer that ranges from 60 to 604800, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device generates logs when users authenticated through the built-in Portal server fail to go online or offline. If a user fails to go online or offline, the user attempts to go online or offline repeatedly, and the device generates a large number of logs within a short time. This results in a high failure rate in the statistics and degrades the system performance. You can enable the log suppression function (configured using the [13.4.158 portal local-server syslog-](#)

limit enable command) for users authenticated through the built-in Portal server. The device then only generates one log if a user fails to go online or offline within a suppression period.

Example

```
# Set the log suppression period to 1000 seconds for users authenticated through the built-in Portal server.
```

```
<HUAWEI> system-view  
[HUAWEI] portal local-server syslog-limit period 1000
```

13.5.123 portal local-server timer session-timeout

Function

The **portal local-server timer session-timeout** command configures the session timeout interval for built-in Portal authentication users.

The **undo portal local-server timer session-timeout** command restores the default session timeout interval for built-in Portal authentication users.

By default, the session timeout interval is 8 hours for built-in Portal authentication users.

Format

portal local-server timer session-timeout *interval*

undo portal local-server timer session-timeout

Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the session timeout interval for built-in Portal authentication users.	The value is an integer that ranges from 1 to 720, in hours.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Scenario

When built-in Portal authentication is used for users and the device functions as a built-in Portal server, you can configure the session timeout interval for the users.

The users are disconnected after the specified session timeout interval. To connect to the network again, the users need to be re-authenticated.

Precautions

The session timeout interval for built-in Portal authentication users is calculated based on the device time. For example, if the session timeout interval is 6 hours and the device time is 2014-09-01 02:00:00 when a user was connected, the user should be disconnected at 2014-09-01 08:00:00. Therefore, ensure that the device time is correct after the session timeout interval is configured for users. If the device time is incorrect, users may fail to be connected or disconnected properly. You can run the **display clock** command to check the device time and the **clock datetime** *HH:MM:SS YYYY-MM-DD* command to configure the time.

Example

Configure the session timeout interval to 10 hours for built-in Portal authentication users.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server timer session-timeout 10
```

Related Topics

[13.5.43 display portal local-server](#)

13.5.124 portal logout different-server enable

Function

The **portal logout different-server enable** command configures a device to process user logout requests sent by a Portal server other than the one from which users log in.

The **undo portal logout different-server enable** command restores the default configuration.

By default, a device does not process user logout requests sent by Portal servers other than the one from which users log in.

Format

portal logout different-server enable

undo portal logout different-server enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In a scenario where Portal server load balancing is configured, by default, a device does not process user logout requests sent by Portal servers other than the one from which users log in and responds ACK messages only to the Portal server from which users log in. Users in arrears then can still stay online. To prevent this problem, run **portal logout different-server enable** command to configure the device to process user logout requests sent by a Portal server other than the one from which users log in. Upon receipt of a user logout request from such a Portal server, the device starts a user logout process. After completing the logout event, the device responds an ACK message to the Portal server, thereby ensuring that the user logs out properly.

Precautions

The user logout requests that a device can process must be sent by Portal servers bound to an access interface. These servers include all the Portal servers configured in the master and backup Portal server templates bound to the interface.

Example

```
# Enable a device to process user logout requests a Portal server other than the one from which users log in.
```

```
<HUAWEI> system-view  
[HUAWEI] portal logout different-server enable
```

Related Topics

[13.5.41 display portal](#)

13.5.125 portal logout resend timeout

Function

The **portal logout resend timeout** command configures the re-transmission times and interval for the Portal authentication user logout packet.

The **undo portal logout resend timeout** command restores the default setting.

By default, the Portal authentication user logout packet can be re-transmitted three times within five seconds.

Format

portal logout resend *times* *timeout* *period*

undo portal logout { **resend** | **timeout** } *

Parameters

Parameter	Description	Value
<i>times</i>	Specifies the number of re-transmission times for the Portal authentication user logout packet.	The value is an integer that ranges from 0 to 15. The value 0 indicates that the re-transmission function is disabled.
<i>period</i>	Specifies the re-transmission interval of the Portal authentication user logout packet.	The value is an integer that ranges from 1 to 300, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After disconnecting a Portal authentication user, the device sends a user logout packet (NTF-LOGOUT) to instruct the Portal server to delete the user information. If the network between the device and Portal server is not stable or packets are lost, the Portal server may fail to receive the user logout packet from the device after the Portal authentication user is disconnected. In this case, the user is displayed as disconnected on the device but still as online on the Portal server. To enable the Portal server to receive the user logout packet and ensure that the online user information on the Portal server is correct, the administrator can enable the user logout packet re-transmission function on the device and configure the re-transmission times and interval.

Example

Configure the re-transmission times to 5 and interval to 10 seconds for the Portal authentication user logout packet.

```
<HUAWEI> system-view  
[HUAWEI] portal logout resend 5 timeout 10
```

Related Topics

[13.5.41 display portal](#)

[13.5.47 display portal user-logout](#)

13.5.126 portal max-user

Function

The **portal max-user** command sets the maximum number of concurrent Portal authentication users allowed to access the device.

The **undo portal max-user** command restores the default maximum number of concurrent Portal authentication users.

By default, the number of Portal authentication users is the maximum number of Portal authentication users supported by the device.

Format

portal max-user *user-number*

undo portal max-user

Parameters

Parameter	Description	Value
<i>user-number</i>	Specifies the maximum number of concurrent Portal users.	The value is an integer that varies depending on product models.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

You can run the **portal max-user** command to set the maximum number of concurrent Portal authentication users.

Example

Set the maximum number of concurrent Portal authentication users to 25.

```
<HUAWEI> system-view  
[HUAWEI] portal max-user 25
```

13.5.127 portal quiet-period

Function

The **portal quiet-period** command enables the quiet timer for Portal authentication.

The **undo portal quiet-period** command disables the quiet timer of Portal authentication.

By default, the quiet timer for Portal authentication is enabled.

Format

portal quiet-period

undo portal quiet-period

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the **portal quiet-period** command is used to enable the quiet timer for Portal authentication. If the number of Portal authentication failures exceeds the value specified by the [13.5.128 portal quiet-times](#) command, the device keeps the Portal authentication user in quiet state for a period of time. During the quiet period, the device discards Portal authentication requests from the user. This prevents the impact of frequent authentications on the system.

The quiet period for Portal authentication can be set using the [13.5.130 portal timer quiet-period](#) command. After the quiet period is reached, the device re-authenticates the user.

Example

```
# Enable the quiet timer for Portal authentication.
```

```
<HUAWEI> system-view  
[HUAWEI] portal quiet-period
```

Related Topics

[13.5.128 portal quiet-times](#)

[13.5.130 portal timer quiet-period](#)

[13.5.46 display portal quiet-user](#)

13.5.128 portal quiet-times

Function

The **portal quiet-times** command sets the maximum number of authentication failures within 60s before a Portal authentication user is kept in quiet state.

The **undo portal quiet-times** command restores the default maximum number of authentication failures within 60s before a Portal authentication user enters the quiet state.

By default, the device allows a maximum of ten authentication failures within 60s before a Portal authentication user enters the quiet state.

Format

portal quiet-times *fail-times*

undo portal quiet-times

Parameters

Parameter	Description	Value
<i>fail-times</i>	Specifies the maximum number of authentication failures before a Portal authentication user enters the quiet state.	The value is an integer that ranges from 1 to 10.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the [13.5.127 portal quiet-period](#) command is used to enable the quiet timer, if the number of Portal authentication failures exceeds the value specified by the **portal quiet-times** command, the device keeps the Portal authentication user in quiet state for a period of time. This prevents the impact of frequent authentications on the system.

Example

```
# Set the maximum number of Portal authentication failures within 60 seconds to 4.
```

```
<HUAWEI> system-view  
[HUAWEI] portal quiet-times 4
```

Related Topics

[13.5.127 portal quiet-period](#)

[13.5.130 portal timer quiet-period](#)

[13.5.46 display portal quiet-user](#)

13.5.129 portal timer offline-detect

Function

The **portal timer offline-detect** command sets the Portal user offline detection interval.

The **undo portal timer offline-detect** command restores the default Portal user offline detection interval.

By default, the Portal user offline detection interval is 300 seconds.

Format

portal timer offline-detect *time-length*

undo portal timer offline-detect

Parameters

Parameter	Description	Value
<i>time-length</i>	Specifies the Portal user offline detection interval.	The value is 0 or an integer that ranges from 30 to 7200, in seconds. The default value is 300. The value 0 indicates that offline detection is not performed.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If a Portal user goes offline due to power failure or network interruption, the device and Portal server may still store the user information, which causes incorrect accounting. Additionally, a limit number of users can access the device. If a user goes offline improperly but the device still stores user information, other users cannot access the network.

After the Portal user offline detection interval is set, if the user does not respond within the interval, the device considers the Portal user offline. The device and Portal server then delete the user information and release resources to ensure an efficient resource use.

Precautions

The **portal timer offline-detect** command only applies to Layer 2 Portal authentication.

The heartbeat detection function of the authentication server can be used to ensure the normal online status of PC users for whom Layer 3 Portal authentication is used. If the authentication server detects that a user goes offline, it instructs the device to disconnect the user.

If the number of offline detection packets (ARP packets) exceeds the default CAR value, the detection fails and the users are logged out. (The [display cpu-defend statistics](#) command can be run to check whether ARP request and response packets are lost.) To resolve the problem, the following methods are recommended:

- Increase the detection interval based on the number of users. The default detection interval is recommended when there are less than 8000 users; the detection interval should be no less than 600 seconds when there are more than 8000 users.
- Deploy the port attack defense function on the access device and limit the rate of packets sent to the CPU.

If user traffic (such as service packets) passes through the device within the Portal user offline detection period, the device does not consider the user offline even if the user does not respond.

Example

```
# Set the Portal user offline detection interval to 400s.
```

```
<HUAWEI> system-view  
[HUAWEI] portal timer offline-detect 400
```

Related Topics

[13.5.164 web-auth-server \(interface view\)](#)

13.5.130 portal timer quiet-period

Function

The **portal timer quiet-period** command sets the quiet period for Portal authentication.

The **undo portal timer quiet-period** command restores the default quiet period for Portal authentication.

By default, the quiet period for Portal authentication is 60s.

Format

portal timer quiet-period *quiet-period-value*

undo portal timer quiet-period

Parameters

Parameter	Description	Value
<i>quiet-period-value</i>	Specifies the quiet period for Portal authentication.	The value is an integer that ranges from 10 to 3600, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the [13.5.127 portal quiet-period](#) command is used to enable the quiet timer, run the **portal timer quiet-period** command to set the quiet period for Portal authentication. If a Portal authentication user is kept in quiet state, the device discards Portal authentication requests from the user during the quiet period.

Example

```
# Set the quiet period to 2000s.
```

```
<HUAWEI> system-view  
[HUAWEI] portal timer quiet-period 2000
```

Related Topics

[13.5.127 portal quiet-period](#)

[13.5.128 portal quiet-times](#)

[13.5.46 display portal quiet-user](#)

13.5.131 portal url-encode enable

Function

The **portal url-encode enable** command enables URL encoding and decoding.

The **undo portal url-encode enable** command disables URL encoding and decoding.

By default, URL encoding and decoding are enabled.

NOTE

If the system software is upgraded from a version earlier than V200R009C00SPC500 to V200R009C00SPC500 or a later version, the switch automatically runs the **undo portal url-encode enable** command to disable URL encoding and decoding.

Format

portal url-encode enable

undo portal url-encode enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To improve web application security, data from untrustworthy sources must be encoded before being sent to clients. URL encoding is most commonly used in web applications. To enable URL encoding and decoding, run the **portal url-encode enable** command. Some special characters in redirected URLs are then converted to secure formats, preventing clients from mistaking them for syntax signs or instructions and unexpectedly modifying the original syntax. In this way, cross-site scripting attacks and injection attacks are prevented.

Precautions

After the URL encoding and decoding function is enabled, some servers may not support the escape characters converted from special characters in redirect URLs. Therefore, check whether servers support the escape characters before configuring special characters in redirect URLs.

Example

```
# Enable URL encoding and decoding.
```

```
<HUAWEI> system-view  
[HUAWEI] portal url-encode enable
```

Related Topics

[13.5.48 display portal url-encode configuration](#)

13.5.132 portal user-alarm percentage

Function

The **portal user-alarm percentage** command sets alarm thresholds for the Portal authentication user count percentage.

The **undo portal user-alarm percentage** command restores the default alarm thresholds for the Portal authentication user count percentage.

By default, the lower alarm threshold for the Portal authentication user count percentage is 50, and the upper alarm threshold for the Portal authentication user count percentage is 100.

Format

portal user-alarm percentage *percent-lower-value percent-upper-value*

undo portal user-alarm percentage

Parameters

Parameter	Description	Value
<i>percent-lower-value</i>	Specifies the lower alarm threshold for the Portal authentication user count percentage.	The value is an integer that ranges from 1 to 100.
<i>percent-upper-value</i>	Specifies the upper alarm threshold for the Portal authentication user count percentage.	The value is an integer that ranges from 1 to 100, but must be larger than or equal to the lower alarm threshold.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After running the [13.5.126 portal max-user](#) command to set the maximum number of online Portal authentication users allowed on a device, you can run the **portal user-alarm percentage** command to set alarm thresholds for the Portal authentication user count percentage.

When the percentage of online Portal authentication users against the maximum number of users allowed by the device exceeds the upper alarm threshold, the device generates an alarm. When the percentage of online Portal authentication users against the maximum number of users allowed by the device reaches or falls below the lower alarm threshold later, the device generates a clear alarm.

If the configured upper alarm threshold for the Portal authentication user count percentage is 100, the device generates an alarm when the number of online users reaches the maximum number of users allowed by the device.

Example

Set the lower alarm threshold for the Portal authentication user count percentage to 30, and the upper alarm threshold for the Portal authentication user count percentage to 80.

```
<HUAWEI> system-view  
[HUAWEI] portal user-alarm percentage 30 80
```

Related Topics

[13.5.126 portal max-user](#)

13.5.133 portal web-authen-server

Function

The **portal web-authen-server** command enables the Portal interconnection function of the HTTP or HTTPS protocol.

The **undo portal web-authen-server** command disables the Portal interconnection function of the HTTP or HTTPS protocol.

By default, the Portal interconnection function of the HTTP or HTTPS protocol is disabled.

Format

portal web-authen-server { **http** | **https ssl-policy** *policy-name* } [**port** *port-number*]

undo portal web-authen-server [**port**]

Parameters

Parameter	Description	Value
http	Sets the HTTP protocol for Portal authentication. NOTE The HTTP protocol poses security risks. The HTTPS protocol is recommended.	-
https	Sets the HTTPS protocol for Portal authentication.	-
ssl-policy <i>policy-name</i>	Specifies the name of an SSL policy.	The value must be the name of an existing SSL policy.

Parameter	Description	Value
port <i>port-number</i>	Specifies a port number.	The value is an integer that ranges from 1025 to 55535. The default HTTP port number is 8000 and the default HTTPS port number is 8443.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If the device is connected to the Portal server that only supports the HTTP or HTTPS protocol, you need to run the **portal web-authen-server** command on the device to enable the Portal interconnection function of the HTTP or HTTPS protocol.

Follow-up Procedure

Run the [13.4.172 protocol \(Portal server template view\)](#) command to set the protocol used in Portal authentication to HTTP or HTTPS.

Precautions

Modifying the **port** parameter causes the pre-connected user to go offline.

Example

```
# Enable the Portal interconnection function of the HTTPS protocol.
```

```
<HUAWEI> system-view  
[HUAWEI] ssl policy huawei  
[HUAWEI-ssl-policy-huawei] quit  
[HUAWEI] portal web-authen-server https ssl-policy huawei port 8443
```

Related Topics

[13.4.89 display web-auth-server configuration](#)

13.5.134 protocol (Portal server template view)

Function

The **protocol** command configures the protocol used in Portal authentication.

The **undo protocol** command restores the default configuration.

By default, the Portal protocol is used in Portal authentication.

Format

protocol { http [password-encrypt { none | uam }] | portal }

undo protocol

Parameters

Parameter	Description	Value
http	Sets the protocol used in Portal authentication to HTTP or HTTPS.	-
password-encrypt { none uam }	Specifies the password encoding mode. <ul style="list-style-type: none"> none: The password is not encoded. uam: The password is encoded using ASCII characters. 	-
portal	Sets the protocol used in Portal authentication to Portal.	-

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

In Portal authentication, the device can use the following protocols to communicate with the Portal server. You can set the protocol according to the protocol supported by the Portal server.

- Portal protocol
- HTTP or HTTPS protocol

Example

```
# Set the protocol used in Portal authentication to HTTP or HTTPS.
<HUAWEI> system-view
[HUAWEI] web-auth-server abc
[HUAWEI-web-auth-server-abc] protocol http password-encrypt uam
```

13.5.135 remark

Function

The **remark** command configures the user group priority.

The **undo remark** command cancels the user group priority configuration.

By default, no user group priority is configured.

NOTE

Only the S5720EI, S5720HI, S6720EI, and S6720S-EI support this command.

Format

remark { **8021p** *8021p-value* | **dscp** *dscp-value* } *

undo remark { **8021p** *8021p-value* | **dscp** *dscp-value* } *

Parameters

Parameter	Description	Value
8021p <i>8021p-value</i>	Specifies the priority for processing Layer 2 Ethernet packets.	The value is an integer that ranges from 0 to 7.
dscp <i>dscp-value</i>	Specifies the priority for processing IP packets.	The value is an integer that ranges from 0 to 63.

Views

User group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the user group priority is configured, users in the user group inherit the priority. That is, different user packets have different priorities. In this way, the administrator can manage different types of users more flexibly.

Precautions

When the **remark** and [5.7.8 voice-vlan remark](#) commands are used together to modify the user packet priority, if the services conflict:

- For S5720HI, the priority configured using the **remark** command takes effect.

- For S5720EI, S6720EI, and S6720S-EI, the priority configured using the [5.7.8 voice-vlan remark](#) command takes effect.

Example

Set the priority for processing IP packets to 3 in the user group **abc**.

```
<HUAWEI> system-view  
[HUAWEI] user-group abc  
[HUAWEI-user-group-abc] remark dscp 3
```

Related Topics

[13.5.157 user-group enable](#)

[13.5.156 user-group](#)

13.5.136 reset aaa statistics access-type-authenreq

Function

The **reset aaa statistics access-type-authenreq** command clears the number of requesting for MAC, Portal, or 802.1X authentication.

Format

reset aaa statistics access-type-authenreq

Parameters

None

Views

All views

Default Level

3: Management level

Usage Guidelines

When users send authentication requests, the device collects statistics on the number of initiating MAC, Portal, and 802.1X authentications.

To clear the number of requesting for MAC, Portal, or 802.1X authentication, run the **reset aaa statistics access-type-authenreq** command.

Example

Clear the number of requesting for MAC, Portal, or 802.1X authentication.

```
<HUAWEI> reset aaa statistics access-type-authenreq
```

13.5.137 reset access-user traffic-statistics

Function

The **reset access-user traffic-statistics** command clears statistics on traffic of online users in a user group.

 **NOTE**

Only the S5720EI, S5720HI, S6720EI, and S6720S-EI support this command.

Format

reset access-user traffic-statistics { **user-id** *begin-id* [*end-id*] | **mac-address** *mac-address* | **ip-address** *ip-address* [**vpn-instance** *vpn-instance*] }

Parameters

Parameter	Description	Value
user-id <i>begin-id</i> [<i>end-id</i>]	Specifies IDs of online users. <ul style="list-style-type: none"><i>begin-id</i> specifies the start ID of online users.<i>end-id</i> specifies the end ID of online users. The value of <i>end-id</i> must be equal to or greater than that of <i>begin-id</i>. To view IDs of online users, run the 13.5.31 display access-user command.	The value is an integer that varies depending on the product model.
mac-address <i>mac-address</i>	Specifies the MAC address of an online user.	The value is in H-H-H format. An H is a hexadecimal number of 1 to 4 digits.
ip-address <i>ip-address</i>	Specifies the IP address of an online user.	The value is in dotted decimal notation.
vpn-instance <i>vpn-instance</i>	Specifies the VPN instance that an online user belongs to.	The value must be an existing VPN instance name.

Views

User view

Default Level

3: Management level

Usage Guidelines

After traffic control is configured for users in a user group using the [13.5.27 car \(user group view\)](#) command, the device collects statistics on traffic of each user in the user group. You can run the **reset access-user traffic-statistics** command to clear statistics on traffic of online users in a user group.

NOTE

After you run the **reset access-user traffic-statistics** command to clear traffic statistics, the cleared user traffic statistics are not included in the accounting packets sent by the device to the accounting server.

Example

```
# Clear statistics on traffic of the user with the IP address as 10.1.1.1.
```

```
<HUAWEI> reset access-user traffic-statistics ip-address 10.1.1.1
```

Related Topics

[13.5.27 car \(user group view\)](#)

13.5.138 reset dot1x statistics

Function

The **reset dot1x statistics** command clears 802.1X authentication statistics.

Format

```
reset dot1x statistics [ interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10> ]
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [<i>to interface-number2</i>] }	<p>Clears 802.1X authentication statistics on a specified interface.</p> <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number. <p>If this parameter is not specified, 802.1X authentication statistics on the device are cleared.</p>	-

Views

User view

Default Level

3: Management level

Usage Guidelines

The 802.1X authentication statistics contain the number of times that the authentication succeeded and failed on an interface and the number of sent and received packets.

The **reset dot1x statistics** command is used in the following scenarios:

- Redeploy services. After the statistics are cleared, collect the 802.1X authentication statistics again, and run the [13.5.34 display dot1x](#) command to check whether the authentication function works properly and whether packets are correctly sent and received.
- Rectify a fault. After the fault is rectified, run the **reset dot1x statistics** command to clear the statistics, collect the statistics on 802.1X authentication again, and then run the [13.5.34 display dot1x](#) command to verify the authentication result and check whether packets are correctly sent and received. If the authentication is successful and packets are correctly sent and received, the fault is rectified.

Example

```
# Clear 802.1X authentication statistics on GE0/0/1.
```

```
<HUAWEI> reset dot1x statistics interface gigabitethernet 0/0/1
```

Related Topics

[13.5.34 display dot1x](#)

13.5.139 reset mac-authen statistics

Function

The **reset mac-authen statistics** command clears MAC address authentication statistics.

Format

```
reset mac-authen statistics [ interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10> ]
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	<p>Clears MAC address authentication statistics on a specified interface.</p> <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number. <p>If this parameter is not specified, MAC address authentication statistics on the device are cleared.</p>	-

Views

User view

Default Level

3: Management level

Usage Guidelines

The **reset mac-authen statistics** command is used in the following scenarios:

- Re-deploy services. After the statistics are cleared, collect the MAC address authentication statistics again, and run the **13.5.38 display mac-authen** command to check whether the authentication function is normal.
- Rectify a fault. After the fault is rectified, run the **reset mac-authen statistics** command to clear statistics, collect MAC address authentication statistics again, and run the **13.5.38 display mac-authen** command to check the authentication result. If the authentication is successful, the fault is rectified.

Example

```
# Clear MAC address authentication statistics on GE0/0/1.
```

```
<HUAWEI> reset mac-authen statistics interface gigabitethernet 0/0/1
```

Related Topics

[13.5.38 display mac-authen](#)

13.5.140 server-detect

Function

The **server-detect** command enables the Portal server detection function.

The **undo server-detect** command disables the Portal server detection function.

By default, the Portal server detection function is disabled.

Format

server-detect [**interval** *interval-period* | **max-times** *times* | **critical-num** *critical-num* | **action** { **log** | **trap** | **permit-all** } *] *

undo server-detect [**interval** | **max-times** | **critical-num** | **action** { **log** | **trap** | **permit-all** } *]

Parameters

Parameter	Description	Value
interval <i>interval-period</i>	Specifies the detection interval of the Portal server.	The value is an integer that ranges from 30 to 65535, in seconds. The default value is 60.
max-times <i>times</i>	Specifies the maximum number of times that the detection fails.	The value is an integer that ranges from 1 to 255. The default value is 3.
critical-num <i>critical-num</i>	Specifies the minimum number of Portal servers in Up state.	The value is an integer that ranges from 0 to 128. The default value is 0. The default value is recommended.
action	Specifies the action to be taken after the number of detection failures exceeds the maximum.	-
log	Indicates that the device sends a log after the number of detection failures exceeds the maximum.	-

Parameter	Description	Value
trap	Indicates that the device sends a trap after the number of detection failures exceeds the maximum.	-
permit-all	Cancels Portal authentication on an interface after the number of detection failures exceeds the maximum.	-

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

If the communication is interrupted because the network between the device and Portal server is faulty or the Portal server is faulty, new Portal authentication users cannot go online. This brings great inconvenience to users.

After the Portal server detection function is enabled in the Portal server template, the device detects all Portal servers configured in the Portal server template. If the number of times that the device fails to detect a Portal server exceeds the upper limit, the status of the Portal server is changed from Up to Down. If the number of Portal servers in Up state is less than or equal to the minimum number (specified by the **critical-num** parameter), the device performs the corresponding operation to allow the administrator to obtain the real-time Portal server status or ensure that the users have certain network access rights.

NOTE

The detection interval of the Portal server multiplied by the maximum number of detection failures cannot be less than the keepalive heartbeat interval of the Portal server. It is recommended that the configured detection interval of the Portal server be greater than the keepalive heartbeat interval of the Portal server.

Example

```
# Enable the Portal server detection function in the Portal server template abc.  
Configure the detection interval to 100 seconds, the maximum number of  
detection failures to 5. Configure the device to send log information when the  
number of detection failures exceeds the upper limit.
```

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server abc  
[HUAWEI-web-auth-server-abc] server-detect interval 100 max-times 5 action log
```

Related Topics

[13.5.158 user-sync](#)

13.5.141 server-ip (Portal server template view)

Function

The **server-ip** command configures an IP address for a Portal server.

The **undo server-ip** command deletes an IP address for a Portal server.

By default, no IP address is configured for a Portal server.

Format

server-ip *server-ip-address* &<1-10>

undo server-ip { *server-ip-address* | **all** }

Parameters

Parameter	Description	Value
<i>server-ip-address</i>	Specifies an IP address of a Portal server.	The value is in dotted decimal notation.
all	Deletes all IP addresses of a Portal server.	-

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After creating a Portal server template on the device using the [13.5.167 web-auth-server \(system view\)](#) command, configure parameters for the template.

Run the **server-ip** command to configure an IP address for the Portal server in the Portal server template view. When receiving a Portal authentication request packet from a user, the device sends a response packet to the Portal server with the configured IP address.

Precautions

- After the IP address corresponding to a Portal server is configured in the Portal server template, users are allowed to access the IP address.
- When a Portal server template is bound to an interface, server IP addresses can be added, but cannot be deleted. If multiple IP addresses are configured for a Portal server in the Portal server profile, you are advised to run the [13.5.150 url \(Portal server template view\)](#) command to configure a URL for the Portal server. If no URL is configured, the device uses the first IP address as the URL by default, and the other IP addresses do not take effect.

Example

Set the Portal server IP address in the Portal server template **huawei** to 10.10.10.1.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] server-ip 10.10.10.1
```

Related Topics

[13.5.56 display web-auth-server configuration](#)

[13.5.167 web-auth-server \(system view\)](#)

[13.5.150 url \(Portal server template view\)](#)

13.5.142 shared-key (Portal server template view)

Function

The **shared-key** command configures the shared key that the device uses to exchange information with a Portal server.

The **undo shared-key** command restores the default setting.

By default, no shared key that the device uses to exchange information with a Portal server is configured.

Format

shared-key cipher *key-string*

undo shared-key

Parameters

Parameter	Description	Value
cipher	Displays a shared key in cipher text.	-
<i>key-string</i>	Specifies the shared key.	The value is a string of case-sensitive characters without spaces. It can be a string of 48 characters in cipher text, or a string of 1 to 16 characters in plain text.

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a shared key is configured using the **shared-key** command, the Portal packet exchanged between the device and Portal server carries an authenticator generated according to the shared key, and the authenticator is used to check whether the Portal packet at the receiver is correct. This effectively improves the information exchange security.

Precautions

To improve security, it is recommended that the password contains at least two types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 6 characters.

Example

Configure the shared key in the Portal server template **huawei** to **huawei@123**.

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server huawei  
[HUAWEI-web-auth-server-huawei] shared-key cipher huawei@123
```

Related Topics

[13.5.56 display web-auth-server configuration](#)

[13.5.167 web-auth-server \(system view\)](#)

13.5.143 snmp-agent trap enable feature-name mid_aaa

Function

The **snmp-agent trap enable feature-name mid_aaa** command enables the trap function for the AAA module.

The **undo snmp-agent trap enable feature-name mid_aaa** command disables the trap function for the AAA module.

By default, the trap function is enabled for the AAA module.

Format

```
snmp-agent trap enable feature-name mid_aaa [ trap-name  
{ hwmacmovedquietmaxuseralarm | hwmacmovedquietuserclearalarm } ]
```

```
undo snmp-agent trap enable feature-name mid_aaa [ trap-name  
{ hwmacmovedquietmaxuseralarm | hwmacmovedquietuserclearalarm } ]
```

Parameters

Parameter	Description	Value
trap-name	Enables or disables the trap function for a specified event of the AAA module.	-
hwmacmovedquiet-maxuseralarm	Sends a Huawei proprietary trap message when the percentage of current MAC address migration users in quiet state against the maximum number of users exceeds the upper alarm threshold.	-
hwlpStaticUserMixe-dInsertAlarm	A Huawei proprietary trap message is sent when an exception occurs during the login attempt of a user with one MAC address and multiple IP addresses through an Eth-Trunk interface to which interfaces on different types of boards are added.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the trap function is enabled, the device generates traps during operation and sends the traps to the NMS through the SNMP module. If the trap function is disabled, the device does not generate traps and the SNMP module does not send traps to the NMS.

You can specify **trap-name** to enable the trap function for one or more events.

Example

```
# Enable the trap function for hwmacmovedquietmaxuseralarm of the AAA module.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name mid_aaa trap-name  
hwmacmovedquietmaxuseralarm
```

Related Topics

[13.5.50 display snmp-agent trap feature-name mid_aaa all](#)

13.5.144 snmp-agent trap enable feature-name mid_eapol

Function

The **snmp-agent trap enable feature-name mid_eapol** command enables the trap function for the DOT1X module.

The **undo snmp-agent trap enable feature-name mid_eapol** command disables the trap function for the DOT1X module.

By default, the trap function is enabled for the DOT1X module.

Format

```
snmp-agent trap enable feature-name mid_eapol [ trap-name  
{ hwmacauthenmaxuseralarm | hwsrvcfgeapmaxuseralarm } ]
```

```
undo snmp-agent trap enable feature-name mid_eapol [ trap-name  
{ hwmacauthenmaxuseralarm | hwsrvcfgeapmaxuseralarm } ]
```

Parameters

Parameter	Description	Value
trap-name	Enables or disables the trap function for a specified event of the DOT1X module.	-
hwmacauthenmaxuseralarm	Enables the device to send a Huawei proprietary trap when the number of MAC address authentication users reaches the maximum number allowed on an interface.	-
hwsrvcfgeapmaxuseralarm	Enables the device to send a Huawei proprietary trap when the number of 802.1X authentication users reaches the maximum number allowed on an interface.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the trap function is enabled, the device generates traps during operation and sends the traps to the NMS through the SNMP module. If the trap function is disabled, the device does not generate traps and the SNMP module does not send traps to the NMS.

You can specify **trap-name** to enable the trap function for one or more events.

Example

Enable the trap function for hwmacauthenmaxuseralarm of the DOT1X module.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name mid_eapol trap-name hwmacauthenmaxuseralarm
```

Related Topics

[13.5.51 display snmp-agent trap feature-name mid_eapol all](#)

13.5.145 snmp-agent trap enable feature-name mid_web

Function

The **snmp-agent trap enable feature-name mid_web** command enables the trap function for the web authentication module.

The **undo snmp-agent trap enable feature-name mid_web** command disables the trap function for the web authentication module.

By default, the trap function is enabled for the web authentication module.

Format

```
snmp-agent trap enable feature-name mid_web [ trap-name  
{ hwportalmaxuseralarm | hwportaluserclearalarm | hwportalserverdown |  
hwportalserverup } ]
```

```
undo snmp-agent trap enable feature-name mid_web [ trap-name  
{ hwportalmaxuseralarm | hwportaluserclearalarm | hwportalserverdown |  
hwportalserverup } ]
```

Parameters

Parameter	Description	Value
trap-name	Enables or disables the trap function for a specified event of the web authentication module.	-
hwportalmaxuseralarm	Enables the device to send a Huawei proprietary trap when the number of online Portal authentication users exceeds the upper threshold.	-
hwportaluserclearalarm	Enables the device to send a Huawei proprietary trap when the number of online Portal authentication users falls below the lower threshold.	-
hwportalserverdown	Enables the device to send a Huawei proprietary trap when it detects that the Portal server changes from Up to Down.	-
hwportalserverup	Enables the device to send a Huawei proprietary trap when it detects that the Portal server changes from Down to Up.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the trap function is enabled, the device generates traps during operation and sends the traps to the NMS through the SNMP module. If the trap function is

disabled, the device does not generate traps and the SNMP module does not send traps to the NMS.

You can specify **trap-name** to enable the trap function for one or more events.

Example

```
# Enable the trap function for hwportalmxuseralarm of the web authentication module.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name mid_web trap-name hwportalmxuseralarm
```

Related Topics

[13.5.52 display snmp-agent trap feature-name mid_web all](#)

13.5.146 source-ip (Portal server template view)

Function

The **source-ip** command configures the source IP address for the device to communicate with a Portal server.

The **undo source-ip** command restores the default setting.

By default, no source IP address is configured for the device to communicate with a Portal server.

Format

source-ip *ip-address*

undo source-ip

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the source IP address for communication with a Portal server.	The value is in dotted decimal notation.

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To ensure normal communication between the device and Portal server, run the **source-ip** command to configure a source IP address on the device.

If the device is configured with a loopback IP address and a common IP address, the device can communicate with the Portal server only when the loopback IP address and common IP address are the same. The **source-ip** command configures a source IP address on the device in the **web-auth-server** view to allow communication between the device and a Portal server.

Precautions

Ensure that the configured source IP address is the device IP address. The source IP address cannot be all 0s, all 1s, class D address, class E address, or loopback address.

Example

Set the source IP address for communication between the device and a Portal server to 192.168.1.100 in the Portal server template **huawei**.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] source-ip 192.168.1.100
```

Related Topics

[13.5.167 web-auth-server \(system view\)](#)

13.5.147 static-user

Function

The **static-user** command configures a static user.

The **undo static-user** command deletes the configured static user.

By default, no static user is configured.

Format

static-user *start-ip-address* [*end-ip-address*] [**vpn-instance** *vpn-instance-name*] [**domain-name** *domain-name* | **interface** *interface-type interface-number* [**detect**] | **mac-address** *mac-address* | **vlan** *vlan-id*] *

undo static-user *start-ip-address* [*end-ip-address*] [**vpn-instance** *vpn-instance-name*]

NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

Parameters

Parameter	Description	Value
<i>start-ip-address</i> [<i>end-ip-address</i>]	Specifies the IP address range that a static user belongs to. If <i>end-ip-address</i> is not specified, a static user is specified by <i>start-ip-address</i> .	The value is in dotted decimal notation.
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance that a static user belongs to.	The value must be an existing VPN instance name.
domain-name <i>domain-name</i>	Specifies the domain that a static user belongs to.	The value must be an existing domain name.
interface <i>interface-type interface-number</i>	Specifies the interface connected to a static user. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. NOTE A management interface cannot be configured as the interface to which a static user belongs.	-
detect	Permits the device to send ARP packets to trigger Portal authentication for static users in offline state.	-
mac-address <i>mac-address</i>	Specifies the MAC address of a static user.	The value is in H-H-H format. An H is a hexadecimal number of 1 to 4 digits.
vlan <i>vlan-id</i>	Specifies the ID of a VLAN that a static user belongs to.	The value is an integer that ranges from 1 to 4094.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In network deployment, static IP addresses are assigned to dumb terminals such as printers and servers. The users can be configured as static users for flexible authentication.

After static users are configured, the device can use static user information such as their IP addresses as the user names to authenticate the users only when Portal authentication is enabled on the interfaces connected to the static users.

Precautions

When the interface (**interface** *interface-type interface-number*) mapping static users is specified, the VLAN (**vlan** *vlan-id*) that the interface belongs to must be configured.

This function takes effect only for users who go online after this function is successfully configured.

Static users are not allowed to update the IP address, otherwise the users will go offline.

Example

```
# Specify the IP address range 10.1.1.1-10.1.1.10, authentication domain huawei,  
and VLAN 10 that static users belong to.
```

```
<HUAWEI> system-view  
[HUAWEI] static-user 10.1.1.1 10.1.1.10 domain-name huawei vlan 10
```

Related Topics

[13.5.149 static-user username format-include](#)

[13.5.148 static-user password](#)

[13.5.53 display static-user](#)

13.5.148 static-user password

Function

The **static-user password** command sets the password for a static user in authentication.

The **undo static-user password** command restores the default password for the static user.

The default username and password are available in *S Series Switches Default Usernames and Passwords* ([Enterprise Network](#) or [Carrier](#)). If you have not obtained the access permission of the document, see **Help** on the website to find out how to obtain it.

Format

static-user password cipher *password*

undo static-user password

Parameters

Parameter	Description	Value
cipher	Displays a password in cipher text.	-
<i>password</i>	Specifies the password of a static user.	The value is a case-sensitive string without question marks (?) or spaces. The password contains 1 to 128 characters in plain text or 48 to 188 characters in cipher text.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When a static user triggers authentication through an ARP packet, you can run the **static-user password** command to set the password for the static user. The access device then sends the password to the authentication server.

Precautions

To improve security, change the default password immediately and update the password periodically. It is recommended that the new password contains at least two types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 6 characters.

This function takes effect only for users who go online after this function is successfully configured.

Example

```
# Configure the password huawei@123 for static users.
```

```
<HUAWEI> system-view  
[HUAWEI] static-user password cipher huawei@123
```

Related Topics

[13.5.147 static-user](#)

[13.5.149 static-user username format-include](#)

[13.5.53 display static-user](#)

13.5.149 static-user username format-include

Function

The **static-user username format-include** command sets the user name for a static user in authentication.

The **undo static-user username format-include** command restores the default user name for the static user.

By default, the name of a static user consists of **system-name** and **ip-address**. For example, if the access device name is **huawei** and user IP address is 1.1.1.1, the static user name is **huawei1.1.1.1**.

Format

static-user username format-include { ip-address | mac-address | system-name }

undo static-user username format-include

Parameters

Parameter	Description	Value
ip-address	Indicates that the user IP address is used as the user name.	-
mac-address	Indicates that the user MAC address is used as the user name.	-
system-name	Indicates that the access device name is used as the user name. To set the device name, run the sysname command.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When a static user triggers authentication through an ARP packet, you can run the **static-user username format-include** command to set the user name for the static user. The access device then sends the user name to the authentication server.

Example

Set the user IP address as the static user name for authentication.

```
<HUAWEI> system-view  
[HUAWEI] static-user username format-include ip-address
```

Related Topics

[13.5.147 static-user](#)

[13.5.148 static-user password](#)

[13.5.53 display static-user](#)

13.5.150 url (Portal server template view)

Function

The **url** command configures the URL for a Portal server.

The **undo url** command restores the default setting.

By default, no URL is configured for a Portal server.

Format

url *url-string*

undo url

Parameters

Parameter	Description	Value
<i>url-string</i>	Specifies the URL of a portal server.	The value is a string of 1 to 200 characters.

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the Portal server IP address is configured using the [13.5.141 server-ip \(Portal server template view\)](#) command, the Portal server URL is generated by default on the device. If the existing Portal server URL is inconsistent with the default one or the domain name needs to be used, you need to run the **url** command to specify the Portal server URL.

Precautions

- A Portal server only has one URL.

Example

Set the URL of a Portal server to http://www.***.com in the Portal server template **huawei**.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] url http://www.***.com
```

Related Topics

[13.5.56 display web-auth-server configuration](#)

[13.5.167 web-auth-server \(system view\)](#)

[13.5.141 server-ip \(Portal server template view\)](#)

13.5.151 url (URL template view)

Function

The **url** command configures the redirection URL or pushed URL.

The **undo url** command cancels the redirection URL or pushed URL.

By default, no redirection URL or pushed URL is configured.

Format

url [**push-only** | **redirect-only**] *url-string*

undo url [**push-only** | **redirect-only**]

Parameters

Parameter	Description	Value
<i>url-string</i>	Specifies the redirection URL of the Portal server or pushed URL.	It is a string of 1 to 200 case-sensitive characters without spaces.
push-only	Specifies the URL as a pushed URL.	-

Parameter	Description	Value
redirect-only	Specifies the URL as a redirection URL.	-

Views

URL template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a URL template is created using the [13.5.155 url-template name](#) command, you can run this command to configure the redirection URL or pushed URL. When a user without network access right connects to the network, the Portal authentication device redirects the user to the specified URL for authentication. The difference between redirection URL and pushed URL is as follows:

- Redirection URL: When a user without network access right connects to the network, the Portal authentication device redirects the user to the redirection URL for authentication.
- Pushed URL: After an authenticated user accesses the network through web for the first time, the access device pushes the web page corresponding to the URL to the user. The web access request from the user is redirected to the specified URL, and then the user is allowed to access network resources.

Precautions

When configuring a URL on the device, you cannot enter a question mark (?). If a URL contains a question mark (?), you can run the [parameter](#) start-mark # command in the URL template view to replace the question mark (?) with the number sign (#).

If the **push-only** and **redirect-only** parameters are not specified, the configured URL is used as both redirection URL and pushed URL. You can configure pushed URL using the [13.5.85 force-push](#) command, or use the [13.5.154 url-template \(Portal server template view\)](#) command to bind a URL template to the Portal server template to configure redirection URL.

Example

```
# Set the redirection URL to http://10.1.1.1.
```

```
<HUAWEI> system-view  
[HUAWEI] url-template name huawei  
[HUAWEI-url-template-huawei] url http://10.1.1.1
```

13.5.152 url-parameter

Function

The **url-parameter** command sets the parameters in URL.

The **undo url-parameter** command deletes the parameters in URL.

By default, a URL does not carry parameters.

Format

url-parameter { **redirect-url** *redirect-url-value* | **sysname** *sysname-value* | **user-ipaddress** *user-ipaddress-value* | **user-mac** *user-mac-value* | **login-url** *url-key url* }

undo url-parameter

Parameters

Parameter	Description	Value
redirect-url <i>redirect-url-value</i>	Specifies the original URL that a user accesses carried in the URL and sets the parameter name.	The value is a string of 1 to 16 case-sensitive characters without spaces.
user-ipaddress <i>user-ipaddress-value</i>	Specifies the user IP address carried in the URL and sets the parameter name.	The value is a string of 1 to 16 case-sensitive characters without spaces.
sysname <i>sysname-value</i>	Specifies the device system name carried in the URL and sets the parameter name.	The value is a string of 1 to 16 case-sensitive characters without spaces.
user-mac <i>user-mac-value</i>	Specifies the user MAC address carried in the URL and sets the parameter name.	The value is a string of 1 to 16 case-sensitive characters without spaces.

Parameter	Description	Value
login-url <i>url-key url</i>	Specifies the login URL of the access device. <ul style="list-style-type: none">• <i>url-key</i>: specifies the identification keyword for the login URL sent to the Portal server during redirection.• <i>url</i>: is a specified URL on the access device.	<ul style="list-style-type: none">• <i>url-key</i>: The value is a string of 1 to 16 case-sensitive characters without spaces, question marks (?), ampersands (&), and equal signs (=).• <i>url</i>: The value is a string of 1 to 200 case-sensitive characters without spaces.

Views

URL template view

Default Level

2: Configuration level

Usage Guidelines

After a URL template is created using the [13.5.155 url-template name](#) command and URL is configured using the [13.5.151 url \(URL template view\)](#) command, you can use the **url-parameter** command to set the parameters in the URL. When a user accesses the Portal server according to the URL, the Portal server obtains user terminal information through the parameters in the URL. The Portal server then provides the corresponding web authentication page for the user according to user terminal information.

In addition, when users are pushed to a website rather than the Portal server according to the URL, the website provides the different web pages for the users according to user terminal information carried in the URL.

Example

Set the user MAC address and access device system name in the URL.

```
<HUAWEI> system-view
[HUAWEI] url-template name huawei
[HUAWEI-url-template-huawei] url-parameter user-mac usermac sysname huawei
```

13.5.153 url-parameter mac-address format

Function

The **url-parameter mac-address format** command configures the MAC address format in URL.

The **undo url-parameter mac-address format** command restores the default MAC address format in URL.

By default, the MAC address format in URL is XXXXXXXXXXXX.

Format

url-parameter mac-address format delimiter *delimiter* { normal | compact }

undo url-parameter mac-address format

Parameters

Parameter	Description	Value
delimiter <i>delimiter</i>	Specifies the delimiter in MAC address.	The value is one case-sensitive character without spaces.
normal	Sets the MAC address format to XX-XX-XX-XX-XX-XX.	-
compact	Sets the MAC address format to XXXX-XXXX-XXXX.	-

Views

URL template view

Default Level

2: Configuration level

Usage Guidelines

Portal servers or websites may require different MAC address formats. You can run the **url-parameter mac-address format** command to set MAC address formats in URL to meet the requirements of Portal servers.

Example

```
# Set the delimiter to - and format to XXXX-XXXX-XXXX.
```

```
<HUAWEI> system-view  
[HUAWEI] url-template name huawei  
[HUAWEI-url-template-huawei] url-parameter mac-address format delimiter - compact
```

13.5.154 url-template (Portal server template view)

Function

The **url-template** command binds a URL template to a Portal server template.

The **undo url-template** command unbinds a URL template from a Portal server template.

By default, no URL template is bound to a Portal server template.

Format

url-template *url-template* [**ciphered-parameter-name** *ciphered-parameter-name* **iv-parameter-name** *iv-parameter-name* **key cipher** *key-string*]

undo url-template

Parameters

Parameter	Description	Value
<i>url-template</i>	Specifies the name of a URL template.	The value must be an existing URL template name.
ciphered-parameter-name <i>ciphered-parameter-name</i>	Specifies the name of the encrypted URL template parameter.	The value is a string of 1 to 16.
iv-parameter-name <i>iv-parameter-name</i>	Specifies the encryption vector name of the URL template parameter.	The value is a string of 1 to 16.
key cipher <i>key-string</i>	Specifies the shared key for encrypting the URL template parameter.	The value is a string of 1-16 plain-text characters or 48 cipher-text characters.

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the parameters of a URL template are configured, the URL template must be bound to a Portal authentication server template so that users can be authenticated on the Portal authentication server corresponding to the redirection URL.

To ensure security, you can encrypt the parameter information in the URL template bound to the Portal server profile.

Prerequisites

A URL template has been created using the [13.5.155 url-template name](#) command.

Precautions

If a URL template is bound to the Portal authentication server template and the [13.5.150 url \(Portal server template view\)](#) command is executed to configure the redirection URL corresponding to the Portal authentication server, only the parameters in the URL template take effect.

The device support encryption of parameter information in the URL template only when it connects to the Huawei Agile Controller-Campus.

Example

Bind the URL template **abc** to the Portal authentication server template.

```
<HUAWEI> system-view
[HUAWEI] url-template name abc
[HUAWEI-url-template-abc] quit
[HUAWEI] web-auth-server huawei
[HUAWEI-web-auth-server-huawei] url-template abc
```

Related Topics

[13.5.151 url \(URL template view\)](#)

[13.5.155 url-template name](#)

13.5.155 url-template name

Function

The **url-template name** command creates a new URL template or enter an existing URL template view.

The **undo url-template name** command deletes a URL template.

By default, no URL template exists on the device.

Format

url-template name *template-name*

undo url-template name *template-name*

Parameters

Parameter	Description	Value
<i>template-name</i>	Specifies the name of a URL template.	The value is a string of 1 to 31 case-sensitive characters. It cannot contain spaces or the following symbols: / \ : * ? " < > @ ' %. The value cannot be - or --.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After a Portal authentication server template is created using the [13.5.167 web-auth-server \(system view\)](#) command, you can bind a URL template to the Portal authentication server template. The URL template contains the redirection URL and redirection URL parameters.

The **url-template name** command creates a new URL template or enter an existing URL template view.

Example

Create a URL template named **huawei** and enter the template view.

```
<HUAWEI> system-view  
[HUAWEI] url-template name huawei
```

13.5.156 user-group

Function

The **user-group** command creates a user group or displays the user group view.

The **undo user-group** command deletes a user group.

By default, no user group is configured.

Format

user-group *group-name*

undo user-group *group-name*

Parameters

Parameter	Description	Value
<i>group-name</i>	Specifies the name of a user group.	The value is a string of 1-64 case-sensitive characters, which cannot be configured to - and --. It cannot contain spaces and the following symbols: / \ : * ? " < > @ ' %.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In practical NAC applications, there are many access users and a large number of ACL rules need to be configured for each user. However, the number of user types is limited.

You can run the **user-group** command to create user groups on the device and associate each user group to a group of ACL rules (for details, see [13.5.6 acl-id \(user group view\)](#)). In this way, users in the same group share a group of ACL rules. The limited ACL resources can support a large number of access users.

NOTE

When the user group function is enabled on models except the S5720EI, S5720HI, S6720EI, and S6720S-EI, ACL rules are delivered to each user and the user group function cannot be used to save ACL resources.

Precautions

- When you create a user group, ensure that the user group name is different from the number of an existing ACL. You can run the **display acl all** command to view the configuration of all ACL rules on the device.
- If you want to delete the user group when the ACL bound to the user takes effect, run the **cut access-user user-group group-name** command to disconnect all users bound to the user group, and run the **undo user-group group-name enable** command to disable the user group function.
- The priority of the user group authorization information delivered by the authentication server is higher than that of the user group authorization information applied in the AAA domain. If the user group authorization information delivered by the authentication server cannot take effect, the user group authorization information applied in the AAA domain is used. For example, if only user group B is configured on the device and the group authorization information is applied in the AAA domain when the authentication server delivers authorization information about user group A, the authorization information about user group A cannot take effect and the authorization information about user group B is used. To make the user group

authorization information delivered by the authentication server take effect, ensure that this user group is configured on the device.

Example

```
# Create a user group test1.
```

```
<HUAWEI> system-view  
[HUAWEI] user-group test1
```

Related Topics

[13.5.6 acl-id \(user group view\)](#)

[13.5.157 user-group enable](#)

13.5.157 user-group enable

Function

The **user-group enable** command enables the user group function.

The **undo user-group enable** command disables the user group function.

By default, the user group function is disabled.

Format

user-group *group-name* **enable**

undo user-group *group-name* **enable**

Parameters

Parameter	Description	Value
<i>group-name</i>	Specifies the name of a user group.	The value is a string of 1 to 64 case-sensitive characters without spaces.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If a user group has been created using the [13.5.156 user-group](#) command, run the **user-group enable** command to enable the user group function.

Precautions

After the user group function is enabled, the binding relationship between a user group and an ACL cannot be modified.

If the user group function is not enabled, users going online through Layer 2 interfaces can access the network without restriction, while users going online through VLANIF interfaces are not allowed to access the network.

Example

```
# Enable the user group huawei.
```

```
<HUAWEI> system-view  
[HUAWEI] user-group huawei enable
```

13.5.158 user-sync

Function

The **user-sync** command enables user information synchronization.

The **undo user-sync** command disables user information synchronization.

By default, user information synchronization is disabled.

Format

```
user-sync [ interval interval-period | max-times times ] *
```

```
undo user-sync
```

Parameters

Parameter	Description	Value
interval <i>interval-period</i>	Specifies the user information synchronization interval.	The value is an integer that ranges from 30 to 65535, in seconds. The default value is 300.
max-times <i>times</i>	Specifies the maximum number of user information synchronization failures.	The value is an integer that ranges from 2 to 255. The default value is 3.

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If communication is interrupted because the network between the device and Portal server is disconnected or the Portal server is faulty, online Portal authentication users cannot go offline. Therefore, user information on the device and on the Portal server may be inconsistent and accounting may be inaccurate.

The **user-sync** command enables user information synchronization so that user information on the device and Portal server is synchronized at intervals to ensure user information consistency.

 **NOTE**

During information synchronization, the device does not disconnect the user immediately after detecting that the device has certain user information while the server does not have such information. Instead, the device disconnects the user when the maximum number of user information synchronization failures is reached.

Precautions

If users go online during the keepalive interval of the Portal server, the Portal server does not have their entries. After the Portal server goes Up and starts synchronizing user information, the device does not disconnect these users even if synchronization fails. The device retains these users until next time these users go online and performs Portal authentication, ensuring good user experience.

The value of *interval-period*times* configured on the device must be greater than the interval for the Portal server to send synchronization packets. Otherwise, the device forces users offline when it cannot receive any synchronization packet from the Portal server after the maximum failure number is reached.

When you run the **user-sync** command, make sure that the Portal server supports this function. otherwise, the users will go offline.

Example

Enable user information synchronization in the Portal server template **abc**, set the interval for user information synchronization to 100s, and set the maximum number of synchronization failures to 5.

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server abc  
[HUAWEI-web-auth-server-abc] user-sync interval 100 max-times 5
```

13.5.159 user-vlan (user group view)

Function

The **user-vlan** command configures a user group VLAN.

The **undo user-vlan** restores the default setting.

By default, no user group VLAN is configured.

Format

user-vlan *vlan-id*

undo user-vlan

Parameters

Parameter	Description	Value
<i>vlan-id</i>	Specifies the ID of a user group VLAN.	The value is an integer that ranges from 1 to 4094.

Views

User group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a user group is created using the **user-group** command, you can run the **user-vlan** command to configure a user group VLAN, so that users in different user groups have different network access permissions. When a user in a user group goes online, the user is added to the user group VLAN to obtain the network access permission of this user group.

Prerequisites

The user group VLAN has been created using the **vlan** command.

Precautions

- An authorized VLAN cannot be delivered to online Portal users.
- If a user uses Portal authentication or combined authentication (including Portal authentication), the device cannot authorize a VLAN to the user.
- The **user-vlan** command does not take effect for the users who are already online.
- If the user access mode is not **multi-share**, to make the **user-vlan** command take effect, you must configure the link type of the interface connected to users to hybrid. Access switches will send untagged frames to users in the user-vlan even when interfaces connected users are added to this user VLAN in tagged mode.

Example

```
# Set the VLAN of the user group abc to 10.
```

```
<HUAWEI> system-view  
[HUAWEI] user-group abc  
[HUAWEI-user-group-abc] user-vlan 10
```

Related Topics

[13.5.157 user-group enable](#)

[13.5.156 user-group](#)

13.5.160 vm-authen password

Function

The **vm-authen password** command configures a password for virtual users during RADIUS authentication.

The **undo vm-authen password** command restores the default password for virtual users during RADIUS authentication.

The default username and password are available in *S Series Switches Default Usernames and Passwords* (**Enterprise Network** or **Carrier**). If you have not obtained the access permission of the document, see **Help** on the website to find out how to obtain it.

 **NOTE**

Only the S5720EI supports this command.

Format

vm-authen password cipher *password*

undo vm-authen password

Parameters

Parameter	Description	Value
cipher	Displays a password in cipher text.	-
<i>password</i>	Specifies the password for virtual users during RADIUS authentication.	The value is a case-sensitive string without question marks (?) or spaces. The password contains 1 to 16 characters in plain text or 32 characters in cipher text.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

You can run the **vm-authen password** command to configure a password for virtual users during RADIUS authentication.

Precautions

To improve security, change the default password immediately. It is recommended that the new password contains at least two types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 6 characters.

Example

```
# Set the password huawei for virtual users during RADIUS authentication.  
<HUAWEI> system-view  
[HUAWEI] vm-authen password cipher huawei
```

13.5.161 vm-user association-type

Function

The **vm-user association-type** command configures the association type of a virtual user.

NOTE

Only the S5720EI supports this command.

Format

vm-user association-type { **online** | **pre-online** | **offline** } **mac-address** *mac-address* **interface** *interface-type interface-number* **vlan** *vlan-id* [**ip-address** *ip-address* | **profile** *profile-name* | **vsi** *vsi-name*] *

Parameters

Parameter	Description	Value
online	Indicates that the association type of the virtual user is online.	-
pre-online	Indicates that the association type of the virtual user is pre-online.	-
offline	Indicates that the association type of the virtual user is offline.	-
mac-address <i>mac-address</i>	Specifies the MAC address of the virtual user.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.

Parameter	Description	Value
interface <i>interface-type</i> <i>interface-number</i>	Specifies the number or name of an interface for associating with a virtual user. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-
vlan <i>vlan-id</i>	Specifies the VLAN to which the virtual user belongs.	The value is an integer that ranges from 0 to 4094.
ip-address <i>ip-address</i>	Specifies the IP address of the virtual user.	The value is in dotted decimal notation.
profile <i>profile-name</i>	Specifies the profile to which the virtual user belongs.	The value is a string of 1 to 64 case-sensitive characters without spaces.
vsi <i>vsi-name</i>	Specifies the name of the virtual site interface.	The value is a string of 1 to 64 case-sensitive characters without spaces.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In virtual network management, you must configure the function specified by the **vm-user association-type** command on the network management system (NMS) so that virtual users can access the network. The NMS then delivers the function configuration to the device. After receiving the related function configuration, the device automatically runs the **vm-user association-type** command to configure the association type of the virtual user.

Precautions

This command should be configured by the network administrator on the NMS and delivered to the device. You are not advised to directly run this command on the device.

Example

```
# Set the association type of the virtual user with the MAC address 1-1-1 in VLAN  
10 on GE0/0/1 to pre-online.  
<HUAWEI> system-view  
[HUAWEI] vm-user association-type pre-online mac-address 1-1-1 interface gigabitethernet 0/0/1 vlan  
10
```

13.5.162 vpn-instance (Portal server template view)

Function

The **vpn-instance** command configures a VPN instance used for communication between the device and Portal server.

The **undo vpn-instance** command restores the default setting.

By default, no VPN instance is configured for communication between the device and Portal server.

NOTE

Only S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support the command.

Format

vpn-instance *vpn-instance-name*

undo vpn-instance

Parameters

Parameter	Description	Value
<i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The value must be an existing VPN instance name.

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A VPN implements interconnection within the same department and between different departments in an enterprise. To enable the Portal authentication service

in the VPN, run the **vpn-instance** command to bind a Portal server template to a VPN instance.

Prerequisites

A VPN instance has been created using the **ip vpn-instance** command.

Precautions

The VPN instance bound to the Portal server template must be the same as that bound to the Portal server; otherwise, the device cannot perform Portal authentication for access users.

The users in VPN instances bound to different Portal server templates cannot use the same IP addresses because users with the same IP addresses cannot go online or offline.

Example

Bind the Portal server template **abc** to the VPN instance **huawei**.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server abc
[HUAWEI-web-auth-server-abc] vpn-instance huawei
```

Related Topics

[10.4.36 ip vpn-instance](#)

13.5.163 web-auth-server version

Function

The **web-auth-server version** command sets the Portal protocol version supported by the device.

The **undo web-auth-server version** command restores the default setting.

By default, the device supports both the versions V1.0 and V2.0.

Format

web-auth-server version v2 [v1]

undo web-auth-server version

Parameters

Parameter	Description	Value
v2	Indicates that the device supports the Portal protocol version V2.0. The major version currently used is V2.0.	-
v1	Indicates that the device supports the Portal protocol version V1.0.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Currently, the Portal protocol has two versions: V1.0 and V2.0. The device and Portal server must use the Portal protocol of the same version to ensure normal communication. You can run the **web-auth-server version** command to set the Portal protocol version supported by the device.

NOTE

The version V2.0 is widely used currently.

To ensure smooth communication, the device supports both versions by default.

Example

Configure the device to use only the Portal protocol V2.0.

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server version v2
```

Related Topics

[13.5.56 display web-auth-server configuration](#)

13.5.164 web-auth-server (interface view)

Function

The **web-auth-server** command binds a Portal server template to an interface.

The **undo web-auth-server** command unbinds a Portal server template from an interface.

By default, no Portal server template is bound to an interface.

Format

- VLANIF interface view:
web-auth-server *server-name* [*bak-server-name*] { **direct** | **layer3** }
undo web-auth-server [*server-name* [*bak-server-name*]] { **direct** | **layer3** }
- Layer 3 Ethernet interface view: (Only the S5720EI, S5720HI, S6720EI, and S6720S-EI support this)
web-auth-server *server-name* [*bak-server-name*] **layer3**
undo web-auth-server [*server-name* [*bak-server-name*]] **layer3**]

Parameters

Parameter	Description	Value
<i>server-name</i>	Specifies the name of the Portal server template.	The value must be an existing Portal server template name.
<i>bak-server-name</i>	Specifies the name of the secondary Portal server template. NOTE The name of the secondary Portal server template can not be configured to the command-line keywords direct and layer3 .	The value must be an existing Portal server template name.
direct	Indicates Layer 2 authentication.	-
layer3	Indicates Layer 3 authentication.	-

Views

VLANIF interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A configured Portal server template must be bound to the interface. In this way, the users connected to this interface can be authenticated by the Portal server.

When the Portal server template is bound to the interface using the **web-auth-server** command and a user attempts to access charged network resources, the user is forcibly redirected to the configured Portal authentication page for Portal authentication.

After the primary and secondary Portal server templates are configured, the users who send HTTP requests are redirected to the network access page provided by the secondary Portal server when the primary Portal server is faulty or cannot be accessed. This meets the users' network access requirements. This function can take effect only when the primary Portal server detection function is enabled using the **13.5.140 server-detect** command and heartbeat detection is enabled on the Portal server.

Portal authentication modes are as follows:

- **direct**: When there is no Layer 3 forwarding device between the user and device, the device can learn the user's MAC address. The device identifies the user using the MAC address.

- **layer3:** Whether Layer 3 forwarding devices exist between the user and device, the device cannot learn the user's MAC address. The device identifies the user using the IP address uniquely.

Prerequisites

A Portal server template has been created using the [13.5.167 web-auth-server \(system view\)](#) command and an IP address has been configured for the Portal server using the [13.5.141 server-ip \(Portal server template view\)](#) command.

Precautions

- You can bind only one Portal server template to an interface. To modify a Portal server template that has been bound to an interface, remove the template from the interface, modify the template, and bind the modified template to the interface again.
- If 802.1X authentication, MAC address authentication, MAC address bypass authentication or built-in Portal authentication is enabled on a Layer 2 interface, this command cannot be executed on the VLANIF interface of a VLAN to which the Layer 2 interface is added.
- This command does not take effect on the VLANIF interface corresponding to the super VLAN.

Example

Bind the Portal server template Server1 to VLANIF10, and set the authentication mode to Layer 2 authentication.

```
<HUAWEI> system-view
[HUAWEI] vlan batch 10
[HUAWEI] web-auth-server Server1
[HUAWEI-web-auth-server-Server1] server-ip 10.10.1.1
[HUAWEI-web-auth-server-Server1] quit
[HUAWEI] interface vlanif 10
[HUAWEI-Vlanif10] web-auth-server Server1 direct
```

Related Topics

- [13.5.167 web-auth-server \(system view\)](#)
- [13.5.141 server-ip \(Portal server template view\)](#)
- [13.5.56 display web-auth-server configuration](#)

13.5.165 web-auth-server listening-port

Function

The **web-auth-server listening-port** command sets the number of the port through which a device listens on Portal protocol packets.

The **undo web-auth-server listening-port** command restores the default listening port.

By default, the device uses port 2000 to listen on Portal protocol packets.

Format

web-auth-server listening-port *port-number*

undo web-auth-server listening-port

Parameters

Parameter	Description	Value
<i>port-number</i>	Specifies the number of the listening port.	The value is an integer that ranges from 1024 to 55535.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When the device exchanges user authentication information with the Portal server using the Portal protocol, you must configure the listening port on the device to receive Portal packets.

You can run the **web-auth-server listening-port** command to set the number of the port through which the device listens on Portal packets. The port number must be the same as the destination port number in Portal packets sent by the Portal server and must be unique.

NOTE

If a specified port is occupied by another service or is a reserved port, the configuration fails. Ensure that the specified port is available when running this command.

Example

Set the number of the port through which a device listens on Portal protocol packets to 3000.

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server listening-port 3000
```

Related Topics

[13.5.56 display web-auth-server configuration](#)

13.5.166 web-auth-server reply-message

Function

The **web-auth-server reply-message** command enables the device to transparently transmit users' authentication responses sent by the authentication server to the Portal server.

The **undo web-auth-server reply-message** command disables the device from transparently transmitting users' authentication responses sent by the authentication server to the Portal server.

By default, the device transparently transmits users' authentication responses sent by the authentication server to the Portal server.

Format

web-auth-server reply-message

undo web-auth-server reply-message

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The AAA server requires that the authentication messages sent to the Portal server contain the authentication reply; therefore, the **web-auth-server reply-message** command is required. In certain situations, the authentication messages are not required to carry the reply. In this case, run the **undo web-auth-server reply-message** command.

By default, the device directly forwards the authentication result message from the RADIUS server to the Portal server without processing. This is called transparent transmission.

Example

Disable the device from transparently transmitting users' authentication responses to the Portal server.

```
<HUAWEI> system-view  
[HUAWEI] undo web-auth-server reply-message
```

Related Topics

[13.5.56 display web-auth-server configuration](#)

13.5.167 web-auth-server (system view)

Function

The **web-auth-server** command creates a Portal server template or displays the Portal server template view.

The **undo web-auth-server** command deletes a Portal server template.

By default, no Portal server template is created.

Format

web-auth-server *server-name*

undo web-auth-server *server-name*

Parameters

Parameter	Description	Value
<i>server-name</i>	Specifies the name of a Portal server.	The value is a string of 1 to 31 case-sensitive characters without spaces. NOTE <i>server-name</i> cannot be set to listening-port, reply-message, version, or the first character or several leftmost characters of these character strings.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When an unauthenticated Portal user goes online, the device forces the user to log in to a specified website (also called the Portal website). The user can access resources in the Portal website for free. When the user attempts to access charged network resources, the user must pass authentication on the Portal website. The specific process is as follows:

1. The unauthorized user opens Internet Explorer and enters a URL in the address box. When receiving the HTTP request sent by the user, the device redirects it to the Portal authentication page of the Portal server.
2. The user enters user information on the authentication page or in the authentication dialog box, and the Portal server forwards the user information to the device.
3. After receiving the user information from the Portal server, the device sends the information to the authentication server for authentication and accounting.

4. After the user is authenticated, the device allows the user to access the Internet if no security policy is enforced.

After a Portal server template is created on the device by using the **web-auth-server** command, run other commands to create a route from the device to the Portal server.

Follow-up Procedure

Run the following commands to configure related attributes of the Portal server template:

- Run the [13.5.141 server-ip \(Portal server template view\)](#) command to configure an IP address for the Portal server.
- Run the [13.5.150 url \(Portal server template view\)](#) command to configure a URL of the Portal server.
- Run the [13.5.104 port \(Portal server template view\)](#) command to set the port number that a Portal server uses to receive notification packets from the device.
- Run the [13.5.142 shared-key \(Portal server template view\)](#) command configures the shared key that the device uses to exchange information with the Portal server.

Precautions

You are advised to back up the Portal server data to prevent authentication failure caused by the Portal server fault.

If you want to run the **undo web-auth-server** command to delete a Portal server template, ensure that the Portal server template is not bound to the interface.

Example

```
# Create the Portal server template huawei.
```

```
<HUAWEI> system-view  
[HUAWEI] web-auth-server huawei
```

Related Topics

- [13.5.56 display web-auth-server configuration](#)
- [13.5.164 web-auth-server \(interface view\)](#)
- [13.5.150 url \(Portal server template view\)](#)
- [13.5.141 server-ip \(Portal server template view\)](#)
- [13.5.104 port \(Portal server template view\)](#)
- [13.5.142 shared-key \(Portal server template view\)](#)

13.5.168 web-redirection disable (Portal server template view)

Function

The **web-redirection disable** command disables the Portal authentication redirection function.

The **undo web-redirectation disable** command enables the Portal authentication redirection function.

By default, the Portal authentication redirection function is enabled.

Format

web-redirectation disable

undo web-redirectation disable

Parameters

None

Views

Portal server template view

Default Level

2: Configuration level

Usage Guidelines

The device redirects all unauthenticated users to the Portal authentication page when the users send access requests to external networks. For example, when the user needs to enter the URL of the authentication page manually, the **web-redirectation disable** command can be executed so that unauthorized users are not forcibly redirected to the Portal authentication page.

NOTE

If the Portal server template has been bound to the VLANIF interface, this command cannot be executed.

After this command is executed, if multiple server IP addresses are configured in the Portal server template and no URL is configured, the device does not display error information when the Portal server template is bound to the VLANIF interface.

Example

Disable the Portal authentication redirection function.

```
<HUAWEI> system-view
[HUAWEI] web-auth-server nac
[HUAWEI-web-auth-server-nac] web-redirectation disable
```

Related Topics

[13.5.56 display web-auth-server configuration](#)

13.6 Policy Association Configuration Commands

[13.6.1 Command Support](#)

- 13.6.2 [as access controller ip-address](#)
- 13.6.3 [as access interface](#)
- 13.6.4 [authentication access-point](#)
- 13.6.5 [authentication access-point max-user](#)
- 13.6.6 [authentication associate alarm-restrain enable](#)
- 13.6.7 [authentication associate alarm-restrain period](#)
- 13.6.8 [authentication control-point](#)
- 13.6.9 [authentication open ucl-policy enable](#)
- 13.6.10 [authentication speed-limit](#)
- 13.6.11 [control-down offline delay \(access device\)](#)
- 13.6.12 [control-down offline delay \(control device\)](#)
- 13.6.13 [display access-user as-name](#)
- 13.6.14 [display associate-user](#)
- 13.6.15 [display associate-user statistics](#)
- 13.6.16 [display authentication associate](#)
- 13.6.17 [display authentication associate alarm-restrain-table](#)
- 13.6.18 [display snmp-agent trap feature-name cfgmgr all](#)
- 13.6.19 [local-authorize](#)
- 13.6.20 [remote-authorize](#)
- 13.6.21 [snmp-agent trap enable feature-name cfgmgr](#)
- 13.6.22 [user-detect](#)
- 13.6.23 [user-sync \(access device\)](#)
- 13.6.24 [user-sync \(control device\)](#)

13.6.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

13.6.2 as access controller ip-address

Function

The **as access controller ip-address** command specifies an IP address for a control device on an access device.

The **undo as access controller ip-address** command deletes the IP address specified for a control device from an access device.

By default, no IP address is specified for a control device on an access device.

Format

as access controller ip-address *ip-address*

undo as access controller ip-address

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies an IP address for a control device.	The value is in dotted decimal notation.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

When the policy association solution is deployed, access and control devices establish connections through CAPWAP tunnels. When an access device dynamically obtains an IP address through the DHCP server, Option 43 is used to notify the access device of the IP address for the control device with which the access device establishes a CAPWAP tunnel. When an IP address is statically configured for an access device, the **as access controller ip-address** *ip-address* command is used to specify the IP address for the control device with which the access device establishes a CAPWAP tunnel.

Precautions

This command is supported only on access devices.

Example

```
# Specify an IP address for a control device.  
<HUAWEI> system-view  
[HUAWEI] as access controller ip-address 10.1.1.1
```

13.6.3 as access interface

Function

The **as access interface** command specifies source interface for establishing CAPWAP tunnels on an access device.

The **undo as access interface** command deletes the source interface specified for establishing CAPWAP tunnels from an access device.

By default, no source interface is specified for establishing CAPWAP tunnels on an access device.

Format

as access interface vlanif *vlan-id*

undo as access interface

Parameters

Parameter	Description	Value
vlanif <i>vlan-id</i>	Specifies a source interface for establishing CAPWAP tunnels.	The value is an integer that ranges from 1 to 4094.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

When the policy association solution is deployed, CAPWAP tunnels are used for connection establishment, user association, message communication, user authorization policy delivery, and user synchronization between control and access devices. On an access device, run the **as access interface vlanif** *vlan-id* command to specify a source interface for establishing CAPWAP tunnels.

Precautions

This command is supported only on access devices.

The management VLAN of the CAPWAP tunnel cannot be the same as the management VLAN of the cloud switch.

In policy association, the management VLAN of a CAPWAP tunnel connects access devices to the network. It is not recommended to perform other service configurations except basic configurations in the management VLAN and the corresponding VLANIF interface. If such configurations are performed, access devices may fail to connect to the network.

Example

Specify a source interface for establishing CAPWAP tunnels.

```
<HUAWEI> system-view  
[HUAWEI] vlan batch 10  
[HUAWEI] interface vlanif 10  
[HUAWEI-Vlanif10] quit  
[HUAWEI] as access interface vlanif 10
```

13.6.4 authentication access-point

Function

The **authentication access-point** command enables remote access control on the interface of an access device.

The **undo authentication access-point** command disables remote access control on the interface of an access device.

By default, remote access control is disabled on the interface of an access device.

Format

authentication access-point [**open**]

undo authentication access-point [**open**]

Parameters

Parameter	Description	Value
open	Disables right control of the access point.	-

Views

Ethernet interface view, MultiGE interface view, 40GE interface view, GE interface view, XGE interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When you deploy policy association, configure the interface of each access device as the access point and enable remote access control on the interface.

To configure right control on a control device instead of an access device, you can disable right control of the access point on the access device (by specifying the **open** parameter).

Precautions

This command is supported only on access devices.

 NOTE

When you run the **authentication access-point** and **undo authentication access-point** commands, ensure that no authentication type is enabled on the interface. Otherwise, disable the authentication type before you run the commands.

The **authentication access-point open** and **authentication access-point** command must be run together; otherwise, the **authentication access-point open** command cannot take effect.

The interface types vary according to device models.

If there is a terminal with one MAC address and multiple IP addresses on the live network, you need to configure the function of identifying static users through IP addresses on the control device. However, because the access device cannot generate multiple entries for the terminal, you cannot implement right control on the access device. In this case, you need to disable right control of the access point on the access device. Otherwise, packets of the terminal will not be forwarded.

Example

```
# Configure GE0/0/1 as the access point.  
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] authentication access-point
```

Related Topics

[13.6.8 authentication control-point](#)

13.6.5 authentication access-point max-user

Function

The **authentication access-point max-user** command sets the maximum number of access users allowed on an interface of an access device.

The **undo authentication access-point max-user** command restores the default setting.

By default, an access device does not limit the maximum number of users who are allowed to log in through its interfaces.

Format

authentication access-point max-user *max-user-number*

undo authentication access-point max-user

Parameters

Parameter	Description	Value
<i>max-user-number</i>	Specifies the maximum number of access users allowed on an interface of an access device.	The value is an integer that ranges from 1 to 128 for S2750EI, and S5700S-LI, from 1 to 512 for S5720EI, S6720EI, and S6720S-EI, and from 1 to 256 for other models.

Views

Ethernet interface view, MultiGE interface view, 40GE interface view, GE interface view, XGE interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To limit the maximum number of access users allowed on an interface of an access device, run the **authentication access-point max-user** command.

Precautions

This command is supported only on access devices.

This command takes effect only for users who attempt to log in for the first time.

The interface types vary according to device models.

Example

Set the maximum number of access users allowed on GE 0/0/1 to 100.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] authentication access-point max-user 100
```

Related Topics

[13.6.8 authentication control-point](#)

13.6.6 authentication associate alarm-restrain enable

Function

The **authentication associate alarm-restrain enable** command enables an access device to suppress alarms that are generated due to excess associated users.

The **undo authentication associate alarm-restrain enable** command disables alarm suppression.

By default, an access device is enabled to suppress alarms that are generated due to excess associated users.

Format

authentication associate alarm-restrain enable

undo authentication associate alarm-restrain enable

Parameters

None

Views

System view

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

If associated users fail to log in to an access device due to the configured limitation on the access number, the device generates alarms about the login failure event.

These alarms consume device resources and affect system performance. To prevent the device from generating too many repeated alarms in a short period, run the **authentication associate alarm-restrain enable** command to enable suppression on these alarms. The device then does not generate alarms of the same type within a specified suppression period (set using the [13.6.7 authentication associate alarm-restrain period](#) command).

Precautions

This command is supported only on access devices.

Example

Enable an access device to suppress alarms that are generated due to excess associated users.

```
<HUAWEI> system-view  
[HUAWEI] authentication associate alarm-restrain enable
```

13.6.7 authentication associate alarm-restrain period

Function

The **authentication associate alarm-restrain period** command sets a suppression period for alarms that an access device generates due to excess associated users.

The **undo authentication associate alarm-restrain period** command restores the default setting.

By default, an access device suppresses such alarms for 300 seconds.

Format

authentication associate alarm-restrain period *period-value*

undo authentication associate alarm-restrain period

Parameters

Parameter	Description	Value
<i>period-value</i>	Specifies a suppression period for alarms that an access device generates due to excess associated users.	The value is an integer that ranges from 60 to 604800, in seconds.

Views

System view

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After an access device is enabled to suppress alarms that are generated due to excess associated users using the **authentication associate alarm-restrain enable** command, run the **authentication associate alarm-restrain period** command to set a suppression period for these alarms. The device then does not generate alarms of the same type within the suppression period.

Precautions

This command is supported only on access devices.

Example

Set the suppression period to 600s for alarms that an access device generates due to excess associated users.

```
<HUAWEI> system-view  
[HUAWEI] authentication associate alarm-restrain period 600
```

13.6.8 authentication control-point

Function

The **authentication control-point** command configures an interface as the control point.

The **undo authentication control-point** command restores the default setting.

By default, an interface does not function as a control point.

Format

authentication control-point [open]

undo authentication control-point

Parameters

Parameter	Description	Value
open	Enables the forwarding function of the control point.	-

Views

VLANIF interface view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, 100GE interface view, Eth-Trunk interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When policy association is configured, the interface on a control device is configured as the control point. If the **open** parameter is configured, the control point directly forwards user traffic. If the **open** parameter is not configured, the control point manages the forwarding rights for user traffic through NAC authentication.

Precautions

- This command is supported only on control devices.
- When the VLANIF interface is configured as the NAC authentication interface, the VLANIF interface and its mapping physical interface must be configured as control points. However, NAC authentication cannot be configured on the physical interface. The **open** parameter cannot be configured for a VLANIF interface.
- When you run the **authentication control-point [open]** and **undo authentication control-point** commands, check whether any authentication type is enabled on the interface. If yes, disable the authentication type before you run the commands.
- When the interface below functions as the control point, it can only directly forward user traffic. That is, only the **authentication control-point open** command can be configured.
 - An interface on the cards except LE1D2S04SEC0 card, LE1D2X32SEC0 card, LE1D2H02QEC0 card, and X series cards

- An Eth-Trunk interface containing interfaces on the cards except LE1D2S04SEC0 card, LE1D2X32SEC0 card, LE1D2H02QEC0 card, and X series
- An interface on the S6720SI, S6720S-SI, S6720EI or S6720S-EI
- An Eth-Trunk interface containing interfaces on the S6720SI, S6720S-SI, S6720EI or S6720S-EI

Example

```
# Configure GE0/0/1 as the control point.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet0/0/1  
[HUAWEI-GigabitEthernet0/0/1] authentication control-point
```

Related Topics

[13.6.4 authentication access-point](#)

13.6.9 authentication open ucl-policy enable

Function

The **authentication open ucl-policy enable** command configures a control point where the **authentication control-point open** command has been configured to filter user traffic based on a user ACL before forwarding the traffic.

The **undo authentication open ucl-policy enable** command restores a control point where **authentication control-point open** has been configured to directly forwarding user traffic.

By default, a control point where **authentication control-point open** has been configured directly forwards user traffic.

NOTE

Only the S5720HI, LE1D2S04SEC0 card, LE1D2X32SEC0 card, LE1D2H02QEC0 card, and X series cards support this command.

Format

authentication open ucl-policy enable

undo authentication open ucl-policy enable

Parameters

None

Views

GE interface view, XGE interface view, 40GE interface view, 100GE interface view, Eth-Trunk interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

This command is applicable to the following scenarios:

- When only independent policy association is used, the **authentication control-point open** command has been configured on a control point.
- When policy association is used in an SVF system, the **authentication control-point open** command is configured on a control point by default.

A control point directly forwards traffic from wired users who go online on an interface of the access device without authentication and the traffic from wireless users in direct forwarding mode. To enable the control point to filter user traffic based on a user ACL, run the **authentication open ucl-policy enable** command.

Prerequisites

The control device has been configured to filter packets based on a user ACL using the **traffic-filter inbound acl { acl-number | name acl-name }** command.

Precautions

This command can be executed only on the control device.

Example

Configure the control point GE1/0/1 where the **authentication control-point open** command has been configured to filter user traffic based on a user ACL before forwarding the traffic.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet1/0/1
[HUAWEI-GigabitEthernet1/0/1] authentication control-point open
[HUAWEI-GigabitEthernet1/0/1] authentication open ucl-policy enable
```

Related Topics

[13.6.8 authentication control-point](#)

13.6.10 authentication speed-limit

Function

The **authentication speed-limit** command configures the rate limit for an access device to send user association and disassociation request messages.

The **undo authentication speed-limit** command restores the default rate limit for an access device to send user association and disassociation request messages.

By default, an access device sends a maximum of 60 user association and disassociation request messages within 30 seconds.

Format

authentication speed-limit max-num *max-num-value* **interval** *interval-value*
undo authentication speed-limit

Parameters

Parameter	Description	Value
max-num <i>max-num-value</i>	Specifies the maximum number of user association and disassociation request messages.	The value is an integer that ranges from 1 to 65535. The default value is 60.
interval <i>interval-value</i>	Specifies the interval for an access device to send user association and disassociation request messages.	The value is an integer that ranges from 1 to 65535, in seconds. The default value is 30.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

A control device can connect to multiple access devices. If the rate limit for an access device to send user association and disassociation request messages is not specified, there will be a heavy load on the control device. You can run this command to adjust the rate limit.

Precautions

This command is supported only on access devices.

In an SVF system, commands cannot be configured on ASs. When the access rate of users is high, they may fail to go online due to a rate limit. To lower the rate limit, run the **direct-command** command on the UC device to deliver the **authentication speed-limit** command configuration to the ASs. This requires that the ASs run V200R013C00 or a later version.

Example

```
# Configure the access device to send a maximum of 100 association and  
disassociation request messages within 10 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] authentication speed-limit max-num 100 interval 10
```

13.6.11 control-down offline delay (access device)

Function

The **control-down offline delay** command configures the user logout delay on an access device when a control tunnel is faulty.

The **undo control-down offline delay** command restores the default user logout delay on an access device when a control tunnel is faulty.

By default, the users on an access device go offline immediately when a control tunnel is faulty.

Format

control-down offline delay { *delay-value* | **unlimited** }

undo control-down offline delay

Parameters

Parameter	Description	Value
<i>delay-value</i>	Specifies the user logout delay when a control tunnel is faulty.	The value is an integer that ranges from 1 to 60, in seconds. The default value is 0, indicating that users immediately go offline when a control tunnel is faulty.
unlimited	Specifies the user logout delay as unlimited. That is, users do not go offline when a control tunnel is faulty.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

You can run the **control-down offline delay** command to configure the user logout delay on an access device when a control tunnel is faulty. In this way, the

users will not directly go offline upon a tunnel fault. If the fault persists after the delay, the users go offline; if the fault is rectified within the delay, the users keep online.

Precautions

This command is supported only on access devices.

You are advised to configure the same user logout delay on control devices and access devices.

Example

Configure the user logout delay to 10 seconds on an access device after the control tunnel is faulty.

```
<HUAWEI> system-view  
[HUAWEI] control-down offline delay 10
```

Related Topics

[13.6.12 control-down offline delay \(control device\)](#)

13.6.12 control-down offline delay (control device)

Function

The **control-down offline delay** command configures the user logout delay on a control device when a control tunnel is faulty.

The **undo control-down offline delay** command restores the default user logout delay on a control device when a control tunnel is faulty.

By default, users on a control device go offline immediately when a control tunnel is faulty.

Format

control-down offline delay { *delay-value* | **unlimited** }

undo control-down offline delay

Parameters

Parameter	Description	Value
<i>delay-value</i>	Specifies the user logout delay when a control tunnel is faulty.	The value is an integer that ranges from 1 to 60, in seconds. The default value is 0, indicating that users immediately go offline when a control tunnel is faulty.

Parameter	Description	Value
unlimited	Specifies the user logout delay as unlimited. That is, users do not go offline when a control tunnel is faulty.	-

Views

Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, 100GE interface view, Eth-Trunk interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

You can run the **control-down offline delay** command to configure the user logout delay on a control device when a control tunnel is faulty. In this way, the users will not directly go offline upon a tunnel fault. If the fault persists after the delay, the users go offline; if the fault is rectified within the delay, the users keep online.

Precautions

This command is supported only on control devices.

You are advised to configure the same user logout delay on control devices and access devices.

When you configure users not to go offline upon a channel tunnel failure, you also need to configure **link-down offline delay unlimited** command in the authentication profile view.

Example

Configure the user logout delay to 10 seconds on GE0/0/1 of the control device after a control tunnel is faulty.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet0/0/1  
[HUAWEI-GigabitEthernet0/0/1] control-down offline delay 10
```

Related Topics

[13.6.11 control-down offline delay \(access device\)](#)

13.6.13 display access-user as-name

Function

The **display access-user as-name** command displays information about online users on a specified access device.

Format

display access-user as-name *as-name*

Parameters

Parameter	Description	Value
<i>as-name</i>	Specifies the name of an access device.	The value is the name of an existing access device.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run this command to check information about online access users on a control device.

The actual name of an access device may differ from the name displayed on the control device (using the **display as all** command). When an access device goes online, its name is processed as follows:

- If the access device uses the default name, its name is changed to *default name-MAC address of the access device* on the control device.
- If the access device name contains spaces or double quotation marks ("), the spaces are changed to en dashes (-) and the double quotation marks (") are changed to single quotation marks (') on the control device.

Example

```
# Display information about users on the access device test_as.
```

```
<HUAWEI> display access-user as-name test_as
-----
UserID Username      IP address  MAC        Status
-----
16019  fdsa@none          192.168.6.5  00e0-4c88-143f Success
-----
Total: 1, printed: 1
```

 **NOTE**

Only letters, digits, and special characters can be displayed for **username**.

When the value of **username** contains special characters or characters in other languages except English, the device displays dots (.) for these characters. If there are more than three such consecutive characters, three dots (.) are displayed. Here, the special characters are the ASCII codes smaller than 32 (space) or larger than 126 (~).

Table 13-104 Description of the **display access-user as-name** command output

Item	Description
UserID	ID that is assigned to a user after the user goes online.
Username	Name of a user.
IP address	IP address of a user.
MAC	MAC address of a user.
Status	Status of a user.

13.6.14 display associate-user

Function

The **display associate-user** command displays associated users on devices.

Format

```
display associate-user
```

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

You can run this command to check associated users on access devices and control devices.

Precautions

There are no longer associated users on control devices after the users are successfully authenticated or added to domains. You can run the [13.1.34 display access-user \(All views\)](#) command to check user information.

Example

Display the associated users on a control device.

```
<HUAWEI> display associate-user
-----
UserID IP address   MAC           SA MAC
-----
27    192.168.12.1    00e0-4c88-143f dcba-6543-e00a
-----
Total: 1, printed: 1
```

Table 13-105 Description of the **display associate-user** command output

Item	Description
UserID	ID that is assigned to a user after the user is associated.
IP address	IP address of a user.
MAC	MAC address of a user.
SA MAC	MAC address of an access device.

Display the associated users on an access device.

```
<HUAWEI> display associate-user
-----
UserID IP address   MAC           Status   Trigger type
-----
27    192.168.12.1    00e0-4c88-143f Associated Arp
-----
Total: 1, printed: 1
```

Table 13-106 Description of the **display associate-user** command output

Item	Description
UserID	ID that is assigned to a user after the user is associated.
IP address	IP address of a user.
MAC	MAC address of a user.

Item	Description
Status	<p>Status of a user.</p> <ul style="list-style-type: none"> ● Up: indicates that the access device has received the authentication success notification from the control device and enabled data forwarding rights for users. ● Associated: indicates that the access device has received the association success response from the control device and is waiting for the authentication success notification from the control device. ● Idle: indicates that the access device detects that the user has been connected and periodically sends an association request or is waiting for the association response from the control device. ● Deleting: indicates that the user has been added to the logout queue and is waiting for logout.
Trigger type	<p>Triggering type.</p> <ul style="list-style-type: none"> ● Arp: indicates that ARP packets are sent to trigger creation of the association table. ● Dot1x: indicates that dot1x packets are sent to trigger creation of the association table. ● Http: indicates that HTTP packets are sent to trigger creation of the association table. ● Dhcp: indicates that DHCP packets are sent to trigger creation of the association table.

13.6.15 display associate-user statistics

Function

The **display associate-user statistics** command displays statistics about associated users on an interface.

Format

display associate-user statistics [**interface** *interface-type interface-number*]

Parameters

Parameter	Description	Value
interface <i>interface-type</i> <i>interface-number</i>	Displays statistics about associated users on a specified interface. <ul style="list-style-type: none"> <i>interface-type</i> specifies the type of the interface. <i>interface-number</i> specifies the number of the interface. 	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

To check statistics about associated users on an interface, run the **display associate-user statistics** command.

Precautions

This command is supported only on access devices.

Example

Display statistics about associated users on an interface.

```
<HUAWEI> display associate-user statistics
```

```
-----  
Interface          number  
-----
```

```
GigabitEthernet0/0/1    3  
TotalNumber             3  
-----
```

```
Total 1
```

Table 13-107 Description of the **display associate-user statistics** command output

Item	Description
Interface	Interface that functions as an access point.

Item	Description
number	Number of associated users on a specified access point.
TotalNumber	Total number of associated users on all access points.
Total: <i>m</i>	Total number of interfaces with which users are associated.

13.6.16 display authentication associate

Function

The **display authentication associate** command displays the global configurations of associated users.

Format

display authentication associate

Parameters

None

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

To check the global configurations of associated users, run the **display authentication associate** command. The command output contains the suppression status of alarms that an access device generates due to excess associated users and the configured alarm suppression period.

Precautions

This command is supported only on access devices.

Example

```
# Display the global configurations of associated users.
```

```
<HUAWEI> display authentication associate
authentication associate alarm-restrain: Enable
authentication associate alarm-restrain period: 300
```

Table 13-108 Description of the **display authentication associate** command output

Item	Description
authentication associate alarm-restrain	<p>Suppression status of alarms that an access device generates due to excess associated users:</p> <ul style="list-style-type: none"> • Enable • Disable <p>To configure a suppression status, run the 13.6.6 authentication associate alarm-restrain enable command.</p>
authentication associate alarm-restrain period	<p>Suppression period for alarms that an access device generates due to excess associated users.</p> <p>To configure a suppression period, run the 13.6.7 authentication associate alarm-restrain period command.</p>

13.6.17 display authentication associate alarm-restrain-table

Function

The **display authentication associate alarm-restrain-table** command displays suppression table information of alarms that are generated due to excess associated users.

Format

```
display authentication associate alarm-restrain-table { all | interface interface-type interface-number }
```

Parameters

Parameter	Description	Value
all	Displays alarm suppression table information on all interfaces.	-

Parameter	Description	Value
interface <i>interface-type</i> <i>interface-number</i>	Displays alarm suppression table information on a specified interface. <ul style="list-style-type: none"> <i>interface-type</i> specifies the type of the interface. <i>interface-number</i> specifies the number of the interface. 	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

Usage Scenario

After an access device is enabled to suppress alarms that are generated due to excess associated users using the **authentication associate alarm-restrain enable** command, run the **display authentication associate alarm-restrain-table** command to check the alarm suppression table information.

Precautions

This command is supported only on access devices.

Example

Display alarm suppression table information on all interfaces.

```
<HUAWEI> display authentication associate alarm-restrain-table all
-----
Interface          alarm time
-----
GigabitEthernet0/0/1  --
-----
Total 1
```

Table 13-109 Description of the **display authentication associate alarm-restrain-table all** command output

Item	Description
Interface	Interface that functions as an access point.

Item	Description
alarm time	Date and time when alarms were generated.
Total: <i>m</i>	Total number of suppressed entries <i>m</i> .

13.6.18 display snmp-agent trap feature-name cfgmgr all

Function

The **display snmp-agent trap feature-name cfgmgr all** command displays the status of all traps for the cfgmgr module.

Format

```
display snmp-agent trap feature-name cfgmgr all
```

Parameters

None

Views

All views

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After enabling the trap function for the cfgmgr module, you can run the **display snmp-agent trap feature-name cfgmgr all** command to check the status of all traps for the cfgmgr module. To enable the trap function for the cfgmgr module, run the **snmp-agent trap enable feature-name cfgmgr** command.

Prerequisites

The SNMP function has been enabled on the device.

Example

```
# Display the status of all traps for the cfgmgr module.
```

```
<> display snmp-agent trap feature-name cfgmgr all
-----
Feature name: cfgmgr
Trap number : 1
-----
Trap name           Default switch status  Current switch status
```

```
hwAuthenAssociateAccessLimitTrap
    on          on
```

Table 13-110 Description of the **display snmp-agent trap feature-name cfgmgr all** command output

Item	Description
Feature name	Name of a module to which a trap belongs
Trap number	Number of traps.
Trap name	Trap name. Traps of the cfgmgr module include: <ul style="list-style-type: none"> hwAuthenAssociateAccessLimitTrap: A Huawei proprietary trap is sent when the number of associated users on an interface exceeds the maximum value.

13.6.19 local-authorize

Function

The **local-authorize** command specifies the user authorization information to be delivered to a control device.

The **undo local-authorize** command restores the default user authorization information to be delivered to a control device.

By default, all user authorization information can be delivered to a control device.

Format

```
local-authorize { none | { acl | car | priority | ucl-group | vlan } * }
```

```
undo local-authorize
```

Parameters

Parameter	Description	Value
acl	Delivers ACL authorization information.	-
car	Delivers CAR authorization information.	-

Parameter	Description	Value
priority	Delivers priority authorization information.	-
ucl-group	Delivers UCL group authorization information. NOTE When you authorize the ACL or UCL group, configure the corresponding ACL or UCL group on control devices to ensure that the authorization information takes effect on the control devices.	-
vlan	Delivers VLAN authorization information.	-
none	Delivers no authorization information.	-

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To enable a control device to implement specified user access policies, you can run this command to specify user authorization information to be delivered to the control device. By default, all authorization information is delivered to a control device.

Precautions

This command is supported only on control devices.

This command takes effect for all user authorization types, such as local authorization, remote authorization, and RADIUS dynamic authorization.

For VLAN authorization in a policy association scenario, VLAN authorization information must be delivered. You must configure the **local-authorize vlan** command or do not configure the **local-authorize** command, that is, use the

default settings. By default, all user authorization information can be delivered to a control device.

Example

Deliver only UCL group authorization information to the control device.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme huawei
[HUAWEI-aaa-service-huawei] local-authorize ucl-group
```

Related Topics

[13.6.20 remote-authorize](#)

13.6.20 remote-authorize

Function

The **remote-authorize** command specifies the user authorization information to be delivered to an access device.

The **undo remote-authorize** command restores the default user authorization information to be delivered to an access device.

By default, all user authorization information cannot be delivered to access devices.

Format

remote-authorize { **acl** | **car** | **ucl-group** } *

undo remote-authorize

Parameters

Parameter	Description	Value
acl	Delivers ACL authorization information.	-
car	Delivers CAR authorization information.	-

Parameter	Description	Value
ucl-group	Delivers UCL group authorization information. NOTE When you authorize the ACL or UCL group, configure the corresponding ACL or UCL group on access devices to ensure that the authorization information takes effect on the access devices.	-

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

To enable an access device to implement specified user access policies, you can run this command to specify user authorization information to be delivered to the access device. By default, no authorization information is delivered to the access device.

Precautions

This command is supported only on access devices.

This command takes effect for all user authorization information, including local authorization, remote authorization, and RADIUS dynamic authorization information.

In SVF centralized configuration mode, access devices do not support ACL-based authorization or UCL groups.

Example

Deliver only ACL authorization information to the access device.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme huawei
[HUAWEI-aaa-service-huawei] remote-authorize acl
```

Related Topics

[13.6.19 local-authorize](#)

13.6.21 snmp-agent trap enable feature-name cfgmgr

Function

The **snmp-agent trap enable feature-name cfgmgr** command enables the trap function for the cfgmgr module.

The **undo snmp-agent trap enable feature-name mid_aaa** command disables the trap function for the cfgmgr module.

By default, the trap function is enabled for the cfgmgr module.

Format

**snmp-agent trap enable feature-name cfgmgr [trap-name
hwauthenassociateaccesslimittrap]**

**undo snmp-agent trap enable feature-name cfgmgr [trap-name
hwauthenassociateaccesslimittrap]**

Parameters

Parameter	Description	Value
cfgmgr	Enables or disables the trap function for the specified event of the cfgmgr module.	-
hwauthenassociateaccesslimittrap	Enables the device to send a Huawei proprietary trap when the number of associated users on an interface exceeds the maximum value.	-

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

After the trap function is enabled, the device generates traps during operation and sends the traps to the NMS through the SNMP module. If the trap function is disabled, the device does not generate traps and the SNMP module does not send traps to the NMS.

You can specify **trap-name** as required to enable the trap function for one or more events.

Example

```
# Enable the hwauthenassociateaccesslimittrap trap function for the cfgmgr module.
```

```
<> system-view  
[] snmp-agent trap enable feature-name cfgmgr trap-name hwauthenassociateaccesslimittrap
```

13.6.22 user-detect

Function

The **user-detect** command enables the online user detection function on an access device.

The **undo user-detect** command disables the online user detection function on an access device.

By default, the online user detection function is enabled on an access device, the detection interval is 15 seconds, and the number of packet retransmission attempts is 3.

Format

```
user-detect { interval interval-value | retry retry-value } *
```

```
undo user-detect
```

Parameters

Parameter	Description	Value
interval <i>interval-value</i>	Specifies the detection interval.	The value is an integer that ranges from 1 to 65535, in seconds. The default value is 15.
retry <i>retry-value</i>	Specifies the number of packet retransmission attempts.	The value is an integer that ranges from 1 to 255. The default value is 3.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If a user goes offline due to a power failure or network interruption, the access device and control device may still store information about this user, which results in a heavy load on the control device. In addition, a limited number of users can access the device. If a user goes offline unexpectedly but the device still stores information of this user, other users cannot access the network.

After the detection interval is set, the device considers a user to be offline if the user does not respond within the interval. Then the access device and control device delete the saved information about the user, ensuring effective resource usage.

Precautions

This command is supported only on access devices.

You are advised to keep this function enabled on access devices.

This function takes effect only for users who go online after it is configured.

Example

Enable online user detection in the system view, and set the detection interval to 10 seconds and number of packet retransmission attempts to 5.

```
<HUAWEI> system-view  
[HUAWEI] user-detect interval 10 retry 5
```

13.6.23 user-sync (access device)

Function

The **user-sync** command enables the user synchronization function on an access device.

The **undo user-sync** command disables the user synchronization function on an access device.

By default, user synchronization is enabled on an access device and the synchronization interval is 60 seconds.

Format

user-sync interval *interval-value*

undo user-sync

Parameters

Parameter	Description	Value
interval <i>interval-value</i>	Specifies the user synchronization interval.	The value is an integer that ranges from 60 to 3600, in seconds. The default value is 60.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If a user is disconnected from an access device due to online detection or a failure to send a disconnection request message, the user information on the control device and access device cannot be synchronized.

After the user synchronization interval is reached, the access device sends a synchronization message containing MAC addresses of all online users to the control device. After receiving the synchronization message, the control device responds with a synchronization failure message if it finds that some users are offline. The access device forcibly disconnects the corresponding users according to the synchronization failure message.

Precautions

This command is supported only on access devices.

The user synchronization function needs to be enabled on both access devices and control devices to ensure that the function works properly. In addition, the user synchronization interval configured on access devices must be shorter than or equal to that configured on control devices, preventing users from being disconnected due to incorrect synchronization.

The user synchronization function of access devices depends on whether the control tunnel is available. When the control tunnel is faulty, the user synchronization function becomes abnormal.

Example

```
# Set the user synchronization interval to 100 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] user-sync interval 100
```

Related Topics

[13.6.24 user-sync \(control device\)](#)

13.6.24 user-sync (control device)

Function

The **user-sync** command enables the user synchronization function on a control device.

The **undo user-sync** command disables the user synchronization function on a control device.

By default, user synchronization is enabled on a control device, the synchronization interval is 60 seconds, and the number of synchronization attempts is 10.

Format

user-sync { **interval** *interval-value* | **retry** *retry-value* } *

undo user-sync

Parameters

Parameter	Description	Value
interval <i>interval-value</i>	Specifies the user synchronization interval.	The value is an integer that ranges from 60 to 3600, in seconds. The default value is 60.
retry <i>retry-value</i>	Specifies the maximum number of synchronization attempts.	The value is an integer that ranges from 5 to 300. The default value is 10.

Views

VLANIF interface view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, 100GE interface view, Eth-Trunk interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If a user is disconnected from an access device due to online detection or a failure to send a disconnection request message, the user information on the control device and access device cannot be synchronized.

After the user synchronization interval is reached, the number of synchronization attempts is added by 1. If the number of synchronization attempts reaches the maximum, the user is forced offline. If the access device detects that the user is online by sending a synchronization message, the number of synchronization attempts is set to 0.

Precautions

This command is supported only on control devices.

The user synchronization function needs to be enabled on both access devices and control devices to ensure that the function works properly. In addition, the user synchronization interval configured on access devices must be shorter than or equal to that configured on control devices, preventing users from being disconnected due to incorrect synchronization.

Example

Set the user synchronization interval to 100 seconds and maximum number of synchronization attempts to 15 on GE0/0/1 of the control device.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet0/0/1  
[HUAWEI-GigabitEthernet0/0/1] user-sync interval 100 retry 15
```

Related Topics

[13.6.23 user-sync \(access device\)](#)