

# 16 Network Management and Monitoring Commands

---

## About This Chapter

- [16.1 SNMP Configuration Commands](#)
- [16.2 RMON and RMON2 Configuration Commands](#)
- [16.3 LLDP Configuration Commands](#)
- [16.4 Performance Management Commands](#)
- [16.5 iPCA Configuration Commands](#)
- [16.6 NQA Configuration Commands](#)
- [16.7 Service Diagnosis Configuration Commands](#)
- [16.8 Mirroring Configuration Commands](#)
- [16.9 Packet Capture Configuration Command](#)
- [16.10 NetStream Configuration Commands](#)
- [16.11 sFlow Configuration Commands](#)
- [16.12 Ping and Tracert Configuration Commands](#)
- [16.13 TWAMP Light Configuration Commands](#)
- [16.14 NETCONF Configuration Commands](#)

## 16.1 SNMP Configuration Commands

- [16.1.1 Command Support](#)
- [16.1.2 clear configuration snmp-agent trap enable](#)
- [16.1.3 display snmp-agent](#)

- 16.1.4 display snmp-agent community
- 16.1.5 display snmp-agent extend error-code status
- 16.1.6 display snmp-agent group
- 16.1.7 display snmp-agent heartbeat configuration
- 16.1.8 display snmp-agent inform
- 16.1.9 display snmp-agent mib-view
- 16.1.10 display snmp-agent notification-log
- 16.1.11 display snmp-agent notify-filter-profile
- 16.1.12 display snmp-agent statistics
- 16.1.13 display snmp-agent statistics mib
- 16.1.14 display snmp-agent sys-info
- 16.1.15 display snmp-agent target-host
- 16.1.16 display snmp-agent trap all
- 16.1.17 display snmp-agent trap feature-name all
- 16.1.18 display snmp-agent trap feature-name snmp all
- 16.1.19 display snmp-agent usm-user
- 16.1.20 enable snmp trap updown
- 16.1.21 reset snmp-agent statistics mib
- 16.1.22 snmp-agent
- 16.1.23 snmp-agent acl
- 16.1.24 snmp-agent community
- 16.1.25 snmp-agent community complexity-check disable
- 16.1.26 snmp-agent extend error-code enable
- 16.1.27 snmp-agent group
- 16.1.28 snmp-agent heartbeat enable
- 16.1.29 snmp-agent heartbeat interval
- 16.1.30 snmp-agent inform
- 16.1.31 snmp-agent inform address
- 16.1.32 snmp-agent local-engineid
- 16.1.33 snmp-agent mib-view
- 16.1.34 snmp-agent notification-log
- 16.1.35 snmp-agent notification-log enable
- 16.1.36 snmp-agent notify-filter-profile

- 16.1.37 snmp-agent packet contextengineid-check enable
- 16.1.38 snmp-agent packet max-size
- 16.1.39 snmp-agent packet-priority
- 16.1.40 snmp-agent protocol get-bulk timeout
- 16.1.41 snmp-agent protocol server disable
- 16.1.42 snmp-agent protocol source-interface
- 16.1.43 snmp-agent protocol server message queue
- 16.1.44 snmp-agent statistics mib disable
- 16.1.45 snmp-agent sys-info
- 16.1.46 snmp-agent target-host inform
- 16.1.47 snmp-agent target-host trap
- 16.1.48 snmp-agent target-host trap ipv6
- 16.1.49 snmp-agent trap disable
- 16.1.50 snmp-agent trap enable
- 16.1.51 snmp-agent trap enable feature-name
- 16.1.52 snmp-agent trap enable feature-name snmp
- 16.1.53 snmp-agent trap life
- 16.1.54 snmp-agent trap queue-size
- 16.1.55 snmp-agent trap start-trap resend disable
- 16.1.56 snmp-agent trap source
- 16.1.57 snmp-agent trap source-port
- 16.1.58 snmp-agent trap type
- 16.1.59 snmp-agent udp-port
- 16.1.60 snmp-agent usm-user
- 16.1.61 snmp-agent usm-user password complexity-check disable

## 16.1.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

## 16.1.2 clear configuration snmp-agent trap enable

### Function

The **clear configuration snmp-agent trap enable** command deletes alarm configurations related to one or all functions in a batch and restores the default alarm functions.

### Format

**clear configuration snmp-agent trap enable** [ **feature-name** *feature-name* ]

### Parameters

Parameter	Description	Value
<b>feature-name</b> <i>feature-name</i>	Deletes configurations of the trap function of a feature.	The value is the name of a feature that has been supported by the device.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

After a feature trap function is enabled or disabled using the **snmp-agent trap enable feature-name** *feature-name* [ **trap-name** *trap-name* ] command, the trap functions of all features are enabled using the **snmp-agent trap enable** command, or the trap functions of all features are disabled using the **snmp-agent trap disable** command. To delete the configurations, run the **clear configuration snmp-agent trap enable** command.

#### Configuration Impact

- When the trap function is enabled or disabled globally, running the **clear configuration snmp-agent trap enable feature-name** *feature-name* command deletes configurations of the trap function of the feature specified by *feature-name* and restores the status of the trap function to be the same as that of the global trap function.
- When the global trap function is in the default state, running the **clear configuration snmp-agent trap enable feature-name** *feature-name* command deletes configurations of the trap function of the feature specified by *feature-name* and restores the status of the trap function to be the default status.

- Running the **clear configuration snmp-agent trap enable** command deletes configurations of the trap functions of all features and restores all feature alarm functions to the default status.

## Example

```
# Delete configurations of the trap functions of all features.
```

```
<HUAWEI> system-view  
[HUAWEI] clear configuration snmp-agent trap enable
```

## 16.1.3 display snmp-agent

### Function

The **display snmp-agent** command displays the engine ID of the local or remote SNMP agent.

### Format

```
display snmp-agent { local-engineid | remote-engineid }
```

### Parameters

Parameter	Description	Value
<b>local-engineid</b>	Displays the engine ID of the local SNMP agent.	-
<b>remote-engineid</b>	Displays the engine ID of a remote SNMP agent.	-

### Views

All views

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

After the SNMP agent function is enabled, you can run the **display snmp-agent { local-engineid | remote-engineid }** command to view the engine ID of the local or remote SNMP agent.

The engine ID of the SNMP agent uniquely identifies an SNMP agent in a management domain. The engine ID of the SNMP agent is an important component of the SNMP agent. It schedules and processes SNMP messages, implements security authentication, access control and so on.

#### Prerequisites

Before running the **display snmp-agent { local-engineid | remote-engineid }** command to view the engine ID of the local or remote SNMP agent, you need to run the **snmp-agent** command to enable the SNMP agent function.

### Precautions

To configure an engine ID for the local SNMP agent, you can run the **snmp-agent local-engineid** command.

## Example

# Display the engine ID of the local SNMP agent.

```
<HUAWEI> display snmp-agent local-engineid  
SNMP local EngineID: 800007DB03360102101100
```

**Table 16-1** Description of the **display snmp-agent local-engineid** command output

Item	Description
SNMP local EngineID	The engine ID of the local SNMP agent.

## Related Topics

[16.1.32 snmp-agent local-engineid](#)

## 16.1.4 display snmp-agent community

### Function

The **display snmp-agent community** command displays the configured community name.

### Format

**display snmp-agent community [ read | write ] \***

### Parameters

Parameter	Description	Value
<b>read</b>	Displays the name of a community with read-only permission.	-
<b>write</b>	Displays the name of a community with read and write permission.	-

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

When configuring a management entity, you can use the **display snmp-agent community** command to check the community name configured on the current agent.

If the parameter **read** or **write** is not specified, the names of all communities are displayed.

You have to configure the community name using the **snmp-agent community** command before you run the **display snmp-agent community** command.

## Example

# Display the current community name.

```
<HUAWEI> display snmp-agent community
Community name: %^%#.T|&Whvyf$<Gd"l,wXi5SP_6~Nakk6<<+3H:N-h@aJ6d,l0md%HCeAY8~>X=>xV
\JKNAL=124r839v<*&^%#
Group name: %^%#.T|&Whvyf$<Gd"l,wXi5SP_6~Nakk6<<+3H:N-h@aJ6d,l0md%HCeAY8~>X=>xV
\JKNAL=124r839v<*&^%#
Alias name:huawei
Acl:2001
Storage type: nonVolatile
```

**Table 16-2** Description of the **display snmp-agent community** command output

Item	Description
Community name	Name of a community. You can run the <b>16.1.24 snmp-agent community</b> command to configure this parameter.
Group name	Name of a group.
Alias name	Alias name for a community This parameter is displayed only when it is specified in the <b>snmp-agent community</b> command.
Acl	Number of the ACL configured for the community. This parameter is displayed only when it is specified in the <b>snmp-agent community</b> command.
Storage type	Mode in which information is stored. Only nonVolatile is supported currently. In this mode, configuration can be restored after the device restarts.

## Related Topics

[16.1.24 snmp-agent community](#)

## 16.1.5 display snmp-agent extend error-code status

### Function

The **display snmp-agent extend error-code status** command allows you to check whether the function of sending extended error codes to the NMS is enabled on the device.

### Format

**display snmp-agent extend error-code status**

### Parameters

None

### Views

All views

### Default Level

3: Management level

### Usage Guidelines

If the NMS does not receive the extended error codes sent from the device, you can run the **display snmp-agent extend error-code status** command to check whether the function of sending extended error codes to the NMS is enabled on the device.

### Example

# Display whether the function of sending extended error codes to the NMS is enabled on the device.

```
<HUAWEI> display snmp-agent extend error-code status  
Extend error-code status: enabled
```

**Table 16-3** Description of the display snmp-agent extend error-code status command output

Item	Description
Extend error-code status	Whether the function of sending extended error codes to the NMS is enabled on the device: <ul style="list-style-type: none"><li>• enabled: The function is enabled.</li><li>• disabled: The function is disabled.</li></ul> You can run the <a href="#">16.1.26 snmp-agent extend error-code enable</a> command to configure this parameter.



## Related Topics

[16.1.26 snmp-agent extend error-code enable](#)

# 16.1.6 display snmp-agent group

## Function

The **display snmp-agent group** command displays information about SNMP user groups.

## Format

**display snmp-agent group** [ *group-name* ]

## Parameters

Parameter	Description	Value
<i>group-name</i>	Displays information about a specified SNMP user group.  If this parameter is not specified, the system displays information about all SNMP user groups.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

When configuring a management object according to the SNMP user group, you can run the **display snmp-agent group** command to view information about the SNMP user group, such as the group name and security model.

### Prerequisites

An SNMP user group has been configured using the [snmp-agent group](#) command.

## Example

```
# Display information about all SNMP user groups.  
<HUAWEI> display snmp-agent group  
Group name: testgroup  
Security model: v3 AuthPriv
```

Readview: ViewDefault  
Writeview: dnsmib  
Notifyview: dnsmib  
Storage type: nonVolatile  
Acl: 2001

**Table 16-4** Table 1 Description of the **display snmp-agent group** command output

Item	Description
Group name	Name of the SNMP user group. You can run the <a href="#">16.1.27 snmp-agent group</a> command to configure this parameter.
Security model	Security mode of the SNMP user group: <ul style="list-style-type: none"> <li>• v3 AuthPriv: SNMP packets need to be authenticated and encrypted.</li> <li>• v3 AuthnoPriv: SNMP packets only need to be authenticated.</li> <li>• v3 noAuthnoPriv: SNMP packets neither need to be authenticated nor encrypted.</li> </ul> You can run the <a href="#">16.1.27 snmp-agent group</a> command to configure this parameter.
Readview	Name of a MIB view with read-only permission of the SNMP user group. You can run the <a href="#">16.1.27 snmp-agent group</a> command to configure this parameter.
Writeview	Name of a MIB view with read and write permission of the SNMP user group. You can run the <a href="#">16.1.27 snmp-agent group</a> command to configure this parameter.
Notifyview	Name of a MIB view name with notification permission of the SNMP user group. You can run the <a href="#">16.1.27 snmp-agent group</a> command to configure this parameter.
Storage-type	Mode in which information is stored. Only nonVolatile is supported currently. In this mode, configuration can be restored after the device restarts.
Acl	ACL number or name of the SNMP user group. You can run the <a href="#">16.1.27 snmp-agent group</a> command to configure this parameter.

## Related Topics

[16.1.27 snmp-agent group](#)

## 16.1.7 display snmp-agent heartbeat configuration

### Function

The **display snmp-agent heartbeat configuration** command displays the configuration of sending heartbeat packets to the NMS.

### Format

**display snmp-agent heartbeat configuration**

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

When the NMS cannot initiatively obtain the status of the device, run the **16.1.28 snmp-agent heartbeat enable** command to enable the device to send heartbeat packets to the NMS. The device then periodically sends heartbeat packets to the NMS to notify the NMS of its status. To check whether the device is enabled to send heartbeat packets to the NMS, run the **display snmp-agent heartbeat configuration** command.

### Example

# Display the configuration of sending heartbeat packets to the NMS.

```
<HUAWEI> display snmp-agent heartbeat configuration
SNMP agent heartbeat configuration:
Status : Enabled
Interval : 60(s)
```

**Table 16-5** Description of the **display snmp-agent heartbeat configuration** command output

Item	Description
SNMP agent heartbeat configuration	Configuration of sending heartbeat packets to the NMS.

Item	Description
Status	<p>Whether the device is enabled to send heartbeat packets to the NMS:</p> <ul style="list-style-type: none"> <li>• Enabled: The function is enabled.</li> <li>• Disabled: The function is disabled.</li> </ul> <p>You can run the <a href="#">16.1.28 snmp-agent heartbeat enable</a> command to configure this parameter.</p>
Interval	<p>The interval at which the device sends heartbeat packets to the NMS.</p> <p>You can run the <a href="#">16.1.29 snmp-agent heartbeat interval</a> command to configure this parameter.</p>

## Related Topics

[16.1.28 snmp-agent heartbeat enable](#)

[16.1.29 snmp-agent heartbeat interval](#)

## 16.1.8 display snmp-agent inform

### Function

The **display snmp-agent inform** command displays parameters for sending traps to the NMS through Inform packets and statistics about Inform packets.

### Format

```
display snmp-agent inform [ address udp-domain ip-address [ vpn-instance
vpn-instance-name ] params securityname { security-name | cipher security-
name } ]
```

#### NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

## Parameters

Parameter	Description	Value
<b>address udp-domain</b> <i>ip-address</i>	Specifies the IP address of the NMS, with the transmission domain of the target host being based on the User Datagram Protocol (UDP). <b>NOTE</b> The IP address specified by <b>address</b> and the security name specified by <b>securityname</b> together identify a NMS.	The value is dotted decimal notation.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the VPN instance to which the NMS belongs. <b>NOTE</b> On the VPN, the VPN instance specified by <b>vpn-instance</b> , IP address, and security name together identify an NMS.	The value must be an existing VPN instance name.
<b>params</b>	Indicates information about the NMS.	-
<b>securityname</b> <i>security-name</i>	Specifies the user security name displayed on the NMS.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.

Parameter	Description	Value
<b>cipher</b> <i>security-name</i>	Indicates the unencrypted or encrypted string of security name.	<p>The value is a string of 1 to 32, 32, or 56 case-sensitive characters without spaces. When double quotation marks are used around the string, spaces are allowed in the string.</p> <ul style="list-style-type: none"> <li>• When the community name is a string of 1 to 32 characters, the string is processed as plain text by default and will be encrypted.</li> <li>• When the community name is a string of 32 or 56 characters, the string is processed as cipher text by default, and the system will determine whether the string can be parsed.</li> </ul>

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

The **display snmp-agent inform** command displays parameters for sending traps to the NMS through Inform packets and statistics about the Inform packets:

- Number of times Inform packets are retransmitted when the device receives no acknowledgement message from the NMS.
- Timeout period for the acknowledgement from the NMS in response to Inform packets.
- Number of Inform packets retransmitted to the NMS.
- Number of Inform packets in the Inform buffer to be acknowledged by the NMS.
- Number of traps sent through Inform packets to the NMS.
- Number of Inform packets discarded when the Inform buffer is full.
- Number of retransmitted Inform packets that are not acknowledged.
- Number of packets acknowledged by the NMS.

If no parameter is specified in the **display snmp-agent inform** command, global parameters for sending traps through Inform packets, all NMS parameters, and packet statistics mode are displayed.

## Example

# Displays global parameters for sending traps through Inform packets, all NMS parameters, and packets statistics mode.

```
<HUAWEI> display snmp-agent inform
Global config: resend-times 3, timeout 15s, pending 39
Global status: current notification count 1
Target-host ID: VPN instance/IP-Address/Security name
-/10.1.1.1/%^%#O>tf1ssv|~v3.\|Y}@Gk,:%/IX{!OrFazE#1lxR%^%#:
Config: resend-times 3, timeout 15s
Status: retries 0, pending 0, sent 0, dropped 0, failed 0, confirmed 0
```

**Table 16-6** Description of the **display snmp-agent inform** command output

Item	Description
Global config	<p>Global Inform parameters:</p> <ul style="list-style-type: none"> <li>• resend-times: indicates the number of times Inform packets are retransmitted when the device receives no acknowledgement message from the NMS.</li> <li>• timeout: indicates timeout period for the acknowledgement from the NMS in response to Inform packets, in seconds.</li> <li>• pending: indicates the number of Inform packets in the Inform buffer to be acknowledged by the NMS.</li> </ul> <p>You can run the <a href="#">snmp-agent inform</a> command to configure these parameters.</p>
Global status	Statistics about global Inform packets.
Target-host ID: VPN instance/IP-Address/Security name	You can run the <a href="#">snmp-agent inform address</a> command to configure these parameters.
Config	<p>Inform packet parameters of the NMS:</p> <ul style="list-style-type: none"> <li>• resend-times: indicates the number of times Inform packets are retransmitted when the device receives no acknowledgement message from the NMS.</li> <li>• timeout: indicates timeout period for the acknowledgement from the NMS in response to Inform packets.</li> </ul> <p>You can run the <a href="#">snmp-agent inform address</a> command to configure these parameters.</p>

Item	Description
Status	<p>Statistics about Inform packets from the switch to the NMS:</p> <ul style="list-style-type: none"> <li>• retries: Number of Inform packets retransmitted to the NMS.</li> <li>• pending: indicates the number of Inform packets in the Inform buffer to be acknowledged by the NMS.</li> <li>• sent: Number of traps sent through Inform packets to the NMS.</li> <li>• dropped: Number of Inform packets discarded when the Inform buffer is full.</li> <li>• failed: Number of retransmitted Inform packets that are not acknowledged.</li> <li>• confirmed: Number of packets acknowledged by the NMS.</li> </ul>

## Related Topics

[16.1.30 snmp-agent inform](#)

[16.1.31 snmp-agent inform address](#)

[16.1.46 snmp-agent target-host inform](#)

## 16.1.9 display snmp-agent mib-view

### Function

The **display snmp-agent mib-view** command displays the current MIB view.

### Format

**display snmp-agent mib-view** [ **exclude** | **include** | **viewname** *view-name* ]

### Parameters

Parameter	Description	Value
<b>exclude</b>	Displays all MIB views that have excluded MIB subtrees configured.	-
<b>include</b>	Displays all MIB views that have included MIB subtrees configured.	-



Parameter	Description	Value
<b>viewname</b> <i>view-name</i>	Displays a specified MIB view.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

The **snmp-agent mib-view** command creates or updates a MIB view. To check the current MIB view, you can run the **display snmp-agent mib-view** command.

### Precautions

The **snmp-agent** command has been run to enable the SNMP Agent. Otherwise, an error message is displayed.

## Example

# Display the current MIB view.

```
<HUAWEI> display snmp-agent mib-view
View name:ViewDefault
MIB Subtree:internet
Subtree mask:F0(Hex)
Storage-type: nonVolatile
View Type:included
View status:active
```

**Table 16-7** Description of the **display snmp-agent mib-view** command output

Item	Description
View name	MIB view name. You can run the <b>snmp-agent mib-view</b> command to configure this parameter.
MIB Subtree	MIB subtree. You can run the <b>snmp-agent mib-view</b> command to configure this parameter.
Subtree mask	MIB subtree mask.

Item	Description
Storage type	Mode in which information is stored. Only nonVolatile is supported currently. In this mode, configuration can be restored after the device restarts.
View Type	Whether the MIB subtree can be accessed by a MIB view: <ul style="list-style-type: none"> <li>• included: The MIB subtree can be accessed by a MIB view.</li> <li>• excluded: The MIB subtree cannot be accessed by a MIB view.</li> </ul> You can run the <a href="#">snmp-agent mib-view</a> command to configure this parameter.
View status	Indicates the status of the MIB view.

## Related Topics

[16.1.33 snmp-agent mib-view](#)

## 16.1.10 display snmp-agent notification-log

### Function

The **display snmp-agent notification-log** command displays information saved in the trap log buffer.

### Format

**display snmp-agent notification-log** [ **info** | **logtime** *starttime* **to** *endtime* | **size** *size* ]

### Parameters

Parameter	Description	Value
<b>info</b>	Displays parameters of trap logs recorded by the device and statistics about trap logs.	-

Parameter	Description	Value
<b>logtime</b> <i>starttime to endtime</i>	Specifies the start time and end time of trap logs to be displayed: <ul style="list-style-type: none"><li>• <i>starttime</i>: specifies the start time of trap logs.</li><li>• <i>endtime</i>: specifies the end time of trap logs.</li></ul>	The value is in the HH:MM:SS YYYY/MM/DD format, where HH:MM:SS indicates the hour, minute, and second and YYYY/MM/DD indicates the year, month, and day. HH ranges from 0 to 23; MM and SS range from 0 to 59. YYYY ranges from 2000 to 2099; MM ranges from 1 to 12; DD ranges from 1 to 31.  The end time must be later than the start time.
<b>size</b> <i>size</i>	Specifies the number of latest trap logs to be displayed.	The value is an integer that ranges from 1 to 5000.

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

You can use any of the following methods to view logs in the trap log buffer using the **display snmp-agent notification-log** command:

- Specify the start time and end time of trap logs to be displayed.
- Specify the number of latest trap logs to be displayed.
- Specify no parameter to view all trap logs.

## Example

# Display parameters of trap logs recorded by the device and statistics about trap logs.

```
<HUAWEI> display snmp-agent notification-log info
Notification log information :
Notification Admin Status: enable
GlobalNotificationsLogged: 0
GlobalNotificationsBumped: 0
GlobalNotificationsLimit: 500
GlobalNotificationsAgeout: 24
Total number of notification log(s): 0
```

**Table 16-8** Description of the **display snmp-agent notification-log info** command output

Item	Description
Notification log information	Parameters of trap logs recorded by the device and statistics about trap logs.
Notification Admin Status	Whether the function of recording trap logs is enabled on the device: <ul style="list-style-type: none"> <li>• enable: The function is enabled.</li> <li>• disable: The function is disabled.</li> </ul> You can run the <b>snmp-agent notification-log enable</b> command to configure this parameter.
GlobalNotificationsLogged	Number of trap logs recorded currently.
GlobalNotificationsBumped	Number of logs recording discarded traps.
GlobalNotificationsLimit	Maximum number of trap logs that can be saved. You can run the <b>snmp-agent notification-log</b> command to configure this parameter.
GlobalNotificationsAgeout	Aging time of trap logs. You can run the <b>snmp-agent notification-log</b> command to configure this parameter.
Total number of notification log(s)	Total number of recorded trap logs.

# Display the latest 20 trap logs. (In this example, only one trap log is available in the system.)

```
<HUAWEI> display snmp-agent notification-log size 20
Total number of notifications log(s) : 1

LogTable :
LogIndex= 12
LogTime= 229323
LogDateAndTime= 2007/3/8 10:28:16
LogEngineID= 000007DB7F00000100004CFB
LogEngineTAddress= 192.168.39.1/162
LogEngineTDomain= snmpUDPDomain
LogContextEngineID= null
LogContextName= null
LogNotificationID= 1.3.6.1.4.1.2011.6.10.2.1
LogVariableTable :
LogVariableIndex= 1
LogVariableOID= 1.3.6.1.2.1.1.3
LogVariableValueType= TimeTicksLogVariableValue = 229323
LogVariableIndex= 2
LogVariableOID= 1.3.6.1.6.3.1.1.4.1
LogVariableValueType= OidLogVariableValue = 1
LogVariableIndex= 3
LogVariableOID= 1.3.6.1.4.1.2011.6.10.1.1.7.1.3.29
LogVariableValueType= Integer32LogVariableValue = 1
LogVariableIndex= 4
```

```
LogVariableOID= 1.3.6.1.4.1.2011.6.10.1.1.7.1.4.29
LogVariableValueType= Integer32LogVariableValue = 3
LogVariableIndex= 5
LogVariableOID= 1.3.6.1.4.1.2011.6.10.1.1.7.1.5.29
LogVariableValueType= Integer32LogVariableValue = 2
```

**Table 16-9** Description of the **display snmp-agent notification-log size 20** command output

Item	Description
LogTable	Log table.
LogIndex	Index of the log.
LogTime	Difference between the time when the log was recorded and the time when the system started. The unit is 10 ms.
LogDateAndTime	Absolute date and time when the log was recorded.
LogEngineID	Engine ID of the SNMP message recorded in the log.
LogEngineTAddress	IP address and port number of the SNMP message recorded in the log.
LogEngineTDomain	Transmission type of the SNMP message recorded in the log.
LogContextEngineID	Engine ID of context of the SNMP message recorded in the log.
LogContextName	Secure user name, IP address, and VPN instance name.
LogNotificationID	OID of the trap object recorded in the log.
LogVariableTable	Variable table of the log.
LogVariableIndex	Index of a variable.
LogVariableOID	OID of a variable.
LogVariableValueType	Value type of a variable.
LogVariableValue	Value of a variable.

## Related Topics

[16.1.34 snmp-agent notification-log](#)

## 16.1.11 display snmp-agent notify-filter-profile

### Function

The **display snmp-agent notify-filter-profile** command displays information about a specified trap filter profile or all trap filter profiles.

### Format

**display snmp-agent notify-filter-profile** [ *profile-name* ]

### Parameters

Parameter	Description	Value
<i>profile-name</i>	Specifies the name of a trap filter profile.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.

### Views

All views

### Default Level

3: Management level

### Usage Guidelines

You can use the **display snmp-agent notify-filter-profile** command to view information about configured trap filter profiles. The command can display all the configured trap filter profiles or a specified trap file profile.

### Example

```
# Display information about configured trap filter profiles.
<HUAWEI> display snmp-agent notify-filter-profile
Notify-filter name:snmpv2
Notify-filter Subtree:snmpV2
Notify-filter Subtree mask:F8(Hex)
Notify-filter Storage-type:nonVolatile
Notify-filter Type:included
Notify-filter status:active
```

**Table 16-10** Description of the **display snmp-agent notify-filter-profile** command output

Item	Description
Notify-filter name	Name of a trap filter profile. You can run the <a href="#">snmp-agent notify-filter-profile</a> command to configure this parameter.
Notify-filter Subtree	Filtered MIB subtree. You can run the <a href="#">snmp-agent notify-filter-profile</a> command to configure this parameter.
Notify-filter Subtree mask	Mask of a MIB subtree.
Notify-filter Storage-type	Mode in which information is stored. Only nonVolatile is supported currently. In this mode, configuration can be restored after the device restarts.
Notify-filter Type	Whether traps of the MIB subtree are sent to the NMS: <ul style="list-style-type: none"><li>• included: Traps of the MIB subtree are sent to the NMS.</li><li>• excluded: Traps of the MIB subtree are not sent to the NMS.</li></ul> You can run the <a href="#">snmp-agent notify-filter-profile</a> command to configure this parameter.
Notify-filter status	Status of a trap filter profile.

## Related Topics

[16.1.36 snmp-agent notify-filter-profile](#)

## 16.1.12 display snmp-agent statistics

### Function

The **display snmp-agent statistics** command displays statistics about SNMP packets on the switch.

### Format

**display snmp-agent statistics**

### Parameters

None

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

In an SNMP management system, the NMS and the SNMP Agent exchange SNMP messages as follows:

- The NMS acts as a manager to send an SNMP Request message to the SNMP Agent.
- The SNMP Agent searches the MIB on the device for the required information and sends an SNMP Response message to the NMS.
- When the trap triggering conditions are met, the SNMP Agent sends a trap to the NMS to report the event occurring on the device. In this manner, the network administrator can process the event occurring on the network in time.

You can run the **display snmp-agent statistics** command to analyze the statistics about SNMP packets exchanged between the NMS and SNMP Agent, facilitating fault location.

### NOTE

If large number of messages are received in short period, a great number of CPU resources are occupied. The number of received messages depends on the frequency at which the NMS sends the Request messages.

## Example

# Display the statistics about SNMP packets on the switch.

```
<HUAWEI> display snmp-agent statistics
0 Messages delivered to the SNMP entity
0 Messages which were for an unsupported version
0 Messages which used a SNMP community name not known
0 Messages which represented an illegal operation for the community supplied
0 ASN.1 or BER errors in the process of decoding
7 Messages passed from the SNMP entity
0 SNMP PDUs which had badValue error-status
0 SNMP PDUs which had genErr error-status
0 SNMP PDUs which had noSuchName error-status
0 SNMP PDUs which had tooBig error-status
0 MIB objects retrieved successfully
0 MIB objects altered successfully
0 GetRequest-PDU accepted and processed
0 GetNextRequest-PDU accepted and processed
0 GetResponse-PDU accepted and processed
0 SetRequest-PDU accepted and processed
0 Trap-PDU accepted and processed
0 Inform-PDU sent
0 Inform ACK PDUs failed to be processed
0 Inform ACK PDUs successfully processed
```



**Table 16-11** Description of the **display snmp-agent statistics** command output

Item	Description
Messages delivered to the SNMP entity	Total number of received SNMP messages
Messages which were for an unsupported version	Number of SNMP messages with version errors
Messages which used an SNMP community name not known	Number of SNMP messages with community name errors
Messages which represented an illegal operation for the community supplied	Number of SNMP messages with authority errors corresponding to community name
ASN.1 or BER errors in the process of decoding	Number of SNMP messages with encoding errors
Messages passed from the SNMP entity	Total number of sent SNMP messages
SNMP PDUs which had badValue error-status	Number of SNMP messages with bad values
SNMP PDUs which had genErr error-status	Number of SNMP messages with general errors
SNMP PDUs which had noSuchName error-status	Number of SNMP messages with requests for non-existing MIB objects
SNMP PDUs which had tooBig error-status	Number of SNMP messages with Too_big errors
MIB objects retrieved successfully	Number of variables requested by NMS
MIB objects altered successfully	Number of variables set by NMS
GetRequest-PDU accepted and processed	Number of received SNMP Get-request messages
GetNextRequest-PDU accepted and processed	Number of received SNMP GetNext-request messages
GetResponse-PDU accepted and processed	Number of sent SNMP Get-response messages
SetRequest-PDU accepted and processed	Number of received SNMP Set-request messages
Trap-PDU accepted and processed	Number of sent SNMP Trap messages
Inform-PDU sent	Number of sent SNMP Inform messages

Item	Description
Inform ACK PDUs failed to be processed	Number of SNMP Inform messages received with no acknowledgement
Inform ACK PDUs successfully processed	Number of SNMP Inform messages received with acknowledgement

## 16.1.13 display snmp-agent statistics mib

### Function

The **display snmp-agent statistics mib** command displays statistics about the NMS's operations on MIB objects.

#### NOTE

Only S5720EI, S5720HI, S6720EI, and S6720S-EI support this command.

### Format

```
display snmp-agent statistics mib [ [ vpn-instance vpn-instance-name ]  
{ address ipv4-address | ipv6 ipv6-address } ]
```

### Parameters

Parameter	Description	Value
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies a VPN instance name.	The value must be an existing VPN instance name.
<b>address</b> <i>ipv4-address</i>	Specifies an IPv4 address.	-
<b>ipv6</b> <i>ipv6-address</i>	Specifies an IPv6 address.	-

### Views

All views

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

An NMS performs operations on MIB objects to manage devices. To check these operation statistics, run the **display snmp-agent statistics mib** command. The command output displays names, access frequencies, and handling dates of MIB objects.

If no NMS is specified, the **display snmp-agent statistics mib** command displays statistics about the operations performed by all NMSs (that is, IPv4+VPN, IPv6+VPN, IPv4, and IPv6 NMSs) on MIB objects.

### Follow-up Procedure

If the NMS accesses a great amount of MIB node information and statistics do not need to be saved, run the **reset snmp-agent statistics mib** command to delete the statistics.

## Example

# Display all statistics about the NMS's operations on MIB objects.

```
<HUAWEI> display snmp-agent statistics mib
-----
ip address:192.168.1.4, total mib node number:9
SUMMARY: Total set:0,Total get:9,Total get-next:75
-----
MibName      Set    Get    GetNext  MaxTime MinTime
AveTime
ifEntry       0     0     75      0       0       0
ifNumber      0     1     0       0       0       0
sysContact    0     1     0       0       0       0
sysDescr      0     1     0       0       0       0
sysLocation   0     1     0       0       0       0
sysName       0     1     0       0       0       0
sysObjectID   0     1     0       0       0       0
sysServices   0     1     0       0       0       0
sysUpTime     0     2     0       0       0       0
```

# Display the statistics about the operations performed by the NMS with the IP address of 192.168.1.3 in the VPN instance **aa**.

```
<HUAWEI> display snmp-agent statistics mib vpn-instance aa address 192.168.1.3
-----
vpn instance:aa, ip address:192.168.1.3, total mib node number:
1
SUMMARY: Total set:0,Total get:1,Total get-next:0
-----
MibName      Set    Get    GetNext  MaxTime MinTime
AveTime
sysDescr      0     1     0       0       0       0
```

**Table 16-12** Description of the **display snmp-agent statistics mib** command output

Item	Description
ip address	IP address of the NMS.
vpn instance	VPN instance name
total mib node number	Total number of MIB objects accessed by the NMS.
SUMMARY	Abstract of statistics about the NMS's operations on MIB objects.

Item	Description
Total set	Total number of Set operations performed on all MIB objects.
Total get	Total number of Get operations performed on all MIB objects.
Total get-next	Total number of GetNext operations performed on all MIB objects.
MibName	MIB object name.
Set	Number of the Set operations performed on a specified MIB object.
Get	Number of the Get operations performed on a specified MIB object.
GetNext	Number of the GetNext operations performed on a specified MIB object.
MaxTime	Maximum time for an operation performed on MIB objects.
MinTime	Minimum time for an operation performed on MIB objects.
AveTime	Average time for an operation performed on MIB objects.

## Related Topics

[16.1.21 reset snmp-agent statistics mib](#)

[16.1.44 snmp-agent statistics mib disable](#)

## 16.1.14 display snmp-agent sys-info

### Function

The **display snmp-agent sys-info** command displays SNMP information about the device, including contact information of device maintenance personnel, physical location of the device, and SNMP version running on the device.

### Format

**display snmp-agent sys-info [ contact | location | version ] \***

### Parameters

Parameter	Description	Value
<b>contact</b>	Displays contact information of device maintenance personnel.	-
<b>location</b>	Displays the physical location of the device.	-

Parameter	Description	Value
version	Displays the SNMP version running on the device.	-

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

You can run the **display snmp-agent sys-info** command to display SNMP information about the device, including:

- Contact information of device maintenance personnel
- Physical location of the device
- SNMP version running on the device

If no parameter is specified, all information is displayed.

## Example

# Display all SNMP information about the device.

```
<HUAWEI> display snmp-agent sys-info
The contact person for this managed node:
  R&D Beijing, Huawei Technologies Co., Ltd.
The physical location of this node:
  Beijing China
SNMP version running in the system:
  SNMPv2c
```

# Display the SNMP version running on the device.

```
<HUAWEI> display snmp-agent sys-info version
SNMP version running in the system:
  SNMPv2c
```

# Display contact information of device maintenance personnel.

```
<HUAWEI> display snmp-agent sys-info contact
The contact person for this managed node:
  R&D Beijing, Huawei Technologies Co., Ltd.
```

# Display the physical location of the device.

```
<HUAWEI> display snmp-agent sys-info location
The physical location of this node:
  Beijing China
```

**Table 16-13** Description of the **display snmp-agent sys-info** command output

Item	Description
The contact person for this managed node	Contact information of device maintenance personnel, which is useful in event of emergencies. You can run the <b>snmp-agent sys-info</b> command to configure this parameter.
The physical location of this node	Physical location of the device. You can run the <b>snmp-agent sys-info</b> command to configure this parameter.
SNMP version running in the system	SNMP version running on the device. The value can be any combination of SNMPv1, SNMPv2c, and SNMPv3. When multiple versions are configured, the NMS manages the device using multiple SNMP versions. You can run the <b>snmp-agent sys-info</b> command to configure this parameter.

## Related Topics

[16.1.45 snmp-agent sys-info](#)

## 16.1.15 display snmp-agent target-host

### Function

The **display snmp-agent target-host** command displays the configurations of destination hosts of all alarms.

### Format

```
display snmp-agent target-host
```

### Parameters

None

### Views

All views

### Default Level

3: Management level

### Usage Guidelines

You can use the **display snmp-agent target-host** command to display the configurations of destination hosts of all traps, including IP addresses of the hosts,

modes in which traps are sent, security name used to send traps, and SNMP versions. At present, the system can save the configuration of a maximum of 20 destination hosts. Therefore, the **display snmp-agent target-host** command can view the configuration of a maximum of 20 destination hosts.

## Example

# Display the configurations of destination hosts of all alarms.

```
<HUAWEI> display snmp-agent target-host
Target-host NO. 1
-----
IP-address   : 10.1.2.1
Source interface : -
VPN instance  : -
Security name : %^%#uq!/YZfvW4*vf[~C|.Cl}UqS(vXd#wwqR~5M(rU%%^%#
Port         : 162
Type         : trap
Version      : v2c
Level        : No authentication and privacy
NMS type     : HW NMS
With ext-vb  : No
-----
```

**Table 16-14** Description of the **display snmp-agent target-host** command output

Parameter	Description
Target-host NO	Target host number, which is generated based on the sequence in which the target host is configured. You can run the <b>snmp-agent target-host inform</b> or <b>snmp-agent target-host trap</b> command to configure parameters of the target host.
IP-address	IP address of the target host.
Source interface	Source interface that sends traps.
VPN instance	VPN instance to which the target host belongs.
Security name	Security name used to send traps.
Port	UDP port number used to send traps.
Type	Mode in which traps are sent: <ul style="list-style-type: none"> <li>• trap</li> <li>• inform</li> </ul>
Version	SNMP version: <ul style="list-style-type: none"> <li>• v1</li> <li>• v2c</li> <li>• v3</li> </ul>

Parameter	Description
Level	Security mode of packets: <ul style="list-style-type: none"><li>• Authentication: Packets only need to be authenticated.</li><li>• Privacy: Packets need to be authenticated and encrypted.</li><li>• No authentication and privacy: Packets need neither to be authenticated nor encrypted.</li></ul>
NMS type	Type of the target host: <ul style="list-style-type: none"><li>• NSM: indicates a network management system, which can be a Huawei NMS or an NMS from another vendor.</li><li>• HW NMS: indicates a Huawei NMS. The traps sent to the Huawei NMS can contain more detailed information.</li></ul>
With ext-vb	Whether the trap sent to the target host carries extended bound variables: <ul style="list-style-type: none"><li>• No</li><li>• Yes</li></ul>

## Related Topics

[16.1.46 snmp-agent target-host inform](#)

[16.1.47 snmp-agent target-host trap](#)

## 16.1.16 display snmp-agent trap all

### Function

The **display snmp-agent trap all** command displays whether the switch is enabled to send alarms of all features to the NM station.

### Format

```
display snmp-agent trap all
```

### Parameters

None

### Views

All views



## Default Level

1: Monitoring level

## Usage Guidelines

You can run the **display snmp-agent trap all** command to check whether the switch is enabled to send alarms of specified features to the NMS. You can configure this function by running [16.1.50 snmp-agent trap enable](#), [16.1.51 snmp-agent trap enable feature-name](#), and [16.1.49 snmp-agent trap disable](#).

## Example

# Check whether the switch is enabled to send alarms of specified features to the NMS.

```
<HUAWEI> display snmp-agent trap all
-----
Feature name: INFO
Trap number : 2
-----
Trap name           Default switch status  Current switch status
hwICLogFileAging    on                      on
hwICLogBufferLose   on                      on
-----
---- More ----
```

**Table 16-15** Description of the display snmp-agent trap all command output

Item	Description
Feature name	Name of the feature that generates alarms.
Trap number	Number of alarms generated by this feature.
Trap name	Name of the alarm.
Default switch status	Default status of the alarm: <ul style="list-style-type: none"> <li>on: The switch is enabled to send this alarm to the NMS.</li> <li>off: The switch is disabled to send this alarm to the NMS.</li> </ul>
Current switch status	Current status of the alarm: <ul style="list-style-type: none"> <li>on: The switch is enabled to send this alarm to the NMS.</li> <li>off: The switch is disabled to send this alarm to the NMS.</li> </ul> <p>This status can be configured using the <a href="#">16.1.51 snmp-agent trap enable feature-name</a> command.</p>

## Related Topics

[16.1.49 snmp-agent trap disable](#)

[16.1.50 snmp-agent trap enable](#)

[16.1.51 snmp-agent trap enable feature-name](#)

## 16.1.17 display snmp-agent trap feature-name all

### Function

The **display snmp-agent trap feature-name all** command displays whether the router is enabled to send alarms of specified features to the NM station.

### Format

**display snmp-agent trap feature-name** *feature-name* **all**

### Parameters

Parameter	Description	Value
<i>feature-name</i>	Specifies the feature that generates alarms.	-

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

You can run the **display snmp-agent trap feature-name all** command to check whether the switch is enabled to send alarms of specified features to the NMS. You can use the [snmp-agent trap enable feature-name](#) command to enable this function. The following table lists the alarm information of related features.

Feature Name	Command Used to Enable or Disable the Trap Function	Command Used to Check the Trap Status
ACL	<a href="#">snmp-agent trap enable feature-name acle</a>	<a href="#">display snmp-agent trap feature-name acle all</a>
ARP	<a href="#">snmp-agent trap enable feature-name arp</a>	<a href="#">display snmp-agent trap feature-name arp all</a>
ASMNG TRAP	<a href="#">snmp-agent trap enable feature-name asmngtrap</a>	<a href="#">display snmp-agent trap feature-name asmngtrap all</a>
BFD	<a href="#">snmp-agent trap enable feature-name bfd</a>	<a href="#">display snmp-agent trap feature-name bfd all</a>
BGP	<a href="#">snmp-agent trap enable feature-name bgp</a>	<a href="#">display snmp-agent trap feature-name bgp all</a>

Feature Name	Command Used to Enable or Disable the Trap Function	Command Used to Check the Trap Status
CONFIGURATION	<code>snmp-agent trap enable feature-name configuration</code>	<code>display snmp-agent trap feature-name configuration all</code>
DATASYNC	<code>snmp-agent trap enable feature-name datasync</code>	<code>display snmp-agent trap feature-name datasync all</code>
DHCP	<code>snmp-agent trap enable feature-name dhcp</code>	<code>display snmp-agent trap feature-name dhcp all</code>
DLDP	<code>snmp-agent trap enable feature-name dldp</code>	<code>display snmp-agent trap feature-name dldp all</code>
EASYOPERATION	<code>snmp-agent trap enable feature-name easyoperatrap</code>	<code>display snmp-agent trap feature-name easyoperatrap all</code>
EFM	<code>snmp-agent trap enable feature-name efm</code>	<code>display snmp-agent trap feature-name efm all</code>
ENTITYMIB	<code>snmp-agent trap enable feature-name entitymib</code>	<code>display snmp-agent trap feature-name entitymib all</code>
ENTITYTRAP	<code>snmp-agent trap enable feature-name entitytrap</code>	<code>display snmp-agent trap feature-name entitytrap all</code>
EOAM-1AG	<code>snmp-agent trap enable feature-name eoam-1ag</code>	<code>display snmp-agent trap feature-name eoam-1ag all</code>
Eoam-Y1731	<code>snmp-agent trap enable feature-name eoam-y1731</code>	<code>display snmp-agent trap feature-name eoam-y1731 all</code>
ERPS	<code>snmp-agent trap enable feature-name erps</code>	<code>display snmp-agent trap feature-name erps all</code>
ERROR-DOWN	<code>snmp-agent trap enable feature-name error-down</code>	<code>display snmp-agent trap feature-name error-down all</code>
ETRUNK	<code>snmp-agent trap enable feature-name etrunk</code>	<code>display snmp-agent trap feature-name etrunk all</code>
FM	<code>snmp-agent trap enable feature-name fm</code>	<code>display snmp-agent trap feature-name fm all</code>
Ftp_Server	<code>snmp-agent trap enable feature-name ftp_server</code>	<code>display snmp-agent trap feature-name ftp_server all</code>
GTL	<code>snmp-agent trap enable feature-name gtl</code>	<code>display snmp-agent trap feature-name gtl all</code>
HGMP	<code>snmp-agent trap enable feature-name hgmp</code>	<code>display snmp-agent trap feature-name hgmp all</code>
IFNET	<code>snmp-agent trap enable feature-name ifnet</code>	<code>display snmp-agent trap feature-name ifnet all</code>

Feature Name	Command Used to Enable or Disable the Trap Function	Command Used to Check the Trap Status
IFPDT	<code>snmp-agent trap enable feature-name ifpdt</code>	<code>display snmp-agent trap feature-name ifpdt all</code>
INFO	<code>snmp-agent trap enable feature-name info</code>	<code>display snmp-agent trap feature-name info all</code>
IP	<code>snmp-agent trap enable feature-name ip</code>	<code>display snmp-agent trap feature-name ip all</code>
IPFPM	<code>snmp-agent trap enable feature-name ipfpm</code>	<code>display snmp-agent trap feature-name ipfpm all</code>
IPLPM	<code>snmp-agent trap enable feature-name iplpm</code>	<code>display snmp-agent trap feature-name iplpm all</code>
IPV6	<code>snmp-agent trap enable feature-name ipv6</code>	<code>display snmp-agent trap feature-name ipv6 all</code>
ISIS	<code>snmp-agent trap enable feature-name isis</code>	<code>display snmp-agent trap feature-name isis all</code>
L2BPTNL	<code>snmp-agent trap enable feature-name l2bptnl</code>	<code>display snmp-agent trap feature-name l2bptnl all</code>
L2IF	<code>snmp-agent trap enable feature-name l2if</code>	<code>display snmp-agent trap feature-name l2if all</code>
L2IFPPI	<code>snmp-agent trap enable feature-name l2ifppi</code>	<code>display snmp-agent trap feature-name l2ifppi all</code>
L2VPN	<code>snmp-agent trap enable feature-name l2vpn</code>	<code>display snmp-agent trap feature-name l2vpn all</code>
L3MB	<code>snmp-agent trap enable feature-name l3mb</code>	<code>display snmp-agent trap feature-name l3mb all</code>
L3VPN	<code>snmp-agent trap enable feature-name l3vpn</code>	<code>display snmp-agent trap feature-name l3vpn all</code>
LACP	<code>snmp-agent trap enable feature-name lacp</code>	<code>display snmp-agent trap feature-name lacp all</code>
LBDT	<code>snmp-agent trap enable feature-name lbdtd</code>	<code>display snmp-agent trap feature-name lbdtd all</code>
LDP	<code>snmp-agent trap enable feature-name ldp</code>	<code>display snmp-agent trap feature-name ldp all</code>
LINE	<code>snmp-agent trap enable feature-name line</code>	<code>display snmp-agent trap feature-name line all</code>
LLDPTRAP	<code>snmp-agent trap enable feature-name lldptrap</code>	<code>display snmp-agent trap feature-name lldptrap all</code>

Feature Name	Command Used to Enable or Disable the Trap Function	Command Used to Check the Trap Status
MAD	<code>snmp-agent trap enable feature-name mad</code>	<code>display snmp-agent trap feature-name mad all</code>
MCAST	<code>snmp-agent trap enable feature-name mcast</code>	<code>display snmp-agent trap feature-name mcast all</code>
Mid_Eapol	<code>snmp-agent trap enable feature-name mid_eapol</code>	<code>display snmp-agent trap feature-name mid_eapol all</code>
Mid_Web	<code>snmp-agent trap enable feature-name mid_web</code>	<code>display snmp-agent trap feature-name mid_web all</code>
MPLS	<code>snmp-agent trap enable feature-name mpls</code>	<code>display snmp-agent trap feature-name mpls all</code>
Mpls_Lspm	<code>snmp-agent trap enable feature-name mpls_lspm</code>	<code>display snmp-agent trap feature-name mpls_lspm all</code>
Mpls_Rsvp	<code>snmp-agent trap enable feature-name mpls_rsvp</code>	<code>display snmp-agent trap feature-name mpls_rsvp all</code>
MSTP	<code>snmp-agent trap enable feature-name mstp</code>	<code>display snmp-agent trap feature-name mstp all</code>
OSPF	<code>snmp-agent trap enable feature-name ospf</code>	<code>display snmp-agent trap feature-name ospf all</code>
OSPFV3	<code>snmp-agent trap enable feature-name ospfv3</code>	<code>display snmp-agent trap feature-name ospfv3 all</code>
PM	<code>snmp-agent trap enable feature-name pm</code>	<code>display snmp-agent trap feature-name pm all</code>
POETRAP	<code>snmp-agent trap enable feature-name poetrp</code>	<code>display snmp-agent trap feature-name poetrp all</code>
RADIUS	<code>snmp-agent trap enable feature-name radius</code>	<code>display snmp-agent trap feature-name radius all</code>
RIP	<code>snmp-agent trap enable feature-name rip</code>	<code>display snmp-agent trap feature-name rip all</code>
RM	<code>snmp-agent trap enable feature-name rm</code>	<code>display snmp-agent trap feature-name rm all</code>
RMON	<code>snmp-agent trap enable feature-name rmon</code>	<code>display snmp-agent trap feature-name rmon all</code>
RRPP	<code>snmp-agent trap enable feature-name rrpp</code>	<code>display snmp-agent trap feature-name rrpp all</code>
SECURITYTRAP	<code>snmp-agent trap enable feature-name securitytrap</code>	<code>display snmp-agent trap feature-name securitytrap all</code>

Feature Name	Command Used to Enable or Disable the Trap Function	Command Used to Check the Trap Status
SINDEX	<code>snmp-agent trap enable feature-name sindex</code>	<code>display snmp-agent trap feature-name sindex all</code>
SNMP	<code>snmp-agent trap enable feature-name snmp</code>	<code>display snmp-agent trap feature-name snmp all</code>
SPMTRAP	<code>snmp-agent trap enable feature-name spmtrap</code>	<code>display snmp-agent trap feature-name spmtrap all</code>
SRMTRAP	<code>snmp-agent trap enable feature-name srmtrap</code>	<code>display snmp-agent trap feature-name srmtrap all</code>
STACK	<code>snmp-agent trap enable feature-name stack</code>	<code>display snmp-agent trap feature-name stack all</code>
SWITHSRVRES	<code>snmp-agent trap enable feature-name swithsrvres</code>	<code>display snmp-agent trap feature-name swithsrvres all</code>
SYSTEM	<code>snmp-agent trap enable feature-name system</code>	<code>display snmp-agent trap feature-name system all</code>
TCP	<code>snmp-agent trap enable feature-name tcp</code>	<code>display snmp-agent trap feature-name tcp all</code>
TRUNK	<code>snmp-agent trap enable feature-name trunk</code>	<code>display snmp-agent trap feature-name trunk all</code>
Uni-Topomng	<code>snmp-agent trap enable feature-name uni-topomng</code>	<code>display snmp-agent trap feature-name uni-topomng all</code>
Uni-Tplm	<code>snmp-agent trap enable feature-name uni-tplm</code>	<code>display snmp-agent trap feature-name uni-tplm all</code>
Uni-Vermng	<code>snmp-agent trap enable feature-name uni-vermng</code>	<code>display snmp-agent trap feature-name uni-vermng all</code>
UNIMBRTRAP	<code>snmp-agent trap enable feature-name unimbrtrap</code>	<code>display snmp-agent trap feature-name unimbrtrap all</code>
USBLOADTRAP	<code>snmp-agent trap enable feature-name usbloadtrap</code>	<code>display snmp-agent trap feature-name usbloadtrap all</code>
VBST	<code>snmp-agent trap enable feature-name vbst</code>	<code>display snmp-agent trap feature-name vbst all</code>
VCMP	<code>snmp-agent trap enable feature-name vcmp</code>	<code>display snmp-agent trap feature-name vcmp all</code>
VFS	<code>snmp-agent trap enable feature-name vfs</code>	<code>display snmp-agent trap feature-name vfs all</code>
VPLSOAM	<code>snmp-agent trap enable feature-name vplsoam</code>	<code>display snmp-agent trap feature-name vplsoam all</code>

Feature Name	Command Used to Enable or Disable the Trap Function	Command Used to Check the Trap Status
VRRP	<code>snmp-agent trap enable feature-name vrrp</code>	<code>display snmp-agent trap feature-name vrrp all</code>
WLAN	<code>snmp-agent trap enable feature-name wlan</code>	<code>display snmp-agent trap feature-name wlan all</code>

## Example

# Display the status of the ARP alarms.

```
<HUAWEI> display snmp-agent trap feature-name arp all
-----
Feature name: ARP
Trap number : 4
-----
Trap name           Default switch status  Current switch status
hwEthernetARPSpeedLimitAlarm  on                    on
hwEthernetARPThresholdExceedAlarm
                               on                    on
hwEthernetARPThresholdResumeAlarm
                               on                    on
hwEthernetARPIPConflictEvent  on                    on
```

**Table 16-16** Description of the display snmp-agent trap feature-name all command output

Item	Description
Feature name	Name of the feature that generates alarms.
Trap number	Number of alarms generated by this feature.
Trap name	Name of the alarm.
Default switch status	Default status of the alarm: <ul style="list-style-type: none"> <li>on: The switch is enabled to send this alarm to the NMS.</li> <li>off: The switch is disabled to send this alarm to the NMS.</li> </ul>
Current switch status	Current status of the alarm: <ul style="list-style-type: none"> <li>on: The switch is enabled to send this alarm to the NMS.</li> <li>off: The switch is disabled to send this alarm to the NMS.</li> </ul> <p>This status can be configured using the <code>snmp-agent trap enable feature-name</code> command.</p>

## Related Topics

[16.1.51 snmp-agent trap enable feature-name](#)

# 16.1.18 display snmp-agent trap feature-name snmp all

## Function

The **display snmp-agent trap feature-name snmp all** command displays whether the switch is enabled to send traps of the SNMP feature to the NMS.

## Format

**display snmp-agent trap feature-name snmp all**

## Parameters

None

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

After running the [snmp-agent trap enable feature-name snmp](#) command to enable the function of sending traps of the SNMP feature to the NMS, you can run the **display snmp-agent trap feature-name snmp all** command to check whether this function is enabled.

### Prerequisites

SNMP has been enabled. For details, see [snmp-agent](#).

## Example

# Display whether the switch is enabled to send traps of SNMP feature to the NMS.

```
<HUAWEI> display snmp-agent trap feature-name snmp all
-----
Feature name: SNMP
Trap number : 5
-----
Trap name           Default switch status  Current switch status
coldStart           on                     on
warmStart           on                     on
authenticationFailure off                    off
hwSNMPLockThreshold on                     on
hwSNMPLockThresholdResume on                    on
```



**Table 16-17** Description of the **display snmp-agent trap feature-name snmp all** command output

Item	Description
Feature name	Name of the feature that generates traps.
Trap number	Number of traps generated by SNMP feature.
Trap name	Name of the trap. The SNMP feature supports the following traps: <ul style="list-style-type: none"> <li>● coldStart: This trap is generated when the device is powered off and restarted.</li> <li>● warmStart: This trap is generated when the status of SNMP agent is changed from disable to enable.</li> <li>● authenticationFailure: This trap is generated when a user uses an incorrect community name and is unable to log in to the device.</li> <li>● hwSNMPLockThreshold: This trap is generated when the number of users who were locked due to an authentication failure reached the upper threshold.</li> <li>● hwSNMPLockThresholdResume: This trap is generated when the number of users who were locked due to an authentication failure fell below the lower threshold.</li> </ul>
Default switch status	Default status of a trap: <ul style="list-style-type: none"> <li>● on: The switch is enabled to send this trap to the NMS.</li> <li>● off: The switch is disabled to send this trap to the NMS.</li> </ul>
Current switch status	Current status of a trap: <ul style="list-style-type: none"> <li>● on: The switch is enabled to send this trap to the NMS.</li> <li>● off: The switch is disabled to send this trap to the NMS.</li> </ul> <p>This status can be configured using the <b>snmp-agent trap enable feature-name snmp</b> command.</p>

## Related Topics

[16.1.52 snmp-agent trap enable feature-name snmp](#)

## 16.1.19 display snmp-agent usm-user

### Function

The **display snmp-agent usm-user** command displays information about an SNMPv3 user.

### Format

**display snmp-agent usm-user** [ **engineid** *engineid* | **group** *group-name* | **username** *user-name* ] \*

### Parameters

Parameter	Description	Value
<b>engineid</b> <i>engineid</i>	Displays information about an SNMPv3 user with a specified SNMP entity engine ID.	-
<b>group</b> <i>group-name</i>	Displays the SNMPv3 user belonging to a specified user group.	-
<b>username</b> <i>user-name</i>	Displays information about a specified SNMPv3 user.	-

### Views

All views

### Default Level

3: Management level

### Usage Guidelines

You can run the **display snmp-agent usm-user** command to display the SNMPv3 user information configured through the **snmp-agent usm-user** command. The SNMPv3 user here refers to the remote user that carries out SNMPv3 management. The displayed information about an SNMPv3 user includes the user name, authentication protocol, encryption algorithm, and user group to which the SNMPv3 user belongs.

### Example

# Display information about all current SNMPv3 users.

```
<HUAWEI> display snmp-agent usm-user
User name: myuser
Engine ID: 800007DB03360102101100 active
Authentication Protocol: sha
Privacy Protocol: aes256
Group name: mygroup
```

**Table 16-18** Description of the **display snmp-agent usm-user** command output

Item	Description
User name	SNMPv3 user name. You can run the <a href="#">snmp-agent usm-user</a> command to configure this parameter.
Engine ID	Local SNMP engine ID. You can run the <a href="#">snmp-agent local-engineid</a> command to configure this parameter.
active	Status of the SNMPv3 user.
Authentication Protocol	Authentication protocol used for the SNMPv3 user: <ul style="list-style-type: none"> <li>• md5</li> <li>• sha</li> </ul> You can run the <a href="#">snmp-agent usm-user</a> command to configure this parameter.
Privacy Protocol	Encryption algorithm used for the SNMPv3 user: <ul style="list-style-type: none"> <li>• des56</li> <li>• aes128</li> <li>• aes192</li> <li>• aes256</li> <li>• 3des</li> </ul> You can run the <a href="#">snmp-agent usm-user</a> command to configure this parameter.
Group name	User group to which the SNMPv3 user belongs. You can run the <a href="#">snmp-agent usm-user</a> command to configure this parameter.

## Related Topics

[16.1.27 snmp-agent group](#)

[16.1.32 snmp-agent local-engineid](#)

[16.1.60 snmp-agent usm-user](#)

## 16.1.20 enable snmp trap updown

### Function

The **enable snmp trap updown** command enables an interface to send a trap to the NMS when the protocol status of the interface changes.

The **undo enable snmp trap updown** command disables an interface from sending a trap to the NMS when the protocol status of the interface changes.

By default, an interface sends a Trap message to the NMS when the protocol status of the interface changes.

## Format

**enable snmp trap updown**  
**undo enable snmp trap updown**

## Parameters

None

## Views

Interface view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The **enable snmp trap updown** command is used to enable an interface to send a Trap message to the NMS when the protocol status of the interface changes, which helps the NMS monitor the interface status in real time.

### Precautions

By default, the function of sending a Trap message to the NMS when the protocol status of the interface changes is enabled. If an interface alternates between Up and Down, it will frequently send Trap messages to the NMS, causing the NMS to be busy processing these Trap messages. In this case, you can run the **undo enable snmp trap updown** command to disable the interface from sending trap messages to the NMS.

## Example

```
# Disable an interface from sending a trap to the NMS when the protocol status  
of the interface changes.  
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] undo enable snmp trap updown
```

## 16.1.21 reset snmp-agent statistics mib

### Function

The **reset snmp-agent statistics mib** command clears statistics about the NMS's operations on MIB objects.

#### NOTE

Only S5720EI, S5720HI, S6720EI, and S6720S-EI support this command.

## Format

**reset snmp-agent statistics mib** [ **address** *ipv4-address* | **ipv6** *ipv6-address* | **vpn-instance** *vpn-instance-name* **address** *ipv4-address* ]

## Parameters

Parameter	Description	Value
<b>address</b> <i>ipv4-address</i>	Specifies an IPv4 address.	-
<b>ipv6</b> <i>ipv6-address</i>	Specifies an IPv6 address.	-
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies a VPN instance name.	The value must be an existing VPN instance name.

## Views

User view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

An NMS performs operations on MIB objects to manage devices. You can run the **display snmp-agent statistics mib** command to check the operation statistics.

If the NMS accesses a great amount of MIB node information and statistics do not need to be saved, run the **reset snmp-agent statistics mib** command to delete the statistics.

If no NMS is specified, the **reset snmp-agent statistics mib** command clears statistics about the operations performed by all NMSs (that is, IPv4+VPN, IPv6+VPN, IPv4, and IPv6 NMSs) on MIB objects.

### Precautions

Operation statistics cannot be restored after they are cleared. Exercise caution when running the **reset snmp-agent statistics mib** command.

## Example

```
# Clear all statistics about the NMS's operations on MIB objects.
```

```
<HUAWEI> reset snmp-agent statistics mib
```

## Related Topics

[16.1.13 display snmp-agent statistics mib](#)

[16.1.44 snmp-agent statistics mib disable](#)

## 16.1.22 snmp-agent

### Function

The **snmp-agent** command enables the SNMP agent function.

The **undo snmp-agent** command disables the SNMP agent function.

By default, the SNMP agent function is disabled.

### Format

**snmp-agent**

**undo snmp-agent**

### Parameters

None

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

Before configuring SNMP, you need to enable the SNMP agent function.

By executing the **snmp-agent** command with any parameter enables the SNMP agent function. For example, if you execute the **snmp-agent community** command, the community name gets created and also SNMP agent function is enabled.

#### Precautions

After the **snmp-agent** command is executed, both the IPv4 and IPv6 services are enabled for the SNMP agent. By default, the switch listens on the IP address 0.0.0.0, that is, all IP addresses. This default setting is a threat to data confidentiality. You are advised to run the **snmp-agent protocol source-interface interface-type interface-number** command to specify the source interface that receives and responds to SNMP requests from the NMS.

### Example

# Enable the SNMP agent function.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent
```

# Disable the SNMP agent function.

```
<HUAWEI> system-view  
[HUAWEI] undo snmp-agent
```

## 16.1.23 snmp-agent acl

### Function

The **snmp-agent acl** command configures an SNMP ACL.

The **undo snmp-agent acl** command deletes the configured SNMP ACL.

By default, no SNMP ACL is configured.

### Format

```
snmp-agent acl { acl-number | acl-name }
```

```
undo snmp-agent acl
```

### Parameters

Parameter	Description	Value
<i>acl-number</i>	Specifies an ACL number.	The value is an integer ranging from 2000 to 3999.
<i>acl-name</i>	Specifies the name of a basic or an advanced Named ACL.	The value is a string of 1 to 64 case-sensitive characters without spaces. The value must start with a letter.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

When using the NMS to manage devices, you can run the **snmp-agent acl** command to configure an SNMP ACL on the devices and restrict the NMS's access to the devices to enhance network security.

#### Precautions

- The SNMP ACLs take precedence over ACLs based on SNMP community names, SNMP groups, and SNMP users.
- The ACL configured takes effect on both IPv4 and IPv6 networks.

## Example

# Configure SNMP ACL 2000 to allow NM stations that match rules defined in ACL 2000 to access the device using SNMP.

```
<HUAWEI> system-view
[HUAWEI] acl 2000
[HUAWEI-basic-2000] rule permit source 192.168.10.10 0
[HUAWEI-basic-2000] quit
[HUAWEI] snmp-agent acl 2000
```

## 16.1.24 snmp-agent community

### Function

The **snmp-agent community** command configures the SNMPv1 or SNMPv2c read-write community name.

The **undo snmp-agent community** command is used to delete the configuration of the community name.

By default, the community name is not configured.

### Format

**snmp-agent community** { **read** | **write** } { *community-name* | **cipher** *community-name* } [ **mib-view** *view-name* | **acl** { *acl-number* | *acl-name* } | **alias** *alias-name* ]  
\*

**undo snmp-agent community** *community-name*

**undo snmp-agent community** { **read** | **write** } [ **cipher** ] *community-name*

### Parameters

Parameter	Description	Value
<b>read</b>	Indicates that the community with a specified name has the read-only rights in the specified view.	-
<b>write</b>	Indicates that the community with a specified name has the read-write rights in the specified view.	-
<i>community-name</i>	Specifies the name of a community. The community name is displayed in cipher text in the configuration file.	The value is a string of 8 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.



Parameter	Description	Value
<b>cipher</b> <i>community-name</i>	Specifies the community name in plain text or in cipher text.  The community name is displayed in cipher text in the configuration file.	The value is a string of 8 to 32, 44, 56, 80 or 88 case-sensitive characters without spaces. When double quotation marks are used around the string, spaces are allowed in the string. <ul style="list-style-type: none"> <li>When the community name is a string of 8 to 31 characters, the string is processed as plain text by default and will be encrypted.</li> <li>When the community name is a string of 32, 44, 56, 80 or 88 characters, the string is processed as cipher text by default, and the system will determine whether the string can be parsed.</li> </ul>
<b>mib-view</b> <i>view-name</i>	Specifies a MIB view that the community name can access.	It is a string of 1 to 32 case-sensitive characters without spaces. When double quotation marks are used around the string, spaces are allowed in the string.
<b>acl</b> { <i>acl-number</i>   <i>acl-name</i> }	Specifies the ACL corresponding to the community name: <ul style="list-style-type: none"> <li><i>acl-number</i>: indicates the ACL ID</li> <li><i>acl-name</i>: indicates the ACL name</li> </ul> The ACL can be a basic ACL or an advanced ACL, and the ACL configured takes effect on both IPv4 and IPv6 networks.	<ul style="list-style-type: none"> <li><i>acl-number</i>: The value is an integer that ranges from 2000 to 3999.</li> <li><i>acl-name</i>: The value is a string of 1 to 64 case-sensitive characters without spaces. The value must start with a letter (case sensitive).</li> </ul>
<b>alias</b> <i>alias-name</i>	Specifies the alias name for a community.  The alias names of communities are stored in plain text in the configuration file.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

The **snmp-agent community** command is used on SNMPv1 and SNMPv2c networks. The community is a combination of the NMS and SNMP agent and is identified by a community name. The community name functions as a password for authentication during device communication in a community. Devices can communicate if the community name of the NMS and that of the SNMP agent are the same. The **snmp-agent community** command configures a community name on a device so that the NMS can communicate with the device. Parameters of the **snmp-agent community** command set the access permission, ACL, and accessible MIB views of a community name.

When running the **snmp-agent community** command, you can select parameters based on the networking requirements.

- To grant the NMS read-only permission in the specified view, configure **read**.
- To grant the NMS read-write permission in the specified view, configure **write**.
- To allow specified NMSs using this community name have the rights of ViewDefault, omit **mib-view** *view-name*.
- To allow all NMSs using this community name to manage specified objects on a managed device, omit **acl** *acl-number*.
- To allow specified NMSs using this community name to manage specified objects on a managed device, configure **mib-view** and **acl**.
- The community name will be saved in encrypted format in the configuration file. To facilitate identification of community names, specify the **alias** *alias-name* parameter to set the alias names for the communities. The alias names are stored in plain text in the configuration file.

### NOTE

When both community name and ACL are configured, the NMS verifies the community name before accessing the device, and then checks the ACL rules. If the community name does not exist, the packet is discarded and a log indicating that the community name is wrong is printed. The ACL rule is not checked. That is, the ACL rule is checked only when the community name exists.

### Precautions

- The device checks the complexity of community names in simple text rather than in ciphertext. The device has the following requirements for community name complexity:
  - The minimum length of a community name is determined by the [2.5.23 set password min-length](#) command. By default, a password contains 8 characters.
  - The community name includes at least two kinds of characters: uppercase letters, lowercase letters, numbers, and special characters (excluding ?).

If a community name fails the complexity check, the community name cannot be configured. To disable the complexity check for a community name, run

the [16.1.25 snmp-agent community complexity-check disable](#) command, and then the length of community names in simple text ranges from 1 to 32. However, if a community name is simple and does not meet complexity requirements, it is prone to be attacked and cracked by unauthorized users, which affects device security. Therefore, enabling complexity check of community names is recommended.

- Only one type of permission can be configured for a community. If a community has both the read-only and read-write permission configured, the permission configured later takes effect.
- If you specify the parameter **mib-view** or **acl** when running the **snmp-agent community** command, configure the MIB view and ACL rule. If the default MIB view is deleted, the NMS using this community name cannot communicate with managed devices. To continue to use this community name, specify an existing MIB view.
- The community name is saved in cipher text in the configuration file. To delete a community name, run the **undo snmp-agent community community name in plain text** or **undo snmp-agent community community name in plain text** command. To view a community name in cipher text, run the [16.1.4 display snmp-agent community](#) command.
- When a user with a level lower than the level configured using this command queries the password configured using the [2.1.10 display this](#) command, the password is displayed as asterisks (\*\*\*\*\*).

## Example

# Set the name of a community to **comaccess1** and configure the read-only rights for the community.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent community read comaccess1
```

# Set the name of a community to **comaccess2** and configure the read-write rights for the community.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent community write comaccess2
```

## Related Topics

[16.1.4 display snmp-agent community](#)

# 16.1.25 snmp-agent community complexity-check disable

## Function

The **snmp-agent community complexity-check disable** command disables the complexity check of a community name.

The **undo snmp-agent community complexity-check disable** command enables the complexity check of a community name.

By default, the device enables the complexity check of a community name.

## Format

**snmp-agent community complexity-check disable**

**undo snmp-agent community complexity-check disable**

## Parameters

None

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

The device checks the complexity of community names in simple text rather than in ciphertext. The device has the following requirements for community name complexity:

- The minimum length of a community name is determined by the [2.5.23 set password min-length](#) command. By default, a password contains 8 characters.
- The community name includes at least two kinds of characters: uppercase letters, lowercase letters, numbers, and special characters (excluding ?).

### Precautions

To ensure the security of SNMP community names, enable the complexity check for community names. If a community name fails the complexity check, the community name cannot be configured. The complexity check can also be disabled for a community name. However, if a community name is simple and does not meet complexity requirements, it is prone to be attacked and cracked by unauthorized users, which affects device security.

## Example

```
# Disable the complexity check for community names.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent community complexity-check disable
```

## Related Topics

[16.1.24 snmp-agent community](#)

[2.5.23 set password min-length](#)

## 16.1.26 snmp-agent extend error-code enable

### Function

The **snmp-agent extend error-code enable** command enables the device to send extended error codes to the NMS.

The **undo snmp-agent extend error-code enable** command disables the function of sending extended error codes to the NMS.

By default, the function of sending extended error codes to the NMS is disabled.

### Format

**snmp-agent extend error-code enable**

**undo snmp-agent extend error-code enable**

### Parameters

None

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

With the increasing number of features and scenarios supported by the system, the current types of SNMP standard error codes can hardly meet requirements in diversified scenarios. Therefore, the extended error code is introduced. The extended error code can define more scenarios for the NMS to correctly analyze the fault type of the current NE.

If the NMS and managed device are Huawei devices, error codes are extended and more scenarios are defined after the function of sending extended error codes is enabled. As a result, users are enabled to locate and troubleshoot faults quickly and accurately.

Support of the MIB for the extended error code:

- For the MIB that supports the extended error code, you can enable the SNMP extended error code function and use Huawei NMS to provide the NMS with various error codes.
- For the MIB that does not support the extended error code, after the SNMP extended error code function is enabled, NMS of either Huawei or other vendors can obtain only the standard error code.

### Example

```
# Enable the device to send extended error codes to the NMS.
```

```
<HUAWEI> system-view
[HUAWEI] snmp-agent extend error-code enable
```

## Related Topics

[16.1.5 display snmp-agent extend error-code status](#)

## 16.1.27 snmp-agent group

### Function

The **snmp-agent group** command creates an SNMP group by mapping SNMP users to SNMP views.

The **undo snmp-agent group** command deletes a specified SNMP user group.

By default, no SNMP group is configured.

### Format

```
snmp-agent group v3 group-name { authentication | privacy | noauthentication } [ read-view read-view | write-view write-view | notify-view notify-view ]* [ acl { acl-number | acl-name } ]
```

```
undo snmp-agent group v3 group-name { authentication | privacy | noauthentication }
```

### Parameters

Parameter	Description	Value
<b>v3</b>	Indicates that the SNMP group uses the security mode in SNMPv3.	-
<i>group-name</i>	Specifies the name of an SNMP group.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.

Parameter	Description	Value
<b>authentication   privacy   noauthentication</b>	<p>Indicates the security level of the SNMP group.</p> <ul style="list-style-type: none"> <li>• <b>authentication:</b> authenticates SNMP messages without encryption.</li> <li>• <b>privacy:</b> authenticates and encrypts SNMP messages.</li> <li>• <b>noauthentication:</b> not authenticate or encrypt SNMP messages.</li> </ul>	<p>To ensure security, it is recommended that you set the security level of the SNMP group to <b>privacy</b>.</p>
<b>read-view</b> <i>read-view</i>	<p>Specifies a read-only view.</p>	<p>The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.</p> <p><i>read-view</i> specified by the <b>snmp-agent mib-view</b> command.</p>
<b>write-view</b> <i>write-view</i>	<p>Specifies a read-write view.</p>	<p>The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.</p> <p><i>write-view</i> is specified by the <b>snmp-agent mib-view</b> command.</p>
<b>notify-view</b> <i>notify-view</i>	<p>Specifies a notify view.</p>	<p>The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.</p> <p><i>notify-view</i> is specified by the <b>snmp-agent mib-view</b> command.</p>

Parameter	Description	Value
<b>acl</b> { <i>acl-number</i>   <i>acl-name</i> }	<p>Specifies the ACL.</p> <ul style="list-style-type: none"> <li>• <i>acl-number</i> specifies the number of the ACL.</li> <li>• <i>acl-name</i> specifies the name of an ACL.</li> </ul> <p>The ACL can be a basic ACL or an advanced ACL, and the ACL configured takes effect on both IPv4 and IPv6 networks.</p>	<ul style="list-style-type: none"> <li>• The value of <i>acl-number</i> is an integer that ranges from 2000 to 3999.</li> <li>• The value of <i>acl-name</i> is a string of 1 to 32 case-sensitive characters without spaces. The value must start with a letter (case sensitive) and can contain numbers, hyphens (-), or underlines (_).</li> </ul>

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

SNMPv1 and SNMPv2c have serious defects in terms of security. The security authentication mechanism used by SNMPv1 and SNMPv2c is based on the community name. In this mechanism, the community name is transmitted in plain text. You are not advised to use SNMPv1 and SNMPv2c on untrusted networks.

By adopting the user-based security model, SNMPv3 eradicates the security defects in SNMPv1 and SNMPv2c and provides two services, authentication and privacy. The SNMP group name and security name determine an SNMP group. SNMPv3 defines the following security levels:

- noAuthNoPriv
- AuthNoPriv
- AuthPriv

### NOTE

The security authentication level noAuthPriv does not exist. This is because the generation of a key is based on the authentication information and product information.

The **snmp-agent group** command can be used to configure the following:

- Authentication
- Privacy
- Access rights for users of SNMP group
- Bind the SNMP group to a MIB view

Parameters are selected based on the following rules:



- To enhance security, configure the parameter **authentication** or **privacy**.
  - If the **noauthentication** parameter is set, SNMP messages are not authenticated or encrypted. This applies to the environment that is secure and has a fixed administrator.
  - To authenticate SNMP messages without encryption, configure the parameter **authentication**. This mode is applicable to secure networks managed by many administrators who may frequently perform operations on the same device. Authentication allows only the administrators with permission to access the device.
  - To authenticate and encrypt SNMP messages, configure the parameter **privacy**. This mode is applicable to insecure networks managed by many administrators who may frequently perform operations on the same device. Authentication and encryption allow only specified administrators to access the device and encrypts data before the transmission. This prevents data from being tampered or leaked.
- To grant the NMS read-only permission in the specified view, configure **read-view**. To grant the NMS read-write permission in the specified view, configure **write-view**. To filter unnecessary alarms, configure **notify-view**. After this parameter is configured, only alarms generated on MIB objects specified by **notify-view** are delivered to the NMS.

By default, the read-only view of an SNMP group is the ViewDefault view, and the names of the read-write view and inform view are not specified.
- To allow specified NMSs in the same SNMPv3 group to access the device, configure **acl**.

### Configuration Impact

When you run the **undo snmp-agent group** command to delete an SNMP user group, you delete all SNMP users in the SNMP user group.

### Precautions

To receive trap messages specified in *notify-view*, you need to ensure the target host for receiving SNMP traps is specified through the **snmp-agent target-host trap** command.

If non authentication and non encryption, or authentication and non encryption is configured for an SNMPv3 group, these modes bring security risks. To improve system security, delete the group and create a group with authentication and encryption.

## Example

# Create an SNMPv3 group named **Johngroup** to authenticate and encrypt SNMP messages, and set the read-only view of the SNMPv3 group to public.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent
[HUAWEI] snmp-agent mib-view excluded public 1.3.6.1.2.1
[HUAWEI] snmp-agent group v3 Johngroup privacy read-view public
```

# Create an SNMPv3 group named **Johngroup** to authenticate and encrypt SNMP messages, and set the write-only view of the SNMPv3 group to private.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent
```

```
[HUAWEI] snmp-agent mib-view included private 1.3.6.1.2.1  
[HUAWEI] snmp-agent group v3 Johngroup privacy write-view private
```

## Related Topics

[16.1.33 snmp-agent mib-view](#)

[16.1.60 snmp-agent usm-user](#)

[16.1.6 display snmp-agent group](#)

## 16.1.28 snmp-agent heartbeat enable

### Function

The **snmp-agent heartbeat enable** command enables the device to send heartbeat packets to the NMS.

The **undo snmp-agent heartbeat enable** command disables the device from sending heartbeat packets to the NMS.

By default, the device does not send heartbeat packets to the NMS.

### Format

**snmp-agent heartbeat enable**

**undo snmp-agent heartbeat enable**

### Parameters

None

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

When the NMS cannot initiatively obtain the status of the device, run the **snmp-agent heartbeat enable** command to enable the device to send heartbeat packets to the NMS. The device then periodically sends heartbeat packets to the NMS to notify the NMS of its status.

### Example

# Enable the device to send heartbeat packets to the NMS.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent heartbeat enable
```

## Related Topics

[16.1.7 display snmp-agent heartbeat configuration](#)

# 16.1.29 snmp-agent heartbeat interval

## Function

The **snmp-agent heartbeat interval** command sets the interval at which the device sends heartbeat packets to the NMS.

The **undo snmp-agent heartbeat interval** command restores the interval at which the device sends heartbeat packets to the NMS to the default interval.

By default, the device sends heartbeat packets to the NMS at an interval of 60 seconds.

## Format

**snmp-agent heartbeat interval** *interval*

**undo snmp-agent heartbeat interval**

## Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the interval at which the device sends heartbeat packets to the NMS.	The value is an integer that ranges from 60 to 86400, in seconds.

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

After enabling the device to send heartbeat packets to the NMS, you can use the **snmp-agent heartbeat interval** command to set the interval at which heartbeat packets are sent. On a stable network, increase the interval to reduce the bandwidth consumed for periodic transmission of heartbeat packets.

### Prerequisites

The device has been enabled to send heartbeat packets to the NMS using the **snmp-agent heartbeat enable** command.

## Example

# Configure the device to send heartbeat packets to the NMS at an interval of 180 seconds.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent heartbeat interval 180
```

## Related Topics

[16.1.7 display snmp-agent heartbeat configuration](#)

[16.1.28 snmp-agent heartbeat enable](#)

# 16.1.30 snmp-agent inform

## Function

The **snmp-agent inform** command sets global parameters of informs, including the timeout period for waiting for inform ACK messages, number of times to retransmit informs, and maximum number of informs to be confirmed in the inform buffer.

The **undo snmp-agent inform** command restores the default setting.

By default, the timeout waiting period for inform ACK messages is 15 seconds, the number of times to retransmit informs is 3, and the maximum number of informs in the inform buffer is 39.

## Format

**snmp-agent inform** { **timeout** *seconds* | **resend-times** *times* | **pending** *number* }

\*

**undo snmp-agent inform** { **timeout** | **resend-times** | **pending** } \*

## Parameters

Parameter	Description	Value
<b>timeout</b> <i>seconds</i>	Specifies the timeout period for waiting for inform ACK messages from the NMS.	The value is an integer ranging from 1 to 1800, in seconds. The default value is 15 seconds.
<b>resend-times</b> <i>times</i>	Specifies the times to retransmit informs in the case that no inform ACK message is returned from the NMS.	The value is an integer ranging from 0 to 10. The default value is 3.
<b>pending</b> <i>number</i>	Specifies the maximum number of informs to be confirmed in the inform buffer.	The value is an integer ranging from 1 to 2048. The default value is 39.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

After sending an inform, the SNMP agent waits for an inform ACK message from the NMS. You can run the **snmp-agent inform** command to set parameters **timeout**, **resend-times**, and **pending** of the inform.

These three parameters mutually affect each other. For example, if the timeout period for waiting for inform ACK messages prolongs or the times to retransmit informs increase, but the maximum number of informs to be confirmed is not changed, the number of informs to be confirmed is increased, causing the inform buffer to be quickly filled up.

Once the inform buffer is filled up, the earliest inform in the inform buffer is deleted each time a new inform enters the queue. The deleted informs are not retransmitted to the NMS. To avoid this problem, you can increase the maximum number of informs to be confirmed in the inform buffer.

You can configure the **snmp-agent inform** command to contain the parameter **timeout**, **resend-times**, or **pending** according to the network condition.

- When a large number of informs are dropped on the network, you can run the **snmp-agent inform pending number** command to increase the inform buffer.
- When the transmission speed on the network is low, you can increase the timeout period. Increasing the timeout period will increase the waiting time of informs in the inform buffer. You can also run the **snmp-agent inform { timeout seconds | pending number } \*** command to increase the inform.
- When the transmission speed on the network is high, you can run the **snmp-agent inform timeout seconds** command to reduce the timeout period.
- When informs are transmitted on an unreliable network, you can increase the retransmission times. In this case, the informs in the inform buffer need to wait for a longer time to be confirmed. You can run the **snmp-agent inform { resend-times times | pending number } \*** command to increase the inform buffer.

### Prerequisites

Parameters for sending informs take effect only after the IP address of the target host for receiving informs is configured using the **snmp-agent target-host inform** command.

### Precautions

You need to configure only parameters for sending informs using the **snmp-agent inform** command; you do not need to configure parameters for sending traps.

You must set the parameters **timeout**, **resend-times**, and **pending** according to the network condition. Otherwise, the SNMP working efficiency is greatly affected.

## Example

# Set the times to retransmit an inform to 5 and the maximum number of informs waiting to be confirmed in the inform buffer to 100.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent inform resend-times 5 pending 100
```

## Related Topics

- [16.1.8 display snmp-agent inform](#)
- [16.1.31 snmp-agent inform address](#)
- [16.1.50 snmp-agent trap enable](#)

## 16.1.31 snmp-agent inform address

### Function

The **snmp-agent inform address** command sets parameters for sending informs, including the timeout period for waiting for inform ACK messages from the NMS and times to retransmit an inform.

The **undo snmp-agent inform address** command restores the default setting for a particular inform host.

By default, the timeout waiting period for inform ACK messages is 15 seconds and the number of times to retransmit informs is 3.

### Format

**snmp-agent inform** { **timeout** *seconds* | **resend-times** *times* } \* **address udp-domain** *ip-address* [ **vpn-instance** *vpn-instance-name* ] **params securityname** { *security-name* | **cipher** *security-name* }

**undo snmp-agent inform** { **timeout** [ *seconds* ] | **resend-times** [ *times* ] } \* **address udp-domain** *ip-address* [ **vpn-instance** *vpn-instance-name* ] **params securityname** { *security-name* | **cipher** *security-name* }

#### NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

### Parameters

Parameter	Description	Value
<b>timeout</b> <i>seconds</i>	Specifies the timeout period for waiting for inform ACK messages from the NMS.	The value is an integer ranging from 1 to 1800, in seconds. The default value is 15, which is equal to the global timeout period configured using the <a href="#">snmp-agent inform</a> command.

Parameter	Description	Value
<b>resend-times</b> <i>times</i>	Specifies the number of times that informs are retransmitted when no inform ACK message is returned from the NMS.	The value is an integer ranging from 0 to 10. The default value is 3, which is equal to the global retransmission times configured using the <b>snmp-agent inform</b> command.
<b>address</b>	Indicates the address of the target host for receiving SNMP traps.  <b>NOTE</b> The IP address specified by <b>address</b> and the security name specified by <b>securityname</b> together identify a host.	The value is dotted decimal notation.
<b>udp-domain</b> <i>ip-address</i>	Specifies the IP address of a specified target host, with the transmission domain based on UDP.	The value is dotted decimal notation.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The value must be an existing VPN instance name. The parameter <b>vpn-instance</b> is optional. On a VPN network, you need to use the VPN instance specified by <b>vpn-instance</b> , IP address, and security name to identify a target host.
<b>params</b>	Indicates information about the target host that generates SNMP notifications.	-

Parameter	Description	Value
<b>securityname</b> <i>security-name</i>	<p>Displays the name of the target host for receiving informs on the NMS.</p> <p>For SNMPv3, <b>securityname</b> must be configured as the user name. <b>securityname</b> configured on the host needs to be the same as that configured on the NMS, or the NMS cannot receive the trap messages sent from the host.</p> <p>For SNMPv2c, the NMS can receive trap messages from all hosts without having <b>securityname</b> configured. <b>securityname</b> is used to distinguish multiple hosts that generate trap messages.</p>	<p>The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.</p>
<b>cipher</b> <i>security-name</i>	<p>Indicates the unencrypted or encrypted string of security name.</p>	<p>The value is a string of 1 to 32, 32, 48, 56, or 68 case-sensitive characters without spaces. When double quotation marks are used around the string, spaces are allowed in the string.</p> <ul style="list-style-type: none"> <li>• When the community name is a string of 1 to 32 characters, the string is processed as plain text by default and will be encrypted.</li> <li>• When the community name is a string of 32, 48, 56, or 68 characters, the string is processed as cipher text by default, and the system will determine whether the string can be parsed.</li> </ul>

## Views

System view

## Default Level

3: Management level



## Usage Guidelines

### Usage Scenario

You can use both the **snmp-agent inform address** command and the **snmp-agent inform** command to set parameters according to the network condition.

- When a large number of Inform messages are dropped on the network, you are recommended to run the **snmp-agent inform pending *number*** command to lengthen the trap queue and then the **snmp-agent inform address** command to specify the destination IP address and name of the target host.
- When the transmission speed on the network is low, you are recommended to increase the timeout period. Increasing the timeout period will surely increase the waiting time of informs in the trap queue for confirmation. In this case, you are also recommended to run the **snmp-agent inform { **timeout *seconds*** | **pending *number*** } \*** command to lengthen the trap queue and then the **snmp-agent inform address** command to specify the destination address and the displayed user name.
- When the transmission speed on the network is high, you are recommended to run the **snmp-agent inform timeout *seconds* address udp-domain *ip-address* params securityname *security-name*** command to reduce the timeout period.
- When informs are transmitted on an unreliable network, you are recommended to increase the retransmission times. In this case, the informs in the trap queue need to wait for a longer time to be confirmed. This requires you to run the **snmp-agent inform { **resend-times *times*** | **pending *number*** } \*** command to lengthen the trap queue and then the **snmp-agent inform address** command to specify the destination address and the displayed user name.

### Prerequisites

Parameters for sending informs take effect only after the IP address of the target host for receiving informs is configured using the **snmp-agent target-host inform** command.

### Precautions

- You need to configure only parameters for sending informs using the **snmp-agent inform address** command; you do not need to configure parameters for sending traps.
- You must set the parameters **timeout** and **resend-times** according to the network condition. Otherwise, the SNMP working efficiency is greatly affected.
- The priority set for the **timeout** and **resend-times** parameters using the **snmp-agent inform address** command is higher than that set for the **timeout** and **resend-times** parameters using the **snmp-agent inform** command. If both parameters in Inform mode and parameters using the **snmp-agent inform address** command are configured, parameters using the **snmp-agent inform address** command take effect for a specified destination host.
- For SNMPv2c, when a user with a level lower than the level configured using this command queries the securityname configured using the **2.1.10 display this** command, the securityname is displayed as asterisks (**\*\*\*\*\***).

## Example

```
# Set the times to retransmit an inform to the target host (with the IP address of  
10.1.1.1 and the security name of ABC) to 10.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent inform resend-times 10 address udp-domain 10.1.1.1 params securityname ABC
```

## Related Topics

[16.1.8 display snmp-agent inform](#)

[16.1.30 snmp-agent inform](#)

## 16.1.32 snmp-agent local-engineid

### Function

The **snmp-agent local-engineid** command sets an engine ID for the local SNMP agent.

The **undo snmp-agent local-engineid** command restores the engine ID of the local SNMP agent to the default value.

By default, the device uses an internal algorithm to automatically generate an engine ID for a device. The engine ID consists of the enterprise number and the device information.

### Format

```
snmp-agent local-engineid engineid
```

```
undo snmp-agent local-engineid
```

### Parameters

Parameter	Description	Value
<i>engineid</i>	Specifies the engine ID of the local SNMP agent.	The value is string of 10 to 64 hexadecimal digits. It cannot be all 0s or all Fs.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

You can run the **snmp-agent local-engineid** command to set an engine ID for the local SNMP agent for identification.

The SNMP engine ID uniquely identifies an SNMP agent in a management domain. The SNMP engine ID is an important component of the SNMP agent. It schedules and processes SNMP messages, and implements security authentication and access control. You can use the [display snmp-agent local-engineid](#) command to check the engine ID of the local SNMP entity.

When setting an engine ID, you need to comply with the following rules:

- The length of the octet strings varies. The first four octets are set to the binary equivalent of the agent, which is SNMP management private enterprise number and is assigned by the Internet Assigned Numbers Authority (IANA). The engine ID of Huawei devices is 2011 in decimal notation. The first digit is in binary format, and has a fixed value 1. Therefore, the engine ID in hexadecimal format is 800007DB.
- The device information can be configured manually. It is recommended that the IP address or MAC address of the device be used as the device information to uniquely identify the device.

#### Precautions

- After the SNMP agent function is enabled using the [snmp-agent](#) command, the system automatically adopts the default engine ID for the local SNMP agent.
- If the local engine ID is set or changed, the existing SNMPv3 user with this engine ID is deleted.

## Example

```
# Set the engine ID of the local SNMP agent to 800007DB03360102101100.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent local-engineid 800007DB03360102101100
```

## Related Topics

[16.1.3 display snmp-agent](#)

[16.1.60 snmp-agent usm-user](#)

## 16.1.33 snmp-agent mib-view

### Function

The **snmp-agent mib-view** command creates or updates a MIB view.

The **undo snmp-agent mib-view** command cancels the configuration of the current MIB view.

In SNMPv1 and SNMPv2c, the default MIB view name is the ViewDefault and the OID is 1.3.6.1. In SNMPv3, there is no default MIB view and must be configured.

### Format

```
snmp-agent mib-view { excluded | included } view-name oid-tree
```

```
undo snmp-agent mib-view view-name [ oid-tree ]
```

**undo snmp-agent mib-view** [ **excluded** | **included** ] *view-name* [ *oid-tree* ]

## Parameters

Parameter	Description	Value
<b>excluded</b>	Indicates that the MIB view excludes the MIB subtree.	-
<b>included</b>	Indicates that the MIB view includes the MIB subtree.	-
<i>view-name</i>	Specifies the MIB view name.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.
<i>oid-tree</i>	Specifies the OID for the MIB subtree. <i>oid-tree</i> can be the OID (such as 1.4.5.3.1) or the name (such as system) of the subtree.	It is a string of 1 to 255 case-sensitive characters without spaces. <b>NOTE</b> It must be a valid MIB subtree.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

Most SNMP configuration commands contain the parameter *view-name*. The **snmp-agent mib-view** command is used to create or update a view. You cannot modify or delete the default ViewDefault MIB view.

In the **snmp-agent mib-view** command, the parameter *view-name* can be displayed as an OID or an object name.

- Displaying the parameter *view-name* as an OID: **snmp-agent mib-view included myview 1.3.6.1.2.1**.
- Displaying the parameter *view-name* as an object name: **snmp-agent mib-view excluded myview system.7**.

### NOTE

To uniquely identify object identifiers in SNMP messages, SNMP uses a hierarchical naming structure to distinguish object identifiers from each other. This is a tree-like structure, with the nodes (such as {1.3.6.1.2.1}) representing object identifiers. The MIB is a collection of standard variables on monitored network devices.

You can select parameters based on the following rules:

- **excluded:** If a few MIB objects on the device or some objects in the current MIB view do not or no longer need to be managed by the NM station, **excluded** needs to be specified in the command to exclude these MIB objects.
- **included:** If a few MIB objects on the device or some objects in the current MIB view need to be managed by the NM station, **included** needs to be specified in the command to include these MIB objects.

If you forget which information you have configured for a MIB view, you can run the **display snmp-agent mib-view** command to check it.

### Precautions

When you run the **snmp-agent mib-view** command for multiple times to define the MIB view, the new configuration overwrites the original configuration if the values of *view-name* and *oid-tree* are the same; the new and original configurations both take effect if the values of *view-name* and *oid-tree* are different. The system can store a maximum of 256 MIB view configurations, among which there are four default views.

If both the **include** and **exclude** parameters are configured for MIB objects that have an inclusion relationship, whether to include or exclude the lowest MIB object will be determined by the parameter configured for the lowest MIB object. For example, the **snmpV2**, **snmpModules**, and **snmpUsmMIB** objects are from top down in the MIB table. If the **exclude** parameter is configured for **snmpUsmMIB** objects and **include** is configured for **snmpV2**, **snmpUsmMIB** objects will still be excluded.

## Example

```
# Create MIB view mib2view that includes all mib-2 objects and the subtree with the OID as 1.3.6.1.2.1.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent mib-view included mib2view 1.3.6.1.2.1
```

## Related Topics

[16.1.9 display snmp-agent mib-view](#)

[16.1.24 snmp-agent community](#)

[16.1.27 snmp-agent group](#)

## 16.1.34 snmp-agent notification-log

### Function

The **snmp-agent notification-log** command sets the aging time of trap logs and the maximum number of trap logs that can be saved in the trap log buffer.

The **undo snmp-agent notification-log** command restores the default configuration.

By default, the aging time of trap logs is 24 hours, and a maximum of 500 trap logs can be saved in the trap log buffer.

## Format

```
snmp-agent notification-log { global-ageout ageout | global-limit limit } *  
undo snmp-agent notification-log { global-ageout [ ageout ] | global-limit  
[ limit ] } *
```

## Parameters

Parameter	Description	Value
<b>global-ageout</b> <i>ageout</i>	Specifies the aging time of trap logs.	The value can be 0 or an integer that ranges from 12 to 36, in hours. The default value is 24. The value 0 indicates that trap logs are never aged out.
<b>global-limit</b> <i>limit</i>	Specifies the maximum number of trap logs that can be saved in the trap log buffer.	The value is an integer that ranges from 1 to 5000.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

When a device sends the alarms propagated through Inform messages, the target host is required to respond with Inform ACK messages. In the following two situations, the alarms propagated through Inform messages are logged and the alarm logs are cached in the log buffer to help the target host synchronize the alarms generated in the event of host or link failures:

- No Inform ACK message is returned when the number of times to resend the Inform message in the alarm queue reaches the set threshold.
- Inform messages will be discarded because the number of logged Inform messages reaches the maximum that the alarm queue can support.

The maximum number of alarm logs in a log buffer is fixed (500 by default) to prevent a device from being burdened with excessive alarm logs. Alarm logs are aged periodically (24 hours by default) to ensure alarm logs remain up-to-date.

### Precautions

- Only Inform logs are saved to the log buffer; trap logs are not saved to the log buffer.
- If notification logs in the log buffer do not need to be aged, you can set the aging time of these notification logs to 0.

- If the number of notification logs saved to the log buffer within the aging time exceeds the limit, new notification logs can still be saved but overwrites the earlier logs in the log buffer.
- The maximum number of alarm logs specified in the **snmp-agent notification-log** command cannot occupy more memory than the memory occupied by the log buffer. If the size of the log buffer is excessively large, more network resources are consumed. You are therefore recommended to set the size of the log buffer to a reasonable value.

## Example

# Set the aging time of trap logs to 36 hours.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent notification-log global-ageout 36
```

# Set the maximum number of trap logs that can be saved in the trap log buffer to 1000.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent notification-log global-limit 1000
```

## Related Topics

[16.1.10 display snmp-agent notification-log](#)

[16.1.35 snmp-agent notification-log enable](#)

# 16.1.35 snmp-agent notification-log enable

## Function

The **snmp-agent notification-log enable** command enables the notification logging function.

The **undo snmp-agent notification-log enable** command disables the notification logging function.

By default, the notification logging function is disabled.

## Format

**snmp-agent notification-log enable**

**undo snmp-agent notification-log enable**

## Parameters

None

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

When the route from a network element to the NMS is unreachable because of a link failure between the network element and NMS, the network element does not send any SNMP notifications to the NMS. If the notification logging function is enabled, the network element records trap logs. When the link between the network element and NMS recovers, the NMS can obtain the trap logs recorded when the link was faulty.

After the notification logging function is enabled, the system records informs in trap logs in either of the following conditions:

- No ACK message is received after an inform in the notification queue is retransmitted the specified number of times.
- Earliest informs are discarded because the number of notifications in the notification queue exceeds the limit. The system records the discarded informs in trap logs.

### Precautions

Only informs are recorded in trap logs, and traps are not recorded.

## Example

```
# Enable the notification logging function.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent notification-log enable
```

## Related Topics

[16.1.34 snmp-agent notification-log](#)

## 16.1.36 snmp-agent notify-filter-profile

### Function

The **snmp-agent notify-filter-profile** command creates or updates a trap filter profile.

The **undo snmp-agent notify-filter-profile** command deletes a trap filter profile.

By default, no trap is filtered.

### Format

```
snmp-agent notify-filter-profile { included | excluded } profile-name oid-tree
```

```
undo snmp-agent notify-filter-profile [ included | excluded ] profile-name
```



## Parameters

Parameter	Description	Value
<b>included</b>	Includes the specified MIB subtree.	-
<b>excluded</b>	Excludes the specified MIB subtree.	-
<i>profile-name</i>	Specifies the name of a trap filter profile.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.
<i>oid-tree</i>	Specifies the OID for the MIB subtree. <i>oid-tree</i> can be the OID (such as 1.4.5.3.1) or the name (such as system) of the subtree.	The value is a string of 1 to 255 case-sensitive characters without spaces. <b>NOTE</b> It must be a valid MIB subtree.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

To filter trap messages sent to a target host, run the **snmp-agent notify-filter-profile** command to add the MIB objects to be filtered to a filter profile to limit the number of MIB objects that can send trap messages to the NMS. After the filter profile is configured using the **snmp-agent notify-filter-profile** command, only the trap messages generated by eligible MIB objects are sent to the NMS.

### Precautions

- If no trap filter profile is configured, all traps are sent to the destination host.
- The **snmp-agent notify-filter-profile** command creates or updates a trap filter profile. The value of *oid-tree* can be an OID or a subtree name. An OID can contain asterisks (\*) as wildcards. An asterisk (\*) cannot be placed at the beginning or end of the OID string.
- In Include filtering mode of an alarm, OIDs of all bound variables in the alarm must be specified in this command. Otherwise, the filtering fails.
- In Exclude filtering mode of an alarm, only the OID of the alarm or that of any bound variable need to be specified in this command.

## Example

```
# Configure a trap filter profile named tmp.  
<HUAWEI> system-view  
[HUAWEI] snmp-agent notify-filter-profile included tmp 1.3.6.1.*.4
```

## Related Topics

[16.1.11 display snmp-agent notify-filter-profile](#)

# 16.1.37 snmp-agent packet contextengineid-check enable

## Function

The **snmp-agent packet contextengineid-check enable** command enables the device to check consistency between the contextEngineID on the NMS and the local engine ID.

The **undo snmp-agent packet contextengineid-check enable** command disables the device from checking consistency between the contextEngineID on the NMS and the local engine ID.

By default, the device does not check consistency between the contextEngineID on the NMS and the local engine ID.

## Format

**snmp-agent packet contextengineid-check enable**

**undo snmp-agent packet contextengineid-check enable**

## Parameters

None

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

If the device does not check consistency between the contextEngineID on the NMS and the local engine ID, the NMS can connect to the device even if the contextEngineID is different from the local engine ID.

To improve system security, run the **snmp-agent packet contextengineid-check enable** command to enable the device to check consistency between the contextEngineID on the NMS and the local engine ID.

### Configuration Impact

After this function is enabled, an NMS cannot connect to the device if the contextEngineID on the NMS is different from the local engine ID.

### Precautions

This consistency check function applies only to SNMPv3.

## Example

```
# Enable the consistency check between the contextEngineID and local engine ID.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent packet contextengineid-check enable
```

## 16.1.38 snmp-agent packet max-size

### Function

The **snmp-agent packet max-size** command sets the maximum size of an SNMP message.

The **undo snmp-agent packet max-size** command restores the default setting.

By default, the maximum size of an SNMP message is 12000 bytes.

### Format

**snmp-agent packet max-size** *byte-count*

**undo snmp-agent packet max-size**

### Parameters

Parameter	Description	Value
<i>byte-count</i>	Specifies the maximum size of an SNMP message that the SNMP agent can receive and send.	The value is an integer that ranges from 484 to 17940, in bytes. The default value is 12000.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

You are recommended to run the **snmp-agent packet max-size** command to set the maximum size of an SNMP message that the SNMP agent receives or sends according to the network condition.

By increasing the maximum size of an SNMP message, you can prevent the NMS from obtaining the incomplete information about the device status.

By decreasing the maximum size of an SNMP message, you can prevent the NMS or device from discarding an SNMP message because its size exceeds the processing capability of the NMS or device.

### Precautions

You need to increase the size of an SNMP message according to the network condition. Otherwise, the transmission efficiency of SNMP messages is affected.

Generally, the default value is recommended.

The maximum size set through the **snmp-agent packet max-size** command takes effect for the SNMP messages of all SNMP versions.

## Example

# Set the maximum size of an SNMP message that the SNMP agent can receive or send to 1042 bytes.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent packet max-size 1042
```

## 16.1.39 snmp-agent packet-priority

### Function

The **snmp-agent packet-priority** command sets the priority of SNMP messages.

The **undo snmp-agent packet-priority** command restores the default priority of SNMP messages.

By default, the priority of SNMP messages is 6.

### Format

**snmp-agent packet-priority** { snmp | trap } *priority-level*

**undo snmp-agent packet-priority** { snmp | trap }

### Parameters

Parameter	Description	Value
snmp	Sets the priority of common SNMP messages (excluding trap messages), including: <ul style="list-style-type: none"> <li>Get-Response packets</li> <li>Set-Response packets</li> </ul>	-

Parameter	Description	Value
<b>trap</b>	Sets the priority of SNMP trap messages, including: <ul style="list-style-type: none"><li>• Trap packets</li><li>• Inform packets</li></ul>	-
<i>priority-level</i>	Specifies the priority of SNMP messages.	The value is an integer that ranges from 0 to 7. The default value is 6. The value 0 indicates the lowest priority, and the value 7 indicates the highest priority.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

SNMP messages may be lost if the number of SNMP messages on a network exceeds the processing capability of the NMS. Run the **snmp-agent packet-priority** command to set the transmission priority of SNMP messages to ensure that the NMS can process important messages first. This command can be used in the following situations:

- To prevent traps from being discarded, increase the priority of SNMP trap messages so that traps can be successfully sent to the NMS.
- To improve reliability of MIB operations performed on the device by the NMS, increase the priority of common SNMP messages, excluding SNMP trap messages.
- When the network is severely congested and traps are generated frequently, reduce the priority of all SNMP messages, including SNMP trap messages.

## Example

```
# Set the priority of common SNMP messages to 5.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent packet-priority snmp 5
```

## 16.1.40 snmp-agent protocol get-bulk timeout

### Function

The **snmp-agent protocol get-bulk timeout** command configures a get-bulk operation timeout period.

The **undo snmp-agent protocol get-bulk timeout** command restores the default get-bulk operation timeout period.

The default get-bulk operation timeout period is 2 seconds.

## Format

**snmp-agent protocol get-bulk timeout** *time*

**undo snmp-agent protocol get-bulk timeout**

## Parameters

Parameter	Description	Value
<i>time</i>	Specifies a get-bulk operation timeout period.	The value is an integer ranging from 0 to 600, in seconds. <b>NOTE</b> The value 0 indicates that a get-bulk operation never expires.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

A get-bulk operation allows an NMS to query information about multiple managed devices at a time, equaling multiple get-next operations.

If an NMS requests many data through a get-bulk operation, a long time is required to obtain the data. You can run the **snmp-agent protocol get-bulk timeout** command to change the get-bulk operation timeout period.

### Precautions

You are not advised to change the get-bulk operation timeout period. The default get-bulk operation timeout period is recommended. To reconfigure a get-bulk operation timeout period, you must ensure that the configured period is less than an NMS's timeout period.

## Example

# Set the get-bulk operation timeout period to 10 seconds.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent protocol get-bulk timeout 10
```

## 16.1.41 snmp-agent protocol server disable

### Function

The **snmp-agent protocol server disable** command disables the SNMP IPv4 or IPv6 listening port.

The **undo snmp-agent protocol server disable** command enables the SNMP IPv4 or IPv6 listening port.

By default, the SNMP IPv4 or IPv6 listening port is disabled.

### Format

**snmp-agent protocol server [ ipv4 | ipv6 ] disable**

**undo snmp-agent protocol server [ ipv4 | ipv6 ] disable**

### Parameters

Parameter	Description	Value
<b>ipv4</b>	Disables the SNMP IPv4 listening port.	-
<b>ipv6</b>	Disables the SNMP IPv6 listening port.	-

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

To enable alarm sending to the NMS without performing the Get/Set operation, SNMP port listening is not required. To disable the SNMP IPv4 or IPv6 listening port, run the **snmp-agent protocol server disable** command.

This command helps separately manage and control SNMP IPv4 and IPv6 listening ports.

If **ipv4** or **ipv6** is not selected, both SNMP IPv4 and IPv6 listening ports are disabled.

#### Precautions

After you disable the SNMP IPv4 or IPv6 listening port using the **snmp-agent protocol server disable** command, SNMP no longer processes SNMP packets. Exercise caution when you disable the SNMP IPv4 or IPv6 listening port.

## Example

```
# Disable the SNMP IPv4 listening port.
<HUAWEI> system-view
[HUAWEI] snmp-agent protocol server ipv4 disable
```

## 16.1.42 snmp-agent protocol source-interface

### Function

The **snmp-agent protocol source-interface** command configures a source interface for receiving and responding to NM station requests.

The **undo snmp-agent protocol source-interface** command restores the default configuration.

By default, the source interface is not configured for receiving and responding to NM station requests.

### Format

**snmp-agent protocol source-interface** *interface-type interface-number*

**undo snmp-agent protocol source-interface**

### Parameters

Parameter	Description	Value
<i>interface-type interface-number</i>	Specifies an interface type and number.	Currently, only loopback interfaces are supported.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

By default, a source interface is randomly selected for receiving and responding to NM station requests, which is inconvenient for unified data management. To resolve this problem, run the **snmp-agent protocol source-interface** command to configure a source interface for receiving and responding to NM station requests.

#### Prerequisites

The interface to be configured as the source interface must have been created, and a valid IP address must have been assigned to this interface. If the interface to be configured as the source interface is not created or a valid IP address is not assigned to the interface, the **snmp-agent protocol source-interface** command



will not take effect. If a valid IP address is assigned to the interface, the **snmp-agent protocol source-interface** command will take effect automatically.

### Precautions

If the interface on which the **snmp-agent protocol source-interface** command is configured is deleted, or an address is changed or deleted on the interface, SNMP configurations will not be affected.

After SNMP is bound to the source interface, SNMP listens only this interface, through which the NMS communicates with the device. If the source interface or its IP address is deleted, SNMP will stop receiving IP packets, and therefore communication between the NMS and devices will interrupt. After the source interface's IP address is changed, the NMS can communicate with devices only through the new IP address.

## Example

```
# Configure loopback 1 as a source interface for receiving and responding to NM
station requests.
<HUAWEI> system-view
[HUAWEI] snmp-agent protocol source-interface Loopback 1
```

## 16.1.43 snmp-agent protocol server message queue

### Function

The **snmp-agent protocol server message queue** command configures the size of a packet queue that can be received by an SNMP agent.

The **snmp-agent protocol server message queue** command restores the default size.

By default, the packet queue that can be received by an SNMP agent contains 30 packets.

### Format

**snmp-agent protocol server message queue** *message-queue*

**undo snmp-agent protocol server message queue**

### Parameters

Parameter	Description	Value
<i>message-queue</i>	Specifies the size of a packet queue.	The value is an integer ranging from 10 to 100.

### Views

System view

## Default Level

3: Management level

## Usage Guidelines

If some packets are discarded when the number of packets in the packet queue that can be received by an SNMP agent has reached the upper limit, run the **snmp-agent protocol server message queue** command to adjust the queue size.

## Example

# Configure the packet queue that can be received by an SNMP agent to contain 50 packets at most.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent protocol server message queue 50
```

## 16.1.44 snmp-agent statistics mib disable

### Function

The **snmp-agent statistics mib disable** command disables the statistics function about the NMS's operations on MIB objects.

The **undo snmp-agent statistics mib disable** command restores the default statistics status.

By default, the statistics function about the NMS's operations on MIB objects is enabled.

#### NOTE

Only S5720EI, S5720HI, S6720EI, and S6720S-EI support this command.

### Format

**snmp-agent statistics mib disable**

**undo snmp-agent statistics mib disable**

### Parameters

None

### Views

System view

### Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

An NMS performs operations on MIB objects to manage devices. Currently, SNMP supports the statistics function about these operations.

By default, the statistics function is enabled. To disable this function due to some reasons, for example, high CPU usage caused by collecting statistics about the NMS accessing MIB objects, run the **snmp-agent statistics mib disable** command.

#### Follow-up Procedure

Run the **display snmp-agent statistics mib** command to check statistics about the NMS's operations on MIB objects.

If the NMS accesses a great amount of MIB node information and statistics do not need to be saved, run the **reset snmp-agent statistics mib** command to delete the statistics.

#### Precautions

After you run the **snmp-agent statistics mib disable** command, the statistics function is disabled, but statistics that have been collected are not deleted.

## Example

```
# Disable the statistics function about the NMS's operations on MIB objects.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent statistics mib disable
```

## Related Topics

[16.1.13 display snmp-agent statistics mib](#)

[16.1.21 reset snmp-agent statistics mib](#)

## 16.1.45 snmp-agent sys-info

### Function

The **snmp-agent sys-info** command sets the SNMP system information.

The **undo snmp-agent sys-info** command restores the default setting.

By default, the system maintenance information is " R&D Beijing, Huawei Technologies Co., Ltd.", the system location is "Beijing China", and the version is SNMPv3.

### Format

```
snmp-agent sys-info { contact contact | location location | version { { v1 | v2c | v3 } * | all } }
```

```
undo snmp-agent sys-info { contact | location | version { { v1 | v2c | v3 } * | all } }
```

## Parameters

Parameter	Description	Value
<b>contact</b> <i>contact</i>	Indicates contact information of system maintenance.	The value is a string of 1 to 225 case-sensitive characters that can contain spaces.
<b>location</b> <i>location</i>	Indicates the location of a device.	The value is a string of 1 to 255 case-sensitive characters that can contain spaces.
<b>version</b> { { <b>v1</b>   <b>v2c</b>   <b>v3</b> } *   <b>all</b> }	<p>Indicates the SNMP version.</p> <ul style="list-style-type: none"> <li>• <b>v1</b>: SNMPv1 is enabled.</li> <li>• <b>v2c</b>: SNMPv2c is enabled.</li> <li>• <b>v3</b>: SNMPv3 is enabled.</li> <li>• <b>all</b>: SNMPv1, SNMPv2c, and SNMPv3 are enabled.</li> </ul> <p><b>NOTE</b></p> <p>This parameter can be repeatedly configured. If a device runs multiple SNMP versions, the NMS can use any one of them to manage the device.</p>	-

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

To configure the contact information for the managed node, you can run the **snmp-agent sys-info contact** command in the system. If a device fails, maintenance personnel can contact the vendor for device maintenance.

To configure the physical location of the node, you can run the **snmp-agent sys-info location** command in the system.

To configure features in a specified version, you can run the **snmp-agent sys-info version** command to set the corresponding SNMP version in the system. SNMPv1 or SNMPv2c is not secure enough. Using SNMPv3 is recommended.

SNMPv1:

- Community-name-based access control
- MIB-view-based access control

SNMPv2c:

- Community-name-based access control
- MIB-view-based access control
- Supporting Inform messages

Besides inheriting basic SNMPv2c operations, SNMPv3 defines a management architecture, which introduces a User-based Security Model (USM) to provide users with a more secure access mechanism.

- User group
- Group-based access control
- User-based access control
- Authentication and encryption mechanisms

 **NOTE**

Use **display snmp-agent sys-info** command to view the information of the system maintenance, the physical location of the node and the SNMP version.

### Precautions

A lack of authentication capabilities in SNMPv1 and SNMPv2c results in vulnerability to security threats, so SNMPv3 is recommended.

## Example

# Set the contact information of the system maintenance as "call Operator at 010-12345678".

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent sys-info contact call Operator at 010-12345678
```

# Set the location of a device as "shanghai China".

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent sys-info location shanghai China
```

# Set the current SNMP version used by the system to v2c.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent sys-info version v2c
```

## Related Topics

[16.1.14 display snmp-agent sys-info](#)

## 16.1.46 snmp-agent target-host inform

### Function

The **snmp-agent target-host inform** command sets the target host for receiving Inform messages.

The **undo snmp-agent target-host** command cancels the target host set to receive Inform messages.

By default, the target host for receiving Inform messages is not set.

## Format

**snmp-agent target-host inform address udp-domain** *ip-address* [ **udp-port** *port-number* | **source** *interface-type interface-number* | [ **vpn-instance** *vpn-instance-name* | **public-net** ] ] \* **params securityname** { *security-name* | **cipher** *security-name* } **v2c** [ **notify-filter-profile** *profile-name* | **ext-vb** ] \*

**snmp-agent target-host inform address udp-domain** *ip-address* [ **udp-port** *port-number* | **source** *interface-type interface-number* | [ **vpn-instance** *vpn-instance-name* | **public-net** ] ] \* **params securityname** *security-name* **v3** [ **authentication** | **privacy** ] [ **notify-filter-profile** *profile-name* | **ext-vb** ] \*

**undo snmp-agent target-host** *ip-address* **securityname** { *security-name* | **cipher** *security-name* } [ **vpn-instance** *vpn-instance-name* ]

**undo snmp-agent target-host inform address udp-domain** *ip-address* [ **udp-port** *port-number* | **source** *interface-type interface-number* | [ **vpn-instance** *vpn-instance-name* | **public-net** ] ] \* **params securityname** { *security-name* | **cipher** *security-name* }

### NOTE

Only S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support **vpn-instance** *vpn-instance-name* and **public-net**.

## Parameters

Parameter	Description	Value
<b>address</b>	Indicates the address of the target host for receiving SNMP Inform messages. <b>NOTE</b> The IP address specified by <b>address</b> and the security name specified by <b>securityname</b> together identify a target host.	-
<b>udp-domain</b> <i>ip-address</i>	Specifies the IP address of a specified target host, with the transmission domain being based on UDP.	It is dotted decimal notation.
<b>udp-port</b> <i>port-number</i>	Specifies the number of the UDP port for receiving Inform messages.	The value is an integer ranging from 0 to 65535. The default value is 162.
<b>source</b> <i>interface-type interface-number</i>	Specifies the source interface for sending Inform messages.	-

Parameter	Description	Value
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of a VPN instance. <b>NOTE</b> On a VPN network, you need to use the VPN instance specified by <b>vpn-instance</b> , IP address, and security name to identify a target host.	The value must be an existing VPN instance name.
<b>public-net</b>	Connects the NMS host on the public network.	-
<b>params</b>	Indicates information about the target host that generates SNMP notifications.	-
<b>securityname</b> <i>security-name</i>	Specifies the user security name displayed on the NMS.  For SNMPv3, <b>securityname</b> must be configured as the user name. <b>securityname</b> configured on the host needs to be the same as that configured on the NMS, or the NMS cannot receive the trap messages sent from the host. Ensure that the <i>security-name</i> value is the same as the created user name; otherwise, the NMS cannot access the device.  For SNMPv1 and SNMPv2c, the NMS can receive trap messages from all hosts without having <b>securityname</b> configured. <b>securityname</b> is used to distinguish multiple hosts that generate trap messages.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.

Parameter	Description	Value
<b>cipher</b> <i>security-name</i>	Indicates the unencrypted or encrypted string of security name.	<p>The value is a string of 1 to 32, 32, 48, 56, or 68 case-sensitive characters without spaces. When double quotation marks are used around the string, spaces are allowed in the string.</p> <ul style="list-style-type: none"> <li>When the community name is a string of 1 to 32 characters, the string is processed as plain text by default and will be encrypted.</li> <li>When the community name is a string of 32 48, 56, or 68 characters, the string is processed as cipher text by default, and the system will determine whether the string can be parsed.</li> </ul>
<b>v2c</b>	Indicates the SNMP version.	v2c indicates SNMPv2c.
<b>v3</b>	Indicates the SNMP version.	v3 indicates SNMPv3.
<b>authentication   privacy</b>	<p>Specifies the security mode.</p> <ul style="list-style-type: none"> <li><b>authentication</b>: authenticates SNMP messages without encryption.</li> <li><b>privacy</b>: authenticates and encrypts SNMP messages.</li> </ul> <p>This parameter takes effect only in SNMPv3.</p>	-
<b>notify-filter-profile</b> <i>profile-name</i>	Specifies the filtering view name.	The filtering view must exist.



Parameter	Description	Value
<b>ext-vb</b>	<p>Indicates that traps sent to a target host carry extended bound variables.</p> <p>If a Huawei data communication device extends the trap objects defined in the public MIB, you can configure this parameter to determine whether traps sent to the NMS carry extended bound variables.</p> <ul style="list-style-type: none"> <li>If this parameter is not configured, the traps sent from the Huawei data communication device do not carry extended bound variables.</li> </ul> <p>If you are using a third-party NMS tool, you are not advised to configure this parameter, which ensures that the NMS tool can receive alarms sent from the Huawei device.</p> <p>By default, a trap sent from a Huawei data communication device does not carry extended bound variables.</p> <ul style="list-style-type: none"> <li>If this parameter is configured, the traps sent from the Huawei data communication device carry extended bound variables.</li> </ul> <p>If you are using a Huawei NMS tool, you are advised to configure this parameter, which allows you to view more information carried in a trap.</p>	-

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

To set the target host to receive SNMP notifications, you can run the **snmp-agent target-host inform** command. When informs are sent to notify the NMS of the network status, you can configure the engine ID for the NMS to ensure that the

NMS can receive informs. The NMS receives an inform and returns an ACK message to the SNMP agent only if the engine ID contained in the Inform message and actual engine ID are the same. If the IDs are inconsistent, the NMS discards the inform.

If there are multiple target hosts, you need to run the **snmp-agent target-host inform** command on each target host. If the **snmp-agent target-host inform** command is executed for multiple times on the target host, only the last successful operation takes effect. For example, if you run the **snmp-agent target-host inform** command twice on a target host, the second operation overwrites the previous one.

The rules for selecting the target host are as follows:

- If the **public-net** parameter is specified, the system accesses the target host on the public network.
- If the **vpn-instance** *vpn-instance-name* parameter is specified, the system accesses the target host in the specified VPN instance.
- If both the **public-net** and **vpn-instance** *vpn-instance-name* parameters are not specified:
  - a. If the **source** *interface-type interface-number* parameter is specified and a VPN instance is bound to the specified interface, the system accesses the target host in the VPN instance. If no VPN instance is bound to the specified interface, the system accesses the target host on the public network.
  - b. If the **16.1.56 snmp-agent trap source** command is run to configure a source interface for sending trap packets and a VPN instance is bound to the interface, the system accesses the target host in the VPN instance. If no VPN instance is bound to the interface, the system accesses the target host on the public network.
  - c. If the **2.7.76 set net-manager vpn-instance** command is run to configure a network management VPN instance, the system accesses the target host in this VPN instance.
  - d. If none of the preceding conditions is met, the system accesses the target host on the public network.

### Configuration Impact

After the **snmp-agent target-host trap** command is executed, no matter whether a trap sent from the SNMP agent reaches the NMS, the SNMP agent deletes the trap to reduce the resource consumption.

After the **snmp-agent target-host inform** command is executed, the SNMP agent, after sending an Inform message, waits for an Inform ACK message from the NMS and will retransmit the same Inform message only when no Inform ACK message is received from the NMS within the specified period. If the SNMP agent does not receive the inform ACK message from the NMS during the retransmission period, the SNMP agent deletes this inform message from the trap queue. This ensures that the NMS can receive the SNMP Inform messages to the maximum extent. The transmission of Inform messages, however, consumes more resources than that of traps.

### Precautions

The **snmp-agent notify-filter-profile** command is used to create or update the trap filtering information. The NMS filters trap messages according to the profile and sends only the eligible trap messages to the target host. If **notify-filter-profile** is not configured, all trap messages are sent to the target host.

To enable a switch to propagate Inform messages, you need to run at least one of the two commands, namely, **snmp-agent target-host inform** on the switch.

Ensure that the security level of a trap host is not higher than that of the user specified by **securityname** and not lower than that of the user group. Otherwise, the trap host cannot send trap messages properly. The user security level can be (in descending order):

- Level 1: privacy (authentication and encryption)
- Level 2: authentication (without encryption)
- Level 3: noauthentication (no authentication or encryption)

When SNMPv3 is used to send Inform messages, run the **snmp-agent remote-engineid usm-user v3** command to configure a remote SNMPv3 user whose remote engine ID must be the same as the engine ID of the destination host.

For SNMPv2c, when a user with a level lower than the level configured using this command queries the securityname configured using the [2.1.10 display this](#) command, the securityname is displayed as asterisks (\*\*\*\*\*).

## Example

```
# Configure alarms to be sent in inform mode, set the security name of the host to 123 and protocol version to SNMPv2c, and send alarms to the NMS host with the IP address of 192.168.10.1.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable  
[HUAWEI] snmp-agent target-host inform address udp-domain 192.168.10.1 params securityname 123 v2c
```

## Related Topics

- [16.1.15 display snmp-agent target-host](#)
- [16.1.50 snmp-agent trap enable](#)

# 16.1.47 snmp-agent target-host trap

## Function

The **snmp-agent target-host trap** command configures the target host for receiving SNMP traps.

The **undo snmp-agent target-host** command deletes the target host configuration for receiving SNMP traps.

By default, the target host is not set.

## Format

**snmp-agent target-host trap address udp-domain** *ip-address* [ **udp-port** *port-number* | **source** *interface-type interface-number* ] [ **public-net** | **vpn-instance**

*vpn-instance-name* ] ] \* **params securityname** *security-name* [ [ **v1** | **v2c** | **v3** [ **authentication** | **privacy** ] ] | **private-netmanager** | **notify-filter-profile** *profile-name* | **ext-vb** ] \*

**snmp-agent target-host trap address udp-domain** *ip-address* [ **udp-port** *port-number* | **source** *interface-type interface-number* | [ **public-net** | **vpn-instance** *vpn-instance-name* ] ] \* **params securityname cipher** *security-name* [ [ **v1** | **v2c** ] | **private-netmanager** | **notify-filter-profile** *profile-name* | **ext-vb** ] \*

**undo snmp-agent target-host** *ip-address* **securityname** { *security-name* | **cipher** *security-name* } [ **vpn-instance** *vpn-instance-name* ]

**undo snmp-agent target-host trap address udp-domain** *ip-address* [ **udp-port** *port-number* | **source** *interface-type interface-number* | [ **public-net** | **vpn-instance** *vpn-instance-name* ] ] \* **params securityname** { *security-name* | **cipher** *security-name* }

 **NOTE**

Only S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support **public-net** and **vpn-instance** *vpn-instance-name*.

## Parameters

Parameter	Description	Value
<b>address</b>	Specifies the address of the target host that receives SNMP traps. <b>NOTE</b> The IP address specified by <b>address</b> and the security name specified by <b>securityname</b> together identify a target host.	-
<b>udp-domain</b> <i>ip-address</i>	Specifies the IP address of a specified target host, with the transmission domain being based on UDP.	-
<b>udp-port</b> <i>port-number</i>	Specifies the number of ports that receive SNMP traps.	The value is an integer ranging from 0 to 65535. The default value is 162.
<b>source</b> <i>interface-type interface-number</i>	Specifies the source interface for sending traps.	-
<b>public-net</b>	Connects the NMS host on the public network.	-

Parameter	Description	Value
<b>vpn-instance</b> <i>vpn-instance-name</i>	<p>Specifies the name of a VPN instance.</p> <p><b>NOTE</b></p> <p>On a VPN network, you need to use the VPN instance specified by <b>vpn-instance</b>, IP address, and security name to identify a target host.</p>	<p>The value must be an existing VPN instance name.</p>
<b>params</b> <b>securityname</b> <i>security-name</i>	<p>Specifies the user security name displayed on the NMS.</p> <p>For SNMPv3, <b>securityname</b> must be configured as the user name. <b>securityname</b> configured on the host needs to be the same as that configured on the NMS, or the NMS cannot receive the trap messages sent from the host. Ensure that the <i>security-name</i> value is the same as the created user name; otherwise, the NMS cannot access the device.</p> <p>For SNMPv1 and SNMPv2c, the NMS can receive trap messages from all hosts without having <b>securityname</b> configured. <b>securityname</b> is used to distinguish multiple hosts that generate trap messages.</p>	<p>The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.</p>

Parameter	Description	Value
<b>cipher</b> <i>security-name</i>	Indicates the unencrypted or encrypted string of security name.	<p>The value is a string of 1 to 32, 32, 48, 56, or 68 case-sensitive characters without spaces. When double quotation marks are used around the string, spaces are allowed in the string.</p> <ul style="list-style-type: none"> <li>When the community name is a string of 1 to 32 characters, the string is processed as plain text by default and will be encrypted.</li> <li>When the community name is a string of 32 48, 56, or 68 characters, the string is processed as cipher text by default, and the system will determine whether the string can be parsed.</li> </ul>
<b>v1</b>   <b>v2c</b>   <b>v3</b>	<p>Indicates the SNMP version.</p> <ul style="list-style-type: none"> <li><b>v1</b>: SNMPv1.</li> <li><b>v2c</b>: SNMPv2c.</li> <li><b>v3</b>: SNMPv3.</li> </ul> <p>If this parameter is not specified, the default version is SNMPv1.</p>	-
<b>authentication</b>   <b>privacy</b>	<p>Specifies the security mode.</p> <ul style="list-style-type: none"> <li><b>authentication</b>: authenticates packets without encryption.</li> <li><b>privacy</b>: authenticates and encrypts SNMP messages.</li> </ul> <p>This parameter takes effect only in SNMPv3.</p>	-

Parameter	Description	Value
<b>private-netmanager</b>	Indicates the Huawei NMS as the target host receiving a trap. When a Huawei NMS is deployed and this parameter is configured, a trap sent to the NMS contains more information, such as the trap type, sequence of the trap, and sending time.	-
<b>notify-filter-profile</b> <i>profile-name</i>	Specifies the filtering view name.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.

Parameter	Description	Value
<b>ext-vb</b>	<p>Indicates that traps sent to a target host carry extended bound variables.</p> <p>If a Huawei data communication device extends the trap objects defined in the public MIB, you can configure this parameter to determine whether traps sent to the NMS carry extended bound variables.</p> <ul style="list-style-type: none"> <li>• If this parameter is not configured, the traps sent from the Huawei data communication device do not carry extended bound variables.</li> </ul> <p>If you are using a third-party NMS tool, you are not advised to configure this parameter, which ensures that the NMS tool can receive alarms sent from the Huawei device.</p> <p>By default, a trap sent from a Huawei data communication device does not carry extended bound variables.</p> <ul style="list-style-type: none"> <li>• If this parameter is configured, the traps sent from the Huawei data communication device carry extended bound variables.</li> </ul> <p>If you are using a Huawei NMS tool, you are advised to configure this parameter, which allows you to view more information carried in a trap.</p>	-

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

SNMP notifications can be classified into traps and inform messages. Trap messages are less reliable than inform messages because the NMS does not send any acknowledgment when it receives a trap. In this case, the sender cannot verify



whether the trap has been received. Informs are configured with an acknowledgment mechanism and therefore are reliable.

To configure multiple target hosts, you must run the **snmp-agent target-host trap** command on each target host. If you run the **snmp-agent target-host trap** command for multiple times on a host, only the latest configuration takes effect. For example, if you configure the trap function for a host that has been configured with trap, the second configuration takes effect.

The rules for selecting the target host are as follows:

- If the **public-net** parameter is specified, the system accesses the target host on the public network.
- If the **vpn-instance** *vpn-instance-name* parameter is specified, the system accesses the target host in the specified VPN instance.
- If both the **public-net** and **vpn-instance** *vpn-instance-name* parameters are not specified:
  - a. If the **source** *interface-type interface-number* parameter is specified and a VPN instance is bound to the specified interface, the system accesses the target host in the VPN instance. If no VPN instance is bound to the specified interface, the system accesses the target host on the public network.
  - b. If the [16.1.56 snmp-agent trap source](#) command is run to configure a source interface for sending trap packets and a VPN instance is bound to the interface, the system accesses the target host in the VPN instance. If no VPN instance is bound to the interface, the system accesses the target host on the public network.
  - c. If the [2.7.76 set net-manager vpn-instance](#) command is run to configure a network management VPN instance, the system accesses the target host in this VPN instance.
  - d. If none of the preceding conditions is met, the system accesses the target host on the public network.

### Configuration Impact

No matter whether a trap sent from the SNMP agent reaches the NMS, the SNMP agent deletes the trap to reduce the resource consumption.

### Precautions

Ensure that the security level of a trap host is not higher than that of the user specified by **securityname** and not lower than that of the user group. Otherwise, the trap host cannot send trap messages properly. The user security level can be (in descending order):

- Level 1: privacy (authentication and encryption)
- Level 2: authentication (without encryption)
- Level 3: noauthentication (no authentication or encryption)

If the SNMP trap function has been enabled, to ensure that SNMPv3-running devices normally send trap messages, **notify-view** *notify-view* must be configured in the [16.1.27 snmp-agent group](#) command for the user group to which **securityname** belongs to allow the devices to have the right to send trap messages.

For SNMPv1 and SNMPv2c, when a user with a level lower than the level configured using this command queries the securityname configured using the [2.1.10 display this](#) command, the securityname is displayed as asterisks (\*\*\*\*\*).

## Example

# Allow the SNMP agent to send SNMP traps to the target host with the IP address of 10.1.1.1.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent trap enable
[HUAWEI] snmp-agent target-host trap address udp-domain 10.1.1.1 params securityname comaccess
```

# Allow the SNMP agent to send SNMP traps to the Huawei NMS with the IP address of 10.1.1.1.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent trap enable
[HUAWEI] snmp-agent target-host trap address udp-domain 10.1.1.1 params securityname comaccess
private-netmanager
```

## Related Topics

[16.1.15 display snmp-agent target-host](#)

[16.1.50 snmp-agent trap enable](#)

# 16.1.48 snmp-agent target-host trap ipv6

## Function

The **snmp-agent target-host trap ipv6** command configures a target host to receive SNMP trap messages.

The **undo snmp-agent target-host ipv6** command deletes the configuration of a target host to receive SNMP trap messages.

By default, the target host that receives SNMP trap messages is not set.

## Format

```
snmp-agent target-host trap ipv6 address udp-domain ipv6-address [ udp-port port-number | vpn-instance vpn-instance-name ] * params securityname security-name [ [ v1 | v2c | v3 [ authentication | privacy ] ] | private-netmanager | notify-filter-profile profile-name | ext-vb ] *
```

```
snmp-agent target-host trap ipv6 address udp-domain ipv6-address [ udp-port port-number | vpn-instance vpn-instance-name ] * params securityname cipher security-name [ [ v1 | v2c ] | private-netmanager | notify-filter-profile profile-name | ext-vb ] *
```

```
undo snmp-agent target-host ipv6 ipv6-address securityname { security-name | cipher security-name } [ vpn-instance vpn-instance-name ]
```

```
undo snmp-agent target-host trap ipv6 address udp-domain ipv6-address [ udp-port port-number | vpn-instance vpn-instance-name ] * params securityname { security-name | cipher security-name }
```

 NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

## Parameters

Parameter	Description	Value
<b>ipv6 address</b>	Sets the IPv6 address of the target host used to receive SNMP trap messages.	-
<b>udp-domain</b>	Indicates that trap messages are sent to the target host through the User Datagram Protocol (UDP).	-
<i>ipv6-address</i>	Specifies the IPv6 address of the target host.	-
<b>udp-port</b> <i>port-number</i>	Specifies the port number used to receive trap messages.	The value is an integer that ranges from 0 to 65535. The default value is 162.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies a VPN instance name. If the <b>vpn-instance</b> <i>vpn-instance-name</i> parameter is not specified, the system accesses the target host on the public network.  The device cannot send traps to a target host on the VPN interface specified by the <a href="#">2.7.76 set net-manager vpn-instance</a> command.	The <b>vpn-instance</b> parameter is optional. If <b>vpn-instance</b> is configured, the VPN instance specified by <b>vpn-instance</b> <i>vpn-instance-name</i> , IP address, and security name specified by <b>securityname</b> <i>security-string</i> form a 3-tuple to identify a host on a VPN.

Parameter	Description	Value
<b>params</b> <b>securityname</b> <i>security-name</i>	<p>Specifies the SNMP security name that is displayed as the user name on the NMS.</p> <p>For SNMPv3, <b>securityname</b> must be configured as the user name. <b>securityname</b> configured on the host needs to be the same as that configured on the NMS, or the NMS cannot receive the trap messages sent from the host.</p> <p>For SNMPv1 and SNMPv2c, the NMS can receive trap messages from all hosts without having <b>securityname</b> configured. <b>securityname</b> is used to distinguish multiple hosts that generate trap messages.</p>	<p>The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.</p>
<b>cipher</b> <i>security-name</i>	<p>Indicates the unencrypted or encrypted string of security name.</p>	<p>The value is a string of 1 to 32, 32, 48, 56, or 68 case-sensitive characters without spaces. When double quotation marks are used around the string, spaces are allowed in the string.</p> <ul style="list-style-type: none"> <li>• When the community name is a string of 1 to 32 characters, the string is processed as plain text by default and will be encrypted.</li> <li>• When the community name is a string of 32, 48, 56, or 68 characters, the string is processed as cipher text by default, and the system will determine whether the string can be parsed.</li> </ul>

Parameter	Description	Value
<b>v1   v2c   v3</b>	Specifies the SNMP version. <ul style="list-style-type: none"> <li>• <b>v1</b>: indicates SNMPv1.</li> <li>• <b>v2c</b>: indicates SNMPv2c.</li> <li>• <b>v3</b>: indicates SNMPv3.</li> </ul> If no SNMP version is specified, SNMPv1 is used by default.	-
<b>authentication   privacy</b>	Specifies the security mode for SNMP trap messages. <ul style="list-style-type: none"> <li>• <b>authentication</b>: indicates that the SNMP trap messages are authenticated but not encrypted.</li> <li>• <b>privacy</b>: indicates that SNMP trap messages are authenticated and encrypted.</li> </ul>	-
<b>private-netmanager</b>	Indicates that the target host is a Huawei NMS. Specify this parameter when a Huawei NMS is used. This parameter enables trap messages sent to the NMS to contain more information, including types, sequence numbers, and transmission time of trap messages.	-
<b>notify-filter-profile</b> <i>profile-name</i>	Specifies the name of a trap filter profile.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.

Parameter	Description	Value
<b>ext-vb</b>	<p>Indicates that trap messages sent to a target host carry extended bound variables.</p> <p>If alarm objects defined in public MIBs are extended on a Huawei data communication device, you can use <b>ext-vb</b> to determine whether the trap messages sent to the NMS carry extended bound variables.</p> <ul style="list-style-type: none"> <li>If <b>ext-vb</b> is not specified, trap messages sent from the device do not carry extended bound variables.</li> </ul> <p>When a third-party NMS is used, you are advised not to specify the <b>ext-vb</b> parameter so that the third-party NMS can receive trap messages from Huawei data communication devices.</p> <p>By default, trap messages sent from a Huawei data communication device do not carry extended bound variables.</p> <ul style="list-style-type: none"> <li>If <b>ext-vb</b> is specified, trap messages sent from the device carry extended bound variables.</li> </ul> <p>This parameter is recommended when a Huawei NMS is used so that more information can be transmitted in trap messages.</p>	-

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

This command is used to configure an IPv6 NMS host so that traps can be sent to the host using the IPv6 protocol.

### Precautions

Ensure that the security level of a trap host is not higher than that of the user specified by **securityname** and not lower than that of the user group. Otherwise,

the trap host cannot send trap messages properly. The user security level can be (in descending order):

- Level 1: privacy (authentication and encryption)
- Level 2: authentication (without encryption)
- Level 3: noauthentication (no authentication or encryption)

For SNMPv1 and SNMPv2c, when a user with a level lower than the level configured using this command queries the securityname configured using the [2.1.10 display this](#) command, the securityname is displayed as asterisks (\*\*\*\*\*).

## Example

# Configure an IPv6 NMS host that uses SNMP v3. Set the security name to Huawei and configure traps to be authenticated and encrypted.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent trap enable
Warning: All switches of SNMP trap/notification will be open. Continue? [Y/N]:y
[HUAWEI] snmp-agent target-host trap ipv6 address udp-domain FC00::1 params securityname
Huawei v3 privacy
```

## 16.1.49 snmp-agent trap disable

### Function

The **snmp-agent trap disable** command disables the trap function for all features.

The **undo snmp-agent trap disable** command restores the trap function for all features to the default status.

By default, the [display snmp-agent trap all](#) command can be used to view the status of the trap function for all features.

### Format

**snmp-agent trap disable**

**undo snmp-agent trap disable**

### Parameters

None

### Views

System view

### Default Level

2: Configuration level

## Usage Guidelines

To enable the trap function for all modules, run the **snmp-agent trap enable** command. To enable the trap function for a specified module, run the **snmp-agent trap enable feature-name** command.

- To disable the trap function for all modules, run the **snmp-agent trap disable** command.
- To restore the trap function for all features to the default status, run the **undo snmp-agent trap disable** or **undo snmp-agent trap enable** command.

### NOTE

To disable the trap function for a specified module, run the **undo snmp-agent trap enable feature-name** command.

## Example

```
# Disable the trap function for all features.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap disable
```

## Related Topics

[16.1.16 display snmp-agent trap all](#)

# 16.1.50 snmp-agent trap enable

## Function

The **snmp-agent trap enable** command enables the switch to send traps.

The **undo snmp-agent trap enable** command restores the default setting.

The default configuration of the **snmp-agent trap enable** command can be checked by the **display snmp-agent trap all** command.

## Format

**snmp-agent trap enable**

**undo snmp-agent trap enable**

## Parameters

None.

## Views

System view

## Default Level

2: Configuration level



## Usage Guidelines

- To enable the trap function for all modules, run the **snmp-agent trap enable** command.
- To disable the trap function for all modules, run the **snmp-agent trap disable** command.
- To enable the trap function for a specified module, run the **snmp-agent trap enable feature-name** *feature-name* command.
- To disable the trap function for a specified module, run the **undo snmp-agent trap enable feature-name** *feature-name* command.
- To enable a specified trap for a specified module, run the **snmp-agent trap enable feature-name** *feature-name* **trap-name** *trap-name* command.
- To disable a specified trap for a specified module, run the **undo snmp-agent trap enable feature-name** *feature-name* **trap-name** *trap-name* command.
- To restore the default trap status of all modules, run the **undo snmp-agent trap disable** or **undo snmp-agent trap enable** command.

The **snmp-agent trap enable** command must be used together with the **snmp-agent target-host inform** command or **snmp-agent target-host trap** command.

To enable a device to send traps, you need to run at least the **snmp-agent target-host inform** command or **snmp-agent target-host trap** command on the device to specify the destination address of the traps.

## Example

```
# Enable the switch to send traps.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable  
Warning: All switches of SNMP trap/notification will be open. Continue? [Y/N]:y
```

## Related Topics

[16.1.16 display snmp-agent trap all](#)

# 16.1.51 snmp-agent trap enable feature-name

## Function

The **snmp-agent trap enable feature-name** command enables a specified trap for a specified feature.

The **undo snmp-agent trap enable feature-name** command disables a specified trap for a specified feature.

The default configuration of the **snmp-agent trap enable feature-name** command can be checked using the **display snmp-agent trap all** command.

## Format

```
snmp-agent trap enable feature-name feature-name [ trap-name trap-name ]  
undo snmp-agent trap enable feature-name feature-name [ trap-name trap-name ]
```

## Parameters

Parameter	Description	Value
<i>feature-name</i>	Specifies the name of the feature that generates traps.	-
<b>trap-name</b> <i>trap-name</i>	Specifies the name of a trap.	-

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

If **trap-name** *trap-name* is not specified, the switch enables all traps about a specified feature after the **snmp-agent trap enable feature-name** *feature-name* command is used.

You can run the **display snmp-agent trap feature-name all** command to check the configuration result.

## Example

```
# Enable the switch to send the fallingalarm trap about RMON to the NMS.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name rmon trap-name fallingalarm
```

## Related Topics

[16.1.16 display snmp-agent trap all](#)

[16.1.17 display snmp-agent trap feature-name all](#)

# 16.1.52 snmp-agent trap enable feature-name snmp

## Function

The **snmp-agent trap enable feature-name snmp** command enables an SNMP trap.

The **undo snmp-agent trap enable feature-name snmp** command disables an SNMP trap.

By default, the coldStart and warmStart traps are enabled and the authenticationFailure trap is disabled.

## Format

```
snmp-agent trap enable feature-name snmp [ trap-name trap-name ]
```

**undo snmp-agent trap enable feature-name snmp [ trap-name *trap-name* ]**

## Parameters

Parameter	Description	Value
<b>trap-name</b> <i>trap-name</i>	Specifies the name of a trap.	The traps are as follows: <ul style="list-style-type: none"> <li>• authenticationFailure</li> <li>• coldstart</li> <li>• hwsnmplockthreshold</li> <li>• hwsnmplockthresholdresume</li> <li>• warmstart</li> </ul>

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

The **snmp-agent trap enable feature-name snmp** command is used to enable an SNMP trap. After that, the trap generated during the device running will be sent to the NMS. At present, the following SNMP traps are supported:

- coldStart: This trap is generated when the device is powered off and restarted.
- warmStart: This trap is generated when the status of SNMP agent is changed from disable to enable.
- authenticationFailure: This trap is generated when a user uses an incorrect community name and is unable to log in to the device.
- hwSNMPLockThreshold: This trap is generated when the number of users who were locked due to an authentication failure reached the upper threshold.
- hwSNMPLockThresholdResume: This trap is generated when the number of users who were locked due to an authentication failure fell below the lower threshold.

You can run the **display snmp-agent trap feature-name snmp all** command to check the configuration result.

## Example

```
# Enable the SNMP authenticationFailure trap.
```

```
<HUAWEI> system-view
[HUAWEI] snmp-agent trap enable feature-name snmp trap-name authenticationFailure
```

## Related Topics

[16.1.18 display snmp-agent trap feature-name snmp all](#)

## 16.1.53 snmp-agent trap life

### Function

The **snmp-agent trap life** command sets the lifetime of trap messages. When the lifetime expires, the trap messages are discarded.

The **undo snmp-agent trap life** command cancels the current settings.

By default, the lifetime of trap messages is 300 seconds.

### Format

**snmp-agent trap life** *seconds*

**undo snmp-agent trap life**

### Parameters

Parameter	Description	Value
<i>seconds</i>	Specifies the lifetime of trap messages.	The value is an integer that ranges from 1 to 2592000, in seconds. The default value is 300.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

Any trap messages are discarded after the duration expires. The trap messages are no longer reserved or sent.

### Example

```
# Set the lifetime of trap messages to 60 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap life 60
```

### Related Topics

- [16.1.50 snmp-agent trap enable](#)
- [16.1.47 snmp-agent target-host trap](#)
- [16.1.46 snmp-agent target-host inform](#)

## 16.1.54 snmp-agent trap queue-size

### Function

The **snmp-agent trap queue-size** command sets the queue length of the trap messages sent to a target host.

The **undo snmp-agent trap queue-size** command cancels the current settings.

The default value is 1000.

### Format

**snmp-agent trap queue-size** *size*

**undo snmp-agent trap queue-size**

### Parameters

Parameter	Description	Value
<i>size</i>	Specifies the queue length of trap messages.	The value is an integer that ranges from 1 to 1000. The default value is 1000.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

When a large number of trap messages need to be sent in a certain period of time, packets will be lost if the queue length of trap messages is insufficient. The queue length can be adjusted to reduce the packet loss ratio.

When the lifetime of trap messages is long, the queue length of trap messages needs to be lengthened. If the queue length is not lengthened, packet loss will occur.

### Example

```
# Set the queue length of the trap messages sent to the target host to 200.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap queue-size 200
```

### Related Topics

[16.1.50 snmp-agent trap enable](#)

[16.1.47 snmp-agent target-host trap](#)

[16.1.46 snmp-agent target-host inform](#)

[16.1.53 snmp-agent trap life](#)

## 16.1.55 snmp-agent trap start-trap resend disable

### Function

The **snmp-agent trap start-trap resend disable** command disables the function of resending device cold-start or warm-start traps.

The **undo snmp-agent trap start-trap resend disable** command restores the default status of the function of resending device cold-start or warm-start traps.

By default, the function of resending device cold-start or warm-start traps is enabled.

### Format

**snmp-agent trap start-trap resend disable**

**undo snmp-agent trap start-trap resend disable**

### Parameters

None

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

SNMP uses the resending mechanism for device cold-start or warm-start traps. This mechanism works in the following way:

- The system resends a cold-start or warm-start trap for three consecutive times to ensure that the trap can be sent to the destination.
- The first trap that the device sends must be a cold-start or warm-start trap. If another alarm is generated before the cold-start or warm-start trap, the system buffers that alarm and sends it only after the cold-start or warm-start trap is sent. The system also resends the buffered alarm for three consecutive times.

If the function of resending device cold-start or warm-start traps is not required any more, run the **snmp-agent trap start-trap resend disable** command to disable it.

### Example

```
# Disable the function of resending device cold-start or warm-start traps.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap start-trap resend disable
```

## 16.1.56 snmp-agent trap source

### Function

The **snmp-agent trap source** command sets the source interface from which traps are sent.

The **undo snmp-agent trap source** command removes the set source interface configuration.

By default, source interface is not set.

### Format

**snmp-agent trap source** *interface-type interface-number*

**undo snmp-agent trap source**

### Parameters

Parameter	Description	Value
<i>interface-type interface-number</i>	Specifies the type and number of the source interface that sends traps.	-

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

You can run the **snmp-agent trap source** command to specify the type and number of the interface on the device from which traps are sent. The system specifies the IP address of this interface as the source IP address of traps. In this way, the trap source can be identified on the NMS.

#### Precautions

The source interface that sends traps must have an IP address; otherwise, the commands will fail to take effect. To ensure device security, it is recommended that you set the source IP address to the local loopback address.

The source interface in traps on the device must be the same as the source interface specified on the NM station. Otherwise, the NM station cannot receive traps.

## Example

# Specify the IP address of VLANIF100 as the source address of traps.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap source vlanif 100
```

## Related Topics

- [16.1.50 snmp-agent trap enable](#)
- [16.1.47 snmp-agent target-host trap](#)
- [16.1.46 snmp-agent target-host inform](#)

## 16.1.57 snmp-agent trap source-port

### Function

The **snmp-agent trap source-port** command configures the number of the source port that sends trap messages.

The **undo snmp-agent trap source-port** command restores the default number of the source port that sends trap messages.

By default, the source port that sends trap messages is a random port.

### Format

**snmp-agent trap source-port** *port-num*

**undo snmp-agent trap source-port**

### Parameters

Parameter	Description	Value
<i>port-num</i>	Specifies the number of the source port that sends trap messages.	The value is an integer ranging from 1025 to 65535.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

To improve security of network packets, run the **snmp-agent trap source-port** command to configure the source port that sends trap messages. Therefore, the user firewall filters packets based on the port number.

#### Precautions



By default, a random port is used to send trap messages, and no configuration file is generated. After you configure a specific source port, the corresponding configuration file is generated. If you delete the specified source port, no configuration file is generated.

If a device sends packets to the NMS in Inform mode and the **snmp-agent trap source-port** command is run to change the source port number, SNMP uses the new source port instead of the original port to receive response packets from the NMS. As a result, packets are retransmitted.

## Example

```
# Set the number of the source port that sends SNMP agent trap messages to 1057.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap source-port 1057
```

## 16.1.58 snmp-agent trap type

### Function

The **snmp-agent trap type** command configures the device to send ENTITYTRAP traps or Basetrap traps.

The **undo snmp-agent trap type** command restores the default configuration.

By default, the device sends Basetrap traps.

### Format

```
snmp-agent trap type { base-trap | entity-trap }
```

```
undo snmp-agent trap type
```

### Parameters

Parameter	Description	Settings
<b>base-trap</b>	Configures the device to send Basetrap traps.	-
<b>entity-trap</b>	Configures the device to send ENTITYTRAP traps.	-

### Views

System view

### Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

There are two types of traps for the hardware of the switch: BASETRAP and ENTITYTRAP.

- The BASETRAP traps are sent when faults occur, so they are classified based on fault types. For example, the same BASETRAP trap is sent when a Power Module or a fan is removed.
- The ENTITYTRAP traps are classified based on hardware types. For example, different ENTITYTRAP traps are sent when a Power Module is removed and when a fan is removed.

The functions of the two types of traps are similar. Select one type of traps based on your requirements.

### Precautions

The following conditions must be met; otherwise, the device does not send BASETRAP traps to the NMS:

- The trap type is set to base-trap using the **snmp-agent trap type** command.
- The BASETRAP trap function is enabled.

The following conditions must be met; otherwise, the device does not send ENTITYTRAP traps to the NMS:

- The trap type is set to entity-trap using the **snmp-agent trap type** command.
- The ENTITYTRAP trap function is enabled.

## Example

```
# Configure the device to send BASETRAP traps.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap type base-trap
```

## Related Topics

[16.1.17 display snmp-agent trap feature-name all](#)

[16.1.16 display snmp-agent trap all](#)

## 16.1.59 snmp-agent udp-port

### Function

The **snmp-agent udp-port** command sets the listening port of the SNMP agent.

The **undo snmp-agent udp-port** command restores the default listening port of the SNMP agent.

By default, the listening port of the SNMP agent is 161.

### Format

**snmp-agent udp-port** *port-num*

## undo snmp-agent udp-port

### Parameters

Parameter	Description	Value
<i>port-num</i>	Specifies the listening port of the SNMP agent.	The value is 161 or an integer that ranges from 1025 to 65535.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

The SNMP agent is a proxy process running on a network device. By default, the SNMP agent listens on port 161 to respond to instructions sent from the NMS. In this manner, the NMS can manage the network device. Fixing the listening port may threaten network security. For example, if all attack packets are sent to this listening port, the network is congested.

To improve device security, run the **snmp-agent udp-port** command to change the listening port of the SNMP agent.

#### Configuration Impact

After you run this command, the SNMP agent listens on the new port number. The original SNMP connection with the NMS is torn down, and the NMS must use the new port number to connect to the device.

#### Precautions

The listening port configured on the NMS must be the same as that specified by the **snmp-agent udp-port** command. Otherwise, the NMS cannot connect to the device.

### Example

```
# Set the listening port of the SNMP agent to 1057.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent udp-port 1057
```

## 16.1.60 snmp-agent usm-user

### Function

The **snmp-agent usm-user** command adds a user to an SNMP user group.

The **undo snmp-agent usm-user** command deletes a user from an SNMP user group.

By default, the SNMP user group has no users added.

## Format

**snmp-agent** [ **remote-engineid** *engineid* ] **usm-user v3** *user-name* [ **group** *group-name* | **acl** { *acl-number* | *acl-name* } ] \*

**snmp-agent** [ **remote-engineid** *engineid* ] **usm-user v3** *user-name*  
**authentication-mode** { **md5** | **sha** } [ **localized-configuration** **cipher** *password* | **cipher** *password* ]

**snmp-agent** [ **remote-engineid** *engineid* ] **usm-user v3** *user-name* **privacy-mode** { **des56** | **aes128** | **aes192** | **aes256** | **3des** } [ **localized-configuration** **cipher** *password* | **cipher** *password* ]

**undo snmp-agent** [ **remote-engineid** *engineid* ] **usm-user v3** *user-name* [ **group** | **acl** | **authentication-mode** | **privacy-mode** ]

## Parameters

Parameter	Description	Value
<b>remote-engineid</b> <i>engineid</i>	Specifies the ID of the engine associated with a user.  <b>NOTE</b> <b>remote-engineid</b> <i>engineid</i> must be set to the engine ID of the destination host that receives alarms. The engine IDs of the source and destination hosts must be different.	The value is string of 10 to 64 hexadecimal digits. It cannot be all 0s or all Fs.
<b>v3</b>	Indicates that the security mode in v3 is adopted.	-
<i>user-name</i>	Specifies the name of a user.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.

Parameter	Description	Value
<b>group</b> <i>group-name</i>	Specifies the name of the group to which a user belongs.	The value is a string of 1 to 32 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string.
<b>authentication-mode</b>	Sets the authentication mode. <b>NOTE</b> Authentication is a process in which the SNMP agent (or the NMS) confirms that the message is received from an authorized NMS (or SNMP agent) and the message is not changed during transmission. RFC 2104 defines Keyed-Hashing for Message Authentication Code (HMAC), an effective tool that uses the security hash function and key to generate the message authentication code. This tool is widely used in the Internet. HMAC used in SNMP includes HMAC-MD5-96 and HMAC-SHA-96. The hash function of HMAC-MD5-96 is MD5 that uses 128-bit authKey to generate the key. The hash function of HMAC-SHA-96 is SHA-1 that uses 160-bit authKey to generate the key.	-
<b>md5   sha</b>	Indicates the authentication protocol. <ul style="list-style-type: none"> <li>● <b>md5</b>: Specifies HMAC-MD5-96 as the authentication protocol.</li> <li>● <b>sha</b>: Specifies HMAC-SHA-96 as the authentication protocol.</li> </ul> <b>NOTE</b> The calculation speed of the HMAC-MD5-96 algorithm is faster than that of the HMAC-SHA-96 algorithm; the HMAC-SHA-96 algorithm is more secure than the HMAC-MD5-96 algorithm. To ensure high security, please use the HMAC-SHA-96 algorithm.	-

Parameter	Description	Value
<b>privacy-mode</b>	<p>Specifies the authentication with encryption.</p> <p>The system adopts the cipher block chaining (CBC) code of the data encryption standard (DES) and uses 128-bit privKey to generate the key. The NMS uses the key to calculate the CBC code and then adds the CBC code to the message while the SNMP agent fetches the authentication code through the same key and then obtains the actual information. Like the identification authentication, the encryption requires the NMS and the SNMP agent to share the same key to encrypt and decrypt the message.</p>	-
<b>des56   aes128   aes192   aes256   3des</b>	<p>Indicates 3DES, AES-128, AES-192, AES-256, or DES-56 as the encryption protocol.</p> <p><b>NOTE</b></p> <p>To ensure high security, the DES56 or 3DES algorithm is not recommended. If the DES56 or 3DES algorithm is used, do not use passwords composed of repeated character strings. For example, in <i>str*n</i>, <i>str</i> is a repeated character string and <i>n</i> indicates the number of times this string repeats. Otherwise, the passwords containing any times of <i>str</i> can pass authentication. For example, if the password is <b>Huawei@123Huawei@123</b>, passwords <b>Huawei@123</b>, <b>Huawei@123Huawei@123</b>, and <b>Huawei@123Huawei@123Huawei@123</b> can all pass authentication.</p>	-
<b>localized-configuration</b>	<p>Specifies the localized password configuration mode.</p> <p><b>NOTE</b></p> <p>After authentication and encryption passwords are configured through MIB, this keyword is displayed in the commands recorded in configuration files.</p> <p>After authentication and encryption passwords are configured through command line, you are not advised to use this keyword. If this keyword is used, the cipher text passwords configured later use the local format.</p> <p>As a password with the <b>localized-configuration</b> keyword is related to the engine ID, copying configurations with this keyword from one device to another causes the password to be invalid.</p>	-

Parameter	Description	Value
<b>cipher</b> <i>password</i>	Specifies the password.	The value is a case-insensitive string without spaces. It must be in cipher text format with 32 to 108 characters. When double quotation marks are used around the string, spaces are allowed in the string.
<b>acl</b> { <i>acl-number</i>   <i>acl-name</i> }	Specifies the ACL: <ul style="list-style-type: none"> <li>• <i>acl-number</i>: indicates the ACL ID</li> <li>• <i>acl-name</i>: indicates the ACL name</li> </ul> <p>The ACL can be a basic ACL or an advanced ACL, and the ACL configured takes effect on both IPv4 and IPv6 networks.</p>	<ul style="list-style-type: none"> <li>• <i>acl-number</i>: The value is an integer that ranges from 2000 to 3999.</li> <li>• <i>acl-name</i>: The value is a string of 1 to 64 case-sensitive characters without spaces. The value must start with a letter (case sensitive).</li> </ul>

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

SNMPv1 and SNMPv2c have serious defects in terms of security. The security authentication mechanism used by SNMPv1 and SNMPv2c is based on the community name. In this mechanism, the community name is transmitted in plain text. You are not advised to use SNMPv1 and SNMPv2c on untrusted networks.

By adopting the user-based security model, SNMPv3 eradicates the security defects in SNMPv1 and SNMPv2c and provides two services, authentication and encryption. The user-based security model defines three security authentication levels: noAuthNoPriv, AuthNoPriv, and AuthPriv.

 **NOTE**

The security authentication level noAuthPriv does not exist. This is because the generation of a key is based on the authentication information and product information.

Different from SNMPv1 and SNMPv2c, SNMPv3 can implement access control, identity authentication, and data encryption through the local processing model and user security model. SNMPv3 can provide higher security and confidentiality than SNMPv1 and SNMPv2c. The following table lists the difference between SNMPv1, SNMPv2c, and SNMPv3:

**Table 16-19** Comparison in the security of SNMP of different versions

Protocol version	User Checksum	Encryption	Authentication
v1	Adopts the community name.	None	None
v2c	Adopts the community name.	None	None
v3	Adopts user name-based encryption/decryption.	Yes	Yes

The **snmp-agent group** command can be used to configure the authentication, encryption, and access rights for an SNMP group. The **snmp-agent group** command can be used to configure the rights for users in a specified SNMP group and bind the SNMP group to a MIB view. The MIB view is created through the **snmp-agent mib-view** command. For details, see the usage guideline of this command. After an SNMP user group is configured, the MIB-view-based access control is configured for the SNMP user group. Users cannot access objects in the MIB view through the SNMP user group. The purpose of adding SNMP users to an SNMP user group is to ensure that SNMP users in an SNMP user group have the same security level and access control list. When you run the **snmp-agent usm-user** command to configure a user in an SNMP user group, you configure the MIB-view-based access rights for the user. If an SNMP user group is configured with the AuthPriv access rights, you can configure the authentication mode and encryption mode when configuring SNMP users. Note that the authentication keys and encryption passwords configured on the NMS and the SNMP agent should be the same; otherwise, authentication fails.

To ensure that the NMS correctly receives the alarm in Inform mode sent by the switch, run the **snmp-agent remote-engineid engineid usm-user v3 user-name** command to specify the NMS engine ID on the host. After the command is run, the host encapsulates the NMS engine ID in the Authoritative Engine ID field of the SNMPv3 alarm packet before sending the alarm in Inform mode. After receiving the alarm, the NMS compares the engine ID carried in the received



packet with its own engine ID. If the two IDs match, the NMS sends a response to the alarm host. If the two IDs do not match, the NMS discards the packet.

When the NMS and device are in an insecure network environment, for example, a network prone to attacks, it is recommended that you configure different authentication password and encryption password to improve security.

### Configuration Impact

If an SNMP agent is configured with a remote user, the engine ID is required during the authentication. If the engine ID changes after the remote user is configured, the remote user becomes invalid.

### Precautions

The user security level must be higher than or equal to the security level of the SNMP user group to which the user is added. The security level of an SNMP user group can be (in descending order):

- Level 1: privacy (authentication and encryption)
- Level 2: authentication (without encryption)
- Level 3: none (neither authentication nor encryption)

If the user security level is set to neither authentication nor encryption, the user only has the read-only permission within MIB-2 (OID: 1.3.6.1.2.1).

To add an SNMP user to an SNMP group, ensure that the SNMP user group is valid.

If you run the **snmp-agent usm-user** command multiple times, only the latest configuration takes effect.

Keep your user name and plain-text password well when creating the user. The plain-text password is required when the NMS accesses the device.

The passwords have the following characteristics:

- The password is a string of 8 to 64 case-sensitive characters.
- The password must contain at least two of the following characters: upper-case character, lower-case character, digit, and special character.  
Special characters do not include the question mark (?) and space.
- The password should not contain repeated character strings such as abc123abc123abc123 and \*\*123abc\*\*123abc.
- The password entered in interactive mode is not displayed on the screen.

Users of the same name can only belong to one user group. If you add a user to a user group, delete a user from a user group, or change a user to another group, the operation takes effect for other users with the same name.

To ensure high security, do not use the MD5 algorithm for SNMPv3 authentication or use the DES56 or 3DES168 algorithm for SNMPv3 encryption.

When a user with a level lower than the level configured using this command queries the password configured using the **display this** command, the password is displayed as asterisks (\*\*\*\*\*).

## Example

# Configure an SNMPv3 user with user name **u1**, group name **g1**, authentication mode **sha**, authentication password **8937561bc**, encryption mode **aes128**, and encryption password **68283asd**.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent usm-user v3 u1 group g1
[HUAWEI] snmp-agent usm-user v3 u1 authentication-mode sha
Please configure the authentication password (8-64)
Enter Password:
Confirm Password:
[HUAWEI] snmp-agent usm-user v3 u1 privacy-mode aes128
Please configure the privacy password (8-64)
Enter Password:
Confirm Password:
[HUAWEI]
```

## Related Topics

[16.1.19 display snmp-agent usm-user](#)

[16.1.27 snmp-agent group](#)

## 16.1.61 snmp-agent usm-user password complexity-check disable

### Function

The **snmp-agent usm-user password complexity-check disable** command disables the complexity check for SNMPv3 user passwords.

The **undo snmp-agent usm-user password complexity-check disable** command enables the complexity check for SNMPv3 user passwords.

By default, the complexity check is enabled for SNMPv3 user passwords.

### Format

**snmp-agent usm-user password complexity-check disable**

**undo snmp-agent usm-user password complexity-check disable**

### Parameters

None

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

After the complexity check is enabled for SNMPv3 user passwords, a newly-configured SNMPv3 user password needs to meet the requirements for the complexity check. After complexity check is disabled for SNMPv3 user passwords, the complexity of the passwords is not checked.

The requirements for the complexity of SNMPv3 user passwords are as follows:

- The password cannot be the same as the user name and cannot be the same as the user name in reverse order (This is still checked even after the complexity check for SNMPv3 user passwords is disabled).
- The minimum length of a password is configured by using the **set password min-length** command. By default, a password contains 8 characters at least.
- A password includes at least two kinds of characters: uppercase letters, lowercase letters, numbers, and special characters (excluding question marks (?) and spaces).

#### Precautions

- After complexity check is disabled for SNMPv3 user passwords, if a configured SNMPv3 user password is simple and does not meet the complexity requirements, the password may be easily attacked and cracked down by unauthorized users, affecting device security. Therefore, enabling the complexity check for SNMPv3 user passwords is recommended.
- In the configuration restoration stage, complexity check is not performed for SNMPv3 user passwords.
- Enabling the complexity check for SNMPv3 user passwords does not affect the SNMPv3 user passwords that have been configured.

## Example

```
# Disable the complexity check for SNMPv3 user passwords.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent usm-user password complexity-check disable
```

## 16.2 RMON and RMON2 Configuration Commands

[16.2.1 Command Support](#)

[16.2.2 display rmon alarm](#)

[16.2.3 display rmon event](#)

[16.2.4 display rmon eventlog](#)

[16.2.5 display rmon history](#)

[16.2.6 display rmon prialarm](#)

[16.2.7 display rmon statistics](#)

[16.2.8 display rmon2 hlhostcontroltable](#)

[16.2.9 display rmon2 nlhosttable](#)

[16.2.10 display rmon2 protocoldirtable](#)

[16.2.11 display snmp-agent trap feature-name rmon all](#)

- [16.2.12 rmon alarm](#)
- [16.2.13 rmon event](#)
- [16.2.14 rmon history](#)
- [16.2.15 rmon prialarm](#)
- [16.2.16 rmon statistics](#)
- [16.2.17 rmon2 hlhostcontroltable](#)
- [16.2.18 rmon2 protocoldirtable](#)
- [16.2.19 rmon-statistics enable](#)
- [16.2.20 snmp-agent trap enable feature-name rmon](#)

## 16.2.1 Command Support

Only S5720EI, S5720HI, S6720EI, and S6720S-EI support RMON2.

## 16.2.2 display rmon alarm

### Function

The **display rmon alarm** command displays information about RMON alarm function.

### Format

**display rmon alarm** [ *entry-number* ]

### Parameters

Parameter	Description	Value
<i>entry-number</i>	Displays information about the RMON alarm entry with the specified index. If no index is specified, information about all alarms is displayed.	The value is an integer that ranges from 1 to 65535.

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

After configuring the RMON alarm thresholds using the **rmon alarm** command, you can run this command to view the configured alarm variables, sampling interval, thresholds, alarm triggering condition, and last sampled value.

## Example

# Display the RMON alarm configurations.

```
<HUAWEI> display rmon alarm
Alarm table 1 owned by creator is valid.
Samples delta value   : 1.3.6.1.2.1.16.1.1.1.4.1<etherStatsOctets.1>
Sampling interval    : 5(sec)
Rising threshold     : 1000 (linked with event 1)
Falling threshold    : 100(linked with event 1)
When startup enables : risingOrFallingAlarm
Latest value         : 0
```

**Table 16-20** Description of the display rmon alarm command output

Item	Description
Alarm table <i>entry-number</i> owned by <i>owner</i> is <i>status</i> .	<p>The current status of the alarm entry <i>entry-number</i> created by <i>owner</i> is <i>status</i>.</p> <ul style="list-style-type: none"> <li><i>entry-number</i>: alarm entry index, corresponding to the alarmIndex object in alarmTable.</li> <li><i>owner</i>: creator of the entry, corresponding to the alarmOwner object in alarmTable.</li> <li><i>status</i>: row status of the alarm entry with the specified index, corresponding to the alarmStatus in alarmTable: undercreation(invalid), valid(valid), invalid(no valid trap).</li> </ul> <p>You can run the <b>rmon alarm</b> command to configure <i>entry-number</i> and <i>owner</i>.</p>
Samples delta value	<p>Alarm variable, namely, monitored MIB object, corresponding to the alarmVariable object in alarmTable.</p> <p>You can run the <b>rmon alarm</b> command to configure this parameter.</p>
Sampling interval	<p>Sampling interval, in seconds, corresponding to the alarmInterval object in alarmTable.</p> <p>You can run the <b>rmon alarm</b> command to configure this parameter.</p>
Rising threshold	<p>Rising threshold of the alarm table, corresponding to the alarmRisingThreshold object in alarmTable. When the sampled value reaches or exceeds the rising threshold, an alarm is generated.</p> <p>You can run the <b>rmon alarm</b> command to configure this parameter.</p>
Falling threshold	<p>Falling threshold of the alarm table, corresponding to the alarmFallingThreshold object in alarmTable. When the sampled value reaches or falls below the falling threshold, an alarm is generated.</p> <p>You can run the <b>rmon alarm</b> command to configure this parameter.</p>

Item	Description
When startup enables	<p>Condition that triggers alarms for the first time, corresponding to the alarmStartupAlarm object in alarmTable. When the sampled value exceeds the rising threshold or falls below the falling threshold, an alarm is generated. The values are:</p> <ul style="list-style-type: none"> <li>• risingOrFallingAlarm: generating an alarm when the sampled value exceeds the rising threshold or falls below the falling threshold</li> <li>• risingAlarm: generating an alarm when the sampled value exceeds the rising threshold</li> <li>• fallingAlarm: generating an alarm when the sampled value falls below the falling threshold</li> </ul> <p>You can run the <b>rmon alarm</b> command to configure this parameter.</p>
Latest value	Latest sampled value, corresponding to the alarmValue object in alarmTable.

## Related Topics

[16.2.12 rmon alarm](#)

## 16.2.3 display rmon event

### Function

The **display rmon event** command displays information about RMON events.

### Format

**display rmon event** [ *entry-number* ]

### Parameters

Parameter	Description	Value
<i>entry-number</i>	Displays the configuration of the RMON event with the specified index. If no index is specified, information about all events is displayed.	The value is an integer that ranges from 1 to 65535.

### Views

All views

### Default Level

1: Monitoring level

## Usage Guidelines

After configuring the trap or log function for RMON events, you can run this command to view the configured event description, whether events trigger traps and logs, and latest event.

## Example

# Display the RMON event configurations.

```
<HUAWEI> display rmon event
Event table 1 owned by Huawei is valid.
  Description: null.
  Will cause log when triggered, last triggered at 0days 00h:24m:10s:69th.
```

**Table 16-21** Description of the display rmon event command output

Item	Description
Event table <i>entry-number</i> owned by <i>owner</i> is <i>status</i> .	<p>The current status of the event entry <i>entry-number</i> created by <i>owner</i> is <i>status</i>.</p> <ul style="list-style-type: none"> <li><i>entry-number</i>: event entry index, corresponding to the eventIndex object in eventTable.</li> <li><i>owner</i>: creator of the entry, corresponding to the eventOwner object in eventTable.</li> <li><i>status</i>: row status of the event entry with the specified index, corresponding to the eventStatus in eventTable: undercreation(invalid), valid(valid), invalid(no valid event).</li> </ul> <p>You can run the <b>rmon event</b> command to configure <i>entry-number</i> and <i>owner</i>.</p>
Description	<p>Event description, corresponding to the eventDescription object in eventTable.</p> <p>You can run the <b>rmon event</b> command to configure this parameter.</p>
Will cause log when triggered	<p>Whether events trigger traps or logs, corresponding to the eventType object in eventTable. The actions associated with events are as follows:</p> <ul style="list-style-type: none"> <li>none: no action is taken.</li> <li>log: a log is recorded when an event is triggered.</li> <li>trap: a trap is sent to the NMS when an event is triggered.</li> <li>log-trap: a log is recorded and a trap is sent to the NMS when an event is triggered.</li> </ul> <p>You can run the <b>rmon event</b> command to configure this parameter.</p>
last triggered at	<p>Latest event time, corresponding to the eventLastTimeSent object in eventTable.</p>

## Related Topics

[16.2.13 rmon event](#)

## 16.2.4 display rmon eventlog

### Function

The **display rmon eventlog** command displays details about RMON event logs.

### Format

```
display rmon eventlog [ entry-number ]
```

### Parameters

Parameter	Description	Value
<i>entry-number</i>	Displays the log with the specified index. If no index is specified, information about all event logs is displayed.	The value is an integer that ranges from 1 to 65535.

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

If you use the **rmon event** command to specify that a log is recorded for a certain event, the event record is stored in the LogTable. The command output includes event index, current event status, time the event triggers a log (calculated based on the number of seconds elapsed since system initialization or startup), and event description.

### Example

```
# Display the log of RMON event 1.
```

```
<HUAWEI> display rmon eventlog 1
Event table 1 owned by User is valid.
Generates eventLog 1.1 at 0days 00h:00m:07s.43th.
Description: The 1.3.6.1.2.1.16.1.1.1.4.1 defined in alarm table 1, less than or equal to 100 with alarm
value 0. Alarm sample type is delta.
Generates eventLog 1.2 at 0days 00h:02m:26s.43th.
Description: The 1.3.6.1.2.1.16.1.1.1.4.1 defined in alarm table 1, greater than or equal to 1000 with alarm
value 10443. Alarm sample type is delta.
```



**Table 16-22** Description of the display rmon eventlog command output

Item	Description
Event table <i>entry-number</i> owned by <i>owner</i> is <i>status</i> .	The current status of the event entry <i>entry-number</i> created by <i>owner</i> is <i>status</i> . <ul style="list-style-type: none"> <li>entry-number: event log entry index, corresponding to the logEventIndex object in LogTable.</li> <li>owner: creator of the entry, corresponding to the eventOwner object in eventTable.</li> <li>status: row status of the event entry with the specified index, corresponding to the eventStatus in eventTable: undercreation(invalid), valid(valid), invalid(no valid event log).</li> </ul>
Generates eventLog at	Log creation time (time elapsed since system startup), corresponding to the logTime object in LogTable.
Description	Event description, corresponding to the logDescription object in LogTable.

## Related Topics

[16.2.3 display rmon event](#)

[16.2.13 rmon event](#)

## 16.2.5 display rmon history

### Function

The **display rmon history** command displays RMON history sampling information.

### Format

**display rmon history** [ *interface-type interface-number* ]

### Parameters

Parameter	Description	Value
<i>interface-type interface-number</i>	Displays RMON history sampling information on the specified Ethernet interface. If this parameter is not specified, RMON history sampling information on all interfaces is displayed.	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

After configuring RMON history statistics on an interface using the **rmon history** command, the system samples packets on the interface periodically. The **display rmon history** command can display history sampling information, including the number of sampled packets, history sampling interval, latest sampling information, Ethernet interface usage, number of CRC error packets, and total number of packets.

## Example

# Display RMON history sampling information.

```
<HUAWEI> display rmon history
History control entry 1 owned by Creator is valid
Samples interface : GigabitEthernet0/0/1<ifIndex.402653698>
Sampling interval : 30(sec) with 10 buckets max
Last Sampling time : 0days 00h:09m:43s.00th
Latest sampled values :
octets :645 , packets :7
broadcast packets :7 , multicast packets :0
undersize packets :6 , oversize packets :0
fragments packets :0 , jabbers packets :0
CRC alignment errors :0 , collisions :0
Dropped packet: :0 , utilization :0
```

# Display RMON history sampling information on the specified interface.

```
<HUAWEI> display rmon history gigabitethernet 0/0/1
History control entry 1 owned by Creator is valid
Samples interface : GigabitEthernet0/0/1<ifIndex.402653698>
Sampling interval : 30(sec) with 10 buckets max
Last Sampling time : 0days 00h:09m:43s.00th
Latest sampled values :
octets :645 , packets :7
broadcast packets :7 , multicast packets :0
undersize packets :6 , oversize packets :0
fragments packets :0 , jabbers packets :0
CRC alignment errors :0 , collisions :0
Dropped packet: :0 , utilization :0
History record:
Record No.1 (Sample time: 0days 00h:02m:30s.01th)
octets :0 , packets :0
broadcast packets :0 , multicast packets :0
undersize packets :0 , oversize packets :0
fragments packets :0 , jabbers packets :0
CRC alignment errors :0 , collisions :0
Dropped packet: :0 , utilization :0
```

**Table 16-23** Description of the display rmon history command output

Item	Description
History control entry <i>entry-number</i> owned by <i>owner</i> is <i>status</i> .	<p>The current status of the event entry <i>entry-number</i> created by <i>owner</i> is <i>status</i>.</p> <ul style="list-style-type: none"> <li>• <i>entry-number</i>: history control table entry index, corresponding to the historyControlIndex object in historyControlTable.</li> <li>• <i>owner</i>: creator of the entry, corresponding to the historyControlOwner object in historyControlTable.</li> <li>• <i>status</i>: row status of the history control table entry with the specified index, corresponding to the historyControlStatus in historyControlTable: undercreation(invalid), valid(valid), invalid(no valid historical sampling information).</li> </ul> <p>You can run the <b>rmon history</b> command to configure <i>entry-number</i> and <i>owner</i>.</p>
Samples interface	Sampled interface.
Sampling interval	<p>Sampling interval, in seconds, corresponding to the historyControlInterval object in historyControlTable. The system samples packets on the interface at this interval.</p> <p>You can run the <b>rmon history</b> command to configure this parameter.</p>
Last Sampling time	Latest sampling time, corresponding to the etherHistoryIntervalStart object in etherHistoryTable.
Latest sampled values	Latest sampling result.
octets	Number of bytes received in a sampling interval, corresponding to the etherHistoryOctets object in etherHistoryTable.
packets	Number of packets received in a sampling interval, corresponding to the etherHistoryPkts object in etherHistoryTable.
broadcast packets	Number of broadcast packets received in a sampling interval, corresponding to the etherHistoryBroadcastPkts object in etherHistoryTable.
multicast packets	Number of multicast packets received in a sampling interval, corresponding to the etherHistoryMulticastPkts object in etherHistoryTable.
undersize packets	Number of undersize packets received in a sampling interval, corresponding to the etherHistoryUndersizePkts object in etherHistoryTable.

Item	Description
oversize packets	Number of large packets received in a sampling interval, corresponding to the etherHistoryOversizePkts object in etherHistoryTable.
fragments packets	Number of undersize and CRC error packets received in a sampling interval, corresponding to the etherHistoryFragments object in etherHistoryTable.
jabbers packets	Number of large and CRC error packets received in a sampling interval, corresponding to the etherHistoryJabbers object in etherHistoryTable.
CRC alignment errors	Number of CRC error packets received in a sampling interval, corresponding to the etherHistoryCRCAAlignErrors object in etherHistoryTable.
collisions	Number of collision packets received in a sampling interval, corresponding to the etherHistoryCollisions object in etherHistoryTable.
Dropped packet	Number of packets discarded in a sampling interval, corresponding to the etherHistoryDropEvents object in etherHistoryTable.
utilization	Bandwidth usage in a sampling interval, corresponding to the etherHistoryUtilization object in etherHistoryTable.
History record	History sampling result.

## Related Topics

[16.2.14 rmon history](#)

## 16.2.6 display rmon prialarm

### Function

The **display rmon prialarm** command displays information about RMON extended alarm function.

### Format

```
display rmon prialarm [ entry-number ]
```

## Parameters

Parameter	Description	Value
<i>entry-number</i>	Displays information about the RMON extended alarm entry with the specified index. If this parameter is not specified, all RMON extended alarm information is displayed.	The value is an integer that ranges from 1 to 65535.

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

After configuring RMON extended alarm function using the **rmon prialarm** command, you can run this command to view sampling interval, rising and falling thresholds, alarm triggering condition, and latest sampled value.

## Example

# Display the RMON extended alarm configurations.

```
<HUAWEI> display rmon prialarm
Prialarm table 1 owned by Huawei is valid.
Samples absolute value : 1.3.6.1.2.1.16.1.1.1.6.1+.1.3.6.1.2.1.16.1.1.1.7.1
Sampling interval      : 30(sec)
Rising threshold       : 1000(linked with event 3)
Falling threshold      : 100(linked with event 3)
When startup enables   : risingOrFallingAlarm
This entry will exist  : forever
Latest value           : 557
```

**Table 16-24** Description of the display rmon prialarm command output

Item	Description
Prialarm table <i>entry-number</i> owned by <i>owner</i> is <i>status</i> .	<p>The current status of the extended alarm entry <i>entry-number</i> created by <i>owner</i> is <i>status</i>.</p> <ul style="list-style-type: none"> <li><i>entry-number</i>: extended alarm entry index.</li> <li><i>owner</i>: creator of the entry.</li> <li><i>status</i>: row status of the extended alarm entry with the specified index: undercreation(invalid), valid(valid), invalid(no valid extended alarm information).</li> </ul> <p>You can run the <b>rmon prialarm</b> command to configure <i>entry-number</i> and <i>owner</i>.</p>

Item	Description
Samples <i>type</i> value	<p>The sampling type is <i>type</i>. The value of <i>type</i> can be:</p> <ul style="list-style-type: none"> <li>absolute: absolute value sampling</li> <li>delta: variable value sampling</li> <li>changeratio: change rate of sampled values (Change rate = Value change/Sampling interval)</li> </ul> <p>This field is followed by an alarm variable.</p> <p>You can run the <b>rmon prialarm</b> command to configure this parameter.</p>
Sampling interval	<p>Interval at which traffic is sampled, in seconds.</p> <p>You can run the <b>rmon prialarm</b> command to configure this parameter.</p>
Rising threshold	<p>Alarm rising threshold.</p> <p>You can run the <b>rmon prialarm</b> command to configure this parameter.</p>
Falling threshold	<p>Alarm falling threshold.</p> <p>You can run the <b>rmon prialarm</b> command to configure this parameter.</p>
linked with event <i>entry-number</i>	<p>Associate with the row with index <i>entry-number</i>.</p> <p>You can run the <b>rmon prialarm</b> command to configure this parameter.</p>
When startup enables	<p>Condition that triggers alarms for the first time. The values are:</p> <ul style="list-style-type: none"> <li>risingOrFallingAlarm: generating an alarm when the sampled value exceeds the rising threshold or falls below the falling threshold</li> <li>risingAlarm: generating an alarm when the sampled value exceeds the rising threshold</li> <li>fallingAlarm: generating an alarm when the sampled value falls below the falling threshold</li> </ul> <p>You can run the <b>rmon alarm</b> command to configure this parameter.</p>
This entry will exist	<p>Aging time of the extended alarm entry. An entry may be valid permanently or in a certain period.</p> <p>You can run the <b>rmon prialarm</b> command to configure this parameter.</p>
Latest value	<p>Latest sampling result.</p>

## Related Topics

### [16.2.15 rmon prialarm](#)

## 16.2.7 display rmon statistics

### Function

The **display rmon statistics** command displays RMON Ethernet statistics.

### Format

**display rmon statistics** [ *interface-type interface-number* ]

### Parameters

Parameter	Description	Value
<i>interface-type</i> <i>interface-number</i>	Displays RMON Ethernet statistics on the specified Ethernet interface. If this parameter is not specified, RMON Ethernet statistics on all interfaces are displayed.	-

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

After you configure Ethernet statistics using the **rmon statistics** command, the system collects packet statistics on Ethernet interfaces. The command output includes communication information generated since statistics function is enabled. The command output helps you locate faults.

When the device restarts, all statistics are cleared.

### Example

```
# Display RMON Ethernet statistics.
```

```
<HUAWEI> display rmon statistics
Statistics entry 1 owned by Creator is valid.
Interface : GigabitEthernet0/0/1<ifIndex.402653698>
Received :
octets      :142915224 , packets      :1749151
broadcast packets :11603 , multicast packets:756252
undersize packets :0 , oversize packets :0
fragments packets :0 , jabbers packets :0
CRC alignment errors:0 , collisions :0
Dropped packet (insufficient resources):1795
Packets received according to length (octets):
64 :150183 , 65-127 :150183 , 128-255 :1383
256-511:3698 , 512-1023:0 , 1024-1518:0
```

**Table 16-25** Description of the display rmon statistics command output

Item	Description
Statistics entry <i>entry-number</i> owned by <i>owner</i> is <i>status</i> .	<p>The current status of the event entry <i>entry-number</i> created by <i>owner</i> is <i>status</i>.</p> <ul style="list-style-type: none"> <li>entry-number: Ethernet statistics entry, corresponding to the etherStatsIndex object in etherStatsTable.</li> <li>owner: creator of the entry, corresponding to the etherStatsOwner object in etherStatsTable.</li> <li>status: row status of the Ethernet statistics entry with the specified index, corresponding to the etherStatsStatus in etherStatsTable: undercreation(invalid), valid(valid), invalid(no valid statistics information).</li> </ul> <p>You can run the <b>rmon statistics</b> command to configure <i>entry-number</i> and <i>owner</i>.</p>
Interface	Interface where statistics are collected, corresponding to the etherStatsDataSource object in etherStatsTable, followed by the interface OID.
Received	Number of received packets.
octets	Number of received octets.
packets	Number of received packets, corresponding to the etherStatsPkts object in etherStatsTable.
broadcast packets	Number of received broadcast packets, corresponding to the etherStatsBroadcastPkts object in etherStatsTable.
multicast packets	Number of received multicast packets, corresponding to the etherStatsMulticastPkts object in etherStatsTable.
undersize packets	Number of received undersize packets, corresponding to the etherStatsUndersizePkts object in etherStatsTable.
oversize packets	<p>Number of received large packets, corresponding to the etherStatsOversizePkts object in etherStatsTable.</p> <p><b>NOTE</b> The S1720GFR, S1720GW, S1720GWR, S1720GW-E, S1720GWR-E, S1720X, S1720X-E, S2720EI, S2750EI, S5700LI, S5700S-LI, S5710-X-LI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S6720LI, S6720S-LI, S6720SI, and S6720S-SI cannot collect statistics on the packets of which the lengths range from 1518 to <b>n</b>. <b>n</b> is the maximum frame length allowed by the interface, and can be set using the <b>4.2.31 jumboframe enable</b> command.</p>
fragments packets	Number of received undersize and CRC error packets, corresponding to the etherStatsFragments object in etherStatsTable.



Item	Description
jabbers packets	Number of received large and CRC error packets, corresponding to the etherStatsJabbers object in etherStatsTable.  <b>NOTE</b> The S5720HI does not support this item.
CRC alignment errors	Number of received CRC error packets, corresponding to the etherStatsCRCAlignErrors object in etherStatsTable.
collisions	Number of received collision packets, corresponding to the etherStatsCollisions object in etherStatsTable.
Dropped packet	Number of discarded packets, corresponding to the etherStatsDropEvents object in etherStatsTable.
Packets received according to length	Number of received packets with different lengths, corresponding to the etherStatsPkts64Octets, etherStatsPkts65to127Octets, etherStatsPkts128to255Octets, etherStatsPkts256to511Octets, etherStatsPkts512to1023Octets, and etherStatsPkts1024to1518Octets objects in etherStatsTable.  <b>NOTE</b> In classified packet statistics on the S1720GFR, S1720GW, S1720GWR, S1720GW-E, S1720GWR-E, S1720X, S1720X-E, S2720EI, S2750EI, S5700LI, S5700S-LI, S5710-X-LI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S6720LI, S6720S-LI, S6720SI, and S6720S-SI, 1024-1518 includes the packets longer than 1518.

## Related Topics

[16.2.16 rmon statistics](#)

## 16.2.8 display rmon2 hlhostcontroltable

### Function

The **display rmon2 hlhostcontroltable** command displays information about entries in hlHostControlTable.

### Format

**display rmon2 hlhostcontroltable** [ *index ctrl-index* ] [ *verbose* ]

## Parameters

Parameter	Description	Value
<i>ctrl-index</i>	Indicates the entry index, which uniquely identifies an entry in the host control table.	The value is an integer that ranges from 1 to 65535.
<b>verbose</b>	Displays details about the host control table.	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

After you use the **rmon2 hlhostcontroltable** command to create a protocol directory table, you can run the **display rmon2 hlhostcontroltable** command to view the configurations.

If no entry index is specified, the configuration of the entire table is displayed.

## Example

# Display information about the entry with index 123 in the host control table.

```
<HUAWEI> display rmon2 hlhostcontroltable index 123
Abbreviation:
index - hlhostcontrolindex
datasource - hlhostcontroldatasource
droppedfrm - hlhostcontrolndroppedframes
inserts - hlhostcontrolninserts
Deletes - hlHostControlNIDeletes
maxentries - hlhostcontrolnmaxdesiredentries
status - hlhostcontrolstatus

index datasource          droppedfrm inserts  Deletes  maxentries  status
123 Vlanif10              0      0      0      50         active
```

# Display detailed information about the entry with index 123 in the host control table.

```
<HUAWEI> display rmon2 hlhostcontroltable index 123 verbose
Abbreviation:
index - hlhostcontrolindex
datasource - hlhostcontroldatasource
droppedfrm - hlhostcontrolndroppedframes
inserts - hlhostcontrolninserts
Deletes - hlHostControlNIDeletes
maxentries - hlhostcontrolnmaxdesiredentries
owner - hlhostcontrolowner
status - hlhostcontrolstatus
index      : 123
datasource : Vlanif10
droppedfrm : 0
inserts    : 0
Deletes    : 0
```

```
maxentries : 50
owner      : china
status     : active
```

**Table 16-26** Description of the **display rmon2 hlhostcontroltable** command output

Item	Description
index	Index of an entry in the hlHostControlTable. You can run the <b>rmon2 hlhostcontroltable</b> command to configure this parameter.
datasource	Source interface of data. You can run the <b>rmon2 hlhostcontroltable</b> command to configure this parameter.
droppedfrm	Number of the frames that are received on the statistics interface but not added into nlHost entries.
inserts	Times add nlHost entries are added to nlHostTable.
Deletes	Times nlHost entries are deleted from nlHostTable.
maxentries	Maximum number of entries that hlHostControlTable contains. You can run the <b>rmon2 hlhostcontroltable</b> command to configure this parameter.
owner	Owner of the entry in the hlHostControlTable. You can run the <b>rmon2 hlhostcontroltable</b> command to configure this parameter.
status	Status of the entry in the hlHostControlTable: <ul style="list-style-type: none"> <li>• active: running normally</li> <li>• not in service: invalid</li> </ul> You can run the <b>rmon2 hlhostcontroltable</b> command to configure this parameter.

## Related Topics

[16.2.17 rmon2 hlhostcontroltable](#)

## 16.2.9 display rmon2 nlhosttable

### Function

The **display rmon2 nlhosttable** command displays information about entries in the nlHostTable.

## Format

**display rmon2 nlhosttable** [ **hostcontrolindex** *ctrl-index* ] [ **timemark** *time-value* ] [ **protocoldirlocalindex** *protocol-local-index* ] [ **hostaddress** *ip-address* ]

## Parameters

Parameter	Description	Value
<b>hostcontrolindex</b> <i>ctrl-index</i>	Specifies the index number. A <i>ctrl-index</i> uniquely identifies an entry in the hIHostControlTable.	It is an integer ranging from 1 to 65535.
<b>timemark</b> <i>time-value</i>	Enables the time filter.	The value is in the range of 0 to 4294967295. The entries in the nlHostTable with the ChgTm value being larger than this value are displayed.
<b>protocoldirlocalindex</b> <i>protocol-local-index</i>	Identifies the network layer protocol of the nlHostAddress.	Its value ranges from 1 to 2147483647.
<b>hostaddress</b> <i>ip-address</i>	Checks the traffic on a specified host.	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

After statistics function is configured on an interface, you can view traffic statistics using this command. A maximum of 5000 rows can be displayed for each protocol on an interface.

## Example

# Display information about the entry with index 1 in the host table.

```
<HUAWEI> display rmon2 nlhosttable hostcontrolindex 1 protocoldirlocalindex 2 hostaddress 10.110.94.177
Abbreviation:
HIdx - hIHostControlIndex
PIdx - ProtocolDirLocalIndex
Addr - nlHostAddress
InPkts - nlHostInPkts
OutPkts - nlHostOutPkts
```

```
InOctes - nlHostInOctets
OutOctes - nlHostOutOctets
OutMac - nlHostOutMacNonUnicastPkts
ChgTm - nlHostTimeMark
CrtTm - nlHostCreateTime
HIdx PIdx Addr      InPkts OutPkts InOctes OutOctes OutMac      ChgTm          CrtTm
1   2   10.110.94.177 59    68    3240  3821    0    0 days 00h:01m:29s.09th(8909) 0 days 00h:
01m:01s.13th(6113)
```

**Table 16-27** Description of the display rmon2 nlhosttable command output

Item	Description
HIdx	Index of the host control table.
PIdx	Protocol directory index.
Addr	Host address. It is the source address of the incoming IP packets on the monitored interface and destination address of the outgoing IP packets on the interface.
InPkts	Number of incoming packets on the monitored interface.
OutPkts	Number of outgoing packets on the monitored interface.
InOctes	Number of incoming bytes on the monitored interface.
OutOctes	Number of outgoing bytes on the monitored interface.
OutMac	Number of outgoing non-unicast packets on the monitored interface.
ChgTm	Entry time filter in the host control table.
CrtTm	Customized time filter.

## 16.2.10 display rmon2 protocoldirtable

### Function

The **display rmon2 protocoldirtable** command displays all entries in the protocolDirTable.

### Format

```
display rmon2 protocoldirtable
```

### Parameters

None

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

After you use the **rmon2 protocoldirtable** command to configure statistics on IP packets, you can run the **display rmon2 protocoldirtable** command to view the configurations.

## Example

# Display entries in the protocolDirTable.

```
<HUAWEI> display rmon2 protocoldirtable
protocolDirId      : 8.0.0.0.1.0.0.8.0
protocolDirParameters : 2.0.0
protocolDirLocalIndex : 2
protocolDirDescr   : ww
protocolDirAddressMapConfig: not supported
protocolDirHostConfig : supported on
protocolDirMatrixConfig : not supported
protocolDirOwner    : huawei
protocolDirStatus   : active
```

**Table 16-28** Description of the display rmon2 protocoldirtable command output

Item	Description
protocolDirId	Protocol directory ID. Currently, RMON2 only supports IP protocol, so the protocol directory ID is fixed at 8.0.0.0.1.0.0.8.0.
protocolDirParameters	Protocol directory parameter. The value is fixed at 2.0.0.
protocolDirLocalIndex	Local protocol directory index.
protocolDirDescr	Indicates the description of the protocol directory table. You can run the <b>rmon2 protocoldirtable</b> command to configure this parameter.
protocolDirAddress-MapConfig	Whether protocol directory address mapping is supported. This function is not supported currently.

Item	Description
protocolDirHostConfig	<p>Whether the configuration of protocol directory host is supported:</p> <ul style="list-style-type: none"> <li>not supported: The device does not monitor the network-layer host table of the protocol, and this value cannot be changed.</li> <li>supported on: The device can monitor the network-layer host table of the protocol, and the monitoring function is enabled.</li> <li>supported off: The device can monitor the network-layer host table of the protocol, but the monitoring function is disabled.</li> </ul> <p>You can run the <a href="#">rmon2 protocoldirtable</a> command to configure this parameter.</p>
protocolDirMatrixConfig	<p>Whether protocol directory matrix is supported. This function is not supported currently.</p>
protocolDirOwner	<p>Indicates the owner.</p> <p>You can run the <a href="#">rmon2 protocoldirtable</a> command to configure this parameter.</p>
protocolDirStatus	<p>Protocol directory status.</p> <ul style="list-style-type: none"> <li>active: running normally</li> <li>not in service: invalid</li> </ul> <p>You can run the <a href="#">rmon2 protocoldirtable</a> command to configure this parameter.</p>

## Related Topics

[16.2.18 rmon2 protocoldirtable](#)

## 16.2.11 display snmp-agent trap feature-name rmon all

### Function

The **display snmp-agent trap feature-name snmp all** command displays whether the switch is enabled to send traps of RMON feature to the NMS.

### Format

**display snmp-agent trap feature-name rmon all**

### Parameters

None

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

After running the **snmp-agent trap enable feature-name snmp** command to enable the function of sending traps of the RMON feature to the NMS, you can run the **display snmp-agent trap feature-name snmp all** command to check whether this function is enabled.

### Prerequisites

RMON has been enabled. For details, see [snmp-agent](#).

## Example

# Display whether the switch is enabled to send traps of RMON feature to the NMS.

```
<HUAWEI> display snmp-agent trap feature-name rmon all
-----
Feature name: RMON
Trap number : 4
-----
Trap name           Default switch status  Current switch status
risingalarm         on                     on
fallingalarm        on                     on
rmon_pri_risingalarm  on                     on
rmon_pri_fallingalarm on                     on
```

**Table 16-29** Description of the **display snmp-agent trap feature-name rmon all** command output

Item	Description
Feature name	Name of the feature that generates traps.
Trap number	Number of traps generated by RMON feature.



Item	Description
Trap name	<p>Name of the trap. The RMON feature supports the following traps:</p> <ul style="list-style-type: none"> <li>risingalarm: Indicates that the current sampled value is greater than or equal to the set threshold specified by the trap table.</li> <li>fallingalarm: Indicates that the current sampled value is less than or equal to the set threshold specified by the trap table.</li> <li>rmon_pri_risingalarm: Indicates that the current sampled value is greater than or equal to the set threshold specified by the pri_alarm table.</li> <li>rmon_pri_fallingalarm: Indicates that the current sampled value is less than or equal to the set threshold specified by the pri_alarm table.</li> </ul>
Default switch status	<p>Default status of a trap:</p> <ul style="list-style-type: none"> <li>on: The switch is enabled to send this trap to the NMS.</li> <li>off: The switch is disabled to send this trap to the NMS.</li> </ul>
Current switch status	<p>Current status of a trap:</p> <ul style="list-style-type: none"> <li>on: The switch is enabled to send this trap to the NMS.</li> <li>off: The switch is disabled to send this trap to the NMS.</li> </ul> <p>This status can be configured using the <a href="#">snmp-agent trap enable feature-name rmon</a> command.</p>

## Related Topics

[16.2.20 snmp-agent trap enable feature-name rmon](#)

## 16.2.12 rmon alarm

### Function

The **rmon alarm** command adds an entry to the alarm table.

The **undo rmon alarm** command deletes an entry from the alarm table.

### Format

```
rmon alarm entry-number alarm-OID sampling-time { absolute | changeratio | delta } rising-threshold threshold-value1 event-entry1 falling-threshold threshold-value2 event-entry2 [ startup-alarm { falling | rising | risingorfalling } ] [ owner owner-name ]
```

**undo rmon alarm** *entry-number*

**Parameters**

Parameter	Description	Value
<i>entry-number</i>	Specifies the index of the entry to be added or deleted.	The value is an integer that ranges from 1 to 65535.
<i>alarm-OID</i>	Specifies the OID of a monitored object.	The name is a string of 1 to 256 case-sensitive characters without spaces. When quotation marks are used around the string, spaces are allowed in the string.
<i>sampling-time</i>	Specifies the sampling interval.	The value is an integer that ranges from 5 to 65535, in seconds.
<b>absolute</b>	Indicates that the sample type is absolute. The value is the sampled value at the end of the period.	-
<b>changeratio</b>	Indicates that the sample type is changeratio. The value is Changing value/Sampling interval.	-
<b>delta</b>	Indicates that the sample type is delta. The value is the difference between the samples at the beginning and end of the period.	-
<b>rising-threshold</b> <i>threshold-value1</i>	Specifies the rising threshold of sampled value.	The value is an integer that ranges from 1 to 2147483647.
<i>event-entry1</i>	Indicates the event index corresponding to the rising threshold.	The value is an integer that ranges from 1 to 65535.

Parameter	Description	Value
<b>falling-threshold</b> <i>threshold-value2</i>	Specifies the falling threshold of sampled value.	The value is an integer that ranges from 0 to 2147483646.
<i>event-entry2</i>	Indicates the event index corresponding to the falling threshold.	The value is an integer that ranges from 1 to 65535.
<b>startup-alarm</b> { <b>falling</b>   <b>rising</b>   <b>risingorfalling</b> }	Specifies the condition of sending an alarm when the system data is sampled for the first time. <ul style="list-style-type: none"> <li>• <b>falling</b>: an alarm is sent when the sampled value falls below the lower threshold value.</li> <li>• <b>rising</b>: an alarm is sent when the sampled value exceeds the upper threshold value.</li> <li>• <b>risingorfalling</b>: an alarm is sent when the sampled value exceeds the upper threshold value or the lower threshold value.</li> </ul> <b>NOTE</b> An alarm is sent no matter whether the following sampled value exceeds the upper threshold value or the lower threshold value.	-
<b>owner</b> <i>owner-name</i>	Indicates the owner of the alarm.	The name is a string of 1 to 127 case-sensitive characters without spaces. When quotation marks are used around the string, spaces are allowed in the string.

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To monitor system running status, run the **rmon alarm** command to configure an alarm table and add an entry to the alarm table. After the command is executed, the RMON alarm function is enabled. The system obtains information about the monitored object at the specified interval, and compares the obtained value with the configured threshold. Then the system triggers the event according to the following table, and records log or sends a trap to the NMS.

Situation	Action
The sampled value is larger than or equal to the configured rising threshold <i>threshold-value1</i> .	Trigger <i>event-entry1</i> .
The sampled value is smaller than or equal to the configured falling threshold <i>threshold-value2</i> .	Trigger <i>event-entry2</i> .

### Prerequisites

Before configuring alarm function for the specified object, run the **rmon event** command to define the associated events. Otherwise, events cannot be triggered even if alarms are generated.

If the alarm variables configured in RMON alarm function are MIB variables defined in the statistics group or history group, the Ethernet statistics function or history statistics function must be configured on the monitored Ethernet interface first. Otherwise, alarm entries cannot be created.

## Example

# Monitor the alarm threshold of etherStatsBroadcastPkts.1 (1.3.6.1.2.1.16.1.1.1.6.1) and sample the absolute value with an interval of 30 seconds. When the sampled value is greater than or equal to the upper threshold 500, event 1 is triggered. When the sampled value is less than or equal to the lower threshold 100, event 2 is triggered. The **creator** parameter indicates the owner that creates the event.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] rmon statistics 1 owner creator
[HUAWEI-GigabitEthernet0/0/1] quit
[HUAWEI] rmon event 1 log
[HUAWEI] rmon event 2 trap public
[HUAWEI] rmon alarm 1 1.3.6.1.2.1.16.1.1.1.6.1 30 absolute rising-threshold 500 1 falling-threshold
100 2 owner creator
```

## Related Topics

[16.2.2 display rmon alarm](#)

## 16.2.13 rmon event

### Function

The **rmon event** command adds an entry to the event table.

The **undo rmon event** command deletes an entry from the event table.

### Format

**rmon event** *entry-number* [ **description** *string* ] { **log** | **trap** *object* | **log-trap** *object* | **none** } [ **owner** *owner-name* ]

**undo rmon event** *entry-number*

### Parameters

Parameter	Description	Value
<i>entry-number</i>	Specifies the index of the entry to be added or deleted.	The value is an integer that ranges from 1 to 65535.
<b>description</b> <i>string</i>	Specifies the event description.	The value is a string of 1 to 127 characters.
<b>log</b>	Records a log for the event.	-
<b>trap</b>	Sends a trap to the NMS.	-
<i>object</i>	Specifies the community name of the NMS receiving the trap.	The value is a string of 1 to 127 characters.
<b>log-trap</b>	Records a log and sends a trap to the NMS for the event.	-
<b>none</b>	Indicates that no action is taken for the event.	-
<b>owner</b> <i>owner-name</i>	Indicates the creator of the event entry.	The name is a string of 1 to 127 case-sensitive characters without spaces. When quotation marks are used around the string, spaces are allowed in the string.

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

This command specifies whether to record a log or send a trap for events. When an error occurs in the system, the RMON alarm function triggers the corresponding event. You can run the **rmon event** command to configure an event table and add an entry to the table. The entry specifies whether to record a log or send a trap to the NMS for the event.

### Prerequisites

The **rmon alarm** command is executed to configure the alarm objects. Otherwise, no alarm will trigger the event.

## Example

```
# Send a trap to the NMS for event 10.
```

```
<HUAWEI> system-view  
[HUAWEI] rmon event 10 trap public
```

## Related Topics

[16.2.3 display rmon event](#)

## 16.2.14 rmon history

### Function

The **rmon history** command adds an entry to the history control table.

The **undo rmon history** command deletes an entry from the history control table.

### Format

**rmon history** *entry-number* **buckets** *number* **interval** *sampling-interval* [ **owner** *owner-name* ]

**undo rmon history** *entry-number*

### Parameters

Parameter	Description	Value
<i>entry-number</i>	Specifies the index of the entry to be added or deleted.	The value is an integer that ranges from 1 to 65535.
<b>buckets</b> <i>number</i>	Indicates the maximum number of records in the history control table.	The value is an integer that ranges from 1 to 10.
<b>interval</b> <i>sampling-interval</i>	Specifies the sampling interval.	The value is an integer that ranges from 5 to 3600, in seconds.

Parameter	Description	Value
<b>owner</b> <i>owner-name</i>	Indicates the owner of the entry in the history control table.	The name is a string of 1 to 127 case-sensitive characters without spaces. When quotation marks are used around the string, spaces are allowed in the string.

## Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To collect statistics on the specified interface at an interval and save the statistics for future retrieval, run the **rmon history** command to configure a history control table and add an entry to the table. The system can periodically collect statistics on each type of traffic, including bandwidth usage, number of error packets, and total number of packets.

### Precautions

The number of stored records is determined by the **buckets number** parameter. When the number of records in the table reaches the maximum, the system overwrites the old records with new ones. Statistics include the number of packets, broadcast packets, and multicast packets received by the interface within a sampling interval. You can run the **display rmon history** command to view history sampling results.

In this version, this command cannot be configured on Eth-Trunk member interfaces.

## Example

# Configure a history control table and add an entry with index 1 to the table. Set the maximum number of entries in the table to 10, sampling interval to 5 seconds, and creator to **user1**.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] rmon history 1 buckets 10 interval 5 owner user1
```

## Related Topics

[16.2.5 display rmon history](#)

## 16.2.15 rmon prialarm

### Function

The **rmon prialarm** command adds an entry to the extended alarm table.

The **undo rmon prialarm** command deletes an entry from the extended alarm table.

### Format

**rmon prialarm** *entry-number prialarm-formula description-string sampling-interval* { **absolute** | **changeratio** | **delta** } **rising-threshold** *threshold-value1 event-entry1* **falling-threshold** *threshold-value2 event-entry2* **entrytype** { **cycle** *entry-period* | **forever** } [ **owner** *owner-name* ]

**undo rmon prialarm** *entry-number*

### Parameters

Parameter	Description	Value
<i>entry-number</i>	Specifies the index of the entry to be added or deleted.	The value is an integer that ranges from 1 to 65535.
<i>prialarm-formula</i>	Specifies the formula for calculating an alarm variable. The alarm variable in the formula is identified by an OID. The OID value starts with a dot, for example, (.1.3.6.1.2.1.2.1.10.1)*8. The calculation formula is defined by user. The calculation result is a long integer. Ensure that the length of calculation result in each step cannot exceed the limit; otherwise, the calculation result is incorrect.	The value is a string of 1 to 256 characters.
<i>description-string</i>	Specifies the alarm description.	The value is a string of 1 to 256 characters.
<i>sampling-interval</i>	Specifies the sampling interval.	The value is an integer that ranges from 10 to 65535, in seconds.
<b>absolute</b>	Indicates that the sample type is absolute. The value is the sampled value at the end of the period.	-
<b>changeratio</b>	Indicates that the sample type is changeratio. The value is Changing value/Sampling interval.	-



Parameter	Description	Value
<b>delta</b>	Indicates that the sample type is delta. The value is the difference between the samples at the beginning and end of the period.	-
<b>rising-threshold</b> <i>threshold-value1</i>	Specifies the alarm rising threshold.	The value is an integer that ranges from 1 to 2147483647.
<i>event-entry1</i>	Indicates the entry number of the event corresponding to the rising threshold in the event table.	The value is an integer that ranges from 1 to 65535.
<b>falling-threshold</b> <i>threshold-value2</i>	Specifies the alarm falling threshold.	The value is an integer that ranges from 0 to 2147483646.
<i>event-entry2</i>	Indicates the entry number of the event corresponding to the falling threshold in the event table.	The value is an integer that ranges from 1 to 65535.
<b>entrytype</b>	Indicates the lifetime type of an alarm entry.	-
<b>cycle</b> <i>entry-period</i>	Indicates the lifetime of an alarm entry.	The value is an integer that ranges from 11 to 2147483646.
<b>forever</b>	Indicates that the alarm entry is valid permanently.	-
<b>owner</b> <i>owner-name</i>	Indicates the owner of the extended alarm variable.	The value is a string of 1 to 127 case-sensitive characters without spaces.

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The extended alarm function can compute the alarm variables and compare the result with the specified threshold.

After the extended alarm function is enabled, the system performs the following operations:

1. Samples the alarm variables in the extended alarm formula at the specified sampling interval.
2. Calculates the sampled value using the defined formula.
3. Compares the calculation result with the thresholds and takes actions according to the following table.

Situation	Action
The sampled value is larger than or equal to the configured rising threshold <i>threshold-value1</i> .	Trigger <i>event-entry1</i> .
The sampled value is smaller than or equal to the configured falling threshold <i>threshold-value2</i> .	Trigger <i>event-entry2</i> .

To use more alarm functions, run the **rmon prialarm** command to configure the extended alarm table and add an entry to the table.

#### Prerequisites

Before configuring extended alarm function for the specified object, run the **rmon event** command to define the associated events. Otherwise, events cannot be triggered even if alarms are generated. When the sampled value exceeds the rising threshold or falls below the falling threshold, whether to record a log or send a trap to the NMS is determined by the **rmon event** command.

### Example

# Monitor broadcast and multicast packets: Set the sampling interval to 10 seconds and sample type to absolute. Trigger event 3 when the sample value reaches or exceeds 100000 and when the sample value reaches or falls below 100. Set the lifetime of the entry to forever and the owner to **Huawei**.

```
<HUAWEI> system-view
[HUAWEI] rmon prialarm 1 .1.1.3.6.1.2.1.16.1.1.1.6.1+.1.3.6.1.2.1.16.1.1.1.7.1 sumofbroadandmulti 10
absolute rising-threshold 100000 3 falling-threshold 100 3 entrytype forever owner Huawei
```

### Related Topics

[16.2.6 display rmon prialarm](#)

## 16.2.16 rmon statistics

### Function

The **rmon statistics** command adds an entry to the statistics table.

The **undo rmon statistics** command deletes an entry from the statistics table.

### Format

**rmon statistics** *entry-number* [ **owner** *owner-name* ]

**undo rmon statistics** *entry-number*

## Parameters

Parameter	Description	Value
<i>entry-number</i>	Indicates the row index corresponding to the entry to be added or deleted.	The value is an integer that ranges from 1 to 65535.
<b>owner</b> <i>owner-name</i>	Indicates the owner name.	The name is a string of 1 to 127 case-sensitive characters without spaces. When quotation marks are used around the string, spaces are allowed in the string.

## Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To keep collecting statistics on the current interface, run the **rmon statistics** command to configure a statistics table and add an entry to the table. This command monitors usage of Ethernet interfaces and collects statistics on errors, including the number of collision packets, CRC error packets, undersize and large packets, timeout packets, fragments, broadcast packets, multicast packets, and unicast packets.

### Prerequisites

The **rmon-statistics enable** command is executed to enable RMON statistics function on the interface. If the command is not executed, the statistics result is 0.

### Precautions

In this version, this command cannot be configured on Eth-Trunk member interfaces.

## Example

```
# Configure a statistics table on GigabitEthernet0/0/1 and add an entry with index 20 to the table.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] rmon statistics 20 owner creator
```

## Related Topics

[16.2.7 display rmon statistics](#)

[16.2.19 rmon-statistics enable](#)

## 16.2.17 rmon2 hlhostcontroltable

### Function

The **rmon2 hlhostcontroltable** command creates or changes an entry in the hlHostControlTable.

The **undo rmon2 hlhostcontroltable** command deletes an entry from the hlHostControlTable or from the whole table.

### Format

**rmon2 hlhostcontroltable index** *ctrl-index* [ **datasource interface** *interface-type interface-number* ] [ **maxentry** *maxentry-value* ] [ **owner** *owner-name* ] [ **status** { **active** | **inactive** } ]

**undo rmon2 hlhostcontroltable** [ **index** *ctrl-index* ]

### Parameters

Parameter	Description	Value
<i>ctrl-index</i>	Indicates the entry index, which uniquely identifies an entry in the host control table.	The value is an integer that ranges from 1 to 65535.
<b>datasource interface</b> <i>interface-type interface-number</i>	Identifies an interface and a subnet, corresponding to hlHostControlDataSource. The parameter value, namely, the interface index, is the data source defining the entry. In this command, the data source is represented by interface type and number.	-
<b>maxentry</b> <i>maxentry-value</i>	Indicates the maximum number of entries in the host table.	The value is an integer that ranges from 1 to 100000. The default value is 50.If the host table contains too many entries, system performance is degraded. The default settings of host table are recommended.
<b>owner</b> <i>owner-name</i>	Indicates the owner.	The value is a string of 1 to 127 characters and cannot be empty.
<b>status</b>	Indicates the status of an entry in the host control table, corresponding to hlHostControlStatus.	-

Parameter	Description	Value
<b>active</b>	Indicates that the hlHostControlStatus value in the host control table is active and this entry is available.	-
<b>inactive</b>	Indicates that the hlHostControlStatus value in the host control table is not in service and this entry is inactive and unavailable.	-

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To monitor traffic on the subnet connected to an interface of the managed device, run the **rmon2 hlhostcontroltable** command and specify the interface.

### Precautions

When creating an entry, specify the **datasource interface** parameter to identify the interface, which specifies the subnet. The parameter value, namely, the interface index, is the data source defining the entry. Enter the interface type and number in the command. Only one entry can be created for each interface in the host control table.

The parameter **status** in the **display rmon2 hlhostcontroltable** command output matches the hlhostcontrolstatus value, which indicates the entry status.

- When the hlhostcontrolstatus value is set to **inactive**, all related entries in the host table are deleted automatically.
- When the hlhostcontrolstatus value is set to **active**, you cannot change the hlhostcontroldatasource and hlhostcontrolnlmaxdesiredentries values.
- If an interface that corresponds to the hlhostcontroldatasource in an entry is deleted, the entry is deleted at the same time.

## Example

```
# Create an entry in the host control table.
```

```
<HUAWEI> system-view  
[HUAWEI] rmon2 hlhostcontroltable index 1 datasource interface gigabitethernet 0/0/1 maxentry 100  
owner huawei status active
```

```
# Set the hlHostControlStatus value in the host control table to inactive.
```

```
<HUAWEI> system-view  
[HUAWEI] rmon2 hlhostcontroltable index 1 status inactive
```

## Related Topics

[16.2.8 display rmon2 hlhostcontroltable](#)

# 16.2.18 rmon2 protocoldirtable

## Function

The **rmon2 protocoldirtable** command creates or modifies an entry in the protocolDirTable.

The **undo rmon2 protocoldirtable** command deletes an entry from the protocolDirTable. If optional parameters are not specified, the entire table is deleted.

## Format

```
rmon2 protocoldirtable protocoldirid protocol-id parameter parameter-value
[ descr description-string ] [ host { notsupported | supportedon |
supportedoff } ] [ owner owner-name ] [ status { active | inactive } ]
```

```
undo rmon2 protocoldirtable [ protocoldirid protocol-id parameter parameter-
value ]
```

## Parameters

Parameter	Description	Value
<b>protocoldirid</b> <i>protocol-id</i>	Indicates the protocol ID. Only IP protocol is supported currently.	The value is fixed at 8.0.0.0.1.0.0.8.0.
<b>parameter</b> <i>parameter-value</i>	Indicates the protocol parameter.	The value is fixed at 2.0.0.
<b>descr</b> <i>description-string</i>	Indicates the description of the protocol directory table.	The value is a string of 1 to 64 characters.

Parameter	Description	Value
<b>host</b> { <b>notsupported</b>   <b>supportedon</b>   <b>supportedoff</b> }	Indicates the configuration of protocol directory host, corresponding to protocolDirHostConfig in the <b>display rmon2 protocoldirtable</b> command output. <ul style="list-style-type: none"> <li>● <b>notsupported</b>: Indicates that the device does not monitor the network-layer host table of the protocol, and this value cannot be changed.</li> <li>● <b>supportedon</b>: Indicates that the device can monitor the network-layer host table of the protocol, and the monitoring function is enabled.</li> <li>● <b>supportedoff</b>: Indicates that the device can monitor the network-layer host table of the protocol, but the monitoring function is disabled.</li> </ul>	-
<b>owner</b> <i>owner-name</i>	Indicates the owner.	The value is a string of 1 to 127 characters.
<b>status</b> { <b>active</b>   <b>inactive</b> }	Indicates the entry status, corresponding to the protocolDirStatus value in the <b>display rmon2 protocoldirtable</b> command output. <ul style="list-style-type: none"> <li>● <b>active</b>: Indicates that the protocolDirStatus value in the host control table is active and this entry is available.</li> <li>● <b>inactive</b>: Indicates that the protocolDirStatus value in the host control table is not in service and this entry is inactive and unavailable.</li> </ul>	-

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To monitor statistics on IP packets, run this command.

RMON2 supports only statistics on IP packets on an Ethernet interface. A protocol occupies an entry, so there is only one entry in the table.

### Precautions

When running the **rmon2 protocoldirtable** command, you must set the description and protocols supported by the host. That is, the **descr** and **host** parameters are mandatory.

The parameter **status** in the **display rmon2 protocoldirtable** command output matches the protocolDirStatus value, which indicates the entry status.

- When the **status** parameter is set to **active**, the **descr** value cannot be modified. The value of **host** (corresponding to the protocolDirHostConfig value, indicating the protocol directory host configuration) can be modified. This parameter indicates whether to monitor the network-layer host table of the protocol.
  - If the **host** value is set to **notsupported**, the **host** value cannot be modified.
  - If the **host** value is not **notsupported**, the value can be switched between **supportedon** and **supportedoff**.
  - When the **host** value is changed from **supportedon** to **supportedoff**, the corresponding entry in the host control table is deleted.
- When the status is **inactive**, all related entries in the host table are deleted.

## Example

# Create an entry in the protocol directory table.

```
<HUAWEI> system-view  
[HUAWEI] rmon2 protocoldirtable protocoldirid 8.0.0.0.1.0.0.8.0 parameter 2.0.0 descr huawei host supportedon owner huawei status active
```

# Set the protocolDirStatus value in the protocol directory table to not in service.

```
<HUAWEI> system-view  
[HUAWEI] rmon2 protocoldirtable protocoldirid 8.0.0.0.1.0.0.8.0 parameter 2.0.0 status inactive
```

# Set the protocolDirHostConfig value in the protocol directory table to supportedoff.

```
<HUAWEI> system-view  
[HUAWEI] rmon2 protocoldirtable protocoldirid 8.0.0.0.1.0.0.8.0 parameter 2.0.0 host supportedoff
```

## Related Topics

[16.2.10 display rmon2 protocoldirtable](#)

# 16.2.19 rmon-statistics enable

## Function

The **rmon-statistics enable** command enables RMON statistics function on an interface.

The **undo rmon-statistics** command disables RMON statistics function on an interface.



By default, RMON statistics function is disabled on interfaces.

## Format

**rmon-statistics enable**

**undo rmon-statistics**

## Parameters

None

## Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

If the statistics function is not enabled on an interface, statistics in the statistics table and history table are 0.

### Precautions

In this version, this command cannot be configured on Eth-Trunk member interfaces.

After the interface mode is changed from Layer 2 to Layer 3 by using the **undo portswitch** command, the device does not support the **rmon-statistics enable** command.

## Example

```
# Enable RMON statistics function on GigabitEthernet0/0/1.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] rmon-statistics enable
```

## Related Topics

[16.2.16 rmon statistics](#)

## 16.2.20 snmp-agent trap enable feature-name rmon

### Function

The **snmp-agent trap enable feature-name rmon** command enables the alarm function for the RMON module.

The **undo snmp-agent trap enable feature-name rmon** command disables the alarm function for the RMON module.

By default, the alarm function is enabled for the RMON module.

## Format

**snmp-agent trap enable feature-name rmon** [ **trap-name** { **fallingalarm** | **risingalarm** | **rmon\_pri\_fallingalarm** | **rmon\_pri\_risingalarm** } ]

**undo snmp-agent trap enable feature-name rmon** [ **trap-name** { **fallingalarm** | **risingalarm** | **rmon\_pri\_fallingalarm** | **rmon\_pri\_risingalarm** } ]

## Parameters

Parameter	Description	Value
<b>trap-name</b>	Enables or disables the alarm function for the specified event.  If no event type is specified using the <b>trap-name</b> parameter, all types of alarms are enabled or disabled for the RMON module.	-
<b>fallingalarm</b>	Indicates that the current sampled value is smaller than or equal to the threshold configured in the alarmTable.	-
<b>risingalarm</b>	Indicates that the current sampled value is larger than or equal to the threshold configured in the alarmTable.	-
<b>rmon_pri_fallingalarm</b>	Indicates that the current sampled value is smaller than or equal to the threshold configured in the prialarmTable.	-
<b>rmon_pri_risingalarm</b>	Indicates that the current sampled value is larger than or equal to the threshold configured in the prialarmTable.	-

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

A device managed by the NMS can send traps to the NMS if the alarm function is enabled for the RMON module on the device. By default, all alarms for the RMON

module are enabled. If only one or some event alarms need to be enabled, run the **snmp-agent trap enable feature-name rmon trap-name** command.

## Example

# Enable the fallingalarm for the RMON module.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name rmon trap-name fallingalarm
```

## 16.3 LLDP Configuration Commands

16.3.1 Command Support

16.3.2 cdp clear neighbor

16.3.3 display cdp local

16.3.4 display cdp neighbor

16.3.5 display cdp neighbor brief

16.3.6 display cdp statistics

16.3.7 display lldp local

16.3.8 display lldp neighbor

16.3.9 display lldp neighbor brief

16.3.10 display lldp statistics

16.3.11 display lldp tlv-config

16.3.12 display snmp-agent trap feature-name lldptrap all

16.3.13 ip domain-name

16.3.14 lldp auto-vlan sensor ap

16.3.15 lldp clear neighbor

16.3.16 lldp compliance cdp receive

16.3.17 lldp compliance cdp txrx

16.3.18 lldp dot3-tlv power

16.3.19 lldp enable (interface view)

16.3.20 lldp enable (system view)

16.3.21 lldp management-address

16.3.22 lldp message-transmission delay

16.3.23 lldp message-transmission hold-multiplier

16.3.24 lldp message-transmission interval

16.3.25 lldp restart-delay

16.3.26 lldp tlv-enable (MEth interface view)

[16.3.27 lldp tlv-enable basic-tlv](#)

[16.3.28 lldp tlv-enable dot1-tlv](#)

[16.3.29 lldp tlv-enable dot3-tlv](#)

[16.3.30 lldp tlv-enable med-tlv](#)

[16.3.31 lldp trap-interval](#)

[16.3.32 reset cdp statistics](#)

[16.3.33 reset lldp statistics](#)

[16.3.34 snmp-agent trap enable feature-name lldptrap](#)

## 16.3.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

## 16.3.2 cdp clear neighbor

### Function

The **cdp clear neighbor** command clears CDP neighbors in the system or on an interface of the device.

### Format

**cdp clear neighbor** [ **interface** *interface-type interface-number* ]

### Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type interface-number</i>	<p>Indicates the type and number of the interface whose CDP neighbors are to be cleared. In the command:</p> <ul style="list-style-type: none"> <li><i>interface-type</i> specifies the type of the interface.</li> <li><i>interface-number</i> specifies the number of the interface.</li> </ul> <p>If no interface is specified, this command clears CDP neighbors on all interfaces.</p>	-

## Views

User view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

If you want to obtain the latest CDP neighbor information of interfaces, use the **cdp clear neighbor** command to clear existing CDP neighbors. When an interface receives new CDP packets, new CDP neighbors are generated.

### Prerequisites

The LLDP function has been enabled globally and on interfaces, and the [16.3.16 lldp compliance cdp receive](#) command has been run to enable CDP-compatible LLDP on interfaces.

## Example

# Clear CDP neighbors on all the interfaces.

```
<HUAWEI> cdp clear neighbor  
Warning: This command will clear CDP neighbor information of all the ports. Continue? [Y/N]:y
```

## Related Topics

- [16.3.20 lldp enable \(system view\)](#)
- [16.3.19 lldp enable \(interface view\)](#)
- [16.3.16 lldp compliance cdp receive](#)

## 16.3.3 display cdp local

### Function

The **display cdp local** command displays local CDP information on a specified interface or all interfaces.

### Format

```
display cdp local [ interface interface-type interface-number ]
```

## Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type</i> <i>interface-number</i>	<p>Displays the CDP local information on a specified interface.</p> <ul style="list-style-type: none"> <li><i>interface-type</i> specifies the interface type.</li> <li><i>interface-number</i> specifies the interface number.</li> </ul> <p>If this parameter is not specified, the command displays CDP local information on all the interfaces.</p>	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

To check CDP information on a specified interface or all interfaces, run the **display cdp local** information.

### Prerequisites

LLDP has been enabled globally using the **lldp enable (system view)** command, and LLDP compatibility with CDP has been enabled on the specified interface using the **lldp compliance cdp receive** command.

## Example

# Display CDP local information on all the interfaces.

```
<HUAWEI> display cdp local
Remote Table Statistics:
-----
Remote Table Last Change Time :0 days, 23 hours, 21 minutes, 37 seconds
Remote Neighbors Added       :0
Remote Neighbors Deleted     :0
Remote Neighbors Dropped     :0
Remote Neighbors Aged        :0
Total Neighbors               :1

Port information:
-----
Interface GigabitEthernet0/0/1:
CDP Status       :enabled       (default is disabled)
Total Neighbors  :1
Interface GigabitEthernet0/0/2:
CDP Status       :enabled       (default is disabled)
Total Neighbors  :0
---- More ----
```

**Table 16-30** Description of the **display cdp local** command output.

Item	Description
Remote Table Statistics	Statistics about CDP neighbors.
Remote Table Last Change Time	Time of the latest update of the CDP neighbor table.
Remote Neighbors Added	Number of added CDP neighbors.
Remote Neighbors Deleted	Number of deleted CDP neighbors.
Remote Neighbors Dropped	Number of CDP neighbors that are deleted because of insufficient storage memory.
Remote Neighbors Aged	Number of CDP neighbors that are deleted by the aging mechanism.
Total Neighbors	Total number of CDP neighbors.
Port information	Local CDP information on all interfaces of the switch.
Interface <i>x</i>	Local CDP information on the <i>x</i> interface.
CDP Status	Whether LLDP compatibility with CDP is enabled on the interface: <ul style="list-style-type: none"><li>• enabled</li><li>• disabled</li></ul> You can run the <b>lldp compliance cdp receive</b> command to configure this parameter.
Total Neighbors	Total number of CDP neighbors on the interface.

## 16.3.4 display cdp neighbor

### Function

The **display cdp neighbor** command displays information about CDP neighbors of all interfaces or a specified interface.

### Format

```
display cdp neighbor [ interface interface-type interface-number ]
```

## Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type</i> <i>interface-number</i>	<p>Displays information about CDP neighbors of a specified interface.</p> <ul style="list-style-type: none"> <li><i>interface-type</i> specifies the interface type.</li> <li><i>interface-number</i> specifies the interface number.</li> </ul> <p>If this parameter is not specified, the command displays information about CDP neighbors of all interfaces.</p>	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

This command enables you to know which CDP neighbors the local device has, Layer 2 information about the neighbors, and to which interfaces the neighbors connect. You can also use this command to check whether the Layer 2 information is configured correctly on the neighbors.

### Prerequisites

LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command, and LLDP compatibility with CDP has been enabled on the specified interface using the [16.3.16 lldp compliance cdp receive](#) command.

## Example

# Display information about CDP neighbors of all the interfaces.

```
<HUAWEI> display cdp neighbor
GigabitEthernet0/0/1 has 1 neighbor(s):

Neighbor index :1
Device ID      :ME3400
Port ID       :GigabitEthernet0/4
Version       :SCCP75.8-3-3SR2S
Platform      :cisco ME-3400EG-2CS-A
Capabilities   :Host phone
MacAddress     :b4a4-e3cf-e984
Discovered time :0 days, 22 hours, 33 minutes, 36 seconds
Expired time   :122
Power drawn    :12000 mw
Power request ID :39308
Power management ID :2
Power request levels :12000 mw 0 mw
---- More ----
```



**Table 16-31** Description of the **display cdp neighbor** command output

Item	Description
<i>m</i> has <i>n</i> neighbor(s)	The interface <i>m</i> has <i>n</i> CDP neighbors.
Neighbor index	Index of a CDP neighbor.
Device ID	ID of the CDP neighbor.
Port ID	Interface of the CDP neighbor connecting to the switch.
Version	Version of the CDP neighbor.
Platform	Software platform of the CDP neighbor.
Capabilities	Type fo the CDP neighbor: <ul style="list-style-type: none"> <li>• Host Phone: host and IP phone</li> <li>• Phone: IP phone</li> <li>• Host</li> </ul> If the CDP neighbor is neither a host nor an IP phone, the Capabilities field is not displayed.
MacAddress	MAC address of the CDP neighbor.
Discovered time	Time when the CDP neighbor was discovered, that is, the time difference between the system time when the device discovers the CDP neighbor and the startup time of the switch.
Expired time	The aging time remaining of CDP neighbor, in seconds.
Power drawn	Power set on the source.
Power request ID	Requested power ID.
Power management ID	ID used to manage power. The ID is the number of times the power is changed.
Power request levels	Requested power level. The maximum power among the negotiated power values is selected.

## Related Topics

[16.3.20 lldp enable \(system view\)](#)

## 16.3.5 display cdp neighbor brief

### Function

The **display cdp neighbor brief** command displays brief information about CDP neighbors of the device.

## Format

**display cdp neighbor brief**

## Parameters

None

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

You can run this command to quickly view brief information about CDP neighbors connected to a switch, such as CDP neighbor names and interfaces on which CDP neighbor relationships are set up.

### Prerequisites

LLDP has been enabled globally using the **lldp enable (system view)** command, and LLDP compatibility with CDP has been enabled on the specified interface using the **lldp compliance cdp receive** command.

## Example

# Display brief information about CDP neighbors.

```
<HUAWEI> display cdp neighbor brief
Local Intf  Neighbor Dev      Neighbor Intf      Exptime(s)
GE0/0/1    ME3400            GE0/0/4            144
```

**Table 16-32** Description of the **display cdp neighbor brief** command output

Item	Description
Local Intf	Local interface of the switch that sets up a CDP neighbor relationship with a peer device.
Neighbor Dev	Name of a CDP neighbor.
Neighbor Intf	Interface of a peer device that sets up a CDP neighbor relationship with the switch.
Exptime(s)	Time left before a CDP neighbor relationship expires, in seconds.

## Related Topics

- [16.3.20 lldp enable \(system view\)](#)
- [16.3.16 lldp compliance cdp receive](#)

## 16.3.6 display cdp statistics

### Function

The **display cdp statistics** command displays statistics about CDP packets received.

### Format

**display cdp statistics** [ **interface** *interface-type interface-number* ]

### Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type</i> <i>interface-number</i>	<p>Displays statistics about CDP packets received by a specified interface.</p> <ul style="list-style-type: none"> <li>• <i>interface-type</i> specifies the interface type.</li> <li>• <i>interface-number</i> specifies the interface number.</li> </ul> <p>If this parameter is not specified, the command displays statistics about CDP packets received by all the interfaces.</p>	-

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

#### Usage Scenario

When you need to locate an LLDP fault on a switch according to statistics about CDP packets received, run the **display cdp statistics** command.

#### NOTE

To check statistics about CDP packets received in a specified period of time, run the **reset cdp statistics** command to clear the historical CDP packet statistics. Wait for the specified period of time, and then run the **display cdp statistics** command to check the new CDP packet statistics.

#### Prerequisites

LLDP has been enabled globally using the **lldp enable (system view)** command, and LLDP compatibility with CDP has been enabled on the specified interface using the **lldp compliance cdp receive** command.

## Example

# Display statistics about CDP packets received by all interfaces.

```
<HUAWEI> display cdp statistics
CDP statistics global Information:
Statistics for GigabitEthernet0/0/1:
Total frames received: 30
Total frames discarded: 0
Total frames error: 0
Last cleared time: never
---- More ----
```

**Table 16-33** Description of the **display cdp statistics** command output

Item	Description
CDP statistics global Information	Statistics about CDP packets received by the switch.
Statistics for $x$	Statistics about CDP packets received by the $x$ interface.
Total frames received	Number of received CDP packets by this interface.
Total frames discarded	Number of discarded CDP packets by this interface.
Total frames error	Number of received CDP error packets by this interface.
Last cleared Time	Time when the statistics about CDP packets received on this interface are cleared last time: <ul style="list-style-type: none"><li>• If the statistics about CDP packets on this interface have been cleared, the time is displayed.</li><li>• If the statistics about CDP packets on this interface have never been cleared, <b>never</b> is displayed.</li></ul>

## Related Topics

[16.3.20 lldp enable \(system view\)](#)

[16.3.32 reset cdp statistics](#)

## 16.3.7 display lldp local

### Function

The **display lldp local** command displays global LLDP information or the LLDP information on a specified interface.

## Format

```
display lldp local [ interface interface-type interface-number ]
```

## Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type</i> <i>interface-number</i>	Displays the LLDP information on a specified interface. <ul style="list-style-type: none"><li>• <i>interface-type</i> specifies the interface type.</li><li>• <i>interface-number</i> specifies the interface number.</li></ul> If no interface is specified, the command displays LLDP information on all the interfaces with LLDP enabled.	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

The **display lldp local** command displays the global LLDP information or the LLDP information on an interface.

- The global LLDP information includes system information, MED system information, system configuration, and data statistics on the peer device.
- The LLDP information on an interface includes the interface information and MED interface information.

To verify the LLDP information and Layer 2 information of the system and interfaces, run this command.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

## Example

# Display the global LLDP information, S5720-56C-HI-AC is used as an example.

```
<HUAWEI> display lldp local  
System information
```

```
Chassis type :MAC address
Chassis ID :00e0-11fc-1710
System name :HUAWEI
System description :S5720-56C-HI-AC
Huawei Versatile Routing Platform Software
VRP (R) software,Version 5.170 (S5720 V200R011C10 )
Copyright (C) 2000-2015 HUAWEI TECH Co., Ltd.
System capabilities supported :bridge router
System capabilities enabled :bridge router
LLDP Up time :2015-01-22 13:29:26

MED system information
-----
Device class :Network Connectivity
(MED inventory information of master board)
HardwareRev :VER.B
FirmwareRev :NA
SoftwareRev :Version 5.1670 V200R011C10
SerialNum :NA
Manufacturer name :HUAWEI TECH Co., Ltd.
Model name :NA
Asset tracking identifier :NA

System configuration
-----
LLDP Status :enabled (default is enabled)
LLDP Message Tx Interval :30 (default is 30s)
LLDP Message Tx Hold Multiplier :4 (default is 4)
LLDP Refresh Delay :2 (default is 2s)
LLDP Tx Delay :2 (default is 2s)
LLDP Notification Interval :5 (default is 5s)
LLDP Notification Enable :enabled (default is enabled)
Management Address :IP:10.10.10.1 MAC:000b-09e6-3da1

Remote Table Statistics:
-----
Remote Table Last Change Time :0 days, 0 hours, 4 minutes, 15
seconds
Remote Neighbors Added :5
Remote Neighbors Deleted :0
Remote Neighbors Dropped :0
Remote Neighbors Aged :0
Total Neighbors :5

Port information:
-----
Interface GigabitEthernet0/0/1:
LLDP Enable Status :enabled (default is enabled)
Total Neighbors :1

Port ID subtype :Interface name
Port ID :GigabitEthernet0/0/1
Port description :GigabitEthernet0/0/1

Port and protocol VLAN ID(PPVID) :0
Port and protocol VLAN supported :No
Port and protocol VLAN enabled :No
Port VLAN ID(PVID) :1
VLAN name of VLAN 1: VLAN0001
Protocol identity :STP RSTP/MSTP LACP EthOAM CFM

Auto-negotiation supported :Yes
Auto-negotiation enabled :Yes
OperMau :speed(1000)/duplex(Full)

Power port class :PD
PSE power supported :No
PSE power enabled :No
PSE pairs control ability:No
```

```

Power pairs           :Unknown
Port power classification:Unknown

Link aggregation supported:Yes
Link aggregation enabled :No
Aggregation port ID   :0
Maximum frame Size    :1526

EEE support           :Yes
Transmit Tw           :16
Receive Tw            :16
Fallback Receive Tw   :65535
Echo Transmit Tw      :16
Echo Receive Tw       :16

MED port information

Media policy type     :Unknown
Unknown Policy        :Yes
VLAN tagged           :No
Media policy VlanID   :0
Media policy L2 priority :0
Media policy Dscp     :0

Power Type            :Unknown
PoE PSE power source  :Unknown
Port PSE Priority     :Unknown
Port Available power value:0.2(w)

---- More ----

```

**Table 16-34** Description of the **display lldp local** command output.

Item	Description
System information	Global LLDP information.
Chassis type	Type of the Device ID: <ul style="list-style-type: none"> <li>● Chassis component: chassis alias</li> <li>● Interface alias: interface alias</li> <li>● Port component: interface or backplane alias</li> <li>● MAC address: MAC address</li> <li>● Network address: network address</li> <li>● Interface name: name of the interface</li> <li>● Locally assigned: name of the local device</li> </ul>
Chassis ID	Device ID.
System name	Name of the device.
System description	Description of the device.
Huawei Versatile Routing Platform Software	-
VRP (R) software, Version	Versions of the VRP and the software of the device.
Copyright (C) 2000-2013 HUAWEI TECH Co., Ltd.	Huawei copyright.

Item	Description
System capabilities supported	Capabilities supported of the local device, including: <ul style="list-style-type: none"> <li>• bridge: bridge device</li> <li>• router: router</li> </ul>
System capabilities enabled	Capabilities enabled on the local device.
LLDP Up time	Time when LLDP is enabled.
MED system information	MED TLV information of the device.
Device class	Type of the device.
MED inventory information of master board	-
HardwareRev	Hardware version of the device.
FirmwareRev	Firmware version of the device.
SoftwareRev	Software version of the device.
SerialNum	Serial number of the device. <b>NOTE</b> If the decimal value of a serial number is not in the range of 32 to 126, the serial number is displayed in octal notation.
Manufacturer name	Name of the manufacturer
Model name	Name of a model.
Asset tracking identifier	Asset tracking ID.
System configuration	Global LLDP configuration.
LLDP Status	Whether LLDP is enabled globally on the switch: <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> You can run the <b>lldp enable (system view)</b> command to configure this parameter.
default is <i>x</i>	Default value <i>x</i> .
LLDP Message Tx Interval	Interval for sending LLDP packets of the device, in seconds. You can run the <b>lldp message-transmission interval</b> command to configure this parameter.



Item	Description
LLDP Message Tx Hold Multiplier	Hold time multiplier of local device information stored on neighbors. You can run the <b>lldp message-transmission hold-multiplier</b> command to configure this parameter.
LLDP Refresh Delay	Delay in re-enabling the LLDP function on the switch, in seconds. You can run the <b>lldp restart-delay</b> command to configure this parameter.
LLDP Tx Delay	Delay in sending LLDP packets on the switch, in seconds. You can run the <b>lldp message-transmission delay</b> command to configure this parameter.
LLDP Notification Interval	Delay in sending the neighbor change traps to the NMS on the switch, in seconds. You can run the <b>lldp trap-interval</b> command to configure this parameter.
LLDP Notification Enable	Whether the function of sending LLDP traps to the NMS is enabled on the switch: <ul style="list-style-type: none"> <li>• enabled</li> <li>• disabled</li> </ul> You can run the <b>16.3.34 snmp-agent trap enable feature-name lldptrap</b> command to configure this parameter.
Management Address	LLDP management address of the switch. You can run the <b>lldp management-address</b> command to configure this parameter. If an invalid management address is used, the inactive field is added for this address. For example, if 10.1.1.1 is an invalid management address, the displayed information is as follows: Management Address :IP:10.10.10.1, 10.1.1.1 (inactive) MAC: 000b-09e6-3da1
Remote Table Statistics	Statistics about LLDP neighbors.
Remote Table Last Change Time	Time that elapsed since the latest modification of remote data.
Remote Neighbors Added	Number of added LLDP neighbors.
Remote Neighbors Deleted	Number of deleted LLDP neighbors.
Remote Neighbors Dropped	Number of devices that do not set up LLDP neighbor relationships because the number of neighbors has reached the maximum value.

Item	Description
Remote Neighbors Aged	Number of LLDP neighbors that are aged out and deleted.
Total Neighbors	Number of LLDP neighbors.
Port information	LLDP information on the interface.
LLDP Enable Status	Whether LLDP is enabled on the interface: <ul style="list-style-type: none"> <li>• Enabled</li> <li>• Disabled</li> </ul> You can run the <b>lldp enable (system view)</b> and <b>lldp enable (interface view)</b> commands to configure this parameter.
Total Neighbors	Number of LLDP neighbors on the interface.
Port ID subtype	Type of the interface ID. <ul style="list-style-type: none"> <li>• Interface alias: interface alias</li> <li>• Port component: interface or backplane alias</li> <li>• MAC address: MAC address</li> <li>• Network address: network address</li> <li>• Interface name: name of the interface</li> <li>• Agent circuit ID: circuit ID of the DHCP agent</li> <li>• Locally assigned: name of the local device</li> </ul>
Port ID	Interface ID.
Port description	Interface description.
Port and protocol VLAN ID(PPVID)	Protocol VLAN ID of a port.
Port and protocol VLAN supported	Whether PPVID is supported: <ul style="list-style-type: none"> <li>• Yes: PPVID is supported.</li> <li>• No: PPVID is not supported.</li> </ul>
Port and protocol VLAN enabled	Whether PPVID is enabled: <ul style="list-style-type: none"> <li>• Yes: PPVID is enabled.</li> <li>• No: PPVID is disabled.</li> </ul>
Port VLAN ID(PVID)	The default VLAN ID of the interface.
VLAN name of VLAN 1	Name of VLAN 1.
Protocol identity	Protocol ID.

Item	Description
Auto-negotiation supported	Whether the interface supports auto-negotiation: <ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul> For details about Ethernet interfaces supporting the auto-negotiation function, see Licensing Requirements and Limitations for Ethernet Interfaces.
Auto-negotiation enabled	Whether the interface is enabled with auto-negotiation: <ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul> You can run the <b>negotiation auto</b> command to configure this parameter.
OperMau	Rate and duplex mode of the interface.
Power port class	PoE type of the interface: <ul style="list-style-type: none"> <li>• PSE: power-sourcing equipment</li> <li>• PD: powered device</li> </ul>
PSE power supported	Whether the PSE power is supported. <ul style="list-style-type: none"> <li>• Yes: PSE power is supported.</li> <li>• No: PSE power is not supported.</li> </ul>
PSE power enabled	Whether the PSE power is enabled. <ul style="list-style-type: none"> <li>• Yes: enabled.</li> <li>• No: disabled.</li> </ul>
PSE pairs control ability	Whether the PSE twisted pair control is supported. <ul style="list-style-type: none"> <li>• Yes: PSE twisted pair control is supported.</li> <li>• No: PSE twisted pair control is not supported.</li> </ul>
Power pairs	PoE remote power supply mode. <ul style="list-style-type: none"> <li>• Signal: power supply mode of signal lines</li> <li>• Spare: power supply mode of spare signal lines</li> <li>• Unknown: an unknown remote power supply mode</li> </ul>
Port power classification	PD power control level on the interface: <ul style="list-style-type: none"> <li>• Class0: indicates level 1.</li> <li>• Class1: indicates level 2.</li> <li>• Class2: indicates level 3.</li> <li>• Class3: indicates level 4.</li> <li>• Class4: indicates level 5.</li> <li>• Unknown: indicates an unknown level.</li> </ul>

Item	Description
Link aggregation supported	Whether the interface supports link aggregation. <ul style="list-style-type: none"> <li>• Yes: The interface supports link aggregation.</li> <li>• No: The interface does not support link aggregation.</li> </ul>
Link aggregation enabled	Whether link aggregation is enabled on the interface. <ul style="list-style-type: none"> <li>• Yes: enabled</li> <li>• No: disabled</li> </ul>
Aggregation port ID	ID of an aggregated interface, If link aggregation is disabled, the value of this field is 0.
Maximum frame Size	Maximum size of a frame supported by the interface. You can run the <b>jumboframe enable</b> command to configure this parameter.
EEE support	Whether the interface supports energy efficient Ethernet (EEE): <ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
Transmit Tw	Amount of time the sender waits before starting sending data after leaving lower power consumption mode(LPI mode).
Receive Tw	Amount of time the receiver expects the sender to wait before starting sending data after leaving LPI mode.
Fallback Receive Tw	Additional information provided to the sender.
Echo Transmit Tw	Transmit Tw value specified in the Echo message sent from the remote end.
Echo Receive Tw	Receive Tw value specified in the Echo message sent from the remote end.
MED port information	-

Item	Description
Media policy type	Type of the media policy: <ul style="list-style-type: none"> <li>• Voice.</li> <li>• Voice Signaling.</li> <li>• Guest Voice.</li> <li>• Guest Voice Signaling.</li> <li>• Softphone Voice.</li> <li>• Video Conferencing.</li> <li>• Streaming Video.</li> <li>• Video Signaling.</li> <li>• Unknown</li> </ul>
Unknown Policy	Whether the type of the media policy is unknown: <ul style="list-style-type: none"> <li>• Yes: unknown</li> <li>• Defined: known</li> <li>• Unknown: indicates that the Media policy VlanID, Media policy L2 priority and Media policy Dscp value fields are ignored.</li> </ul>
VLAN tagged	Whether to add tag to the packets of the voice VLAN. <ul style="list-style-type: none"> <li>• Yes: Adds a VLAN tag to packets of the voice VLAN.</li> <li>• No: Not to add a VLAN tag to packets of the voice VLAN.</li> </ul>
Media policy VlanID	ID of the voice VLAN.
Media policy L2 priority	802.1p priority.
Media policy Dscp	DSCP value.
Power Type	Power supply type. Layer 3 interfaces do not support PoE TLV, so this parameter is not displayed on Layer 3 interfaces.
PoE PSE power source	Type of the PSE: <ul style="list-style-type: none"> <li>• Primary: indicates primary power supply.</li> <li>• Backup: indicates backup power supply.</li> <li>• Unknown: indicates power supply of an unknown type.</li> </ul> Layer 3 interfaces do not support PoE TLV, so this parameter is not displayed on Layer 3 interfaces.

Item	Description
Port PSE Priority	PSE priority of an interface: <ul style="list-style-type: none"><li>• Unknown: indicates an unknown priority.</li><li>• Critical: indicates the highest priority.</li><li>• High: indicates the medium priority.</li><li>• Low: indicates the lowest priority.</li></ul> Layer 3 interfaces do not support PoE TLV, so this parameter is not displayed on Layer 3 interfaces.
Port Available power value	Port power supply. Layer 3 interfaces do not support PoE TLV, so this parameter is not displayed on Layer 3 interfaces.

## Related Topics

[16.3.20 lldp enable \(system view\)](#)

## 16.3.8 display lldp neighbor

### Function

The **display lldp neighbor** command displays information about neighboring device of all interfaces or a specified interface.

### Format

```
display lldp neighbor [ interface interface-type interface-number ]
```

## Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type</i> <i>interface-number</i>	<p>Displays information about neighboring devices of a specified interface.</p> <ul style="list-style-type: none"> <li>• <i>interface-type</i> specifies the interface type.</li> <li>• <i>interface-number</i> specifies the interface number.</li> </ul> <p>If no interface is specified, the command displays information about neighboring devices of all interfaces with LLDP enabled.</p>	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

Using this command, you can know which neighboring devices are connected to the local device, to which interfaces the neighboring devices are connected, layer 2 information about the neighbors, and whether LLDP configuration is correct.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

## Example

# Display information about neighbor devices of interfaces GigabitEthernet0/0/1.

```
<HUAWEI> display lldp neighbor interface gigabitethernet0/0/1
GigabitEthernet0/0/1 has 1 neighbor(s):
```

```
Neighbor index : 1
Chassis type  :MAC address
```

```
Chassis ID :00e0-11fc-1710
Port ID type :Interface name
Port ID :GigabitEthernet0/0/1
Port description :GigabitEthernet0/0/1
System name :HUAWEI
System description :S5720-56C-HI-AC
Huawei Versatile Routing Platform Software
VRP (R) software,Version 5.160 (S5720 V200R011C10)
Copyright (C) 2000-2015 HUAWEI TECH CO., LTD
System capabilities supported :bridge router
System capabilities enabled :bridge router
Management address type :ipv4
Management address value : 127.0.0.1
OID :0.6.15.43.6.1.4.1.2011.5.25.41.1.2.1.1.1.
Expired time :104s

Port VLAN ID(PVID) :1
Port and protocol VLAN ID(PPVID) :0
Port and protocol VLAN supported :No
Port and protocol VLAN enabled :No
VLAN name of VLAN 1: VLAN 0001
Protocol identity :

Auto-negotiation supported :Yes
Auto-negotiation enabled :Yes
OperMau :speed(1000)/duplex(Full)

Power port class :PD
PSE power supported :No
PSE power enabled :No
PSE pairs control ability:No
Power pairs :Unknown
Port power classification:Unknown
Power type :Type 2 PD
Power source :PSE
Power priority :Low
PD requested power value :60.0(w)
PSE allocated power value :60.0(w)
PD requested power mode A value :30.0(w)
PD requested power mode B value :30.0(w)
Power class :6
Power typex :Type 3 PSE
PSE allocated power mode A value :0.0(w)
PSE allocated power mode B value :0.0(w)
PSE maximum available power :0.0(w)
PSE power pairsx :Unknown
PSE Autoclass support :PSE does not supports Autoclass
PD 4PID :PD does not supports powering of both Modes
PD Load :PD is single-signature or dual-signature and power demand on Mode A and
Mode B are not electrically isolated
Autoclass completed :Autoclass idle
Autoclass request :Autoclass idle
Power down :Not power down

Link aggregation supported:Yes
Link aggregation enabled :No
Aggregation port ID :0
Maximum frame Size :9216

EEE support :Yes
Transmit Tw :16
Receive Tw :16
Fallback Receive Tw :65535
Echo Transmit Tw :16
Echo Receive Tw :16

MED Device information
Device class :Network Connectivity
```



```

HardwareRev      :VER.A
FirmwareRev      :NA
SoftwareRev      :Version 5.160 V200R011C10
SerialNum        :NA
Manufacturer name :HUAWEI TECH CO., LTD
Model name       :NA
Asset tracking identifier :NA

Media policy type :Voice
Unknown Policy    :Defined
VLAN tagged      :Yes
Media policy VlanID :0
Media policy L2 priority :6
Media policy Dscp :46

Power Type        :Unknown
PoE PSE power source :Unknown
Port PSE Priority :Unknown
Port Available power value:0.2(w)
    
```

**Table 16-35** Description of the **display lldp neighbor** command output

Item	Description
Neighbor index	Index of a neighbor.
Chassis type	ID sub-types of a neighboring device: <ul style="list-style-type: none"> <li>• Chassis component: chassis alias</li> <li>• Interface alias: interface alias</li> <li>• Port component: interface or backplane alias</li> <li>• MAC address: MAC address</li> <li>• Network address: network address</li> <li>• Interface name: name of the interface</li> <li>• Locally assigned: name of the local device</li> </ul>
Chassis Id	ID of a neighboring device.
Port ID type	ID sub-type of a neighboring interface: <ul style="list-style-type: none"> <li>• Interface alias: interface alias</li> <li>• Port component: interface or backplane alias</li> <li>• MAC address: MAC address</li> <li>• Network address: network address</li> <li>• Interface name: name of the interface</li> <li>• Agent circuit ID: circuit ID of the DHCP agent</li> <li>• Locally assigned: name of the local device</li> </ul>
Port Id	ID of a neighbor interface.
Port description	Description of a neighboring interface.
System name	System name of a neighboring device.
System description	Description of a neighboring device.

Item	Description
System capabilities supported	Capabilities of a neighboring device (at least one capability is supported): <ul style="list-style-type: none"> <li>● other: other capabilities</li> <li>● repeater: repeater</li> <li>● bridge: bridge device</li> <li>● wlanAccessPoint: wireless access point</li> <li>● router: router</li> <li>● telephone: wireless device</li> <li>● docsisCableDevice: management station</li> <li>● stationOnly: base station</li> </ul>
System capabilities enabled	Capabilities enabled on a neighboring device (This field is a subset of the system capabilities supported field, and at least one capability must be enabled). <ul style="list-style-type: none"> <li>● other: other capabilities</li> <li>● repeater: repeater</li> <li>● bridge: bridge device</li> <li>● wlanAccessPoint: wireless access point (AP)</li> <li>● router: router</li> <li>● telephone: wireless device</li> <li>● docsisCableDevice: management station</li> <li>● stationOnly: base station</li> </ul>
Management address value	Management address of a neighbor.
Management address	Management address of a neighbor.
OID	Neighbor management address OID.
Expired time	Aging time of a neighbor.
Port VLAN ID(PVID)	VLAN ID of an interface.
Port and protocol VLAN ID(PPVID)	Protocol VLAN ID of a port.
Port and protocol VLAN supported	Whether PPVID is supported: <ul style="list-style-type: none"> <li>● Yes: PPVID is supported.</li> <li>● No: PPVID is not supported.</li> </ul>
Port and protocol VLAN enabled	Whether PPVID is enabled: <ul style="list-style-type: none"> <li>● Yes: PPVID is enabled.</li> <li>● No: PPVID is disabled.</li> </ul>
VLAN name of VLAN 1	Name of VLAN 1.

Item	Description
Protocol identity	Protocol ID.
Auto-negotiation supported	Whether the interface supports auto-negotiation: <ul style="list-style-type: none"> <li>● Yes: Auto-negotiation is supported.</li> <li>● No: Auto-negotiation is not supported.</li> </ul>
Auto-negotiation enabled	Whether the interface is enabled with auto-negotiation: <ul style="list-style-type: none"> <li>● Yes: enabled.</li> <li>● No: disabled.</li> </ul>
OperMau	Transmission rate and duplex mode of the interface.
Power port class	PoE type: <ul style="list-style-type: none"> <li>● PSE: power-sourcing equipment.</li> <li>● PD: powered device.</li> </ul>
PSE power supported	Whether the PSE power is supported. <ul style="list-style-type: none"> <li>● Yes: PSE power is supported.</li> <li>● No: PSE power is not supported.</li> </ul>
PSE power enabled	Whether the PSE power is enabled. <ul style="list-style-type: none"> <li>● Yes: enabled.</li> <li>● No: disabled.</li> </ul>
PSE pairs control ability	Whether the PSE control is supported. <ul style="list-style-type: none"> <li>● Yes: PSE control is supported.</li> <li>● No: PSE control is not supported.</li> </ul>
Power pairs	PoE remote power supply mode. <ul style="list-style-type: none"> <li>● Signal: power supply mode of signal lines.</li> <li>● Spare: power supply mode of spare signal lines.</li> <li>● Unknown: an unknown remote power supply mode.</li> </ul>
Port power classification	PD power control level on the interface: <ul style="list-style-type: none"> <li>● Class0: indicates level 1.</li> <li>● Class1: indicates level 2.</li> <li>● Class2: indicates level 3.</li> <li>● Class3: indicates level 4.</li> <li>● Class4: indicates level 5.</li> <li>● Unknown: indicates an unknown control level.</li> </ul>

Item	Description
Power type	The power supply type: <ul style="list-style-type: none"> <li>● Type 1 PD: indicates the PD that does not support IEEE 802.3at.</li> <li>● Type 1 PSE: indicates the PSE that does not support IEEE 802.3at.</li> <li>● Type 2 PD: indicates the PD that supports IEEE 802.3at.</li> <li>● Type 2 PSE: indicates the PSE that supports IEEE 802.3at.</li> </ul>
Power source	The power supply source.
Power priority	The power supply priority of an interface: <ul style="list-style-type: none"> <li>● low</li> <li>● high</li> <li>● Critical</li> <li>● unknown</li> </ul>
PD requested power value	-
PSE allocated power value	-
PD requested power mode A value	-
PD requested power mode B value	-
Power class	<ul style="list-style-type: none"> <li>● When the power type is PD this field shall be set to the requested Class of the PD.</li> <li>● When the power type is PSE this field shall be set to the PSEs assigned Class.</li> </ul>
Power typex	<ul style="list-style-type: none"> <li>● Type 1 PSE</li> <li>● Type 1 PD</li> <li>● Type 2 PSE</li> <li>● Type 2 PD</li> <li>● Type 3 PSE</li> <li>● Type 3 single-signature PD</li> <li>● Type 4 PSE</li> <li>● Type 4 single-signature PD</li> <li>● Type 3 dual-signature PD</li> <li>● Type 4 dual-signature PD</li> </ul>
PSE allocated power mode A value	-

Item	Description
PSE allocated power mode B value	-
PSE maximum available power	The highest power the PSE can grant to the PD.
PSE power pairsx	The power supply modes that the PSE supports: <ul style="list-style-type: none"> <li>• Alternative A</li> <li>• Alternative B</li> <li>• Alternative A and Alternative B</li> <li>• Unknown</li> </ul>
PSE Autoclass support	Whether PSE supports Autoclass: <ul style="list-style-type: none"> <li>• PSE supports Autoclass</li> <li>• PSE does not support Autoclass</li> </ul>
PD 4PID	<ul style="list-style-type: none"> <li>• PD supports powering of both Modes</li> <li>• PD does not support powering of both Modes</li> </ul>
PD Load	<ul style="list-style-type: none"> <li>• PD is dual-signature and power demand on Mode A and Mode B are electrically isolated</li> <li>• PD is single-signature or dual-signature and power demand on Mode A and Mode B are not electrically isolated</li> </ul>
Autoclass completed	Whether Autoclass is completed: <ul style="list-style-type: none"> <li>• Autoclass measurement completed</li> <li>• Autoclass idle</li> </ul>
Autoclass request	Whether the interface has received Autoclass request: <ul style="list-style-type: none"> <li>• PD requests Autoclass measurement</li> <li>• Autoclass idle</li> </ul>
Power down	Whether the interface powers down.
Link aggregation supported	Whether link aggregation is supported on the interface. <ul style="list-style-type: none"> <li>• Yes: The interface supports link aggregation.</li> <li>• No: The interface does not support link aggregation.</li> </ul>
Link aggregation enabled	Whether link aggregation is enabled on an interface. <ul style="list-style-type: none"> <li>• Yes: The interface supports link aggregation.</li> <li>• No: The interface does not support link aggregation.</li> </ul>

Item	Description
Aggregation port ID	ID of an aggregated interface, If link aggregation is disabled, the value of this field is 0.
Maximum frame Size	Maximum size of a frame supported by the interface.
EEE support	Whether the interface supports energy efficient Ethernet (EEE).
Transmit Tw	Amount of time the sender waits before starting sending data after leaving lower power consumption mode(LPI mode).
Receive Tw	Amount of time the receiver expects the sender to wait before starting sending data after leaving LPI mode.
Fallback Receive Tw	Additional information provided to the sender.
Echo Transmit Tw	Transmit Tw value specified in the Echo message sent from the remote end.
Echo Receive Tw	Receive Tw value specified in the Echo message sent from the remote end.
Device class	Type of the MED device.
HardwareRev	Hardware version of the device.
FirmwareRev	Firmware version of the device.
SoftwareRev	Software version of the device.
SerialNum	Serial number of the device. <b>NOTE</b> If the decimal value of a serial number is not in the range of 32 to 126, the serial number is displayed in octal notation.
Manufacturer name	Name of the manufacturer.
Model name	Name of a model.
Asset tracking identifier	Asset tracking ID.

Item	Description
Media policy type	Type of the media policy: <ul style="list-style-type: none"> <li>• Voice.</li> <li>• Voice Signaling.</li> <li>• Guest Voice.</li> <li>• Guest Voice Signaling.</li> <li>• Softphone Voice.</li> <li>• Video Conferencing.</li> <li>• Streaming Video.</li> <li>• Video Signaling.</li> <li>• unknown indicates that the type of the media policy is unknown.</li> </ul>
Unknown Policy	Whether the type of the media policy is unknown: <ul style="list-style-type: none"> <li>• Yes: unknown</li> <li>• Defined: known</li> <li>• Unknown: indicates that the Media policy VlanID, Media policy L2 priority and Media policy Dscp value fields are ignored.</li> </ul>
VLAN tagged	Whether to add tag to the packets of the voice VLAN.
Media policy VlanID	ID of the voice VLAN.
Media policy L2 priority	Layer 2 priority.
Media policy Dscp	DSCP value.
Power Type	Power supply type: <ul style="list-style-type: none"> <li>• PSE: power-sourcing equipment.</li> <li>• PD: powered device.</li> <li>• Unknown: an unknown power supply type.</li> </ul>
PoE PSE power source	Type of the PSE: <ul style="list-style-type: none"> <li>• Primary: indicates primary power supply.</li> <li>• Backup: indicates backup power supply.</li> <li>• Unknown: indicates power supply of an unknown type.</li> </ul>
Port PSE Priority	PSE priority of an interface: <ul style="list-style-type: none"> <li>• Unknown: indicates an unknown priority.</li> <li>• Critical: indicates the highest priority.</li> <li>• High: indicates the medium priority.</li> <li>• Low: indicates the lowest priority.</li> </ul>

Item	Description
Port Available power value	Port power supply

## Related Topics

[16.3.20 lldp enable \(system view\)](#)

## 16.3.9 display lldp neighbor brief

### Function

The **display lldp neighbor brief** command displays brief information about neighbors of the device.

### Format

**display lldp neighbor brief**

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

To quickly view brief information about the LLDP neighbors of a switch and the interfaces connected to neighbors, run this command.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

## Example

# Display brief information about LLDP neighbors of the switch.

```
<HUAWEI> display lldp neighbor brief
Local Intf  Neighbor Dev      Neighbor Intf      Exptime(s)
GE0/0/1    Huawei            GE0/0/1            103
```



**Table 16-36** Description of the **display lldp neighbor brief** command output

Item	Description
Local Intf	Local interface on which the LLDP neighbor relationship is established with a peer device.
Neighbor Dev	Name of an LLDP neighbor.
Neighbor Intf	Interface of a peer device on which the LLDP neighbor relationship is established.
Exptime	Time left before an LLDP neighbor relationship expires, in seconds.

## Related Topics

[16.3.8 display lldp neighbor](#)

[16.3.20 lldp enable \(system view\)](#)

## 16.3.10 display lldp statistics

### Function

The **display lldp statistics** command displays statistics about LLDP packets sent and received by all or a specified interface.

### Format

**display lldp statistics** [ **interface** *interface-type interface-number* ]

### Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type interface-number</i>	<p>Displays statistics about LLDP packet sent and received by a specified interface.</p> <ul style="list-style-type: none"> <li>• <i>interface-type</i> specifies the interface type.</li> <li>• <i>interface-number</i> specifies the interface number.</li> </ul> <p>If no interface is specified, the command displays statistics about LLDP packets on all interfaces.</p>	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

To display the LLDP packet statistics within a specified period of time, run the **reset lldp statistics** command to clear the existing statistics first, and then run the **display lldp statistics** command to display the new statistics.

### Prerequisites

The LLDP function has been enabled globally and on the interface using the **lldp enable (system view)** and **lldp enable (interface view)** commands.

### Precautions

1. LLDP has been enabled globally using the **16.3.20 lldp enable (system view)** command.
2. LLDP has been enabled on the interface using the **16.3.19 lldp enable (interface view)** command.

## Example

# Display the statistics about LLDP packets sent and received by all interfaces.

```
<HUAWEI> display lldp statistics
LLDP statistics global Information:
Statistics for GigabitEthernet0/0/1:
Transmitted Frames Total: 2839
Received Frames Total: 2728   Frames Discarded Total: 0
Frames Error Total: 0       TLVs Discarded Total: 0
TLVs Unrecognized Total: 0   Neighbors Expired Total: 0
```

**Table 16-37** Description of the **display lldp statistics** command output

Item	Description
LLDP statistics global Information	Statistics about LLDP packets.
Statistics for <i>x</i>	Statistics about LLDP packets received and sent by the <i>x</i> interface.
Transmitted Frames Total	Number of sent LLDP packets.
Received Frames Total	Number of received LLDP packets.
Frames Discarded Total	Number of discarded LLDP packets.
Frames Error Total	Number of received errored LLDP packets.

Item	Description
TLVs Discarded Total	Number of discarded TLVs.
TLVs Unrecognized Total	Number of unknown TLVs.
Neighbors Expired Total	Number of aged-out neighbors.

## Related Topics

[16.3.20 lldp enable \(system view\)](#)

[16.3.33 reset lldp statistics](#)

## 16.3.11 display lldp tlv-config

### Function

The **display lldp tlv-config** command displays optional TLVs that can be sent with LLDP packets on all or a specified interface.

### Format

**display lldp tlv-config** [ **interface** *interface-type interface-number* ]

### Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type interface-number</i>	<p>Displays optional TLVs supported by a specified interface.</p> <ul style="list-style-type: none"> <li><i>interface-type</i> specifies the interface type.</li> <li><i>interface-number</i> specifies the interface number.</li> </ul> <p>If no interface is specified, the command displays optional TLVs on all interfaces.</p>	-

### Views

All views

### Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

The **display lldp tlv-config** command displays the TLVs supported by the specified interface or all interfaces, and thus you can know whether the required TLVs are enabled and unneeded TLVs are disabled.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

## Example

# Display Optional TLVs that can be sent with LLDP packets on GigabitEthernet0/0/1.

```
<HUAWEI> display lldp tlv-config interface gigabitethernet 0/0/1
```

```
LLDP tlv-config of port [GigabitEthernet0/0/1]:
```

```
-----
Name                Status  Default
-----
Basic optional TLV:
-----
Port Description TLV      Yes     Yes
System Name TLV          Yes     Yes
System Description TLV   Yes     Yes
System Capabilities TLV  Yes     Yes
Management Address TLV   Yes     Yes

IEEE 802.1 extend TLV:
-----
Port VLAN ID TLV         Yes     Yes
Port And Protocol VLAN ID TLV  Yes     Yes
VLAN Name TLV            Yes     Yes
Protocol Identity TLV     No      No

IEEE 802.3 extend TLV:
-----
MAC-Physic TLV          Yes     Yes
Power Via MDI TLV        Yes     Yes
Link Aggregation TLV     Yes     Yes
Maximum Frame Size TLV   Yes     Yes
EEE TLV                  Yes     Yes

LLDP-MED extend TLV:
-----
Capabilities TLV         Yes     Yes
Extended Power Via MDI TLV  Yes     Yes
Inventory TLV            Yes     Yes
Network Policy TLV       Yes     Yes
Location Identification TLV  No      No
```

**Table 16-38** Description of the display lldp tlv-config command output

Item	Description
Name	Type of TLV.

Item	Description
Status	Whether the interface is configured to send the TLVs of the specified type.
Default	Whether the TLVs of the specified types are sent on an interface by default.
Basic optional TLV	Basic TLVs that can be sent on an interface.
Port Description TLV	Interface description TLV.
System Name TLV	System name TLV.
System Description TLV	System description TLV.
System Capabilities TLV	TLV indicating the system capability set.
Management Address TLV	Management address TLV.
IEEE 802.1 extend TLV	Type of the IEEE 802.1 organizational-specific TLVs that can be sent on an interface.
Port VLAN ID TLV	PVID TLV.
Port And Protocol VLAN ID TLV	Port and protocol VLAN ID TLV.
VLAN Name TLV	VLAN name TLV.
Protocol Identity TLV	Protocol ID TLV.
IEEE 802.3 extend TLV	IEEE 802.3 organizational-specific TLVs that can be sent on an interface.
MAC-Physic TLV	TLV indicating physical attributes of an interface.
Power Via MDI TLV	Power capability TLV.
Link Aggregation TLV	Link aggregation TLV.
Maximum Frame Size TLV	Maximum frame length TLV.
LLDP-MED extend TLV	LLDP MED TLV.
Capabilities TLV	TLV indicating MED capability sets.
Extended Power Via MDI TLV	TLV indicating the extended power supply capabilities.
Inventory TLV	Inventory information, including Hardware Revision TLV, Firmware Revision TLV, Software Revision TLV, Serial Number TLV, Manufacturer Name TLV, Model name TLV, and Asset id TLV.
Network Policy TLV	Network policy TLV.

Item	Description
Location Identification TLV	Location ID TLV.
EEE TLV	EEE capability TLV.

## 16.3.12 display snmp-agent trap feature-name lldptrap all

### Function

The **display snmp-agent trap feature-name lldptrap all** command displays whether the switch is enabled to send traps of LLDP feature to the NMS.

### Format

**display snmp-agent trap feature-name lldptrap all**

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

Before running the **display snmp-agent trap feature-name lldptrap all** command, run the **snmp-agent** command to enable the SNMP Agent function.

### Example

# Display whether the switch is enabled to send traps of LLDP feature to the NMS.

```
<HUAWEI> display snmp-agent trap feature-name lldptrap all
-----
Feature name: LLDPTRAP
Trap number : 5
-----
Trap name           Default switch status  Current switch status
lldpRemTablesChange    on                    on
hwLldpEnabled         on                    on
hwLldpDisabled        on                    on
hwLldpLocManIPAddrChange on                    on
hwLldpRateExcessive   on                    on
```

**Table 16-39** Description of the **display snmp-agent trap feature-name lldptrap all** command output

Item	Description
Feature name	Name of the feature that generates traps.
Trap number	Number of traps generated by LLDP feature.
Trap name	Name of the trap. The LLDP feature supports the following traps: <ul style="list-style-type: none"> <li>• lldpRemTablesChange: Sends a trap when LLDP neighbor information changes.</li> <li>• hwLldpEnabled: Sends a Huawei proprietary trap when the LLDP function is enabled globally.</li> <li>• hwLldpDisabled: Sends a Huawei proprietary trap when the LLDP function is disabled globally.</li> <li>• hwLldpLocManIPAddrChange: Sends a Huawei proprietary trap when the LLDP management address of the device changes.</li> <li>• hwLldpRateExcessive: Sends a Huawei proprietary trap when the rate of LLDPDUs received by an interface exceeds the trap threshold.</li> </ul>
Default switch status	Default status of a trap: <ul style="list-style-type: none"> <li>• on: The switch is enabled to send this trap to the NMS.</li> <li>• off: The switch is disabled to send this trap to the NMS.</li> </ul>
Current switch status	Current status of a trap: <ul style="list-style-type: none"> <li>• on: The switch is enabled to send this trap to the NMS.</li> <li>• off: The switch is disabled to send this trap to the NMS.</li> </ul> <p>This status can be configured using the <a href="#">snmp-agent trap enable feature-name lldptrap</a> command.</p>

## Related Topics

[16.3.34 snmp-agent trap enable feature-name lldptrap](#)

## 16.3.13 ip domain-name

### Function

The **ip domain-name** command adds a suffix to a device name.

The **undo ip domain-name** command deletes the suffix of a device name.

By default, a device name does not have a suffix.

 NOTE

Only the S1720GFR, S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S2750EI, S5700LI, S5700S-LI, S5710-X-LI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S6720LI, S6720S-LI, S6720SI, and S6720S-SI support this command.

## Format

**ip domain-name** *domain-name*

**undo ip domain-name**

## Parameters

Parameter	Description	Value
<i>domain-name</i>	Specifies the suffix of a device name.	The value is a string of 1 to 255 characters without spaces. It contains digits, letters, hyphens (-), underscores (_), and dots (.).

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

A device name and a suffix form a fully qualified domain name (FQDN). If you need to add a suffix to a device name, run the **ip domain-name** command. In this situation, the System Name TLV in an LLDP packet is in "device name.suffix" format. For example, if the device name is **HUAWEI** and suffix is **area1**, the System Name TLV in an LLDP packet is **HUAWEI.area1**.

### Precautions

If you run this command multiple times, only the latest configuration takes effect.

## Example

# Set the device name suffix to **area1**.

```
<HUAWEI> system-view
[HUAWEI] ip domain-name area1
```



## 16.3.14 lldp auto-vlan sensor ap

### Function

The **lldp auto-vlan sensor ap** command configures a switch to identify Huawei fit APs using LLDP and adds the interfaces receiving the LLDP packets from APs to the specified VLAN.

The **undo lldp auto-vlan** command disables this function.

By default, this function is disabled.

### Format

**lldp auto-vlan** *vlan-id* **sensor ap**

**undo lldp auto-vlan**

### Parameters

Parameter	Description	Value
<i>vlan-id</i>	Indicates the VLAN to which the interfaces receiving LLDP packets from APs are added.	The value is an integer that ranges from 1 to 4094.

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

When a switch is connected to Huawei fit APs, the interfaces connected to APs must be added to the AP's management VLAN in untagged mode. If many APs are connected to the switch, the configuration is complex. To facilitate operation, run the **lldp auto-vlan *vlan-id* sensor ap** command to enable the switch to automatically add the interfaces receiving LLDP packets from APs to the AP's management VLAN in untagged mode.

#### Prerequisites

LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.

#### Precautions

The VLAN specified in the command can be an existing VLAN or created after this command is executed, but cannot be the control VLAN for SEP/RRPP/ERPS.

After an interface receiving LLDP packets is added to the specified VLAN, the PVID on the interface becomes invalid. To view VLAN information on the interfaces, run the **display port vlan** [ *interface interface-number* | **active** ] command. After the LLDP neighbor relationships on the interfaces are aged out (for example, the APs go offline), the original PVIDs become valid.

## Example

# Add the interfaces receiving LLDP packets from Huawei fit APs to VLAN 100.

```
<HUAWEI> system-view
[HUAWEI] vlan 100
[HUAWEI-vlan100] quit
[HUAWEI] lldp enable
[HUAWEI] lldp auto-vlan 100 sensor ap
```

## Related Topics

[16.3.20 lldp enable \(system view\)](#)

## 16.3.15 lldp clear neighbor

### Function

The **lldp clear neighbor** command clears LLDP neighbors in the system or on an interface of the device.

### Format

**lldp clear neighbor** [ **interface** *interface-type interface-number* ]

### Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type interface-number</i>	<p>Indicates the type and number of the interface whose LLDP neighbors to be cleared. In the command:</p> <ul style="list-style-type: none"> <li>• <i>interface-type</i> specifies the interface type.</li> <li>• <i>interface-number</i> specifies the interface number.</li> </ul> <p>If no interface is specified, this command clears LLDP neighbors on all interfaces.</p>	-

## Views

User view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

If you want to obtain the latest LLDP neighbor information of interfaces, use the **lldp clear neighbor** command to clear existing LLDP neighbors. When an interface receives new LLDP packets, new LLDP neighbors are generated.

### Prerequisites

LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.

## Example

```
# Clear LLDP neighbors of all interfaces.
```

```
<HUAWEI> lldp clear neighbor  
Warning: This command will clear the neighbor information of all the ports. Continue? [Y/N]:y
```

## Related Topics

- [16.3.7 display lldp local](#)
- [16.3.8 display lldp neighbor](#)
- [16.3.9 display lldp neighbor brief](#)
- [16.3.19 lldp enable \(interface view\)](#)
- [16.3.20 lldp enable \(system view\)](#)

## 16.3.16 lldp compliance cdp receive

### Function

The **lldp compliance cdp receive** command enables CDP-compatible LLDP on an interface.

The **undo lldp compliance cdp receive** command disables CDP-compatible LLDP on an interface.

By default, CDP-compatible LLDP is disabled on an interface.

### Format

**lldp compliance cdp receive**

**undo lldp compliance cdp receive**

## Parameters

None

## Views

MEth interface view, Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

Neighbors may use other proprietary protocols but LLDP, for example, CDP. To ensure that the local device can discover and identify the neighbors, you can use this command to enable CDP-compatible LLDP on an interface.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

### Precautions

An Ethernet interface supports this command no matter whether it works in Layer 2 or Layer 3 mode.

## Example

```
# Enable CDP-compatible LLDP on GigabitEthernet0/0/1.
```

```
<HUAWEI> system-view  
[HUAWEI] interface GigabitEthernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] lldp compliance cdp receive
```

## Related Topics

[16.3.20 lldp enable \(system view\)](#)

[16.3.19 lldp enable \(interface view\)](#)

## 16.3.17 lldp compliance cdp txrx

### Function

The **lldp compliance cdp txrx** command enables an interface to exchange information with CDP-capable devices.

The **undo lldp compliance cdp txrx** command disables an interface from exchanging information with CDP-capable devices.

By default, an interface cannot exchange information with CDP-capable devices.

## Format

**lldp compliance cdp txrx**  
**undo lldp compliance cdp txrx**

## Parameters

None

## Views

MEth interface view, Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

Some IP phones send proprietary protocol packets but not DHCP packets to apply for IP addresses. After you run the **lldp compliance cdp txrx** command on an interface, the switch can identify proprietary protocol packets sent from such the IP phone connected to the interface and respond to the proprietary protocol packets. In addition, the switch assigns the voice VLAN configured on the LLDP module to the IP phone.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

### Precautions

An Ethernet interface supports this command no matter whether it works in Layer 2 or Layer 3 mode.

When a switch connects the IP phones of some vendors, you are advised to run the **lldp tlv-enable med-tlv network-policy voice-vlan vlan *vlan-id*** command to specify the voice VLAN ID in the MED TLVs advertised from the interface.

## Example

# Enable GigabitEthernet0/0/1 to exchange information with CDP-capable voice devices.

```
<HUAWEI> system-view
[HUAWEI] interface GigabitEthernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] lldp tlv-enable med-tlv network-policy voice-vlan vlan 10
[HUAWEI-GigabitEthernet0/0/1] lldp compliance cdp txrx
```

## 16.3.18 lldp dot3-tlv power

### Function

The **lldp dot3-tlv power** command sets the standard to which the 802.3 Power Via MDI TLV sent by an interface conforms.

The **undo lldp dot3-tlv power** command restores the default configuration.

By default, the 802.3 Power Via MDI TLV conforms to 802.1 ab.

### Format

```
lldp dot3-tlv power { 802.1ab | 802.3at }
```

```
undo lldp dot3-tlv power 802.3at
```

### Parameters

Parameter	Description	Value
<b>802.1ab</b>	Indicates that the 802.3 Power Via MDI TLV sent by the interface conforms to 802.1 ab.	-
<b>802.3at</b>	Indicates that the 802.3 Power Via MDI TLV sent by the interface conforms to 802.3 at.	-

### Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The 802.3 Power Via MDI TLV has the following formats:

- 802.1 ab format: [ TLV type | TLV information string length | 802.3 OUI | MDI power support | PSE power pair | power class ]
- 802.3 at format: [ TLV type | TLV information string length | 802.3 OUI | MDI power support | PSE power pair | power class | type/source/priority | PD requested power value | PSE allocated power value ]

Based on 802.1 ab, 802.3 at extends three fields: type/source/priority, PD requested power value, and PSE allocated power value.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

### Precautions

Before selecting a format of the 802.3 Power via MDI TLV, you must know the TLV format supported by the neighbors. The TLV format on the local device must be the same as that on the neighbors. You are advised to retain the default configuration of the switch. That is, interfaces send 802.3 Power via MDI TLV conforming to 802.1 ab. The switch can then adapt to 802.3 Power via MDI TLV conforming to 802.1ab or 802.3at based on the remote device and correctly communicates with the remote device.

An Ethernet interface supports the **lldp dot3-tlv power** command no matter whether it works in Layer 2 or Layer 3 mode.

## Example

```
# Configure the interface to send the 802.3 Power Via MDI TLV conforming to 802.3 at.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] lldp dot3-tlv power 802.3at
```

## Related Topics

- [16.3.7 display lldp local](#)
- [16.3.20 lldp enable \(system view\)](#)
- [16.3.19 lldp enable \(interface view\)](#)

## 16.3.19 lldp enable (interface view)

### Function

The **lldp enable** command enables LLDP on an interface.

The **undo lldp enable** command disables LLDP on an interface.

After LLDP is enabled in the system view, all interfaces are enabled with LLDP.

### Format

```
lldp enable  
undo lldp enable
```

### Parameters

None

## Views

MEth interface view, Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

After LLDP is enabled on an interface, the interface exchanges LLDP packets with LLDP-enabled neighbors. The interface receives status information from the neighbors and sends the local status information to the neighbors. The NMS then obtains the status information for topology discovery.

### Prerequisites

LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.

### Precautions

LLDP can be enabled in the system view and the interface view.

- After LLDP is enabled in the system view, all interfaces are enabled with LLDP.
- After LLDP is disabled in the system view, all LLDP settings are restored to the default settings except the setting of LLDP trap. Therefore, LLDP is also disabled on all interfaces.
- An interface can send and receive LLDP packets only after LLDP is enabled in both the system view and the interface view.
- After LLDP is disabled globally, the commands for enabling and disabling LLDP on an interface do not take effect.
- If LLDP needs to be disabled on some interfaces, enable LLDP globally first, and run the **undo lldp enable** command on these interfaces. To re-enable LLDP on these interfaces, run the **lldp enable** command in the views of these interfaces.

The **lldp enable (interface view)** command can be executed only on an Ethernet interface, regardless of whether it works at Layer 2 or Layer 3 mode, but not on a logical interface such as a VLANIF or Eth-Trunk interface. For an Eth-Trunk interface, LLDP can only be enabled on its member interfaces. LLDP-enabled interfaces and LLDP-disabled interfaces can exist in the same Eth-Trunk.

## Example

```
# Disable LLDP on GigabitEthernet0/0/1.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] undo lldp enable
```

## Related Topics

[16.3.7 display lldp local](#)



### 16.3.20 lldp enable (system view)

## 16.3.20 lldp enable (system view)

### Function

The **lldp enable** command enables LLDP globally.

The **undo lldp enable** command disables LLDP globally.

By default, LLDP is enabled globally.

### Format

**lldp enable**

**undo lldp enable**

### Parameters

None

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

To view the Layer 2 link status or analyze network topology, run the **lldp enable** command.

#### Configuration Impact

After LLDP is enabled globally, the device sends its own status information to LLDP-enabled neighbors and receives the status information from the neighbors.

#### Precautions

After the global LLDP is disabled, the LLDP configuration is deleted from all interfaces.

The interval between enabling LLDP globally and disabling LLDP cannot be shorter than 10 seconds; otherwise, an error message is displayed.

LLDP can be enabled in the system view and the interface view.

- After LLDP is enabled in the system view, all interfaces are enabled with LLDP.
- After LLDP is disabled in the system view, all LLDP settings are restored to the default settings except the setting of LLDP trap. Therefore, LLDP is also disabled on all interfaces.

- An interface can send and receive LLDP packets only after LLDP is enabled in both the system view and the interface view.
- After LLDP is disabled globally, the commands for enabling and disabling LLDP on an interface do not take effect.

For the device running a version earlier than V200R011C10SPC200:

- By default, LLDP is disabled globally, and the configuration file does not have the **undo lldp enable** configuration. After the device is upgraded to V200R011C10SPC200 or a later version, the configuration file has the **undo lldp enable** configuration.
- If **lldp enable** has been executed to enable LLDP globally, the configuration file has the **lldp enable** configuration. After the device is upgraded to V200R011C10SPC200 or a later version, the configuration file no longer has the **lldp enable** configuration.

The status of global LLDP does not change after the device is upgraded.

## Example

# Enable LLDP globally.

```
<HUAWEI> system-view
[HUAWEI] lldp enable
```

# Disable LLDP globally.

```
<HUAWEI> system-view
[HUAWEI] undo lldp enable
Warning: This command will delete the configurations of LLDP on all the ports.Continue?[Y/N]:y
```

## 16.3.21 lldp management-address

### Function

The **lldp management-address** command configures the LLDP management IP address.

The **undo lldp management-address** command restores the default setting.

By default, the system automatically obtains the management IP address.

### Format

**lldp management-address** *ip-address*

**undo lldp management-address**

### Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the management IP address.	The value is in dotted decimal notation.

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The management IP address is carried in the management address TLV field of the LLDP packet. It is used by the NMS to identify and manage devices. A management address identifies a device, facilitating the layout of the network topology and network management. To allocate a management address to a neighbor, run the **lldp management-address** command.

### Prerequisites

LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.

The management IP address to be allocated must be a valid unicast IP address existing on the device. And the interface configured with the IP address must not be bound to any VPN instance.

### Configuration Impact

After the configuration, the management IP address is added to the management address TLV field of the LLDP packet. The NMS then identifies the device according to the management IP address.

### Precautions

If no management address is configured or an invalid management address is configured, the system sets an IP address in the address list as the management address. The system selects the IP address in the following sequence: loopback interface address, management port address, VLANIF interface address, VBDIF interface address, Layer 3 Ethernet interface address, and Sub-interface. Among the IP addresses of the same type, the system selects the smallest one. If the system fails to find a management IP address, the bridge MAC address is used as the management address.

## Example

```
# Set the LLDP management IP address to 10.10.10.1.
```

```
<HUAWEI> system-view  
[HUAWEI] lldp management-address 10.10.10.1
```

## Related Topics

[16.3.7 display lldp local](#)

[16.3.20 lldp enable \(system view\)](#)

## 16.3.22 lldp message-transmission delay

### Function

The **lldp message-transmission delay** command sets the LLDP packet transmission delay.

The **undo lldp message-transmission delay** command restores the default LLDP packet transmission delay.

By default, the LLDP packet transmission delay is 2 seconds.

### Format

**lldp message-transmission delay** *delay*

**undo lldp message-transmission delay** [ *delay* ]

### Parameters

Parameter	Description	Value
<i>delay</i>	Specifies the LLDP packet transmission delay.	The value is an integer ranging from 1 to 8192, in seconds. The default value is 2 seconds. The <i>delay</i> value depends on the <i>interval</i> value in <b>lldp message-transmission interval</b> . The <i>delay</i> value must be equal to or smaller than a quarter of the <i>interval</i> value.

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

There is a delay before the interface sends an LLDP packet to the neighbor when the device status changes frequently. After the LLDP packet transmission delay is set on the device, the LLDP-enabled interfaces send LLDP packets to neighbors after a delay (the delay is the same as or longer than the delay you specified). The interfaces may send LLDP packets at different time points.

If the device status changes frequently, extend the delay in preventing the device from frequently sending packets to the neighbors. A delay suppresses the network topology flapping.

### Prerequisites

LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.

### Configuration Impact

The LLDP packet transmission delay must be set properly and adjusted according to network loads.

- A large value reduces the LLDP packet transmission frequency when the local device status frequently changes. This helps save system resources. However, if the value is too large, the device cannot notify neighbors of its status in a timely manner, and the NMS cannot discover the network topology changes in real time.
- A small value increases the LLDP packet transmission frequency and enables the NMS to discover network topology changes in real time when the local device status frequently changes. However, if the value is too small, LLDP packets are exchanged frequently, increasing the system load.
- The default value is recommended.

### Precautions

Consider the value of *interval* when adjusting the value of *delay* because it is restricted by the value of *interval*.

- The value of *delay* ranges from 1 to 8192.
- The value of *delay* must be smaller than or equal to a quarter of *interval*. Therefore, if you want to set *delay* to be greater than a quarter of *interval*, first increase the *interval* value to four times the new *delay* value, and then increase the *delay* value.

#### NOTE

If the *interval* value is smaller than four times the *delay* value, the system displays an error message when you run the **undo lldp message-transmission delay** command. To run the **undo lldp message-transmission delay** command in this case, increase the *interval* value to at least four times the *delay* value first.

## Example

```
# Set the LLDP packet transmission delay to 5 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] lldp message-transmission delay 5
```

## Related Topics

[16.3.7 display lldp local](#)

[16.3.20 lldp enable \(system view\)](#)

[16.3.24 lldp message-transmission interval](#)

## 16.3.23 lldp message-transmission hold-multiplier

### Function

The **lldp message-transmission hold-multiplier** command sets the hold time multiplier of device information stored on neighbors.

The **undo lldp message-transmission hold-multiplier** command restores the default hold time multiplier of device information stored on neighbors.

The default hold time multiplier is 4.

### Format

**lldp message-transmission hold-multiplier** *hold*

**undo lldp message-transmission hold-multiplier** [*hold*]

### Parameters

Parameter	Description	Value
<i>hold</i>	Specifies the hold time multiplier of device information on neighbors.	The value is an integer ranging from 2 to 10. The default value is 4.

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The time multiplier is used to calculate how long a packet can be saved on a neighboring node. After receiving an LLDP packet, a neighbor updates the aging time of the device information from the sender based on the TTL.

The storage time calculation formula is:  $TTL = \text{Min} (65535, (interval \times hold))$ .

TTL is the device information storage time. It is the smaller value between 65535 and  $(interval \times hold)$ .

*interval* indicates the interval at which the device sends LLDP packets to neighbors. This parameter is set by **lldp message-transmission interval**. *hold* indicates the hold time multiplier of device information on neighbors.

After the LLDP function is disabled on the device, its neighbors wait until the TTL of the device information expires, and then delete the device information. This prevents network topology flapping.

### Prerequisites

LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.

### Configuration Impact

The hold time multiplier of device information on neighbors must be set to a proper value.

- A large value of *hold* prevents network topology flapping. However, if the value is too large, the device cannot notify neighbors of its status in a timely manner, and the NMS cannot discover the network topology changes in real time.
- A small value of *hold* enables the NMS to discover topology change in time. However, if the value is too small, the neighbors update device information too frequently. This increases the load on the system and wastes resources.
- The default value is recommended.

## Example

```
# Set the hold time multiplier of device information on neighbors to 5.
```

```
<HUAWEI> system-view  
[HUAWEI] lldp message-transmission hold-multiplier 5
```

## Related Topics

[16.3.7 display lldp local](#)

[16.3.20 lldp enable \(system view\)](#)

[16.3.24 lldp message-transmission interval](#)

## 16.3.24 lldp message-transmission interval

### Function

The **lldp message-transmission interval** command sets the LLDP transmission interval.

The **undo lldp message-transmission interval** command restores the default LLDP transmission interval.

The default LLDP transmission interval is 30 seconds.

### Format

**lldp message-transmission interval** *interval*

**undo lldp message-transmission interval** [ *interval* ]

## Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the LLDP transmission interval.	The value is an integer ranging from 5 to 32768, in seconds. The default value is 30 seconds.  The <i>interval</i> value depends on the <i>delay</i> value in <b>lldp message-transmission delay</b> . The value of <i>interval</i> must be equal to or greater than four times the value of <i>delay</i> . Otherwise, an error occurs in the configuration.

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

When the LLDP status of the device keeps unchanged or the device does not discover new neighbors, the interface sends LLDP packets to the neighbors at a certain interval. After the LLDP transmission interval is set on the device, the LLDP enabled interfaces send LLDP packets to neighbors at this interval. The interfaces may send LLDP packets at different time points.

If you want to change the network topology detection frequency, run the **lldp message-transmission interval** command to change the LLDP transmission interval.

### Prerequisites

LLDP has been enabled globally using the **16.3.20 lldp enable (system view)** command.

### Configuration Impact

The LLDP transmission interval must be set properly and adjusted according to network loads.

- A large value reduces the LLDP packet transmission frequency. This helps save system resources. However, if the value is too large, the device cannot notify neighbors of its status in a timely manner, and the NMS cannot discover the network topology changes in real time.



- A short interval increases the LLDP packet transmission frequency and enables the NMS to discover network topology changes in real time. However, if the interval is too short, LLDP packets are exchanged frequently, increasing the system load.

### Precautions

Consider the value of *delay* when adjusting the value of *interval* because it is restricted by the value of *delay*.

- The value of *interval* ranges from 5 to 32768.
- The value of *interval* must be equal to or greater than four times the value of *delay*. Therefore, if you want to set *interval* to be smaller than four times the value of *delay*, first reduce the *delay* value to be equal to or smaller than a quarter of the new *interval* value, and then reduce the *interval* value.

### NOTE

If the *delay* value is greater than a quarter of the *interval* value, the system displays an error message when you run the **undo lldp message-transmission interval** command. To run the **undo lldp message-transmission interval** command in this case, reduce the *delay* value to be equal to or smaller than a quarter of *interval* first.

## Example

```
# Set the LLDP transmission interval to 35 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] lldp message-transmission interval 35
```

## Related Topics

- [16.3.7 display lldp local](#)
- [16.3.20 lldp enable \(system view\)](#)
- [16.3.22 lldp message-transmission delay](#)

## 16.3.25 lldp restart-delay

### Function

The **lldp restart-delay** command sets the delay in re-enabling the LLDP function on an interface.

The **undo lldp restart-delay** command restores the default delay in re-enabling the LLDP function on an interface.

The default delay is 2 seconds.

### Format

**lldp restart-delay** *delay*

**undo lldp restart-delay** [*delay*]

## Parameters

Parameter	Description	Value
<i>delay</i>	Specifies the delay in re-enabling the LLDP function on an interface.	The value is an integer ranging from 1 to 10, in seconds. The default value is 2 seconds.

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

There is a delay before LLDP is re-enabled on an interface. The delay suppresses the topology flapping caused by the frequent LLDP status changes.

### Prerequisites

LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.

### Configuration Impact

The delay in re-enabling the LLDP function on an interface must be set properly.

- A large value of *delay* prevents network topology flapping. However, if the value is too large, the device cannot notify neighbors of its status in a timely manner, and the NMS cannot discover the network topology changes in real time.
- A small value of *delay* enables the NMS to discover topology change in time. However, if the value is too small, the neighbors update device information too frequently. This increases the load on the system and wastes resources.
- The default value is recommended.

## Example

# Set the delay in re-enabling the LLDP function on an interface to 3 second.

```
<HUAWEI> system-view  
[HUAWEI] lldp restart-delay 3
```

## Related Topics

[16.3.7 display lldp local](#)

[16.3.20 lldp enable \(system view\)](#)

## 16.3.26 lldp tlv-enable (MEth interface view)

### Function

The **lldp tlv-enable** command sets the TLVs that can be sent by the MEth interface.

The **undo lldp tlv-enable** command sets the TLVs disabled on the MEth interface.

By default, the MEth interface can advertise all TLVs except the Location Identification TLV.

### Format

```
lldp tlv-enable basic-tlv { all | management-address | port-description |  
system-capability | system-description | system-name }
```

```
lldp tlv-enable med-tlv { all | capability | inventory | location-id { civic-address  
device-type country-code { ca-type ca-value } & <1-10> | elin-address Tel-  
Number } }
```

```
undo lldp tlv-enable basic-tlv { all | management-address | port-description |  
system-capability | system-description | system-name }
```

```
undo lldp tlv-enable med-tlv { all | capability | inventory | location-id [ civic-  
address | elin-address ] }
```

### Parameters

Parameter	Description	Value
<b>all</b>	Indicates to advertise all basic TLV.	-
<b>management-address</b>	Indicates to advertise Management-address TLV.	-
<b>port-description</b>	Indicates to advertise Port Description TLV.	-
<b>system-capability</b>	Indicates to advertise System Capabilities TLV.	-
<b>system-description</b>	Indicates to advertise System Description TLV.	-
<b>system-name</b>	Indicates to advertise System Name TLV.	-
<b>all</b>	Indicates to advertise all MED TLVs except the Location Identification TLV.	-
<b>capability</b>	Indicates to advertise MED Capabilities TLV.	-

Parameter	Description	Value
<b>inventory</b>	Indicates to advertise Hardware Revision TLV, Firmware Revision TLV, Software Revision TLV, Serial Number TLV, Manufacturer Name TLV, Model Name TLV, and Asset ID TLV.	-
<b>location-id</b>	Indicates to advertise Location Identification TLV.	-
<b>civic-address</b> <i>device-type country-code</i> { <i>ca-type ca-value</i> } & <1-10>	Indicates to advertise the common address information of the network devices encapsulated in Location Identification TLV. <ul style="list-style-type: none"> <li><i>device-type</i> specifies the type of the device. The value is an integer that ranges from 0 to 2. 0 indicates that the device is a DHCP server. 1 indicates that the device is a switch. 2 indicates that the device is an MED endpoint.</li> <li><i>country-code</i> specifies the country code. For the value range, see ISO 3166.</li> <li>{ <i>ca-type ca-value</i> }&amp;&lt;1-10&gt; specifies the address information. <i>ca-type</i> specifies the type of address information. The value is an integer that ranges from 0 to 255. <i>ca-value</i> specifies the content of the address information. The value is a string of 1-250 characters. &lt;1-10&gt; indicates that the preceding parameters can be entered 10 times.</li> </ul>	-
<b>elin-address</b> <i>Tel-Number</i>	Advertises the emergency phone number encapsulated in Location Identification TLV.	The value is a string of 10 to 25 numerals. Each numeral ranges from 0 to 9.

## Views

MEth interface view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In LLDP, all device information is encapsulated in Link Layer Discovery Protocol data units (LLDPDUs), which are then sent to neighbors. An LLDPDU contains a variety of TLVs. In a TLV, T indicates the information type, L indicates the information length, and V indicates the value or the content to be sent.

Devices exchange LLDPDUs carrying TLVs to obtain neighbor information. LLDPDUs supported by the management interface includes basic TLVs and MED TLVs.

Devices on both ends can have different TLV types configured. You only need to configure TLV types according to networking requirements.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

### Precautions

- If the **all** parameter is not specified, all the available TLVs of the specified type can be advertised except the Location Identification TLV. If the **all** parameter is not specified, only one type of TLV can be advertised. To advertise multiple types of TLVs, run this command multiple times.
- You can specify the other types of MED TLVs only after specifying the MED Capabilities TLV.  
To disable the MED Capabilities TLV, first disable the other types of MED TLVs.

## Example

```
# Configure The MEth interface to advertise the MED Capabilities TLV.
```

```
<HUAWEI> system-view  
[HUAWEI] interface meth 0/0/1  
[HUAWEI-METh0/0/1] lldp tlv-enable med-tlv capability
```

## Related Topics

[16.3.20 lldp enable \(system view\)](#)

## 16.3.27 lldp tlv-enable basic-tlv

### Function

The **lldp tlv-enable basic-tlv** command sets the basic TLVs that can be sent by an interface.

The **undo lldp tlv-enable basic-tlv** command set the basic TLVs disabled on an interface.

By default, an interface can advertise all basic TLVs.

## Format

```
lldp tlv-enable basic-tlv { all | management-address | port-description |  
system-capability | system-description | system-name }
```

```
undo lldp tlv-enable basic-tlv { all | management-address | port-description |  
system-capability | system-description | system-name }
```

## Parameters

Parameter	Description	Value
<b>all</b>	Indicates to advertise all basic TLVs.	-
<b>management-address</b>	Indicates to advertise Management-address TLV.	-
<b>port-description</b>	Indicates to advertise Port Description TLV.	-
<b>system-capability</b>	Indicates to advertise System Capabilities TLV.	-
<b>system-description</b>	Indicates to advertise System Description TLV.	-
<b>system-name</b>	Indicates to advertise System Name TLV.	-

## Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In LLDP, all device information is encapsulated in Link Layer Discovery Protocol data units (LLDPDUs), which are then sent to neighbors. An LLDPDU contains a variety of TLVs. In a TLV, T indicates the information type, L indicates the information length, and V indicates the value or the content to be sent.

Devices exchange LLDPDUs carrying TLVs to obtain neighbor information. The TLVs that can be encapsulated in an LLDP packet include basic TLVs, TLVs in the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs.

Basic TLVs are essential for managing network devices. The TLVs in the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs are defined by standardization organizations and other organizations, which are used to enhance the network device management. You can determine whether to advertise the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs.

Devices on both ends can have different TLV types configured. You only need to configure TLV types according to networking requirements.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

### Precautions

If the **all** parameter is not specified, only one type of TLV can be advertised. To advertise multiple types of TLVs, run this command multiple times.

An Ethernet interface supports this command no matter whether it works in Layer 2 or Layer 3 mode.

## Example

# Configure GigabitEthernet0/0/1 to advertise all basic TLVs.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] lldp tlv-enable basic-tlv all
```

## Related Topics

- [16.3.20 lldp enable \(system view\)](#)
- [16.3.11 display lldp tlv-config](#)

## 16.3.28 lldp tlv-enable dot1-tlv

### Function

The **lldp tlv-enable dot1-tlv** command sets to advertise TLVs defined by the IEEE 802.1 working group.

The **undo lldp tlv-enable dot1-tlv** command sets the TLVs defined by the IEEE 802.1 working group disabled on an interface.

By default, an interface advertises all TLVs defined by the IEEE 802.1 working group, except Protocol Identity TLV.

## Format

**lldp tlv-enable dot1-tlv** { **all** | **port-vlan-id** | **protocol-vlan-id** [ *vlan-id* ] | **vlan-name** [ *vlan-id* ] | **protocol-identity** }

**undo lldp tlv-enable dot1-tlv** { **all** | **port-vlan-id** | **protocol-vlan-id** [ *vlan-id* ] | **vlan-name** [ *vlan-id* ] | **protocol-identity** }

## Parameters

Parameter	Description	Value
<b>all</b>	Indicates to advertise all TLVs defined by the IEEE 802.1 working group.	-
<b>port-vlan-id</b>	Indicates to advertise Port VLAN ID TLV. The VLAN ID is the default VLAN ID on the interface.	-
<b>protocol-vlan-id</b> [ <i>vlan-id</i> ]	Indicates to advertise Port And Protocol VLAN ID TLV. If <i>vlan-id</i> is not specified, the interface does not support protocol VLAN TLVs.	The value of <i>vlan-id</i> is an integer that ranges from 1 to 4094.
<b>vlan-name</b> [ <i>vlan-id</i> ]	Indicates to advertise VLAN Name TLV. If <i>vlan-id</i> is not specified, the default VLAN ID is used.	The value of <i>vlan-id</i> is an integer that ranges from 1 to 4094.
<b>protocol-identity</b>	Indicates to advertise Protocol Identity TLV.	-

## Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In LLDP, all device information is encapsulated in Link Layer Discovery Protocol data units (LLDPDUs), which are then sent to neighbors. An LLDPDU contains a variety of TLVs. In a TLV, T indicates the information type, L indicates the information length, and V indicates the value or the content to be sent.



Devices exchange LLDPDUs carrying TLVs to obtain neighbor information. The TLVs that can be encapsulated in an LLDP packet include basic TLVs, TLVs in the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs.

Basic TLVs are essential for managing network devices. The TLVs in the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs are defined by standardization organizations and other organizations, which are used to enhance the network device management. You can determine whether to advertise the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs.

Devices on both ends can have different TLV types configured. You only need to configure TLV types according to networking requirements.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

### Precautions

If the **all** parameter is not specified, only one type of TLV can be advertised. To advertise multiple types of TLVs, run this command multiple times.

#### NOTE

An Ethernet interface working in Layer 3 mode does not support the TLVs defined in IEEE802.1.

## Example

```
# Configure GigabitEthernet0/0/1 to advertise the port VLAN TLV in the IEEE 802.1 format.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] lldp tlv-enable dot1-tlv port-vlan-id
```

## Related Topics

- [16.3.20 lldp enable \(system view\)](#)
- [16.3.11 display lldp tlv-config](#)

## 16.3.29 lldp tlv-enable dot3-tlv

### Function

The **lldp tlv-enable dot3-tlv** command sets to advertise the TLVs defined by the IEEE 802.3 working group.

The **undo lldp tlv-enable dot3-tlv** command sets the TLVs defined by the IEEE 802.3 working group disabled on an interface.

By default, an interface advertises all TLVs defined by the IEEE 802.3 working group.

## Format

**lldp tlv-enable dot3-tlv { all | eee | link-aggregation | mac-physic | max-frame-size | power }**

**undo lldp tlv-enable dot3-tlv { all | eee | link-aggregation | mac-physic | max-frame-size | power }**

## Parameters

Parameter	Description	Value
<b>all</b>	Indicates to advertise all TLVs defined by the IEEE 802.3 working group.	-
<b>eee</b>	Indicates to advertise EEE (Energy Efficient Ethernet) TLV. EEE is supported only when the switch has only one neighbor.	-
<b>link-aggregation</b>	Indicates to advertise Link Aggregation TLV.	-
<b>mac-physic</b>	Indicates to advertise MAC/PHY Configuration/Status TLV.	-
<b>max-frame-size</b>	Indicates to advertise Maximum Frame Size TLV.	-
<b>power</b>	Indicates to advertise Power Via MDI TLV.	-

## Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In LLDP, all device information is encapsulated in Link Layer Discovery Protocol data units (LLDPDUs), which are then sent to neighbors. An LLDPDU contains a variety of TLVs. In a TLV, T indicates the information type, L indicates the information length, and V indicates the value or the content to be sent.

Devices exchange LLDPDUs carrying TLVs to obtain neighbor information. The TLVs that can be encapsulated in an LLDP packet include basic TLVs, TLVs in the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs.

Basic TLVs are essential for managing network devices. The TLVs in the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs are defined by standardization organizations and other organizations, which are used to enhance the network device management. You can determine whether to advertise the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs.

Devices on both ends can have different TLV types configured. You only need to configure TLV types according to networking requirements.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

### Precautions

If the **all** parameter is not specified, only one type of TLV can be advertised. To advertise multiple types of TLVs, run this command multiple times.

An Ethernet interface supports this command no matter whether it works in Layer 2 or Layer 3 mode.

## Example

```
# Configure GigabitEthernet0/0/1 to advertise the Link Aggregation TLV in the IEEE 802.3 format.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] lldp tlv-enable dot3-tlv link-aggregation
```

## Related Topics

- [16.3.20 lldp enable \(system view\)](#)
- [16.3.11 display lldp tlv-config](#)

## 16.3.30 lldp tlv-enable med-tlv

### Function

The **lldp tlv-enable med-tlv** command sets to advertise the MED TLVs.

The **undo lldp tlv-enable med-tlv** command sets the MED TLVs disabled on an interface.

By default, an interface advertises all types of MED TLVs except the Location Identification TLV and Network Policy TLV.

#### NOTE

Although the interface does not advertise Network Policy TLV, Network Policy TLV is still enabled.

## Format

**lldp tlv-enable med-tlv** { **all** | **capability** | **inventory** | **location-id** { **civic-address** *device-type country-code* { *ca-type ca-value* } &<1-10> | **elin-address** *Tel-Number* } | **network-policy** [ **voice-vlan** { **vlan** *vlan-id* [ **cos** *cvalue* | **dscp** *dvalue* ]\* | **8021p** [ **cos** *cvalue* | **dscp** *dvalue* ]\* | **untagged** } ] | **power-over-ethernet** }

**undo lldp tlv-enable med-tlv** { **all** | **capability** | **inventory** | **location-id** [ **civic-address** | **elin-address** ] | **network-policy** [ **voice-vlan** { **vlan** | **cos** | **dscp** | **8021p** | **untagged** } ] | **power-over-ethernet** }

## Parameters

Parameter	Description	Value
<b>all</b>	Indicates that all MED TLVs except Location Identification TLV and Network Policy TLV are advertised. <b>NOTE</b> After the <b>all</b> parameter is specified, the Network Policy TLV is enabled, but not advertised.	-
<b>capability</b>	Indicates to advertise MED Capabilities TLV.	-
<b>inventory</b>	Indicates to advertise Hardware Revision TLV, Firmware Revision TLV, Software Revision TLV, Serial Number TLV, Manufacturer Name TLV, Model Name TLV, and Asset ID TLV.	-
<b>location-id</b>	Indicates to advertise Location Identification TLV.	-

Parameter	Description	Value
<b>civic-address</b> <i>device-type country-code</i> { <i>ca-type ca-value</i> } & <1-10>	<p>Indicates to advertise the common address information of the network devices encapsulated in Location Identification TLV.</p> <ul style="list-style-type: none"> <li>• <i>device-type</i> specifies the type of the device. The value is an integer that ranges from 0 to 2. 0 indicates that the device is a DHCP server. 1 indicates that the device is a switch. 2 indicates that the device is an MED endpoint.</li> <li>• <i>country-code</i> specifies the country code. For the value range, see ISO 3166.</li> <li>• { <i>ca-type ca-value</i> }&amp;&lt;1-10&gt; specifies the address information. <i>ca-type</i> specifies the type of address information. The value is an integer that ranges from 0 to 255. <i>ca-value</i> specifies the content of the address information. The value is a string of 1-250 characters. &lt;1-10&gt; indicates that the preceding parameters can be entered 10 times.</li> </ul>	-
<b>elin-address</b> <i>Tel-Number</i>	Advertises the emergency phone number encapsulated in Location Identification TLV.	The value is a string of 10 to 25 numerals. Each numeral ranges from 0 to 9.
<b>network-policy</b>	<p>Advertises Network Policy TLV. Network Policy TLV is used to exchange VLAN configurations between network devices and terminal devices. A switch uses the TLV to advertise voice VLAN ID and voice stream priority to an IP phone. Then the IP phone forwards packets according to the received voice VLAN ID and priority, ensuring the voice quality.</p> <p><b>NOTE</b> An Ethernet interface working in Layer 3 mode does not support the Network Policy TLV.</p>	-

Parameter	Description	Value
<b>voice-vlan</b>	Encapsulates the voice VLAN ID when advertising Network Policy TLV.	-
<b>vlan</b> <i>vlan-id</i>	Specifies the voice VLAN ID.	The value is an integer that ranges from 1 to 4094.
<b>cos</b> <i>cvalue</i>	Specifies the CoS priority. The CoS priority is the PRI (Priority) field in an 802.1Q VLAN frame. This field is 3 bits long and ensures that high-priority data packets are forwarded first when congestion occurs.	The value is an integer that ranges from 0 to 7. The default value is 5. A larger value indicates a higher priority.
<b>dscp</b> <i>dvalue</i>	Sets the DSCP priority. The first six bits of the Type of Service (ToS) field in an IPv4 packet header are used as the DiffServ Code Point (DSCP). DSCP is used in the DiffServ model to provide QoS guarantee on an IP network. The operations performed by the traffic controller on the gateway are determined only by these six bits.	The value is an integer that ranges from 0 to 63. The default value is 46.
<b>8021p</b>	Sets the voice VLAN ID to VLAN 0.	-
<b>untagged</b>	Configures voice devices to send untagged voice data packets.	-
<b>power-over-ethernet</b>	Advertises Extended Power via MDI TLV.	-

## Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In LLDP, all device information is encapsulated in Link Layer Discovery Protocol data units (LLDPDUs), which are then sent to neighbors. An LLDPDU contains a variety of TLVs. In a TLV, T indicates the information type, L indicates the information length, and V indicates the value or the content to be sent. Devices exchange LLDPDUs carrying TLVs to obtain neighbor information. The TLVs that can be encapsulated in an LLDP packet include basic TLVs, TLVs in the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs. Basic TLVs are essential for managing network devices. The TLVs in the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs are defined by standardization organizations and other organizations, which are used to enhance the network device management. You can determine whether to advertise the IEEE 802.1 format, TLVs in the IEEE 802.3 format, and MED TLVs.

Devices on both ends can have different TLV types configured. You only need to configure TLV types according to networking requirements.

### Prerequisites

1. LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.
2. LLDP has been enabled on the interface using the [16.3.19 lldp enable \(interface view\)](#) command.

### Precautions

- When the supported TLVs are MED TLVs, the **lldp tlv-enable** command with the **all** parameter advertises all TLVs except Location Identification TLV. If the **all** parameter is not specified, only one type of TLV can be advertised. To advertise multiple types of TLVs, run this command multiple times.
- You can specify the other types of MED TLVs only after specifying the MED Capabilities TLV. To disable the MED Capabilities TLV, first disable the other types of MED TLVs.
- To disable the 802.3 MAC/PHY Configuration/Status TLVs, first disable the MED Capabilities TLV.
- The 802.3 MAC/PHY Configuration/Status TLVs are automatically advertised after the MED Capabilities TLV is advertised.
- If you disable the MED TLVs using the command with the **all** parameter, the 802.3 MAC/PHY Configuration/Status TLVs are not disabled automatically.
- When the switch detects that the LLDP packet sent by an LLDP neighbor on an interface contains any type of MED TLV, the switch advertises all MED TLVs that can be advertised on the interface to the LLDP neighbor. However, the LLDP neighbor may support only parts of MED TLVs advertised by the switch, leading to an LLDP negotiation failure. You can run the **undo lldp tlv-enable med-tlv** command to enable the interface not to advertise the MED TLV that is not supported by the LLDP neighbor. For example, if a terminal does not support the 802.3af standard, that is, Extended Power-via-MDI TLV cannot be identified, run the **undo lldp tlv-enable med-tlv power-over-ethernet** command on the interface connected to the terminal to enable the interface not to advertise Extended Power-via-MDI TLV.

## Example

```
# Configure GigabitEthernet0/0/1 to advertise the MED Capabilities TLV.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] lldp tlv-enable med-tlv capability
```

## Related Topics

[16.3.20 lldp enable \(system view\)](#)

[16.3.11 display lldp tlv-config](#)

## 16.3.31 lldp trap-interval

### Function

The **lldp trap-interval** command sets the delay in sending neighbor change traps to the NMS.

The **undo lldp trap-interval** command restores the default delay in sending neighbor change traps to the NMS.

By default, the device sends a neighbor change trap to the NMS after a 5-second delay.

### Format

**lldp trap-interval** *interval*

**undo lldp trap-interval** [ *interval* ]

### Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the delay in sending traps.	The value is an integer ranging from 5 to 3600, in seconds. The default value is 5 seconds. The default value is recommended.

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

There is a delay before the device sends LLDP traps about neighbor information changes to the NMS. When neighbor information changes frequently, you can



prolong the delay. In this way, the device will not frequently send traps to the NMS, and the network topology flapping is suppressed.

#### Prerequisites

LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.

#### Configuration Impact

After the delay is set on the device, LLDP-enabled interfaces send LLDP traps to neighbors after a delay (the delay is the same as or longer than the delay you specified). The interfaces may send LLDP traps at different time points.

#### Precautions

The configured delay applies only to the trap, which reports changes in neighbor information, including the number of added neighbors, number of deleted neighbors, number of neighbors that are aged out, and number of neighbors of which the information is deleted.

### Example

```
# Set the delay in sending neighbor change traps to 6 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] lldp trap-interval 6
```

### Related Topics

[16.3.7 display lldp local](#)

[16.3.20 lldp enable \(system view\)](#)

## 16.3.32 reset cdp statistics

### Function

The **reset cdp statistics** command clears statistics about CDP packets that all interfaces receive and send or CDP packets that a specified interface receives and sends.

### Format

```
reset cdp statistics [ interface interface-type interface-number ]
```

## Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type</i> <i>interface-number</i>	Interface on which statistics about CDP packets are to be cleared. <ul style="list-style-type: none"><li>• <i>interface-type</i> specifies the interface type.</li><li>• <i>interface-number</i> specifies the interface number.</li></ul> If this parameter is not specified, CDP packet information about all interfaces is cleared.	-

## Views

User view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

If you want to quickly locate and process a CDP fault, you must calculate the numbers of CDP packets sent and received by a device for a specified period. Before collecting specific CDP packet statistics, you can run the **reset cdp statistics** command to clear existing statistics about CDP packets.

### Prerequisites

LLDP has been globally enabled using the **lldp enable** command in the system view and LLDP has been configured to be compatible with CDP on interfaces using the **lldp compliance cdp receive** command.

### Follow-up Procedure

After running the **reset cdp statistics** command to clear existing statistics about CDP packets, you can run the **display cdp statistics** command to check statistics about CDP packets sent and received by a device for a specific period.

### Precautions

If you do not set the **interface** parameter when running the **reset cdp statistics** command, statistics about CDP packets sent and received by all interfaces are cleared. Exercise caution when running this command.

## Example

```
# Display statistics about CDP packets that all interfaces receive and send.
```

```
<HUAWEI> reset cdp statistics
```

## Related Topics

[16.3.20 lldp enable \(system view\)](#)

[16.3.6 display cdp statistics](#)

## 16.3.33 reset lldp statistics

### Function

The **reset lldp statistics** command clears LLDP packet statistics on all interfaces or on a specified interface.

### Format

**reset lldp statistics** [ **interface** *interface-type interface-number* ]

### Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type interface-number</i>	<p>Specifies the type and number of the interface where the LLDP statistics you want to reset. In the command:</p> <ul style="list-style-type: none"><li>• <i>interface-type</i> specifies the interface type.</li><li>• <i>interface-number</i> specifies the interface number.</li></ul> <p>If no interface is specified, LLDP packet statistics of all interfaces are cleared.</p>	-

### Views

User view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

To troubleshoot LLDP faults, you may need to view LLDP packet statistics within a certain period of time. In this case, you must run the **reset lldp statistics** command to clear existing LLDP packet statistics, and run the [display lldp statistics](#) command to view the new LLDP packet statistics.

#### Prerequisites

LLDP has been enabled globally using the [16.3.20 lldp enable \(system view\)](#) command.

## Example

```
# Clear LLDP packet statistics on all interfaces.
```

```
<HUAWEI> reset lldp statistics  
Warning: This Command will clear LLDP statistics of all the ports. Continue? [Y/N]:y
```

```
# Clear LLDP packet statistics of GigabitEthernet0/0/1.
```

```
<HUAWEI> reset lldp statistics interface gigabitethernet 0/0/1
```

## Related Topics

[16.3.10 display lldp statistics](#)

[16.3.20 lldp enable \(system view\)](#)

## 16.3.34 snmp-agent trap enable feature-name lldptrap

### Function

The **snmp-agent trap enable feature-name lldptrap** command enables the LLDP trap function on the device.

The **undo snmp-agent trap enable feature-name lldptrap** command disables the LLDP trap function on the device.

By default, the LLDP trap function is enabled.

### Format

```
snmp-agent trap enable feature-name lldptrap [ trap-name { hwlldpdisabled |  
hwlldpenabled | hwlldplocmanipaddrchange | hwlldprateexcessive |  
lldpremtableschange } ]
```

```
undo snmp-agent trap enable feature-name lldptrap [ trap-name  
{ hwlldpdisabled | hwlldpenabled | hwlldplocmanipaddrchange |  
hwlldprateexcessive | lldpremtableschange } ]
```

### Parameters

Parameter	Description	Value
trap-name	Enables or disables the trap function for the specified event.	-
hwlldpdisabled	Sends a Huawei proprietary trap when the LLDP function is disabled globally.	-

Parameter	Description	Value
<b>hwlldpenabled</b>	Sends a Huawei proprietary trap when the LLDP function is enabled globally.	-
<b>hwlldplocmanipaddrchange</b>	Sends a Huawei proprietary trap when the LLDP management address of the device changes.	-
<b>hwlldprateexcessive</b>	Sends a Huawei proprietary trap when the rate of LLDPDUs received by an interface exceeds the alarm threshold.  The alarm threshold is 5. That is, a trap is sent if more than 5 LLDPDUs are received by an interface within one second.	-
<b>lldpremtableschange</b>	Sends a trap when LLDP neighbor information changes.	-

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To enable the device to send traps when the LLDP status changes, run the **snmp-agent trap enable feature-name lldptrap** command.

### Prerequisites

A reachable route exists between the device and the NMS, and the SNMP parameters are set.

### Configuration Impact

After the LLDP trap function is enabled, the device sends traps to the NMS in one of the following cases:

- The LLDP function is enabled or disabled globally.
- The local management address changes.
- The rate of LLDPDUs received by an interface exceeds the alarm threshold.
- A neighbor is added, deleted, discarded, or aged out.

#### Precautions

The LLDP trap function applies to all interfaces.

If the network topology is unstable, disable the LLDP trap function to prevent frequent trap sending.

To set the interval between sending neighbor change traps to the NMS, run the **lldp trap-interval** command. If neighbor information changes frequently, extend the interval to reduce the number of traps.

### Example

```
# Enable the LLDP trap function on the device.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name lldptrap
```

### Related Topics

[16.3.12 display snmp-agent trap feature-name lldptrap all](#)

## 16.4 Performance Management Commands

[16.4.1 Command Support](#)

[16.4.2 binding](#)

[16.4.3 display pm brief](#)

[16.4.4 display pm measure-info](#)

[16.4.5 display pm statistics](#)

[16.4.6 display pm statistics-file](#)

[16.4.7 display pm statistics-task](#)

[16.4.8 display snmp-agent trap feature-name pm all](#)

[16.4.9 measure disable](#)

[16.4.10 path](#)

[16.4.11 pm](#)

[16.4.12 pm-server](#)

[16.4.13 protocol \(PM server view\)](#)

[16.4.14 record-file disable](#)

[16.4.15 record-interval](#)

[16.4.16 reset pm current-data](#)

- [16.4.17 retry](#)
- [16.4.18 sample-interval](#)
- [16.4.19 snmp-agent trap enable feature-name pm](#)
- [16.4.20 statistics enable](#)
- [16.4.21 statistics-cycle](#)
- [16.4.22 statistics-task](#)
- [16.4.23 threshold-alarm enable](#)
- [16.4.24 threshold-alarm measure](#)
- [16.4.25 upload](#)
- [16.4.26 upload auto](#)
- [16.4.27 upload-config](#)
- [16.4.28 username password](#)

## 16.4.1 Command Support

Performance management is only supported by the S5720HI, S6720SI, and S6720S-SI.

## 16.4.2 binding

### Function

The **binding** command binds an instance to a performance statistics collection task.

The **undo binding** command unbinds an instance from a performance statistics collection task.

By default, no instance is bound to a performance statistics collection task.

### Format

**binding instance-type** *instance-type* **all**

**binding instance-type** *instance-type* **instance** *instance-name* <1-5>

**undo binding instance-type** *instance-type* { **all** | **instance** *instance-name* <1-5> }

## Parameters

Parameter	Description	Value
<b>instance-type</b> <i>instance-type</i>	Specifies the type of an instance bound to a performance statistics collection task.	<p>The enumerated values include:</p> <ul style="list-style-type: none"> <li>● <b>ipfpm</b>: collects IP FPM statistics.</li> <li>● <b>uni-mng-as-port</b>: collects statistics on an AS port.</li> <li>● <b>wlan-ap</b>: collects AP statistics:</li> <li>● <b>wlan-radio</b>: collects statistics about a specified AP radio.</li> <li>● <b>wlan-ssid</b>: collects statistics about a service set bound to a specific AP radio.</li> <li>● <b>wlan-ap-wiredport</b>: collects statistics on an AP wired port.</li> </ul> <p><b>NOTE</b> The S6720SI and S6720S-SI only support the <b>uni-mng-as-port</b>.</p>
<b>all</b>	<p>Binds all instances.</p> <p>When <b>all</b> is specified, <i>instance-type</i> can only be <b>ipfpm</b>.</p>	-



Parameter	Description	Value
<b>instance</b> <i>instance-name</i>	Specifies the name of an instance of a specific type.	<p>The value is a string of 1 to 255 case-insensitive characters.</p> <ul style="list-style-type: none"> <li>When <i>instance-type</i> is <b>ipfpm</b>, the <i>instance-name</i> value is configured using the <b>instance (IPFPM-MCP view)</b> command.</li> <li>When <i>instance-type</i> is <b>uni-mng-as-port</b>, the <i>instance-name</i> value is AS name+interface number, for example, as1 gigabitethernet0/0/1.</li> <li>When <i>instance-type</i> is <b>wlan-ap</b>, the <i>instance-name</i> value is ap-id. For example, 1 indicates AP 1.</li> <li>When <i>instance-type</i> is <b>wlan-radio</b>, the <i>instance-name</i> value is ap-id.radio-id. For example, 0.1 indicates radio 1 of AP 0.</li> <li>When <i>instance-type</i> is <b>wlan-ssid</b>, the <i>instance-name</i> value is ap-id.radio-id.SSID name length.SSID name ASCII code. For example, 1.0.5.98.99.100.101.102 indicates the SSID with the name bcdef and name length 5 of radio 0 of AP 1.</li> <li>When <i>instance-type</i> is <b>wlan-ap-wiredport</b>, the <i>instance-name</i> value is ap-id.port type x 100+port number. For example, 0.101 indicates FE port 1 of AP 0. The port type can be 1 (an FE port) or 2 (a GE port). The port number ranges from 0 to 99.</li> </ul>

## Views

Performance statistics collection task view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The **binding** command is used to bind an instance to a performance statistics task so that the system can collect the performance statistics about the instance. Multiple instances can be bound to a performance statistics collection task.

### Prerequisites

The traffic statistics function has been enabled using the **statistics enable** command. Otherwise, the **binding** command cannot take effect.

### Precautions

If multiple performance statistics tasks are bound to the same interface to collect interface statistics, the peak values of the tasks are inaccurate.

If **instance-type** is set to **uni-mng-as-port**, performance statistics on interfaces of the AS are collected. The interval for collecting traffic statistics on interfaces configured by the **set flow-stat interval interval-time** command must be shorter than the interval for collecting performance statistics configured by the **statistics-cycle cycle** command. If the value of *interval-time* is greater than the value of *cycle*, performance statistics on interfaces are incorrect. This is because the statistics about the rate and bandwidth usage on interfaces remain the same within the interval specified by *interval-time*.

## Example

# Bind all instances in IP FPM to performance statistics collection task **task1**.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm mcp
[HUAWEI-nqa-ipfpm-mcp] instance 1
[HUAWEI-nqa-ipfpm-mcp-instance-1] quit
[HUAWEI-nqa-ipfpm-mcp] quit
[HUAWEI] pm
[HUAWEI-pm] statistics-task task1
[HUAWEI-pm-statistics-task1] binding instance-type ipfpm all
```

## Related Topics

[16.4.11 pm](#)

[16.4.22 statistics-task](#)

## 16.4.3 display pm brief

### Function

The **display pm brief** command displays brief PM information.

### Format

```
display pm brief
```

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

## Usage Guidelines

After PM is configured, you can run the **display pm brief** command to view brief PM information, such as the PM status, number of performance statistics tasks, number of performance statistics files.

### NOTE

Number of Active Statistics Objects in the output of the **display pm brief** command shows the number of current statistics objects. When this number exceeds 10000, you are advised to run the **statistics-cycle** command to set the statistics collection period to 30 minutes or longer, and run the **sample-interval** command to set the sampling period to 5 minutes or longer.

## Example

# Display brief PM information.

```
<HUAWEI> display pm brief
Statistics Status          : disable
Statistics Start Time     : -
Number of Statistics Tasks : 2
Number of Active Statistics Objects : 0
Number of Configured Pm Servers : 0
Number of Statistics Files : 0
Statistics Files Saved Directory : /pmdata/
```

**Table 16-40** Description of the **display pm brief** command output

Item	Description
Statistics Status	Whether the performance statistics function is enabled: <ul style="list-style-type: none"> <li>enable: enabled</li> <li>disable: disabled</li> </ul> You can run the <b>16.4.20 statistics enable</b> command to configure this parameter.
Statistics Start Time	Time when the performance statistics function starts.
Number of Statistics Tasks	Number of performance statistics tasks.
Number of Active Statistics Objects	Number of current performance statistics objects.
Number of Configured Pm Servers	Number of configured PM servers.
Number of Statistics Files	Number of performance statistics files.
Statistics Files Saved Directory	Path where performance statistics files are saved.

## 16.4.4 display pm measure-info

### Function

The **display pm measure-info** command displays information about performance statistics counters.

### Format

**display pm measure-info** [ **instance-type** *instance-type* ]

### Parameters

Parameter	Description	Value
<b>instance-type</b> <i>instance-type</i>	Specifies the type of an instance bound to a performance statistics task.	The enumerated values include: <ul style="list-style-type: none"><li>• <b>ipfpm</b>: collects IP FPM statistics.</li><li>• <b>uni-mng-as-port</b>: collects statistics on an AS port.</li><li>• <b>wlan-ap</b>: collects AP statistics:</li><li>• <b>wlan-radio</b>: collects statistics about a specified AP radio.</li><li>• <b>wlan-ssid</b>: collects statistics about a service set bound to a specific AP radio.</li><li>• <b>wlan-ap-wiredport</b>: collects statistics on an AP wired port.</li></ul> <b>NOTE</b> The S6720SI and S6720S-SI only support the <b>uni-mng-as-port</b> .

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

Before running the **measure disable** command to configure performance statistics counters for instances of a specific type, run the **display pm measure-info** command to view information about available performance statistics counters, including the name, type, maximum value, and minimum value of each counter.

### Example

```
# Display information about performance statistics counters of the instance of the IPFPM type.
```

```
<HUAWEI> display pm measure-info instance-type ipfpm
```

```
Total instance types: 1, total measures: 10
```

```
-----
Instance Type: ipfpm, Measures Count: 10
Measure Name      : forward-loss-ratio-max
Measure Type      : Maximum
Measure Counter Size(bits) : 32
Measure MaxValue  : 100000000
Measure MinValue  : -100000000

Measure Name      : forward-loss-ratio-min
Measure Type      : Minimum
Measure Counter Size(bits) : 32
Measure MaxValue  : 100000000
Measure MinValue  : -100000000

Measure Name      : forward-loss-pkts-inc
Measure Type      : Increase
Measure Counter Size(bits) : 64
Measure MaxValue  : 9223372036854775807
Measure MinValue  : -9223372036854775808
.....
```

**Table 16-41** Description of the **display pm measure-info** command output

Item	Description
Total instance types	Total types of measurement instances.
total measures	Total statistics counters.
Instance Type	Type of an instance.
Measures Count	Number of a performance statistics counter.
Measure Name	Name of a performance statistics counter.
Measure Type	Type of a performance statistics counter. The value can be: <ul style="list-style-type: none"> <li>● Increase: Accumulated performance statistics are compared with the counter.</li> <li>● Actual: The currently collected performance statistics are compared with the counter.</li> <li>● Maximum: The maximum performance statistics are compared with the counter.</li> <li>● Minimum: The minimum performance statistics are compared with the counter.</li> <li>● Average: The average performance statistics are compared with the counter.</li> </ul>
Measure Counter Size(bits)	Size of a performance statistics counter, 32 bits or 64 bits.
Measure MaxValue	Maximum value of a performance statistics counter.
Measure MinValue	Minimum value of a performance statistics counter.

## 16.4.5 display pm statistics

### Function

The **display pm statistics** command displays the collected performance statistics.

### Format

**display pm statistics** *task-name* **data-index** *index* [ **instance-type** *instance-type* [ **measure** *measure-name* | **instance** *instance-name* &<1-5> ] \* ]

### Parameters

Parameter	Description	Value
<i>task-name</i>	Displays the performance statistics of a specified performance statistics collection task.	The value is a string of 1 to 31 case-insensitive characters, spaces not supported. The string contains letters, digits, and underscores (_), and must start with letters or digits.
<b>data-index</b> <i>index</i>	Displays the performance statistics collected at a specified interval.	The value is an integer that ranges from 0 to 16. <ul style="list-style-type: none"> <li>• If the value is 0, the current performance statistics are displayed.</li> <li>• If the value is larger than 0, the performance statistics collected in one or more cycles are displayed. The smaller the value, the latest the statistics. If a short performance statistics collection cycle (5, 10, 15, 30, or 60 minutes) is set, the value of <i>index</i> ranges from 1 to 16. If a long performance statistics collection cycle (1440 minutes) is set, the value of <i>index</i> ranges from 1 to 3.</li> </ul>

Parameter	Description	Value
<b>instance-type</b> <i>instance-type</i>	Specifies the type of an instance bound to a performance statistics collection task.	<p>The enumerated values include:</p> <ul style="list-style-type: none"> <li>• <b>ipfpm</b>: collects IP FPM statistics.</li> <li>• <b>uni-mng-as-port</b>: collects statistics on an AS port.</li> <li>• <b>wlan-ap</b>: collects AP statistics:</li> <li>• <b>wlan-radio</b>: collects statistics about a specified AP radio.</li> <li>• <b>wlan-ssid</b>: collects statistics about a service set bound to a specific AP radio.</li> <li>• <b>wlan-ap-wiredport</b>: collects statistics on an AP wired port.</li> </ul> <p><b>NOTE</b> The S6720SI and S6720S-SI only support the <b>uni-mng-as-port</b>.</p>
<b>measure</b> <i>measure-name</i>	Specifies the name of a statistics counter.	The value is a string of 1 to 63 case-insensitive characters without spaces. Select statistics counters according to the device configuration.

Parameter	Description	Value
<b>instance</b> <i>instance-name</i>	Specifies the name of an instance.	<p>The value is a string of 1 to 255 case-insensitive characters.</p> <ul style="list-style-type: none"> <li>When <i>instance-type</i> is <b>ipfpm</b>, the <i>instance-name</i> value is configured using the <b>instance (IPFPM-MCP view)</b> command.</li> <li>When <i>instance-type</i> is <b>uni-mng-as-port</b>, the <i>instance-name</i> value is AS name+interface number, for example, as1 gigabitethernet0/0/1.</li> <li>When <i>instance-type</i> is <b>wlan-ap</b>, the <i>instance-name</i> value is ap-id. For example, 1 indicates AP 1.</li> <li>When <i>instance-type</i> is <b>wlan-radio</b>, the <i>instance-name</i> value is ap-id.radio-id. For example, 0.1 indicates radio 1 of AP 0.</li> <li>When <i>instance-type</i> is <b>wlan-ssid</b>, the <i>instance-name</i> value is ap-id.radio-id.SSID name length.SSID name ASCII code. For example, 1.0.5.98.99.100.101.102 indicates the SSID with the name bcdef and name length 5 of radio 0 of AP 1.</li> <li>When <i>instance-type</i> is <b>wlan-ap-wiredport</b>, the <i>instance-name</i> value is ap-id.port type x 100+port number. For example, 0.101 indicates FE port 1 of AP 0. The port type can be 1 (an FE port) or 2 (a GE port). The port number ranges from 0 to 99.</li> </ul>

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

To view the current or historical performance statistics, run the **display pm statistics** command. The system can display the current performance statistics and historical performance statistics collected in a maximum of 16 cycles.

### Prerequisites

- An instance has been bound to the current performance statistics using **binding** command.



- Performance statistics has been enabled for the current performance statistics task using **statistics enable** command.

### Precautions

To display the performance statistics, confirm that the performance statistics task is running.

## Example

# Display the current performance statistics of the performance statistics collection task **task1**.

```
<HUAWEI> display pm statistics task1 data-index 0
Total measures count: 10
-----
Instance Type      : ipfpm
Instance Name     : 1
Measure Name      : forward-loss-ratio-max
Measure Data      : 0
Valid Flag        : no statistics
Timestamp         : 2014-04-15 11:17:00
.....
```

**Table 16-42** Description of the **display pm statistics** command output

Item	Description
Total measures count	Number of a performance statistics counter.
Instance Type	Type of an instance bound to a performance statistics collection task.
Instance Name	Name of an instance bound to a performance statistics collection task.
Measure Name	Name of a performance statistics counter.
Measure Data	Statistics counter.
Valid Flag	Valid flag of the performance statistics. The value can be: <ul style="list-style-type: none"> <li>• no statistics: The performance statistics are not collected.</li> <li>• valid: The performance statistics are valid.</li> <li>• incredible value: The performance statistics are not reliable.</li> <li>• measure not configured: The statistics counter is disabled.</li> </ul>
Timestamp	Time when the performance statistics are collected.

## 16.4.6 display pm statistics-file

### Function

The **display pm statistics-file** command displays performance statistics files.

## Format

**display pm statistics-file** [ *task-name* ]

## Parameters

Parameter	Description	Value
<i>task-name</i>	Displays the performance statistics files generated for a performance statistics task.	The value is a string of 1 to 31 case-insensitive characters, spaces not supported. The string contains letters, digits, and underscores (_), and must start with letters or digits.

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

After a performance statistics task starts, the system automatically generates performance statistics files for the task. To view the performance statistics files generated for the performance statistics task, run the **display pm statistics-file** command.

## Example

# Display performance statistics files for all performance statistics tasks.

```
<HUAWEI> display pm statistics-file
Total files count: 1
-----
Task Name: test
test20130701150001.txt
```

**Table 16-43** Description of the **display pm statistics-file** command output

Item	Description
Total files count	Number of performance statistics files.
Task Name	Name of a performance statistics task. You can run the <a href="#">16.4.22 statistics-task</a> command to configure this parameter.
test20130701150001.txt	Name of the performance statistics file.

## 16.4.7 display pm statistics-task

### Function

The **display pm statistics-task** command displays information about a performance statistics collection task.

### Format

```
display pm statistics-task [ task-name ]
```

### Parameters

Parameter	Description	Value
<i>task-name</i>	Displays the information about a specified performance statistics collection task.	The performance statistics collection task must exist.

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

You can use this command to check information about a performance statistics collection task, including the running status of the task, statistics collection cycle, and type of the instance bound to the task.

### Example

```
# Display information about performance statistics collection tasks.
```

```
<HUAWEI> display pm statistics-task
Total task count: 1
-----
Task Name       : task1
Task State      : ready
Record-file Status : enable
Threshold Alarm Status : disable
Task Cycle      : 15 minutes
Sample Interval : 3 minutes
Instance Type   : -
Record Interval(cycle) : 4
File Format      : text
File Name Prefix : task1
File Transfer Mode : passive
Current File Name : -
```

**Table 16-44** Description of the **display pm statistics-task** command output

Item	Description
Total task count	Number of performance statistics collection tasks.
Task Name	Name of a performance statistics collection task. The task name is specified in the <a href="#">16.4.22 statistics-task task-name</a> command.
Task State	Running status of a performance statistics collection task.
Record-file Status	Whether performance statistics file generation is enabled. The value can be: <ul style="list-style-type: none"> <li>enable: This function is enabled.</li> <li>disable: This function is not enabled.</li> </ul> This function is configured using the <a href="#">16.4.14 record-file disable</a> command.
Threshold Alarm Status	Whether the threshold alarm function is enabled. The value can be: <ul style="list-style-type: none"> <li>enable: This function is enabled.</li> <li>disable: This function is not enabled.</li> </ul> This function is configured using the <a href="#">16.4.23 threshold-alarm enable</a> command.
Task Cycle	Performance statistics collection cycle configured in a performance statistics collection task. This parameter is configured using the <a href="#">16.4.21 statistics-cycle cycle</a> command.
Sample Interval	Sampling interval configured in a performance statistics collection task. This parameter is configured using the <a href="#">16.4.18 sample-interval interval</a> command.
Instance Type	Type of an instance bound to a performance statistics collection task. This parameter is configured using the <a href="#">16.4.2 binding instance-type instance-type { all   instance instance-name &lt;1-5&gt; }</a> command.
Record Interval(cycle)	Interval at which the system generates performance statistics files. This parameter is configured using the <a href="#">16.4.15 record-interval interval</a> command.
File Format	Format of performance statistics files.
File Name Prefix	Name prefix of a performance statistics file.

Item	Description
File Transfer Mode	<p>Mode in which statistics files are uploaded to the performance management server. The value can be:</p> <ul style="list-style-type: none"> <li>• active: The device automatically uploads statistics files to the performance management server, this function is configured using the <b>upload auto</b> command.</li> <li>• passive: The device uploads statistics files to the performance management server following the instructions from the command line interface or network management system, this function is configured using the <b>upload</b> command.</li> </ul>
Current File Name	Name of the current performance statistics file.

## Related Topics

- [16.4.2 binding](#)
- [16.4.14 record-file disable](#)
- [16.4.15 record-interval](#)
- [16.4.18 sample-interval](#)
- [16.4.21 statistics-cycle](#)
- [16.4.22 statistics-task](#)

## 16.4.8 display snmp-agent trap feature-name pm all

### Function

The **display snmp-agent trap feature-name pm all** command displays whether the switch is enabled to send traps of PM feature to the NMS.

### Format

**display snmp-agent trap feature-name pm all**

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

After running the **snmp-agent trap enable feature-name pm** command to enable the function of sending traps of the PM feature to the NMS, you can run the **display snmp-agent trap feature-name pm all** command to check whether this function is enabled.

### Prerequisites

SNMP has been enabled. For details, see [snmp-agent](#).

## Example

# Display whether the switch is enabled to send traps of PM feature to the NMS.

```
<HUAWEI> display snmp-agent trap feature-name pm all
-----
Feature name: PM
Trap number : 3
-----
Trap name           Default switch status  Current switch status
hwPMStatisticsTaskThresholdTriggerAlarm
                    on              on
hwPMStatisticsTaskThresholdClearAlarm
                    on              on
hwPMMeasureExceed  on              on
```

**Table 16-45** Description of the **display snmp-agent trap feature-name pm all** command output

Item	Description
Feature name	Name of the feature that generates traps.
Trap number	Number of traps generated by PM feature.
Trap name	Name of the trap.
Default switch status	Default status of a trap: <ul style="list-style-type: none"> <li>on: The switch is enabled to send this trap to the NMS.</li> <li>off: The switch is disabled to send this trap to the NMS.</li> </ul>
Current switch status	Current status of a trap: <ul style="list-style-type: none"> <li>on: The switch is enabled to send this trap to the NMS.</li> <li>off: The switch is disabled to send this trap to the NMS.</li> </ul> This status can be configured using the <a href="#">snmp-agent trap enable feature-name pm</a> command.

## Related Topics

[16.4.19 snmp-agent trap enable feature-name pm](#)

# 16.4.9 measure disable

## Function

The **measure disable** command disables statistics counters in a performance statistics task.

The **undo measure disable** or **measure enable** command enables statistics counters in a performance statistics task.

By default, all statistics counters of the instance bound to the performance statistics collection task are measured.

## Format

**measure disable** [ *measure-name* ]

**undo measure disable** [ *measure-name* ]

**measure enable** [ *measure-name* ]

## Parameters

Parameter	Description	Value
<i>measure-name</i>	Specifies the name of a statistics counter in a performance statistics collection task.	The value is a string of 1 to 63 case-insensitive characters without spaces. Select statistics counters according to the device configuration.

## Views

Performance statistics collection task view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

If the type of the instance bound to a performance statistics task is specified, statistics counters of instances of the specified type are enabled by default. The **measure disable** command can be used to disable some or all statistics counters.

After you run the **measure disable** [ *measure-name* ] command, some or all statistics counters are disabled. To add one or more counters that have been disabled to the performance statistics task again, run the **measure enable**

[ *measure-name* ] or **undo measure disable** [ *measure-name* ] command to enable these counters.

### Prerequisites

An instance has been bound to a performance statistics task using the **binding instance-type** *instance-type-name* **instance** *instance-name* command.

The performance statistics function has been enabled using the **statistics enable** command.

## Example

# Disable measurement of the forward-loss-ratio-max counter for ipfpm instances.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] statistics-task task1
[HUAWEI-pm-statistics-task1] binding instance-type ipfpm all
[HUAWEI-pm-statistics-task1] measure disable forward-loss-ratio-max
```

## Related Topics

- [16.4.4 display pm measure-info](#)
- [16.4.2 binding](#)
- [16.4.11 pm](#)
- [16.4.22 statistics-task](#)

## 16.4.10 path

### Function

The **path** command configures the destination path to save performance statistics files on the PM server.

The **undo path** command deletes the configured destination path.

By default, performance statistics files are uploaded to the default path on a PM server.

### Format

**path** *destination-path*

**undo path**

### Parameters

Parameter	Description	Value
<i>destination-path</i>	Specifies the destination path to save performance statistics files on the PM server.	The value is a string of 1 to 63 case-sensitive characters without spaces.



## Views

PM server view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To upload performance statistics files to a specific path on the PM server, run the **path** command to specify the destination path.

### Precautions

The specified destination path must exist in the performance management server. Otherwise, the statistics file cannot be uploaded to the server.

## Example

# Specify the destination path to save performance statistics on the PM server.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] pm-server server1
[HUAWEI-pm-server-server1] path d:/pmdata
```

## Related Topics

[16.4.11 pm](#)

[16.4.12 pm-server](#)

## 16.4.11 pm

### Function

The **pm** command displays the PM view.

### Format

**pm**

### Parameters

None

### Views

System view

### Default Level

2: Configuration level

## Usage Guidelines

To enable the performance statistics function of PM, run the **pm** command to display the PM view.

## Example

```
# Display the PM view.
```

```
<HUAWEI> system-view  
[HUAWEI] pm  
[HUAWEI-pm]
```

## 16.4.12 pm-server

### Function

The **pm-server** command creates a process serving the PM server and displays the view of the PM server created in the process. If there is an existing PM server view, the **pm-server** command displays the PM server view without creating a process.

The **undo pm-server** command deletes the created process.

By default, no process serving the PM server is created.

### Format

```
pm-server server-name
```

```
undo pm-server server-name
```

### Parameters

Parameter	Description	Value
<i>server-name</i>	Specifies the name of the process serving the PM server.	The value is a string of 1 to 31 case-sensitive characters, spaces not supported. The string contains letters, digits, and underscores (_), and must start with letters or digits.

### Views

PM view

### Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To upload generated performance statistics files to the PM server, run the **pm-server** command to create a process serving the PM server.

#### Follow-up Procedure

Configure the IP address and port number for the PM server, and user name and password for logging in to the PM server. Performance statistics files are uploaded to the PM server using FTP or SFTP.

#### Precautions

If a device is enabled to upload performance statistics files to a PM server, the process serving the PM server cannot be deleted.

### Example

```
# Create a process named server1 to serve the PM server.
```

```
<HUAWEI> system-view  
[HUAWEI] pm  
[HUAWEI-pm] pm-server server1  
[HUAWEI-pm-server-server1]
```

## 16.4.13 protocol (PM server view)

### Function

The **protocol** command configures the parameters for connecting to a PM server.

The **undo protocol** command deletes the parameters for connecting to a PM server.

By default, no PM server connection parameter is configured.

### Format

```
protocol { ftp | sftp } ip-address ip-address [ port port-number | { net-manager-vpn | vpn-instance vpn-instance-name } ] *
```

```
undo protocol
```

### Parameters

Parameter	Description	Value
<b>ftp</b>	Uses the FTP protocol to upload performance statistics files.	-
<b>sftp</b>	Uses the SFTP protocol to upload performance statistics files.	-
<b>ip-address</b> <i>ip-address</i>	Specifies the IP address of the PM server.	The value is in dotted decimal notation.

Parameter	Description	Value
<b>port</b> <i>port-number</i>	Specifies the port number.	The value is an integer that ranges from 1 to 65535. The default port number is 21 (using FTP) or 22 (using SFTP).
<b>net-manager-vpn</b>	Indicates the network management VPN.	-
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies a VPN instance name.	The value must be an existing VPN instance name.

## Views

PM server view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To upload statistics files to a PM server, use this command to configure connection parameters, including the transfer protocol, IP address, and port number of the PM server.

If the PM server uses a private IP address, you can use the **net-manager-vpn** parameter to specify a network management VPN or use the **vpn-instance** *vpn-instance-name* parameter to specify a VPN instance to upload a performance statistics file.

### Precautions

Using FTP to upload performance statistics files is insecure. Therefore, using SFTP is recommended.

## Example

# Configure the device to upload performance statistics files to the SFTP server with the IP address 10.1.1.1.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] pm-server server1
[HUAWEI-pm-server-server1] protocol sftp ip-address 10.1.1.1
```

## Related Topics

[16.4.11 pm](#)

[16.4.12 pm-server](#)

## 16.4.14 record-file disable

### Function

The **record-file disable** command disables performance statistics file generation.

The **undo record-file disable** command restores performance statistics file generation.

By default, a performance statistics file is automatically generated and saved on the device. A maximum of four performance statistics files can be generated for each performance statistics collection task.

### Format

**record-file disable**

**undo record-file disable**

### Parameters

None

### Views

Performance statistics collection task view

### Default Level

2: Configuration level

### Usage Guidelines

To save system resources, reduce system cost and operations on storage devices, and prolong the lifespan of storage devices during performance statistics collection, run the **record-file disable** command to prevent performance statistics files from being generated.

The system-generated file name is named in the format of "name of a performance statistics task+time that a performance statistics file is generated", and is saved in the text format. Each performance statistics collection task can generate a maximum of four statistics files. If more than four statistics files are generated, the new file replaces the earliest one.

### Example

# Disable performance statistics file generation.

```
<HUAWEI> system-view  
[HUAWEI] pm  
[HUAWEI-pm] statistics-task task1  
[HUAWEI-pm-statistics-task1] record-file disable
```

### Related Topics

[16.4.11 pm](#)

16.4.22 statistics-task

## 16.4.15 record-interval

### Function

The **record-interval** command sets the number of performance statistics collection cycles after which the system generates a statistics file.

The **undo record-interval** command restores the default number of performance statistics collection cycles.

By default:

- If a short performance statistics collection cycle (5, 10, 15, 30, or 60 minutes) is set, the system generates a statistics file after four cycles.
- If a long performance statistics collection cycle (1440 minutes) is set, the system generates a statistics file after one cycle.

### Format

**record-interval** *interval*

**undo record-interval**

### Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the number of performance statistics collection cycles.	The value is an integer. The value range depends on the performance statistics collection cycle: <ul style="list-style-type: none"><li>• If a short performance statistics collection cycle is set, the value of <i>interval</i> ranges from 1 to 16, and the default value is 4.</li><li>• If a long performance statistics collection cycle is set, the value of <i>interval</i> ranges from 1 to 3, and the default value is 1.</li></ul>

### Views

Performance statistics collection task view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

After you configure a performance statistics collection task, the system periodically saves collected performance data to statistics files. To set the interval at which the system generates statistics files, run the **record-interval** command.

Then the system generates performance statistics files every *cycle* x *interval* minutes, and automatically saves the performance data in the files. The system generates a maximum of four statistics files for each performance statistics collection task, and saves performance statistics files to the path flash: /pmdata by default.

#### Prerequisites

1. The performance statistics function has been enabled using the [statistics enable](#) command.
2. The *cycle* has been set using the [statistics-cycle](#) command.

### Example

# Configure the system to save performance data to a statistics file every three performance statistics collection cycles. If the performance statistics collection cycle is 5 minutes, the system saves a performance data to a statistics file every 15 minutes.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] statistics enable
[HUAWEI-pm] statistics-task task1
[HUAWEI-pm-statistics-task1] statistics-cycle 5
Warning: All data of the statistics task will be deleted. Continue? [Y/N]: y
[HUAWEI-pm-statistics-task1] record-interval 3
Warning: This operation will cause some data to be lost. Continue? [Y/N]: y
```

### Related Topics

- [16.4.11 pm](#)
- [16.4.15 record-interval](#)
- [16.4.21 statistics-cycle](#)
- [16.4.22 statistics-task](#)

## 16.4.16 reset pm current-data

### Function

The **reset pm current-data** command deletes the collected performance statistics.

### Format

```
reset pm current-data [ instance-type instance-type [ measure measure-name | instance instance-name &<1-5> ] * ]
```

## Parameters

Parameter	Description	Value
<b>instance-type</b> <i>instance-type</i>	Deletes the performance statistics about instances of a specified type.  If <b>instance-type</b> <i>instance-type</i> is not specified, the system deletes the performance statistics about instances of all types.	The enumerated values include: <ul style="list-style-type: none"> <li>• <b>ipfpm</b>: collects IP FPM statistics.</li> <li>• <b>uni-mng-as-port</b>: collects statistics on an AS port.</li> <li>• <b>wlan-ap</b>: collects AP statistics:</li> <li>• <b>wlan-radio</b>: collects statistics about a specified AP radio.</li> <li>• <b>wlan-ssid</b>: collects statistics about a service set bound to a specific AP radio.</li> <li>• <b>wlan-ap-wiredport</b>: collects statistics on an AP wired port.</li> </ul> <p><b>NOTE</b> The S6720SI and S6720S-SI only support the <b>uni-mng-as-port</b>.</p>
<b>measure</b> <i>measure-name</i>	Deletes the performance statistics about a specified counter.	The value is a string of 1 to 63 case-insensitive characters without spaces. Select statistics counters according to the device configuration.



Parameter	Description	Value
<b>instance</b> <i>instance-name</i>	Deletes the performance statistics about a specified instance.	<p>The value is a string of 1 to 255 case-insensitive characters.</p> <ul style="list-style-type: none"> <li>When <i>instance-type</i> is <b>ipfpm</b>, the <i>instance-name</i> value is configured using the <b>instance (IPFPM-MCP view)</b> command.</li> <li>When <i>instance-type</i> is <b>uni-mng-as-port</b>, the <i>instance-name</i> value is AS name +interface number, for example, as1 gigabitethernet0/0/1.</li> <li>When <i>instance-type</i> is <b>wlan-ap</b>, the <i>instance-name</i> value is ap-id. For example, 1 indicates AP 1.</li> <li>When <i>instance-type</i> is <b>wlan-radio</b>, the <i>instance-name</i> value is ap-id.radio-id. For example, 0.1 indicates radio 1 of AP 0.</li> <li>When <i>instance-type</i> is <b>wlan-ssid</b>, the <i>instance-name</i> value is ap-id.radio-id.SSID name length.SSID name ASCII code. For example, 1.0.5.98.99.100.101.102 indicates the SSID with the name bcdef and name length 5 of radio 0 of AP 1.</li> <li>When <i>instance-type</i> is <b>wlan-ap-wiredport</b>, the <i>instance-name</i> value is ap-id.port type x 100+port number. For example, 0.101 indicates FE port 1 of AP 0. The port type can be 1 (an FE port) or 2 (a GE port). The port number ranges from 0 to 99.</li> </ul>

## Views

Performance statistics collection task view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

To delete the collected performance statistics and collect new performance statistics, run the **reset pm current-data** command.

### Precautions

Performance statistics cannot be restored after being deleted. Confirm your action before using this command.

## Example

```
# Delete the collected performance statistics.
```

```
<HUAWEI> system-view  
[HUAWEI] pm  
[HUAWEI-pm] statistics-task task1  
[HUAWEI-pm-statistics-task1] reset pm current-data
```

## Related Topics

[16.4.11 pm](#)

[16.4.22 statistics-task](#)

## 16.4.17 retry

### Function

The **retry** command sets the number of retransmissions for a performance statistics file.

The **undo retry** command restores the number of retransmissions for a performance statistics file to the default value.

The default number of retransmissions for a performance statistics file is 3.

### Format

```
retry retry-times
```

```
undo retry
```

### Parameters

Parameter	Description	Value
<i>retry-times</i>	Sets the number of retransmissions for a performance statistics file.	The value is an integer ranging from 1 to 3. The default value is 3.

### Views

PM server view

### Default Level

2: Configuration level

### Usage Guidelines

The system generates performance statistics files and transmits these files to a PM server. To set the number of retransmissions for a performance statistics file, run the **retry** command.

## Example

# Set the number of retransmissions for a performance statistics file to 2.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] pm-server server1
[HUAWEI-pm-server-server1] retry 2
```

## Related Topics

[16.4.11 pm](#)

[16.4.12 pm-server](#)

## 16.4.18 sample-interval

### Function

The **sample-interval** command configures the sampling interval for a performance statistics task.

The **undo sample-interval** command restores the default setting.

By default, the sampling interval varies with the performance statistics interval as follows:

- If the interval at which the performance statistics are collected is 5 minutes, the default sampling interval is 1 minute.
- If the interval at which the performance statistics are collected is 10 minutes, the default sampling interval is 2 minutes.
- If the interval at which the performance statistics are collected is 15 minutes, the default sampling interval is 3 minutes.
- If the interval at which the performance statistics are collected is 30 minutes, the default sampling interval is 5 minutes.
- If the interval at which the performance statistics are collected is 60 minutes, the default sampling interval is 5 minutes.
- If the interval at which the performance statistics are collected is 1440 minutes, the default sampling interval is 15 minutes.

### Format

**sample-interval** *interval*

**undo sample-interval**

## Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the interval at which the performance statistics collected in a performance statistics task is sampled.	The value can be 1, 2, 3, 5, 10, 15, 30, or 60, in minutes: <ul style="list-style-type: none"><li>• If the interval at which performance statistics are collected is 5 minutes, the sampling interval is 1 minute by default and can be set to 1 minute or 5 minutes.</li><li>• If the interval at which performance statistics are collected is 10 minutes, the sampling interval is 2 minutes by default and can be set to 1, 2, 5, or 10 minutes.</li><li>• If the interval at which performance statistics are collected is 15 minutes, the sampling interval is 3 minutes by default and can be set to 1, 3, 5, or 15 minutes.</li><li>• If the interval at which performance statistics are collected is 30 minutes, the sampling interval is 5 minutes by default and can be set to 1, 2, 3, 5, 10, 15, or 30 minutes.</li><li>• If the interval at which performance statistics are collected is 60 minutes, the sampling interval is 5 minutes by default and can be set to 1, 2, 3, 5, 10, 15, 30, or 60 minutes.</li><li>• If the interval at which performance statistics are collected is 1440 minutes, the sampling interval is 15 minutes by default and can be set to 1, 2, 3, 5, 10, 15, 30, or 60 minutes.</li></ul>

## Views

Performance statistics task view

## Default Level

2: Configuration level

## Usage Guidelines

After the statistics task is configured, the system collects statistics at a specified sampling interval. The shorter the sampling interval, the more accurate the statistics. However, more system resources are consumed.

## Example

```
# Set the sampling interval to 5 minutes.
```

```
<HUAWEI> system-view  
[HUAWEI] pm
```

```
[HUAWEI-pm] statistics-task task1  
[HUAWEI-pm-statistics-task1] sample-interval 5
```

## Related Topics

[16.4.11 pm](#)

[16.4.22 statistics-task](#)

## 16.4.19 snmp-agent trap enable feature-name pm

### Function

The **snmp-agent trap enable feature-name pm** command enables the trap function of the PM module.

The **undo snmp-agent trap enable feature-name pm** command disables the trap function of the PM module.

By default, the trap function of the PM module is enabled.

### Format

```
snmp-agent trap enable feature-name pm [ trap-name trap-name ]
```

```
undo snmp-agent trap enable feature-name pm [ trap-name trap-name ]
```

### Parameters

Parameter	Description	Value
<b>trap-name</b> <i>trap-name</i>	Specifies the name of a trap.	This parameter has enumerated values. Select one from the displayed values.

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

The **snmp-agent trap enable feature-name pm** command is used to enable a PM trap. After that, the trap generated during the device running will be sent to the NMS.

You can run the [16.4.8 display snmp-agent trap feature-name pm all](#) command to check the configuration result.

### Example

```
# Enable hwpmstatisticstaskthresholdtriggeralarm for the PM module.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name pm trap-name  
hwpmstatisticstaskthresholdtriggeralarm
```

## Related Topics

[16.4.8 display snmp-agent trap feature-name pm all](#)

# 16.4.20 statistics enable

## Function

The **statistics enable** command enables the performance statistics function.

The **undo statistics enable** command disables the performance statistics function.

By default, the performance statistics function is disabled.

## Format

**statistics enable**

**undo statistics enable**

## Parameters

None

## Views

PM view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To collect performance statistics, run the **statistics enable** command to enable the performance statistics function.

### Precautions

After the **undo statistics enable** command is run, the performance statistics task that is running will be stopped. Therefore, exercise caution when you run this command.

## Example

# Enable the performance statistics function.

```
<HUAWEI> system-view  
[HUAWEI] pm  
[HUAWEI-pm] statistics enable
```

## Related Topics

[16.4.11 pm](#)

# 16.4.21 statistics-cycle

## Function

The **statistics-cycle** command configures the performance statistics collection interval for a performance statistics task.

The **undo statistics-cycle** command restores the default setting.

The default interval is 15 minutes.

## Format

**statistics-cycle** *cycle*

**undo statistics-cycle**

## Parameters

Parameter	Description	Value
<i>cycle</i>	Specifies the performance statistics collection interval for a performance statistics task.	The value can be 5, 10, 15, 30, 60, or 1440, in minutes. The default value is 15 minutes.  The system defines the interval 1440 minutes as a long interval and the interval 5, 10, 15, 30, or 60 minutes as a short interval.

## Views

Performance statistics task view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

A specific performance statistics collection interval is set for each performance statistics task. After the performance statistics collection interval is set, bind an instance to the performance statistics task and enable statistics counter measurement so that the system can collect performance statistics at the specified interval. If the statistics interval is set to a small value, the obtained performance statistics are more accurate but more system resources are consumed.

### Configuration Impact

Running the **statistics-cycle** command in the performance statistics task view has the following impacts:

- Performance statistics of the performance statistics task are deleted.
- The default interval at which the system generates performance statistics files is used. In the case of a short statistics collection interval, the system generates a performance statistics file every four performance statistics collection intervals; in the case of a long statistics collection interval, the system generates a performance statistics file every one performance statistics collection interval.

### Prerequisites

The performance statistics function has been enabled using the **statistics enable** command.

## Example

# Set the performance statistics collection interval for the performance statistics task named **task1** to 5 minutes.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] statistics-task task1
[HUAWEI-pm-statistics-task1] statistics-cycle 5
Warning: All data of the statistics task will be deleted. Continue? [Y/N]: y
```

## Related Topics

[16.4.11 pm](#)

[16.4.22 statistics-task](#)

## 16.4.22 statistics-task

### Function

The **statistics-task** command creates a performance statistics task or displays the performance statistics task view.

The **undo statistics-task** command deletes a performance statistics task.

By default, no performance statistics task is created.

### Format

**statistics-task** *task-name*

**undo statistics-task** *task-name*



## Parameters

Parameter	Description	Value
<i>task-name</i>	Specifies the name of a performance statistics task.	The value is a string of 1 to 31 case-insensitive characters, spaces not supported. The string contains letters, digits, and underscores (_), and must start with letters or digits.

## Views

PM view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

A performance statistics task is the minimum statistics collection unit of PM. Before configuring the performance statistics function, run the **statistics-task** command to create a performance statistics task. Only one performance statistics collection interval can be configured for each performance statistics task. After a performance statistics task is configured, enable statistics counter measurement for the task.

### Precautions

- A maximum of 16 performance statistics tasks can be configured.
- After the **undo statistics-task** command is run to delete a performance statistics task, performance statistics and performance statistics files of the task are deleted.

### Prerequisites

The performance statistics function has been enabled using the **statistics enable** command.

## Example

# Configure a performance statistics task named **task1**.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] statistics-task task1
[HUAWEI-pm-statistics-task1]
```

## Related Topics

[16.4.11 pm](#)

## 16.4.23 threshold-alarm enable

### Function

The **threshold-alarm enable** command enables the threshold alarm.

The **undo threshold-alarm enable** command disables the threshold alarm.

By default, the threshold alarm function is disabled.

### Format

**threshold-alarm enable**

**undo threshold-alarm enable**

### Parameters

None

### Views

Performance statistics task view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The threshold alarm function enables users to learn the device operating status in a timely manner so that the device maintenance level can be promoted. To monitor the running data, run the command to enable the threshold alarm.

#### Precautions

After the **undo threshold-alarm enable** command is run, the threshold alarm function will be disabled and threshold alarms will be cleared. Exercise caution before operation.

#### Follow-up Procedure

After the command is run, run the [16.4.24 threshold-alarm measure](#) command to configure monitoring rules for the threshold alarm. Otherwise, the threshold alarm function will not take effect.

### Example

# Enable the threshold alarm function.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] statistics-task task1
[HUAWEI-pm-statistics-task1] threshold-alarm enable
```

## Related Topics

[16.4.24 threshold-alarm measure](#)

# 16.4.24 threshold-alarm measure

## Function

The **threshold-alarm measure** command creates monitoring rules for threshold alarms.

The **undo threshold-alarm measure** command deletes monitoring rules for threshold alarms.

By default, no monitoring rules are created for threshold alarms about performance statistics tasks.

## Format

**threshold-alarm measure** *measure-name* **operation** { **ge** | **le** } **trigger-value**  
*trigger-value-val* **clear-value** *clear-value-val*

**undo threshold-alarm measure** *measure-name* **operation** { **ge** | **le** }

## Parameters

Parameter	Description	Value
<i>measure-name</i>	Specifies the threshold monitoring indicator. The indicator name is predefined by each feature.	The value is a string of 1 to 63 case-insensitive characters without spaces. Select statistics counters according to the device configuration.
<b>operation</b> { <b>ge</b>   <b>le</b> }	Specifies the type of triggering a threshold alarm.	Enumerated value: ge or le <ul style="list-style-type: none"> <li>ge: the system triggers an alarm if the monitored indicator value is greater than or equal to the threshold value</li> <li>le: the system triggers an alarm if the monitored indicator value is less than or equal to the threshold value.</li> </ul>
<b>trigger-value</b> <i>trigger-value-val</i>	Specifies the threshold information when the alarm is triggered.	The value is an integer, and the value range is determined by <i>measure-name</i> .
<b>clear-value</b> <i>clear-value-val</i>	Specifies the threshold information when the alarm is cleared.	The value is an integer, and the value range is determined by <i>measure-name</i> .

## Views

Performance statistics task view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The threshold alarm function is used for the system to periodically monitor the device operating status. If an alarm condition is triggered, the alarm will be sent to the NMS and cleared after the alarm condition is cleared.

The **threshold-alarm measure** command configures threshold monitoring rules for current performance statistics tasks. The **threshold-alarm measure** command configures the alarm triggering type, threshold for triggering an alarm and threshold for clearing an alarm based on the instance type and indicators of the threshold monitoring instance.

### Prerequisites

Before the **threshold-alarm measure** command is run, run the **binding instance-type** *instance-type* { **all** | **instance** *instance-name* &<1-5> } command to bind a threshold monitoring instance, and run the **threshold-alarm enable** command to enable the threshold alarm function. Otherwise, alarms will not be sent.

## Example

# Create threshold monitoring rules.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] statistics-task task1
[HUAWEI-pm-statistics-task1] binding instance-type ipfpm all
[HUAWEI-pm-statistics-task1] threshold-alarm enable
[HUAWEI-pm-statistics-task1] threshold-alarm measure forward-loss-ratio-max operation ge trigger-value 1000 clear-value 10
```

## Related Topics

[16.4.2 binding](#)

[16.4.23 threshold-alarm enable](#)

## 16.4.25 upload

### Function

The **upload** command configures the device to upload performance statistics files to a PM server.

### Format

**upload** *request-name* **file** *filename* &<1-16>

## Parameters

Parameter	Description	Value
<i>request-name</i>	Specifies the name of a request for uploading performance statistics files.	The value is a string of 1 to 31 case-sensitive characters, spaces not supported. The string contains letters, digits, and underscores (_), and must start with letters or digits.
<b>file</b> <i>filename</i>	Specifies the name of a performance statistics file.	The value is a string of 1 to 255 case-insensitive characters without spaces.  The file name can contain the file path. If multiple files are specified, separate them with spaces.

## Views

PM view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

The system periodically generates performance statistics files based on the collected performance statistics. You can manually upload the statistics files to a PM server.

### Prerequisites

A request for uploading performance statistics files to the PM server has been created using the **upload-config** *request-name* **server** *server-name* command.

### Follow-up Procedure

View the performance statistics on the PM server.

## Example

# Configure the device to upload performance statistics file to the PM server.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] pm-server ftpserver
[HUAWEI-pm-server-ftpserver] quit
[HUAWEI-pm] upload-config req1 server ftpserver
[HUAWEI-pm] upload req1 file stream20130703103001.txt
```

## Related Topics

[16.4.11 pm](#)

[16.4.27 upload-config](#)

## 16.4.26 upload auto

### Function

The **upload auto** command enables a device to automatically upload performance statistics files to a server.

The **undo upload auto** command disables a device from automatically uploading performance statistics files to a server.

By default, a device does not automatically upload performance statistics files to a server.

### Format

**upload auto** *request-name*

**undo upload auto**

### Parameters

Parameter	Description	Value
<i>request-name</i>	Specifies the name of a request for uploading performance statistics files to a server.	The value is a string of 1 to 31 case-sensitive characters, spaces not supported. The string contains letters, digits, and underscores (_), and must start with letters or digits.

### Views

Performance statistics collection task view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The system periodically generates performance statistics files based on the collected performance statistics. To enable the device to automatically upload performance statistics files to the PM server at a specific interval, run the **upload auto** command.

#### Prerequisites

A request for uploading performance statistics files to the PM server has been created using the **upload-config** *request-name* **server** *server-name* command.

## Example

# Configure the device to automatically upload statistics files to a PM server.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] pm-server ftpserver
[HUAWEI-pm-server-ftpserver] quit
[HUAWEI-pm] upload-config req1 server ftpserver
[HUAWEI-pm] statistics-task task1
[HUAWEI-pm-statistics-task1] upload auto req1
```

## Related Topics

[16.4.11 pm](#)

[16.4.27 upload-config](#)

## 16.4.27 upload-config

### Function

The **upload-config** command creates a request for uploading performance statistics files to a specified PM server.

The **undo upload-config** command deletes a request for uploading performance statistics files to a specified PM server.

By default, no request for uploading performance statistics files is available on a device.

### Format

**upload-config** *request-name* **server** *server-name*

**undo upload-config** *request-name*

### Parameters

Parameter	Description	Value
<i>request-name</i>	Specifies the name of a request for uploading performance statistics files.	The value is a string of 1 to 31 case-sensitive characters, spaces not supported. The string contains letters, digits, and underscores (_), and must start with letters or digits.
<b>server</b> <i>server-name</i>	Specifies the name of the process serving the PM server.	The value is a string of 1 to 31 case-sensitive characters, spaces not supported. The string contains letters, digits, and underscores (_), and must start with letters or digits.

### Views

PM view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To enable a device to upload performance statistics files to a PM server, run the **upload-config** command to create a file uploading request.

### Prerequisites

A PM server process has been created using the **pm-server** *server-name* command.

### Follow-up Procedure

Enable the device to upload performance statistics files to the PM server.

- Run the **upload** *request-name* **file** *filename* &<1-16> command in the PM view to manually upload statistics files to the PM server.
- Run the **upload auto** *request-name* command in the performance statistics collection task view to configure the device to automatically upload statistics files to the PM server.

## Example

# Create a request for uploading statistics files to a PM server.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] pm-server ftpserver
[HUAWEI-pm-server-ftpserver] quit
[HUAWEI-pm] upload-config req1 server ftpserver
```

## Related Topics

[16.4.11 pm](#)

[16.4.12 pm-server](#)

[16.4.25 upload](#)

[16.4.27 upload-config](#)

## 16.4.28 username password

### Function

The **username password** command configures the user name and password for logging in to the PM server.

The **undo username** command deletes the user name and password for logging in to the PM server.

By default, no user name and password for logging in to the PM server are configured.



## Format

**username** *user-name* **password** *password*

**undo username**

## Parameters

Parameter	Description	Value
<i>user-name</i>	Specifies the user name for logging in to a PM server.	The name is a string of 1 to 255 case-sensitive characters without spaces.
<i>password</i>	Specifies the password for logging in to a PM server.	<p>The value is a string of 1 to 128 characters or a string of 32 to 200 characters. The password can be in plain or cipher text.</p> <ul style="list-style-type: none"> <li>The password in plain text is a string of 1 to 128 case-sensitive characters without spaces.</li> <li>The password in cipher text is a string of 32 to 200 characters.</li> </ul> <p>The password is displayed in ciphertext in the configuration file regardless of whether it is input in plain or cipher text.</p> <p><b>NOTE</b> A 24-character ciphertext password configured in an earlier version is also supported in this version.</p>

## Views

PM server view

## Default Level

2: Configuration level

## Usage Guidelines

To log in to a PM server for upload performance statistics files to the PM server, run the **username password** command to configure the user name and password.

## Example

# Configure the user name and password for logging in to the PM server.

```
<HUAWEI> system-view
[HUAWEI] pm
[HUAWEI-pm] pm-server server1
[HUAWEI-pm-server-server1] username admin password Pwd@123
```

## Related Topics

[16.4.11 pm](#)

[16.4.12 pm-server](#)

## 16.5 iPCA Configuration Commands

[16.5.1 Command Support](#)

[16.5.2 ach](#)

[16.5.3 authentication-mode \(IPFPM-DCP view\)](#)

[16.5.4 authentication-mode \(IPFPM-DCP instance view\)](#)

[16.5.5 authentication-mode \(IPFPM-MCP view\)](#)

[16.5.6 color-flag loss-measure](#)

[16.5.7 dcp](#)

[16.5.8 dcp id](#)

[16.5.9 description \(IPFPM-DCP instance view\)](#)

[16.5.10 description \(IPFPM-MCP instance view\)](#)

[16.5.11 display ipfpm dcp](#)

[16.5.12 display ipfpm mcp](#)

[16.5.13 display ipfpm statistic-type](#)

[16.5.14 display iplpm configuration brief](#)

[16.5.15 display iplpm loss-measure statistics global](#)

[16.5.16 display iplpm loss-measure statistics history-record](#)

[16.5.17 display iplpm loss-measure statistics interface](#)

[16.5.18 display iplpm loss-measure statistics port-flow interface](#)

[16.5.19 display iplpm loss-measure statistics qos-queue interface](#)

[16.5.20 display snmp-agent trap feature-name ipfpm all](#)

[16.5.21 display snmp-agent trap feature-name iplpm all](#)

[16.5.22 flow \(IPFPM-DCP instance view\)](#)

[16.5.23 flow \(IPFPM-MCP-ACH view\)](#)

[16.5.24 in-group](#)

[16.5.25 instance \(IPFPM-DCP view\)](#)

[16.5.26 instance \(IPFPM-MCP view\)](#)

[16.5.27 interval \(IPFPM-DCP instance view\)](#)

[16.5.28 ipfpm tlp](#)

[16.5.29 iplpm global loss-measure alarm enable](#)

[16.5.30 iplpm global loss-measure enable](#)

- 16.5.31 `iplpm global loss-measure interval`
- 16.5.32 `iplpm link authentication-mode`
- 16.5.33 `iplpm link loss-measure alarm enable`
- 16.5.34 `iplpm link loss-measure enable`
- 16.5.35 `iplpm link loss-measure interval`
- 16.5.36 `iplpm loss-measure color-flag`
- 16.5.37 `loss-measure enable`
- 16.5.38 `loss-measure enable continual`
- 16.5.39 `loss-measure ratio-threshold`
- 16.5.40 `mcp (IPFPM-DCP view)`
- 16.5.41 `mcp (IPFPM-DCP instance view)`
- 16.5.42 `mcp id`
- 16.5.43 `measure disable (IPFPM-MCP instance view)`
- 16.5.44 `nqa ipfpm dcp`
- 16.5.45 `nqa ipfpm mcp`
- 16.5.46 `out-group`
- 16.5.47 `protocol udp port`
- 16.5.48 `snmp-agent trap enable feature-name ipfpm`
- 16.5.49 `snmp-agent trap enable feature-name iplpm`
- 16.5.50 `tlp`

## 16.5.1 Command Support

Only the S5720HI supports iPCA.

## 16.5.2 `ach`

### Function

The **`ach`** command creates an Atomic Closed Hop (ACH) and displays the ACH view. If the ACH already exists, the command displays the ACH view directly.

The **`undo ach`** command deletes an ACH and all configurations in the ACH view.

By default, no ACH is created.

### Format

**`ach`** *ach-id*

**`undo ach`** *ach-id*

## Parameters

Parameter	Description	Value
<i>ach-id</i>	Specifies an ACH ID.	The value is an integer ranging from 1 to 2147483647.

## Views

IPFPM-MCP instance view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

An ACH consists of two target logical ports (TLPs) and is used to identify a segment between two specified devices on the network. In IP FPM hop-by-hop measurement, you need to specify the ACH for the target flow in a measurement instance and configure the direction and measurement points for the target flow in the ACH view. You can create an ACH and enter the ACH view by running the **ach** command.

### Prerequisites

The **instance** command has been run to configure an IP FPM instance on an MCP.

## Example

```
# Create an ACH.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm mcp  
[HUAWEI-nqa-ipfpm-mcp] instance 1  
[HUAWEI-nqa-ipfpm-mcp-instance-1] ach 1
```

## Related Topics

[16.5.41 mcp \(IPFPM-DCP instance view\)](#)

[16.5.46 out-group](#)

[16.5.24 in-group](#)

## 16.5.3 authentication-mode (IPFPM-DCP view)

### Function

The **authentication-mode** command configures the authentication mode and password on a Data Collecting Point (DCP).

The **undo authentication-mode** command deletes the authentication mode and password on a DCP.

By default, no authentication mode or password is configured on a DCP.

## Format

**authentication-mode hmac-sha256 key-id** *key-id* [ **cipher** ] *password*

**undo authentication-mode hmac-sha256**

## Parameters

Parameter	Description	Value
<b>hmac-sha256</b>	Uses HMAC-SHA256 to encrypt and authenticate packets sent by a DCP to the MCP.	-
<b>key-id</b> <i>key-id</i>	Specifies the ID of the authentication password configured on a DCP.	The value is an integer that ranges from 1 to 64.
<b>cipher</b>	Specifies the cipher-text authentication password on a DCP.	-
<i>password</i>	Specifies the authentication password on a DCP.	The value is a case-sensitive character string without spaces. <ul style="list-style-type: none"><li>• The value is a string of 1 to 255 characters in plain text.</li><li>• The value is a string of 32 to 392 characters in cipher text.</li></ul>

## Views

IPFPM-DCP view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To enhance network security and performance statistics reliability, run the **authentication-mode** command so that authentication is performed during IP FPM performance statistics. An MCP and its associated DCPs must have the same authentication mode and password configured. The MCP processes packets only from the authenticated DCPs.

### Prerequisites

Global DCP has been enabled using the [nqa ipfpm dcp](#) command.

## Example

# Configure the authentication mode and password on a DCP.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm dcp
[HUAWEI-nqa-ipfpm-dcp] authentication-mode hmac-sha256 key-id 1 cipher huawei
```

## Related Topics

[16.5.44 nqa ipfpm dcp](#)

[16.5.5 authentication-mode \(IPFPM-MCP view\)](#)

[16.5.4 authentication-mode \(IPFPM-DCP instance view\)](#)

## 16.5.4 authentication-mode (IPFPM-DCP instance view)

### Function

The **authentication-mode** command configures the authentication mode and password for a measurement instance on a DCP.

The **undo authentication-mode** command deletes the authentication mode and password of a measurement instance on a DCP.

By default, no authentication mode or password is configured for a measurement instance on a DCP.

### Format

**authentication-mode** hmac-sha256 **key-id** *key-id* [ **cipher** ] *password*

**undo authentication-mode** hmac-sha256

### Parameters

Parameter	Description	Value
<b>hmac-sha256</b>	Uses HMAC-SHA256 to encrypt and authenticate packets sent by a DCP to the MCP.	-
<b>key-id</b> <i>key-id</i>	Specifies the ID of the authentication password configured for a measurement instance.	The value is an integer that ranges from 1 to 64.
<b>cipher</b>	Specifies the cipher-text authentication password for a measurement instance.	-

Parameter	Description	Value
<i>password</i>	Specifies the authentication password for a measurement instance.	The value is a case-sensitive character string without spaces. <ul style="list-style-type: none"><li>• The value is a string of 1 to 255 characters in plain text.</li><li>• The value is a string of 32 to 392 characters in cipher text.</li></ul>

## Views

IPFPM-DCP instance view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

On a network demanding high security, when iPCA is used to measure network-level packet loss, enable authentication. After the same authentication mode and password are configured on the MCP and DCPs, the MCP accepts the packets only from authenticated DCPs. This improves network security and reliability of packet loss measurement. The **authentication-mode** command configures the authentication mode and password for a measurement instance on a DCP.

### Prerequisites

A measurement instance has been created on the DCP using the [instance](#) command.

### Precautions

If the **authentication-mode** command is not used to configure the authentication mode and password, all measurement instances of the DCP use the authentication mode and password configured by the [authentication-mode \(IPFPM-DCP view\)](#) command.

## Example

# Configure the authentication mode and password for a measurement instance.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm dcp
[HUAWEI-nqa-ipfpm-dcp] instance 1
[HUAWEI-nqa-ipfpm-dcp-instance-1] authentication-mode hmac-sha256 key-id 1 cipher huawei
```

## Related Topics

[16.5.25 instance \(IPFPM-DCP view\)](#)

[16.5.5 authentication-mode \(IPFPM-MCP view\)](#)

[16.5.3 authentication-mode \(IPFPM-DCP view\)](#)

## 16.5.5 authentication-mode (IPFPM-MCP view)

### Function

The **authentication-mode** command configures the authentication mode and password on the Measurement Control Point (MCP).

The **undo authentication-mode** command deletes the authentication mode and password on the MCP.

By default, no authentication mode or password is configured on the MCP.

### Format

**authentication-mode hmac-sha256 key-id *key-id* [ *cipher* ] *password***

**undo authentication-mode hmac-sha256 key-id *key-id***

### Parameters

Parameter	Description	Value
<b>hmac-sha256</b>	Uses HMAC-SHA256 to decrypt and authenticate packets sent by a DCP to the MCP.	-
<b>key-id</b> <i>key-id</i>	Specifies the ID of the authentication password configured on the MCP.	The value is an integer that ranges from 1 to 64.
<b>cipher</b>	Specifies the cipher-text authentication password configured on the MCP.	-
<i>password</i>	Specifies the authentication password configured on the MCP.	The value is a case-sensitive character string without spaces. <ul style="list-style-type: none"> <li>The value is a string of 1 to 255 characters in plain text.</li> <li>The value is a string of 32 to 392 characters in cipher text.</li> </ul>

### Views

IPFPM-MCP view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

On a network demanding high security, when iPCA is used to measure network-level packet loss, enable authentication. After the same authentication mode and



password are configured on the MCP and DCPs, the MCP accepts the packets only from authenticated DCPs. This improves network security and reliability of packet loss measurement. The **authentication-mode** command configures the authentication mode and password on the MCP.

#### Prerequisites

Global MCP has been enabled using the **nqa ipfpm mcp** command.

#### Precautions

The MCP and DCP must be configured with the same authentication mode and password; otherwise, the MCP cannot obtain packet loss measurement from the DCP.

### Example

# Configure the authentication mode and password on the MCP.

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm mcp  
[HUAWEI-nqa-ipfpm-mcp] authentication-mode hmac-sha256 key-id 1 huawei
```

### Related Topics

[16.5.45 nqa ipfpm mcp](#)

[16.5.3 authentication-mode \(IPFPM-DCP view\)](#)

[16.5.4 authentication-mode \(IPFPM-DCP instance view\)](#)

## 16.5.6 color-flag loss-measure

### Function

The **color-flag loss-measure** command configures the color bit used in network-level packet loss measurement.

The **undo color-flag** command restores the default color bit used in network-level packet loss measurement.

By default, bit 6 in the ToS field is used as the color bit for network-level packet loss measurement. The default configuration is recommended.

### Format

**color-flag loss-measure** { **tos-bit** *tos-bit* | **flags-bit0** }

**undo color-flag**

## Parameters

Parameter	Description	Value
<b>tos-bit</b> <i>tos-bit</i>	Specifies a bit in the range of bits 3 to 7 in the ToS field of IP packets as the color bit for network-level packet loss measurement.	The value is an integer that ranges from 3 to 7.
<b>flags-bit0</b>	Specifies bit 0 in the Flags field of IP packets as the color bit for network-level packet loss measurement.	-

## Views

IPFPM-DCP view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

Before deploying Packet Conservation Algorithm for Internet (iPCA) to implement network-level packet loss measurement, run this command to configure the color bit. You can select a color bit according to the actual situation and network planning.

### Prerequisites

Global DCP has been enabled using the [nqa ipfpm dcp](#) command.

### Precautions

All devices on a network must use the same color bit setting. When the DS field is used to provide differentiated service, it is not recommended that you configure bits 3-5 as color bits because the measurement result may be inaccurate.

When both network-level and device-level packet loss measurements are enabled on a device, the color bits must be differentiated.

## Example

# Configure bit 3 in the ToS field as the color bit for network-level packet loss measurement.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm dcp
[HUAWEI-nqa-ipfpm-dcp] color-flag loss-measure tos-bit 3
```

## Related Topics

[16.5.44 nqa ipfpm dcp](#)

## 16.5.7 dcp

### Function

The **dcp** command associates the DCP ID with a measurement instance on the MCP.

The **undo dcp** command disassociates the DCP ID from a measurement instance on the MCP.

By default, no DCP ID is associated with a measurement instance on the MCP.

### Format

**dcp** *dcp-id*

**undo dcp** [ *dcp-id* ]

### Parameters

Parameter	Description	Value
<i>dcp-id</i>	Specifies the DCP ID to be associated with a measurement instance.	The value is in dotted decimal notation.

### Views

IPFPM-MCP instance view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

Each measurement instance of the MCP contains one or more DCP IDs. The MCP checks whether the statistics data is complete based on the DCP ID, so the DCP ID must be specified for a measurement instance created on the MCP. The **dcp** command associates the DCP ID with a measurement instance on the MCP.

#### Prerequisites

A measurement instance has been created on the MCP using the **instance** command.

#### Precautions

The DCP ID associated with the measurement instance on the MCP must be the same as the DCP ID configured by the **dcp id** command on the DCP.

The **undo dcp** command without *dcp-id* specified deletes all DCP IDs associated with a measurement instance.

## Example

# Associate a DCP ID with measurement instance 1 on the MCP.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm mcp
[HUAWEI-nqa-ipfpm-mcp] instance 1
[HUAWEI-nqa-ipfpm-mcp-instance-1] dcp 10.1.1.1
```

## Related Topics

[16.5.45 nqa ipfpm mcp](#)

[16.5.26 instance \(IPFPM-MCP view\)](#)

## 16.5.8 dcp id

### Function

The **dcp id** command sets the DCP ID.

The **undo dcp id** command deletes the DCP ID.

By default, no DCP ID is configured.

### Format

**dcp id** *dcp-id*

**undo dcp id**

### Parameters

Parameter	Description	Value
<i>dcp-id</i>	Specifies the DCP ID. It is recommended that you configure the router ID of the device as the DCP ID.	The value is in dotted decimal notation.

### Views

IPFPM-DCP view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

When the MCP communicates with a DCP, the DCP encapsulates statistics data collected from Target Logical Ports (TLPs) in a packet and sends the packet with the DCP ID as the source IP address. After receiving the packet sent from the DCP, the MCP compares the DCP ID in the packet with the DCP ID configured by the **dcp** command:

- If the two DCP IDs are the same, the MCP accepts the packet, and then summarizes and calculates the statistics data.
- If the two DCP IDs are different, the MCP considers the packet invalid and discards it.

### Prerequisites

Global DCP has been enabled using the [nqa ipfpm dcp](#) command.

### Precautions

Each DCP has a unique ID on the network. It is recommended that you configure the router ID of the device as the DCP ID. The DCP ID must be the same as the DCP ID in the measurement instance configured by the [dcp](#) command on the MCP.

## Example

```
# Set the DCP ID.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm dcp  
[HUAWEI-nqa-ipfpm-dcp] dcp id 10.1.1.1
```

## Related Topics

[16.5.44 nqa ipfpm dcp](#)

[16.5.42 mcp id](#)

[16.5.7 dcp](#)

## 16.5.9 description (IPFPM-DCP instance view)

### Function

The **description** command configures the description for a measurement instance on a DCP.

The **undo description** command deletes the description of a measurement instance on a DCP.

By default, no description is configured for a measurement instance on a DCP.

### Format

**description** *text*

**undo description**

### Parameters

Parameter	Description	Value
<i>text</i>	Specifies the description of a measurement instance.	The value is a string of 1 to 64 case-sensitive characters with spaces supported.

## Views

IPFPM-DCP instance view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

An IP FPM instance is identified by an integer ID, and therefore its functions are not easy to understand. The **description** command configures the description for a measurement instance on a DCP, which helps you understand the function of the measurement instance.

It is recommended that the **description** command be used to configure the description for a measurement instance in the following situations:

- Many measurement instances are configured, and it is difficult to differentiate functions of each measurement instance.
- The interval for using the same measurement instance is too long, and functions of measurement instances change.

### Precautions

If an IP FPM instance is configured but does not have a description, it may be misused.

## Example

# Configure the description for measurement instance 1.

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm dcp  
[HUAWEI-nqa-ipfpm-dcp] instance 1  
[HUAWEI-nqa-ipfpm-dcp-instance-1] description NanJinToHeFei
```

## Related Topics

[16.5.10 description \(IPFPM-MCP instance view\)](#)

## 16.5.10 description (IPFPM-MCP instance view)

### Function

The **description** command configures the description for a measurement instance on the MCP.

The **undo description** command deletes the description of a measurement instance on the MCP.

By default, no description is configured for a measurement instance on the MCP.

## Format

**description** *text*

**undo description**

## Parameters

Parameter	Description	Value
<i>text</i>	Specifies the description of a measurement instance.	The value is a string of 1 to 64 case-sensitive characters with spaces supported.

## Views

IPFPM-MCP instance view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

An IP FPM instance is identified by an integer ID, and therefore its functions are not easy to understand. The **description** command configures the description for a measurement instance on a DCP, which helps you understand the function of the measurement instance.

It is recommended that the **description** command be used to configure the description for a measurement instance in the following situations:

- Many measurement instances are configured, and it is difficult to differentiate functions of each measurement instance.
- The interval for using the same measurement instance is too long, and functions of measurement instances change.

### Precautions

If an IP FPM instance is configured but does not have a description, it may be misused.

## Example

```
# Configure the description for measurement instance 1 on the MCP.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm mcp  
[HUAWEI-nqa-ipfpm-mcp] instance 1  
[HUAWEI-nqa-ipfpm-mcp-instance-1] description NanJinToHeFei
```

## Related Topics

[16.5.9 description \(IPFPM-DCP instance view\)](#)

## 16.5.11 display ipfpm dcp

### Function

The **display ipfpm dcp** command displays the DCP configuration in the IP Flow Performance Measurement (FPM) system.

### Format

```
display ipfpm dcp
```

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

You can run this command to check the DCP configuration.

### Example

```
# Display the DCP configuration.
```

```
<HUAWEI> display ipfpm dcp
Specification Information(Main Board):
Max Instance Number           : 512
Max 10s Instance Number       : 512
Max 1s Instance Number        : 1
Max TLP Number                 : 512
Max TLP Number Per Instance   : 8
Configuration Information:
DCP ID                         : 10.1.1.1
Loss-measure Flag              : tos-bit6(default)
Authentication Mode            : --
Test Instances MCP ID          : 10.2.2.2
Test Instances MCP Port        : 65030(default)
Current Instance Number        : 1
```

**Table 16-46** Description of the display ipfpm dcp command output

Item	Description
Specification Information(Main Board)	Specification information of the main board.



Item	Description
Max Instance Number	Maximum number of measurement instances supported.
Max 10s Instance Number	Maximum number of measurement instances at intervals of 10s.
Max 1s Instance Number	Maximum number of measurement instances at intervals of 1s.
Max TLP Number	Maximum number of TLPs supported .
Max TLP Number Per Instance	Maximum number of TLPs supported by each measurement instance.
Configuration Information	DCP configuration.
DCP ID	DCP ID. To configure this parameter, run the <a href="#">16.5.8 dcp id</a> command.
Loss-measure Flag	Color bit used in packet loss measurement: <ul style="list-style-type: none"> <li>• tos-bit3: bit 3 in the ToS field</li> <li>• tos-bit4: bit 4 in the ToS field</li> <li>• tos-bit5: bit 5 in the ToS field</li> <li>• tos-bit6: bit 6 in the ToS field</li> <li>• tos-bit7: bit 7 in the ToS field</li> <li>• flag-bit0: bit 0 in the Flags field</li> </ul> To configure this parameter, run the <a href="#">16.5.6 color-flag loss-measure</a> command.
Authentication Mode	Authentication mode on the DCP: <ul style="list-style-type: none"> <li>• hmac-sha256: HMAC-SHA256 encrypted authentication</li> <li>• --: non-authentication</li> </ul> To configure the authentication mode on a DCP, run the <a href="#">16.5.3 authentication-mode (IPFPM-DCP view)</a> command.
Test Instances MCP ID	ID of the MCP corresponding to the DCP.
Test Instances MCP Port	UDP port number used by the DCP to communicate with the MCP.
Current Instance Number	Number of measurement instances.

## Related Topics

[16.5.12 display ipfpm mcp](#)

## 16.5.12 display ipfpm mcp

### Function

The **display ipfpm mcp** command displays the MCP configuration and status in the IP Flow Performance Measurement (FPM) system.

### Format

```
display ipfpm mcp
```

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

You can run this command to check the MCP configuration and status.

### Example

# Display the MCP configuration.

```
<HUAWEI> display ipfpm mcp
Specification Information:
Max Instance Number          :128
Max DCP Number Per Instance  :128
Max ACH Number Per Instance  :16
Max TLP Number Per ACH      :16

Configuration Information:
MCP ID                       :10.1.1.1
Status                       :Active
Protocol Port                 :65030(default)
Current Instance Number      :1
```

**Table 16-47** Description of the display ipfpm mcp command output

Item	Description
Specification Information	Specifications of the MCP.
Max Instance Number	Maximum number of measurement instances supported by the MCP.
Max DCP Number Per Instance	Maximum number of DCPs supported by each measurement instance on the MCP.

Item	Description
Max ACH Number Per Instance	Maximum number of ACHs supported by each measurement instance on the MCP.
Max TLP Number Per ACH	Maximum number of TLPs supported by ACH on the MCP.
Configuration Information	MCP configuration.
MCP ID	MCP ID. To set the MCP ID, run the <a href="#">16.5.42 mcp id</a> command on the MCP.
Status	MCP status: <ul style="list-style-type: none"> <li>Active: The MCP works properly.</li> <li>Deleting: The <a href="#">undo nqa ipfpm mcp</a> command is being used to disable global MCP.</li> </ul>
Protocol Port	UDP port number through which the DCP and MCP communicate with each other. To configure the UDP port number through which the DCP and MCP communicate with each other, run the <a href="#">16.5.47 protocol udp port</a> command.
Current Instance Number	Total number of measurement instances.

## Related Topics

[16.5.11 display ipfpm dcp](#)

## 16.5.13 display ipfpm statistic-type

### Function

The **display ipfpm statistic-type** command displays packet loss statistics of a specified measurement instance in the IP Flow Performance Measurement (FPM) system.

### Format

**display ipfpm statistic-type loss instance** *instance-id* [ **ach** *ach-id* ]

### Parameters

Parameter	Description	Value
<b>loss</b>	Displays packet loss statistics.	-

Parameter	Description	Value
<b>instance</b> <i>instance-id</i>	Displays packet loss statistics of a specified measurement instance.	The value is an integer that ranges from 1 to 16777214.
<b>ach</b> <i>ach-id</i>	Displays hop-by-hop performance statistics for an Atomic Closed Hop (ACH).	The value is an integer ranging from 1 to 2147483647.

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

The packet loss statistics of a specified measurement instance include the indicators such as the number of discarded packets, number of discarded bytes, and packet loss ratio. To view packet loss statistics of a specified measurement instance, run the **display ipfpm statistic-type** command.

To locate and diagnose network faults when network performance deteriorates, run the **display ipfpm statistic-type** command with **ach** configured to check statistics for a specified ACH.

### Precautions

This command can be only executed on the MCP.

The first statistics record obtained through the IP FPM may be inaccurate, so do not use the first statistics record to determine network performance.

If the packet loss ratio is a negative value, the service packets may be unknown unicast packets or the color bits on devices participating in measurement may be different.

## Example

# Display packet loss statistics of measurement instance 1.

```
<HUAWEI> display ipfpm statistic-type loss instance 1
```

Latest loss statistics of forward flow:

Unit: p - packet, b - byte

Period	Loss(p)	LossRatio(p)	Loss(b)	LossRatio(b)
136118757	20	20.000000%	2000	20.000000%
136118756	20	20.000000%	2000	20.000000%
136118755	20	20.000000%	2000	20.000000%
136118753	20	20.000000%	2000	20.000000%
136118752	20	20.000000%	2000	20.000000%
136118751	20	20.000000%	2000	20.000000%

```

136118750      20      20.000000% 2000      20.000000%
136118749      20      20.000000% 2000      20.000000%
136118748      20      20.000000% 2000      20.000000%
136118747      20      20.000000% 2000      20.000000%
136118746      20      20.000000% 2000      20.000000%
136118745      20      20.000000% 2000      20.000000%

```

Latest loss statistics of backward flow:  
Unit: p - packet, b - byte

```

-----
Period          Loss(p)          LossRatio(p) Loss(b)          LossRatio(b)
-----
136118757      20      20.000000% 2000      20.000000%
136118756      20      20.000000% 2000      20.000000%
136118755      20      20.000000% 2000      20.000000%
136118753      20      20.000000% 2000      20.000000%
136118752      20      20.000000% 2000      20.000000%
136118751      20      20.000000% 2000      20.000000%
136118750      20      20.000000% 2000      20.000000%
136118749      20      20.000000% 2000      20.000000%
136118748      20      20.000000% 2000      20.000000%
136118747      20      20.000000% 2000      20.000000%
136118746      20      20.000000% 2000      20.000000%
136118745      20      20.000000% 2000      20.000000%

```

**Table 16-48** Description of the **display ipfpm statistic-type** command output

Item	Description
Latest loss statistics of forward flow	-
Latest loss statistics of backward flow	-
Period	Measurement interval.
Loss(p)	Number of discarded packets.
LossRatio(p)	Packet loss ratio.
Loss(b)	Number of discarded bytes.
LossRatio(b)	Packet loss ratio of bytes.

## 16.5.14 display iplpm configuration brief

### Function

The **display iplpm configuration brief** command displays the brief configuration of device-level packet loss measurement (including measurement on the entire device and direct link).

### Format

**display iplpm configuration brief**

## Parameters

None

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

To view parameters of device-level packet loss measurement, run this command.

## Example

# Display the brief configuration of device-level packet loss measurement.

```
<HUAWEI> display iplpm configuration brief
Configuration information:
-----
Loss-measure flag          : flags-bit0(default)
Global loss-measure interval(s) : 10(default)
Global loss-measure status  : disable
Global loss-measure alarm   : disable
Loss-measure board number   : 1
Loss-measure board list    : 0
Loss-measure port number    : 9
Loss-measure port list     : GigabitEthernet0/0/1
                           GigabitEthernet0/0/2
                           GigabitEthernet0/0/3
                           GigabitEthernet0/0/4
                           GigabitEthernet0/0/5
                           GigabitEthernet0/0/6
                           GigabitEthernet0/0/7
                           GigabitEthernet0/0/8
                           GigabitEthernet0/0/9
-----
```

**Table 16-49** Description of the display iplpm configuration brief command output

Item	Description
Configuration information	Configuration of device-level packet loss measurement.
Loss-measure flag	Color bit for packet loss measurement. To configure the color bit, run the <b>iplpm loss-measure color-flag</b> command. <ul style="list-style-type: none"> <li>tos-bit6: bit 6 in the ToS field</li> <li>tos-bit7: bit 7 in the ToS field</li> <li>flags-bit0: bit 0 in the Flags field</li> </ul> The value default indicates that the default color bit is used.

Item	Description
Global loss-measure interval(s)	Measurement interval of packet loss measurement on the device. To set the measurement interval, run the <b>iplpm global loss-measure interval</b> command. The value default indicates that the default measurement interval is used.
Global loss-measure status	Whether packet loss measurement on the device is enabled. To packet loss measurement for a device, run the <b>iplpm global loss-measure enable</b> command. <ul style="list-style-type: none"> <li>• enable</li> <li>• disable</li> </ul>
Global loss-measure alarm	Whether the alarm and clear alarm of packet loss ratio are enabled. To enable the alarm and clear alarm of packet loss ratio, run the <b>iplpm global loss-measure alarm enable</b> command. <ul style="list-style-type: none"> <li>• enable</li> <li>• disable</li> </ul>
Loss-measure board number	Number of devices that support device-level packet loss measurement.
Loss-measure board list	List of slot numbers of devices that support device-level packet loss measurement. The value -- indicates that no device supports device-level packet loss measurement.
Loss-measure port number	Number of interfaces where packet loss measurement for direct links is enabled.
Loss-measure port list	List of interfaces where packet loss measurement for direct links is enabled. The value -- indicates that no interface is enabled with packet loss measurement for direct links.

## Related Topics

- [16.5.36 iplpm loss-measure color-flag](#)
- [16.5.31 iplpm global loss-measure interval](#)
- [16.5.30 iplpm global loss-measure enable](#)
- [16.5.29 iplpm global loss-measure alarm enable](#)

## 16.5.15 display iplpm loss-measure statistics global

### Function

Run the **display iplpm loss-measure statistics global** command displays the packet loss measurement result on a device.

## Format

**display iplpm loss-measure statistics global**

## Parameters

None

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

You can run this command to view the packet loss measurement result on a device, including the number of discarded packets, packet loss ratio, and error information.

## Example

# Display the packet loss measurement result on a device.

```
<HUAWEI> display iplpm loss-measure statistics global
Latest global loss statistics:
-----
StartTime(DST)   Loss Packets   LossRatio     ErrorInfo
-----
2014-06-12 18:47:30 344127        4.513519%    OK
2014-06-12 18:47:20 381085        4.513196%    OK
2014-06-12 18:47:10 381192        4.513290%    OK
2014-06-12 18:47:00 381339        4.513341%    OK
2014-06-12 18:46:50 381465        4.513392%    OK
2014-06-12 18:46:40 381444        4.513487%    OK
2014-06-12 18:46:30 381129        4.513309%    OK
-----
```

**Table 16-50** Description of the **display iplpm loss-measure statistics global** command output

Item	Description
Latest global loss statistics	Latest statistics about packet loss measurement on the device.
StartTime(DST)	Time the packet loss measurement result was generated (standard DST), which is also the start time of each measurement interval.
Loss Packets	Number of discarded packets in the current measurement interval.
LossRatio	Packet loss ratio in the current measurement interval.



Item	Description
ErrorInfo	<p>Error code about packet loss measurement in the current measurement interval:</p> <ul style="list-style-type: none"> <li>• OK: There is no error, and the packet loss measurement result is normal.</li> <li>• Incomplete: The statistics data is incomplete. The possible reason is the inter-chassis communication error. Part of statistics on the standby or slave switch cannot be sent to the master switch.</li> </ul>

## 16.5.16 display iplpm loss-measure statistics history-record

### Function

The **display iplpm loss-measure statistics history-record** command displays the historical records of packet loss measurement on a device and a direct link.

### Format

```
display iplpm loss-measure statistics history-record { global | interface
interface-type interface-number }
```

### Parameters

Parameter	Description	Value
<b>global</b>	Displays the historical records of packet loss measurement on a device.	-
<b>interface</b> <i>interface-type</i> <i>interface-number</i>	Displays the historical records of packet loss measurement on a direct link.	-

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

When the measurement interval is 1s, 10s, or 60s, the system summarizes statistics results in each measurement interval every 5 minutes to obtain the maximum and minimum packet loss ratios within 5 minutes. When the measurement interval is 600s, the system summarizes statistics results in each measurement interval every 60 minutes to obtain the maximum and minimum packet loss ratios within 60 minutes. The system saves a maximum of four summarized records. You can run this command to view historical records.

## Example

# Display the historical records of packet loss measurement on a device.

```
<HUAWEI> display iplpm loss-measure statistics history-record global
Latest global history record(every 5 minutes):
-----
Record no          : 29
Period(DST)       : 2014-03-19 16:20:10 to 2014-03-19 16:25:10
Valid statistic data number : 30
Maximum loss ratio : 0.000000%
Minimum loss ratio : 0.000000%
Total loss packets : 0
Total receive packets : 0

Record no          : 28
Period(DST)       : 2014-03-19 16:15:10 to 2014-03-19 16:20:10
Valid statistic data number : 30
Maximum loss ratio : 0.000000%
Minimum loss ratio : 0.000000%
Total loss packets : 0
Total receive packets : 0

Record no          : 27
Period(DST)       : 2014-03-19 16:10:10 to 2014-03-19 16:15:10
Valid statistic data number : 30
Maximum loss ratio : 0.000000%
Minimum loss ratio : 0.000000%
Total loss packets : 0
Total receive packets : 0

Record no          : 26
Period(DST)       : 2014-03-19 16:05:10 to 2014-03-19 16:10:10
Valid statistic data number : 30
Maximum loss ratio : 0.000000%
Minimum loss ratio : 0.000000%
Total loss packets : 0
Total receive packets : 0
-----
```

# Display the historical records of packet loss measurement on a direct link of GE0/0/1.

```
<HUAWEI> display iplpm loss-measure statistics history-record interface gigabitethernet 0/0/1
Latest history record of interface GigabitEthernet0/0/1(every 5 minutes):
-----
Record no          : 29
Period(DST)       : 2014-03-19 16:20:10 to 2014-03-19 16:25:10
Valid statistic data number : 30
Maximum forward loss ratio : 0.000000%
Minimum forward loss ratio : 0.000000%
Total forward loss packets : 0
Total forward receive packets : 0
Maximum backward loss ratio : 20.000000%
Minimum backward loss ratio : 19.980020%
Total backward loss packets : 6000
Total backward receive packets : 30001

Record no          : 28
Period(DST)       : 2014-03-19 16:15:10 to 2014-03-19 16:20:10
Valid statistic data number : 30
Maximum forward loss ratio : 0.000000%
Minimum forward loss ratio : 0.000000%
Total forward loss packets : 0
Total forward receive packets : 0
Maximum backward loss ratio : 20.079920%
Minimum backward loss ratio : 19.980020%
Total backward loss packets : 6001
```

```
Total backward receive packets : 30003

Record no          : 27
Period(DST)       : 2014-03-19 16:10:10 to 2014-03-19 16:15:10
Valid statistic data number : 30
Maximum forward loss ratio : 0.000000%
Minimum forward loss ratio : 0.000000%
Total forward loss packets : 0
Total forward receive packets : 0
Maximum backward loss ratio : 20.039880%
Minimum backward loss ratio : 19.960080%
Total backward loss packets : 6001
Total backward receive packets : 30005

Record no          : 26
Period(DST)       : 2014-03-19 16:05:10 to 2014-03-19 16:10:10
Valid statistic data number : 30
Maximum forward loss ratio : 0.000000%
Minimum forward loss ratio : 0.000000%
Total forward loss packets : 0
Total forward receive packets : 0
Maximum backward loss ratio : 20.059880%
Minimum backward loss ratio : 19.980020%
Total backward loss packets : 6001
Total backward receive packets : 30004
-----
```

**Table 16-51** Description of the **display iplpm loss-measure statistics history-record** command output

Item	Description
Latest global historical record(every 5 minutes)	Latest statistics about packet loss measurement in every five minutes on the device.
Latest historical record of interface <i>x</i> (every 5 minutes)	Latest statistics about packet loss measurement on a direct link of the <i>x</i> interface in every five minutes.
Record no	Historical record ID.
Period(DST)	Time historical records were generated (standard DST).
Valid statistic data number	Number of valid historical statistics records.
Maximum loss ratio	Maximum packet loss ratio of the device.
Minimum loss ratio	Minimum packet loss ratio of the device.
Total loss packets	Total number of packets discarded by the device.
Total receive packets	Total number of packets received by the device.
Maximum forward loss ratio	Maximum packet loss ratio of a forward flow (a forward flow is sent by the local device interface and received by the remote device interface).
Minimum forward loss ratio	Minimum packet loss ratio of a forward flow.

Item	Description
Total forward loss packets	Total number of discarded packets of a forward flow.
Total forward receive packets	Total number of received packets (including the number of discarded packets) of a forward flow.
Maximum backward loss ratio	Maximum packet loss ratio of a backward flow (a backward flow is sent by the remote device interface and received by the local device interface).
Minimum backward loss ratio	Minimum packet loss ratio of a backward flow.
Total backward loss packets	Total number of discarded packets of a backward flow.
Total backward receive packets	Total number of received packets (including the number of discarded packets) of a backward flow.

## 16.5.17 display iplpm loss-measure statistics interface

### Function

The **display iplpm loss-measure statistics interface** command displays the packet loss measurement result on the direct link of a specified interface.

### Format

**display iplpm loss-measure statistics interface** *interface-type interface-number*  
[ **forward** | **backward** ]

### Parameters

Parameter	Description	Value
<i>interface-type interface-number</i>	Displays the packet loss measurement result on the direct link of a specified interface.	-
<b>forward</b>	Displays the packet loss measurement result of a forward flow on the direct link of a specified interface. A forward flow is sent by the local device interface and received by the remote device interface.	-
<b>backward</b>	Displays the packet loss measurement result of a backward flow on the direct link of a specified interface. A backward flow is sent by the remote device interface and received by the local device interface.	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

You can run this command to view the packet loss measurement result in the forward and backward directions, including the number of discarded packets and packet loss ratio.

## Example

# Display the packet loss measurement result on the direct link of GE0/0/1.

```
<HUAWEI> display iplpm loss-measure statistics interface gigabitethernet 0/0/1
Latest forward loss statistics of interface GigabitEthernet0/0/1:
```

```
-----
StartTime(DST)   Forward Loss Packets  Forward LossRatio
ErrorInfo
-----
2014-03-19 15:50:50  200                19.980020%      OK
2014-03-19 15:50:40  200                20.000000%      OK
2014-03-19 15:50:30  200                19.980020%      OK
2014-03-19 15:50:20  200                20.020020%      OK
2014-03-19 15:50:10  200                20.000000%      OK
2014-03-19 15:50:00  200                19.980020%      OK
-----
```

```
Latest backward loss statistics of interface
GigabitEthernet0/0/1:
```

```
-----
StartTime(DST)   Backward Loss Packets  Backward LossRatio
ErrorInfo
-----
2014-03-19 15:50:50  0                   0.000000%      OK
2014-03-19 15:50:40  0                   0.000000%      OK
2014-03-19 15:50:30  0                   0.000000%      OK
2014-03-19 15:50:20  0                   0.000000%      OK
2014-03-19 15:50:10  0                   0.000000%      OK
2014-03-19 15:50:00  0                   0.000000%      OK
-----
```

**Table 16-52** Description of the **display iplpm loss-measure statistics interface** command output

Item	Description
Latest forward loss statistics of interface <i>x</i>	Latest statistics about packet loss measurement of a forward target flow on the direct link of the <i>x</i> interface (a forward flow is sent by the local device interface and received by the remote device interface).

Item	Description
Latest backward loss statistics of interface $x$	Latest statistics about packet loss measurement of a backward target flow on the direct link of the $x$ interface (a backward flow is sent by the remote device interface and received by the local device interface).
StartTime(DST)	Time the packet loss measurement result was generated (standard DST), which is also the start time of each measurement interval.
Forward Loss Packets	Number of discarded packets of a forward flow in the current measurement interval.
Forward LossRatio	Packet loss ratio of a forward flow in the current measurement interval.
Backward Loss Packets	Number of discarded packets of a backward flow in the current measurement interval.
Backward LossRatio	Packet loss ratio of a backward flow in the current measurement interval.
ErrorInfo	<p>Error code about packet loss measurement in the current measurement interval:</p> <ul style="list-style-type: none"> <li>• Init: The device is in initialized state and there is no statistics data.</li> <li>• OK: There is no error, and the packet loss measurement result is normal.</li> <li>• NoRecvData: The local end does not receive statistics data from the remote end. The possible causes may be that the packet loss measurement on a direct link is not enabled on the remote device or the direct link becomes faulty or there is a forwarding node on the link.</li> <li>• DataErr: The local end receives error statistics data from the remote end.</li> <li>• DiffAuth: The authentication modes or passwords on both ends are different.</li> <li>• DiffIntvl: The measurement intervals on both ends are different.</li> <li>• ASynClock: The time on both ends is asynchronous. When this code occurs, check the NTP configuration.</li> <li>• PortIsDown: The interface is Down.</li> </ul>

## 16.5.18 display iplpm loss-measure statistics port-flow interface interface

### Function

The **display iplpm loss-measure statistics port-flow interface** command displays statistics about discarded packets on an interface.

### Format

**display iplpm loss-measure statistics port-flow interface** *interface-type interface-number*

### Parameters

Parameter	Description	Value
<i>interface-type interface-number</i>	Displays statistics about discarded packets on a specified interface.	-

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

When you find packet loss on an interface in the packet loss measurement result on the direct link in the **display iplpm loss-measure statistics interface** command output, you can run the **display iplpm loss-measure statistics port-flow interface** command to check the statistics data. Then you can check whether the fault on the local interface causes packet loss.

### Example

# Display statistics about discarded packets on GE0/0/1.

```
<HUAWEI> display iplpm loss-measure statistics port-flow interface gigabitethernet 0/0/1
Latest port loss statistics of interface GigabitEthernet0/0/1:
-----
StartTime(DST)      Output Packets Loss Ratio  Input Packets Loss Ratio
-----
2014-04-01 18:09:40  0.000000%                 0.000000%
2014-04-01 18:09:30  0.000000%                 0.000000%
2014-04-01 18:09:20  0.000000%                 0.000000%
2014-04-01 18:09:10  0.000000%                 0.000000%
-----
```

**Table 16-53** Description of the **display iplpm loss-measure statistics port-flow interface** command output

Item	Description
Latest port loss statistics of interface <i>x</i>	Latest statistics about packet loss measurement on the <i>x</i> interface.
StartTime(DST)	Time the packet loss measurement result was generated (standard DST), which is also the start time of each measurement interval.
Output Packets Loss Ratio	Packet loss rate of packets sent from the local interface and received by the peer interface during the current statistics interval.
Input Packets Loss Ratio	Packet loss rate of packets sent from the peer interface and received by the local interface during the current statistics interval.

## 16.5.19 display iplpm loss-measure statistics qos-queue interface

### Function

The **display iplpm loss-measure statistics qos-queue interface** command displays statistics about sent packets in QoS queues on an interface.

### Format

**display iplpm loss-measure statistics qos-queue interface** *interface-type interface-number*

### Parameters

Parameter	Description	Value
<i>interface-type interface-number</i>	Displays statistics about sent packets in QoS queues on a specified interface.	-

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

When you find packet loss on an interface in the packet loss measurement result on the direct link in the [display iplpm loss-measure statistics interface](#)



command output, you can run the **display iplpm loss-measure statistics qos-queue interface** command to check the statistics about sent packets in QoS queues on an interface. Then you can check whether congestion in queues causes packet loss.

## Example

# Display statistics about sent packets in QoS queues on GE0/0/1.

```
<HUAWEI> display iplpm loss-measure statistics qos-queue interface gigabitethernet 0/0/1
Latest qos queue loss statistics of interface
GigabitEthernet0/0/1:
-----
StartTime(DST): 2014-03-19 16:25:10
Queue0 : 0.000000%      Queue1: 0.000000%
Queue2 : 0.000000%      Queue3: 0.000000%
Queue4 : 0.000000%      Queue5: 0.000000%
Queue6 : 0.000000%      Queue7: 0.000000%
UserQueue: 0.000000%

StartTime(DST): 2014-03-19 16:25:00
Queue0 : 0.000000%      Queue1: 0.000000%
Queue2 : 0.000000%      Queue3: 0.000000%
Queue4 : 0.000000%      Queue5: 0.000000%
Queue6 : 0.000000%      Queue7: 0.000000%
UserQueue: 0.000000%
-----
```

**Table 16-54** Description of the display iplpm loss-measure statistics qos-queue interface command output

Item	Description
StartTime(DST)	Time the packet loss measurement result was generated (standard DST), which is also the start time of each measurement interval.
Queue0-Queue7	Packet loss ratios of queues 0 to 7 in the measurement interval, which is used for reference only.
UserQueue	Packet loss ratio of the subscriber queue on the interface in the current measurement interval. The value of this field can be obtained only when HQoS is configured, and is used for reference only.

## 16.5.20 display snmp-agent trap feature-name ipfpm all

### Function

The **display snmp-agent trap feature-name ipfpm all** command displays whether the switch is enabled to send traps of IP Flow Performance Measurement (IP FPM) module to the NMS.

### Format

```
display snmp-agent trap feature-name ipfpm all
```

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

#### Usage Scenario

After running the [snmp-agent trap enable feature-name ipfpm](#) command to enable the function of sending traps of IP FPM modules to the NMS, you can run the **display snmp-agent trap feature-name ipfpm all** command to check whether this function is enabled.

#### Prerequisites

SNMP has been enabled. For details, see [snmp-agent](#).

### Example

# Display whether the switch is enabled to send traps of IP FPM module to the NMS.

```
<HUAWEI> display snmp-agent trap feature-name ipfpm all
-----
Feature name: IPFPM
Trap number : 4
-----
Trap name           Default switch status  Current switch status
hwlpfpmLossRatioExceed  off                    on
hwlpfpmLossRatioRecovery off                    on
hwlpfpmTlpExceed      off                    on
hwlpfpmTlpRecovery     off                    on
```

**Table 16-55** Description of the **display snmp-agent trap feature-name ipfpm all** command output

Item	Description
Feature name	Name of the feature that generates traps.
Trap number	Number of traps generated by IP FPM module.
Trap name	Name of the trap. Traps of the IP FPM module include: <ul style="list-style-type: none"> <li>• hwlpfpmLossRatioExceed: The packet loss ratio exceeds the threshold.</li> <li>• hwlpfpmLossRatioRecovery: The default packet loss ratio is restored.</li> <li>• hwlpfpmTlpExceed: The number of TLPs exceeds the limit.</li> <li>• hwlpfpmTlpRecovery: The default number of TLPs is restored.</li> </ul>
Default switch status	Default status of a trap: <ul style="list-style-type: none"> <li>• on: The switch is enabled to send this trap to the NMS.</li> <li>• off: The switch is disabled to send this trap to the NMS.</li> </ul>
Current switch status	Current status of a trap: <ul style="list-style-type: none"> <li>• on: The switch is enabled to send this trap to the NMS.</li> <li>• off: The switch is disabled to send this trap to the NMS.</li> </ul> <p>This status can be configured using the <a href="#">snmp-agent trap enable feature-name ipfpm</a> command.</p>

## Related Topics

[16.5.48 snmp-agent trap enable feature-name ipfpm](#)

## 16.5.21 display snmp-agent trap feature-name iplpm all

### Function

The **display snmp-agent trap feature-name iplpm all** command displays whether the switch is enabled to send traps of IP Local Performance Measurement (IP LPM) module to the NMS.

### Format

**display snmp-agent trap feature-name iplpm all**

## Parameters

None

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

After running the **snmp-agent trap enable feature-name iplpm** command to enable the function of sending traps of IP LPM modules to the NMS, you can run the **display snmp-agent trap feature-name iplpm all** command to check whether this function is enabled.

### Prerequisites

SNMP has been enabled. For details, see [snmp-agent](#).

## Example

# Display whether the switch is enabled to send traps of IP LPM module to the NMS.

```
<HUAWEI> display snmp-agent trap feature-name iplpm all
-----
Feature name: iplpm
Trap number : 4
-----
Trap name           Default switch status  Current switch status
hwiplpmGlobalLossRatioExceed  on                    on
hwiplpmGlobalLossRatioRecovery on                    on
hwiplpmLinkForwardLossRatioExceed
                        on                    on
hwiplpmLinkForwardLossRatioRecovery
                        on                    on
```

**Table 16-56** Description of the **display snmp-agent trap feature-name iplpm all** command output

Item	Description
Feature name	Name of the feature that generates traps.
Trap number	Number of traps generated by IP LPM module.

Item	Description
Trap name	Name of the trap. Traps of the IP LPM module include: <ul style="list-style-type: none"> <li>• hwlplpmGlobalLossRatioExceed: The packet loss ratio of the entire device exceeds the upper limit.</li> <li>• hwlplpmGlobalLossRatioRecovery: The packet loss ratio of the entire device falls below the upper limit.</li> <li>• hwlplpmLinkForwardLossRatioExceed: The packet loss ratio of the link between directly connected devices exceeds the upper limit.</li> <li>• hwlplpmLinkForwardLossRatioRecovery: The packet loss ratio of the link between directly connected devices falls below the upper limit.</li> </ul>
Default switch status	Default status of a trap: <ul style="list-style-type: none"> <li>• on: The switch is enabled to send this trap to the NMS.</li> <li>• off: The switch is disabled to send this trap to the NMS.</li> </ul>
Current switch status	Current status of a trap: <ul style="list-style-type: none"> <li>• on: The switch is enabled to send this trap to the NMS.</li> <li>• off: The switch is disabled to send this trap to the NMS.</li> </ul> <p>This status can be configured using the <a href="#">snmp-agent trap enable feature-name iplpm</a> command.</p>

## Related Topics

[16.5.49 snmp-agent trap enable feature-name iplpm](#)

## 16.5.22 flow (IPFPM-DCP instance view)

### Function

The **flow** command configures a target flow in a measurement instance on a DCP.

The **undo flow** command deletes the target flow from a measurement instance on a DCP.

By default, no target flow is configured in a measurement instance on a DCP.

### Format

# Define a unidirectional flow.

- When the protocol of a target flow is TCP or UDP, run the following command:

```
flow { forward | backward } { protocol { tcp | udp } { source-port src-port-number1 [ to src-port-number2 ] | destination-port dest-port-number1 [ to dest-port-number2 ] } * | dscp dscp-value | source src-ip-address [ src-mask-length ] | destination dest-ip-address [ dest-mask-length ] } *
```

- When the protocol of a target flow is not TCP or UDP, run the following command:

```
flow { forward | backward } { protocol protocol-number | dscp dscp-value | source src-ip-address [ src-mask-length ] | destination dest-ip-address [ dest-mask-length ] } *
```

# Define a bidirectional symmetrical flow.

- When the protocol of a target flow is TCP or UDP, run the following command:

```
flow bidirectional { protocol { tcp | udp } { source-port src-port-number1 [ to src-port-number2 ] | destination-port dest-port-number1 [ to dest-port-number2 ] } * | dscp dscp-value | source src-ip-address [ src-mask-length ] | destination dest-ip-address [ dest-mask-length ] } *
```

- When the protocol of a target flow is not TCP or UDP, run the following command:

```
flow bidirectional { protocol protocol-number | dscp dscp-value | source src-ip-address [ src-mask-length ] | destination dest-ip-address [ dest-mask-length ] } *
```

# Cancel the configured target flow.

```
undo flow { forward | backward | bidirectional }
```

## Parameters

Parameter	Description	Value
<b>forward</b>	Indicates the forward flow.	-
<b>backward</b>	Indicates the backward flow.	-
<b>protocol</b> { <b>tcp</b>   <b>udp</b> }	Indicates that the protocol of a target flow is TCP or UDP.	-
<b>source-port</b> <i>src-port-number1</i>	Specifies the start source port number of a target flow.	The value is an integer that ranges from 1 to 65535.
<i>src-port-number2</i>	Specifies the end source port number of a target flow.	The value is an integer that ranges from 1 to 65535. <i>src-port-number2</i> must be larger than <i>src-port-number1</i> .
<b>destination-port</b> <i>dest-port-number1</i>	Specifies the start destination port number of a target flow.	The value is an integer that ranges from 1 to 65535.

Parameter	Description	Value
<i>dest-port-number2</i>	Specifies the end destination port number of a target flow.	The value is an integer that ranges from 1 to 65535. <i>dest-port-number2</i> must be larger than <i>dest-port-number1</i> .
<b>dscp</b> <i>dscp-value</i>	Specifies the value of a Differentiated Services CodePoint (DSCP) of a target flow.	The value is an integer that ranges from 0 to 63.
<b>source</b> <i>src-ip-address</i>	Specifies the source IP address of a target flow. Only unicast IP addresses are supported.	The value is in dotted decimal notation.
<i>src-mask-length</i>	Specifies the mask length of the source IP address of a target flow.	The value is an integer that ranges from 1 to 32.
<b>destination</b> <i>dest-ip-address</i>	Specifies the destination IP address of a target flow. Only unicast IP addresses are supported.	The value is in dotted decimal notation.
<i>dest-mask-length</i>	Specifies the mask length of the destination IP address of a target flow.	The value is an integer that ranges from 1 to 32.
<b>protocol</b> <i>protocol-number</i>	Specifies the protocol type of a target flow.	The value is an integer ranging from 1 to 5, 7 to 16, or 18 to 255. <b>NOTE</b> The value 6 indicates TCP and the value 17 indicates UDP.
<b>bidirectional</b>	Indicates the bidirectional symmetrical flow. <b>NOTE</b> If the target flow is symmetrical bidirectional, set <i>src-ip-address</i> to specify a source IP address and <i>dest-ip-address</i> to specify a destination IP address for the target flow.	-

## Views

IPFPM-DCP instance view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The target flow must be specified before each measurement.

A target flow is the objective in iPCA measurement, and can be defined by any combinations of source IP address, destination IP address, protocol type, DSCP value, source port number, and destination port number. Specifying more attributes can make the target flow accurate. Therefore, it is recommended that you specify more attributes to improve precision of measurement results.

### Precautions

An instance can have only one target flow configured, either unidirectional or bidirectional. A bidirectional target flow is logically two unidirectional flows in opposite directions.

- If the target flow in an instance is unidirectional, you can specify **forward** to configure a forward flow or **backward** to configure a backward flow.
- If the target flow in an instance is bidirectional, two situations are available:
  - If the bidirectional target flow is symmetrical, you can specify **bidirectional** to configure the bidirectional target flow characteristics, and you must specify the source and destination IP addresses. By default, the characteristics specified are used for the forward flow, and the reverse of those are used for the backward flow. Specifically, the source and destination IP addresses and port numbers specified for the forward flow are used respectively as the destination and source IP addresses and port numbers for the backward flow.
  - If the bidirectional target flow is asymmetrical, you must configure **forward** and **backward** in two command instances to configure the forward and backward flow characteristics.

Target flows in different IP FPM instances cannot have the same characteristics. The forward and backward target flows in an IP FPM instance cannot have the same characteristics neither.

## Example

# Configure a target flow of measurement instance 1 on a DCP.

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm dcp  
[HUAWEI-nqa-ipfpm-dcp] instance 1  
[HUAWEI-nqa-ipfpm-dcp-instance-1] flow bidirectional protocol udp source-port 1025 source 10.1.1.1  
destination 10.2.2.2
```

## Related Topics

[16.5.44 nqa ipfpm dcp](#)

[16.5.25 instance \(IPFPM-DCP view\)](#)



## 16.5.23 flow (IPFPM-MCP-ACH view)

### Function

The **flow** command configures the target flow direction in the Atomic Closed Hop (ACH) view.

The **undo flow** command deletes the target flow direction in the ACH view.

By default, no direction is configured for target flows in the ACH view.

### Format

**flow** { **forward** | **backward** }

**undo flow**

### Parameters

Parameter	Description	Value
<b>forward</b>	Indicates the forward target flow.	-
<b>backward</b>	Indicates the backward target flow.	-

### Views

IPFPM-MCP-ACH view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

Run the **flow** command in IP FPM hop-by-hop performance statistics scenarios.

#### Prerequisites

The **ach** command has been run to create an ACH and display the ACH view.

### Example

# Configure the forward target flow in the ACH view.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm mcp
[HUAWEI-nqa-ipfpm-mcp] instance 1
[HUAWEI-nqa-ipfpm-mcp-instance-1] ach 1
[HUAWEI-nqa-ipfpm-mcp-instance-1-ach-1] flow forward
```

## Related Topics

- [16.5.45 nqa ipfpm mcp](#)
- [16.5.26 instance \(IPFPM-MCP view\)](#)
- [16.5.2 ach](#)

## 16.5.24 in-group

### Function

The **in-group** command creates a Target Logical Port (TLP) in-group for the target flow.

The **undo in-group** command deletes a TLP in-group or deletes a TLP from a TLP in-group.

By default, no TLP in-group is configured for the target flow.

### Format

```
in-group dcp dcp-id tlp tlp-id  
undo in-group [ dcp dcp-id tlp tlp-id ]
```

### Parameters

Parameter	Description	Value
<b>dcp</b> <i>dcp-id</i>	Specifies a DCP to which TLPs in a TLP in-group belongs.	This value is in dotted decimal notation.
<b>tlp</b> <i>tlp-id</i>	Indicates a TLP in a TLP in-group.	The value is an integer ranging from 1 to 16777215.

### Views

IPFPM-MCP-ACH view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

In IP FPM hop-by-hop performance statistics scenarios, a hop is a set of links and interfaces that service packets travel through, from one measurement point or group to the next measurement point or group, and therefore is represented by (TLP in-group, TLP out-group). Performance statistics are implemented on the TLP in-point or in-group through which service packets enter a network and the TLP out-point or out-group through which service packets leave the network.

### Prerequisites

The **ach** command has been run to create an ACH and display the ACH view.

### Example

# Create a TLP in-group for the target flow.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm mcp
[HUAWEI-nqa-ipfpm-mcp] instance 1
[HUAWEI-nqa-ipfpm-mcp-instance-1] ach 1
[HUAWEI-nqa-ipfpm-mcp-instance-1-ach-1] in-group dcp 10.1.1.1 tlp 100
```

### Related Topics

[16.5.45 nqa ipfpm mcp](#)

[16.5.2 ach](#)

[16.5.24 in-group](#)

## 16.5.25 instance (IPFPM-DCP view)

### Function

The **instance** command creates an IPFPM-DCP instance and displays the IPFPM-DCP instance view, or directly displays the view of an existing IPFPM-DCP instance.

The **undo instance** command deletes an IPFPM-DCP instance.

By default, no IPFPM-DCP instance is created on a DCP.

### Format

**instance** *instance-id*

**undo instance** *instance-id*

### Parameters

Parameter	Description	Value
<i>instance-id</i>	Specifies the ID of an IPFPM-DCP instance.	The value is an integer that ranges from 1 to 8355838.

### Views

IPFPM-DCP view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The DCP collects statistics data based on measurement instances. Each measurement instance consists of the target flow, TLP, and measurement interval. The MCP reports measurement results based on measurement instances. The MCP summarizes and analyzes statistics data of the same measurement instance on all DCPs, and reports measurement results of target flows.

### Prerequisites

Global DCP has been enabled using the [nqa ipfpm dcp](#) command.

### Follow-up Procedure

Run the [flow](#) command to configure a target flow, run the [tlp](#) command to configure the TLPs of the measurement instance, and run the [interval](#) command to configure the measurement interval.

### Precautions

To measure packet loss for a specified service flow, create the same measurement instance on the MCP and DCP.

## Example

```
# Create IPFPM-DCP instance 1.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm dcp  
[HUAWEI-nqa-ipfpm-dcp] instance 1
```

## Related Topics

- [16.5.44 nqa ipfpm dcp](#)
- [16.5.9 description \(IPFPM-DCP instance view\)](#)
- [16.5.26 instance \(IPFPM-MCP view\)](#)
- [16.5.22 flow \(IPFPM-DCP instance view\)](#)
- [16.5.50 tlp](#)
- [16.5.27 interval \(IPFPM-DCP instance view\)](#)

## 16.5.26 instance (IPFPM-MCP view)

### Function

The **instance** command creates an IPFPM-MCP instance and displays the IPFPM-MCP instance view, or directly displays the view of an existing IPFPM-MCP instance.

The **undo instance** command deletes an IPFPM-MCP instance.

By default, no IPFPM-MCP instance is created on the MCP.

### Format

**instance** *instance-id*

**undo instance** *instance-id*

## Parameters

Parameter	Description	Value
<i>instance-id</i>	Specifies the ID of an IPFPM-MCP instance.	The value is an integer that ranges from 1 to 8355838.

## Views

IPFPM-MCP view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The DCP collects statistics data based on measurement instances. Each measurement instance consists of the target flow, TLP, and measurement interval. The MCP reports measurement results based on measurement instances. The MCP summarizes and analyzes statistics data of the same measurement instance on all DCPs, and reports measurement results of target flows.

### Prerequisites

Global MCP has been enabled using the [nqa ipfpm mcp](#) command.

### Precautions

To measure packet loss for a specified service flow, create the same measurement instance on the MCP and DCP.

## Example

```
# Create IPFPM-MCP instance 1.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm mcp  
[HUAWEI-nqa-ipfpm-mcp] instance 1
```

## Related Topics

[16.5.45 nqa ipfpm mcp](#)

[16.5.10 description \(IPFPM-MCP instance view\)](#)

[16.5.25 instance \(IPFPM-DCP view\)](#)

## 16.5.27 interval (IPFPM-DCP instance view)

### Function

The **interval** command sets the measurement interval of a measurement instance on a DCP.

The **undo interval** command restores the default measurement interval of a measurement instance on a DCP.

By default, the measurement interval of a measurement instance on a DCP is 10 seconds.

## Format

**interval** *interval*

**undo interval**

## Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the measurement interval of a measurement instance on a DCP.	The value is of the enumerated type and can be 1, 10, 60, or 600, in seconds.

## Views

IPFPM-DCP instance view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The measurement interval of a measurement instance on a DCP is the interval at which a TLP collects statistics on packets or bytes and records the timestamp of packet receiving or sending. It is also the interval at which a DCP reports statistics data to the MCP. A shorter interval indicates a higher frequency at which a DCP reports statistics data to the MCP, so the interval adjustment affects the performance of the DCP and MCP.

Considering factors such as the clock synchronization offset, maximum transmission delay, and device performance, you can run this command to change the measurement interval.

### Precautions

The measurement intervals of the same measurement instances on all DCPs must be the same; otherwise, the statistics data will be empty.

The measurement interval of a measurement instance cannot be changed when the measurement instance is running. If the measurement interval of a running measurement instance is changed, the statistics reported by MCP may be inaccurate. To change the measurement interval, run the **measure disable** command in the IPFPM-MCP instance view to disable the measurement, and then run the **measure enable** command to enable the measurement.

## Example

# Set the measurement interval of measurement instance 1 to 60s.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm dcp
[HUAWEI-nqa-ipfpm-dcp] instance 1
[HUAWEI-nqa-ipfpm-dcp-instance-1] interval 60
```

## Related Topics

[16.5.44 nqa ipfpm dcp](#)

[16.5.25 instance \(IPFPM-DCP view\)](#)

[16.5.22 flow \(IPFPM-DCP instance view\)](#)

## 16.5.28 ipfpm tlp

### Function

The **ipfpm tlp** command binds a Target Logical Port (TLP) to an interface in a measurement instance on a DCP.

The **undo ipfpm tlp** command unbinds a TLP from an interface in a measurement instance on a DCP.

By default, an interface is not bound to a TLP in a measurement instance on a DCP.

### Format

**ipfpm tlp** *tlp-id*

**undo ipfpm tlp** { *tlp-id* | **all** }

### Parameters

Parameter	Description	Value
<i>tlp-id</i>	Specifies the ID of a TLP.	The value is an integer that ranges from 1 to 16777215.
<b>all</b>	Cancels the binding between all TLPs and interfaces.	-

### Views

GE interface view, XGE interface view, Eth-Trunk interface view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

Before performing packet loss measurement, run this command to bind a TLP to an interface.

### Prerequisites

A Layer 2 or Layer 3 interface can be bound to a TLP. You can run the **undo portswitch** command to switch the interface to Layer 3 mode.

### Precautions

A TLP can be bound to only one interface on the DCPs associated with an MCP, and an interface can bound only one TLP.

## Example

```
# Bind GE0/0/1 to TLP 100.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] undo portswitch  
[HUAWEI-GigabitEthernet0/0/1] ipfpm tlp 100
```

## Related Topics

[16.5.50 tlp](#)

## 16.5.29 iplpm global loss-measure alarm enable

### Function

The **iplpm global loss-measure alarm enable** command enables the alarm and clear alarm of the packet loss ratio for device-level packet loss measurement.

The **undo iplpm global loss-measure alarm enable** command restores the default setting.

By default, the alarm and clear alarm of the packet loss ratio are disabled.

### Format

**iplpm global loss-measure alarm enable**

**undo iplpm global loss-measure alarm enable**

### Parameters

None

### Views

System view

### Default Level

2: Configuration level



## Usage Guidelines

After this command is used, the alarm threshold and clear alarm threshold of the packet loss ratio are 5% and 1%.

- If the packet loss ratio in five consecutive measurement intervals exceeds the alarm threshold, the device reports the `hwlpfpmLossRatioExceed` alarm to the NMS to notify the link fault in real time.
- If the packet loss ratio in five consecutive measurement intervals falls below or is equivalent to the clear alarm threshold, the device reports the `hwlpfpmLossRatioRecovery` alarm to the NMS to notify link recovery in real time.

## Example

# Enable the alarm and clear alarm of the packet loss ratio for device-level packet loss measurement.

```
<HUAWEI> system-view  
[HUAWEI] iplpm global loss-measure alarm enable
```

## 16.5.30 iplpm global loss-measure enable

### Function

The **iplpm global loss-measure enable** command enables packet loss measurement for a device.

The **undo iplpm global loss-measure enable** command disables packet loss measurement for a device.

By default, packet loss measurement for a device is disabled.

### Format

```
iplpm global loss-measure enable  
undo iplpm global loss-measure enable
```

### Parameters

None

### Views

System view

### Default Level

2: Configuration level

## Usage Guidelines

To measure the packet loss of a switch, run this command to enable packet loss measurement for the switch.

## Example

```
# Enable packet loss measurement for a device.
```

```
<HUAWEI> system-view  
[HUAWEI] iplpm global loss-measure enable
```

## 16.5.31 iplpm global loss-measure interval

### Function

The **iplpm global loss-measure interval** command configures the device-level packet loss measurement interval.

The **undo iplpm global loss-measure interval** command restores the default device-level packet loss measurement interval.

By default, the device-level packet loss measurement interval is 10s.

### Format

**iplpm global loss-measure interval** *interval*

**undo iplpm global loss-measure interval**

### Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the device-level packet loss measurement interval.	The value is of the enumerated type and can be 1, 10, 60, or 600, in seconds.

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

The device-level packet loss measurement interval refers to the period from received packet statistics collection to sent packet statistics collection. To ensure accuracy of statistics data, run the **undo iplpm global loss-measure enable** command to disable device-level packet loss measurement in the system view before changing the measurement interval.

## Example

```
# Set the device-level packet loss measurement interval to 60s.
```

```
<HUAWEI> system-view  
[HUAWEI] iplpm global loss-measure interval 60
```

## Related Topics

[16.5.30 iplpm global loss-measure enable](#)

## 16.5.32 iplpm link authentication-mode

### Function

The **iplpm link authentication-mode** command configures the authentication mode and password for packet loss measurement on a direct link.

The **undo iplpm link authentication-mode** command deletes the authentication mode and password.

By default, no authentication mode or password is configured for packet loss measurement on a direct link.

### Format

**iplpm link authentication-mode hmac-sha256 key-id *key-id* [ cipher ] *password***

**undo iplpm link authentication-mode**

### Parameters

Parameter	Description	Value
<b>hmac-sha256</b>	Uses HMAC-SHA256 to authenticate packets between devices.	-
<b>key-id</b> <i>key-id</i>	Specifies the ID of the authentication password.	The value is an integer that ranges from 1 to 64.
<b>cipher</b>	Specifies the cipher-text authentication password.	-
<i>password</i>	Specifies the authentication password.	The value is a character string without spaces. <ul style="list-style-type: none"><li>• The value is a string of 1 to 255 characters in plain text.</li><li>• The value is a string of 32 to 392 characters in cipher text.</li></ul>

### Views

GE interface view, XGE interface view

### Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

After packet loss measurement is configured on a direct link, statistics data on received and sent packets on an interface at one end is sent to an interface at the other end and summarized for packet loss measurement. This command is used to authenticate communication packets on the direct link, improving security.

### Precautions

When the authentication mode and password are configured on an interface, packets encapsulated with local statistics data sent from the interface are authenticated. Therefore, both interfaces of the direct link must be configured with the same authentication mode and password.

## Example

# Set the authentication mode to hmac-sha256 and password to **huawei** in cipher text for packet loss measurement on a direct link on the GE0/0/1.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] iplpm link authentication-mode hmac-sha256 key-id 1 cipher huawei
```

## 16.5.33 iplpm link loss-measure alarm enable

### Function

The **iplpm link loss-measure alarm enable** command enables the alarm and clear alarm of the packet loss ratio for packet loss measurement on a direct link.

The **undo iplpm link loss-measure alarm enable** command restores the default setting.

By default, the packet loss alarm and clear alarm are disabled for packet loss measurement on a direct link.

### Format

**iplpm link loss-measure alarm enable**

**undo iplpm link loss-measure alarm enable**

### Parameters

None

### Views

GE interface view, XGE interface view

### Default Level

2: Configuration level

## Usage Guidelines

After this command is used, the alarm threshold and clear alarm threshold of the packet loss ratio are 5% and 1%.

- If the packet loss ratio in five consecutive measurement intervals exceeds the alarm threshold, the device reports the `hwlpfpmLossRatioExceed` alarm to the NMS to notify the link fault in real time.
- If the packet loss ratio in five consecutive measurement intervals falls below the clear alarm threshold, the device reports the `hwlpfpmLossRatioRecovery` alarm to the NMS to notify link recovery in real time.

## Example

# On the GE0/0/1, enable the alarm and clear alarm of the packet loss ratio for packet loss measurement on a direct link.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] iplpm link loss-measure alarm enable
```

## 16.5.34 iplpm link loss-measure enable

### Function

The **iplpm link loss-measure enable** command enables packet loss measurement on the direct link.

The **undo iplpm link loss-measure enable** command disables packet loss measurement on the direct link.

By default, packet loss measurement is disabled on the direct link.

### Format

**iplpm link loss-measure enable**

**undo iplpm link loss-measure enable**

### Parameters

None

### Views

GE interface view, XGE interface view

### Default Level

2: Configuration level

## Usage Guidelines

To accurately locate packet loss on a link, run the **iplpm link loss-measure enable** command to enable packet loss measurement on the direct link between two devices.

This function must be enabled on both device interfaces of the direct link.

## Example

# On the GE0/0/1, enable packet loss measurement on the direct link.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] iplpm link loss-measure enable
```

## 16.5.35 iplpm link loss-measure interval

### Function

The **iplpm link loss-measure interval** command configures the interval for packet loss measurement on the direct link.

The **undo iplpm link loss-measure interval** command restores the default interval for packet loss measurement on the direct link.

By default, the interval for packet loss measurement on the direct link is 10s.

### Format

**iplpm link loss-measure interval** *interval*

**undo iplpm link loss-measure interval**

### Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the interval for packet loss measurement on the direct link.	The value is an integer that can be 1, 10, 60, or 600, in seconds.

### Views

GE interface view, XGE interface view

### Default Level

2: Configuration level

### Usage Guidelines

The interval for packet loss measurement on the direct link refers to the period from received packet statistics collection to sent packet statistics collection on a specified interface. To ensure accuracy of statistics data, run the **undo iplpm link loss-measure enable** command to disable packet loss measurement on the direct link in the interface view before changing the measurement interval.

## Example

# On the GE0/0/1, set the interval for packet loss measurement on the direct link to 60s.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] iplpm link loss-measure interval 60
```

## Related Topics

[16.5.34 iplpm link loss-measure enable](#)

# 16.5.36 iplpm loss-measure color-flag

## Function

The **iplpm loss-measure color-flag** command configures the color bit used in device-level packet loss measurement.

The **undo iplpm loss-measure color-flag** command restores the default color bit used in device-level packet loss measurement.

By default, bit 0 in the Flags field is used as the color bit for device-level packet loss measurement. The default configuration is recommended.

## Format

**iplpm loss-measure color-flag** { **tos-bit** *tos-bit* | **flags-bit0** }

**undo iplpm loss-measure color-flag**

## Parameters

Parameter	Description	Value
<b>tos-bit</b> <i>tos-bit</i>	Specifies bit 6 or 7 in the ToS field of IP packets as the color bit for device-level packet loss measurement.	The value is 6 or 7.
<b>flags-bit0</b>	Specifies bit 0 in the Flags field of IP packets as the color bit for device-level packet loss measurement.	-

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

Device-level packet loss measurement contains measurement on the entire device and direct link. Before deploying Packet Conservation Algorithm for Internet (iPCA) to implement device-level packet loss measurement, run this command to configure the color bit. You can select a color bit according to the actual situation and network planning.

### Precautions

Before changing the color bit for device-level packet loss measurement, run the **undo iplpm global loss-measure enable** command in the system view to disable device-level packet loss measurement. If packet loss measurement is configured on the direct link, run the **undo iplpm link loss-measure enable** command in the interface view to disable packet loss measurement on the direct link and ensure that the color bits on both devices of the direct link are changed to be the same.

When both network-level and device-level packet loss measurements are enabled on a device, the color bits must be differentiated.

## Example

# Configure bit 7 in the ToS field as the color bit for device-level packet loss measurement.

```
<HUAWEI> system-view  
[HUAWEI] iplpm loss-measure color-flag tos-bit 7
```

## Related Topics

[16.5.30 iplpm global loss-measure enable](#)

[16.5.34 iplpm link loss-measure enable](#)

## 16.5.37 loss-measure enable

### Function

The **loss-measure enable** command enables statistics collection based on the time range for a measurement instance on a DCP.

The **undo loss-measure enable** command disables statistics collection for a measurement instance on a DCP.

By default, statistics collection based on the time range is disabled for a measurement instance on a DCP.

### Format

**loss-measure enable** [ **mid-point** ] [ **time-range** *time-range* ]

**undo loss-measure enable** [ [ **mid-point** ] **time-range** [ *time-range* ] ]



## Parameters

Parameter	Description	Value
<b>mid-point</b>	<p>Enables on-demand packet loss measurement for mid-points.</p> <p>If this parameter is configured, on-demand packet loss measurement is enabled for all mid-points. If this parameter is not configured, on-demand packet loss measurement is enabled for all measurement points.</p> <p><b>NOTE</b></p> <p>The mid-point is only applied to hop-by-hop measurement.</p>	-
<b>time-range</b> <i>time-range</i>	Specifies the time range for statistics collection.	The value is 5, 10, 15, or 30, in minutes. The default value is 10 minutes.

## Views

IPFPM-DCP instance view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The IP FPM performance statistics serve as a reliable reference for assessing IP network performance and therefore are useful for fault diagnosis and service statistics. To monitor on-demand packet loss performance in a specified period or diagnose network faults and locate faulty nodes when network performance deteriorates, run the **loss-measure enable** command.

### Prerequisites

An IP FPM model has been established, including configuring a DCP and MCP, binding a TLP to a physical interface, and creating a target flow and IP FPM instance.

### Precautions

This command is not recorded in the configuration file after being executed.

After device restart, statistics collection based on the time range becomes invalid, and needs to be reconfigured.

Statistics collection based on the time range and continual statistics collection cannot be enabled simultaneously.

## Example

# Enable statistics collection based on the time range for a measurement instance on a DCP.

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm dcp  
[HUAWEI-nqa-ipfpm-dcp] instance 1  
[HUAWEI-nqa-ipfpm-dcp-instance-1] loss-measure enable time-range 30
```

## Related Topics

[16.5.44 nqa ipfpm dcp](#)

[16.5.25 instance \(IPFPM-DCP view\)](#)

[16.5.38 loss-measure enable continual](#)

# 16.5.38 loss-measure enable continual

## Function

The **loss-measure enable continual** command enables continual statistics collection for a measurement instance on a DCP.

The **undo loss-measure enable continual** command disables continual statistics collection for a measurement instance on a DCP.

By default, continual statistics collection is disabled for a measurement instance on a DCP.

## Format

**loss-measure enable continual**

**undo loss-measure enable continual**

## Parameters

None

## Views

IPFPM-DCP instance view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

If you are unaware of network performance degrading and want to continuously monitor packet loss on the network, run the **loss-measure enable continual** command to enable continual statistics collection.

### Prerequisites

An IP FPM model has been established, including configuring a DCP and MCP, binding a TLP to a physical interface, and creating a target flow and IP FPM instance.

### Precautions

Continual statistics collection and statistics collection based on the time range cannot be enabled simultaneously.

## Example

# Enable continual statistics collection for a measurement instance on a DCP.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm dcp
[HUAWEI-nqa-ipfpm-dcp] instance 1
[HUAWEI-nqa-ipfpm-dcp-instance-1] loss-measure enable continual
```

## Related Topics

[16.5.44 nqa ipfpm dcp](#)

[16.5.25 instance \(IPFPM-DCP view\)](#)

[16.5.37 loss-measure enable](#)

## 16.5.39 loss-measure ratio-threshold

### Function

The **loss-measure ratio-threshold** command configures the alarm and clear alarm thresholds of the packet loss ratio for a measurement instance on the MCP.

The **undo loss-measure ratio-threshold** command restores the default setting.

By default, the alarm and clear alarm thresholds of the packet loss ratio are not configured for a measurement instance on the MCP. That is, no alarm is generated for packet loss.

### Format

**loss-measure ratio-threshold upper-limit** *upper-limit* **lower-limit** *lower-limit*

**undo loss-measure ratio-threshold**

### Parameters

Parameter	Description	Value
<b>upper-limit</b> <i>upper-limit</i>	Specifies the alarm threshold for the packet loss ratio.	The value is a string of 1 to 10 digits and in the range of 0.000001 to 100. The value is accurate to six decimal places, in percentage.

Parameter	Description	Value
<b>lower-limit</b> <i>lower-limit</i>	Specifies the clear alarm threshold for the packet loss ratio.	The value is a string of 1 to 10 digits and in the range of 0.000001 to 100. The value is accurate to six decimal places, in percentage. <i>lower-limit</i> must be smaller than or equal to <i>upper-limit</i> .

## Views

IPFPM-MCP instance view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

After the alarm and clear alarm thresholds of the packet loss ratio are configured for a measurement instance on the MCP:

- If the packet loss ratio in five consecutive measurement intervals exceeds the alarm threshold, the MCP reports the `hwIpfpMcpLossRatioExceed` alarm to the NMS to notify the link fault in real time.
- If the packet loss ratio in five consecutive measurement intervals falls below the clear alarm threshold, the MCP reports the `hwIpfpMcpLossRatioRecovery` alarm to the NMS to notify link recovery in real time.

To facilitate operation and maintenance, you are advised to run this command to configure the alarm and clear alarm thresholds of the packet loss ratio for a measurement instance on the MCP according to network performance.

### Precautions

If you run the **loss-measure ratio-threshold** command multiple times, only the latest configuration takes effect.

This command only configures the alarm and clear alarm thresholds of the packet loss ratio for a measurement instance on the MCP. The `hwIpfpMcpLossRatioExceed` and `hwIpfpMcpLossRatioRecovery` alarms are triggered only when the alarm and clear alarm functions are enabled and the packet loss ratio in five consecutive measurement intervals reaches the threshold.

## Example

# Set the alarm and clear alarm thresholds of the packet loss ratio to 10% and 5.5% for measurement instance 1.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm mcp
[HUAWEI-nqa-ipfpm-mcp] instance 1
[HUAWEI-nqa-ipfpm-mcp-instance-1] loss-measure ratio-threshold upper-limit 10 lower-limit 5.5
```

## Related Topics

[16.5.45 nqa ipfpm mcp](#)

[16.5.26 instance \(IPFPM-MCP view\)](#)

[16.5.48 snmp-agent trap enable feature-name ipfpm](#)

## 16.5.40 mcp (IPFPM-DCP view)

### Function

The **mcp** command associates the MCP ID with all measurement instances of a DCP.

The **undo mcp** command disassociates the MCP ID from all measurement instances of a DCP.

By default, no MCP ID is associated with a measurement instance of a DCP.

### Format

**mcp** *mcp-id* [ **port** *port-number* ] [ **vpn-instance** *vpn-instance-name* | **net-manager-vpn** ]

**undo mcp**

### Parameters

Parameter	Description	Value
<i>mcp-id</i>	Specifies the MCP ID associated with all measurement instances of a DCP. It is recommended that you configure the router ID of the device as the MCP ID.	The value is in dotted decimal notation.
<b>port</b> <i>port-number</i>	Specifies the UDP port number through which the DCP and MCP communicate with each other.	The value is an integer that ranges from 1024 to 65535. The default value is 65030 and is recommended.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the VPN instance where the DCP and MCP communicate with each other.	The value must be an existing VPN instance name.
<b>net-manager-vpn</b>	Specifies the manager VPN where the DCP and MCP communicate with each other.	-

### Views

IPFPM-DCP view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In the IP Flow Performance Measurement (FPM) system, each measurement instance belongs to an MCP. Before a DCP sends statistics data of a measurement instance from TLPs to the MCP, you must associate the MCP ID with the measurement instance. The **mcp** command associates the MCP ID with all measurement instances of a DCP.

A DCP encapsulates statistics data collected from Target Logical Ports (TLPs) and MCP ID associated with all measurement instances on the DCP in a packet, and sends the packet with the MCP ID as the destination IP address. After receiving the packet sent from the DCP, the MCP compares the MCP ID in the packet with the MCP ID configured by the **mcp id** command:

- If the two MCP IDs are the same, the MCP accepts the packet, and then summarizes and calculates the statistics data.
- If the two MCP IDs are different, the MCP considers the packet invalid and discards it.

### Prerequisites

Global DCP has been enabled using the **nqa ipfpm dcp** command.

#### NOTE

If the DCP is required to send statistics data to the MCP through a specified VPN instance or manager VPN, the VPN instance must have been created on the DCP before you run the **mcp** command with **vpn-instance** *vpn-instance-name* or **net-manager-vpn** specified.

### Precautions

The MCP ID must be an IP address that DCPs can reach and must be the same as the MCP ID configured by the **mcp id** command on the MCP.

The UDP port number through which the DCP and MCP communicate with each other must be the same as the UDP port number configured by the **protocol udp port** command.

The **mcp** command associates the MCP ID with all measurement instances on the DCP. However, if some measurement instances on the DCP have been associated with the MCP ID configured by the **mcp** command, the measurement instances still use the MCP ID in the IPFPM-DCP instance view.

## Example

# Associate the MCP ID with all measurement instances of a DCP.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm dcp
[HUAWEI-nqa-ipfpm-dcp] mcp 10.1.1.1
```

## Related Topics

[16.5.44 nqa ipfpm dcp](#)

- [16.5.47 protocol udp port](#)
- [16.5.41 mcp \(IPFPM-DCP instance view\)](#)
- [16.5.42 mcp id](#)

## 16.5.41 mcp (IPFPM-DCP instance view)

### Function

The **mcp** command associates the MCP ID with a measurement instance of a DCP.

The **undo mcp** command disassociates the MCP ID from a measurement instance of a DCP.

By default, no MCP ID is associated with a measurement instance of a DCP.

### Format

**mcp** *mcp-id* [ **port** *port-number* ] [ **vpn-instance** *vpn-instance-name* | **net-manager-vpn** ]

**undo mcp**

### Parameters

Parameter	Description	Value
<i>mcp-id</i>	Specifies the MCP ID associated with a measurement instance of a DCP. It is recommended that you configure the router ID of the device as the MCP ID.	The value is in dotted decimal notation.
<b>port</b> <i>port-number</i>	Specifies the UDP port number through which the DCP and MCP communicate with each other.	The value is an integer that ranges from 1024 to 65535. The default value 65030 is recommended.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the VPN instance where the DCP and MCP communicate with each other.	The value is a string of 1 to 31 case-sensitive characters without spaces.
<b>net-manager-vpn</b>	Specifies the manager VPN where the DCP and MCP communicate with each other.	-

### Views

IPFPM-DCP instance view

### Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

Before a DCP sends statistics data of a measurement instance from TLPs to the MCP, you must associate the MCP ID with the measurement instance. The **mcp** command associates the MCP ID with a measurement instance of a DCP.

A DCP encapsulates statistics data collected from Target Logical Ports (TLPs) and MCP ID associated with a measurement instance of the DCP in a packet, and sends the packet with the MCP ID as the destination IP address. After receiving the packet sent from the DCP, the MCP compares the MCP ID in the packet with the MCP ID configured by the **mcp id** command:

- If the two MCP IDs are the same, the MCP accepts the packet, and then summarizes and calculates the statistics data.
- If the two MCP IDs are different, the MCP considers the packet invalid and discards it.

### Prerequisites

A measurement instance has been created on the DCP using the **instance** command.

### Precautions

The MCP ID must be an IP address that DCPs can reach and must be the same as the MCP ID configured by the **mcp id** command on the MCP.

The UDP port number through which the DCP and MCP communicate with each other must be the same as the UDP port number configured by the **protocol udp port** command.

The VPN instance has been created on the DCP before you configure **vpn-instance** *vpn-instance-name* or **net-manager-vpn** to allow the DCP to report the statistics to the MCP through the specified VPN or management VPN.

## Example

# Associate the MCP ID with a measurement instance of a DCP.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm dcp
[HUAWEI-nqa-ipfpm-dcp] instance 1
[HUAWEI-nqa-ipfpm-dcp-instance-1] mcp 10.1.1.1
```

## Related Topics

- [16.5.44 nqa ipfpm dcp](#)
- [16.5.25 instance \(IPFPM-DCP view\)](#)
- [16.5.40 mcp \(IPFPM-DCP view\)](#)
- [16.5.42 mcp id](#)



## 16.5.42 mcp id

### Function

The **mcp id** command configures the MCP ID in the IP Flow Performance Measurement (FPM) system.

The **undo mcp id** command deletes the MCP ID.

By default, no MCP ID is configured.

### Format

**mcp id** *mcp-id*

**undo mcp id**

### Parameters

Parameter	Description	Value
<i>mcp-id</i>	Specifies the MCP ID. It is recommended that you configure the router ID of the device as the MCP ID.	The value is in dotted decimal notation.

### Views

IPFPM-MCP view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

When the MCP communicates with a DCP, the DCP encapsulates statistics data collected from TLPs and MCP ID associated with a measurement instance by the **mcp** command in a packet, and sends the packet with the MCP ID as the destination IP address. After receiving the packet sent from the DCP, the MCP compares the MCP ID in the packet with the MCP ID of the device:

- If the two MCP IDs are the same, the MCP accepts the packet, and then summarizes and calculates the statistics data.
- If the two MCP IDs are different, the MCP considers the packet invalid and discards it.

This command configures the MCP ID.

#### Prerequisites

Global MCP has been enabled using the **nqa ipfpm mcp** command.

#### Precautions

The MCP ID must be an IP address that a DCP can reach and must be the same as the MCP ID configured by the **mcp** command on the DCP. If you have changed the MCP ID, you must change the MCP ID associated with measurement instances on the DCP; otherwise, the DCP cannot communicate with the MCP.

## Example

```
# Set the MCP ID.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm mcp  
[HUAWEI-nqa-ipfpm-mcp] mcp id 10.1.1.1
```

## Related Topics

[16.5.8 dcp id](#)

[16.5.45 nqa ipfpm mcp](#)

[16.5.41 mcp \(IPFPM-DCP instance view\)](#)

## 16.5.43 measure disable (IPFPM-MCP instance view)

### Function

The **measure disable** command disables measurement of all indicators in a measurement instance on the MCP.

Both the **undo measure disable** and **measure enable** commands enable measurement of all indicators in a measurement instance on the MCP.

By default, measurement of all indicators is enabled in a measurement instance on the MCP.

### Format

**measure disable**

**measure enable**

**undo measure disable**

### Parameters

None

### Views

IPFPM-MCP instance view

### Default Level

2: Configuration level

## Usage Guidelines

If the MCP receives error data during the DCP configuration update, you can run the **measure disable** command to disable measurement of all indicators in a measurement instance on the MCP. When the DCP configuration update is complete, run the **undo measure disable** or **measure enable** command to enable measurement of all indicators in a measurement instance on the MCP so that data of the measurement instance is more accurate.

## Example

# Disable measurement of all indicators in measurement instance 1 on the MCP.

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm mcp  
[HUAWEI-nqa-ipfpm-mcp] instance 1  
[HUAWEI-nqa-ipfpm-mcp-instance-1] measure disable
```

## Related Topics

[16.5.45 nqa ipfpm mcp](#)

# 16.5.44 nqa ipfpm dcp

## Function

The **nqa ipfpm dcp** command enables global DCP and displays the IPFPM-DCP view, or directly displays the IPFPM-DCP view if global DCP has been enabled.

The **undo nqa ipfpm dcp** command disables global DCP.

By default, global DCP is disabled.

## Format

**nqa ipfpm dcp**

**undo nqa ipfpm dcp**

## Parameters

None

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

Before performing packet loss measurement for service traffic, run the **nqa ipfpm dcp** command to enable global DCP and enter the IPFPM-DCP view.

#### Follow-up Procedure

Run the **dcp id** command to set the DCP ID.

#### Precautions

DCP and MCP functions can be configured on the same device.

## Example

# Enable global DCP and enter the IPFPM-DCP view.

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm dcp  
[HUAWEI-nqa-ipfpm-dcp]
```

## Related Topics

[16.5.8 dcp id](#)

[16.5.45 nqa ipfpm mcp](#)

## 16.5.45 nqa ipfpm mcp

### Function

The **nqa ipfpm mcp** command enables global MCP and displays the IPFPM-MCP view, or directly displays the IPFPM-MCP view if global MCP has been enabled.

The **undo nqa ipfpm mcp** command disables global MCP.

By default, global MCP is disabled.

### Format

**nqa ipfpm mcp**

**undo nqa ipfpm mcp**

### Parameters

None

### Views

System view

### Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

Before performing packet loss measurement for service traffic, run the **nqa ipfpm mcp** command to enable global MCP and enter the IPFPM-MCP view.

#### Follow-up Procedure

Run the **mcp id** command to set the MCP ID.

#### Precautions

MCP and DCP functions can be configured on the same device.

### Example

# Enable global MCP and enter the IPFPM-MCP view.

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm mcp  
[HUAWEI-nqa-ipfpm-mcp]
```

### Related Topics

[16.5.42 mcp id](#)

[16.5.44 nqa ipfpm dcp](#)

## 16.5.46 out-group

### Function

The **out-group** command creates a Target Logical Port (TLP) out-group for the target flow.

The **undo out-group** command deletes a TLP out-group or deletes a TLP from a TLP out-group.

By default, no TLP out-group is configured for the target flow.

### Format

**out-group dcp** *dcp-id tlp tlp-id*

**undo out-group** [ **dcp** *dcp-id tlp tlp-id* ]

### Parameters

Parameter	Description	Value
<b>dcp</b> <i>dcp-id</i>	Indicates a DCP to which TLPs in a TLP out-group belongs.	This value is in dotted decimal notation.
<b>tlp</b> <i>tlp-id</i>	Indicates a TLP in a TLP out-group.	The value is an integer ranging from 1 to 16777215.

### Views

IPFPM-MCP-ACH view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To measure the packet loss or delay of service packets leaving a network, run the **out-group** command. In IP FPM hop-by-hop performance statistics scenarios, a hop is a set of links and interfaces that service packets travel through, from one measurement point or group to the next measurement point or group, and therefore is represented by (TLP in-group, TLP out-group). Performance statistics are implemented on the TLP in-point or in-group through which service packets enter a network and the TLP out-point or out-group through which service packets leave the network.

### Prerequisites

The **ach** command has been run to create an ACH and display the ACH view.

## Example

# Create a TLP out-group for the target flow.

```
<HUAWEI> system-view
[HUAWEI] nqa ipfpm mcp
[HUAWEI-nqa-ipfpm-mcp] instance 1
[HUAWEI-nqa-ipfpm-mcp-instance-1] ach 1
[HUAWEI-nqa-ipfpm-mcp-instance-1-ach-1] out-group dcp 10.1.1.1 tlp 100
```

## Related Topics

[16.5.45 nqa ipfpm mcp](#)

[16.5.2 ach](#)

[16.5.24 in-group](#)

## 16.5.47 protocol udp port

### Function

The **protocol udp port** command configures the UDP port number through which the DCP and MCP communicate with each other.

The **undo protocol udp port** command restores the default UDP port number through which the DCP and MCP communicate with each other.

By default, the DCP and MCP communicate with each other through UDP port 65030. The default configuration is recommended.

### Format

**protocol udp port** *port-number*

**undo protocol udp port**

## Parameters

Parameter	Description	Value
<i>port-number</i>	Specifies the UDP port number through which the DCP and MCP communicate with each other.	The value is an integer that ranges from 1024 to 65535.

## Views

IPFPM-MCP view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The DCP uses UDP and default port 65030 to send statistics data to the MCP. To change the UDP port number, run this command.

### Prerequisites

Global MCP has been enabled using the [nqa ipfpm mcp](#) command.

### Precautions

The UDP port number of the DCP must be the same as the UDP port number configured by the [mcp \(IPFPM-DCP instance view\)](#) command on the DCP. If a UDP port number is changed on an MCP, it must be changed for all DCPs associated with this MCP in an IP FPM instance. Otherwise, the MCP cannot process the statistics reported by the DCPs.

## Example

# Specify UDP port 1024 through which the DCP and MCP communicate with each other.

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm mcp  
[HUAWEI-nqa-ipfpm-mcp] protocol udp port 1024
```

## Related Topics

[16.5.42 mcp id](#)

[16.5.45 nqa ipfpm mcp](#)

[16.5.44 nqa ipfpm dcp](#)

## 16.5.48 snmp-agent trap enable feature-name ipfpm

### Function

The **snmp-agent trap enable feature-name ipfpm** command enables the trap function for the IP Flow Performance Measurement (FPM) module.

The **undo snmp-agent trap enable feature-name ipfpm** command disables the trap function for the IP FPM module.

By default, the trap function is disabled for the IP FPM module.

### Format

```
snmp-agent trap enable feature-name ipfpm [ trap-name
{ hwipfpmlossratioexceed | hwipfpmlossratiorecovery | hwipfpmtlpexceed |
hwipfpmtlprecovery } ]
```

```
undo snmp-agent trap enable feature-name ipfpm [ trap-name
{ hwipfpmlossratioexceed | hwipfpmlossratiorecovery | hwipfpmtlpexceed |
hwipfpmtlprecovery } ]
```

### Parameters

Parameter	Description	Value
<b>trap-name</b>	Enables the trap function for the specified event.	-
<b>hwipfpmlossratioexceed</b>	Enables the trap function about the packet loss ratio exceeding the threshold.	-
<b>hwipfpmlossratiorecovery</b>	Enables the trap function about the packet loss ratio restoration.	-
<b>hwipfpmtlpexceed</b>	Enables the trap function for TLPs exceeding the specifications.	-
<b>hwipfpmtlprecovery</b>	Enables the trap function for TLP specification restoration.	-

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The Simple Network Management Protocol (SNMP) is a network management standard widely used on the TCP/IP network. It uses a central computer (a



network management station) that runs network management software to manage network elements. The SNMP agent reports trap messages to the network management station so that the network management station can obtain the network status in a timely manner, and the network administrator can take measures accordingly.

The **snmp-agent trap enable feature-name ipfpm** command enables the trap function for the IP FPM module.

### Precautions

To enable the trap function for one or several events, specify **trap-name**. If **trap-name** is not specified, all trap functions are enabled for the IP FPM module.

### Example

# Enable the trap function about the packet loss ratio exceeding the threshold.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent trap enable feature-name ipfpm trap-name hwipfpmlossratioexceed
```

### Related Topics

[16.5.20 display snmp-agent trap feature-name ipfpm all](#)

## 16.5.49 snmp-agent trap enable feature-name iplpm

### Function

The **snmp-agent trap enable feature-name iplpm** command enables the trap function for the IP Local Performance Measurement (LPM) module.

The **undo snmp-agent trap enable feature-name iplpm** command disables the trap function for the IP LPM module.

By default, the trap function is enabled for the IP LPM module.

### Format

```
snmp-agent trap enable feature-name iplpm [ trap-name
{ hwiplpmgloballossratioexceed | hwiplpmgloballossratiorecovery |
hwiplpmlinkforwardlossratioexceed | hwiplpmlinkforwardlossratiorecovery } ]
```

```
undo snmp-agent trap enable feature-name iplpm [ trap-name
{ hwiplpmgloballossratioexceed | hwiplpmgloballossratiorecovery |
hwiplpmlinkforwardlossratioexceed | hwiplpmlinkforwardlossratiorecovery } ]
```

### Parameters

Parameter	Description	Value
<b>trap-name</b>	Enables the trap function for the specified event.	-

Parameter	Description	Value
<b>hwiplpmgloballossratioexceed</b>	Enables the trap function about the packet loss ratio exceeding the threshold on the device.	-
<b>hwiplpmgloballossratiorecovery</b>	Enables the trap function about the packet loss ratio restoration on the device.	-
<b>hwiplpmlinkforwardlossratioexceed</b>	Enables the trap function about the packet loss ratio exceeding the threshold on the direct link.	-
<b>hwiplpmlinkforwardlossratiorecovery</b>	Enables the trap function about the packet loss ratio restoration on the direct link.	-

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The Simple Network Management Protocol (SNMP) is a network management standard widely used on the TCP/IP network. It uses a central computer (a network management station) that runs network management software to manage network elements. The SNMP agent reports trap messages to the network management station so that the network management station can obtain the network status in a timely manner, and the network administrator can take measures accordingly.

The **snmp-agent trap enable feature-name iplpm** command enables the trap function for the IP LPM module.

### Precautions

To enable the trap function for one or several events, specify **trap-name**. If **trap-name** is not specified, all trap functions are enabled for the IP LPM module.

## Example

# Enable the trap function about the packet loss ratio exceeding the threshold on the direct link.

```
<HUAWEI> system-view
[HUAWEI] snmp-agent trap enable feature-name iplpm trap-name hwiplpmlinkforwardlossratioexceed
```

## Related Topics

[16.5.21 display snmp-agent trap feature-name iplpm all](#)

## 16.5.50 tlp

### Function

The **tlp** command configures Target Logical Ports (TLPs) of an IP FPM instance and their roles.

The **undo tlp** command deletes TLPs of a measurement instance.

By default, no TLP of a measurement instance is configured.

### Format

```
tlp tlp-id { in-point | out-point } { ingress | egress }
```

```
tlp tlp-id mid-point flow { forward | backward | bidirectional } { ingress | egress }
```

```
undo tlp tlp-id
```

### Parameters

Parameter	Description	Value
<i>tlp-id</i>	Specifies the ID of a TLP.	The value is an integer that ranges from 1 to 16777215.
<b>in-point</b>	Indicates the in-point TLP. An in-point TLP colors a target flow.	-
<b>out-point</b>	Indicates the out-point TLP. An out-point TLP removes the color flag from a target flow.	-
<b>ingress</b>	Indicates the ingress TLP. An ingress TLP only receives packets.	-
<b>egress</b>	Indicates the egress TLP. An egress TLP only sends packets.	-
<b>mid-point</b>	Indicates the TLP as a mid-point.	-
<b>flow</b>	Indicates the target flow.	-
<b>forward</b>	Indicates the forward target flow.	-
<b>backward</b>	Indicates the backward target flow.	-
<b>bidirectional</b>	Indicates the bidirectional target flows.	-

### Views

IPFPM-DCP instance view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

To locate faults in IP FPM performance statistics scenarios, run the **tlp** command to configure TLPs in an IP FPM instance. TLPs are measurement points along the path of the target flow and compile and output the statistics. TLPs can be in-points, mid-points, or out-points.

### Precautions

A TLP that functions as the in-point for the forward target flow is the out-point for the backward target flow. The TLP role specified in the **tlp** command applies only to the forward target flow, and the reverse of the specified role is used for the backward target flow.

Mid-points apply only to IP FPM hop-by-hop performance statistics scenarios. Therefore, you must configure **flow** to specify the target flow direction when specifying a TLP as a mid-point.

A TLP cannot function as both the in-point and out-point for the same unidirectional target flow.

## Example

```
# Configure TLP 100 and its role for measurement instance 1.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa ipfpm dcp  
[HUAWEI-nqa-ipfpm-dcp] instance 1  
[HUAWEI-nqa-ipfpm-dcp-instance-1] tlp 100 in-point ingress
```

## Related Topics

- [16.5.44 nqa ipfpm dcp](#)
- [16.5.25 instance \(IPFPM-DCP view\)](#)
- [16.5.28 ipfpm tlp](#)

# 16.6 NQA Configuration Commands

- [16.6.1 Command Support](#)
- [16.6.2 agetime](#)
- [16.6.3 clear-records](#)
- [16.6.4 community read cipher](#)
- [16.6.5 datafill](#)
- [16.6.6 datasize](#)
- [16.6.7 description \(NQA view\)](#)

- 16.6.8 destination-address
- 16.6.9 destination-port
- 16.6.10 display nqa history
- 16.6.11 display nqa results
- 16.6.12 display nqa-agent
- 16.6.13 display nqa-server
- 16.6.14 dns-server
- 16.6.15 fail-percent
- 16.6.16 frequency
- 16.6.17 ftp-filename
- 16.6.18 ftp-filesize
- 16.6.19 ftp-operation
- 16.6.20 ftp-password
- 16.6.21 ftp-username
- 16.6.22 http-operation
- 16.6.23 http-url
- 16.6.24 icmp-jitter-mode
- 16.6.25 interval (NQA view)
- 16.6.26 ip-forwarding
- 16.6.27 jitter-packetnum
- 16.6.28 local-pw-id
- 16.6.29 local-pw-type
- 16.6.30 label-type
- 16.6.31 lsp-exp
- 16.6.32 lsp-nexthop
- 16.6.33 lsp-replymode
- 16.6.34 lsp-tetunnel
- 16.6.35 lsp-type
- 16.6.36 lsp-version
- 16.6.37 md
- 16.6.38 mep
- 16.6.39 nexthop
- 16.6.40 nqa

- 16.6.41 nqa-jitter tag-version
- 16.6.42 nqa-server tcpconnect
- 16.6.43 nqa-server udpecho
- 16.6.44 probe-count
- 16.6.45 probe-failtimes
- 16.6.46 records
- 16.6.47 remote-pw-id
- 16.6.48 restart (NQA view)
- 16.6.49 sendpacket passroute
- 16.6.50 send-trap
- 16.6.51 sender-address
- 16.6.52 set-df
- 16.6.53 source-address
- 16.6.54 source-interface
- 16.6.55 source-port
- 16.6.56 start
- 16.6.57 stop
- 16.6.58 test-failtimes
- 16.6.59 test-type
- 16.6.60 timestamp-unit
- 16.6.61 threshold
- 16.6.62 timeout
- 16.6.63 tos
- 16.6.64 tracert-hopfailtimes
- 16.6.65 tracert-lifetime
- 16.6.66 ttl
- 16.6.67 ttl-copymode
- 16.6.68 undo no-control-word
- 16.6.69 vc-type
- 16.6.70 vpn-instance (NQA view)

## 16.6.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

## 16.6.2 agetime

### Function

The **agetime** command sets the aging time of an NQA test instance.

The **undo agetime** command restores the default aging time of an NQA test instance.

The default aging time of an NQA test instance is 0, indicating that the test instance is not aged.

### Format

**agetime** *hh:mm:ss*

**undo agetime**

### Parameters

Parameter	Description	Value
<i>hh:mm:ss</i>	Specifies the aging time.	<i>hh</i> ranges from 0 to 23; <i>mm</i> ranges from 0 to 59; <i>ss</i> ranges from 0 to 59.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

To prevent endless running of a test instance, you need to age the test instance periodically. The **agetime** command can be used to configure the aging time to change the survival time of a test instance in the system.

- The aging time is started when the NQA test instance is in the inactive state. When the aging time expires, the system deletes the NQA test instance automatically.
- The aging time is reset when the NQA test instance is in the active state.

#### Prerequisites

The type of a test instance has been specified using the **test-type** command.

#### Precautions

The aging time of a running test instance cannot be changed.

## Example

# Set the aging time of NQA test instance **user test**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] agetime 1:0:0
```

## Related Topics

[16.6.40 nqa](#)

[16.6.59 test-type](#)

## 16.6.3 clear-records

### Function

The **clear-records** command clears statistics on NQA test instances.

### Format

**clear-records**

### Parameters

None

### Views

NQA view

### Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

After each test instance is complete, test results and historical information will be recorded in result and historical tables respectively. You can run the following commands to view the corresponding data and assess the network quality.

- The **display nqa results** command displays the results of an NQA test instance.
- The **display nqa history** command displays the historical records of an NQA test instance.

After several test instances are performed to detect network quality, there may be too many records in the statistics table. In this case, you can run the **clear-records** command to clear historical records and result records of an NQA test instance.



### Configuration Impact

Statistics cannot be restored after being cleared using the **clear-records** command.

### Precautions

Clearing statistics on the ongoing test is forbidden.

Before running the command, ensure that the test type specified by the **test-type** command exists.

## Example

# Clear all statistics on NQA test instance **user test**.

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type jitter  
[HUAWEI-nqa-user-test] clear-records
```

## Related Topics

- [16.6.40 nqa](#)
- [16.6.59 test-type](#)
- [16.6.10 display nqa history](#)
- [16.6.11 display nqa results](#)

## 16.6.4 community read cipher

### Function

The **community read cipher** command configures the community name for SNMP test.

The **undo community** command deletes the community name of SNMP test.

By default, the community name for SNMP test is public.

### Format

**community read cipher** *community-name*

**undo community**

## Parameters

Parameter	Description	Value
<i>community-name</i>	Specifies the community name for SNMP test.	The value is a string of case-sensitive characters without command line characters such as spaces and question marks. The length ranges from 1 to 32 for plain text and ranges from 32 to 68 for cipher text. <b>NOTE</b> When quotation marks are used around the string, spaces are allowed in the string.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

A community, uniquely identified by a community name, defines administrative relationships between NMSs and SNMP agents. The community name acts like a password to regulate access to an SNMP agent. An NMS can access an SNMP agent only if the community name carried in the SNMP request sent by the NMS is the same as the community name configured on the SNMP agent.

When the SNMP versions on agents are SNMPv1 or SNMPv2c, the community name must be configured using the **community read cipher** command, and the community name must be a read-only community name on SNMP agents. When the SNMP versions on agents are SNMPv3, the community name does not need to be configured because SNMPv3 does not support community names.

### Prerequisites

The NQA test instance has been configured using the **nqa** command, and the test instance type has been set to SNMP using the **test-type** command.

## Example

```
# Set the community name for SNMP test.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test1  
[HUAWEI-nqa-user-test1] test-type snmp  
[HUAWEI-nqa-user-test1] community read cipher Huawei-123
```

## 16.6.5 datafill

## Function

The **datafill** command configures pad characters in an NQA test instance.

The **undo datafill** command deletes the pad characters in an NQA test instance.

By default, there are no padding characters in an NQA test instance.

## Format

**datafill** *fillstring*

**undo datafill**

## Parameters

Parameter	Description	Value
<i>fillstring</i>	Specifies the pad characters for NQA test packets.	The value is a string of 1 to 230 case-sensitive characters with spaces supported. The question mark (?) is not supported. The default value is 0 (an empty pad character).

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In an NQA test, you need to simulate actual datagrams to obtain more accurate statistics. The **datasize** command can be used to set the size of the Data field. To differentiate packets sent from different test instances, add the specified characters to identify the test packets.

### Prerequisites

The type of a test instance has been specified using the **test-type** command. The type can be one of the following:

- UDP
- UDP Jitter
- ICMP
- Trace
- Path Jitter

### Configuration Impact

After the **datafill** command is run, the following situations may occur:

- If the length of the data packet sent from the test instance is shorter than the configured pad character, only the forepart of the pad character can be used.
- If the length of the data packet sent from the test instance is larger than the configured pad character, the pad character is repeated in sequence until the data packet is successfully padded.

For example, the pad character is set to **abcd**. If the length of the test packet is 3, only **abc** is used to pad the test packet. If the length of the test packet is 6, **abcdab** is used to pad the test packet.

#### Precautions

The pad character of a running test instance cannot be changed.

### Example

# Set the pad characters of the test named **user test** to **abcd**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] datafill abcd
```

### Related Topics

[16.6.40 nqa](#)

[16.6.59 test-type](#)

[16.6.6 datasize](#)

## 16.6.6 datasize

### Function

The **datasize** command sets the size of the NQA test packet.

The **undo datasize** command restores the size of the NQA test packet.

The default size is 0, which indicates that the test packet does not carry data information.

### Format

**datasize** *size*

**undo datasize**

## Parameters

Parameter	Description	Value
<i>size</i>	Specifies the size of the NQA test packet.	The value is an integer that ranges from 0 to 8100, in bytes. If the configured size of a packet is smaller than the default size of a packet, the configured size is invalid and the packet is forwarded based on its default size. <b>NOTE</b> Only for MAC ping test instance, the value ranges from 95 to 9000, in bytes.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

You can run the **datasize** command to set the size of the data field of a test packet. This ensures that the size of the test packet is closer to the size of the actual data packet and the obtained statistics are more accurate.

For example, if a UDP jitter test instance is used to detect voice over IP (VoIP) services, you can run the **datasize** command to set the size of the NQA test packet to the same size as the actual voice packet. This enables a simulation of the actual traffic that occurs in a period of time.

To simulate a voice data flow with the transmission rate of 64 kbit/s, you can set the size of the voice packet to 172 bytes (160-byte payload + 12-byte RTP header + 28-byte IP header and UDP header) and set the interval for sending the voice packet to 20 ms. In this manner, 3000 packets can be sent in one minute.

### Prerequisites

The test type has been specified using the **test-type** command.

The **datasize** command is applicable only to the LSP Ping, LSP Jitter, PWE3 Ping, ICMP, MAC Ping, Path Jitter, Trace, UDP, and UDP Jitter test instances.

### Precautions

You cannot change the size of the running test packets.

## Example

# Set the size of the packets to 100 bytes in the test instance named **user test**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] datasize 100
```

## Related Topics

- [16.6.40 nqa](#)
- [16.6.59 test-type](#)
- [16.6.25 interval \(NQA view\)](#)
- [16.6.5 datafill](#)

## 16.6.7 description (NQA view)

### Function

The **description** command configures description of an NQA test instance.

The **undo description** command deletes the description of an NQA test instance.

By default, no description is configured for an NQA test instance.

### Format

**description** *string*

**undo description**

### Parameters

Parameter	Description	Value
<i>string</i>	Specifies the description of an NQA test instance.	The value is a string of 1 to 230 case-sensitive characters with spaces.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The **description** command can be used to briefly describe the test instance to help maintenance. Generally, the test item or the test objective of a test instance is described.

### Prerequisites

The type of a test instance has been specified using the **test-type** command.

### Configuration Impact

If the description of a test instance has been configured, running the **description** command will override the previous configuration.

### Precautions

The description of a running test instance cannot be changed.

## Example

# Set the description of the test named **user test** to fortest.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type jitter
[HUAWEI-nqa-user-test] description fortest
```

## Related Topics

[16.6.40 nqa](#)

[16.6.59 test-type](#)

## 16.6.8 destination-address

### Function

The **destination-address** command specifies the destination address of an NQA test instance.

The **undo destination-address** command deletes the destination address of an NQA test instance.

By default, destination address is not configured for an NQA test instance.

### Format

**destination-address ipv4** *ipv4-address* [ **lsp-masklen** *masklen* | **lsp-loopback** *loopback-address* ] \* [ **vpn-frr-path** ]

**destination-address mac** *mac-address*

**destination-address remote-mep** *mep-id* *rmep-id*

**destination-address url** *urlstring*

**undo destination-address**

## Parameters

Parameter	Description	Value
<b>ipv4</b> <i>ipv4-address</i>	Specifies an IPv4 destination address.	The IPv4 address is in dotted decimal notation.
<b>lsp-masklen</b> <i>masklen</i>	Specifies the mask length of an LSP's IPv4 address prefix.	The value is an integer that ranges from 0 to 32.
<b>lsp-loopback</b> <i>loopback-address</i>	Specifies a 127/8 IP address in the MPLS echo request packet header.	-
<b>vpn-frr-path</b>	Indicates that the connectivity of the backup VPN FRR LSP will be checked.	-
<b>mac</b> <i>mac-address</i>	Specifies a unicast MAC address.	The value is in H-H-H format, in which H is a 16-bit binary number.
<b>remote-mep mep-id</b> <i>rmep-id</i>	Specifies the ID of a remote MEP.	The value is an integer that ranges from 1 to 8191.
<b>url</b> <i>urlstring</i>	Specifies a destination URL address.	The value is a string of 1 to 230 case-insensitive characters without spaces. When quotation marks are used around the string, spaces are allowed in the string.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

NQA detects service features by creating test instances. In NQA, two test ends are called an NQA client and an NQA server. An NQA test is initiated by the NQA client. For a test instance, the server is specified using the destination IP address configured with the **destination-address** command.

For example, to detect whether the peer device is reachable, run the **nqa** command to create an NQA test instance, set the test type to ICMP, and then run the **destination-address** command to configure the IP address of the peer device as the destination IP address. After that, you can start the test instance. Based on the response packet, you can know whether the peer device is reachable.



### Precautions

- The Label Switched Path (LSP) parameters can be configured only for the LSP test instances.
- The **mac** and **remote-mep mep-id** parameters can be configured only for MAC ping test instances.
- Only the destination addresses of HTTP, trace, and DNS test instances can be URL addresses. For the HTTP test instances, only absolute URL addresses are supported.
- The destination addresses of DNS test instances cannot be IPv4 addresses, and the destination URL addresses must contain dots (.); otherwise, the test will fail.
- You cannot change the destination address of a running test instance.

### Example

# Configure the destination address for test instance **user test**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] destination-address ipv4 10.1.1.1
```

### Related Topics

[16.6.40 nqa](#)

[16.6.59 test-type](#)

## 16.6.9 destination-port

### Function

The **destination-port** command configures the destination port number for an NQA test.

The **undo destination-port** command restores the default setting.

The default port numbers for test instances of different types are as follows:

- TCP and UDP: 7
- HTTP: 80
- FTP: 21
- Trace: 33434
- Jitter: No default value is available, and the destination port number must be configured.

#### NOTE

A port number larger than 10000 is recommended for a jitter test instance. A small port number may conflict with the default port number of a protocol, causing a test failure.

### Format

**destination-port** *port-number*

## undo destination-port

### Parameters

Parameter	Description	Value
<i>port-number</i>	Specifies the destination port number.	The value is integer that ranges from 1 to 65535. The configured port cannot be a well-known port or used by other modules.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

NQA detects service features by creating test instances. In NQA, two test ends are called an NQA client and an NQA server. An NQA test is initiated by the NQA client. After test instances are configured with commands on the client, NQA places different types of test instances into various test queues. After the test starts, a response packet is returned. Carriers can then know the operating status about protocols by analyzing the received response packet.

For a test instance, the port for accessing the server is specified using the destination port number configured with the **destination-port** command on the client.

For example, to detect whether the TCP service runs normally on the peer device using a TCP test instance, perform the following configurations:

- On the server: Configure the TCP server used for NQA tests, including the supported client IP address and the TCP port number opened to the client.
- On the client:
  - Create an NQA test instance and set its type to TCP.
  - Configure the IP address of the server as the destination IP address and configure the opened TCP port number on the server as the destination port number.
  - Start the test instance.

#### Precautions

In the case of a TCP test instance and a UDP test instance, the configured destination port number must be the same as the opened port number on the server.

This command applies to only the FTP, HTTP, TCP, Trace, UDP, and UDP Jitter test instances.

You cannot change the destination port number of the test that is being performed.

## Example

# Set the destination port number to 2020 for the test instance named **user test**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type jitter
[HUAWEI-nqa-user-test] destination-port 2020
```

## Related Topics

[16.6.40 nqa](#)

[16.6.59 test-type](#)

## 16.6.10 display nqa history

### Function

The **display nqa history** command displays the history records about an NQA test.

### Format

**display nqa history** [ **test-instance** *admin-name test-name* ]

### Parameters

Parameter	Description	Value
<b>test-instance</b>	Indicates NQA test instances.	-
<i>admin-name</i>	Specifies the name of the administrator for an NQA test instance.	The value must be the name of an existing NQA test instance administrator.
<i>test-name</i>	Specifies the name of an NQA test instance.	The value must be the name of an existing NQA test instance.

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

#### Usage Scenario

NQA provides NQA test instances to test network operation conditions, to export statistics, and to effectively cut costs. NQA measures the performance of different protocols running on the network.

The **display nqa history** command helps you understand the network status by displaying the operation statistics about each test packet, including the status and round-trip delay.

 **NOTE**

No history record about the failed UDP Jitter test instances exist.

**Precautions**

If no optional parameter is specified, all history records of an NQA test instance are displayed.

When NQA test result table and historical table are displayed in a split screen, latest results are displayed to improve user experience.

**Example**

# Display the history records about an NQA test.

```
<HUAWEI> display nqa history
NQA entry(admin, ftp) history:
Index T/H/P  Response Status    Address    Time
1     1/1/1  1157ms success    10.2.1.2   2012-07-15 10:16:38.188
2     2/1/1  3000ms success    10.2.1.2   2012-07-15 10:18:2.922
NQA entry(admin, http) history:
Index T/H/P  Response Status    Address    Time
1     1/1/1  0ms busy      unknown    2012-07-15 11:16:39.915
2     1/1/2  0ms busy      unknown    2012-07-15 11:16:39.978
3     1/1/3  0ms busy      unknown    2012-07-15 11:16:39.40
```

**Table 16-57** Description of the **display nqa history** command output

Item	Description
NQA entry(admin, ftp) history	The history records about an NQA test instance: <ul style="list-style-type: none"> <li>admin: administrator of an NQA test instance.</li> <li>ftp: name of an NQA test instance.</li> </ul> You can run the <b>nqa</b> command to configure this parameter.
Index	Index of a test record.
T/H/P	<ul style="list-style-type: none"> <li>T: Times, which indicates the sequence of the test for a test instance.</li> <li>H: Hop, which indicates the sequence of the hop.</li> <li>P: Probe, which indicates the sequence of the probe.</li> </ul>
Response	Period from the time when a probe packet is sent to the time when a response packet is received.

Item	Description
Status	Probe status: <ul style="list-style-type: none"> <li>• success: indicates that the probe succeeds.</li> <li>• timeout: indicates that the probe times out and no response packet is received.</li> <li>• busy: indicates that the resources are insufficient and the probe packet fails to be sent. When Status is busy, the value of the Response field is 0 ms.</li> <li>• drop: indicates that the probe packet is discarded because of no link is available. When Status is busy, the value of the Response field is 0 ms.</li> </ul>
Address	Destination IP address of an NQA test instance.
Time	Time when the response packet is received.

## Related Topics

[16.6.3 clear-records](#)

[16.6.46 records](#)

## 16.6.11 display nqa results

### Function

The **display nqa results** command displays NQA test results.

### Format

**display nqa results** [ **test-instance** *admin-name test-name* ] [ **verbose** ]

### Parameters

Parameter	Description	Value
<b>test-instance</b>	Indicates an NQA test instance.	-
<i>admin-name</i>	Specifies the name of the administrator for an NQA test instance.	The value must be the name of an existing NQA test instance administrator.
<i>test-name</i>	Specifies the name of an NQA test instance.	The value must be the name of an existing NQA test instance.
<b>verbose</b>	Displays detailed information. <b>NOTE</b> Only ICMP, UDP, ICMP Jitter, and UDP Jitter test instances support the query of details.	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

### Usage Scenario

NQA test results cannot be displayed automatically on the terminal. To view NQA test results, run the **display nqa results** command.

If no test instance is specified, the test result of the test instance is displayed in the corresponding test instance view, and the test result of all test instances is displayed in the system view or other views irrelevant to test instances. If a test instance is specified, the test result of only this test instance is displayed.

The output of the **display nqa results** command contains the following two parts:

- Universal test results: This part does not vary according to the test instance type.
- Detailed statistics of each test: Statistics items in this part vary according to the test instance type.

### Precautions

The **display nqa results** command only displays the result of a test instance that has been completed.

When NQA test result table and historical table are displayed in a split screen, latest results are displayed to improve user experience.

By default, the unit of the delay statistics field in the result table is millisecond. The **timestamp-unit** command specifies the unit of delay statistics fields in result tables of the UDP Jitter and ICMP Jitter test instances.

When you run the **display nqa results** command to check the results of a single UDP Jitter or ICMP Jitter test instance:

- If the value of **SendProbe** is 0, no test packet has been sent, and **Packet Loss Ratio** is displayed as 100% (default value).
- If the value of **SendProbe** is not 0 and the value of **Packet Loss Ratio** is 100%, all test packets have been lost.

When you run the **display nqa results collection** command to check the accumulative results of multiple UDP Jitter or ICMP Jitter test instances:

- If the value of **SendProbe** is 0, no test packet has been sent in these tests, and **Packet Loss Ratio** is displayed as 0% (default value).
- If the value of **SendProbe** is not 0 but the value of **Packet Loss Ratio** is 0%, no test packet has been lost.

Formula used to calculate the accumulative packet loss ratio: Accumulative packet loss ratio = (Accumulative number of sent packets – Accumulative number of received packets)/Accumulative number of sent packets x 100%. If the value of

**SendProbe** in the results of a single test is 0, it is not considered during the calculation of the accumulative packet loss ratio.

## Example

# Display the results of an NQA ICMP test.

```
<HUAWEI> display nqa results test-instance admin icmp
NQA entry(admin, icmp) :testflag is inactive ,testtype is icmp
1 . Test 1 result The test is finished
Send operation times: 3          Receive response times: 3
Completion:success             RTD OverThresholds number: 0
Attempts number:1              Drop operation number:0
Disconnect operation number:0   Operation timeout number:0
System busy operation number:0  Connection fail number:0
Operation sequence errors number:0 RTT Status errors number:0
Destination ip address:10.138.77.21
Min/Max/Average Completion Time: 2/2/2
Sum/Square-Sum Completion Time: 6/12
Last Good Probe Time: 2012-07-02 17:09:18.1
Lost packet ratio: 0 %
```

# Display detailed results of an NQA ICMP test.

```
<HUAWEI> display nqa results test-instance admin icmp verbose
NQA entry(admin, icmp) :testflag is inactive ,testtype is icmp
1 . Test 1 result The test is finished
Send operation times: 3          Receive response times: 3
Completion:success             RTD OverThresholds number: 0
Attempts number:1              Drop operation number:0
Disconnect operation number:0   Operation timeout number:0
System busy operation number:0  Connection fail number:0
Operation sequence errors number:0 RTT Status errors number:0
Destination ip address:10.138.77.21
Min/Max/Average Completion Time: 2/2/2
Sum/Square-Sum Completion Time: 6/12
Last Good Probe Time: 2012-07-02 17:09:18.1
Lost packet ratio: 0 %
Detailed result information:
```

**Table 16-58** Description of the **display nqa results test-instance admin icmp** and **display nqa results test-instance admin icmp verbose** command output

Item	Description
NQA entry(admin, icmp)	<p>NQA test items:</p> <ul style="list-style-type: none"> <li>admin: indicates the administrator or creator of the NQA test instance.</li> <li>icmp: indicates the name of the NQA test instance.</li> </ul> <p>You can run the <a href="#">16.6.40 nqa</a> command to configure this parameter.</p>
testflag	<p>Test flag.</p> <ul style="list-style-type: none"> <li>active: indicates that the test is running. Checking the result of a running test is invalid.</li> <li>inactive: indicates that the test is complete. At this time, the actual test result is displayed.</li> </ul>

Item	Description
testtype	Test type. You can run the <a href="#">16.6.59 test-type</a> command to configure this parameter.
1 . Test 1 result	Sequence number of test results. Test results are numbered based on the time when the tests are complete.
The test is finished	Test status: <ul style="list-style-type: none"> <li>finished: indicates that the test is complete.</li> <li>running: indicates that the test is running.</li> </ul>
Send operation times	Number of sent packets.
Receive response times	Number of received response packets.
Completion	Completing status of the test: <ul style="list-style-type: none"> <li>success: indicates that the test is complete successfully.</li> <li>no result: indicates that the test is running, so no test result is obtained or no test result is obtained after the test.</li> <li>failed: indicates that the test fails.</li> </ul>
RTD OverThresholds number	Number of times that the round-trip delay (RTD) threshold is exceeded.
Attempts number	Test times.
Drop operation number	Number of system resource allocation failures.
Disconnect operation number	Number of forcible disconnections.
Operation timeout number	Number of timeout operations during the test.
System busy operation number	Number of conflict operations.
Connection fail number	Number of times that the local end fails to establish connections with the peer.
Operation sequence errors number	Number of received disordered packets.
RTT Status errors number	Number of RTT status errors.



Item	Description
Destination ip address	Destination IP address of the test. You can run the <b>destination-address</b> command to configure this parameter.
Min/Max/Average Completion Time	Minimum/Maximum/Average time taken to complete the test.
Sum/Square-Sum Completion Time	Sum/square sum of the time taken to complete the test.
Last Good Probe Time	Time at which the last probe is complete.
Lost packet ratio	Packet loss ratio.
Detailed result information	Displays detailed result information.

# Display the result of an NQA UDP Jitter test.

```
<HUAWEI> display nqa results test-instance admin jitter
NQA entry(admin, jitter) :testflag is inactive ,testtype is jitter
1 . Test 1 result The test is finished
SendProbe:60 ResponseProbe:0
Completion:failed RTD OverThresholds number:0
Min/Max/Avg/Sum RTT:0/0/0/0 RTT Square Sum:0
NumOfRTT:0 Drop operation number:0
Operation sequence errors number:0 RTT Stats errors number:0
System busy operation number:0 Operation timeout number:60
Min Positive SD:0 Min Positive DS:0
Max Positive SD:0 Max Positive DS:0
Positive SD Number:0 Positive DS Number:0
Positive SD Sum:0 Positive DS Sum:0
Positive SD Square Sum:0 Positive DS Square Sum:0
Min Negative SD:0 Min Negative DS:0
Max Negative SD:0 Max Negative DS:0
Negative SD Number:0 Negative DS Number:0
Negative SD Sum:0 Negative DS Sum:0
Negative SD Square Sum:0 Negative DS Square Sum:0
Min Delay SD:0 Min Delay DS:0
Avg Delay SD:0 Avg Delay DS:0
Max Delay SD:0 Max Delay DS:0
Packet Loss SD:0 Packet Loss DS:0
Packet Loss Unknown:0 Average of Jitter:0
Average of Jitter SD:0 Average of Jitter DS:0
Jitter out value:0.0000000 Jitter in value:0.0000000
NumberOfOWD:0 OWD SD Sum:0
OWD DS Sum:0 TimeStamp unit: ms
Packet Rewrite Number: 0 Packet Rewrite Ratio: 0%
Packet Disorder Number: 0 Packet Disorder Ratio: 0%
Fragment-disorder Number: 0 Fragment-disorder Ratio: 0%
Start time: 2014-09-01 10:47:57+08:00
End time: 2014-09-01 10:48:01+08:00
```

**Table 16-59** Description of the **display nqa results test-instance admin jitter** command output

Item	Description
NQA entry(admin, jitter)	NQA test items: <ul style="list-style-type: none"> <li>• admin: indicates the name of the administrator for an NQA test instance.</li> <li>• jitter: indicates the name of the NQA test instance.</li> </ul>
testflag	Test flag: <ul style="list-style-type: none"> <li>• active: indicates that the test is running. Checking the test result during the operation is invalid.</li> <li>• inactive: indicates that the test is complete. At this time, the actual test result is displayed.</li> </ul>
testtype	Test type.
SendProbe	Number of sent probes.
ResponseProbe	Number of received response probes.
Completion	Completing status of the test: <ul style="list-style-type: none"> <li>• success: indicates that the test is complete successfully.</li> <li>• no result: indicates that the test is running, so no test result is obtained or no test result is obtained after the test.</li> <li>• failed: indicates that the test fails.</li> </ul>
RTD OverThresholds number	Number of times that the RTD threshold is exceeded.
Min/Max/Avg/Sum RTT	Minimum/Maximum/Average/Sum of the RTT.
RTT Square Sum	RTT square sum of the probes.
NumOfRTT	Number of RTTs.
Drop operation number	Number of system resource allocation failures.
Operation sequence errors number	Serial number of the error packets received by the client.
RTT Stats errors number	Number of RTT status errors.
System busy operation number	Number of conflict operations.
Operation timeout number	Number of timeout operations during the test.
Min Positive SD	Minimum positive jitter from the source to the destination.

Item	Description
Min Positive DS	Minimum positive jitter from the destination to the source.
Max Positive SD	Maximum positive jitter from the source to the destination.
Max Positive DS	Maximum positive jitter from the destination to the source.
Positive SD Number	Number of the positive jitter from the source to the destination.
Positive DS Number	Number of the positive jitter from the destination to the source.
Positive SD Sum	Sum of the positive jitter from the source to the destination.
Positive DS Sum	Sum of the positive jitter from the destination to the source.
Positive SD Square Sum	Square sum of the positive jitter from the source to the destination.
Positive DS Square Sum	Square sum of the positive jitter from the destination to the source.
Min Negative SD	Minimum negative jitter from the source to the destination.
Min Negative DS	Minimum negative jitter from the destination to the source.
Max Negative SD	Maximum negative jitter from the source to the destination.
Max Negative DS	Maximum negative jitter from the destination to the source.
Negative SD Number	Number of the negative jitter from the source to the destination.
Negative DS Number	Number of the negative jitter from the destination to the source.
Negative SD Sum	Sum of the negative jitter from the source to the destination.
Negative DS Sum	Sum of the negative jitter from the destination to the source.
Negative SD Square Sum	Square sum of the negative jitter from the source to the destination.
Negative DS Square Sum	Square sum of the negative jitter from the destination to the source.

Item	Description
Min Delay SD	Minimum delay from the source to the destination.
Min Delay DS	Minimum delay from the destination to the source.
Avg Delay SD	Average delay from the source to the destination.
Avg Delay DS	Average delay from the destination to the source.
Max Delay SD	Maximum delay from the source to the destination.
Max Delay DS	Maximum delay from the destination to the source.
Packet Loss SD	Maximum number of lost packets from the source to the destination.
Packet Loss DS	Maximum number of lost packets from the destination to the source.
Packet Loss Unknown	Number of packets lost at an unknown direction.
Average of Jitter	Average jitter.
Average of Jitter SD	Average jitter from the source to the destination.
Average of Jitter DS	Average jitter from the destination to the source.
Jitter out value	Jitter in sending packets.
Jitter in value	Jitter in receiving packets.
NumberOfOWD	Number of OWD packets.
OWD SD Sum	Sum of OWD from the source to the destination.
OWD DS Sum	Sum of OWD from the destination to the source.
TimeStamp unit	Unit of the timestamp.
Packet Rewrite Number	Number of rewritten packets.
Packet Rewrite Ratio	Percentage of rewritten packets to total packets.
Packet Disorder Number	Number of out-of-order packets.
Packet Disorder Ratio	Percentage of out-of-order packets to total packets.
Fragment-disorder Number	Number of out-of-order fragmented packets.
Fragment-disorder Ratio	Percentage of out-of-order fragmented packets to total packets.
Start time	Time when the test began.
End time	Time when the test ended.

## Related Topics

[16.6.3 clear-records](#)

# 16.6.12 display nqa-agent

## Function

The **display nqa-agent** command displays the status and configuration of the specified or all NQA test instances on an NQA client.

## Format

**display nqa-agent** [ *admin-name test-name* ] [ **verbose** ]

## Parameters

Parameter	Description	Value
<i>admin-name</i>	Specifies the administrator of an NQA test instance.	The value is a string of 1 to 32 characters.
<i>test-name</i>	Specifies the name of an NQA test instance.	The value is a string of 1 to 32 characters.
<b>verbose</b>	Indicates detailed information about the client status of an NQA test.	-

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

After the test instances are configured on an NQA client, run the **display nqa-agent** command to view the status and configuration of the specified or all NQA test instances on an NQA client.

## Example

# Display the status and configuration of all NQA test instances on an NQA client.

```
<HUAWEI> display nqa-agent
nqa test-instance admin ftp
test-type ftp
ftp-operation get
nqa status : normal
nqa test-instance admin icmp
nqa status : normal
nqa test-instance admin jitter
test-type jitter
destination-address ipv4 10.10.10.10
```

```
destination-port 100  
nqa status : normal
```

**Table 16-60** Description of the **display nqa-agent** command output

Item	Description
nqa test-instance admin icmp test-type icmp destination-address ipv4 192.168.1.2 nqa status : normal	The administrator of NQA test instance <b>icmp</b> is <b>admin</b> . Configurations of this test instance include the following: <ul style="list-style-type: none"><li>• test-type</li><li>• destination-address</li><li>• nqa status</li></ul> You can run the <b>nqa</b> command to configure an NQA test instance. Configurations of different NQA test instances are not the same. For details, see <b>Configuring an NQA Test Instance</b> .

## Related Topics

- [16.6.40 nqa](#)
- [16.6.59 test-type](#)
- [16.6.56 start](#)

## 16.6.13 display nqa-server

### Function

The **display nqa-server** command displays information about NQA servers.

### Format

```
display nqa-server
```

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

## Usage Guidelines

The **display nqa-server** command can display information about NQA servers, including the maximum number of configurable NQA servers and the number and types of configured NQA servers.

## Example

# Display the information about NQA servers.

```
<HUAWEI> display nqa-server
NQA Server Max:100           NQA Server Num:3
NQA Concurrent TCP Server:1  NQA Concurrent UDP Server:2
nqa-server tcpconnect 10.1.1.1 2000 ACTIVE
nqa-server udpecho 10.1.1.1 2000 ACTIVE
nqa-server udpecho 10.1.1.1 6000 ACTIVE
```

**Table 16-61** Description of the display nqa-server command output

Item	Description
NQA Server Max	Maximum number of NQA servers that can be configured.
NQA Server Num	Number of current NQA servers.
NQA Concurrent TCP Server	Number of the configured TCP servers.
NQA Concurrent UDP Server	Number of the configured UDP servers.
nqa-server	Running servers.
ACTIVE	Status of the NQA server.

## Related Topics

[16.6.42 nqa-server tcpconnect](#)

[16.6.43 nqa-server udpecho](#)

## 16.6.14 dns-server

### Function

The **dns-server** command configures the IP address of the domain name service (DNS) server in the NQA test.

The **undo dns-server** command deletes the configured IP address of the DNS server.

By default, the IP address of the DNS server is not configured.

### Format

**dns-server ipv4** *ip-address*

## undo dns-server

### Parameters

Parameter	Description	Value
<b>ipv4</b> <i>ip-address</i>	Specifies an IPv4 address for the DNS server.	The value is in dotted decimal notation.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

Before using a DNS test instance to detect the rate of resolving a given DNS name to an IP address, configure a DNS server first.

#### Prerequisites

The type of a test instance has been specified using the **test-type** command. The test instance can only be a DNS or HTTP test instance.

#### Precautions

The DNS server configuration of a running test instance cannot be changed.

### Example

# Set the IP address of the DNS server to 10.1.1.1 in the test named **user test**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type dns
[HUAWEI-nqa-user-test] dns-server ipv4 10.1.1.1
```

### Related Topics

[16.6.40 nqa](#)

[16.6.59 test-type](#)

[16.6.8 destination-address](#)

## 16.6.15 fail-percent

### Function

The **fail-percent** command sets the failure percentage for the NQA test instance.

The **undo fail-percent** command deletes the configured failure percentage for the NQA test instance.



By default, the failure percentage is 100%. That is, the test is regarded as a failure only when all the probes fail.

## Format

**fail-percent** *percent*

**undo fail-percent**

## Parameters

Parameter	Description	Value
<i>percent</i>	Specifies the percentage of failed probes.	The value is an integer that ranges from 1 to 100.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In an NQA test instance, multiple probes are sent to test probe packets. Statistics obtained from multiple probe tests show the network quality.

In actual scenarios, however, a probe test may fail because of interference in the network. In addition, a failure in a probe test does not mean that the NQA test fails. The **fail-percent** command can be used to set failure percentage to check whether an NQA test fails or not. If the number of failure probe packets to the total number of probe packets reaches a specified percentage, the NQA test is considered as a failure.

For example, the number of sent packets set in the **probe-count** command is 10, but seven of them are lost during the probe test, the following situations occur:

- If the failure percentage is set to 80, the probe test is considered a success.
- If the failure percentage is set to 60, the probe test is considered a failure.

### Prerequisites

The type of a test instance has been specified using the **test-type** command. The type of test instances that are not supported is as follows:

- FTP
- Trace
- LSP Trace
- PWE3 Trace
- DNS

- Path Jitter

### Precautions

The failure percentage of a running test instance cannot be changed.

## Example

# Set the percentage of the failed probes to 10% in the test named **user test**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] fail-percent 10
```

## Related Topics

[16.6.44 probe-count](#)

# 16.6.16 frequency

## Function

The **frequency** command sets the interval at which an NQA test instance is automatically performed.

The **undo frequency** command deletes the configured interval at which an NQA test instance is automatically performed.

By default, the interval at which an NQA test instance is automatically performed is not configured. That is, the test is performed once.

## Format

**frequency** *interval*

**undo frequency**

## Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the interval at which an NQA test instance is automatically performed.	The value is an integer that ranges from 1 to 604800, in seconds.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

You can run the **start** command to set the start time and end time of an NQA test. If you need to perform period test from the start time to the end time in a test instance, run the **frequency** command to set the interval at which an NQA test instance is automatically performed. After that, the NQA test is automatically performed once at each configured interval.

Configuring the interval of periodic NQA test avoids time-consuming manual operations.

### Prerequisites

The type of a test instance has been specified using the **test-type** command.

### Precautions

In a trace, LSP trace, or PWE3 trace test, the configured frequency must be greater than or equal to 60s.

If the configured frequency is smaller than or equal to  $(\text{probe-count} - 1) \times \text{interval} + \text{timeout} + 1$ , the test result may be **no result**. For the test instance supporting the **jitter-packetnum** parameter, the number of sent packets is **probe-count** x **jitter-packetnum** packets.

In an FTP test instance, the configured frequency must be 2s greater than the timeout value; otherwise, the FTP test instance may fail.

If the master/slave switchover is performed on the NQA client before the test instance (group) is complete, the following situations may occur:

- If the interval for automatically performing the test is not set, the test stops after the master/slave switchover.
- If the interval for automatically performing the test instance is set, the test is performed from the next period after the master/slave switchover.

If no end time is configured, the test cannot stop automatically. You need to stop it manually. The frequency of a running test instance cannot be changed.

## Example

# Set the interval at which test instance **user test** is automatically performed to 20 seconds.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] frequency 20
```

## 16.6.17 ftp-filename

### Function

The **ftp-filename** command configures the file name and file path for an NQA FTP test instance.

The **undo ftp-filename** command deletes the file name and file path for an NQA FTP test instance.

By default, no file name and file path are configured.

## Format

**ftp-filename** *file-name*

**undo ftp-filename**

## Parameters

Parameter	Description	Value
<i>file-name</i>	Specifies the name and path of the operation file in an FTP test instance.	The value is a string of 1 to 230 characters.

## Views

NQA view

## Default Level

3: Management level

## Usage Guidelines

The **ftp-filename** command is valid only for FTP test instances.

You cannot change the file path and file name of a running test instance.

If no file path is specified, the system searches for the file in the current path.

The file name cannot end with any forward slashes (/) or backward slashes (\).

The file name includes but is not limited to the extension name, such as .txt.

### NOTE

Various FTP servers may support files with the file name in different length ranges. Before you configure this command, ensure that the target FTP server supports the length of the specified file name. Otherwise, NQA test results may fail to be transmitted using FTP.

## Example

# Set the FTP path and file name of test instance **user test** to **D:\abc** and **abc.txt** respectively.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type ftp
[HUAWEI-nqa-user-test] ftp-filename D:\abc\abc.txt
```

## Related Topics

[16.6.40 nqa](#)

[16.6.19 ftp-operation](#)

[16.6.59 test-type](#)

## 16.6.18 ftp-filesize

### Function

The **ftp-filesize** command sets the size of the file used in an NQA FTP test instance.

The **undo ftp-filesize** command restores the default size of the file used in an NQA FTP test instance.

By default, the size of the file used in the FTP test is 1000 Kbytes.

### Format

**ftp-filesize** *size*

**undo ftp-filesize**

### Parameters

Parameter	Description	Value
<i>size</i>	Specifies the size of the file used in the FTP test.	The value is an integer that ranges from 1 to 10000, in Kbytes.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

You cannot change the configured size of the file when the test is running.

If specifying the size of the upload file is adopted, the FTP client automatically generates the file name **nqa-ftp-test.txt**. If the test is performed several times, the newly uploaded file replaces the previous one.

The type of the test instance has been set to **ftp** using the **test-type** command.

### Example

# Set the size of the file to 1024 bytes in the FTP upload test named **user test**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type ftp
[HUAWEI-nqa-user-test] ftp-filesize 1024
```

## Related Topics

[16.6.19 ftp-operation](#)

[16.6.59 test-type](#)

## 16.6.19 ftp-operation

### Function

The **ftp-operation** command sets the operation mode for an NQA FTP test instance.

The **undo ftp-operation** command restores the default operation mode of an NQA FTP test instance.

By default, the operation mode of an FTP test instance is **get**.

### Format

```
ftp-operation { get | put }
```

```
undo ftp-operation put
```

### Parameters

Parameter	Description	Value
<b>get</b>	Indicates that the client downloads a file from the server and the download speed is recorded.	-
<b>put</b>	Indicates that the client uploads a local file or a created file to the server and the upload speed is recorded.	-

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

In the FTP download test, the local device functions as an FTP client to download/upload the specified file from/to the FTP server. Statistics about each FTP phase are displayed, including the time to set up an FTP control connection and the time to transmit data.

The **ftp-operation** command can be used to specify the FTP operation mode as **put** or **get**. A connection with the FTP server is set up using the IP address, the user name, and the password of the FTP server, and the time to set up FTP connection is recorded.

### Prerequisites

The type of the test instance has been set to **ftp** using the **test-type** command.

### Precautions

The operation mode of a running test instance cannot be changed.

## Example

# Perform a test named **user test** to obtain the FTP download speed.

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type ftp  
[HUAWEI-nqa-user-test] ftp-operation get
```

## Related Topics

[16.6.18 ftp-filesize](#)

[16.6.17 ftp-filename](#)

[16.6.59 test-type](#)

## 16.6.20 ftp-password

### Function

The **ftp-password** command sets a password for logging in to the FTP server in an NQA FTP test instance.

The **undo ftp-password** command deletes the configured password for logging in to the FTP server.

By default, no password is set for FTP test instances.

### Format

**ftp-password** { *password* | **cipher** *cipher-password* }

**undo ftp-password**

## Parameters

Parameter	Description	Value
<i>password</i>	Specifies the password for logging in to the FTP server in an FTP test instance.	<p>The value is a string of 1 to 32 or 32 to 68 case-sensitive characters without spaces.</p> <ul style="list-style-type: none"> <li>• If the password is plaintext, the length ranges from 1 to 32.</li> <li>• If the password is ciphertext, the length ranges from 32 to 68.</li> <li>• If the password length is 32 and the configured ciphertext password can be decrypted successfully, the configured ciphertext password takes effect. If the configured ciphertext password cannot be decrypted, the plaintext password is used after passing the validity check.</li> </ul> <p><b>NOTE</b> When quotation marks are used around the string, spaces are allowed in the string.</p>
<b>cipher</b> <i>cipher- password</i>	Specifies the password for logging in to the FTP server in an FTP test instance.	<p>The value is a string of 1 to 32 or 32 to 68 case-sensitive characters without spaces.</p> <ul style="list-style-type: none"> <li>• If the password is plaintext, the length ranges from 1 to 32.</li> <li>• If the password is ciphertext, the length ranges from 32 to 68.</li> <li>• If the password length is 32 and the configured ciphertext password can be decrypted successfully, the configured ciphertext password takes effect. If the configured ciphertext password cannot be decrypted, the plaintext password is used after passing the validity check.</li> </ul> <p><b>NOTE</b> When quotation marks are used around the string, spaces are allowed in the string.</p>



## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In the FTP test, the local device functions as an FTP client to download/upload the specified file from/to the FTP server. Statistics about each FTP phase are displayed, including the time to set up an FTP control connection and the time to transmit data.

To ensure test security and prevent unauthorized users from accessing the network, you need to enable identity authentication. The **ftp-password** command can be used to set the specified user and password. Only the user who enters the authorized user name and password is authorized to access the network.

### Prerequisites

The type of the test instance has been set to **ftp** using the **test-type** command.

### Precautions

The password of a running test instance cannot be changed.

## Example

# Set the password for logging in to the FTP server to **Huawei-123**.

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type ftp  
[HUAWEI-nqa-user-test] ftp-password Huawei-123
```

## Related Topics

[16.6.21 ftp-username](#)

[16.6.59 test-type](#)

## 16.6.21 ftp-username

### Function

The **ftp-username** command sets the user name for logging in to the FTP server in an FTP test instance.

The **undo ftp-username** command deletes the configured user name for logging in to the FTP server.

By default, no user name is set for FTP test instances.

## Format

**ftp-username** *name*

**undo ftp-username**

## Parameters

Parameter	Description	Value
<i>name</i>	Specifies the user name for logging in to the FTP server.	The value is a string of 1 to 255 case-sensitive characters without spaces. <b>NOTE</b> When quotation marks are used around the string, spaces are allowed in the string.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In the FTP test, the local device functions as an FTP client to download/upload the specified file from/to the FTP server. Statistics about each FTP phase are displayed, including the time to set up an FTP control connection and the time to transmit data.

To ensure test security and prevent unauthorized users from accessing the network, you need to enable identity authentication. The **ftp-username** command can be used to set the specified user in an FTP test. Only the user who enters the authorized user name and password is authorized to access the network.

### Prerequisites

The type of the test instance has been set to **ftp** using the **test-type** command.

### Precautions

The user name of a running test instance cannot be changed.

## Example

# Set the user name for logging in to the FTP server to **user1**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type ftp
[HUAWEI-nqa-user-test] ftp-username user1
```

## Related Topics

[16.6.20 ftp-password](#)

[16.6.59 test-type](#)

## 16.6.22 http-operation

### Function

The **http-operation** command sets the operation mode for an NQA HTTP test instance.

By default, the operation mode of the HTTP test instance is GET.

### Format

**http-operation get**

### Parameters

Parameter	Description	Value
<b>get</b>	Obtains data from the HTTP server.	-

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

This command applies only to the HTTP test.

You cannot change the operation mode of a running HTTP test instance.

### Example

# Set the operation mode of HTTP test instance **user test** to **get**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type http
[HUAWEI-nqa-user-test] http-operation get
```

## Related Topics

[16.6.23 http-url](#)

[16.6.59 test-type](#)

## 16.6.23 http-url

### Function

The **http-url** command configures the uniform resource locator (URL) and version information for an HTTP test instance.

The **undo http-url** command deletes the configured URL and version information.

By default, no URL or version information is configured for an HTTP test instance.

### Format

**http-url** *deststring* [ *verstring* ]

**undo http-url**

### Parameters

Parameter	Description	Value
<i>deststring</i>	Specifies the name of the web page used for an HTTP test.	The value is a string of 1 to 230 case-insensitive characters without spaces. <b>NOTE</b> When quotation marks are used around the string, spaces are allowed in the string.
<i>verstring</i>	Specifies the HTTP version.	The total length of <i>verstring</i> should be equal to or shorter than 7 characters. It can be set to v1.0 or 1.1. The default HTTP version is v1.0.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

HTTP1.0 and HTTP1.1 are supported in this test instance.

#### Precautions

The **http-url** command applies only to HTTP test instances. You cannot change the URL of a running HTTP test instance.

When running the **http-url** command, you need to specify a domain name or a server's IP address; otherwise, the test instance fails.

## Example

```
# Set the URL of HTTP test instance user test to http://www.***.com.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type http  
[HUAWEI-nqa-user-test] http-url http://www.***.com
```

## Related Topics

[16.6.22 http-operation](#)

[16.6.59 test-type](#)

## 16.6.24 icmp-jitter-mode

### Function

The **icmp-jitter-mode** command specifies the mode of an ICMP jitter test.

The **undo icmp-jitter-mode** command restores the default mode of an ICMP jitter test.

By default, the ICMP jitter test is in **icmp-timestamp** mode.

### Format

```
icmp-jitter-mode { icmp-echo | icmp-timestamp }
```

```
undo icmp-jitter-mode
```

### Parameters

Parameter	Description	Value
<b>icmp-echo</b>	Configures the ICMP jitter test to use ICMP Echo messages.	-
<b>icmp-timestamp</b>	Configures the ICMP jitter test to use ICMP Timestamp messages.	-

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

The **icmp-jitter-mode** command can only be used to configure the mode for ICMP jitter or path jitter tests.

## Example

# Configure the ICMP jitter test to use ICMP Echo messages.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance admin icmpjitter
[HUAWEI-nqa-admin-icmpjitter] test-type icmpjitter
[HUAWEI-nqa-admin-icmpjitter] icmp-jitter-mode icmp-echo
```

## Related Topics

[16.6.59 test-type](#)

## 16.6.25 interval (NQA view)

### Function

The **interval** command sets the interval at which NQA test packets are sent.

The **undo interval** command restores the default setting.

By default, the intervals for sending test packets in various tests are as follows:

- For UDP Jitter, Path Jitter, and ICMP Jitter test instance, the interval is 50 milliseconds on the S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI and is 100 milliseconds for other devices.
- The interval is 4 seconds for other test instances.

### Format

**interval** { **milliseconds** *interval* | **seconds** *interval* }

**undo interval**

### Parameters

Parameter	Description	Value
<b>milliseconds</b> <i>interval</i>	Sets the interval at which packets are sent, in milliseconds. <b>NOTE</b> If the configured interval is a multiple of 1000 milliseconds, the system will automatically convert milliseconds into seconds.	The value is an integer that ranges from 20 to 60000.
<b>seconds</b> <i>interval</i>	Sets the interval at which packets are sent, in seconds.	The value is an integer that ranges from 1 to 60, in seconds.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In an NQA test instance, multiple probes are sent. Statistics obtained from multiple probe tests show the network quality. Probe packets (or probes) are sent at a specified interval.

- If the network quality is poor, the interval at which packets are sent must be increased. Otherwise, the network performance may deteriorate.
- If the network quality is good, the interval at which are sent can be decreased to shorten the waiting time.

### Prerequisites

The type of a test instance has been specified using the **test-type** command. The **interval** command is valid only for the ICMP, ICMP Jitter, Path Jitter, SNMP, LSP Jitter, LSP Ping, PWE3 Ping, TCP, UDP, or UDP Jitter test instances.

### Configuration Impact

- Packets can be sent at interval of milliseconds only in UDP Jitter, Path Jitter, or ICMP Jitter test instances. The interval at which packets are sent must be greater than the timeout period set using the **timeout** command in all test instances except the UDP Jitter, Path Jitter, or ICMP Jitter test instance.
- If the interval for sending packets has been configured, running the **interval** command will override the previous configuration.

### Precautions

The interval for sending packets of a running test instance cannot be changed.

## Example

```
# Set the interval for sending test packets to 1000 milliseconds.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type jitter  
[HUAWEI-nqa-user-test] interval milliseconds 1000
```

## 16.6.26 ip-forwarding

### Function

The **ip-forwarding** command configures packets to be forcibly forwarded using IP on the first node.

The **undo ip-forwarding** command disables packets from being forcibly forwarded using IP on the first node.

## Format

**ip-forwarding**

**undo ip-forwarding**

## Parameters

None

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

When a fault occurs on the network, you can first run the **ping** command to check network connectivity. On an MPLS network, if a fault occurs but the control layer fails to detect the fault, the ping operation fails. To fast identify whether the fault occurs on the MPLS network or on the IP network, you can configure IP packets to be forcibly forwarded using IP on the first node. This can help you fast locate the fault.

### NOTE

Only ICMP test instances support this configuration.

If you configure both the **ip-forwarding** and **sendpacket passroute** commands, the **sendpacket passroute** command takes effect. Therefore, the device sends packets without searching the routing table.

## Example

```
# Configure packets to be forwarded using IP.  
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type icmp  
[HUAWEI-nqa-user-test] ip-forwarding
```

## Related Topics

[16.6.59 test-type](#)



## 16.6.27 jitter-packetnum

### Function

The **jitter-packetnum** command sets the number of packets sent in each probe test instance.

The **undo jitter-packetnum** command restores the default number of packets sent in each probe test instance.

By default, 20 test packets are sent in each probe.

### Format

**jitter-packetnum** *number*

**undo jitter-packetnum**

### Parameters

Parameter	Description	Value
<i>number</i>	Specifies the number of test packets sent in each probe in the jitter test ( <b>probe-count</b> ).	The value is an integer that ranges from 1 to 3000. The default value is 20.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

In an NQA test instance, the **jitter-packetnum** command can be used to set the number of consecutive packets to simulate the actual traffic of a data in a specified period of time. This helps simulate services more accurately.

For example, the **jitter-packetnum** command can be used to set the number of consecutive packets to 3000 and an interval of 20 ms to send packets. In this way, G.711 traffic can be simulated within one minute to detect VoIP services in UDP jitter test instances.

#### Prerequisites

The type of a test instance has been specified using the **test-type** command. The number of sent packets can be configured only for UDP Jitter, LSP jitter, Path Jitter, and ICMP Jitter test instances.

#### Configuration Impact

- In UDP Jitter, LSP jitter, Path Jitter, and ICMP Jitter test instances, the number of sent packets = **jitter-packetnum** x **probe-count**, but the product cannot exceed 3000.
- If the number of probe packets has been set, running the **jitter-packetnum** command will override the previous configuration.

#### Precautions

The number of probe packets of a running test instance cannot be changed.

## Example

# Perform 3 probes in the test named **user test** and send 1000 packets in each probe.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type jitter
[HUAWEI-nqa-user-test] probe-count 3
[HUAWEI-nqa-user-test] jitter-packetnum 1000
```

## Related Topics

[16.6.25 interval \(NQA view\)](#)

[16.6.44 probe-count](#)

## 16.6.28 local-pw-id

### Function

Using the **local-pw-id** command, you can set the ID of the local end of a PW or a VC.

Using the **undo local-pw-id** command, you can delete the configured ID of the local end of a PW or a VC.

By default, **local-pw-id** is not configured.

### Format

**local-pw-id** *local-pw-id*

**undo local-pw-id**

## Parameters

Parameter	Description	Value
<i>local-pw-id</i>	Specifies the ID of the local end of a PW or a VC.	The value is a decimal integer. <ul style="list-style-type: none"><li>When the test instance is of PWE3Ping, the value of <i>local-pw-id</i> is an integer that ranges from 1 to 4294967295, and only the VC type of LDP is supported.</li><li>When the test instance is of PWE3Trace: when the VC type is LDP, the value of <i>local-pw-id</i> is an integer that ranges from 1 to 4294967295; when the VC type is BGP, the value of <i>local-pw-id</i> is an integer that ranges from 0 to 65534.</li></ul>

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

PWE3 ping and PWE3 trace test instances can be used in the following scenarios:

Connectivity and faulty node detections for a single-hop PW. After the **local-pw-id** command is run in the NQA view to configure the local PW ID or VC ID, you can specify a PW for the detection.

Connectivity and faulty node detections for a multi-hop PW. After the **local-pw-id** command is run in the NQA view to configure the local PW ID or VC ID, you need to specify the destination address.

- If the **label-type** parameter is set to **control-word**, run the **remote-pw-id remote-pw-id** command to configure the remote PW ID.
- If the **label-type** parameter is set to **label-alert** or **normal**, run the **destination-address ipv4 ipv4-address [ lsp-masklen masklen | lsp-masklen masklen lsp-loopback loopback-address | lsp-loopback loopback-address lsp-masklen masklen ]** command to configure the destination address for PWE3 ping and PWE3 trace test instances.

### Prerequisites

Before running the **local-pw-id** command, you must set the NQA test type to PWE3 Trace or PWE3 Ping in the NQA view.

### Precautions

The *local-pw-id* value must be the same as the **VC ID** value in the **display mpls l2vc** command output; otherwise, the test may fail.

## Example

# Set the ID of the local end of a PW to 100 in the NQA view.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance admin pwe3
[HUAWEI-nqa-admin-pwe3] test-type pwe3trace
[HUAWEI-nqa-admin-pwe3] local-pw-id 100
```

## Related Topics

[16.6.47 remote-pw-id](#)

[16.6.69 vc-type](#)

## 16.6.29 local-pw-type

### Function

Using the **local-pw-type** command, you can configure the PW type of the local end.

Using the **undo local-pw-type** command, you can cancel setting the PW type of the local end.

By default, the PW type of the local end is Ethernet.

### Format

**local-pw-type** *local-pw-type*

**undo local-pw-type**

### Parameters

Parameter	Description	Value
<i>local-pw-type</i>	Specifies the PW type of the local end.	Currently, encapsulation types <b>ethernet</b> , <b>ip-interworking</b> and <b>vlan</b> are supported. By the default, the value is <b>ethernet</b> .

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The **local-pw-type** command is used to configure a PW encapsulation type for the local PE. The PW encapsulation type configured for the local PE must be the same as the PW encapsulation type for the remote PE.

#### Prerequisites

Before configuring the **local-pw-type** command, configure the test type of NQA test instances as PWE3 trace or PWE3 ping in the NQA view.

#### Precautions

The *local-pw-type* value must be the same as the **VC type** value in the **display mpls l2vc** command output; otherwise, the test may fail.

## Example

# In the NQA view, configure the local pw-type as VLAN.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance admin pwe3
[HUAWEI-nqa-admin-pwe3] test-type pwe3trace
[HUAWEI-nqa-admin-pwe3] local-pw-type vlan
```

## Related Topics

[16.6.28 local-pw-id](#)

## 16.6.30 label-type

### Function

Using the **label-type** command, you can configure the label type.

Using the **undo label-type** command, you can cancel the operation of configuring the label type.

By default, the label type is **control-word**.

### Format

**label-type** { **control-word** | { **label-alert** | **normal** } [ **no-control-word** ] }

**undo label-type**

### Parameters

Parameter	Description	Value
<b>control-word</b>	Indicates that the control word option is encapsulated in MPLS Echo Request packets.	-
<b>label-alert</b>	Indicates that the router alert option is encapsulated in MPLS Echo Request packets.	-
<b>normal</b>	Indicates that neither control words nor router alert options are encapsulated in MPLS Echo Request packets.	-

Parameter	Description	Value
<b>no-control-word</b>	Indicates that the control word option is not encapsulated in MPLS Echo Request packets. This parameter can be used in NQA PWE3 ping and NQA PWE3 trace tests.	-

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The usage scenarios of the label types are as follows:

- **control-word:**
  - If the encapsulation type is set to **control-word**, at a switch node on a multi-hop PW, the MPLS Echo Request packets are not delivered to the CPU for processing until the TTL of the label times out. In this case, the source obtains little PW information. This type, however, ensures system performance and the source cannot learn information on the downstream interfaces of the switch node. You should use this type when there are a great number of packets.
  - Only **control-word** is supported when the vc-type is BGP and lsp-version is draft6.
- **label-alert:**
  - If the encapsulation type is set to **label-alert**, at a switch node on a multi-hop PW, the MPLS Echo Request packets are delivered to the CPU for processing. In this case, the source can obtain more PW information. The system performance is greatly affected when there are a great number of packets. You can use this type to obtain details about the switch node when test instances are few.
  - Only **control-word** or **label-alert** is supported when the vc-type is BGP and lsp-version is rfc4379.
- In the case that a device communicates with Huawei devices running earlier versions and the label alert or normal mode is adopted, the no-control-word option must be carried in the test packets.
- **normal** is unsupported when the lsp-version is draft6.

### Prerequisites

Before running the **label-type** command, you must set the test type to PWE3 Trace or PWE3 Ping in the NQA view; otherwise, **label-type** cannot be specified.

### Precautions

The **label-type** value must be the same as the **local VCCV** value in the **display mpls l2vc** command output; otherwise, the test may fail.

## Example

# Configure the encapsulation type of test packets as **label-alert** in the NQA view.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance admin pwe3
[HUAWEI-nqa-admin-pwe3] test-type pwe3trace
[HUAWEI-nqa-admin-pwe3] label-type label-alert
```

## Related Topics

[16.6.29 local-pw-type](#)

# 16.6.31 lsp-exp

## Function

The **lsp-exp** command configures the LSP EXP value of MPLS Echo Request packets in an NQA test instance.

Using the **undo lsp-exp** command, you can restore the default setting.

By default, LSP EXP is 0.

## Format

**lsp-exp** *exp*

**undo lsp-exp**

## Parameters

Parameter	Description	Value
<i>exp</i>	Specifies the LSP EXP value of an NQA test instance.	The value is an integer that ranges from 0 to 7. The default value is 0.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The MPLS experimental bits (EXP) field is a 3-bit field in the MPLS header used to mark the precedence of MPLS packets.

Test packets are added to different queues according to their LSP EXP values, so that

- Congestion on the link can be avoided.
- Specified queue can be detected.

### Precautions

This command applies to only the LSP test.

You cannot change the configured LSP EXP value when the test is performed.

## Example

```
# Set the LSP EXP value to 5.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type lsping  
[HUAWEI-nqa-user-test] lsp-exp 5
```

## Related Topics

[16.6.59 test-type](#)

## 16.6.32 lsp-nexthop

### Function

The **lsp-nexthop** command is used to configure the IP address of the next hop in the case that load balancing is enabled.

Using the **undo lsp-nexthop** command, you can cancel the current setting.

By default, the next-hop IP address of any link that participates in load balancing.

### Format

```
lsp-nexthop nexthop-ip-address
```

```
undo lsp-nexthop
```

### Parameters

Parameter	Description	Value
<i>nexthop-ip-address</i>	Specifies the next hop address.	It is in dotted decimal notation.

### Views

NQA view

### Default Level

2: Configuration level



## Usage Guidelines

### Usage Scenario

Two conditions must be met before you use the command:

- **lsp-type** is IPv4
- **lsp-version** is RFC4379

You can use the **lsp-nexthop** command to configure the IP address of the next hop. Test instance type supported as following:

- LSP Ping
- LSP Trace
- LSP Jitter

### Precautions

A running test instance cannot be configured with the next hop address.

## Example

# Specify the next hop address for the LSP Ping test instance whose LSP type is IPv4 and lsp-version is rfc4379.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type lsping
[HUAWEI-nqa-user-test] lsp-type ipv4
[HUAWEI-nqa-user-test] lsp-version rfc4379
[HUAWEI-nqa-user-test] lsp-nexthop 10.1.2.20
```

## Related Topics

[16.6.59 test-type](#)

[16.6.35 lsp-type](#)

## 16.6.33 lsp-replymode

### Function

Using the **lsp-replymode** command, you can set the reply mode for the LSP test.

Using the **undo lsp-replymode** command, you can restore the default setting.

By default, UDP packets are used.

### Format

**lsp-replymode** { **no-reply** | **udp** }

**undo lsp-replymode**

## Parameters

Parameter	Description	Value
<b>no-reply</b>	Indicates that the LSP test is not responded.	If the <b>no-reply</b> parameter is specified in the command, the destination does not respond to NQA probe packets. This configuration is used to collect the statistics on or process received probe packets on the destination host, and no response packets need to be sent. Meanwhile, the NQA test instance fails because the client does not receive response packets.
<b>udp</b>	Indicates that IPv4 UDP packets are used to respond to the LSP test.	-

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

Using the **lsp-replymode** command, you can set the reply mode for the LSP test. The supported test instance are:

- LSP Ping
- LSP Trace
- LSP Jitter
- PWE3 Ping
- PWE3 Trace

### Precautions

**lsp-replymode no-reply** indicates the unidirectional test. If the client displays timeout, it indicates that the test succeeds; or the client displays that the LSP is non-existent.

You cannot change the reply mode of the currently performed LSP test.

## Example

# Set the reply mode of the test named **user test** to sending UDP packets.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
```

[HUAWEI-nqa-user-test] **test-type lsping**  
[HUAWEI-nqa-user-test] **lsp-replymode udp**

## Related Topics

[16.6.59 test-type](#)

## 16.6.34 lsp-tetunnel

### Function

The **lsp-tetunnel** command configures the TE tunnel used in an NQA LSP test.

The **undo lsp-tetunnel** command deletes the configured TE tunnel.

By default, no TE tunnel is configured for an LSP test instance.

### Format

**lsp-tetunnel tunnel** *interface-number* [ **hot-standby** | **primary** ]

**undo lsp-tetunnel**

### Parameters

Parameter	Description	Value
<b>tunnel</b> <i>interface-number</i>	Specifies the tunnel interface number.	-
<b>hot-standby</b>	Indicates the hot-standby tunnel of the TE tunnel.	-
<b>primary</b>	Indicates the primary tunnel of the TE tunnel.	-

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

Hot standby: An ordinary backup CR-LSP is set up immediately after a primary CR-LSP is set up. The ordinary backup CR-LSP takes over traffic if the primary CR-LSP fails. After the primary CR-LSP recovers, traffic switches back.

CR-LSP backup can be configured to allow traffic to switch from a primary CR-LSP to a backup CR-LSP, providing end-to-end protection.

An NQA LSP test instance can check the reachability of the following LSPs and collect SLA statistics:

- MPLS TE tunnel: Run the **lsp-tetunnel** *interface-type interface-number* command to configure an interface number for an MPLS TE tunnel.
- Hot-standby MPLS CR-LSP: Run the **lsp-tetunnel** *interface-type interface-number hot-standby* command to configure an interface number for a hot-standby MPLS CR-LSP.
- Primary MPLS TE tunnel: Run the **lsp-tetunnel** *interface-type interface-number primary* command to configure an interface number for a primary MPLS TE tunnel.

### Prerequisites

Before using the **lsp-tetunnel** command to configure the TE tunnel in an NQA LSP test instance, perform the following operations:

- Run the **interface tunnel** *interface-number* command to create a tunnel interface.
- Run the **lsp-type te** command to set the NQA LSP test type to TE.

### Precautions

LSP Jitter test instances cannot test the hot-standby tunnel of a TE tunnel.

You cannot change the TE tunnel when the LSP test is performed.

## Example

# Configure the TE tunnel of the test named **user test**.

```
<HUAWEI> system-view
[HUAWEI] interface tunnel 1
[HUAWEI-Tunnel1] quit
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type lsping
[HUAWEI-nqa-user-test] lsp-type te
[HUAWEI-nqa-user-test] lsp-tetunnel tunnel 1
```

# Configure the CR-LSP hot-standby tunnel of the test named **user test**.

```
<HUAWEI> system-view
[HUAWEI] interface tunnel 1
[HUAWEI-Tunnel1] quit
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type lsping
[HUAWEI-nqa-user-test] lsp-type te
[HUAWEI-nqa-user-test] lsp-tetunnel tunnel 1 hot-standby
```

## Related Topics

[16.6.59 test-type](#)

[16.6.35 lsp-type](#)

## 16.6.35 lsp-type

### Function

Using the **lsp-type** command, you can configure the LSP test type.

Using the **undo lsp-type** command, you can cancel configuring the LSP test type.

By the default, the value of **lsp-type** is **ipv4**.

## Format

```
lsp-type { ipv4 | te | ipv4-vpn }  
undo lsp-type
```

## Parameters

Parameter	Description	Value
<b>ipv4</b>	Sets the test type to IPv4 LSP ping/trace/jitter.	-
<b>te</b>	Sets the type to LSP ping/trace/jitter of the TE tunnel.	-
<b>ipv4-vpn</b>	Sets the LSP test type to IPv4 L3VPN.	-

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The **lsp-type** command can be used to configure the LSP test type of an NQA test instance to detect an LDP or a TE tunnel.

- If **ipv4** is configured, the NQA test instance is used to detect the connectivity of a specified LDP LSP. The destination address of the test instance is configured using the **destination-address** command.
- If **te** is configured, the NQA test instance is used to detect the connectivity of a specified TE tunnel. The destination address of the test instance is configured using the **lsp-tetunnel** command.
- If the **ipv4-vpn** parameter is set, the NQA test case is used to test LSPs on a BGP-based L3VPN network.
  - To test a primary LSP on a BGP-based L3VPN network, specify the destination address using the **destination-address lsp-masklen masklen** command.
  - To test a primary LSP on a BGP-based L3VPN network, specify the destination address using the **destination-address lsp-masklen masklen vpn-frr-path** command.

### Prerequisites

- If the LSP test type is set to IPv4, the NQA test instance type must be set to LSP ping, LSP trace, or LSP jitter.
- If the LSP test type is set to TE, the NQA test instance type must be set to LSP ping, LSP trace, or LSP jitter.

- If the LSP test type is set to IPv4 L3VPN, the NQA test instance type must be set to LSP ping.

### Precautions

The type of an LSP test that is running cannot be changed.

After the **lsp-type** command is configured, the **destination-address**, **lsp-tetunnel**, and **lsp-version** commands cannot be configured.

## Example

# Set the type of the test named **user test** to Ipv4 LSP ping.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type lsping
[HUAWEI-nqa-user-test] lsp-type ipv4
```

## Related Topics

[16.6.59 test-type](#)

## 16.6.36 lsp-version

### Function

Using the **lsp-version** command, you can configure the protocol that is used by the LSP test instance.

Using the **undo lsp-version** command, you can restore the default setting.

By default, draft6 is adopted.

### Format

```
lsp-version { rfc4379 | draft6 }
```

```
undo lsp-version
```

### Parameters

Parameter	Description	Value
<b>rfc4379</b>	Indicates that the protocol defined in RFC 4379 is adopted.	-
<b>draft6</b>	Indicates that Draft-ietf-mpls-lsp-ping-06 is adopted.	-

### Views

NQA view

### Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The **lsp-version** command can be used to specify the protocol that is used by the LSP test instance.

### Prerequisites

If **draft6** or **rfc4379** is specified in the **lsp-version** command, specify **lsping**, **lsptrace**, **lspjitter**, **pwe3ping**, or **pwe3trace** in the **test-type** command.

### NOTE

The protocol adopted by a running LSP test instance cannot be changed.

## Example

# Configure the LSP test instance to use the protocol defined in RFC 4379.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type lsping
[HUAWEI-nqa-user-test] lsp-version rfc4379
```

## Related Topics

[16.6.59 test-type](#)

## 16.6.37 md

### Function

Using the **md** command, you can specify the Maintenance Domain (MD) and Maintenance Association (MA) of the NQA test packet to be sent. This command takes effect only in the MAC Ping test instance.

Using the **undo md** command, you can remove the specified MD from the NQA test packet to be sent.

By default, no MD is specified.

### NOTE

The S1720GFR does not support this command.

### Format

**md** *md-name* **ma** *ma-name*

**undo md**

## Parameters

Parameter	Description	Value
<i>md-name</i>	Specifies an MD.	The value is a string of 1 to 43 case-sensitive characters without spaces.
<i>ma-name</i>	Specifies an MA.	The value is a string of 1 to 43 case-sensitive characters without spaces.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

You can use this command to specify the MD and MA of an MAC Ping test instance. This command has the same effect as the operation of checking the connectivity fault in the MA view. Before running this command, you need to create an MD and MA, and set the test type to macping.

You cannot modify the MD and MA when the test instance is running. The total length of *ma-name* and *md-name* combination cannot be greater than 44 characters.

## Example

```
# Set the test type of an NQA test instance to MAC Ping and specify the MD name to "mdcustome" and the MA name to "macustomer".
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type macping  
[HUAWEI-nqa-user-test] md mdcustomer ma macustomer
```

## Related Topics

[16.6.40 nqa](#)

## 16.6.38 mep

### Function

Using the **mep** command, you can configure the MEP ID for an NQA test instance.

Using the **undo mep** command, you can delete the MEP ID configured for an NQA test instance.

By default ,the MEP ID for an NQA test instance is 0.



 NOTE

The S1720GFR does not support this command.

## Format

**mep mep-id mep-id**

**undo mep**

## Parameters

Parameter	Description	Value
<i>mep-id</i>	Specifies the MEP ID of an NQA test instance.	The value is an integer ranging from 1 to 8191.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

Before starting an NQA test instance, you need to run the **mep-id mep-id** command to configure the EOAM module. Otherwise, the normal operation of the NQA test instance will be affected.

This command is available for NQA MAC ping test instances.

## Example

# Set the MEP ID of an NQA MAC ping test instance to 1.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance test macping
[HUAWEI-nqa-test-macping] test-type macping
[HUAWEI-nqa-test-macping] mep mep-id 1
```

## Related Topics

[12.7.32 mep mep-id](#)

## 16.6.39 nexthop

### Function

The **nexthop** configures a next hop address for NQA test packets.

The **undo nexthop** deletes the configured next hop address for the NQA test packets.

By default, the next hop address for the NQA test packets is obtained by searching the routing table.

## Format

**nexthop ipv4** *ip-address*

**undo nexthop**

## Parameters

Parameter	Description	Value
<b>ipv4</b> <i>ip-address</i>	Specifies a next hop address for NQA test packets.	The value is in dotted decimal notation.  <b>NOTE</b> The specified next hop must be the physical interface directly connected to the device that sends the NQA test packets.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

In the scenario that an NQA test instance is associated with static routes, if a link becomes faulty, the NQA test instance detects this fault and then the static routes associated with the NQA test instance become Down. After the link recovers, the NQA test instance attempts to send ICMP test packets over the static routes. Because these static routes are still Down, the NQA test instance still fails to detect link connectivity. Traffic fails to be forwarded.

The **nexthop** command configures a next hop address for the NQA test packets, which ensures that the packets are forwarded when the link recovers from the fault, and the static routes associated with the NQA test instance are Up.

### Prerequisites

Only the NQA ICMP test instance allows you to specify a next hop address for NQA test packets.

### Precautions

After you configure a next hop address for an NQA ICMP test instance, the test instance packets will be sent based on the address.

You can also run the **source-interface** command to specify an outbound interface through which the NQA ICMP test instance packets are sent to the specified next

hop address. To guarantee that the test packets are sent, the following two conditions must be met:

- The specified next hop address matches the outbound interface.
- The specified outbound interface cannot be the member interface of a logical interface.

## Example

# Configure a next hop address for NQA ICMP test packets.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] nexthop ipv4 10.1.1.1
```

## 16.6.40 nqa

### Function

The **nqa** command creates an NQA test instance and enters the NQA view.

The **undo nqa** command deletes an NQA test instance.

### Format

**nqa test-instance** *admin-name test-name*

**undo nqa** { **test-instance** *admin-name test-name* | **all-test-instance** }

### Parameters

Parameter	Description	Value
<i>admin-name</i>	Specifies the administrator of an NQA test instance.	The value is a string of 1 to 32 characters without question marks (?), spaces, or hyphens (-). <b>NOTE</b> If the string is enclosed in double quotation marks (" "), the string can contain spaces.
<i>test-name</i>	Specifies the name of an NQA test instance.	The value is a string of 1 to 32 characters without question marks (?), spaces, or hyphens (-). <b>NOTE</b> If the string is enclosed in double quotation marks (" "), the string can contain spaces.
<b>all-test-instance</b>	Specifies all NQA test instances.	-

### Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The NQA is an integrated network test function. NQA test instances can accurately detect network running status, collect test statistics, and reduce costs.

NQA measures the performance of different protocols running on the network. NQA allows enterprise users to collect network operation indexes in real time, such as total delay of the HTTP, TCP connection delay, DNS resolution delay, file transmission delay, FTP connection delay, and DNS resolution error ratio.

To check these performance indexes, you can create NQA test instances. The two ends of an NQA test are called the NQA client and NQA server. The NQA client is responsible for initiating an NQA test. After receiving packets, the NQA server sends response messages to the NQA client. You can learn about the running status of a corresponding network according to the returned packets.

### Configuration Impact

After the **undo nqa all-test-instance** command is run, all NQA test instances except the running test instance will be deleted.

### Precautions

A running test instance cannot be deleted.

## Example

```
# Create a test named user test.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test]
```

## Related Topics

[16.6.59 test-type](#)

## 16.6.41 nqa-jitter tag-version

### Function

The **nqa-jitter tag-version** command sets the packet version for a UDP Jitter test instance.

The **undo nqa-jitter tag-version** command restores the default packet version for a UDP Jitter test instance.

By default, the packet version of a UDP Jitter test instance is 1.

### Format

**nqa-jitter tag-version** *version-number*

## undo nqa-jitter tag-version

### Parameters

Parameter	Description	Value
<i>version-number</i>	Specifies the packet version for a UDP Jitter test instance.	The value can be 1 or 2.

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

Version 1 does not support unidirectional packet loss statistics.

Version 2 produces more accurate packet statistics, which helps network administrators to locate network faults and detect malicious attacks towards the network. After version 2 and collecting the packet loss across a unidirectional link are enabled, you can view the packet loss across the link from the source end to the destination end, from the destination end to the source end, or in an unknown direction in the test results.

Therefore, configuring version 2 is recommended.

#### Configuration Impact

If the packet version of a UDP Jitter test instance has been configured, running the **nqa-jitter tag-version** command will override the previous configuration.

#### Precautions

No matter the version number of the UDP Jitter test packet is 1 or 2, you need to run the **nqa-server udpecho** command to configure the NQA server. Otherwise, the UDP Jitter test instance will fail due to timeout.

### Example

```
# Set the packet version of a UDP Jitter test instance to 2.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa-jitter tag-version 2
```

## 16.6.42 nqa-server tcpconnect

### Function

The **nqa-server tcpconnect** command configures the IP address and port number for the TCP server in an NQA TCP test instance.

The **undo nqa-server tcpconnect** command deletes the IP address and port number configured for the TCP server in an NQA TCP test instance.

By default, no IP address or port number is configured for the TCP server in an NQA TCP test instance.

## Format

**nqa-server tcpconnect** [ **vpn-instance** *vpn-instance-name* ] *ip-address port-number*

**undo nqa-server tcpconnect** { **all** | [ **vpn-instance** *vpn-instance-name* ] *ip-address port-number* }

### NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

## Parameters

Parameter	Description	Value
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of the VPN instance to which the TCP server belongs. <b>NOTE</b> This parameter is invalid when a loopback address is specified as the TCP server address.	The value must be an existing VPN instance name.
<b>all</b>	Indicates all TCP listening addresses and port numbers.	-
<i>ip-address</i>	Specifies the IP address of the TCP server for monitoring TCP services.	The value is in dotted decimal notation.
<i>port-number</i>	Specifies the port number of the TCP server for monitoring TCP services.	The value is an integer that ranges from 1 to 65535. The configured port cannot be a well-known port or used by other modules.

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The NQA TCP test is used to detect the rate at which a TCP connection is set up between an NQA client and a TCP server through the three-way handshake. In a TCP test instance, a TCP server needs to be configured on the server end to respond to probe packets.

Perform the following steps on the client to configure TCP server parameters:

- Run the [destination-address](#) command to configure the destination address of an NQA test instance or the IP address of the TCP server.
- Run the [destination-port](#) command to configure the destination port number of an NQA test instance, or the port number of the TCP server.

If the client and the server are connected through a VPN, you need to specify the VPN instance name.

### Configuration Impact

Running the **undo nqa-server tcpconnect all** command will delete the IP address and port number of the TCP server.

### Precautions

A TCP server is configured only in a TCP test instance.

## Example

# Create a TCP server for an NQA test instance with the IP address as 10.10.10.1 and the port number as 5000.

```
<HUAWEI> system-view  
[HUAWEI] nqa-server tcpconnect 10.10.10.1 5000
```

## Related Topics

[16.6.8 destination-address](#)

[16.6.9 destination-port](#)

## 16.6.43 nqa-server udpecho

### Function

The **nqa-server udpecho** command configures the IP address and port number for the UDP server in an NQA test.

The **undo nqa-server udpecho** command deletes the IP address and port number configured for the UDP server in an NQA test.

By default, no IP address or port number is configured for the UDP server in an NQA test.

## Format

**nqa-server udpecho** [ **vpn-instance** *vpn-instance-name* ] *ip-address port-number*  
**undo nqa-server udpecho** { [ **vpn-instance** *vpn-instance-name* ] *ip-address port-number* | **all** }

### NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

## Parameters

Parameter	Description	Value
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of the VPN instance to which the server belongs. <b>NOTE</b> This parameter is invalid when a loopback address is specified as the UDP server address.	The value is a string of 1 to 31 characters.
<b>all</b>	Specifies a server for all NQA test instances.	-
<i>ip-address</i>	Specifies the IP address of the server for monitoring UDP services.	The value is in dotted decimal notation.
<i>port-number</i>	Specifies the port number of the server for monitoring UDP services.	The value is an integer that ranges from 1 to 65535. The configured port cannot be a well-known port or used by other modules.

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

This command is used on a UDP server.

UDP packets are transmitted in a UDP Jitter test. The test is used to obtain the packet delay, jitter, and packet loss ratio by comparing timestamps in the request



and response packets. A UDP server needs to be configured for an NQA test to respond to probe packets.

If the local IPv4 address cannot be predicted because of dynamic address allocation by DHCP, specify the **auto-address** keyword to configure the UDP service on the NQA server to automatically monitor all IPv4 addresses.

### Configuration Impact

Running the **undo nqa-server udpecho all** command will delete the IP address and port number of the UDP server for all NQA UDP test instances.

### Precautions

If the client and the server are connected through a VPN, you need to specify the VPN instance name.

No matter the version number of the UDP Jitter test packet is 1 or 2, you need to configure the NQA server. Otherwise, the UDP Jitter test instance will fail due to timeout.

## Example

# Create an NQA UDP monitoring server with the IP address 10.10.10.2 and the port number 6000.

```
<HUAWEI> system-view
[HUAWEI] nqa-server udpecho 10.10.10.2 6000
```

## 16.6.44 probe-count

### Function

The **probe-count** command sets the number of probes for an NQA test instance.

The **undo probe-count** command restores the default number of probes for an NQA test instance.

By default, the number of probes for an NQA test instance is 3.

### Format

**probe-count** *number*

**undo probe-count**

### Parameters

Parameter	Description	Value
<i>number</i>	Specifies the number of probes in an NQA test instance.	The value is an integer that ranges from 1 to 15. The default value is 3. <b>NOTE</b> The number of probes in a trace test instance cannot be more than 10.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

An NQA test consists of multiple probes. By default, if one or more probes are successful in an NQA test, the test is considered successful. If all probes fail, the test is considered a failure. The number of probes in an NQA test is based on the network quality.

- If the network to be tested is a reliable network, the number of probes can be set relatively small because the probe can be successful after a small number of probe packets are sent.
- If the network to be tested is an unreliable network, the number of probes can be set relatively large because the probe can be successful only after a large number of probe packets are sent.

You can also detect the network quality based on statistics obtained from multiple probes. For example,

- If the probe test is successful after a small number of probes packets are sent, the network quality is good.
- If the probe test is successful after a large number of probes packets are sent, the network quality is poor.

### Prerequisites

The type of a test instance has been specified using the **test-type** command. The type of test instances that are not supported is as follows:

- FTP
- DNS

### Configuration Impact

- In UDP Jitter test instances, ICMP Jitter test instances, Path Jitter test instances, LSP Jitter test instances, the number of sent packets = **probe-count** x **jitter-packetnum**, but the product cannot exceed 3000.
- If the number of probes has been configured, running the **probe-count** command will override the previous configuration.

### Precautions

The number of probes of a running test instance cannot be changed.

## Example

```
# Set the number of probes to 6 in NQA test instance user test.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test
```

```
[HUAWEI-nqa-user-test] test-type jitter  
[HUAWEI-nqa-user-test] probe-count 6
```

## Related Topics

[16.6.27 jitter-packetnum](#)

[16.6.45 probe-failtimes](#)

## 16.6.45 probe-failtimes

### Function

The **probe-failtimes** command sets the threshold for the number of traps to be sent when the NQA test fails. That is, test packet fragmentation is not allowed.

The **undo probe-failtimes** command restores the default threshold for the number of traps to be sent when the NQA test fails.

By default, one trap is sent for each probe failure.

### Format

**probe-failtimes** *times*

**undo probe-failtimes**

### Parameters

Parameter	Description	Value
<i>times</i>	Specifies the threshold for the number of traps to be sent when the NQA test fails, that is, the number of continuous probe failures.	The value is an integer that ranges from 1 to 15. The default value is 1.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The NQA probe test is used to check whether response packets are received in a probe. If the number of continuous probe failures reaches the specified value, the system sends a trap to the specified NMS.

#### Prerequisites

The type of a test instance has been specified using the **test-type** command. Path jitter test is not supported.

### Follow-up Procedure

Run the **send-trap probefailure** command to enable the system to send a trap to the NMS after a probe fails. Otherwise, the trap cannot be sent to the NMS after a probe fails.

### Precautions

This configuration of a running test instance cannot be changed.

If the test instance does not support **probe-count**, you are advised to set **probe-failtimes** to 1; otherwise, traps cannot be sent.

If the test instance supports **probe-count**, you are advised to set **probe-failtimes** to be smaller or equivalent to probe-count; otherwise, traps cannot be sent.

## Example

# Set the number of continuous probe failures to 10 in the test named **user test**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type tcp
[HUAWEI-nqa-user-test] probe-failtimes 10
```

## Related Topics

[16.6.59 test-type](#)

[16.6.50 send-trap](#)

## 16.6.46 records

### Function

The **records** command sets the maximum number of history records and the maximum number of test results for NQA test instances.

The **undo records** command restores the default maximum number of history records and the default maximum number of test results for NQA test instances.

By default, the number of history records is 50, and the number of test results is 5.

### Format

**records** { **history** *number* | **result** *number* }

**undo records** { **history** | **result** }

### Parameters

Parameter	Description	Value
<b>history</b> <i>number</i>	Specifies the maximum number of history records.	The value is an integer that ranges from 0 to 1000. The default value is 50.

Parameter	Description	Value
<b>result</b> <i>number</i>	Specifies the maximum number of test results.	The value is an integer that ranges from 1 to 10. The default value is 5.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

You can run the **records** command to set the maximum number of history records and the maximum number of test results for NQA test instances.

By default, a test instance supports 50 history records. You need to limit the number of history records on the device. In addition, you need to set the number of allowed remaining history records that can be added. The configured maximum number of history records cannot exceed the sum of the total default number of history records and the remaining number of history records.

### Precautions

The type of a test instance has been specified using the **test-type** command.

This configuration of a running test instance cannot be changed.

## Example

# Set the maximum number of history records to 30 for test instance **user test**.

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type jitter  
[HUAWEI-nqa-user-test] records history 30
```

## Related Topics

[16.6.10 display nqa history](#)

[16.6.11 display nqa results](#)

## 16.6.47 remote-pw-id

### Function

Using the **remote-pw-id** command, you can configure the ID of the remote end of a PW or a VC.

Using the **undo remote-pw-id** command, you can remove the configured ID of the remote end of a PW or a VC.

When the VC type is LDP, **remote-pw-id** defaults to be 0.

## Format

**remote-pw-id** *remote-pw-id*

**undo remote-pw-id**

## Parameters

Parameter	Description	Value
<i>remote-pw-id</i>	Specifies the ID of the remote end of a PW or a VC.	<p>The value is a decimal integer.</p> <ul style="list-style-type: none"> <li>In the case of a PWE3 ping test instance, the value of <i>remote-pw-id</i> is an integer that ranges from 1 to 4294967295, and only the VC type of LDP is supported. The default value is 0, indicating that the ID of the remote end of a PW is not configured.</li> <li>In the case of a PWE3 trace: if the VC type is LDP, the value of <i>remote-pw-id</i> is an integer that ranges from 1 to 4294967295. The default value is 0; if the VC type is BGP, the value of <i>remote-pw-id</i> is an integer that ranges from 0 to 65534.</li> </ul>

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

Before running the **remote-pw-id** command, you must set the test type to PWE3 Trace or PWE3 Ping in the NQA view.

### Precautions

You cannot configure the **remote-pw-id** command after setting **lsp-version** to **rfc4379**.

The *remote-pw-id* value must be the same as the **VC ID** value in the **display mpls l2vc remote-info verbose** command output; otherwise, the test may fail.

## Example

# In the NQA view, configure the ID of the remote end of a PW to 100, the administrator to admin, and the test type to PWE3 trace.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance admin pwe3
[HUAWEI-nqa-admin-pwe3] test-type pwe3trace
[HUAWEI-nqa-admin-pwe3] remote-pw-id 100
```

## Related Topics

[16.6.28 local-pw-id](#)

## 16.6.48 restart (NQA view)

### Function

The **restart** command restarts the current running test instance.

### Format

**restart**

### Parameters

None

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

Function of the **restart** command is the same as that of the **start now** command.

## Example

# Restart the test instance named **user test**.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type jitter
[HUAWEI-nqa-user-test] destination-port 8000
[HUAWEI-nqa-user-test] destination-address ipv4 10.1.1.1
[HUAWEI-nqa-user-test] restart
```

## Related Topics

[16.6.56 start](#)

[16.6.57 stop](#)

## 16.6.49 sendpacket passroute

### Function

The **sendpacket passroute** command enables test packets to be sent without searching the routing table.

The **undo sendpacket passroute** command restores the default setting.

By default, the test packet is sent according to the routing table.

### Format

**sendpacket passroute**

**undo sendpacket passroute**

### Parameters

None

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The type of a test instance has been specified using the **test-type** command. The type of test instances that are supported is as follows:

- ICMP
- TCP
- UDP
- HTTP
- UDP Jitter
- FTP
- SNMP
- Trace

#### Precautions

You cannot change this configuration of a running test instance.

If you configure both the **sendpacket passroute** and **source-interface** commands, the **source-interface** command takes effect. In this scenario, packets are sent from the interface specified using the **source-interface** command.



After the **sendpacket passroute** command is executed, the device sends test packets without searching the routing table. However, the configurations of **tll** and **ip-forwarding** become invalid.

## Example

# Enable test packets to be sent without searching the routing table.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type jitter
[HUAWEI-nqa-user-test] sendpacket passroute
```

## Related Topics

[16.6.59 test-type](#)

[16.6.40 nqa](#)

## 16.6.50 send-trap

### Function

The **send-trap** command configures conditions for sending traps.

The **undo send-trap** command deletes the previous configuration.

By default, the device is disabled from sending traps.

### Format

```
send-trap { all | { probefailure | rtd | testcomplete | testfailure | testresult-change } * }
```

```
undo send-trap { all | { probefailure | rtd | testcomplete | testfailure | testresult-change } * }
```

### Parameters

Parameter	Description	Value
<b>all</b>	Indicates that a trap is sent in any of the following situations: <ul style="list-style-type: none"> <li>The RTD exceeds the threshold.</li> <li>NQA probes fail.</li> <li>An NQA test succeeds.</li> <li>NQA tests fail.</li> </ul>	-
<b>probefailure</b>	Indicates that a trap is sent when the number of probe failures reaches the threshold.  <b>NOTE</b> This parameter does not apply to the UDP Jitter and ICMP Jitter test instances.	-

Parameter	Description	Value
<b>rtd</b>	Indicates that a trap is sent when the RTD exceeds the threshold.	-
<b>testcomplete</b>	Indicates that a trap is sent when a test succeeds.	-
<b>testfailure</b>	Indicates that a trap is sent when the number of test failures reaches the threshold.	-
<b>testresult-change</b>	Indicates that a trap is sent when the probe result changes.  <b>NOTE</b> This function supports only ICMP test instances.	-

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

Traps are generated no matter whether the NQA test succeeds or fails. You can determine whether traps are sent to the NMS by enabling or disabling the trap function.

The device sends traps to the NMS in any of the following situations:

- The RTD exceeds the threshold.  
If the RTD exceeds the threshold, the device sends a trap to the NMS using the configured address.
- NQA probes fail.  
When no response packet is received after a specified number of continuous test packets are sent, the device sends a trap to the NMS using the configured address.
- An NQA test succeeds.  
When the device receives a response packet from a destination address, the device sends a trap to the NMS using the configured address.
- NQA tests fail.  
When the number of continuous test failures reaches the maximum number, the device sends a trap to the NMS using the configured address.

You can run the **send-trap** command to configure conditions for sending traps. When a condition is met, the device sends a trap to the NMS.

### Prerequisites

The type of a test instance has been specified using the **test-type** command. Path jitter test is not supported.

The route between the device and NMS is reachable, and related configurations are complete. The host where traps are sent is configured using the **snmp-agent target-host trap** command; otherwise, traps cannot be sent to the NMS.

### Precautions

You cannot change this configuration of a running test instance.

## Example

# Configure the test instance **user test** to send a trap when the test fails.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type jitter
[HUAWEI-nqa-user-test] send-trap testfailure
```

## Related Topics

[16.6.45 probe-failtimes](#)

[16.6.58 test-failtimes](#)

## 16.6.51 sender-address

### Function

The **sender-address** command configures the source IP address in the multi-hop PW scenario.

The **undo sender-address** command restores the default setting.

By default, no source IP address is configured.

### Format

**sender-address ipv4** *ip-address*

**undo sender-address**

### Parameters

Parameter	Description	Value
<b>ipv4</b> <i>ip-address</i>	Specifies a source IPv4 address.	-

### Views

NQA view

### Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

When PWE3 ping is performed in the multi-hop PW scenario, and the *lsp-version* is **rfc4379**, the **sender-address** command specifies a source IP address. The value is a routable address on the same public network with the address of the destination PE. Usually, the source IP address is the address of the adjacent SPE or UPE.

### Precautions

After the **sender-address** command is run, the LSP version cannot be set to **draft6**.

## Example

# Set the source IP address of the PWE3 ping test instance in the multi-hop PW scenario to 10.1.1.1.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type pwe3ping
[HUAWEI-nqa-user-test] lsp-version rfc4379
[HUAWEI-nqa-user-test] sender-address ipv4 10.1.1.1
```

## 16.6.52 set-df

### Function

The **set-df** command configures the DF (Don't Fragment) field of the test packet. This field prevents packets from being fragmented.

The **undo set-df** command restores the default setting.

By default, packet fragmentation is allowed.

### Format

**set-df**

**undo set-df**

### Parameters

None

### Views

NQA view

### Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

If two hosts need to communicate with each other over multiple networks, the smallest MTU value of the networks is the path MTU value. Packets can be transmitted normally over multiple networks only after the path MTU value is obtained.

If the DF bit of a packet is not configured, and the length of the packet is longer than the MTU value, the packet will be fragmented into several fragments that are shorter than the path MTU value. As a result, the path MTU cannot be detected by sending packets with increasing lengths. To detect the path MTU value, run the **set-df** command to prohibit packet fragmentation. Then, increase the length of packets sent along the path to find the path MTU value.

### Prerequisites

The type of a test instance has been set to Trace using the **test-type trace** command.

### Precautions

The configuration of the DF bit for packets in a running test instance cannot be changed.

## Example

```
# Set the test packet sent without being fragmented.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type trace  
[HUAWEI-nqa-user-test] set-df
```

## Related Topics

[16.6.59 test-type](#)

## 16.6.53 source-address

### Function

The **source-address** command sets the source IP address for a test instance.

The **undo source-address** command restores the default setting.

By default, the IP address of the interface where packets are sent functions as the source IP address of a test instance.

### Format

```
source-address ipv4 ipv4-address
```

```
undo source-address
```

## Parameters

Parameter	Description	Value
<b>ipv4</b> <i>ipv4-address</i>	Specifies the IPv4 source address for the NQA test instance.	The value is in dotted decimal notation.

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

After the test packets are transmitted to the destination address, the source address of the NQA test instance The **source-address** command is used to configure the source IP address for the NQA test. If no source IP address is configured, the system specifies the IP address that sends test packets as the source IP address.

### Prerequisites

The type of a test instance has been specified using the **test-type** command. However, the test type cannot be PWE3 trace, PWE3 ping, or MAC ping.

### Precautions

The configuration of the source IP address of the running test instance cannot be changed.

## Example

```
# Set the source IP address to 10.1.1.1 for test instance user test.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type jitter  
[HUAWEI-nqa-user-test] source-address ipv4 10.1.1.1
```

## Related Topics

- [16.6.59 test-type](#)
- [16.6.54 source-interface](#)
- [16.6.55 source-port](#)

## 16.6.54 source-interface

### Function

The **source-interface** command configures the source interface for an NQA test instance.

The **undo source-interface** command cancels the configuration.

By default, no source interface is configured for an NQA test instance.

## Format

**source-interface** *interface-type interface-number*

**undo source-interface**

## Parameters

Parameter	Description	Value
<i>interface-type interface-number</i>	Specifies the type and number of the source interface for an NQA test instance.	-

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

After test packets reach the destination address, the destination end sends response packets to the client end. After the **source-interface** command is used to configure the source interface for an NQA test instance, there are the following scenarios:

- If the **source-address** command is run to specify the source IP address, the test packets are sent from the specified source interface, but the response packets are received from the configured source IP address.
- If no source IP address is specified for an NQA test instance, the IP address of the source interface will be used as the source IP address of the NQA test instance. In this scenario, the initiated and responded packets are both transmitted over the outbound interface specified by the **source-interface** command.

### Prerequisites

The type of a test instance has been specified using the **test-type** command. The source interface can be configured only for ICMP, ICMP Jitter, UDP Jitter, and MAC Ping test instances.

### Precautions

The configuration of the source interface of a running test instance cannot be changed.

The source interface of an NQA test instance must be an interface with an IP address configured; otherwise, the command cannot take effect.

The source interface cannot be a link aggregation interface or a member interface in load balancing scenario; otherwise, the command cannot take effect.

## Example

# Set the source interface of test instance **user test** to vlanif 100.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] source-interface vlanif 100
```

## Related Topics

[16.6.59 test-type](#)

[16.6.55 source-port](#)

[16.6.53 source-address](#)

## 16.6.55 source-port

### Function

The **source-port** command configures the source port for an NQA test instance.

The **undo source-port** command restores the default setting.

No default source port number is specified, port numbers are randomly allocated by the system.

### Format

**source-port** *port-number*

**undo source-port**

### Parameters

Parameter	Description	Value
<i>port-number</i>	Specifies the source port number for an NQA test instance.	The value is an integer that ranges from 1 to 65535. The configured port cannot be a well-known port or used by other modules.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario



If a source port number is specified in an NQA test instance, NQA test packets can be regulated more accurately, which prevents the probe packets from being filtered by rules such as ACL. The **source-port** command can be used to configure the source port for this NQA test instance:

- If no source port number is specified for an NQA test instance, a port number is selected at random to receive or send NQA test packets.
- If source port number is specified for an NQA test instance, the specified port number is used to receive and send NQA test packets.

### Prerequisites

The test instance type has been specified using the **test-type** command. The source port can be configured for FTP, HTTP, SNMP, UDP Jitter, TCP, and UDP test instances.

### Precautions

The port specified in the **source-port** command must be available; otherwise, the probe fails.

You cannot change this configuration of a running test instance.

## Example

```
# Set the source port number of test instance user test to 3000.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type tcp  
[HUAWEI-nqa-user-test] source-port 3000
```

## Related Topics

- [16.6.59 test-type](#)
- [16.6.54 source-interface](#)
- [16.6.53 source-address](#)

## 16.6.56 start

### Function

The **start** command sets the start mode and end mode for an NQA test instance.

The **undo start** command stops a running NQA test instance or restores the configuration of start mode and end mode of an unperformed NQA test instance.

By default, the test instance stops automatically after test packets are sent.

### Format

```
start at [ yyyy/mm/dd ] hh:mm:ss [ end { at [ yyyy/mm/dd ] hh:mm:ss | delay  
{ seconds second | hh:mm:ss } | lifetime { seconds second | hh:mm:ss } } ]
```

```
start delay { seconds second | hh:mm:ss } [ end { at [ yyyy/mm/dd ] hh:mm:ss |  
delay { seconds second | hh:mm:ss } | lifetime { seconds second | hh:mm:ss } } ]
```

**start now** [ **end** { **at** [ *yyyy/mm/dd* ] *hh:mm:ss* | **delay** { **seconds** *second* | *hh:mm:ss* } | **lifetime** { **seconds** *second* | *hh:mm:ss* } } ]

**undo start**

## Parameters

Parameter	Description	Value
<b>start at</b> [ <i>yyyy/mm/dd</i> ] <i>hh:mm:ss</i>	Performs a test instance at a specified time. <b>NOTE</b> The configured time must be later than the time on the device.	-
<b>start delay</b> { <b>seconds</b> <i>second</i>   <i>hh:mm:ss</i> }	Specifies a delay in performing a test instance.	<ul style="list-style-type: none"> <li>• <b>seconds</b> <i>second</i>: specifies a delay in performing a test instance. The value is an integer ranging from 1 to 86399, in seconds.</li> <li>• <i>hh:mm:ss</i>: specifies a delay in performing a test instance. If <i>hh:mm:ss</i> is specified, the system automatically sets the moment in seconds. For example, 1:0:0 indicates that a test instance starts in one hour (3600 seconds).</li> </ul>
<b>start now</b>	Performs a test instance immediately.	-
<b>end at</b> [ <i>yyyy/mm/dd</i> ] <i>hh:mm:ss</i>	Stops a test instance at a specified time.	-
<b>end delay</b> { <b>seconds</b> <i>second</i>   <i>hh:mm:ss</i> }	Specifies a delay in stopping a test instance. This delay is set based on the current system time. For example: If <b>start at 9:00:00 end delay seconds 60</b> is run at 8:59:40, then, a test instance starts at 9:00:00 and ends at 9:00:40.	<ul style="list-style-type: none"> <li>• <b>seconds</b> <i>second</i>: specifies a delay in stopping a test instance. The value is an integer ranging from 6 to 86399 in seconds.</li> <li>• <i>hh:mm:ss</i>: specifies a delay in stopping a test instance. For example, 1:0:0 stands for a 3600-second delay from the current system time till the time that the test instance stops.</li> </ul> <b>NOTE</b> The delay in stopping a test instance must be set to at least 6s later than the delay in performing the test instance.

Parameter	Description	Value
<b>end lifetime</b> { <b>seconds</b> <i>second</i>   <i>hh:mm:ss</i> }	Specifies the lifetime of an NQA test instance (starting from the moment that the NQA test instance starts). For example: If <b>start delay seconds 60 end lifetime seconds 120</b> is run at 9:00:00, then, a test instance lasts for 120s as it starts at 09:01:00 and ends at 09:03:00.	<ul style="list-style-type: none"> <li>• <b>seconds</b> <i>second</i>: sets the life time of a test instance in seconds. The value is an integer ranging from 6 to 86399 in seconds.</li> <li>• <i>hh:mm:ss</i>: sets the lifetime of a test instance. For example, 1:0:0 indicates that the lifetime of a test instance is 3600s starting from the moment a test instance starts.</li> </ul>

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

After configuring test instances and relevant attributes, you need to manually set the start and end modes for the test instances. The types of start and end modes are as follows:

- Start modes:
  - Starting a test instance at a specified time
  - Starting a test instance immediately
  - Starting a test instance after a certain delay
- End modes:
  - Ending a test instance at a specified time
  - Ending a test instance immediately
  - Ending a test instance after a certain delay
  - Ending a test instance after all test packets are sent

You can set the start and end modes as required.

### Precautions

If the number of the running test instances reaches the maximum value defined by the system, the **start** command is invalid.

For the same test instance, the **start now** command can be used again only when the previous configuration is complete. Although this command has been run and configurations have been saved, this **start now** command will not be restored and needs to be run again after the device is restarted.

When starting a test instance at a specified time, the time must be later than the current time on the device.

## Example

```
# Perform the test 10 hours later.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type jitter  
[HUAWEI-nqa-user-test] destination-address ipv4 10.1.1.1  
[HUAWEI-nqa-user-test] destination-port 4000  
[HUAWEI-nqa-user-test] start delay 10:00:00
```

## Related Topics

[16.6.59 test-type](#)

[16.6.12 display nqa-agent](#)

## 16.6.57 stop

### Function

The **stop** command stops an NQA test instance.

### Format

```
stop
```

### Parameters

None

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

You can run this command to stop only the running NQA test instances, that is, test instances in active state.

## Example

```
# Stop the test instance named user test.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] stop
```

## Related Topics

- [16.6.56 start](#)
- [16.6.16 frequency](#)

## 16.6.58 test-failtimes

### Function

The **test-failtimes** command sets the number of consecutive test failures in an NQA test.

The **undo test-failtimes** command restores the default setting.

By default, a trap message is sent for each test failure.

### Format

**test-failtimes** *times*

**undo test-failtimes**

### Parameters

Parameter	Description	Value
<i>times</i>	Specifies the number of consecutive test failures in an NQA test.	The value is an integer that ranges from 1 to 15. The default value is 1.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

An NQA test consists of multiple probe tests. By default, if one or more probe tests are successful in an NQA test, the test is considered successful. If all probe tests fail, the test is considered failed. If the number of consecutive test failures reaches the specified value, the system will send a trap to the specified NMS.

#### Prerequisites

The type of a test instance has been specified using the **test-type** command. Path jitter test is not supported.

#### Follow-up Procedure

Run the **send-trap testfailure** command to send a trap to the NMS after an NQA test fails. Otherwise, the trap cannot be sent to the NMS after an NQA test fails.

### Precautions

This configuration of a running test instance cannot be changed.

### Example

# Set the number of consecutive test failures to 10.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type jitter
[HUAWEI-nqa-user-test] test-failtimes 10
```

### Related Topics

[16.6.15 fail-percent](#)

[16.6.50 send-trap](#)

## 16.6.59 test-type

### Function

The **test-type** command configures the test type for an NQA test instance.

The **undo test-type** command cancels the test type configured for an NQA test instance.

By default, no test type is configured.

### Format

**test-type** { dns | ftp | http | icmp | icmpjitter | jitter | lspjitter | lsping | lspttrace | macping | pathjitter | pwe3ping | pwe3trace | snmp | tcp | trace | udp }

**undo test-type**

 NOTE

The S1720GFR does not support **macping**.

Only the S5720EI, S5720HI, S6720EI, and S6720S-EI support **lspjitter**, **lsping**, **lspttrace**, **pwe3ping**, and **pwe3trace**.

### Parameters

Parameter	Description	Value
<b>dns</b>	Specifies a DNS test.	-
<b>ftp</b>	Specifies an FTP service test.	-
<b>http</b>	Specifies an HTTP service test.	-
<b>icmp</b>	Specifies an ICMP test.	-
<b>icmpjitter</b>	Specifies an ICMP jitter test, which can detect the jitter on the network.	-

Parameter	Description	Value
<b>jitter</b>	Specifies a UDP jitter test, which can detect the jitter during UDP packet transmission.	-
<b>lspjitter</b>	Specifies an LSP jitter test.	-
<b>lsping</b>	Specifies an LSP ping test.	-
<b>lsptrace</b>	Specifies an LSP trace route test.	-
<b>macping</b>	Specifies a MAC ping test.	-
<b>pathjitter</b>	Specifies a path jitter test, which can detect the hop-by-hop jitter during the ICMP packet transmission.	-
<b>pwe3ping</b>	Specifies a PWE3 ping test.	-
<b>pwe3trace</b>	Specifies a PWE3 trace test.	-
<b>snmp</b>	Specifies an SNMP test.	-
<b>tcp</b>	Specifies a TCP test.	-
<b>trace</b>	Specifies a trace test.	-
<b>udp</b>	Specifies a UDP test.	-

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

- After an NQA test instance is created, a test type needs to be specified for it as other parameters are configured based on the test instance type. To configure the test type for an NQA test instance, run the **test-type** command.
- You cannot change the type of a running test instance.
- An ICMP test is usually conducted to check the connectivity. However, it cannot accurately test the link delay. Therefore, to test link delay or other link performance, you are advised to conduct an ICMP jitter or UDP jitter test.

## Example

# Configure the test type of an NQA test instance as TCP.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type tcp
```

## Related Topics

[16.6.40 nqa](#)

## 16.6.60 timestamp-unit

### Function

The **timestamp-unit** command sets the unit of timestamp for an NQA test instance.

The **undo timestamp-unit** command restores the default setting.

By default, the unit of timestamp for an NQA test instance is millisecond.

### Format

```
timestamp-unit { millisecond | microsecond }
```

```
undo timestamp-unit microsecond
```

### Parameters

Parameter	Description	Value
<b>millisecond</b>	Sets the unit of timestamp for an NQA test instance to millisecond.	-
<b>microsecond</b>	Sets the unit of timestamp for an NQA test instance to microsecond.	-

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

This command applies to the ICMP Jitter and UDP Jitter tests.

### Example

```
# Set the unit of timestamp for an NQA test instance to microsecond.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type jitter  
[HUAWEI-nqa-user-test] timestamp-unit microsecond
```

### Related Topics

[16.6.40 nqa](#)



## 16.6.61 threshold

### Function

The **threshold** command sets the RTD threshold.

The **undo threshold** command deletes the RTD threshold.

By default, no threshold is set.

### Format

**threshold rtd** *rtd-value*

**undo threshold rtd**

### Parameters

Parameter	Description	Value
<b>rtd</b> <i>rtd-value</i>	Sets the RTD threshold.	The value is an integer that ranges from 1 to 60000. The unit of this value is the same as that of the timestamp set using the <a href="#">timestamp-unit</a> command.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

The type of a test instance has been specified using the [test-type](#) command. Path jitter test is not supported.

### Example

```
# Set the RTD threshold to 2 ms.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type jitter  
[HUAWEI-nqa-user-test] threshold rtd 2
```

### Related Topics

[16.6.50 send-trap](#)

## 16.6.62 timeout

### Function

The **timeout** command sets the timeout period for a probe of an NQA test instance.

The **undo timeout** command restores the default timeout period for a probe of an NQA test instance.

By default, the timeout period for FTP test instances is 15 seconds and that for other test instances is 3 seconds.

### Format

**timeout** *time*

**undo timeout**

### Parameters

Parameter	Description	Value
<i>time</i>	Specifies the timeout period for a probe.	The value is an integer that ranges from 1 to 60, in seconds.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

The timeout period refers to the waiting time after a probe is sent. If no response packet is received when the timeout period expires, the test fails. The timeout period is set based on the actual networking.

On an unstable network with a low transmission rate, you need to prolong the timeout period for sending probe packets to ensure that response packets can be received.

#### Prerequisites

The type of a test instance has been specified using the **test-type** command.

#### Precautions

- You are advised to set the timeout period based on the round-trip time (RTT) value. Ensure that the timeout period set by the **timeout** command is longer than the RTT value.

- The timeout period set by the **timeout** command must be smaller than or equal to the interval of automatic tests set by the **interval** command. Otherwise, the tests fail due to timeout of test packets.

### Precautions

You cannot change this configuration of a running test instance.

In an ICMP test instance, if the following conditions are met, the Completion field in the test results will be displayed as **no result**:

- The system CPU usage exceeds 90% and the configured timeout period is less than 6s.
- **frequency** configured  $\leq (\text{probe-count} - 1) \times \text{interval} + 6$ .

## Example

# Set the timeout period of the test instance named **user test** to 20 seconds.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type jitter
[HUAWEI-nqa-user-test] timeout 20
```

## Related Topics

[16.6.16 frequency](#)

[16.6.25 interval \(NQA view\)](#)

## 16.6.63 tos

### Function

The **tos** command sets the ToS value for an NQA test packet.

The **undo tos** command restores the default ToS value of an NQA test packet.

By default, the ToS value is 0.

### Format

**tos** *value*

**undo tos**

### Parameters

Parameter	Description	Value
<i>value</i>	Specifies the ToS value of a packet.	The value is an integer that ranges from 0 to 255. The default value is 0.

### Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The ToS field contains a precedence sub-field and a ToS sub-field. The precedence sub-field indicates the priority of a packet and the ToS sub-field is seldom used. All the bits in the ToS sub-field must be set to 0. You can set the priority of probe packets by setting the ToS value. When a large number of packets are received, packets of high priorities are processed preferentially.

### Prerequisites

The type of a test instance has been specified using the **test-type** command. The following types of test instances are supported:

- FTP
- HTTP
- ICMP
- ICMP Jitter
- UDP Jitter
- SNMP
- TCP
- UDP

### Configuration Impact

If you run the **tos** command multiple times, only the latest configuration takes effect.

### Precautions

The ToS value of a running test instance cannot be changed.

## Example

# Set the ToS value for the test instance named **user test** to 10.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] tos 10
```

## Related Topics

[16.6.59 test-type](#)

[16.6.40 nqa](#)

## 16.6.64 tracert-hopfailtimes

### Function

The **tracert-hopfailtimes** command sets the number of consecutive failed hops indicating a failed trace test instance.

The **undo tracert-hopfailtimes** command restores the default number of consecutive failed hops indicating a failed trace test instance.

By default, five consecutive failed hops indicate a failed trace test instance.

### Format

**tracert-hopfailtimes** *times*

**undo tracert-hopfailtimes**

### Parameters

Parameter	Description	Value
<i>times</i>	Specifies the number of consecutive failed hops indicating a failed trace test instance.	The value is an integer that ranges from 1 to 255.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

The **tracert-hopfailtimes** command only takes effect for trace test instances.

You cannot change this configuration of a running test instance.

### Example

# Set the number of consecutive failed hops indicating a failed trace test instance to 6.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type trace
[HUAWEI-nqa-user-test] tracert-hopfailtimes 6
```

### Related Topics

[16.6.59 test-type](#)

## 16.6.65 tracert-lifetime

### Function

The **tracert-lifetime** command sets the time to live (TTL) value for trace test instances in an NQA test.

The **undo tracert-lifetime** command restores the default TTL value for trace test instances in an NQA test.

By default, the initial TTL value is 1 and the maximum TTL value is 30.

### Format

```
tracert-lifetime first-ttl first-ttl max-ttl max-ttl
```

```
undo tracert-lifetime
```

### Parameters

Parameter	Description	Value
<b>first-ttl</b> <i>first-ttl</i>	Specifies the initial TTL value of a packet.	The value is an integer that ranges from 1 to 255. The default value is 1.
<b>max-ttl</b> <i>max-ttl</i>	Specifies the maximum TTL value of a packet.	The value is an integer that ranges from 1 to 255. The value of <i>max-ttl</i> must be greater than the value of <i>first-ttl</i> . By default, the maximum TTL value is 30.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

The **tracert-lifetime** command takes effect only for trace test instances.

You cannot change this configuration of a running test instance.

### Example

# Set the initial TTL value of the test instance named **user test** to 5 and the maximum TTL value to 20.

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type trace  
[HUAWEI-nqa-user-test] tracert-lifetime first-ttl 5 max-ttl 20
```

## Related Topics

[16.6.59 test-type](#)

## 16.6.66 ttl

### Function

The **ttl** command sets the TTL value for the test packets of an NQA test instance.

The **undo ttl** command restores the default setting.

The default TTL value is 30.

### Format

**ttl** *number*

**undo ttl**

### Parameters

Parameter	Description	Value
<i>number</i>	Specifies the TTL value.	The value is an integer that ranges from 1 to 255. The default TTL value is 30.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

To prevent test packets from being transmitted endlessly, the test instance must be performed within certain hops.

When a test packet is created, you can run the **ttl** command to set the TTL value. When the test packet is transmitted along Layer 3 routing devices, each Layer 3 routing device decrements the TTL value by one when the packet arrives. When the TTL value is 0, the Layer 3 routing device discards the test packet and sends an error message to the sending end. This prevents test packets from being transmitted endlessly.

#### Prerequisites

The type of a test instance has been specified using the **test-type** command. The type of test instances that are not supported is as follows:

- DNS

- Trace
- MAC Ping
- Path Jitter

### Configuration Impact

If you run the **ttl** command multiple times, only the latest configuration takes effect.

### Precautions

The type of a running test instance cannot be changed.

## Example

# Set the TTL value for the test packets of a test instance named **user test** to 10.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] ttl 10
```

## Related Topics

[16.6.59 test-type](#)

## 16.6.67 ttl-copymode

### Function

Using the **ttl-copymode** command, you can specify the TTL propagation mode (pipe or uniform) for a multi-hop PW detection.

Using the **undo ttl-copymode** command, you can cancel the TTL propagation mode configured in the NQA view.

By default, the TTL propagation mode varies with products.

### Format

**ttl-copymode** { pipe | uniform }

**undo ttl-copymode**

### Parameters

Parameter	Description	Value
<b>pipe</b>	Sets the TTL propagation mode to pipe.	-
<b>uniform</b>	Sets the TTL propagation mode to uniform.	-

### Views

NQA view



## Default Level

2: Configuration level

## Usage Guidelines

During the detection of a multi-hop PW, if the default TTL propagation mode on different devices is different, you need to specify the TTL propagation mode on the first hop of the PW. This command is used to detect PWE3 networks and BGP/MPLS IP VPN networks.

The TTL propagated in pipe and uniform modes is processed in different manners:

- When receiving a packet carrying the TTL propagated in pipe mode, the system strips the outer tag of the packet, decreases the TTL in the inner tag by 1, and then sets the TTL in the outer tag to 255.
- When receiving a packet carrying the TTL propagated in uniform mode, the system maps the TTL in the outer tag to the inner tag, decreases the TTL in the inner tag by 1, and then sets the TTL in the outer tag to the value of the TTL in the inner tag.

### NOTE

The **ttl-copymode** command makes sense only in the Trace test instances. In the case of a trace test instance, you need to first run the **vpn-instance** *vpn-instance-name* command to bind the NQA trace test instance with a VPN instance.

## Example

# Configure the TTL propagation mode of packets in the NQA trace test instance as pipe.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance admin trace
[HUAWEI-nqa-admin-trace] test-type trace
[HUAWEI-nqa-admin-trace] vpn-instance voice
[HUAWEI-nqa-admin-trace] ttl-copymode pipe
```

## Related Topics

[16.6.59 test-type](#)

## 16.6.68 undo no-control-word

### Function

Using the **undo no-control-word** command, you can enable the control-word option.

By default, the control-word is used in packet encapsulation.

### Format

**undo no-control-word**

## Parameters

None

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

The control-word option carries control-word information in each encapsulated packet. The information is used for packet sequence verification, packet fragmentation, and packet reassembling on the forwarding plane.

By default, the control-word is used in packet encapsulation. If a non-huawei device does not support control-word information in the packet structure, the **label-type** { { **label-alert** | **normal** } **no-control-word** } command can be used on the Huawei device to remove the control-word option from each packet sent to the non-huawei device to facilitate their interworking.

If a non-huawei device supports control-word information in the packet structure, the **undo no-control-word** command can be used on the Huawei device to restore the Huawei packet structure.

### NOTE

Only PWE3 Ping and PWE3 Trace test instances support the **undo no-control-word** command.

## Example

```
# Enable the control-word option.
```

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance user test  
[HUAWEI-nqa-user-test] test-type pwe3ping  
[HUAWEI-nqa-user-test] label-type label-alert no-control-word  
[HUAWEI-nqa-user-test] undo no-control-word
```

## Related Topics

[16.6.30 label-type](#)

## 16.6.69 vc-type

### Function

Using the **vc-type** command, you can configure the type of the protocol used for setting up an L2VPN VC in the NQA view.

Using the **undo vc-type** command, you can delete the protocol type configured in the NQA view.

By default, the type of the protocol used for setting up an L2VPN VC is LDP.

## Format

**vc-type** { **ldp** | **bgp** }

**undo vc-type**

## Parameters

Parameter	Description	Value
<b>ldp</b>	Propagates inner labels by using LDP as the signaling protocol.	-
<b>bgp</b>	Propagates inner labels by using BGP as the signaling protocol.	-

## Views

NQA view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

The **vc-type** command is used to configure the signaling protocol for an NQA test instance to be identical with that for the PW on the network to be tested.

### Prerequisites

For the **vc-type ldp** command, ensure that the test instance is of the following type:

- PWE3 Ping
- PWE3 Trace

For the **vc-type bgp** command, ensure that the test instance is of the following type:

- PWE3 Trace

### Precautions

The signaling type of a running test instance cannot be changed.

## Example

# In the NQA view, configure BGP to be the type of the protocol used for setting up an L2VPN VC.

```
<HUAWEI> system-view  
[HUAWEI] nqa test-instance admin pwe3
```

```
[HUAWEI-nqa-admin-pwe3] test-type pwe3trace  
[HUAWEI-nqa-admin-pwe3] vc-type bgp
```

## Related Topics

[16.6.40 nqa](#)

## 16.6.70 vpn-instance (NQA view)

### Function

The **vpn-instance** command configures the VPN instance that an NQA test instance belongs to.

The **undo vpn-instance** command deletes the configured VPN instance.

By default, no VPN instance is configured.

#### NOTE

Only S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support this command.

### Format

**vpn-instance** *vpn-instance-name*

**undo vpn-instance**

### Parameters

Parameter	Description	Value
<i>vpn-instance-name</i>	Specifies the VPN instance that an NQA test instance belongs to.	The value must be an existing VPN instance name.

### Views

NQA view

### Default Level

2: Configuration level

### Usage Guidelines

The **vpn-instance** command applies to FTP, HTTP, ICMP, ICMP Jitter, Path Jitter, SNMP, TCP, trace, UDP, and UDP Jitter test instances.

In a PWE3 Trace test instance, if the protocol type of the L2VPN VC is set to BGP by the **vc-type** command, you can run the **vpn-instance** command to specify a VPN instance name for the PWE3 Trace test instance.

You cannot change this configuration of a running test instance.

## Example

# Set the VPN instance for an NQA test instance named **user test** to vrf1.

```
<HUAWEI> system-view
[HUAWEI] nqa test-instance user test
[HUAWEI-nqa-user-test] test-type icmp
[HUAWEI-nqa-user-test] vpn-instance vrf1
```

## Related Topics

[16.6.40 nqa](#)

[16.6.59 test-type](#)

# 16.7 Service Diagnosis Configuration Commands

[16.7.1 Command Support](#)

[16.7.2 display trace information](#)

[16.7.3 display trace instance](#)

[16.7.4 display trace object](#)

[16.7.5 reset trace instance](#)

[16.7.6 save trace information](#)

[16.7.7 trace enable](#)

[16.7.8 trace object](#)

[16.7.9 trace syslog source](#)

## 16.7.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

## 16.7.2 display trace information

### Function

The **display trace information** command displays information about service diagnosis.

### Format

**display trace information**

### Parameters

None

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

After configuring service diagnosis, you can run this command to view global information about service diagnosis, for example, the counts of diagnosis instances and objects created on the device.

## Example

# Display information about service diagnosis.

```
<HUAWEI> display trace information
Trace Information:
-----
Trace Enable           : Enable
Debug info level      : Brief
Debug fill-instance   : Off
Debug quit-instance   : Off
Debug output information : Off
Syslog Source IP Address : -

The sum of all the instances : 0
The startID of the instance table : -
Alloc instance times      : 9
Free instance times       : 9
The sum of all the objects : 2
-----
```

**Table 16-62** Description of the display trace information command output

Item	Description
Trace Information	Information about service diagnosis.
Trace Enable	Status of service diagnosis. <ul style="list-style-type: none"> <li>• Disable: Service diagnosis is disabled.</li> <li>• Enable: Service diagnosis is enabled.</li> </ul> This field can be modified using the <b>trace enable</b> command.
Debug info level	Output level of service diagnosis information. <ul style="list-style-type: none"> <li>• Brief: brief service diagnosis information.</li> <li>• Detail: detailed service diagnosis information.</li> </ul> This field can be modified using the <b>trace enable</b> command.

Item	Description
Debug fill-instance	Debugging status of the <b>fill-instance</b> module. <ul style="list-style-type: none"><li>• Off: disabled</li><li>• On: enabled</li></ul>
Debug quit-instance	Debugging status of the <b>quit-instance</b> module. <ul style="list-style-type: none"><li>• Off: disabled</li><li>• On: enabled</li></ul>
Debug output information	Debugging status of the <b>output information</b> module. <ul style="list-style-type: none"><li>• Off: disabled</li><li>• On: enabled</li></ul>
Syslog Source IP Address	Source IP address of the interface for exporting diagnosis information to the log server. To set the IP address of the interface for exporting diagnosis information to a log server, run the <b>trace syslog source</b> command.
The sum of all the instances	Total number of diagnosis instances.
The startID of the instance table	Start ID of the instance table.
Alloc instance times	Number of the allocated diagnosis instances.
Free instance times	Number of the release diagnosis instances.
The sum of all the objects	Total number of diagnosis objects.

## Related Topics

[16.7.7 trace enable](#)

[16.7.9 trace syslog source](#)

## 16.7.3 display trace instance

### Function

The **display trace instance** command displays diagnosis instances on a device.

### Format

```
display trace instance [ instance-start-id [ instance-end-id ] | mac-address mac-address | ip-address ip-address [ vpn-instance vpn-instance-name ] | interface interface-type interface-number | cid cid ] [ process-wlan ]
```

 NOTE

The **process-wlan** keyword is only supported by S5720HI.

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

## Parameters

Parameter	Description	Value
<i>instance-start-id</i>	Specifies the ID of the first instance whose information is displayed, that is, start ID.	The value varies according to different devices.
<i>instance-end-id</i>	Specifies the ID of the last instance whose information is displayed, that is, end ID.	The value varies according to different devices. <b>NOTE</b> The <i>instance-end-id</i> value must be larger than the <i>instance-start-id</i> value.
<b>mac-address</b> <i>mac-address</i>	Specifies a MAC address.	The value is in the format of H-H-H, in which H is a hexadecimal number of 1 to 4 digits.
<b>ip-address</b> <i>ip-address</i>	Specifies an IP address.	The value is in dotted decimal notation.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The value must be an existing VPN instance name.
<b>interface</b> <i>interface-type</i> <i>interface-number</i>	Specifies the type and number of an interface.	-
<b>cid</b> <i>cid</i>	Specifies the diagnosis instance CID.	The value varies according to different devices.
<b>process-wlan</b>	Specifies the WLAN sub-core.	-

## Views

All views

## Default Level

1: Monitoring level



## Usage Guidelines

If you specify no parameter, all diagnosis instances are displayed in sequence. Each time you run this command, 10 diagnosis instances are displayed. For example, all diagnosis instances have been created on the device. When you run the **display trace instance** command for the first time, information about diagnosis instances 0 to 9 is displayed. When you run this command again, information about instances 10 to 19 is displayed. This process is repeated until information about all the diagnosis instances is displayed. If you specify the value of *instance-start-id*, information about 10 diagnosis instances from this ID is displayed.

To view information about diagnosis instances within a specified range, run the **display trace instance** *instance-start-id instance-end-id* command to specify the start and end IDs of diagnosis instances.

## Example

# Display information about diagnosis instances on the interface with the IP address of 10.10.10.1.

```
<HUAWEI> display trace instance ip-address 10.10.10.1
Trace Instance:
-----
ID          : 0
MAC Address : 0101-0101-0101
IP Flag     : -
Session ID  : -
IP Address  : 10.10.10.1
VRF Index   : -
CID         : 100
User Name   : -
Interface   : -
QinQ VLAN ID : -
User VLAN ID : -
Access Mode : dot1x
Modules online : EAPoL :0  WEBS :0  WEB :0  AAA :0
                  CM :0  TM :0  SAM :0  RADIUS :1
                  DHCPSP :0  DHCPC :0  DHCPR :0  DHCP :0
                  TACACS :0  AM :0  SAVI :0  WLAN_AC :0
-----
Total 1, 1 printed
```

**Table 16-63** Description of the display trace instance command output

Item	Description
ID	ID of the diagnosis instance.
MAC Address	MAC address of the interface.
IP Flag	Flag of the IP address.
Session ID	ID of the session, only valid for PPPoX users.
IP Address	IP address of the interface.
VRF Index	User VPN instance index.
CID	User connect ID.
User Name	User name.

Item	Description
Interface	Interface index.
QinQ VLAN ID	QinQ VLAN ID.
User VLAN ID	User VLAN ID.
Access Mode	User access mode, including dot1x, mac-authen, portal, and wlan. To set the user access mode, run the <a href="#">trace object</a> command.
Modules online	User status on a module. User status can be: <ul style="list-style-type: none"> <li>0: The user is offline on the module.</li> <li>1: The user is online on the module.</li> </ul>

## Related Topics

[16.7.8 trace object](#)

## 16.7.4 display trace object

### Function

The **display trace object** command displays the configuration about a service diagnosis object.

### Format

```
display trace object [ service-object-id ] [ process-wlan ]
```

#### NOTE

The **process-wlan** parameter is only supported by S5720HI.

### Parameters

Parameter	Description	Value
<i>service-object-id</i>	Specifies the ID of a diagnosis object.	The value is an integer that ranges from 0 to 3.
<b>process-wlan</b>	Specifies the WLAN sub-core.	-

### Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

If you do not specify the parameter *service-object-id*, configurations about all diagnosis objects are displayed.

## Example

# Display configurations about all diagnosis objects.

```
<HUAWEI> display trace object
Trace Object:
-----
Object ID   : 0
Slot       : -
MAC Address : -
IP Flag    : -
Session ID : -
IP Address : 10.1.1.1
VRF Index  : -
CID       : -
User Name  : -
Interface  : -
QinQ VLAN ID : -
User VLAN ID : -
Access Mode : -
Output     : command line ( User-Intf 4 )

Object ID   : 1
Slot       : -
MAC Address : 0101-0101-0101
IP Flag    : -
Session ID : -
IP Address : -
VRF Index  : -
CID       : -
User Name  : -
Interface  : -
QinQ VLAN ID : -
User VLAN ID : -
Access Mode : -
Output     : file ( flash:/a.txt )

Object ID   : 2
Slot       : -
MAC Address : 0101-0101-0101
IP Flag    : -
Session ID : -
IP Address : 10.2.2.2
VRF Index  : -
CID       : -
User Name  : -
Interface  : -
QinQ VLAN ID : -
User VLAN ID : -
Access Mode : -
Output     : server ( 10.10.10.10 )
-----
Total 3, 3 printed
```

**Table 16-64** Description of the display trace object command output

Item	Description
Object ID	ID of the diagnosis object. This parameter is automatically generated from 0 in sequence of creation time.
Slot	Slot ID of the device.
MAC Address	MAC address of the interface. To set the MAC address of an interface, run the <b>trace object</b> command.
IP Flag	Flag of the IP address.
Session ID	ID of the session, only valid for PPPoX users.
IP Address	IP address of the interface. To set the IP address of an interface, run the <b>trace object</b> command.
VRF Index	User VRF index.
CID	User connect ID.
User Name	User name. To set the user name, run the <b>trace object</b> command.
Interface	Interface index. To set the interface index, run the <b>trace object</b> command.
QinQ VLAN ID	QinQ VLAN ID. To set the QinQ VLAN ID, run the <b>trace object</b> command.
User VLAN ID	User VLAN ID. To set the user VLAN ID, run the <b>trace object</b> command.
Access Mode	User access mode, including dot1x, mac-authen, portal, and wlan. To set the user access mode, run the <b>trace object</b> command.
Output	<p>Direction in which the device exports diagnosis information. To set the direction, run the <b>trace object</b> command.</p> <ul style="list-style-type: none"> <li>Command line (User-Intf X): Diagnosis information is displayed on the screen of a configuration terminal.</li> </ul> <p><b>NOTE</b> When the configuration terminal is online, X displays the absolute number of the user interface (the absolute number can be checked using the <b>display users</b> command). When the configuration terminal is offline, X displays offline.</p> <ul style="list-style-type: none"> <li>file: Diagnosis information is exported to files.</li> <li>server: Diagnosis information is exported to a log server.</li> </ul>

Item	Description
Total 3, 3 printed	Total number of created diagnosis objects and count of displayed objects.

## Related Topics

[16.7.8 trace object](#)

## 16.7.5 reset trace instance

### Function

The **reset trace instance** command clears all the diagnosis instances on a device.

### Format

**reset trace instance**

### Parameters

None

### Views

System view

### Default Level

3: Management level

## Usage Guidelines

After service diagnosis is enabled and a diagnosis object is created on a device, the device creates a diagnosis instance when a user matching the attributes of the diagnosis object gets online. If the device diagnoses services of multiple users, it creates a diagnosis instance for each user, which occupies a large amount of system resources. Therefore, the device needs to delete the diagnosis instance of a user when the user goes online successfully or fails to go online. Additionally, the device provides an aging mechanism for service diagnosis. When the aging time is reached, the device automatically deletes diagnosis instances to reclaim resources.

In addition to the preceding two methods for automatically clearing diagnosis instances, you can run the **reset trace instance** command to clear all the diagnosis instances.

#### NOTICE

After all the diagnosis instances are cleared using the **reset trace instance** command, properly running diagnosis instances are also deleted. Exercise caution when you run the **reset trace instance** command.

## Example

```
# Clear all diagnosis instances on the device.
```

```
<HUAWEI> system-view  
[HUAWEI] reset trace instance
```

## Related Topics

[16.7.3 display trace instance](#)

## 16.7.6 save trace information

### Function

The **save trace information** command saves diagnosis information in the buffer area as a file.

### Format

```
save trace information
```

### Parameters

None

### Views

System view

### Default Level

2: Configuration level

## Usage Guidelines

### Usage scenario

After you specify the parameter **file** *file-name* in the **trace object** command to save diagnosis information as files to the default root directory on the storage device, the system saves diagnosis information in the buffer area until the buffer is full. To prevent data loss, the system automatically saves diagnosis information in the buffer area as the file *file-name*. Before the buffer becomes full, to view real-time diagnosis information, run the **save trace information** command to save diagnosis information in the buffer area as a file.

### Prerequisites

The device has been configured to export diagnosis information as a file using the [trace object](#) command.

## Example

```
# Save diagnosis information as a file.
```

```
<HUAWEI> system-view  
[HUAWEI] save trace information
```

## Related Topics

[16.7.8 trace object](#)

# 16.7.7 trace enable

## Function

The **trace enable** command enables service diagnosis.

The **undo trace enable** command disables service diagnosis.

By default, service diagnosis is disabled.

## Format

```
trace enable [ brief ]
```

```
undo trace enable
```

## Parameters

Parameter	Description	Value
<b>brief</b>	Configures the device to output brief service diagnosis information.	-

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage scenario

It is difficult to locate problems during user access based on debugging information on existing networks because multiple users may get online or offline simultaneously and debugging information about a specified user cannot be

displayed. Service diagnosis provided by the switch allows maintenance personnel to customize attributes and create diagnosis objects to diagnose information about services of specified users. To enable service diagnosis, run the **trace enable** command.

Service diagnosis information can be displayed in two methods:

- The **trace enable brief** command configures the device to output brief service diagnosis information.
- The **trace enable** command configures the device to output detailed service diagnosis information.

### Follow-up Procedure

After service diagnosis is enabled, run the **trace object** command to create a diagnosis object. After an ID is generated for the diagnosis object, the system starts diagnosis services.

### Precautions

Service diagnosis affects system performance. Therefore, enable service diagnosis only when fault locating is required. After locating faults, immediately run the **undo trace enable** command to disable service diagnosis.

The **trace enable** command is not recorded in the configuration file. Therefore, run the **trace enable** command again after the device restarts to make service diagnosis take effect.

## Example

```
# Enable the service diagnosis function and configure the device to output brief service diagnosis information.
```

```
<HUAWEI> system-view  
[HUAWEI] trace enable brief
```

## Related Topics

[16.7.8 trace object](#)

# 16.7.8 trace object

## Function

The **trace object** command creates a diagnosis object.

The **undo trace object** command deletes a diagnosis object.

By default, no diagnosis object is created. If you do not specify the direction at which information is exported, the default direction is the CLI.

## Format

```
trace object { mac-address mac-address | ip-address ip-address [ vpn-instance vpn-instance-name ] | interface interface-type interface-number | user-vlan user-vlan-id [ qinq-vlan qinq-vlan-id ] | user-name user-name | access-mode { dot1x |
```



**mac-authen | portal | wlan } } \* [ process-wlan ] [ output { command-line | file file-name | syslog-server syslog-server-ip } ]**

**undo trace object { mac-address mac-address | ip-address ip-address [ vpn-instance vpn-instance-name ] | interface interface-type interface-number | user-vlan user-vlan-id [ qinq-vlan qinq-vlan-id ] | user-name user-name | access-mode { dot1x | mac-authen | portal | wlan } } \* [ process-wlan ] [ output { command-line | file file-name | syslog-server syslog-server-ip } ]**

**undo trace object { service-object-id | all }**

 **NOTE**

Only S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support **vpn-instance** *vpn-instance-name*.

The **access-mode** **wlan** and **process-wlan** parameters are only supported by S5720HI.

## Parameters

Parameter	Description	Value
<b>mac-address</b> <i>mac-address</i>	Creates a diagnosis object based on the MAC address.	The value is in the format of H-H-H, in which H is a hexadecimal number of 1 to 4 digits.
<b>ip-address</b> <i>ip-address</i>	Creates a diagnosis object based on the IP address.	The value is in dotted decimal notation.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The value must be an existing VPN instance name.
<b>interface</b> <i>interface-type</i> <i>interface-number</i>	Creates a diagnosis object based on the interface.	-
<b>user-vlan</b> <i>user-vlan-id</i>	Creates a diagnosis object based on the user VLAN.	The value is an integer that ranges from 1 to 4094.
<b>qinq-vlan</b> <i>qinq-vlan-id</i>	Creates a diagnosis object based on the QinQ VLAN ID.	The value is an integer that ranges from 1 to 4094.
<b>user-name</b> <i>user-name</i>	Creates a diagnosis object based on the user name.	The value is a string of 1 to 253 case-insensitive characters without spaces.
<b>access-mode</b>	Creates a diagnosis object based on the access mode.	-

Parameter	Description	Value
<b>dot1x</b>	Creates a diagnosis object based on the dot1x access mode.	-
<b>mac-authen</b>	Creates a diagnosis object based on the mac-authen access mode.	-
<b>portal</b>	Creates a diagnosis object based on the portal access mode.	-
<b>wlan</b>	Creates a diagnosis object based on the wlan access mode.	-
<b>process-wlan</b>	Specifies the WLAN sub-core.	-
<b>output</b>	Specifies the direction in which the device exports diagnosis information.	-
<b>command-line</b>	Exports diagnosis information to the CLI.	-
<b>file</b> <i>file-name</i>	Exports diagnosis information as a file.  <b>NOTE</b> It is recommended that you export the diagnosis information to a specified file.	The value of <i>file-name</i> is a string of 1 to 63 case-insensitive characters without spaces.
<b>syslog-server</b> <i>syslog-server-ip</i>	Exports diagnosis information to a log server.	<i>syslog-server-ip</i> specifies the IP address of the log server, in dotted decimal notation.
<i>service-object-id</i>	Specifies the ID of a diagnosis object to be deleted.  <b>NOTE</b> Diagnosis object IDs are generated based on sequence in which the diagnosis objects are created. The ID starts from 0.  To view all created diagnosis objects, run the <b>display trace object</b> command.	The value is an integer that ranges from 0 to 3.
<b>all</b>	Deletes all diagnosis objects.	-

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage scenario

When locating faults of DHCP, AAA, or NAC service during user access, maintenance personnel can create diagnosis objects to trace services and locate the faults.

Users with different services have different attributes. Create diagnosis objects for different services based on different attributes.

- DHCP service: based on the MAC address.
- AAA and NAC services: based on the MAC address, IP address, user name, user VLAN ID, or access mode.

### NOTE

To ensure that you can diagnose the entire DHCP service process, create a diagnosis object based on the MAC address. You can run the **trace object mac-address** *mac-address* [ **output** { **command-line** | **file** *file-name* | **syslog-server** *syslog-server-ip* } ] command to create a diagnosis object for the DHCP service.

Service diagnosis supports only common AAA users.

### Prerequisites

Service diagnosis has been enabled using the **trace enable** command.

### Precautions

If a diagnosis object is created based on the MAC address or IP address, various service processes can be diagnosed generally. If a diagnosis object is created based on other parameters, service diagnosis may fail to be performed because the parameters may not be obtained in service processes. Therefore, you are advised to create a diagnosis object based on the MAC address or IP address.

When the **slot** parameter is used for service diagnosis, if a user switches between the pre-authentication connection and authentication success states and authorization information (including ACL, VLAN, or authentication event authorization) is not changed in the switching process, no service diagnosis information will be output. In this situation, you can use the user name or interface for service diagnosis.

The diagnosis output file cannot exceed 1 MB. The excessive diagnosis information is not recorded.

You can run the **undo trace object** command to delete diagnosis objects in any of the following modes:

- Delete diagnosis objects based on the object attributes. Run the **undo trace object** { **mac-address** *mac-address* | **ip-address** *ip-address* [ **vpn-instance**

*vpn-instance-name* ] | **interface** *interface-type interface-number* | **user-vlan** *user-vlan-id* [ **qinq-vlan** *qinq-vlan-id* ] | **user-name** *user-name* | **access-mode** { **dot1x** | **mac-authen** | **portal** | **wlan** } } \* [ **output** { **command-line** | **file** *file-name* | **syslog-server** *syslog-server-ip* } ] command. For example, diagnosis objects 1 (10.10.10.1) and 2 (10.10.10.1+0025-9efb-be78) have been created. To delete diagnosis objects based on the IP address, run the **undo trace object ip-address 10.10.10.1** command. Diagnosis objects 1 and 2 are deleted.

- Delete diagnosis objects based on the object ID. Run the **undo trace object service-object-id** command to delete a specified diagnosis object. You can view the object ID using the **display trace object** command
- Delete all diagnosis objects using the **undo trace object all** command.
- The AR1000V does not support diagnosis objects of the **dot1x**, **mac-authen**, or **portal** access mode, so specifying these parameters is not recommended on the AR1000V.

## Example

# Create a diagnosis instance on the interface with the IP address of 10.10.10.1.

```
<HUAWEI> system-view  
[HUAWEI] trace object ip-address 10.10.10.1
```

## Related Topics

[16.7.4 display trace object](#)

[16.7.7 trace enable](#)

## 16.7.9 trace syslog source

### Function

The **trace syslog source** command sets the source interface from which the device exports diagnosis information to a log server.

The **undo trace syslog source** command cancels the configuration of the source interface from which the device exports diagnosis information to a log server.

By default, no interface is specified to export diagnosis information to the log server.

### Format

**trace syslog source** *interface-type interface-number*

**undo trace syslog source**

## Parameters

Parameter	Description	Value
<i>interface-type interface-number</i>	Specifies the type and number of an interface.	-

## Views

System view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage scenario

After you specify an interface for exporting diagnosis information to a log server, the system specifies the IP address of this interface as the source IP address of service diagnosis packets. In this way, the log server can identify the source of diagnosis information.

### Prerequisites

The device has been configured to export diagnosis information to a log server using the [trace object](#) command.

### Precautions

The **trace syslog source** command is not recorded in the configuration file. After the device restarts, the configured source interface for exporting diagnosis information is invalid. To set the source interface, run the **trace syslog source** command again.

## Example

# Set VLANIF100 as the source interface for exporting diagnosis information to the log server.

```
<HUAWEI> system-view  
[HUAWEI] trace syslog source vlanif 100
```

## Related Topics

[16.7.8 trace object](#)

## 16.8 Mirroring Configuration Commands

### NOTE

The device supports the mirroring function, which is mainly used for network monitoring and fault management and may use user communication information. Huawei will not collect or save user communication information independently. You must use this function in compliance with applicable laws and regulations. Ensure that your customers' privacy is protected when you are using or saving communication information.

#### [16.8.1 Command Support](#)

#### [16.8.2 display observe-port](#)

#### [16.8.3 display port-mirroring](#)

#### [16.8.4 mac-mirroring](#)

#### [16.8.5 mirroring to observe-port \(VLAN view\)](#)

#### [16.8.6 mirroring to observe-port \(traffic behavior view\)](#)

#### [16.8.7 observe-port \(local observing port\)](#)

#### [16.8.8 observe-port \(remote observing port\)](#)

#### [16.8.9 port-mirroring to observe-port](#)

### 16.8.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

### 16.8.2 display observe-port

#### Function

The **display observe-port** command displays the observing port configuration.

#### Format

```
display observe-port
```

#### Parameters

None

#### Views

All views

#### Default Level

1: Monitoring level

## Usage Guidelines

After observing ports are configured using the [16.8.7 observe-port \(local observing port\)](#) or [16.8.8 observe-port \(remote observing port\)](#) command in the system view, you can run the **display observe-port** command to check detailed information about the configured observing ports.

## Example

# Display the observing port configuration.

```
<HUAWEI> display observe-port
-----
Index      : 1
Untag-packet : No
Interface  : GigabitEthernet0/0/1
Vlan      : 10
-----
```

**Table 16-65** Description of the **display observe-port** command output

Item	Description
Index	Index of an observing port. This parameter is configured using the <a href="#">16.8.7 observe-port (local observing port)</a> or <a href="#">16.8.8 observe-port (remote observing port)</a> command.
Untag-packet	Whether to remove VLAN tags of mirrored packets. This parameter is configured using the <a href="#">16.8.7 observe-port (local observing port)</a> command. <b>NOTE</b> VLAN tags of mirrored packets can be removed only when local observing ports are configured on an S5720HI. Each mirrored packet can have at most two VLAN tags removed.
Interface	Observing ports configured one by one. This parameter is configured using the <a href="#">16.8.7 observe-port (local observing port)</a> or <a href="#">16.8.8 observe-port (remote observing port)</a> command.
Vlan	ID of the VLAN to which an observing port belongs. This parameter is configured using the <a href="#">16.8.8 observe-port (remote observing port)</a> command.

## 16.8.3 display port-mirroring

### Function

The **display port-mirroring** command displays the mirroring configuration.

### Format

**display port-mirroring**

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

After observing ports and mirrored ports are configured on the switch, you can run the **display port-mirroring** command to check detailed mirroring configuration on the switch.

### Example

# Display the mirroring configuration.

```
<HUAWEI> display port-mirroring
-----
Observe-port 1 : GigabitEthernet0/0/2
-----
Port-mirror:
-----
   Mirror-port      Direction  Observe-port
-----
1  GigabitEthernet0/0/15  Inbound   Observe-port 1
-----
Stream-mirror:
-----
   Behavior      Direction  Observe-port
-----
1  b1            -          Observe-port 1
-----
Vlan-mirror:
-----
Mirror-vlan      Direction  Observe-port
-----
10               Inbound   Observe-port 1
-----
Mac-mirror:
-----
Mirror-mac      Vlan      Direction  Observe-port
-----
0001-0001-0001  10       Inbound   Observe-port 1
-----
```



**Table 16-66** Description of the **display port-mirroring** command output

Item	Description
Port-mirror	Port mirroring configuration.
Mirror-port	Mirrored port. This parameter is configured using the <a href="#">16.8.9 port-mirroring to observe-port</a> command.
Direction	Direction of mirrored packets: <ul style="list-style-type: none"> <li>• Inbound</li> <li>• Outbound</li> </ul> This parameter is configured using the <a href="#">16.8.9 port-mirroring to observe-port</a> command.
Observe-port	Observing port to which mirrored packets are sent. This parameter is configured using the <a href="#">16.8.7 observe-port (local observing port)</a> or <a href="#">16.8.8 observe-port (remote observing port)</a> command.
Stream-mirror	Traffic mirroring configuration.
Behavior	Traffic behavior of traffic mirroring. <ul style="list-style-type: none"> <li>• In MQC-based traffic mirroring, this parameter is configured using the <a href="#">16.8.6 mirroring to observe-port (traffic behavior view)</a> command.</li> <li>• In ACL-based traffic mirroring, this parameter is configured using the <a href="#">15.8.10 traffic-mirror (system view)</a> or <a href="#">15.8.9 traffic-mirror (interface view)</a> command.</li> </ul>
Vlan-mirror	VLAN mirroring configuration.
Mirror-vlan	VLAN ID in VLAN mirroring. This parameter is configured using the <a href="#">16.8.5 mirroring to observe-port (VLAN view)</a> command.
Mac-mirror	MAC address mirroring configuration.
Mirror-mac	MAC address in MAC address mirroring. This parameter is configured using the <a href="#">16.8.4 mac-mirroring</a> command.
Vlan	VLAN in which MAC address mirroring is used.

## 16.8.4 mac-mirroring

### Function

The **mac-mirroring** command copies packets with a specified MAC address to observing ports.

The **undo mac-mirroring** command cancels copying packets with a specified MAC address to observing ports.

By default, packets with a specified MAC address are not copied to observing ports.

 **NOTE**

This command is not supported by the S5720HI.

## Format

**mac-mirroring** *mac-address* **to observe-port** *observe-port-index* **inbound**

**undo mac-mirroring** *mac-address* [**to observe-port** *observe-port-index*] **inbound**

## Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies the MAC address of mirrored packets.	The value is in H-H-H format, where H is a hexadecimal number of 1 to 4 digits.
<i>observe-port-index</i>	Specifies the index of observing ports.	The value is an integer. The value ranges from 1 to 8 on the S5720EI, S6720EI, or S6720S-EI. The value is 1 on other devices.
<b>inbound</b>	Copies inbound packets on all the active ports in a VLAN to observing ports.	-

## Views

VLAN view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

In MAC address mirroring, you can run the **mac-mirroring** command to copy packets matching a specified source or destination MAC address in a VLAN to observing ports.

### Prerequisites

Observing ports have been configured using the [16.8.7 observe-port \(local observing port\)](#) or [16.8.8 observe-port \(remote observing port\)](#) command in the system view.

### Precautions

Currently, in MAC address mirroring, only the packets that are received by all the active ports in a VLAN and contain a specified MAC address can be copied to observing ports.

## Example

# Copy inbound packets of which the source or destination MAC address is 0000-0000-0001 on the active ports in VLAN 3 to observing ports with index 1.

```
<HUAWEI> system-view
[HUAWEI] observe-port 1 interface gigabitethernet 0/0/1
[HUAWEI] vlan 3
[HUAWEI-vlan3] mac-mirroring 0000-0000-0001 to observe-port 1 inbound
```

## Related Topics

[16.8.7 observe-port \(local observing port\)](#)

[16.8.8 observe-port \(remote observing port\)](#)

## 16.8.5 mirroring to observe-port (VLAN view)

### Function

The **mirroring to observe-port** command copies packets on all the active ports in a VLAN to observing ports.

The **undo mirroring** command cancels copying packets on all the active ports in a VLAN to observing ports.

By default, packets on all the active ports in a VLAN are not copied to observing ports.

#### NOTE

This command is not supported by the S5720HI.

### Format

**mirroring to observe-port** *observe-port-index* **inbound**

**undo mirroring** [ **to observe-port** *observe-port-index* ] **inbound**

## Parameters

Parameter	Description	Value
<i>observe-port-index</i>	Specifies the index of observing ports.	The value is an integer. The value ranges from 1 to 8 on the S5720EI, S6720EI, or S6720S-EI. The value is 1 on other devices.
<b>inbound</b>	Copies inbound packets on all the active ports in a VLAN to observing ports.	-

## Views

VLAN view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

In VLAN mirroring, you can run the **mirroring to observe-port** command to copy packets on all the active ports in a specified VLAN to observing ports.

### Prerequisites

Observing ports have been configured using the [16.8.7 observe-port \(local observing port\)](#) or [16.8.8 observe-port \(remote observing port\)](#) command in the system view.

### Precautions

Currently, in VLAN mirroring, only the packets that are received by all the active ports in a VLAN can be copied to observing ports.

## Example

# Copy inbound packets on the active ports in VLAN 10 to observing ports with index 1.

```
<HUAWEI> system-view
[HUAWEI] observe-port 1 interface gigabitethernet 0/0/1
[HUAWEI] vlan 10
[HUAWEI-vlan10] mirroring to observe-port 1 inbound
```

## Related Topics

[16.8.7 observe-port \(local observing port\)](#)

[16.8.8 observe-port \(remote observing port\)](#)

## 16.8.6 mirroring to observe-port (traffic behavior view)

### Function

The **mirroring to observe-port** command copies traffic that matches rules to observing ports.

The **undo mirroring** command cancels copying traffic that matches rules to observing ports.

By default, the switch does not copy traffic that matches rules to observing ports.

### Format

**mirroring to observe-port** *observe-port-index*

**undo mirroring**

### Parameters

Parameter	Description	Value
<i>observe-port-index</i>	Specifies the index of an observing port.	The value is an integer. The value ranges from 1 to 8 on the S5720EI, S5720HI, S6720EI, or S6720S-EI. The value is 1 on other devices.

### Views

Traffic behavior view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

In traffic mirroring, you can run the **mirroring to observe-port** command to copy traffic that matches rules to specified observing ports.

#### Prerequisites

Observing ports have been configured using the [16.8.7 observe-port \(local observing port\)](#) or [16.8.8 observe-port \(remote observing port\)](#) command in the system view.

## Example

# Copy traffic that matches rules to observing ports with index 1.

```
<HUAWEI> system-view
[HUAWEI] observe-port 1 interface gigabitethernet 0/0/1
[HUAWEI] traffic behavior tb1
[HUAWEI-behavior-tb1] mirroring to observe-port 1
```

## Related Topics

[16.8.7 observe-port \(local observing port\)](#)

[16.8.8 observe-port \(remote observing port\)](#)

## 16.8.7 observe-port (local observing port)

### Function

The **observe-port** command configures local observing ports.

The **undo observe-port** command deletes local observing ports.

By default, no local observing ports are configured.

### Format

**observe-port** [ *observe-port-index* ] **interface** *interface-type interface-number* [ **untag-packet** ] (single configuration)

**observe-port** [ *observe-port-index* ] **interface-range** { *interface-type interface-number* [ **to** *interface-type interface-number* ] } &<1-n> [ **untag-packet** ] (batch configuration, supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI; n in &<1-n> is 4 on an S5720EI, S6720EI, or S6720S-EI and 8 on an S5720HI)

**observe-port** *observe-port-index* **interface-range** { **add** | **delete** } *interface-type interface-number* (supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI)

**undo observe-port** *observe-port-index*

### Parameters

Parameter	Description	Value
<i>observe-port-index</i>	Specifies the index of observing ports.	The value is an integer. The value ranges from 1 to 8 on the S5720EI, S5720HI, S6720EI, or S6720S-EI, and ranges from 1 to 6 on other devices.
<i>interface-type interface-number</i>	Specifies the type and number of an interface.	-

Parameter	Description	Value
<b>add</b>	Adds observing ports to the observing ports configured in a batch.	-
<b>delete</b>	Deletes observing ports from the observing ports configured in a batch.	-
<b>untag-packet</b>	Removes VLAN tags of mirrored packets.  <b>NOTE</b> Only the S5720HI supports this parameter. Each mirrored packet can have at most two VLAN tags removed.	-

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

When an observing port is directly connected to a monitoring host, you can run the **observe-port** command to configure a local observing port. Observing ports can be configured one by one or in a batch. The single configuration and batch configuration modes can be used simultaneously. If multiple observing ports are configured in a batch, these observing ports are bound to the same mirrored port. Therefore, batch configuration is often used to simplify the configuration of 1:N mirroring.

### Precautions

- The management interface cannot be configured as an observing port.
- If you configure observing ports without specifying *observe-port-index*, the system selects the smallest unused indexes and assigns the indexes to the observing ports in sequence.
- If you need to update the observing ports configured in a batch, run the **observe-port observe-port-index interface-range { add | delete } interface-type interface-number** command to add or delete observing ports to or from the configured observing ports.
- In 1:N mirroring, if you configure packets (in the inbound or outbound direction) on a mirrored port to be copied to multiple observing ports configured in a batch, the packets cannot be copied to other observing ports.
- On the S5720EI, S5720HI, S6720EI, and S6720S-EI, both Ethernet ports and Eth-Trunks can be configured as observing ports. On other devices, only Ethernet ports can be configured as observing ports.

- An observing port in blocked state can still forward mirrored packets.
- The maximum number of observing ports varies depending on device models. For details, see Observing Port Specifications in "Mirroring Configuration" in the *S1720, S2700, S5700, and S6720 V200R011C10 Configuration Guide - Network Management and Monitoring*.
- An observing port is dedicated to forwarding mirrored traffic. Do not configure other services on an observing port; otherwise, mirrored traffic and other service traffic interfere with each other. Do not configure any member port of an Eth-Trunk as an observing port. If you must do so, ensure that the bandwidth of service traffic on this port and the bandwidth occupied by the mirrored traffic do not exceed the bandwidth limit of the port.

## Example

```
# Configure GigabitEthernet0/0/1 as a local observing port.
```

```
<HUAWEI> system-view  
[HUAWEI] observe-port 1 interface gigabitethernet 0/0/1
```

```
# Configure GigabitEthernet0/0/1 through GigabitEthernet0/0/3 as local observing  
ports in a batch.
```

```
<HUAWEI> system-view  
[HUAWEI] observe-port 1 interface-range gigabitethernet 0/0/1 to gigabitethernet 0/0/3
```

## Related Topics

[16.8.2 display observe-port](#)

[16.8.8 observe-port \(remote observing port\)](#)

## 16.8.8 observe-port (remote observing port)

### Function

The **observe-port** command configures remote observing ports.

The **undo observe-port** command deletes remote observing ports.

By default, no remote observing ports are configured.

### Format

**observe-port** [ *observe-port-index* ] **interface** *interface-type interface-number*  
**vlan** *vlan-id* (Layer 2 remote observing port configured one by one)

**observe-port** [ *observe-port-index* ] **interface-range** { *interface-type interface-number* [ **to** *interface-type interface-number* ] } &<1-n> **vlan** *vlan-id* (Layer 2 remote observing ports configured in a batch, supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI; n in &<1-n> is 4 on an S5720EI, S6720EI, or S6720S-EI and 8 on an S5720HI)

**observe-port** *observe-port-index* **interface-range** { **add** | **delete** } *interface-type interface-number* (supported only by the S5720EI, S5720HI, S6720EI, and S6720S-EI)

**undo observe-port** *observe-port-index*



## Parameters

Parameter	Description	Value
<i>observe-port-index</i>	Specifies the index of observing ports.	The value is an integer. The value ranges from 1 to 8 on the S5720EI, S5720HI, S6720EI, or S6720S-EI, and ranges from 1 to 6 on other devices.
<i>interface-type</i> <i>interface-number</i>	Specifies the type and number of an interface.	-
<b>add</b>	Adds observing ports to the observing ports configured in a batch.	-
<b>delete</b>	Deletes observing ports from the observing ports configured in a batch.	-
<b>vlan</b> <i>vlan-id</i>	Specifies the VLAN ID encapsulated into mirrored packets.	The value is an integer that ranges from 1 to 4094.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

In remote mirroring, a monitoring device and monitored device where an observing port resides are connected through a Layer 2 network. The monitored device adds a specified VLAN tag to mirrored packets, and then the observing port broadcasts the mirrored packets in a specified VLAN so that the mirrored packets can be sent to the monitoring device.

Observing ports can be configured one by one or in a batch. The single configuration and batch configuration modes can be used simultaneously. If multiple observing ports are configured in a batch, these observing ports are bound to the same mirrored port. Therefore, batch configuration is often used to simplify the configuration of 1:N mirroring.

### Precautions

- The management interface cannot be configured as an observing port.
- If you configure observing ports without specifying *observe-port-index*, the system selects the smallest unused indexes and assigns the indexes to the observing ports in sequence.
- If you need to update the observing ports configured in a batch, run the **observe-port** *observe-port-index* **interface-range** { **add** | **delete** } *interface-type* *interface-number* command to add or delete observing ports to or from the configured observing ports.
- In 1:N mirroring, if you configure packets (in the inbound or outbound direction) on a mirrored port to be copied to multiple observing ports configured in a batch, the packets cannot be copied to other observing ports.
- On the S5720EI, S5720HI, S6720EI, and S6720S-EI, both Ethernet ports and Eth-Trunks can be configured as observing ports. On other devices, only Ethernet ports can be configured as observing ports.
- An observing port in blocked state can still forward mirrored packets.
- The maximum number of observing ports varies depending on device models. For details, see Observing Port Specifications in "Mirroring Configuration" in the *S1720, S2700, S5700, and S6720 V200R011C10 Configuration Guide - Network Management and Monitoring*.
- An observing port is dedicated to forwarding mirrored traffic. Do not configure other services on an observing port; otherwise, mirrored traffic and other service traffic interfere with each other. Do not configure any member port of an Eth-Trunk as an observing port. If you must do so, ensure that the bandwidth of service traffic on this port and the bandwidth occupied by the mirrored traffic do not exceed the bandwidth limit of the port.

The mac-address learning disable command must be run in the VLAN view to disable the MAC address learning function in VLANs on all the intermediate devices between the monitoring device and the observing port. Otherwise, mirrored traffic will be discarded on the intermediate devices.

## Example

# Configure GigabitEthernet0/0/1 as a Layer 2 remote observing port, and bind the port to VLAN 10.

```
<HUAWEI> system-view  
[HUAWEI] observe-port 1 interface gigabitethernet 0/0/1 vlan 10
```

# Configure GigabitEthernet0/0/1 through GigabitEthernet0/0/3 as Layer 2 remote observing ports in a batch, and bind these ports to VLAN 10.

```
<HUAWEI> system-view  
[HUAWEI] observe-port 2 interface-range gigabitethernet 0/0/1 to gigabitethernet 0/0/3 vlan 10
```

## Related Topics

[16.8.2 display observe-port](#)

[16.8.7 observe-port \(local observing port\)](#)

## 16.8.9 port-mirroring to observe-port

### Function

The **port-mirroring to observe-port** command copies packets on a mirrored port to observing ports.

The **undo port-mirroring** command cancels copying packets on a mirrored port to observing ports.

By default, packets on a mirrored port are not copied to observing ports.

### Format

**port-mirroring to observe-port** *observe-port-index* { **both** | **inbound** | **outbound** }

**undo port-mirroring** [ **to observe-port** *observe-port-index* ] { **both** | **inbound** | **outbound** }

### Parameters

Parameter	Description	Value
<i>observe-port-index</i>	Specifies the index of observing ports.	The value is an integer. The value ranges from 1 to 8 on the S5720EI, S5720HI, S6720EI, or S6720S-EI, and ranges from 1 to 6 on other devices.
<b>both</b>	Copies inbound and outbound packets on a mirrored port to observing ports.	-
<b>inbound</b>	Copies inbound packets on a mirrored port to observing ports.	-
<b>outbound</b>	Copies outbound packets on a mirrored port to observing ports.	-

### Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, Eth-Trunk interface view, port group view

### Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

In port mirroring, you can run the **port-mirroring to observe-port** command to copy packets that pass through a mirrored port to specified observing ports.

### Prerequisites

Observing ports have been configured using the [16.8.7 observe-port \(local observing port\)](#) or [16.8.8 observe-port \(remote observing port\)](#) command in the system view.

### Precautions

To prevent mirrored packets from being lost, ensure that mirrored and monitoring ports have the same port type and bandwidth.

Both physical interfaces and Eth-Trunks can be configured as mirrored ports. If an Eth-Trunk is configured as a mirrored port, its member ports cannot be configured as observing ports.

## Example

```
# Configure port mirroring for inbound packets on GigabitEthernet0/0/1.
```

```
<HUAWEI> system-view  
[HUAWEI] observe-port 1 interface gigabitethernet 0/0/2  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] port-mirroring to observe-port 1 inbound
```

## Related Topics

[16.8.7 observe-port \(local observing port\)](#)

[16.8.8 observe-port \(remote observing port\)](#)

# 16.9 Packet Capture Configuration Command

### NOTE

Based on your requirements to detect failures in telecom transmission, this feature may collect or store some communication information about specific customers. Huawei cannot offer services to collect or store this information unilaterally. Before enabling the function, ensure that it is performed within the boundaries permitted by applicable laws and regulations. Effective measures must be taken to ensure that information is securely protected.

[16.9.1 Command Support](#)

[16.9.2 capture-packet](#)

[16.9.3 capture-packet cpu](#)

## 16.9.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

## 16.9.2 capture-packet

### Function

The **capture-packet** command captures service packets matching specified rules.

### Format

```
capture-packet { interface interface-type interface-number | acl acl-number } *
[ vlan vlan-id | cvlan cvlan-id ] * destination { file file-name | terminal } * [ car
cir car-value | time-out time-out-value | packet-num number | packet-len
length ] *
```

#### NOTE

Only S5720EI, S5720HI, S6720EI, and S6720S-EI support the **cvlan** *cvlan-id* and **car cir** *car-value* parameters.

### Parameters

Parameter	Description	Value
<b>interface</b> <i>interface-type interface-number</i>	Captures packets on a specified interface. <ul style="list-style-type: none"> <li><i>interface-type</i> specifies the interface type.</li> <li><i>interface-number</i> specifies the interface number.</li> </ul>	-
<b>acl</b> <i>acl-number</i>	Captures packets matching a specified ACL.	The value is an integer that ranges from 2000 to 5999 for S5720EI, S5720HI, S6720EI, and S6720S-EI, and from 2000 to 4999 for other models.
<b>vlan</b> <i>vlan-id</i>	Captures packets from a specified VLAN.	The value is an integer that ranges from 1 to 4094.
<b>cvlan</b> <i>cvlan-id</i>	Captures packets with a specified inner VLAN ID.	The value is an integer that ranges from 1 to 4094.
<b>destination</b>	Indicates the destination to which captured packet information is sent.	-

Parameter	Description	Value
<b>file</b> <i>file-name</i>	Saves captured packet information to a file. The file name extension must be <b>.cap</b> . <b>NOTE</b> The captured outgoing packets cannot be saved to a specified file.	The value is a string of 5 to 63 characters.
<b>terminal</b>	Displays captured packet information on a terminal.	-
<b>car cir</b> <i>car-value</i>	Specifies the rate at which packets are captured.	The value is an integer that ranges from 8 to 256, in kbit/s. The default value is 64 kbit/s.
<b>time-out</b> <i>time-out-value</i>	Specifies the timeout period for capturing packets. The system stops capturing packets after the specified timeout period expires.	The value is an integer that ranges from 1 to 300, in seconds. By default, the timeout period is 60s.
<b>packet-num</b> <i>number</i>	Specifies the number of packets to be captured. The system stops capturing packets after the specified number of packets are captured.	The value is an integer that ranges from 1 to 1000. The default value is 100.
<b>packet-len</b> <i>length</i>	Specifies the length of captured packets.	The value is an integer that ranges from 20 to 64, in bytes. The default value is 64 bytes.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

If an error occurs in service traffic forwarding (for example, the traffic status does not match the traffic model), it is recommended that you configure the device to

capture service packets for analysis so that the device can quickly identify invalid packets. This function ensures correct data transmission on the network.

### Precautions

- Currently, packets on the management interface cannot be captured.
- The switch can capture only incoming packets and cannot capture outgoing packets.
- If the IP addresses of ARP packets on the control plane match the IP addresses in a basic or advanced ACL, these ARP packets can also be captured.
- The packet capture configuration is not saved in the configuration file, and becomes invalid when packet capture is complete.
- Different packet capture instances cannot be executed simultaneously. That is, a new packet capture instance can be executed only when the previous one is complete.
- The system limits the rate of captured packets. The default rate limit is 64 kbit/s. If the rate of packets exceeds the limit, some packets may be discarded.
- The device cannot capture the packets of fast ICMP reply, BFD, 802.1ag and VBST.
- When an S1720GFR, S1720GW, S1720GWR, S1720GW-E, S1720GWR-E, S1720X, S1720X-E, S2720EI, S2750EI, S5700LI, S5700S-LI, S5710-X-LI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S6720LI, S6720S-LI, S6720SI, or S6720S-SI discards the packets that it cannot forward, packets may not be captured in some situations. It is recommended that you obtain packets in other ways, such as mirroring.
- For S1720GFR, S1720GW-E, S1720GWR-E, S1720X-E, S2720EI, S2750EI, S5700LI, S5700S-LI, S5710-X-LI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S6720LI, S6720S-LI, S6720SI, and S6720S-SI, the VLAN ID in the packets captured using this command is not the original VLAN ID but the VLAN ID replaced during Layer 3 forwarding. However, the packets can be forwarded normally without affecting services.

## Example

# Capture packets on the interface GigabitEthernet0/0/1, saves them to the capture.cap file, and display them on the terminal.

```
<HUAWEI> system-view
[HUAWEI] capture-packet interface gigabitethernet 0/0/1 destination file capture.cap terminal
[HUAWEI]
Packet: 1
-----
01 80 c2 00 00 00 00 e0 09 87 78 90 81 00 00 01
00 69 42 42 03 00 00 03 02 7c 80 00 00 e0 09 87
78 90 00 00 00 00 80 00 00 e0 09 87 78 90 80 23
00 00 14 00 02 00 0f 00 00 00 40 00 72 67 31 00
-----
Packet: 2
-----
01 80 c2 00 00 00 00 e0 09 87 78 90 81 00 00 01
00 69 42 42 03 00 00 03 02 7c 80 00 00 e0 09 87
78 90 00 00 00 00 80 00 00 e0 09 87 78 90 80 23
00 00 14 00 02 00 0f 00 00 00 40 00 72 67 31 00
-----
```

```
-----packet getting report-----
file: flash:/capture.cap
packets getting: interface GigabitEthernet0/0/1
acl: -
vlan: - cvlan: -
car: 64kbps timeout: 60s
packets: 100 (expected) 0 (actual)
length: 64 (expected)
-----
```

**Table 16-67** Description of the capture-packet command output

Item	Description
file	Local path that stores captured packets.
packets getting	Interface where packets are captured.
acl	ACL number matched by captured packets.
vlan	VLAN ID of captured packets.
cvlan	Inner VLAN ID of captured packets.
car	Rate of captured packets.
timeout	Timeout interval of packet capture. The system stops capturing packets after the specified time interval.
packets	Expected number and actual number of captured packets.
length	Length of captured packets.

### 16.9.3 capture-packet cpu

#### Function

The **capture-packet cpu** command captures packets sent to the CPU.

#### Format

**capture-packet cpu** [ **vlan** *vlan-id* | **acl** *acl-number* ] \* **destination** { **file** *file-name* | **terminal** } \* [ **time-out** *time-out-value* | **packet-num** *number* | **packet-len** *length* ] \*



## Parameters

Parameter	Description	Value
<b>acl</b> <i>acl-number</i>	Captures packets matching a specified ACL.	The value is an integer that ranges from 2000 to 5999 for S5720EI, S5720HI, S6720EI, and S6720S-EI, and from 2000 to 4999 for other models.
<b>vlan</b> <i>vlan-id</i>	Captures packets from a specified VLAN.	The value is an integer that ranges from 1 to 4094.
<b>destination</b>	Indicates the destination to which captured packet information is sent.	-
<b>file</b> <i>file-name</i>	Saves captured packet information to a file. The file name extension must be <b>*.cap</b> .	The value is a string of 5 to 63 characters.
<b>terminal</b>	Displays captured packet information on a terminal.	-
<b>time-out</b> <i>time-out-value</i>	Specifies the timeout period for capturing packets. The system stops capturing packets after the specified timeout period expires.	The value is an integer that ranges from 1 to 300, in seconds. By default, the timeout period is 60s.
<b>packet-num</b> <i>number</i>	Specifies the number of packets to be captured. The system stops capturing packets after the specified number of packets are captured.	The value is an integer that ranges from 1 to 1000. The default value is 100.
<b>packet-len</b> <i>length</i>	Specifies the length of captured packets.	The value is an integer that ranges from 20 to 64, in bytes. The default value is 64 bytes.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

When a CPU fault occurs, such as the CPU usage is high, configure the packet capture function to capture packets sent to the CPU for analysis. This allows the device to process invalid packets in time, ensuring that the CPU works properly.

### Precautions

- If the IP addresses of ARP packets on the control plane match the IP addresses in a basic or advanced ACL, these ARP packets can also be captured.
- When the CPU usage is above 80%, executing this command will keep the CPU usage increasing.
- The packet capture configuration is not saved in the configuration file, and becomes invalid when packet capture is complete.
- Different packet capture instances cannot be executed simultaneously. That is, a new packet capture instance can be executed only when the previous one is complete.
- The system limits the rate of captured packets. The default rate limit is 64 kbit/s. If the rate of packets exceeds the limit, some packets may be discarded.

## Example

# Capture the packets to be sent to the CPU, saves them to the abc.cap file, and display them on the terminal.

```
<HUAWEI> system-view
[HUAWEI] capture-packet cpu destination file flash:/abc.cap
[HUAWEI]
Packet: 1
-----
01 80 c2 00 00 0e 00 e0 09 87 78 90 81 00 00 01
88 cc 02 07 04 00 e0 09 87 78 90 04 16 05 47 69
67 61 62 69 74 45 74 68 65 72 6e 65 74 34 2f 30
2f 32 36 06 02 00 78 08 15 47 69 67 61 62 69 74
-----

Packet: 2
-----
01 80 c2 00 00 0e 00 e0 09 87 78 90 81 00 00 01
88 cc 02 07 04 00 e0 09 87 78 90 04 16 05 47 69
67 61 62 69 74 45 74 68 65 72 6e 65 74 34 2f 30
2f 32 36 06 02 00 78 08 15 47 69 67 61 62 69 74
-----

-----packet getting report-----
file: flash:/abc.cap
packets getting: cpu
acl: -
vlan: - cvlan: -
car: -- timeout: 60s
packets: 100 (expected) 0 (actual)
length: 64 (expected)
-----
```

**Table 16-68** Description of the capture-packet cpu command output

Item	Description
file	Local path that stores captured packets.
packets getting	The system captures the packets to be sent to the CPU.
acl	ACL number matched by captured packets.
vlan	VLAN ID of captured packets.
cvlan	Inner VLAN ID of captured packets.
car	Rate of captured packets.
timeout	Timeout interval of packet capture. The system stops capturing packets after the specified time interval.
packets	Expected number and actual number of captured packets.
length	Length of captured packets.

## 16.10 NetStream Configuration Commands

### NOTE

NetStream collects statistics and analyzes service traffic. During service provisioning, personal data may be involved. You have an obligation to make privacy policies and take measures according to the applicable law of the country to protect personal data.

#### [16.10.1 Command Support](#)

#### [16.10.2 collect counter](#)

#### [16.10.3 collect interface](#)

#### [16.10.4 display ip netstream record](#)

#### [16.10.5 display ip netstream statistics](#)

#### [16.10.6 display netstream](#)

#### [16.10.7 display netstream cache ip aggregation](#)

#### [16.10.8 display netstream cache ip record](#)

#### [16.10.9 display netstream cache ip origin](#)

#### [16.10.10 display netstream cache ipv6 record](#)

#### [16.10.11 display netstream cache ipv6 origin](#)

#### [16.10.12 display snmp-agent trap feature-name index all](#)

#### [16.10.13 enable](#)

- 16.10.14 export version
- 16.10.15 ip netstream
- 16.10.16 ip netstream aggregation
- 16.10.17 ip netstream export host
- 16.10.18 ip netstream export index-switch
- 16.10.19 ip netstream export source
- 16.10.20 ip netstream export version
- 16.10.21 ip netstream record
- 16.10.22 ip netstream sampler
- 16.10.23 ip netstream tcp-flag enable
- 16.10.24 ip netstream timeout active
- 16.10.25 ip netstream timeout inactive
- 16.10.26 ipv6 netstream
- 16.10.27 ipv6 netstream export host
- 16.10.28 ipv6 netstream export index-switch
- 16.10.29 ipv6 netstream export source
- 16.10.30 ipv6 netstream export version
- 16.10.31 ipv6 netstream sampler
- 16.10.32 mask
- 16.10.33 match ip
- 16.10.34 port ip netstream record
- 16.10.35 refresh netstream template
- 16.10.36 reset ip netstream cache
- 16.10.37 reset ip netstream statistics
- 16.10.38 snmp-agent trap enable feature-name index

## 16.10.1 Command Support

Only the S5720HI supports NetStream.

## 16.10.2 collect counter

### Function

The **collect counter** command allows the flexible flow statistics exported to the NetStream Collector (NSC) to contain the number of bytes and packets.

The **undo collect counter** command restores the default setting.

By default, the flexible flow statistics exported to the NSC do not contain the number of bytes or packets.

## Format

```
collect counter { bytes | packets }
```

```
undo collect counter { bytes | packets }
```

## Parameters

Parameter	Description	Value
<b>bytes</b>	Indicates that the flexible flow statistics exported to NSC contain the number of bytes.	-
<b>packets</b>	Indicates that the flexible flow statistics exported to NSC contain the number of packets.	-

## Views

Flexible flow statistics template view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

To obtain richer flow statistics, configure whether flexible flow statistics contain the number of bytes and packets.

### Prerequisites

A flexible flow statistics template has been created using the [ip netstream record](#) command.

### Precaution

If a flexible flow statistics template has been applied to an interface, the template configuration cannot be modified or deleted.

## Example

```
# Configure the flexible flow statistics template record1 to export the flexible flow statistics containing the number of packets to the NSC.
```

```
<HUAWEI> system-view  
[HUAWEI] ip netstream record record1  
[HUAWEI-record-record1] collect counter packets
```

## Related Topics

[16.10.21 ip netstream record](#)

## 16.10.3 collect interface

### Function

The **collect interface** command allows the flexible flow statistics exported to the NSC to contain the indexes of inbound and outbound interfaces.

The **undo collect interface** command restores the default setting.

By default, the flexible flow statistics exported to the NSC do not contain the index of inbound or outbound interface.

### Format

```
collect interface { input | output }
```

```
undo collect interface { input | output }
```

### Parameters

Parameter	Description	Value
<b>input</b>	Indicates that the flexible flow statistics exported to the NSC contain the index of inbound interface.	-
<b>output</b>	Indicates that the flexible flow statistics exported to the NSC contain the index of outbound interface.	-

### Views

Flexible flow statistics template view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

To obtain richer flow statistics, configure whether flexible flow statistics exported to the NSC contain indexes of inbound and outbound interfaces.

### Prerequisites

A flexible flow statistics template has been created using the [ip netstream record](#) command.

### Precaution

If a flexible flow statistics template has been applied to an interface, the template configuration cannot be modified or deleted.

## Example

# Configure the flexible flow statistics template **record1** to export the flexible flow statistics containing the inbound interface index to the NSC.

```
<HUAWEI> system-view  
[HUAWEI] ip netstream record record1  
[HUAWEI-record-record1] collect interface input
```

## Related Topics

[16.10.21 ip netstream record](#)

## 16.10.4 display ip netstream record

### Function

The **display ip netstream record** command displays the configuration of a flexible flow statistics template.

### Format

```
display ip netstream record { all | name record-name }
```

### Parameters

Parameter	Description	Value
<b>all</b>	Displays configurations of all flexible flow statistics templates.	-
<b>name</b> <i>record-name</i>	Displays the configuration of a flexible flow statistics template specified by <i>record-name</i> .	The flexible flow statistics template must be existed.

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

After you create and configure a flexible flow statistics template using the **ip netstream record** command, you can run the **display ip netstream record** command to view the configuration of the template.

## Example

# Display the configuration of the flexible flow statistics template **test0**.

```
<HUAWEI> display ip netstream record name test0
ip netstream record test0
match ip source-address
match ip destination-address
```

**Table 16-69** Description of the **display ip netstream record** command output

Item	Description
ip netstream record <i>record-name</i>	The flexible flow statistics template is <i>record-name</i> . You can run the <b>ip netstream record</b> command to configure this parameter.
match ip <i>x</i>	This template aggregates flows based on the <i>x</i> , and <i>x</i> can be: <ul style="list-style-type: none"> <li>protocol: IP protocol aggregation of IPv4 and IPv6 flows.</li> <li>dscp: DSCP priority aggregation of IPv4 and IPv6 flows.</li> <li>source-address: source IP address aggregation of IPv4 and IPv6 flows.</li> <li>destination-address: destination address aggregation of IPv4 and IPv6 flows.</li> <li>source-port: source port number aggregation of IPv4 and IPv6 flows.</li> <li>destination-port: destination port number aggregation of IPv4 and IPv6 flows.</li> <li>flow-label: IPv6 flow label aggregation. This aggregation method applies only to IPv6 flows.</li> </ul> You can run the <b>match ip</b> command to configure this field.

## Related Topics

[16.10.21 ip netstream record](#)



## 16.10.5 display ip netstream statistics

### Function

The **display ip netstream statistics** command displays the NetStream flow statistics.

### Format

**display ip netstream statistics slot** *slot-id*

### Parameters

Parameter	Description	Value
<b>slot</b> <i>slot-id</i>	Specifies the slot ID.	The value depends on the actual configuration.

### Views

All views

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

After NetStream is configured, you can run the **display ip netstream statistics** command to view NetStream statistics.

#### Precautions

After each statistics item in the command output reaches the maximum value, it is reset to 0. To ensure accurate statistics about NetStream flows, it is recommended to run the **reset ip netstream statistics** command to clear statistics about current NetStream flows before running the **display ip netstream statistics** command.

### Example

# Display the NetStream flow statistics of the device.

```
<HUAWEI> display ip netstream statistics slot 0
====Netstream statistics:====
Origin/Flexible ingress entries : 572
Origin/Flexible ingress packets : 56122
Origin/Flexible ingress octets : 6762976
Origin/Flexible egress entries : 57
Origin/Flexible egress packets : 3588
Origin/Flexible egress octets : 394680
Origin/Flexible total entries : 629
Handle origin entries : 620
Handle As aggre entries : 12
```

```

Handle ProtPort aggre entries : 11
Handle SrcPrefix aggre entries : 10
Handle DstPrefix aggre entries : 15
Handle Prefix aggre entries : 7
Handle AsTos aggre entries : 6
Handle ProtPortTos aggre entries : 5
Handle SrcPreTos aggre entries : 5
Handle DstPreTos aggre entries : 4
Handle PreTos aggre entries : 1
Record test handle entries : 0
    
```

**Table 16-70** Description of the display ip netstream statistics command output

Item	Description
Netstream statistics	-
Origin/Flexible ingress entries	Total number of incoming original flows or flexible flows.
Origin/Flexible ingress packets	Total number of packets in incoming original flows or flexible flows.
Origin/Flexible ingress octets	Total number of bytes in incoming original flows or flexible flows.
Origin/Flexible egress entries	Total number of outgoing original flows or flexible flows.
Origin/Flexible egress packets	Total number of packets in outgoing original flows or flexible flows.
Origin/Flexible egress octets	Total number of bytes in outgoing original flows or flexible flows.
Origin/Flexible total entries	Total number of original flows or flexible flows of the real-time statistics.
Handle origin entries	Number of processed incoming and outgoing original flows.
Handle As aggre entries	Number of processed incoming and outgoing AS aggregation flows.
Handle ProtPort aggre entries	Number of processed incoming and outgoing protocol-port aggregation flows.
Handle SrcPrefix aggre entries	Number of processed incoming and outgoing source-prefix aggregation flows.
Handle DstPrefix aggre entries	Number of processed incoming and outgoing destination-prefix aggregation flows.
Handle Prefix aggre entries	Number of processed incoming and outgoing prefix aggregation flows.
Handle AsTos aggre entries	Number of processed incoming and outgoing AS-ToS aggregation flows.

Item	Description
Handle ProtPortTos aggre entries	Number of processed incoming and outgoing protocol-port-ToS aggregation flows.
Handle SrcPreTos aggre entries	Number of processed incoming and outgoing source-prefix-ToS aggregation flows.
Handle DstPreTos aggre entries	Number of processed incoming and outgoing destination-prefix-ToS aggregation flows.
Handle PreTos aggre entries	Number of processed incoming and outgoing prefix-ToS aggregation flows.
Record test handle entries	Number of flows processed using the flexible flow statistics template <b>test</b> .

## 16.10.6 display netstream

### Function

The **display netstream** command displays the NetStream configurations.

### Format

**display netstream** { **all** | **global** | **interface** *interface-type interface-number* }

### Parameters

Parameter	Description	Value
<b>all</b>	Displays all the NetStream configurations, including: <ul style="list-style-type: none"> <li>• NetStream configurations in the system view</li> <li>• NetStream configurations in the aggregation view</li> <li>• NetStream configurations in the flexible flow statistics view</li> <li>• NetStream configurations in the interface view</li> </ul>	-

Parameter	Description	Value
<b>global</b>	Displays the global NetStream configurations, including: <ul style="list-style-type: none"> <li>• NetStream configurations in the system view</li> <li>• NetStream configurations in the aggregation view</li> <li>• NetStream configurations in the flexible flow statistics view</li> </ul>	-
<b>interface</b> <i>interface-type interface-number</i>	Displays the NetStream configurations on a specified interface. The parameter <i>interface-type interface-number</i> specifies the interface type and number.	-

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

This command displays the NetStream configurations for both IPv4 and IPv6 flows.

## Example

# Display all the NetStream configurations.

```
<HUAWEI> display netstream all
system
ip netstream export version 9
ip netstream export source 10.1.1.1
ip netstream export host 10.0.0.2 6000
ip netstream export host 10.5.5.5 6000
ipv6 netstream export version 9
ipv6 netstream export host 10.0.0.3 6000
ip netstream record test
ip netstream aggregation destination-prefix
enable
export version 9
```

```
ip netstream aggregation protocol-port
export version 9

slot 0
GigabitEthernet0/0/1
ip netstream inbound
```

**Table 16-71** Description of the **display netstream all** command output

Item	Description
system	The global NetStream configuration.
ip netstream export version <i>version</i>	The field <i>version</i> indicates the version of the exported packets carrying IPv4 original flow statistics. This field is displayed only when the <a href="#">16.10.20 ip netstream export version</a> command has been executed. If the version retains the default setting, this field is not displayed.
ip netstream export host <i>ip-address port-number</i>	The field <i>ip-address</i> indicates the destination address of the exported packets carrying IPv4 flow statistics, and <i>port-number</i> is the UDP port. This field is displayed only when the <a href="#">16.10.17 ip netstream export host</a> command has been executed in the system view.
ip netstream export source <i>ip-address</i>	The field <i>ip-address</i> indicates the source address of the exported packets carrying IPv4 flow statistics. This field is displayed only when the <a href="#">16.10.19 ip netstream export source</a> command has been executed. If the source address is not specified, the outbound interface IP address is used.
ipv6 netstream export version <i>version</i>	The field <i>version</i> indicates the version of the exported packets carrying IPv6 original flow statistics. This field is displayed only when the <a href="#">16.10.30 ipv6 netstream export version</a> command has been executed. If the version retains the default setting, this field is not displayed.
ipv6 netstream export host <i>ip-address port-number</i>	The field <i>ip-address</i> indicates the destination address of the exported packets carrying IPv6 flow statistics, and <i>port-number</i> is the UDP port. This field is displayed only when the <a href="#">16.10.27 ipv6 netstream export host</a> command has been executed in the system view.

Item	Description
ip netstream record <i>record-name</i>	The flexible flow statistics template is <i>record-name</i> . This field is displayed only when the <b>16.10.21 ip netstream record</b> command has been executed. If the flexible flow statistics template is not specified, this field is not displayed.
ip netstream aggregation destination-prefix	<p>Destination-prefix aggregation method. This field is displayed only when the <b>16.10.16 ip netstream aggregation</b> command has been executed to set the aggregation method.</p> <p>Currently, the following aggregation methods are supported:</p> <ul style="list-style-type: none"> <li>• <b>as</b>: AS aggregation</li> <li>• <b>as-tos</b>: AS-ToS aggregation</li> <li>• <b>destination-prefix</b>: destination-prefix aggregation</li> <li>• <b>destination-prefix-tos</b>: destination-prefix-ToS aggregation</li> <li>• <b>prefix</b>: prefix aggregation</li> <li>• <b>prefix-tos</b>: prefix-ToS aggregation</li> <li>• <b>protocol-port</b>: protocol-port aggregation</li> <li>• <b>protocol-port-tos</b>: protocol-port-ToS aggregation</li> <li>• <b>source-prefix</b>: source-prefix aggregation</li> <li>• <b>source-prefix-tos</b>: source-prefix-ToS aggregation</li> </ul>
enable	The destination-prefix aggregation method is enabled. This field is displayed only when the <b>enable</b> command has been executed in the aggregation view.
export version <i>version</i>	The field <i>version</i> indicates the version format of the exported packets carrying aggregation flow statistics. If the version retains the default setting, this field is not displayed. This field is displayed only when the <b>16.10.14 export version</b> command has been executed.
slot <i>x</i>	NetStream configurations on the card in slot <i>x</i> .
GigabitEthernet0/0/1 ip netstream inbound	The flow statistics function is enabled for incoming packets on GE0/0/1. This field is displayed only when the <b>16.10.15 ip netstream</b> command has been executed in the interface view.

## Related Topics

- [16.10.16 ip netstream aggregation](#)
- [16.10.17 ip netstream export host](#)
- [16.10.20 ip netstream export version](#)
- [16.10.19 ip netstream export source](#)
- [16.10.27 ipv6 netstream export host](#)
- [16.10.30 ipv6 netstream export version](#)
- [16.10.29 ipv6 netstream export source](#)
- [16.10.22 ip netstream sampler](#)
- [16.10.13 enable](#)

## 16.10.7 display netstream cache ip aggregation

### Function

The **display netstream cache ip aggregation** command displays details about IPv4 aggregation flow statistics on a device.

### Format

**display netstream cache ip aggregation** { **as** | **as-tos** | **destination-prefix** | **destination-prefix-tos** | **prefix** | **prefix-tos** | **protocol-port** | **protocol-port-tos** | **source-prefix** | **source-prefix-tos** } slot *slot-id*

### Parameters

Parameter	Description	Value
<b>as</b>	Specifies the AS aggregation. It classifies flows based on source AS number, destination AS number, inbound interface index, and outbound interface index.	-
<b>as-tos</b>	Specifies the AS-ToS aggregation. It classifies flows based on source AS number, destination AS number, inbound interface index, outbound interface index, and ToS.	-
<b>destination-prefix</b>	Specifies the destination-prefix aggregation. It classifies flows based on destination AS number, destination mask length, destination prefix, and outbound interface index.	-
<b>destination-prefix-tos</b>	Specifies the destination-prefix-ToS aggregation. It classifies flows based on destination AS number, destination mask length, destination prefix, outbound interface index, and ToS.	-

Parameter	Description	Value
<b>prefix</b>	Specifies the prefix aggregation. It classifies flows based on source AS number, destination AS number, source mask length, destination mask length, source prefix, destination prefix, inbound interface index, and outbound interface index.	-
<b>prefix-tos</b>	Specifies the prefix-ToS aggregation. It classifies flows based on source AS number, destination AS number, source mask length, destination mask length, source prefix, destination prefix, inbound interface index, outbound interface index, and ToS.	-
<b>protocol-port</b>	Specifies the protocol-port aggregation. It classifies flows based on protocol number, source port, and destination port.	-
<b>protocol-port-tos</b>	Specifies the protocol-port-ToS aggregation. It classifies flows based on protocol number, source port, destination port, ToS, inbound interface index, and outbound interface index.	-
<b>source-prefix</b>	Specifies the source-prefix aggregation. It classifies flows based on source AS number, source mask length, source prefix, and inbound interface index.	-
<b>source-prefix-tos</b>	Specifies the source-prefix-ToS aggregation. It classifies flows based on source AS number, source mask length, source prefix, ToS, and inbound interface index.	-
<b>slot</b> <i>slot-id</i>	Specifies the slot ID.	The value depends on the device configuration.

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

This command displays real-time statistics on IPv4 aggregation flows on the device.

### Precaution



This command must be executed before the flows age out; otherwise, no information will be displayed.

## Example

# Display detailed statistics about flows aggregated based on protocol and port on the device.

```
<HUAWEI> display netstream cache ip aggregation protocol-port slot 0
NetStream cache information:
```

```
-----
Protocol  SrcPort  DstPort  Direction  Streams  Packets  Octets
-----
114      0        0        IN         200     50688   5271552
-----
.....
```

**Table 16-72** Description of the **display netstream cache ip aggregation** command output

Item	Description
NetStream cache information	NetStream flow information.
Protocol	Protocol number of packets.
SrcPort	Source port number of packets.
DstPort	Destination port number of packets.
Direction	Packet sampling direction: <ul style="list-style-type: none"> <li>• IN: inbound direction</li> <li>• OUT: outbound direction</li> </ul>
Streams	Number of flows.
Packets	Number of packets.
Octets	Number of octets in packets.

## 16.10.8 display netstream cache ip record

### Function

The **display netstream cache ip record** command displays details about IPv4 flexible flow statistics on a device.

### Format

```
display netstream cache ip record record-name [ { inbound | outbound } ] |
destination interface interface-type interface-number | destination ip ip-address
| destination port port-number | source interface interface-type interface-
number | source ip ip-address | source port port-number | protocol protocol-type
| tos tos-number ] * slot slot-id [ verbose ]
```

## Parameters

Parameter	Description	Value
<i>record-name</i>	Specifies the name of a flexible flow statistics template.	It must be an existing template name on the device.
<b>inbound</b>	Specifies incoming packets.	-
<b>outbound</b>	Specifies outgoing packets.	-
<b>destination interface</b> <i>interface-type interface-number</i>	Specifies the destination interface of packets.	-
<b>destination ip</b> <i>ip-address</i>	Specifies the destination IP address of packets.	-
<b>destination port</b> <i>port-number</i>	Specifies the destination port number of packets.	The value is an integer that ranges from 0 to 65535.
<b>source interface</b> <i>interface-type interface-number</i>	Specifies the source interface of packets.	-
<b>source ip</b> <i>ip-address</i>	Indicates the source IP address of packets.	-
<b>source port</b> <i>port-number</i>	Specifies the source port number of packets.	The value is an integer that ranges from 0 to 65535.
<b>protocol</b> <i>protocol-type</i>	Specifies the protocol type of packets.	The value is an integer that ranges from 0 to 255.
<b>tos</b> <i>tos-number</i>	Specifies the ToS value of packets.	The value is an integer that ranges from 0 to 255.
<b>slot</b> <i>slot-id</i>	Specifies the slot ID.	The value depends on the device configuration.
<b>verbose</b>	Displays detailed information.	-

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

This command displays real-time statistics on IPv4 flexible flows on the device.

### Precaution

This command must be executed before the flows age out; otherwise, no information will be displayed.

## Example

# Display IPv4 flexible flow statistics on the device.

```
<HUAWEI> display netstream cache ip record record1 slot 0 verbose
```

```
NOTE: L4 Info: Source Port:Destination Port:Protocol
```

```
TCP Flags: Ack, Fin, Push, Reset, Syn, Urgent
```

```
NetStream cache information:
```

```
-----
SrcIP      DstIP      L4 Info      DstAS      Direction
SrcIflf    DstIflf    TCP Flags    SrcAS      ToS
NextHop    BGPNextHop Octets       Packets
-----
10.1.1.2   10.1.1.1   0:0:114     --         IN
GE0/0/5   --         0:0:0:0:0   --         0
--         --         4784        46
-----
```

**Table 16-73** Description of the **display netstream cache ip record** command output

Item	Description
NOTE	Note.
L4 Info: Source Port:Destination Port:Protocol	Transport-layer information of packets: including source port, destination port, and protocol type.
TCP Flags: Ack, Fin, Push, Reset, Syn, Urgent	TCP flag of packets: including ACK, Fin, Push, Reset, Syn, and Urgent.
NetStream cache information	NetStream flow information.
SrcIP	Source IP address of packets.
DstIP	Destination IP address of packets.
DstAS	Destination AS number of packets.

Item	Description
Direction	Packet sampling direction: <ul style="list-style-type: none"> <li>• IN: inbound direction</li> <li>• OUT: outbound direction</li> </ul>
SrcIf	Source interface of packets.
DstIf	Destination interface of packets.
SrcAS	Source AS number of packets.
ToS	ToS field of packets.
NextHop	Next hop address.
BGPNextHop	Address of the BGP next hop.
Octets	Number of octets in packets.
Packets	Number of packets.

## 16.10.9 display netstream cache ip origin

### Function

The **display netstream cache ip origin** command displays details about IPv4 original flow statistics on a device.

### Format

```
display netstream cache ip origin [ { inbound | outbound } | destination interface interface-type interface-number | destination ip ip-address | destination port port-number | source interface interface-type interface-number | source ip ip-address | source port port-number | protocol protocol-type | tos tos-number ] * slot slot-id [ verbose ]
```

### Parameters

Parameter	Description	Value
<b>inbound</b>	Specifies incoming packets.	-
<b>outbound</b>	Specifies outgoing packets.	-
<b>destination interface</b> <i>interface-type interface-number</i>	Specifies the destination interface of packets.	-

Parameter	Description	Value
<b>destination ip</b> <i>ip-address</i>	Specifies the destination IP address of packets.	-
<b>destination port</b> <i>port-number</i>	Specifies the destination port number of packets.	The value is an integer that ranges from 0 to 65535.
<b>source interface</b> <i>interface-type interface-number</i>	Specifies the source interface of packets.	-
<b>source ip</b> <i>ip-address</i>	Indicates the source IP address of packets.	-
<b>source port</b> <i>port-number</i>	Specifies the source port number of packets.	The value is an integer that ranges from 0 to 65535.
<b>protocol</b> <i>protocol-type</i>	Specifies the protocol type of packets.	The value is an integer that ranges from 0 to 255.
<b>tos</b> <i>tos-number</i>	Specifies the ToS value of packets.	The value is an integer that ranges from 0 to 255.
<b>slot</b> <i>slot-id</i>	Specifies the slot ID.	The value depends on the device configuration.
<b>verbose</b>	Displays detailed information.	-

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

This command displays real-time statistics on IPv4 original flows on the device.

### Precaution

This command must be executed before the flows age out; otherwise, no information will be displayed.

## Example

# Display details about IPv4 original flow statistics on the device.

```
<HUAWEI> display netstream cache ip origin slot 0 verbose
```

```
NOTE: L4 Info: Source Port:Destination Port:Protocol
```

```
TCP Flags: Ack, Fin, Push, Reset, Syn, Urgent
```

```
NetStream cache information:
```

```
-----
SrcIf      SrcIP/Mask  DstIP/Mask  L4 Info
ToS        Direction  SrcAS       DstAS
DstIf      TCP Flags   Octets      Packets
NextHop    BGPNextHop
-----
GEO/0/5    10.1.1.2/-- 10.1.1.1/-- 0:0:114
0          IN          --          --
--         0:0:0:0:0  5200       50
--         --
-----
```

**Table 16-74** Description of the **display netstream cache ip origin** command output

Item	Description
NOTE	Note.
L4 Info: Source Port:Destination Port:Protocol	Transport-layer information of packets: including source port, destination port, and protocol type.
TCP Flags: Ack, Fin, Push, Reset, Syn, Urgent	TCP flag of packets: including ACK, Fin, Push, Reset, Syn, and Urgent.
NetStream cache information	NetStream flow information.
SrcIf	Source interface of packets.
SrcIP/Mask	Source IP address and mask of packets.
DstIP/Mask	Destination IP address and mask of packets.
ToS	ToS of packets.
Direction	Packet sampling direction: <ul style="list-style-type: none"> <li>• IN: inbound direction</li> <li>• OUT: outbound direction</li> </ul>
SrcAS	Source AS number of packets.
DstAS	Destination AS number of packets.
DstIf	Destination interface of packets.
Octets	Number of octets in packets.
Packets	Number of packets.
NextHop	Next hop address.

Item	Description
BGP NextHop	BGP next hop address.

## 16.10.10 display netstream cache ipv6 record

### Function

The **display netstream cache ipv6 record** command displays details about IPv6 flexible flow statistics on a device.

### Format

```
display netstream cache ipv6 record record-name [ { inbound | outbound } |
destination interface interface-type interface-number | destination ipv6 ipv6-
address | destination port port-number | source interface interface-type
interface-number | source ipv6 ipv6-address | source port port-number |
flowlabel flowlabel | protocol protocol-type | tos tos-number ] * slot slot-id
[ verbose ]
```

### Parameters

Parameter	Description	Value
<i>record-name</i>	Specifies the name of a flexible flow statistics template.	It must be an existing template name on the device.
<b>inbound</b>	Specifies incoming packets.	-
<b>outbound</b>	Specifies outgoing packets.	-
<b>destination interface</b> <i>interface-type interface-number</i>	Specifies the destination interface of packets.	-
<b>destination ipv6</b> <i>ipv6-address</i>	Specifies the destination IPv6 address of packets.	-
<b>destination port</b> <i>port-number</i>	Specifies the destination port number of packets.	The value is an integer that ranges from 0 to 65535.
<b>source interface</b> <i>interface-type interface-number</i>	Specifies the source interface of packets.	-
<b>source ipv6</b> <i>ipv6-address</i>	Specifies the source IPv6 address of packets.	-

Parameter	Description	Value
<b>source port</b> <i>port-number</i>	Specifies the source port number of packets.	The value is an integer that ranges from 0 to 65535.
<b>flowlabel</b> <i>flowlabel</i>	Specifies the flow label of packets.	The value is an integer that ranges from 0 to 1048575.
<b>protocol</b> <i>protocol-type</i>	Specifies the protocol type of packets.	The value is an integer that ranges from 0 to 255.
<b>tos</b> <i>tos-number</i>	Specifies the ToS value of packets.	The value is an integer that ranges from 0 to 255.
<b>slot</b> <i>slot-id</i>	Specifies the slot ID.	The value depends on the device configuration.
<b>verbose</b>	Displays detailed information.	-

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

This command displays real-time statistics on IPv6 flexible flows on the device.

### Precaution

This command must be executed before the flows age out; otherwise, no information will be displayed.

## Example

# Display IPv6 flexible flow statistics on the device.

```
<HUAWEI> display netstream cache ipv6 record test slot 0 verbose
NOTE: L4 Info: Source Port:Destination Port:Protocol
      TCP Flags: Ack, Fin, Push, Reset, Syn, Urgent
NetStream cache information:
-----
SrcIP          SrcIflf      L4 Info
DstIP          DstIflf      ToS
NextHop        SrcAS        DstAS
BGPNextHop     FlowLabel    Direction
```



TCP Flags	Octets	Packets
FEC0::801:200:0:A01:102	GE0/0/5	0:0:59
FEC0::801:200:0:C108:101	--	0
--	--	--
--	0	IN
0:0:0:0:0	232648	2237

**Table 16-75** Description of the **display netstream cache ipv6 record** command output

Item	Description
NOTE	Note.
L4 Info: Source Port:Destination Port:Protocol	Transport-layer information of packets: including source port, destination port, and protocol type.
TCP Flags: Ack, Fin, Push, Reset, Syn, Urgent	TCP flag of packets: including ACK, Fin, Push, Reset, Syn, and Urgent.
NetStream cache information	NetStream flow information.
SrcIP	Source IPv6 address of packets.
SrcIf	Source interface of packets.
DstIP	Destination IPv6 address of packets.
DstIf	Destination interface of packets.
ToS	ToS of packets.
NextHop	Next hop address.
SrcAS	Source AS number of packets.
DstAS	Destination AS number of packets.
BGPNextHop	Address of the BGP next hop.
FlowLabel	IPv6 flow label.
Direction	Packet sampling direction: <ul style="list-style-type: none"> <li>• IN: inbound direction</li> <li>• OUT: outbound direction</li> </ul>
Octets	Number of octets in packets.
Packets	Number of packets.

## 16.10.11 display netstream cache ipv6 origin

### Function

The **display netstream cache ipv6 origin** command displays details about IPv6 original flow statistics on a device.

### Format

**display netstream cache ipv6 origin** [ { **inbound** | **outbound** } | **destination interface** *interface-type interface-number* | **destination ipv6** *ipv6-address* | **destination port** *port-number* | **source interface** *interface-type interface-number* | **source ipv6** *ipv6-address* | **source port** *port-number* | **flowlabel** *flowlabel* | **protocol** *protocol-type* | **tos** *tos-number* ] \* **slot** *slot-id* [ **verbose** ]

### Parameters

Parameter	Description	Value
<b>inbound</b>	Specifies incoming packets.	-
<b>outbound</b>	Specifies outgoing packets.	-
<b>destination interface</b> <i>interface-type interface-number</i>	Specifies the destination interface of packets.	-
<b>destination ipv6</b> <i>ipv6-address</i>	Specifies the destination IPv6 address of packets.	-
<b>destination port</b> <i>port-number</i>	Specifies the destination port number of packets.	The value is an integer that ranges from 0 to 65535.
<b>source interface</b> <i>interface-type interface-number</i>	Specifies the source interface of packets.	-
<b>source ipv6</b> <i>ipv6-address</i>	Specifies the source IPv6 address of packets.	-
<b>source port</b> <i>port-number</i>	Specifies the source port number of packets.	The value is an integer that ranges from 0 to 65535.
<b>flowlabel</b> <i>flowlabel</i>	Specifies the flow label of packets.	The value is an integer that ranges from 0 to 1048575.
<b>protocol</b> <i>protocol-type</i>	Specifies the protocol type of packets.	The value is an integer that ranges from 0 to 255.

Parameter	Description	Value
<b>tos</b> <i>tos-number</i>	Specifies the ToS value of packets.	The value is an integer that ranges from 0 to 255.
<b>slot</b> <i>slot-id</i>	Specifies the slot ID.	The value depends on the device configuration.
<b>verbose</b>	Displays detailed information.	-

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

This command displays real-time statistics on IPv6 original flows on the device.

### Precaution

This command must be executed before the flows age out; otherwise, no information will be displayed.

## Example

# Display details about IPv6 original flow statistics on the device.

```
<HUAWEI> display netstream cache ipv6 origin slot 0 verbose
```

```
NOTE: L4 Info: Source Port:Destination Port:Protocol
```

```
TCP Flags: Ack, Fin, Push, Reset, Syn, Urgent
```

```
NetStream cache information:
```

```
-----
SrcIflf    TCP Flags    SrcIP/Mask
DstIflf    ToS          DstIP/Mask
L4 Info    FlowLabel    NextHop
SrcAS      DstAS        BGP NextHop
Direction  Octets       Packets
-----
GEO/0/5    0:0:0:0:0    FEC0::801:200:0:A01:102/--
--         0            FEC0::801:200:0:C108:101/--
0:0:59    0            --
--         --          --
IN         3821896     36749
-----
.....
```

**Table 16-76** Description of the **display netstream cache ipv6 origin** command output

Item	Description
NOTE	Note.
L4 Info: Source Port:Destination Port:Protocol	Transport-layer information of packets: including source port, destination port, and protocol type.
TCP Flags: Ack, Fin, Push, Reset, Syn, Urgent	TCP flag of packets: including ACK, Fin, Push, Reset, Syn, and Urgent.
NetStream cache information	NetStream flow information.
SrcIf	Source interface of packets.
SrcIP/Mask	Source IPv6 address and mask of packets.
DstIf	Destination interface of packets.
ToS	Service type of packets.
DstIP/Mask	Destination IPv6 address and mask of packets.
FlowLable	IPv6 flow label.
NextHop	Next hop address.
SrcAS	Source AS number of packets.
DstAS	Destination AS number of packets.
BGP NextHop	BGP next hop address.
Direction	Packet sampling direction: <ul style="list-style-type: none"><li>• IN: inbound direction</li><li>• OUT: outbound direction</li></ul>
Octets	Number of octets in packets.
Packets	Number of packets.

## 16.10.12 display snmp-agent trap feature-name index all

### Function

The **display snmp-agent trap feature-name index all** command displays the status of all traps on the SINDEX module.

### Format

**display snmp-agent trap feature-name index all**

## Parameters

None

## Views

All views

## Default Level

1: Monitoring level

## Usage Guidelines

You can run the **display snmp-agent trap feature-name index all** command to check the status of all traps on the SINDEX module. This status can be configured using the **snmp-agent trap enable feature-name index** command.

## Example

# Display the status of all traps on the SINDEX module.

```
<HUAWEI> display snmp-agent trap feature-name index all
-----
Feature name: SINDEX
Trap number : 1
-----
Trap name           Default switch status  Current switch status
hwNetStreamIndexUsedUp    on                      on
```

**Table 16-77** Description of the display snmp-agent trap feature-name index all command output

Item	Description
Feature name	Name of the module that a trap message belongs.
Trap number	Number of trap messages.
Trap name	Name of a trap.
Default switch status	Default status of a trap: <ul style="list-style-type: none"> <li>on: The trap is enabled.</li> <li>off: The trap is disabled.</li> </ul>
Current switch status	Status of a trap: <ul style="list-style-type: none"> <li>on: The trap is enabled.</li> <li>off: The trap is disabled.</li> </ul> This status can be configured using the <b>snmp-agent trap enable feature-name index</b> command.
hwNetStreamIndexUsed-Up	The NetStream interface indexes are all allocated.

## Related Topics

[16.10.38 snmp-agent trap enable feature-name index](#)

# 16.10.13 enable

## Function

The **enable** command enables the aggregation function in the aggregation view.

The **undo enable** command disables the aggregation function in the aggregation view.

By default, the aggregation function is disabled.

## Format

**enable**

**undo enable**

## Parameters

None

## Views

NetStream aggregation view

## Default Level

3: Management level

## Usage Guidelines

The **enable** command takes effect only in the NetStream aggregation view. Flow statistics are exported according to the configured aggregation method only after you run the **enable** command in the aggregation view.

## Example

```
# Enable destination address prefix aggregation.
```

```
<HUAWEI> system-view  
[HUAWEI] ip netstream aggregation destination-prefix  
[HUAWEI-aggregation-dstpre] enable
```

## Related Topics

[16.10.16 ip netstream aggregation](#)

# 16.10.14 export version

## Function

The **export version** command configures the version of exported packets carrying aggregation flow statistics.

The **undo export version** command restores the default setting.

By default, the aggregation flow statistics are exported in the version of V8.

## Format

**export version** *version*

**undo export version**

## Parameters

Parameter	Description	Value
<i>version</i>	Specifies the version number of exported packets carrying aggregation flow statistics.	The value of <i>version</i> is set to 8 or 9. The default is 8.

## Views

NetStream aggregation view

## Default Level

3: Management level

## Usage Guidelines

The NDE exports NetStream flow statistics to the NSC. The version of exported packets must be the same as that configured on the NSC so that the NSC can parse the exported packets.

The format of exported packets in V8 is fixed and is not easy to expand. The format of exported packets in V9 is defined in templates and is easy to combine or expand. The statistics are exported more flexibly.

V9 is supported by most NSCs for its advantages. It is recommended that you set the version of exported packets carrying aggregation flow statistics to V9.

## Example

# Set the version number of exported packets carrying aggregation flow statistics to V9.

```
<HUAWEI> system-view  
[HUAWEI] ip netstream aggregation as  
[HUAWEI-aggregation-as] export version 9
```

## Related Topics

[16.10.16 ip netstream aggregation](#)

# 16.10.15 ip netstream

## Function

The **ip netstream** command enables IPv4 flow statistics collection on the inbound and outbound interfaces.

The **undo ip netstream** command restores the default setting.

By default, statistics collection for IPv4 flows is disabled on the inbound and outbound interfaces.

## Format

```
ip netstream { inbound | outbound }
```

```
undo ip netstream { inbound | outbound }
```

## Parameters

Parameter	Description	Value
<b>inbound</b>	Enables flow statistics collection on the inbound interface.	-
<b>outbound</b>	Enables flow statistics collection on the outbound interface.	-

## Views

GE interface view, XGE interface view, port group view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

To export IPv4 flow statistics, you must run the **ip netstream** command to enable the IPv4 flow statistics collection function on the interface.

### Precautions

After the statistics collection function is enabled for IPv4 and IPv6 flows, the statistics are independent of each other.



Currently, the flow statistics collection function can be enabled only on the main interface.

If the NetStream function is enabled on the main interface but you do not set a sampling ratio using the [16.10.22 ip netstream sampler](#) command, the main interface uses the sampling ratio of 1:1000. If you set the sampling ratio, the interface uses this sampling ratio.

## Example

```
# Enable the flow statistics collection function for the incoming IPv4 packets on GE0/0/1.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] ip netstream inbound
```

## Related Topics

[16.10.22 ip netstream sampler](#)

# 16.10.16 ip netstream aggregation

## Function

The **ip netstream aggregation** command configures the aggregation method and displays the aggregation view.

## Format

```
ip netstream aggregation { as | as-tos | destination-prefix | destination-prefix-tos | prefix | prefix-tos | protocol-port | protocol-port-tos | source-prefix | source-prefix-tos }
```

## Parameters

Parameter	Description	Value
as	Specifies the AS aggregation. It classifies flows based on: <ul style="list-style-type: none"><li>• Source AS number</li><li>• Destination AS number</li><li>• Inbound interface index</li><li>• Outbound interface index</li></ul>	-

Parameter	Description	Value
<b>as-tos</b>	Specifies the AS-ToS aggregation. It classifies flows based on: <ul style="list-style-type: none"> <li>• Source AS number</li> <li>• Destination AS number</li> <li>• Inbound interface index</li> <li>• Outbound interface index</li> <li>• ToS</li> </ul>	-
<b>destination-prefix</b>	Specifies the destination-prefix aggregation. It classifies flows based on: <ul style="list-style-type: none"> <li>• Destination AS number</li> <li>• Destination mask length</li> <li>• Outbound interface index</li> <li>• Destination prefix</li> </ul>	-
<b>destination-prefix-tos</b>	Specifies the destination-prefix-ToS aggregation. It classifies flows based on: <ul style="list-style-type: none"> <li>• Destination AS number</li> <li>• Destination mask length</li> <li>• Destination prefix</li> <li>• ToS</li> <li>• Outbound interface index</li> </ul>	-

Parameter	Description	Value
<b>prefix</b>	<p>Specifies the prefix aggregation. It classifies flows based on:</p> <ul style="list-style-type: none"> <li>• Source and destination AS numbers</li> <li>• Source and destination mask lengths</li> <li>• Source and destination prefixes</li> <li>• Inbound interface index</li> <li>• Outbound interface index</li> </ul>	-
<b>prefix-tos</b>	<p>Specifies the prefix-ToS aggregation. It classifies flows based on:</p> <ul style="list-style-type: none"> <li>• Source and destination AS numbers</li> <li>• Source and destination mask lengths</li> <li>• Source and destination prefixes</li> <li>• ToS</li> <li>• Inbound interface index</li> <li>• Outbound interface index</li> </ul>	-
<b>protocol-port</b>	<p>Specifies the protocol-port aggregation. It classifies flows based on:</p> <ul style="list-style-type: none"> <li>• Protocol number</li> <li>• Source port number</li> <li>• Destination port number</li> </ul>	-

Parameter	Description	Value
<b>protocol-port-tos</b>	Specifies the protocol-port-ToS aggregation. It classifies flows based on: <ul style="list-style-type: none"> <li>• Protocol number</li> <li>• Source port number</li> <li>• Destination port number</li> <li>• ToS</li> <li>• Inbound interface index</li> <li>• Outbound interface index</li> </ul>	-
<b>source-prefix</b>	Specifies the source-prefix aggregation. It classifies flows based on: <ul style="list-style-type: none"> <li>• Source AS number</li> <li>• Source mask length</li> <li>• Source prefix</li> <li>• Inbound interface index</li> </ul>	-
<b>source-prefix-tos</b>	Specifies the source-prefix-ToS aggregation. It classifies flows based on: <ul style="list-style-type: none"> <li>• Source AS number</li> <li>• Source mask length</li> <li>• Source prefix</li> <li>• ToS</li> <li>• Inbound interface index</li> </ul>	-

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

NetStream aggregation groups the original flows with the same attributes together. The aggregation flow statistics collection and original flow statistics

collection are different. The original flow statistics collection is on the basis of sampled packets, while the aggregation flow statistics collection is on the basis of original flows. Therefore, the aggregation flow statistics collection generates less data.

### Follow-up Procedure

Run the **enable** command in the aggregation view to enable the device to export flow statistics according to the configured aggregation method.

## Example

# Configure the NetStream AS aggregation method.

```
<HUAWEI> system-view  
[HUAWEI] ip netstream aggregation as  
[HUAWEI-aggregation-as]
```

# Configure the NetStream destination-prefix aggregation method.

```
<HUAWEI> system-view  
[HUAWEI] ip netstream aggregation destination-prefix  
[HUAWEI-aggregation-dstpre]
```

## Related Topics

[16.10.13 enable](#)

## 16.10.17 ip netstream export host

### Function

The **ip netstream export host** command configures the destination IP address and destination UDP port number for the exported packets carrying IPv4 flow statistics.

The **undo ip netstream export host** command deletes the configured destination IP address and destination UDP port number for the exported packets carrying IPv4 flow statistics.

By default, no destination IP address and destination UDP port number are configured in the system view or aggregation view for the exported packets carrying IPv4 flow statistics.

### Format

**ip netstream export host** *ip-address port-number*

**undo ip netstream export host** *ip-address port-number*

## Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the destination IPv4 address of the exported packets carrying IPv4 flow statistics.	-
<i>port-number</i>	Specifies the destination UDP port number of the exported packets carrying IPv4 flow statistics.	The value is an integer that ranges from 1 to 65535.

## Views

System view, NetStream aggregation view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

After finishing data collection, the NDE sends the collected data to the NSC. This command specifies the destination address of the collected data, that is, the NSC IP address.

### Precautions

When you run the **ip netstream export host** command in the system view, this command configures the destination address for the exported packets carrying IPv4 original flow statistics and IPv4 flexible flow statistics; when you run this command in the aggregation view, this command configures the destination address for the exported packets carrying IPv4 aggregation flows. The exported packets carrying aggregation flow statistics preferentially use the destination address configured in the aggregation view. If the destination address is not configured in the aggregation view, the exported packets carrying aggregation flow statistics use the destination address configured in the system view.

You can configure two destination addresses in the system view or aggregation view to implement NSC backup. To configure a third destination IP address, run the **undo netstream export ip host** command to delete an existing one first; otherwise, the system displays a message indicating that the maximum number of addresses is exceeded and the configuration fails.

## Example

```
# Set the destination IP address for the exported packets carrying original flow statistics to 10.1.1.1, and UDP port number to 222.
```

```
<HUAWEI> system-view  
[HUAWEI] ip netstream export host 10.1.1.1 222
```

# Set the destination IP address for the exported packets carrying aggregation flow statistics to 10.2.2.1, and UDP port number to 255.

```
<HUAWEI> system-view  
[HUAWEI] ip netstream aggregation as  
[HUAWEI-aggregation-as] ip netstream export host 10.2.2.1 255
```

## Related Topics

[16.10.6 display netstream](#)

## 16.10.18 ip netstream export index-switch

### Function

The **ip netstream export index-switch** command sets the number of digits in the interface index contained in an exported packet carrying IPv4 flow statistics.

By default, the number of digits in interface indexes is 16..

### Format

**ip netstream export index-switch** *index-switch*

**undo ip netstream export index-switch**

### Parameters

Parameter	Description	Value
<i>index-switch</i>	Specifies the number of digits in the index of a specified interface.	The value is 16 or 32. The default value is 16.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

You can run the **ip netstream export index-switch** command to set the number of digits in the interface index to 16 or 32.

The number of digits in an interface index contained in exported packets must be the same as the number of digits in an interface index that can be parsed by the

NMS. For example, if the NMS can parse the 32-digit interface index, set the number of digits in an interface index contained in exported packets to 32.

### Precautions

The number of digits in the interface index can be changed to 32 only when the NMS supports 32-digit interface index. If the number of digits in an interface index contained in exported packets is different from the number of digits in an interface index supported by the NMS, the NMS cannot identify NetStream packets sent by the device.

This command is valid for V9. Before changing 16-digit interface indexes to 32-digit interface indexes, ensure that:

- The version of exported packets of original flows is V9.
- The version of exported packets carrying aggregation flow statistics is V9.

When the 32-digit interface index is used, the version of exported packets of original flows cannot be changed from V9 to V5, and the version of exported packets carrying aggregation flow statistics cannot be changed from V9 to V8.

## Example

# Change the number of digits in the interface index contained in an exported packet carrying IPv4 flow statistics from 16 to 32.

```
<HUAWEI> system-view  
[HUAWEI] ip netstream export version 9  
[HUAWEI] ip netstream export index-switch 32
```

## Related Topics

[16.10.20 ip netstream export version](#)

[16.10.14 export version](#)

## 16.10.19 ip netstream export source

### Function

The **ip netstream export source** command configures the source address for the exported packets carrying IPv4 flow statistics.

The **undo ip netstream export source** command deletes the configured source address for the exported packets carrying IPv4 flow statistics.

By default, no source address is configured in the system view or aggregation view for the exported packets carrying IPv4 flow statistics.

### Format

**ip netstream export source** *ip-address*

**undo ip netstream export source**



## Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the source IPv4 address of the exported packets carrying IPv4 flow statistics.	The parameter must be set to an existing IP address on the device.

## Views

System view, NetStream aggregation view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

If the NMS identifies the data source according to the source IP address in NetStream packets, you need to specify the source IP address for NetStream packets.

### Precautions

NetStream prefers the source IP address configured in the aggregation view. If no source address is specified in an aggregation method, the source address configured in the system view is used.

This command must be performed; otherwise, the source address of output packets may be 0.0.0.0, and the output packets may be discarded during transmission or cannot be parsed by the NetStream server.

## Example

# In the system view, set the source address for the exported packets carrying IPv4 flow statistics to 10.1.1.1.

```
<HUAWEI> system-view  
[HUAWEI] ip netstream export source 10.1.1.1
```

# In the aggregation view, set the source address for the exported packets carrying IPv4 flow statistics to 10.2.2.2.

```
<HUAWEI> system-view  
[HUAWEI] ip netstream aggregation as  
[HUAWEI-aggregation-as] ip netstream export source 10.2.2.2
```

## Related Topics

[16.10.6 display netstream](#)

## 16.10.20 ip netstream export version

### Function

The **ip netstream export version** command configures the version number and AS option of the exported packets carrying IPv4 flow statistics.

The **undo ip netstream export version** command restores the default setting.

By default, the version number of the exported packets carrying IPv4 original flow statistics is 5 and no AS option is used. The version number of the exported packets carrying IPv4 flexible flow statistics is 9. Packets of V9 have no AS option and do not carry BGP next hop information.

### Format

**ip netstream export version** *version* [ **origin-as** | **peer-as** ] [ **bgp-nexthop** ]

**undo ip netstream export version**

### Parameters

Parameter	Description	Value
<i>version</i>	Specifies the version number of exported packets carrying IPv4 flow statistics.	The value of <i>version</i> is set to 5 or 9.
<b>origin-as</b>	Specifies the AS number recorded in the statistics as the original AS number.	-
<b>peer-as</b>	Specifies the AS number recorded in the statistics as the peer AS number.	-
<b>bgp-nexthop</b>	Configures the statistics to carry BGP next hop information. Currently, only V9 supports the exported packets carrying BGP next hop information.	-

### Views

System view

### Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

The NDE exports NetStream flow statistics to the NSC. The version of exported packets must be the same as that configured on the NSC so that the NSC can parse the exported packets.

The format of exported packets in V5 is fixed and is not easy to expand. The format of exported packets in V9 is defined in templates and is easy to combine or expand. The statistics are exported more flexibly.

V9 is supported by most NSCs for its advantages. It is recommended that you set the version of exported packets carrying aggregation flow statistics to V9.

### Precautions

Only one version can be specified on a device. The versions configured on all the devices on the network must be the same as the version configured on the NMS.

The AS option is used according to the actual situation of the AS configured on each device. The AS option affects only the packet statistics result, but does not affect the flows. The AS option is encapsulated in the AS option field carried in the NetStream packets sent to the NMS. The exported packets of V5 do not support BGP next hop information.

## Example

```
# Set the version of the exported packets carrying IPv4 flow statistics to V9 and AS option to peer-as.
```

```
<HUAWEI> system-view  
[HUAWEI] ip netstream export version 9 peer-as
```

## Related Topics

[16.10.6 display netstream](#)

## 16.10.21 ip netstream record

### Function

The **ip netstream record** command creates a new flexible flow statistics template or displays the view of an existing flexible statistics template.

The **undo ip netstream record** command deletes a specified flexible flow statistics template.

By default, no flexible flow statistics template exists.

### Format

```
ip netstream record record-name
```

```
undo ip netstream record record-name
```

## Parameters

Parameter	Description	Value
<i>record-name</i>	Specifies the name of the flexible flow statistics template.	The value is a string of 1 to 32 case-insensitive characters without spaces. The name of the flexible flow statistics template cannot contain special characters such as / \ : * ? " < >   @ ' %.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

You need to create the flexible flow statistics template before exporting flexible flow statistics.

### Precautions

A maximum of 16 flexible flow statistics templates can be configured on one device. To configure a third flexible flow statistics template, run the **undo ip netstream record** command to delete an existing one first.

The flexible flow statistics template that has been applied to an interface cannot be modified or deleted. Run the **undo port ip netstream record** command on the interface to unbind a specified flexible flow statistics template from the interface, and then you can modify or delete the template.

## Example

# Create the flexible flow statistics template named **abc**.

```
<HUAWEI> system-view
[HUAWEI] ip netstream record abc
Info: Creating the new record succeeded.
[HUAWEI-record-abc]
```

## Related Topics

[16.10.34 port ip netstream record](#)

[16.10.4 display ip netstream record](#)

## 16.10.22 ip netstream sampler

### Function

The **ip netstream sampler** command configures the packet sampling function for IPv4 packets on an interface.

The **undo ip netstream sampler** command restores the default setting.

By default, an interface uses the packet-based regular sampling and the sampling ratio is 1000.

### Format

```
ip netstream sampler fix-packets packet-interval { inbound | outbound }
```

```
undo ip netstream sampler [ fix-packets packet-interval ] { inbound | outbound }
```

### Parameters

Parameter	Description	Value
<b>fix-packets</b> <i>packet-interval</i>	Indicates the sampling ratio for packet-based regular sampling.	Its value is an integer that ranges from 1 to 65535.
<b>inbound</b>	Samples incoming traffic on an interface.	-
<b>outbound</b>	Samples outgoing traffic on an interface.	-

### Views

GE interface view, XGE interface view, port group view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

You can set an interval for sampling packets so that only statistics about sampled packets are collected. The statistics show the flow status on the entire network. The sampling function reduces NetStream impact on device performance.

#### Precautions

You must run the **ip netstream sampler** command together with the [16.10.15 ip netstream](#) command. If you run only the **ip netstream sampler** command, the command does not take effect.

If you run the **ip netstream sampler** command multiple times in the same view, only the latest configuration takes effect.

## Example

# Set the packet-based regular sampling ratio for the incoming packets on GE0/0/1 to 1200.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] ip netstream sampler fix-packets 1200 inbound
[HUAWEI-GigabitEthernet0/0/1] ip netstream inbound
```

## Related Topics

[16.10.15 ip netstream](#)

# 16.10.23 ip netstream tcp-flag enable

## Function

The **ip netstream tcp-flag enable** command configures the aging of NetStream traffic according to the FIN flag or the RST flag in the TCP packet header.

The **undo ip netstream tcp-flag enable** command restores the default setting.

By default, NetStream flows are not aged according to the FIN or RST flag in the TCP packet header.

## Format

```
ip netstream tcp-flag enable
undo ip netstream tcp-flag enable
```

## Parameters

None

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

The FIN or RST flag in a TCP packet indicates that the TCP connection is terminated. When receiving a packet with the FIN or RST flag, the device immediately ages the corresponding NetStream flow. If the **ip netstream tcp-flag**

**enable** command is not run, NetStream flows are aged by following other criteria, for example, inactive aging time or bytes overflow.

#### Precautions

If you set multiple aging modes on the device, a flow is aged when it matches any criterion.

Only original flows can be aged according to the FIN or RST flag in the TCP packet header.

## Example

```
# Configure the aging of original flows according to the FIN or RST flag in the TCP packet header.
```

```
<HUAWEI> system-view  
[HUAWEI] ip netstream tcp-flag enable
```

## 16.10.24 ip netstream timeout active

### Function

The **ip netstream timeout active** command configures the active flow aging time.

The **undo ip netstream timeout active** command restores the default setting.

By default, the active flow aging time is 200 seconds.

### Format

**ip netstream timeout active** *active-interval*

**undo ip netstream timeout active**

### Parameters

Parameter	Description	Value
<i>active-interval</i>	Specifies the active aging time.	The value is an integer that ranges from 1 to 300, in seconds. The default is 200.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

Network traffic may burst intermittently, while the memory capacity of the NDE is limited. Earlier flows in the memory need to be exported to release space for the new flows. The process of exporting old flows is called aging. All flows in the NDE memory will be exported to the NSC for analysis.

When the active time (from flow creation time to the current time) of a flow exceeds the specified active aging time, the flow is exported to the destination.

To quickly detect the status of an active flow, set the active time to a small value; however, this setting increases the frequency at which NetStream packets are sent. To reduce the frequency at which NetStream packets are exported and improve statistics collecting efficiency, set the active time to a large value.

### Precautions

If you set multiple aging modes on the device, a flow is aged when it matches any criterion.

## Example

```
# Set the active aging time to 240 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] ip netstream timeout active 240
```

## 16.10.25 ip netstream timeout inactive

### Function

The **ip netstream timeout inactive** command configures the inactive aging time.

The **undo ip netstream timeout inactive** command restores the default setting.

By default, the inactive aging time is 30 seconds.

### Format

**ip netstream timeout inactive** *inactive-interval*

**undo ip netstream timeout inactive**

### Parameters

Parameter	Description	Value
<i>inactive-interval</i>	Specifies the inactive aging time.	The value is an integer that ranges from 1 to 300, in seconds. The default is 30.

### Views

System view



## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

Network traffic may burst intermittently, while the memory capacity of the NDE is limited. Earlier flows in the memory need to be exported to release space for the new flows. The process of exporting old flows is called aging. All flows in the NDE memory will be exported to the NSC for analysis.

When the inactive time (from the last packet receiving time to the current time) of an original or flexible flow exceeds the specified inactive aging time, the flow is exported to the destination.

To quickly detect the status of an inactive flow, set the inactive time to a small value; however, this setting increases the frequency at which NetStream packets are sent. To reduce the frequency at which NetStream packets are exported and improve statistics collecting efficiency, set the inactive time to a large value.

### Precautions

The inactive aging time that is configured using the **ip netstream timeout inactive** command applies to both IPv4 and IPv6 flows.

If you set multiple aging modes on the device, a flow is aged when it matches any criterion.

## Example

```
# Set the inactive aging time to 20 seconds.
```

```
<HUAWEI> system-view  
[HUAWEI] ip netstream timeout inactive 20
```

## 16.10.26 ipv6 netstream

### Function

The **ipv6 netstream** command enables IPv6 flow statistics collection on the inbound and outbound interfaces.

The **undo ipv6 netstream** command restores the default setting.

By default, statistics collection for IPv6 flows is disabled on the inbound and outbound interfaces.

### Format

```
ipv6 netstream { inbound | outbound }
```

```
undo ipv6 netstream { inbound | outbound }
```

## Parameters

Parameter	Description	Value
<b>inbound</b>	Enables IPv6 flow statistics collection on the inbound interface.	-
<b>outbound</b>	Enables IPv6 flow statistics collection on the outbound interface.	-

## Views

GE interface view, XGE interface view, port group view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

To export IPv6 flow statistics, you must run the **ipv6 netstream** command to enable IPv6 flow statistics collection on the inbound interface.

### Precautions

When you enable IPv6 flow statistics collection on the inbound interface, enable statistics collection on unicast and multicast packets.

After statistics collection is enabled for IPv4 and IPv6 flows, the statistics are independent of each other.

Currently, flow statistics collection can be enabled only on main interfaces.

If statistics collection is enabled on an interface but you do not set a sampling ratio using the **16.10.31 ipv6 netstream sampler** command, the interface uses the sampling ratio of 1:1000. If you have set the sampling ratio, the interface uses this sampling ratio.

## Example

```
# Enable statistics collection for the incoming IPv6 flows on GE0/0/1.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] ipv6 netstream inbound
```

## Related Topics

[16.10.31 ipv6 netstream sampler](#)

## 16.10.27 ipv6 netstream export host

### Function

The **ipv6 netstream export host** command configures the destination IP address and destination UDP port number for the exported packets carrying IPv6 flow statistics.

The **undo ipv6 netstream export host** command deletes the configured destination IP address and destination UDP port number for the exported packets carrying IPv6 flow statistics.

By default, no destination IP address or destination UDP port number is configured in the system view for the exported packets carrying IPv6 flow statistics.

### Format

**ipv6 netstream export host** *ip-address port-number*

**undo ipv6 netstream export host** *ip-address port-number*

### Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the destination IPv4 address of the exported packets carrying IPv6 flow statistics.	-
<i>port-number</i>	Specifies the destination UDP port number of the exported packets.	The value is an integer that ranges from 1 to 65535.

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

After finishing data collection, the NDE sends the collected data to the NSC. This command specifies the destination address of the collected data, that is, the NSC IP address.

### Precautions

The **netstream export ipv6 host** command configures the destination address for the exported packets carrying IPv6 original flows and flexible flows.

You can configure two destination IP addresses to implement NSC backup. To configure a third destination IP address, run the **undo ipv6 netstream export host** command to delete an existing one first; otherwise, the system displays a message indicating that the maximum number of addresses is exceeded and the configuration fails.

### Example

```
# Set the destination IP address for the exported packets carrying IPv6 original flows to 10.1.1.1, and UDP port number to 222.
```

```
<HUAWEI> system-view  
[HUAWEI] ipv6 netstream export host 10.1.1.1 222
```

## 16.10.28 ipv6 netstream export index-switch

### Function

The **ipv6 netstream export index-switch** command sets the number of digits in the interface index contained in an exported packet carrying IPv6 flow statistics.

The **undo ipv6 netstream export index-switch** command restores the default setting.

By default, an interface index contains 16 digits.

### Format

```
ipv6 netstream export index-switch index-switch
```

```
undo ipv6 netstream export index-switch
```

### Parameters

Parameter	Description	Value
<i>index-switch</i>	Specifies the digit of the interface index.	The value is an integer that can be 16 or 32. The default is 16.

### Views

System view

### Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

You can run the **ipv6 netstream export index-switch** command to set the number of digits in the interface index to 16 or 32.

Set the type of the interface index contained in exported packets the same as the type of the interface index that can be parsed by the NMS. For example, if the NMS can parse the 32-digit interface index, set the type of the interface index contained in exported packets to 32-digit interface index.

### Prerequisites

The interface index length in exported packets can be set to 32 bits only when the NMS supports 32-bit interface index; otherwise, the NMS cannot identify the NetStream packets.

## Example

# Change the interface index type of the exported packets carrying IPv6 flow statistics from 16-digit to 32-digit.

```
<HUAWEI> system-view  
[HUAWEI] ipv6 netstream export index-switch 32
```

## 16.10.29 ipv6 netstream export source

### Function

The **ipv6 netstream export source** command configures the source address for the exported packets carrying IPv6 flow statistics.

The **undo ipv6 netstream export source** command deletes the configured source address for the exported packets carrying IPv6 flow statistics.

By default, no source address is configured on the device for the exported packets carrying IPv6 flow statistics.

### Format

**ipv6 netstream export source** *ip-address*

**undo ipv6 netstream export source**

### Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the source IPv4 address of the exported packets carrying IPv6 flow statistics.	-

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

If the NMS identifies the data source according to the source IP address in NetStream packets, you need to specify the source IP address for NetStream packets.

### Precautions

This command must be performed; otherwise, the source address of output packets may be 0.0.0.0, and the output packets may be discarded during transmission or cannot be parsed by the NetStream server.

## Example

# In the system view, set the source address for the exported packets carrying IPv6 flow statistics to 10.1.1.1.

```
<HUAWEI> system-view  
[HUAWEI] ipv6 netstream export source 10.1.1.1
```

## 16.10.30 ipv6 netstream export version

### Function

The **ipv6 netstream export version** command configures the version number and AS option of the exported packets carrying IPv6 flow statistics.

The **undo ipv6 netstream export version** command restores the default setting.

By default, the version number of the exported packets carrying IPv6 flow statistics is not specified.

### Format

**ipv6 netstream export version** *version* [ **origin-as** | **peer-as** ]

**undo ipv6 netstream export version**

### Parameters

Parameter	Description	Value
<i>version</i>	Specifies the version of exported packets.	Only V9 is supported.

Parameter	Description	Value
<b>origin-as</b>	Specifies the AS number recorded in the statistics as the original AS number.	-
<b>peer-as</b>	Specifies the AS number recorded in the statistics as the peer AS number.	-

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

The NDE exports NetStream flow statistics to the NSC. The version of exported packets must be the same as that configured on the NSC so that the NSC can parse the exported packets.

### Precautions

The AS option is used according to the actual situation of the AS configured on each device. The AS option affects only the packet statistics result, but does not affect the flows. The AS option is encapsulated in the AS option field carried in the NetStream packets sent to the NMS.

## Example

```
# Set the version of exported packets carrying IPv6 flow statistics to V9 and AS to peer-as.
```

```
<HUAWEI> system-view  
[HUAWEI] ipv6 netstream export version 9 peer-as
```

## 16.10.31 ipv6 netstream sampler

### Function

The **ipv6 netstream sampler** command configures packet sampling for IPv6 packets on an interface.

The **undo ipv6 netstream sampler** command restores the default setting.

By default, an interface uses the packet-based regular sampling and the sampling ratio is 1000.

## Format

```
ipv6 netstream sampler fix-packets packet-interval { inbound | outbound }
undo ipv6 netstream sampler [ fix-packets packet-interval ] { inbound |
outbound }
```

## Parameters

Parameter	Description	Value
<b>fix-packets</b> <i>packet-interval</i>	Indicates the sampling ratio for packet-based regular sampling.	The value is an integer that ranges from 1 to 65535.
<b>inbound</b>	Samples incoming traffic on an interface.	-
<b>outbound</b>	Samples outgoing traffic on an interface.	-

## Views

GE interface view, XGE interface view, port group view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

You can set an interval for sampling packets so that only statistics about sampled packets are collected. The statistics show the flow status on the entire network. The sampling function reduces impact of NetStream on device performance.

### Precautions

You must run the **ipv6 netstream sampler** command together with the [16.10.26 ipv6 netstream](#) command. If you run only the **ipv6 netstream sampler** command, the command does not take effect.

If you run the **ipv6 netstream sampler** command multiple times in the same view, only the latest configuration takes effect.

## Example

```
# Set the packet-based regular sampling interval for the incoming packets on
GE0/0/1 to 1200.
```

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] ipv6 netstream inbound
[HUAWEI-GigabitEthernet0/0/1] ipv6 netstream sampler fix-packets 1200 inbound
```



## Related Topics

[16.10.26 ipv6 netstream](#)

# 16.10.32 mask

## Function

The **mask** command sets the aggregation mask length.

The **undo mask** command restores the default setting.

By default, no aggregation mask is configured.

## Format

**mask** { **source** | **destination** } **minimum** *mask-length*

**undo mask** { **source** | **destination** }

## Parameters

Parameter	Description	Value
<b>source</b>	Indicates the aggregation mask of the source address. It is used in the following aggregation methods: prefix, prefix-ToS, source-prefix, and source-prefix-ToS.	-
<b>destination</b>	Indicates the aggregation mask of the destination address. It is used in the following aggregation methods: prefix, prefix-ToS, destination-prefix, or destination-prefix-ToS.	-
<i>mask-length</i>	Specifies the aggregation mask length.	The value is an integer that ranges from 1 to 32.

## Views

NetStream aggregation view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

The system uses the larger value between the set mask and the largest mask in the FIB table. If the aggregation mask is not configured, the system uses the mask in the FIB table for aggregation.

### Precaution

Aggregation masks are applied to six aggregation methods: **destination-prefix**, **destination-prefix-tos**, **prefix**, **prefix-tos**, **source-prefix**, and **source-prefix-tos**.

### Example

```
# Set the aggregation mask length in the source-prefix aggregation method to 24.
```

```
<HUAWEI> system-view  
[HUAWEI] ip netstream aggregation source-prefix  
[HUAWEI-aggregation-srcpre] mask source minimum 24
```

## 16.10.33 match ip

### Function

The **match ip** command configures aggregation keywords in a flexible flow statistics template.

The **undo match ip** command deletes aggregation keywords from a flexible flow statistics template.

By default, no aggregation keyword is configured in a flexible flow statistics template.

### Format

```
match ip { protocol | dscp | source-address | destination-address | source-port | destination-port | flow-label }
```

```
undo match ip { protocol | dscp | source-address | destination-address | source-port | destination-port | flow-label }
```

### Parameters

Parameter	Description	Value
<b>protocol</b>	Indicates the IP protocol aggregation of IPv4 and IPv6 flows.	-
<b>dscp</b>	Indicates the DSCP priority aggregation of IPv4 and IPv6 flows.	-
<b>source-address</b>	Indicates the source IP address aggregation of IPv4 and IPv6 flows.	-
<b>destination-address</b>	Indicates the destination address aggregation of IPv4 and IPv6 flows.	-

Parameter	Description	Value
<b>source-port</b>	Indicates the source port number aggregation of IPv4 and IPv6 flows.	-
<b>destination-port</b>	Indicates the destination port number aggregation of IPv4 and IPv6 flows.	-
<b>flow-label</b>	Indicates the IPv6 flow label aggregation. This aggregation method applies only to IPv6 flows.	-

## Views

Flexible flow statistics template view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

During NetStream implementation, you can run the **match ip** command to configure aggregation keywords in a flexible flow statistics template.

### Prerequisites

A flexible flow statistics template has been created using the [16.10.21 ip netstream record](#) command.

### Precautions

When you run the **match ip** command to configure the aggregation keywords, only one keyword can be configured each time. If you run this command multiple times in the same view, a set of multiple aggregation keywords is configured. If a template has been applied to an interface, you cannot modify or delete aggregation keywords from the template.

## Example

# Set the flexible flow statistics template **abc123** to aggregate flows based on the source port number.

```
<HUAWEI> system-view
[HUAWEI] ip netstream record abc123
[HUAWEI-record-abc123] match ip source-port
```

## 16.10.34 port ip netstream record

## Function

The **port ip netstream record** command applies the flexible flow statistics template to an interface.

The **undo port ip netstream record** command unbinds a specified flexible flow statistics template from an interface.

By default, no flexible flow statistics template is applied to an interface.

## Format

**port ip netstream record** *record-name*

**undo port ip netstream record**

## Parameters

Parameter	Description	Value
<i>record-name</i>	Specifies the name of a flexible flow statistics template.	The value is a string of 1 to 32 case-insensitive characters without spaces.  The value is the same as the IPv4 flexible flow statistics template name configured using the <b>ip netstream record</b> command.

## Views

GE interface view, XGE interface view, port group view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

After a flexible flow statistics template is configured, run the **port ip netstream record** command to apply the template to an interface.

The interface then aggregates flows based on the configured aggregation keywords, collects flow statistics, and exports aged flows to the NSC.

### Prerequisites

The flexible flow statistics template has been created and at least one aggregation keyword has been configured using the **match ip** command.

### Precautions

Each interface can be configured with only one flexible flow statistics template. Before modifying the flexible flow statistics template in the same interface view, run the **undo port ip netstream record** command to delete the existing configuration.

If the flexible flow statistics template has been applied to an interface, the template configuration cannot be modified or deleted.

When flow statistics collection is enabled both on the inbound and outbound interfaces, the **port ip netstream record** command does not take effect.

### Example

# Configure the flexible flow statistics template **abc1** (aggregating flows based on the source and destination IP addresses, collecting statistics about the number of packets, and exporting the inbound interface index). Apply the template to GE0/0/1.

```
<HUAWEI> system-view
[HUAWEI] ip netstream record abc1
[HUAWEI-record-abc1] match ip source-address
[HUAWEI-record-abc1] match ip destination-address
[HUAWEI-record-abc1] collect counter packets
[HUAWEI-record-abc1] collect interface input
[HUAWEI-record-abc1] quit
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] port ip netstream record abc1
```

### Related Topics

[16.10.21 ip netstream record](#)

[16.10.15 ip netstream](#)

[16.10.26 ipv6 netstream](#)

## 16.10.35 refresh netstream template

### Function

The **refresh netstream template** command immediately refreshes the NetStream export template.

By default, the template is refreshed every 30 minutes.

### Format

**refresh netstream template**

### Parameters

None

### Views

User view

## Default Level

3: Management level

## Usage Guidelines

After a NetStream server restarts, you need to run this command to enable the device to immediately resend the NetStream export template. Only the V9 template supports this command.

## Example

```
# Refresh the NetStream export template.
```

```
<HUAWEI> refresh netstream template
```

## 16.10.36 reset ip netstream cache

### Function

The **reset ip netstream cache** command forcibly ages all the flows in the cache.

### Format

```
reset ip netstream cache slot slot-id
```

### Parameters

Parameter	Description	Value
slot <i>slot-id</i>	Specifies the slot ID.	The value depends on the actual configuration.

### Views

System view

### Default Level

3: Management level

## Usage Guidelines

Forced aging is used when you require the latest statistics, but you do not satisfy with the existing aging conditions or some flows fail to age out due to an anomaly. You can forcibly age out all the original flows in the cache and export the flow statistics.

#### NOTE

If you run the **reset ip netstream cache** command on the device before the inactive aging time is reached, the NDE does not export the flow statistics to the NSC.

## Example

```
# Age all the flows forcibly in slot 0.
```

```
<HUAWEI> system-view  
[HUAWEI] reset ip netstream cache slot 0
```

## 16.10.37 reset ip netstream statistics

### Function

The **reset ip netstream statistics** command deletes NetStream flow statistics.

### Format

```
reset ip netstream statistics slot slot-id
```

### Parameters

Parameter	Description	Value
slot <i>slot-id</i>	Specifies the slot ID.	The value depends on the actual configuration.

### Views

User view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

When diagnosing and locating network faults, collect flow statistics in a specified period. Before statistics collection starts, you can run this command to delete historical statistics.

#### Precautions

The **reset ip netstream statistics** command deletes all NetStream statistics. The statistics cannot be restored after being deleted. Therefore, confirm the action before running this command.

You can run this command multiple times at any interval.

## Example

```
# Delete NetStream statistics in slot 0.
```

```
<HUAWEI> reset ip netstream statistics slot 0
```

## 16.10.38 snmp-agent trap enable feature-name index

### Function

The **snmp-agent trap enable feature-name index** command enables the trap function for the SINDEXT module.

The **undo snmp-agent trap enable feature-name index** command disables the trap function for the SINDEXT module.

By default, the trap function is enabled for the SINDEXT module.

### Format

**snmp-agent trap enable feature-name index [ trap-name  
hwnetstreamindexusedup ]**

**undo snmp-agent trap enable feature-name index [ trap-name  
hwnetstreamindexusedup ]**

### Parameters

Parameter	Description	Value
<b>trap-name</b>	Specifies the name of the trap for a specified event on the SINDEXT module.	-
<b>hwnetstreamindexusedup</b>	Sends Huawei-proprietary trap messages when all interface indexes are allocated.	-

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

The **snmp-agent trap enable feature-name index** command is used to enable an SINDEXT trap. After that, the trap generated during the device running will be sent to the NMS.

You can run the [16.10.12 display snmp-agent trap feature-name index all](#) command to check the configuration result.



## Example

```
# Enable the trap function for the SINDEX module.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name sindex
```

# 16.11 sFlow Configuration Commands

## NOTE

sFlow collects statistics and analyzes service traffic. During service provisioning, personal data may be involved. You have an obligation to make privacy policies and take measures according to the applicable law of the country to protect personal data.

### [16.11.1 Command Support](#)

### [16.11.2 display sflow](#)

### [16.11.3 display sflow statistics](#)

### [16.11.4 sflow agent](#)

### [16.11.5 sflow collector](#)

### [16.11.6 sflow counter-sampling collector](#)

### [16.11.7 sflow counter-sampling interval](#)

### [16.11.8 sflow flow-sampling](#)

### [16.11.9 sflow flow-sampling collector](#)

### [16.11.10 sflow flow-sampling max-header](#)

### [16.11.11 sflow flow-sampling rate](#)

## 16.11.1 Command Support

Only the S1720GW, S1720GWR, S1720GW-E, S1720GWR-E, S1720X, S1720X-E, S2720EI, S2750EI, S5700LI, S5700S-LI, S5710-X-LI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support sFlow.

## 16.11.2 display sflow

### Function

The **display sflow** command displays the sFlow configuration on a specified device.

### Format

```
display sflow [ slot slot-id ]
```

## Parameters

Parameter	Description	Value
<b>slot</b> <i>slot-id</i>	Displays the sFlow information on a device, where <i>slot-id</i> specifies the slot ID of the device.  If this parameter is not configured, the global sFlow configuration is displayed.	The value is an integer and must be set according to the device configuration.

## Views

All views

## Default Level

3: Management level

## Usage Guidelines

After configuring the sFlow function, you can use the **display sflow** command to verify the configuration.

The **display sflow** command shows the sFlow configuration, which helps you locate faults.

## Example

# Display the sFlow configuration on a specified device.

```
<HUAWEI> display sflow slot 0
sFlow Version 5 Information:
-----
Agent Information:
    IP Address: 192.168.1.206(CLI)
    Address family: IPV4
    Vpn-instance: NA
-----
Collector Information:
    Collector ID: 1
    IP Address: 192.168.1.194
    Address family: IPV4
    Vpn-instance: NA
    Port: 6343
    Datagram size: 1500
    Time out: NA
    Description: zjm-pc
-----
Port on slot 0 Information:
Interface: GE0/0/1
Flow-sample collector: 1          Counter-sample collector : 1
Flow-sample rate(1/x): 2048      Counter-sample interval(s): 10
```

Flow-sample maxheader: 64  
Flow-sample direction: IN,OUT

**Table 16-78** Description of the **display sflow** command output

Item	Description
sFlow Version 5 Information	-
Agent Information	Configuration of the sFlow Agent.
IP Address	IP address of the sFlow Agent. To configure this parameter, run the <b>16.11.4 sflow agent</b> command. The string in the parentheses next to the IP address can be: <ul style="list-style-type: none"> <li>• CLI: Indicate that this IP address is specified using the <b>16.11.4 sflow agent</b> command.</li> <li>• Auto: Indicate that the sFlow agent uses the IP address of the outbound interface in the route to the sFlow collector as the sFlow agent IP address.</li> </ul>
Address family	Address family of the sFlow Agent: <ul style="list-style-type: none"> <li>• IPV4: IPv4 address family</li> <li>• IPV6: IPv6 address family</li> </ul> To configure this parameter, run the <b>16.11.4 sflow agent</b> command.
Vpn-instance	VPN instance of the sFlow Agent. To configure this parameter, run the <b>16.11.4 sflow agent</b> command. The value will be NA if this parameter is not configured in the <b>16.11.4 sflow agent</b> command.
Collector Information	Configuration of the sFlow Collector.
Collector ID	ID of the sFlow Collector. To configure this parameter, run the <b>16.11.5 sflow collector</b> command.
IP Address	IP address of the sFlow Collector. To configure this parameter, run the <b>16.11.5 sflow collector</b> command.
Address family	Address family of the sFlow collector: <ul style="list-style-type: none"> <li>• IPV4: IPv4 address family</li> <li>• IPV6: IPv6 address family</li> </ul> To configure this parameter, run the <b>16.11.5 sflow collector</b> command.
Vpn-instance	VPN instance of the sFlow Collector. To configure this parameter, run the <b>16.11.5 sflow collector</b> command. The value will be NA if this parameter is not configured in the <b>16.11.5 sflow collector</b> command.

Item	Description
Port	Port number of the sFlow Collector. To configure this parameter, run the <a href="#">16.11.5 sflow collector</a> command.
Datagram size	Maximum length of sFlow packets sent to the sFlow Collector. To configure this parameter, run the <a href="#">16.11.5 sflow collector</a> command.
Time out	Aging time of the sFlow Collector. To configure this parameter, run the <a href="#">16.11.5 sflow collector</a> command. The value will be NA if this parameter is not configured or is set to 0 in the <a href="#">16.11.5 sflow collector</a> command.
Description	Description of the sFlow Collector. To configure this parameter, run the <a href="#">16.11.5 sflow collector</a> command. The value will be NA if this parameter is not configured in the <a href="#">16.11.5 sflow collector</a> command.
Port on slot 0 Information	-
Interface	sFlow-enabled interface. To configure this parameter, run the <a href="#">16.11.9 sflow flow-sampling collector</a> command.
Flow-sample collector	sFlow Collector that receives flow sampling data. To configure this parameter, run the <a href="#">16.11.9 sflow flow-sampling collector</a> command.
Counter-sample collector	sFlow Collector that receives counter sampling data. To configure this parameter, run the <a href="#">16.11.6 sflow counter-sampling collector</a> command.
Flow-sample rate(1/x)	Flow sampling rate. To configure this parameter, run the <a href="#">16.11.11 sflow flow-sampling rate</a> command.
Counter-sample interval(s)	Counter sampling interval. To configure this parameter, run the <a href="#">16.11.7 sflow counter-sampling interval</a> command.
Flow-sample maxheader	The maximum bytes of data that can be copied from a sampled packet in flow sampling. To configure this parameter, run the <a href="#">16.11.10 sflow flow-sampling max-header</a> command.
Flow-sample direction	Flow sampling direction: <ul style="list-style-type: none"> <li>• IN: Enable flow sampling in the inbound direction.</li> <li>• OUT: Enable flow sampling in the outbound direction.</li> <li>• IN,OUT: Enable flow sampling in both inbound direction and outbound direction.</li> </ul> To configure this parameter, run the <a href="#">16.11.8 sflow flow-sampling</a> command.

## Related Topics

- [16.11.4 sflow agent](#)
- [16.11.5 sflow collector](#)
- [16.11.6 sflow counter-sampling collector](#)
- [16.11.7 sflow counter-sampling interval](#)
- [16.11.8 sflow flow-sampling](#)
- [16.11.9 sflow flow-sampling collector](#)
- [16.11.10 sflow flow-sampling max-header](#)
- [16.11.11 sflow flow-sampling rate](#)
- [16.11.3 display sflow statistics](#)

## 16.11.3 display sflow statistics

### Function

The **display sflow statistics** command displays sFlow statistics.

### Format

**display sflow statistics** [ **slot** *slot-id* | **interface** *interface-type interface-number* ]

### Parameters

Parameter	Description	Value
<b>slot</b> <i>slot-id</i>	Specifies the slot ID of a device.	The value is an integer and must be set according to the device configuration.
<b>interface</b> <i>interface-type interface-number</i>	Specifies the type and number of an interface.	-

### Views

All views

### Default Level

3: Management level

### Usage Guidelines

The **display sflow statistics** command displays sFlow statistics, including the sampling mode, number of sampled packets, sequence number of sent packets, and number of discarded sFlow packets because of expiration. You can use the command output to locate faults.

## Example

# Display sFlow statistics.

```
<HUAWEI> display sflow statistics
sFlow Version 5 statistic Information:
-----
Collector 1 Current sample sequence:22388
-----
Port on slot 0 statistic Information:

Interface: GE0/0/1
Flow-sample sequence : 7      Counter-sample sequence : 44778
Flow-sample inbound pool: 28000   Flow-sample outbound pool: 4000
-----
```

**Table 16-79** Description of the **display sflow statistics** command output

Item	Description
sFlow Version 5 statistic Information	sFlow sampling of sFlow version 5.
Collector 1 Current sample sequence	Sampling sequence number of the sFlow collector.
Port on slot 0 statistic Information	sFlow sampling information on slot 0.
Interface: GE0/0/1	sFlow-enabled interface.
Flow-sample sequence	Sequence number for flow sampling on an interface.
Counter-sample sequence	Sequence number for counter sampling on an interface.
Flow-sample inbound pool	Number of incoming packets for flow sampling on an interface.
Flow-sample outbound pool	Number of outgoing packets for flow sampling on an interface.

## Related Topics

- [16.11.4 sflow agent](#)
- [16.11.5 sflow collector](#)
- [16.11.6 sflow counter-sampling collector](#)
- [16.11.7 sflow counter-sampling interval](#)
- [16.11.8 sflow flow-sampling](#)
- [16.11.9 sflow flow-sampling collector](#)
- [16.11.10 sflow flow-sampling max-header](#)
- [16.11.11 sflow flow-sampling rate](#)
- [16.11.2 display sflow](#)

## 16.11.4 sflow agent

### Function

The **sflow agent** command creates an sFlow agent and specifies an IP address for the sFlow agent or updates the IP address of the existing sFlow agent.

The **undo sflow agent** command deletes the IP address of an sFlow agent.

By default, an sFlow agent uses the IP address of the outbound interface in the route to the sFlow collector as the sFlow agent IP address of sFlow packets.

### Format

```
sflow agent { ip [ vpn-instance vpn-instance-name ] ip-address | ipv6 [ vpn-instance vpn-instance-name ] ipv6-address }
```

```
undo sflow agent { ip [ vpn-instance vpn-instance-name ] ip-address | ipv6 [ vpn-instance vpn-instance-name ] ipv6-address }
```

#### NOTE

Only S1720GW, S1720GWR, S1720GW-E, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support **vpn-instance** *vpn-instance-name*.

### Parameters

Parameter	Description	Value
<b>ip</b> <i>ip-address</i>	Specifies the IPv4 address of an sFlow agent.	The value is in dotted decimal notation and is a valid unicast address except 127.X.X.X.
<b>ipv6</b> <i>ipv6-address</i>	Specifies an IPv6 address of the sFlow agent.	The value is an IPv6 unicast address, which is a 32-digit hexadecimal number.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The value is a string of 1 to 31 case-sensitive characters without spaces.

### Views

System view

### Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

sFlow is a traffic monitoring technique that collects and analyzes traffic statistics. An sFlow agent encapsulates traffic statistics into sFlow packets and sends the sFlow packets to specified sFlow collectors. To send the sFlow packets to a certain sFlow collector, configure an IP address for the sFlow agent as the source address of sFlow packets. The sFlow collector analyzes and displays the traffic statistics based on the traffic in the received sFlow packets. Network administrators can view the traffic statistics on a specified interface based on the IP address of the sFlow agent and interface number.

### Prerequisites

- The IP address configured as the source address must exist on the device.
- A VPN instance has been created if the sFlow agent is located on a private network.

### Configuration Impact

If you run the **sflow agent** command multiple times, only the latest configuration takes effect.

### Precautions

A maximum of two sFlow agents can be configured in the system, and each VPN instance of an address family supports only one agent. The IP address of an agent must be a valid unicast IP address of an interface. If an IPv6 address is specified for an agent, the IPv6 address must be a global unicast address, but cannot be a link-local address.

## Example

# Configure an IPv4 address for the sFlow agent.

```
<HUAWEI> system-view  
[HUAWEI] sflow agent ip 192.168.100.10
```

# Configure an IPv6 address for the sFlow agent.

```
<HUAWEI> system-view  
[HUAWEI] sflow agent ipv6 FC00::1
```

## Related Topics

- [16.11.5 sflow collector](#)
- [16.11.6 sflow counter-sampling collector](#)
- [16.11.7 sflow counter-sampling interval](#)
- [16.11.8 sflow flow-sampling](#)
- [16.11.9 sflow flow-sampling collector](#)
- [16.11.10 sflow flow-sampling max-header](#)
- [16.11.11 sflow flow-sampling rate](#)
- [16.11.2 display sflow](#)
- [16.11.3 display sflow statistics](#)



## 16.11.5 sflow collector

### Function

The **sflow collector** command creates an sFlow collector and sets or modifies optional parameters for the sFlow collector.

The **undo sflow collector** command restores default values of optional parameters of the sFlow collector or deletes the sFlow collector.

By default, no sFlow collector is configured.

### Format

```
sflow collector collector-id { ip [ vpn-instance vpn-instance-name ] ip-address | ipv6 [ vpn-instance vpn-instance-name ] ipv6-address } [ datagram-size datagram-size | port port-num | time-out time ] * [ description description ]
```

```
sflow collector collector-id { datagram-size datagram-size | port port-num } * [ description description ]
```

```
undo sflow collector collector-id [ datagram-size | port | description ] *
```

#### NOTE

Only S1720GW, S1720GWR, S1720GW-E, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support **vpn-instance** *vpn-instance-name*.

### Parameters

Parameter	Description	Value
<i>collector-id</i>	Specifies the ID of an sFlow collector. This ID is used when you specify the collector in subsequent sFlow configuration.	The value is an integer that can be 1 or 2.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The value must be an existing VPN instance name.
<i>ip-address</i>	Specifies an IPv4 address of the sFlow collector.	The value is a value unicast IP address in X.X.X.X format, dotted decimal notation. The value cannot be 127.X.X.X.

Parameter	Description	Value
<i>ipv6-address</i>	Specifies an IPv6 address for the sFlow collector.	The value is a 32-digit hexadecimal number in the format of X:X:X:X:X:X:X and is a valid global IPv6 unicast address.
<b>datagram-size</b> <i>datagram-size</i>	Specifies the maximum length of sFlow packets sent from an sFlow agent to an sFlow collector.	The value is an integer, in bytes. It ranges from 1024 to 8100. The default value is 1400.
<b>port</b> <i>port-num</i>	Specifies the UDP destination port number of sFlow packets.	The value is an integer that ranges from 1 to 65535. The default value is 6343.
<b>description</b> <i>description</i>	Specifies the description of an sFlow collector.	The value is a string of 1 to 255 case-sensitive characters without spaces.
<b>time-out</b> <i>time</i>	Specifies the aging time of an sFlow collector.	The value is an integer that ranges from 0 to 3600, in seconds. The default value is 0, indicating that the sFlow collector is not aged out. If the default value is used, the aging time cannot be changed.

## Views

System view

## Default Level

3: Management level

## Usage Guidelines

### Usage scenario

sFlow is a traffic monitoring technique that collects and analyzes traffic statistics. An sFlow agent encapsulates traffic statistics into sFlow packets and sends the sFlow packets to all sFlow collectors. To send the sFlow packets to a certain sFlow collector, configure an sFlow collector used to receive sFlow packets and analyze traffic of sFlow packets. When both flow sampling and counter sampling are configured on an interface of an sFlow agent, the sFlow agent sends the flow

sampling data and counter sampling data to one or two sFlow collectors. Because sFlow packets are sampled quickly and the number of sFlow packets sent every second is limited, run the **sflow collector** command with **datagram-size length** specified to set the maximum length of sFlow packets so that an sFlow packet carries more sampled data. This reduces the number of sent sFlow packets.

#### NOTE

When you create an sFlow collector, specify the ID and IP address for the sFlow collector. If the aging time of the sFlow collector is not set, the sFlow collector is not aged out by default and the aging time cannot be changed.

#### Prerequisites

- There is a reachable route between an sFlow agent and an sFlow collector.
- A VPN instance has been created if the sFlow collector is located on a private network.

#### Configuration Impact

If you run the **sflow collector** command multiple times on the same address family and VPN instance, only the latest configuration takes effect.

#### Precautions

A maximum of two sFlow collectors can be configured in the system.

## Example

# Configure an IPv4 address for the sFlow collector, and set the aging time of the sFlow collector to 100s.

```
<HUAWEI> system-view  
[HUAWEI] sflow collector 1 ip 192.168.100.10 time-out 100
```

# Configure an IPv6 address for the sFlow collector, and set the aging time of the sFlow collector to 100s.

```
<HUAWEI> system-view  
[HUAWEI] sflow collector 1 ipv6 FC00::1 time-out 100
```

## Related Topics

- [16.11.4 sflow agent](#)
- [16.11.6 sflow counter-sampling collector](#)
- [16.11.7 sflow counter-sampling interval](#)
- [16.11.8 sflow flow-sampling](#)
- [16.11.9 sflow flow-sampling collector](#)
- [16.11.10 sflow flow-sampling max-header](#)
- [16.11.11 sflow flow-sampling rate](#)
- [16.11.2 display sflow](#)
- [16.11.3 display sflow statistics](#)

## 16.11.6 sflow counter-sampling collector

### Function

The **sflow counter-sampling collector** command specifies the target sFlow collector that receives counter sampling data.

The **undo sflow counter-sampling collector** command deletes the target sFlow collector.

By default, no target sFlow collector is specified.

### Format

**sflow counter-sampling collector** { *collector-id* | **all** }

**undo sflow counter-sampling collector** { *collector-id* | **all** }

### Parameters

Parameter	Description	Value
<i>collector-id</i>	Specifies the ID of the target sFlow collector that receives counter sampling data.	The value is an integer that can be 1 or 2. <b>NOTE</b> The value of <i>collector-id</i> is set using the <b>sflow collector</b> command.
<b>all</b>	Indicates all the configured sFlow collectors.	-

### Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

### Default Level

3: Management level

### Usage Guidelines

#### Usage scenario

Counter sampling is based on time. An sFlow agent periodically obtains traffic statistics on an interface, encapsulates the traffic statistics into sFlow packets, and sends them to an sFlow collector. When multiple sFlow collectors are configured, you can run the **sflow counter-sampling collector** command to specify the target sFlow collector to receive the counter sampling data. Each interface can send sFlow sampling data to a maximum of two sFlow collectors.

When you run the **sflow counter-sampling collector** command to specify the first target sFlow collector on an interface, counter sampling is enabled on the interface. When you run the **undo sflow counter-sampling collector** command to delete the last target sFlow collector on an interface, counter sampling is disabled on the interface.

#### Prerequisites

An sFlow collector has been created using the **sflow collector** command.

#### Precautions

The **sflow flow-sampling rate** command only applies to Layer 2 physical interfaces, but does not apply to Eth-Trunk or Layer 3 interfaces. However, this command takes effect on the Layer 3 interface which is switched from a Layer 2 interface using the **undo portswitch** command, and can take effect on Eth-Trunk member interfaces.

## Example

# Specify sFlow collector 1 to receive counter sampling data.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] sflow counter-sampling collector 1
```

# Configure a port group **pg1** that has member ports GE0/0/2 and GE0/0/3, and specify sFlow collector 1 to receive counter sampling data for the port group **pg1**.

```
[HUAWEI] port-group pg1  
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/2  
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/3  
[HUAWEI-port-group-pg1] sflow counter-sampling collector 1
```

## Related Topics

- [16.11.4 sflow agent](#)
- [16.11.5 sflow collector](#)
- [16.11.7 sflow counter-sampling interval](#)
- [16.11.2 display sflow](#)
- [16.11.3 display sflow statistics](#)

## 16.11.7 sflow counter-sampling interval

### Function

The **sflow counter-sampling interval** command sets the counter sampling interval on an interface.

The **undo sflow counter-sampling interval** command restores the default counter sampling interval on an interface.

By default, the counter sampling interval on an interface is 10s.

### Format

**sflow counter-sampling interval** *interval*

## undo sflow counter-sampling interval

### Parameters

Parameter	Description	Value
<b>interval</b> <i>interval</i>	Specifies the counter sampling interval.	The value is an integer that ranges from 2 to 3600, in seconds. The default value is 10.

### Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

### Default Level

3: Management level

### Usage Guidelines

#### Usage scenario

Counter sampling is based on time. An sFlow agent periodically obtains traffic statistics on an interface, encapsulates the traffic statistics into sFlow packets, and sends them to an sFlow collector. You can run the **sflow counter-sampling interval** command to set an appropriate counter sampling interval.

#### Precautions

The **sflow flow-sampling rate** command only applies to Layer 2 physical interfaces, but does not apply to Eth-Trunk or Layer 3 interfaces. However, this command takes effect on the Layer 3 interface which is switched from a Layer 2 interface using the **undo portswitch** command, and can take effect on Eth-Trunk member interfaces. If you run the **sflow flow-sampling rate** command multiple times, only the latest configuration takes effect.

### Example

```
# Set the counter sampling interval to 100s.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] sflow counter-sampling interval 100
```

```
# Configure a port group pg1 that has member ports GE0/0/2 and GE0/0/3, and set the counter sampling interval to 100s for the port group pg1.
```

```
[HUAWEI] port-group pg1  
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/2  
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/3  
[HUAWEI-port-group-pg1] sflow counter-sampling interval 100
```

## Related Topics

- [16.11.4 sflow agent](#)
- [16.11.5 sflow collector](#)
- [16.11.6 sflow counter-sampling collector](#)
- [16.11.2 display sflow](#)
- [16.11.3 display sflow statistics](#)

## 16.11.8 sflow flow-sampling

### Function

The **sflow flow-sampling** command enables flow sampling in a specified direction on an interface.

The **undo sflow flow-sampling** command disables flow sampling in a specified direction on an interface.

By default, flow sampling is enabled in both directions on an interface.

### Format

**sflow flow-sampling { inbound | outbound }**

**undo sflow flow-sampling { inbound | outbound }**

### Parameters

Parameter	Description	Value
<b>inbound</b>	Enables flow sampling in the inbound direction.	-
<b>outbound</b>	Enables flow sampling in the outbound direction.	-

### Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

### Default Level

3: Management level

### Usage Guidelines

#### Usage scenario

You can specify the direction in which flow sampling is performed. Flow sampling can be performed in both inbound and outbound directions.

#### Precautions

The **sflow flow-sampling rate** command only applies to Layer 2 physical interfaces, but does not apply to Eth-Trunk or Layer 3 interfaces. However, this command takes effect on the Layer 3 interface which is switched from a Layer 2 interface using the **undo portswitch** command, and can take effect on Eth-Trunk member interfaces. If you run the **sflow flow-sampling rate** command multiple times, only the latest configuration takes effect.

## Example

```
# Enable flow sampling in the inbound direction.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] sflow flow-sampling inbound
```

```
# Configure a port group pg1 that has member ports GE0/0/2 and GE0/0/3, and enable flow sampling in the inbound direction of the port group pg1.
```

```
[HUAWEI] port-group pg1  
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/2  
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/3  
[HUAWEI-port-group-pg1] sflow flow-sampling inbound
```

## Related Topics

- [16.11.4 sflow agent](#)
- [16.11.5 sflow collector](#)
- [16.11.9 sflow flow-sampling collector](#)
- [16.11.10 sflow flow-sampling max-header](#)
- [16.11.11 sflow flow-sampling rate](#)
- [16.11.2 display sflow](#)
- [16.11.3 display sflow statistics](#)

## 16.11.9 sflow flow-sampling collector

### Function

The **sflow flow-sampling collector** command specifies the target sFlow collector that receives flow sampling data.

The **undo sflow flow-sampling collector** command deletes the target sFlow collector that receives flow sampling data.

By default, no target sFlow collector is specified.

### Format

```
sflow flow-sampling collector { collector-id | all }
```

```
undo sflow flow-sampling collector { collector-id | all }
```



## Parameters

Parameter	Description	Value
<i>collector-id</i>	Specifies the ID of the target sFlow collector that receives flow sampling data.	The value is an integer that can be 1 or 2.
<b>all</b>	Indicates all the configured sFlow collectors.	-

## Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

## Default Level

3: Management level

## Usage Guidelines

### Usage scenario

An sFlow agent samples packets in a direction of an interface based on a sampling rate, analyzes packets, encapsulates sampled packets and analysis result into sFlow packets, and then sends the sFlow packets to an sFlow collector. When multiple sFlow collectors are configured, you can run the **sflow flow-sampling collector** command to specify one or two to receive sFlow packets. Each interface can send sFlow sampling packets to a maximum of two collectors.

When you run the **sflow flow-sampling collector** command to specify the first target sFlow collector on an interface, flow sampling is enabled on the interface. When you run the **undo sflow flow-sampling collector** command to delete the last target sFlow collector on an interface, flow sampling is disabled on the interface.

### Prerequisites

An sFlow collector has been created using the **sflow collector** command.

### Precautions

The **sflow flow-sampling rate** command only applies to Layer 2 physical interfaces, but does not apply to Eth-Trunk or Layer 3 interfaces. However, this command takes effect on the Layer 3 interface which is switched from a Layer 2 interface using the **undo portswitch** command, and can take effect on Eth-Trunk member interfaces.

## Example

```
# Specify sFlow collector 1 to receive the flow sampling data.
```

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] sflow flow-sampling collector 1
```

# Configure a port group **pg1** that has member ports GE0/0/2 and GE0/0/3, and specify sFlow collector 1 to receive flow sampling data for the port group **pg1**.

```
[HUAWEI] port-group pg1
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/2
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/3
[HUAWEI-port-group-pg1] sflow flow-sampling collector 1
```

## Related Topics

- [16.11.4 sflow agent](#)
- [16.11.5 sflow collector](#)
- [16.11.8 sflow flow-sampling](#)
- [16.11.10 sflow flow-sampling max-header](#)
- [16.11.11 sflow flow-sampling rate](#)
- [16.11.2 display sflow](#)
- [16.11.3 display sflow statistics](#)

## 16.11.10 sflow flow-sampling max-header

### Function

The **sflow flow-sampling max-header** command sets the maximum bytes of data that can be copied from a sampled packet in flow sampling.

The **undo sflow flow-sampling max-header** command restores the default maximum bytes of data.

By default, a maximum of 64 bytes of data can be copied from a sampled packet in flow sampling.

### Format

**sflow flow-sampling max-header** *length*

**undo sflow flow-sampling max-header**

### Parameters

Parameter	Description	Value
<i>length</i>	Specifies the maximum bytes of data that can be copied from a sampled packet.	The unit is byte. The value is an integer that ranges from 18 to 512. The default value is 64.

## Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

## Default Level

3: Management level

## Usage Guidelines

### Usage scenario

An sFlow agent samples packets in a direction of an interface based on a sampling rate, analyzes packets, encapsulates sampled packets and analysis result into sFlow packets, and then sends the sFlow packets to an sFlow collector. The datagram size of sFlow packets is set using the **sflow collector** [ **datagram-size datagram-size** ] command. If only the information carried in the packet header is required, run the **sflow flow-sampling max-header** command to set the maximum length of data starting from the original packet header that can be copied from a sampled packet.

### Precautions

The **sflow flow-sampling rate** command only applies to Layer 2 physical interfaces, but does not apply to Eth-Trunk or Layer 3 interfaces. However, this command takes effect on the Layer 3 interface which is switched from a Layer 2 interface using the **undo portswitch** command, and can take effect on Eth-Trunk member interfaces.

## Example

# Set the maximum length of data starting from the original packet header that can be copied from a sampled packet to 256 bytes.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] sflow flow-sampling max-header 256
```

# Configure a port group **pg1** that has member ports GE0/0/2 and GE0/0/3, and set the maximum length of data starting from the original packet header that can be copied from a sampled packet to 256 bytes for the port group **pg1**.

```
[HUAWEI] port-group pg1
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/2
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/3
[HUAWEI-port-group-pg1] sflow flow-sampling max-header 256
```

## Related Topics

- [16.11.4 sflow agent](#)
- [16.11.5 sflow collector](#)
- [16.11.8 sflow flow-sampling](#)
- [16.11.9 sflow flow-sampling collector](#)
- [16.11.11 sflow flow-sampling rate](#)
- [16.11.2 display sflow](#)

[16.11.3 display sflow statistics](#)

## 16.11.11 sflow flow-sampling rate

### Function

The **sflow flow-sampling rate** command sets the sampling rate on an interface.

The **undo sflow flow-sampling rate** command restores the default sampling rate on an interface.

By default, the sampling rate on a 40GE interface is 1/20480 and on other types of interfaces is 1/2048.

### Format

**sflow flow-sampling rate** *rate*

**undo sflow flow-sampling rate**

### Parameters

Parameter	Description	Value
<b>rate</b> <i>rate</i>	Specifies the sampling rate in the format of 1/ <i>rate</i> . <i>rate</i> specifies the number of packets out of which the interface will sample a packet.	The <i>rate</i> is an integer that ranges from 256 to 1048576.

### Views

Ethernet interface view, GE interface view, XGE interface view, MultiGE interface view, 40GE interface view, port group view

### Default Level

3: Management level

### Usage Guidelines

#### Usage scenario

An sFlow agent samples packets in a direction of an interface based on a sampling rate, analyzes packets, encapsulates sampled packets and analysis result into sFlow packets, and then sends the sFlow packets to an sFlow collector. You can run the **sflow flow-sampling rate** command to set the sampling rate to limit the number of sampled packets.

#### Precautions

The **sflow flow-sampling rate** command only applies to Layer 2 physical interfaces, but does not apply to Eth-Trunk or Layer 3 interfaces. However, this

command takes effect on the Layer 3 interface which is switched from a Layer 2 interface using the **undo portswitch** command, and can take effect on Eth-Trunk member interfaces. If you run the **sflow flow-sampling rate** command multiple times, only the latest configuration takes effect.

## Example

# Set the sampling rate to 1/3072.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] sflow flow-sampling rate 3072
```

# Configure a port group **pg1** that has member ports of GE0/0/2 and GE0/0/3, and set the sampling rate to 1/3072 for the port group **pg1**.

```
[HUAWEI] port-group pg1
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/2
[HUAWEI-port-group-pg1] group-member gigabitethernet 0/0/3
[HUAWEI-port-group-pg1] sflow flow-sampling rate 3072
```

## Related Topics

- [16.11.4 sflow agent](#)
- [16.11.5 sflow collector](#)
- [16.11.8 sflow flow-sampling](#)
- [16.11.9 sflow flow-sampling collector](#)
- [16.11.10 sflow flow-sampling max-header](#)
- [16.11.2 display sflow](#)
- [16.11.3 display sflow statistics](#)

## 16.12 Ping and Tracert Configuration Commands

- [16.12.1 Command Support](#)
- [16.12.2 ping](#)
- [16.12.3 ping ipv6](#)
- [16.12.4 tracert](#)
- [16.12.5 tracert ipv6](#)

### 16.12.1 Command Support

Commands provided in this section and all the parameters in the commands are supported by all switch models by default, unless otherwise specified. For details, see specific commands.

## 16.12.2 ping

### Function

The **ping** command checks whether a specified IPv4 address is reachable and exports corresponding statistics.

### Format

```
ping [ ip ] [ -a source-ip-address | -c count | -d | { -f | ignore-mtu } | -h ttl-value |
-nexthop nexthop-ip-address | -i interface-type interface-number | -m time | -n | -
name | -p pattern | -q | -r | { -s packetsize | -range [ min min-size | max max-size
| step step-size ] * } | -system-time | -t timeout | -tos tos-value | -v | -vpn-
instance vpn-instance-name ] * host [ ip-forwarding ]
```

#### NOTE

The **vpn-instance** *vpn-instance-name* command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

### Parameters

Parameter	Description	Value
<b>ip</b>	Indicates the IPv4 protocol. If <b>ip</b> is not specified, the IPv4 protocol is used.	-
<b>-a</b> <i>source-ip-address</i>	Specifies the source IP address of the ICMP Echo Request message. If the source IP address is not specified, the IP address of the outbound interface is used as the source IP address of the ICMP Echo Request message.	The value is in dotted decimal notation.

Parameter	Description	Value
<b>-c</b> <i>count</i>	<p>Specifies the number of times for sending ICMP Echo Request messages.</p> <p>The <b>ping</b> command labels each ICMP Echo Request message with a sequence ID that starts from 1 and is increased by 1. By default, five ICMP Echo Request messages are sent. You can set the number of ICMP Echo Request messages to send by specifying the parameter <i>count</i>, that is, performing a Ping test with multiple Ping packets.</p> <p>In the case of poor network quality, you can set this parameter to a comparatively large value to check the network quality based on the packet loss rate.</p>	The value is an integer that ranges from 1 to 4294967295. The default value is 5.
<b>-d</b>	Indicates that the socket works in debug mode.	By default, the socket works in non-debug mode.
<b>-f</b>	<p>Indicates that packets are not fragmented during transmission.</p> <p><b>NOTE</b></p> <p>After this parameter is specified, ICMP packets are not fragmented. If the ICMP packet size exceeds the link MTU, the ICMP packet is discarded. If you do not want ICMP packets to be discarded, do not specify this parameter or increase the link MTU.</p>	-
<b>-h</b> <i>ttl-value</i>	<p>Specifies the TTL value.</p> <p>If the TTL field is reduced to 0 during message forwarding, the Layer 3 device that the message reaches sends an ICMP timeout message to the source host, indicating that the destination host is unreachable.</p>	The value is an integer that ranges from 1 to 255. The default value is 255.

Parameter	Description	Value
<b>-nexthop</b> <i>nexthop-ip-address</i>	<p>Specifies an IP address for the next hop.</p> <p>If you have specified this parameter, the device no longer searches the routing table before sending ICMP Echo Response packets. This process prevents ping failures caused by incorrect routing entries.</p> <p><b>NOTE</b></p> <p>The specified next hop address must be the next hop address of a directly connected physical interface.</p> <p>When you specify a next hop address, you can configure <i>-i interface-type interface-number</i> to specify an outbound interface. The following conditions must be met to ensure a test success: the specified next hop address must match the outbound interface; the specified outbound interface cannot be a logical interface's member interface.</p> <p>If you have specified a next hop address, you cannot specify a VPN.</p>	The value is in dotted decimal notation.
<b>-i interface-type</b> <i>interface-number</i>	<p>Specifies the outbound interface for sending ICMP Echo Request packets.</p> <p><b>NOTE</b></p> <p>In load balancing scenarios, if an interface is specified to send ICMP Echo Request packets, all packets are sent from the interface and load balancing is not performed.</p> <p>The interface specified to send ICMP Echo Request packets must be a Layer 3 interface, such as a VLANIF interface.</p>	-
<b>-m time</b>	<p>Specifies the time to wait before sending the next ICMP Echo Request message.</p> <p>Each time the source sends an ICMP Echo Request message using the <b>ping</b> command, the source waits a period of time (500 ms by default) before sending the next ICMP Echo Request message. You can set the time to wait before sending the next ICMP Echo Request message using the parameter <i>time</i>. In the case of poor network condition, the value should be equal to or larger than 500, in milliseconds.</p>	The value is an integer that ranges from 1 to 10000, in milliseconds. The default value is 500.



Parameter	Description	Value
<b>-n</b>	Uses the value of <i>host</i> as the IP address to spare domain name resolution.	-
<b>-name</b>	Displays the name of the destination host.	-
<b>-p <i>pattern</i></b>	Specifies pad characters for ICMP Echo Request messages.  By configuring pad characters for ICMP Echo Request messages, you can identify a specific message among the large number of received ICMP Echo Reply messages.	The value is a hexadecimal integer that ranges from 0 to FFFFFFFF. By default, the padding starts from 0x01, and continues in ascending order.
<b>-q</b>	Displays only the statistics. If the <b>ping</b> command carries this parameter, the system displays only the statistics information such as the number of sent and received packets, packet loss rate, and minimum, average, and maximum RTTs of the packet.	By default, the system displays all statistics information.
<b>-r</b>	Records the route along which an IP packet is forwarded.  When <b>-r</b> is specified, during the transmission of an IP packet, the IP address of each Layer 3 device that the IP packet passes through is added to the Options field. When the IP packet reaches the destination, all IP addresses recorded in the Options field are copied to the ICMP Echo Reply message. In addition, the IP address of each Layer 3 device that the returned IP packet passes through is added to the message. When the ping program receives the ICMP Echo Reply message, IP addresses of the passed Layer 3 devices are displayed.	By default, the route along which an IP packet is forwarded is not recorded.
<b>-s <i>packetsize</i></b>	Specifies the length of an ICMP Echo Request message, excluding the IP header and ICMP header, that is, performing a Ping test with large-sized Ping packets.	The value is an integer that ranges from 20 to 9600, in bytes. The default value is 56.

Parameter	Description	Value
<b>-range</b>	<p>Enables the device to send ICMP Echo Request messages with variable payload lengths.</p> <p><b>NOTE</b></p> <p>The command execution takes a long period if a large number of ICMP Echo Request messages need to be sent. If you want to terminate the command execution, press <b>Ctrl+C</b>.</p> <p>To change the number of ICMP Echo Request messages to be sent, change the values of <b>min</b> <i>min-size</i> and <b>max</b> <i>max-size</i>. The value of <b>min</b> <i>min-size</i> must be smaller than that of <b>max</b> <i>max-size</i>.</p> <p>If both the <b>-range</b> and <b>-c</b> <i>count</i> parameters are specified, the device sends ICMP Echo Request messages of the same payload length for the number of times specified by the <b>-c</b> <i>count</i> parameter.</p>	<ul style="list-style-type: none"> <li>• If the <b>-range</b> parameter is not specified, the payload length of an ICMP Echo Request message is equal to the length specified by the <b>-s</b> <i>packetsize</i> parameter. The default value is 56, in bytes.</li> <li>• If the <b>-range</b> parameter is specified, the payload length of the first ICMP Echo Request message is <b>min</b> <i>min-size</i>, and that of the second ICMP Echo Request message is <b>min</b> <i>min-size</i> plus <b>step</b> <i>step-size</i>. The payload length increases incrementally by <b>step</b> <i>step-size</i> for subsequent ICMP Echo Request messages until <b>max</b> <i>max-size</i> is reached. After that, the device will not send ICMP Echo Request messages any more.</li> </ul> <p>By default, the payload length of an ICMP Echo Request message ranges from 56 to 9600 bytes, and the step length is 1 byte.</p>
<b>min</b> <i>min-size</i>	Specifies the minimum payload length of an ICMP Echo Request message.	The value is an integer ranging from 20 to 9600, in bytes. The default value is 56.
<b>max</b> <i>max-size</i>	Specifies the maximum payload length of an ICMP Echo Request message.	The value is an integer ranging from 20 to 9600, in bytes. The default value is 9600.

Parameter	Description	Value
<b>step</b> <i>step-size</i>	Specifies the step length of an ICMP Echo Request message.	The value is an integer ranging from 1 to 1000, in bytes. The default value is 1.
<b>-system-time</b>	Displays the system time when the ping packet is sent.	-
<b>-t</b> <i>timeout</i>	<p>Specifies the timeout period to wait for an ICMP Echo Reply message after an ICMP Echo Request message is sent.</p> <p>After the <b>ping</b> command is run, the source sends an ICMP Echo Request message to a destination and waits for an ICMP Echo Reply message. If the destination, after receiving the ICMP Echo Request message, returns an ICMP Echo Reply message to the source within the period specified by the parameter <i>timeout</i>, the destination is reachable. If the destination does not return an ICMP Echo Reply message within the specified period, the source displays that the message times out.</p> <p>Normally, the source receives an ICMP Echo Reply message within 1 to 10 seconds after sending an ICMP Echo Request message. If the transmission speed is low, properly prolong the timeout period.</p>	The value is an integer that ranges from 0 to 65535, in milliseconds. The default value is 2000.
<b>-tos</b> <i>tos-value</i>	Specifies the ToS value of the sent ICMP Echo Request messages. The ToS value is used to set the packet priority.	The value is an integer that ranges from 0 to 255. The default value is 0.
<b>-v</b>	<ul style="list-style-type: none"> <li>If <b>-v</b> is not specified, the system displays only the ICMP Echo Reply messages received by the local user.</li> <li>If <b>-v</b> is specified, the system displays all received ICMP Echo Reply messages.</li> </ul>	-
<b>-vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The value must be an existing VPN instance name.

Parameter	Description	Value
<b>ignore-mtu</b>	Indicates that the system does not check the interface MTU when a packet is sent.	-
<i>host</i>	Specifies the domain name or IP address of the destination host.	The value is a string of 1 to 255 case-sensitive characters with spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string. Alternatively, the value can be a valid IPv4 address in dotted decimal notation.
<b>ip-forwarding</b>	Indicates that the ping packets are forcibly forwarded through IP on the first node.	-

## Views

All views

## Default Level

0: Visit level

## Usage Guidelines

### Usage Scenario

The **ping** command is a common debugging tool for testing the network connectivity by transmitting ICMP Echo messages. It can detect the following items:

- Availability of the remote device
- Round-trip delay in communication between the local and remote devices
- Packet loss rate

You can run the **ping** command to check the network connectivity or line quality in the following scenarios:

- Scenario 1: Check the protocol stack on the local device. You can run the **ping loopback-address** command to check whether the TCP/IP protocol stack works properly on the local device.
- Scenario 2: Check whether the destination host is reachable on an IP network. You can run the **ping host** command to send an ICMP Echo Request message to the destination host. If a reply is received, the destination host is reachable.
- Scenario 3: In the case of an unstable network, you can run the **ping -c count -t timeout host** command to check the quality of the network between the

local device and the peer. By analyzing the packet loss rate and average delay in the command output, you can evaluate the network quality. If the network is unreliable, set the packet transmission count (-c) and timeout (-t) to the upper limits. This makes the test result accurate.

- Scenario 4: Check the path. You can run the **ping -r host** command to obtain information about nodes along the path from the local device to the peer.
- Scenario 5: Check the path MTU. You can run the **ping -f -s packetsize host** command to prevent ICMP message fragmentation and set the length of an ICMP message so as to obtain the path MTU through multiple probes.
- Scenario 6: Check whether the peer is reachable on a Layer 3 VPN. On a Layer 3 VPN, devices may not have routing information about each other. Therefore, you cannot use the **ping host** command to check whether the peer is reachable. When a VPN instance name is specified, you can run the **ping -vpn-instance vpn-instance-name host** command to send an ICMP Echo Request message to the peer. If the peer returns an ICMP Echo Reply message, the peer is reachable.

### Prerequisite

- Before running the **ping** command, ensure that the ICMP module is working properly.
- If **-vpn-instance** is specified, ensure that the VPN module is working properly.

### Precautions

- If an intermediate device is disabled from responding to ICMP messages, detection on this node fails.
- If a fault occurs in the ping process, you can press **Ctrl+C** to terminate the ping operation.
- To ensure security, do not **ping** the broadcast address, such as XX.XX.XX.255.
- When the destination host is unreachable, the system displays "Request time out", which indicates that the ICMP Echo Request message times out.
- The **ping** command is typically used to check network connectivity and link quality, and cannot be used to evaluate the forwarding latency of a switch. If the pinged IP address is not the local switch's, the switch forwards the ICMP packet according to routing entries, without sending them to the CPU. If the pinged IP address is the local switch's, the switch sends the ICMP packets to the CPU for processing. In this case, you can run the **icmp-reply fast** command on the switch to enable the fast ICMP reply function. With this function, the switch directly processes the ICMP packets destined for its own IP address on interfaces, without sending the packets to the CPU. This minimizes the **ping** latency.

## Example

# Check whether the host at 10.1.1.2 is reachable.

```
<HUAWEI> ping 10.1.1.2
PING 10.1.1.2: 56 data bytes, press CTRL_C to break
Reply from 10.1.1.2: bytes=56 Sequence=1 ttl=255 time=2 ms
Reply from 10.1.1.2: bytes=56 Sequence=2 ttl=255 time=1 ms
Reply from 10.1.1.2: bytes=56 Sequence=3 ttl=255 time=1 ms
Reply from 10.1.1.2: bytes=56 Sequence=4 ttl=255 time=1 ms
Reply from 10.1.1.2: bytes=56 Sequence=5 ttl=255 time=1 ms
```

```
--- 10.1.1.2 ping statistics ---
 5 packet(s) transmitted
 5 packet(s) received
 0.00% packet loss
 round-trip min/avg/max = 1/1/2 ms
```

# Check whether the host at 10.1.1.4 is reachable, set the transmission count to 8, and set the period for waiting for an ICMP Echo Reply message to 4000 ms.

```
<HUAWEI> ping -c 8 -t 4000 10.1.1.4
PING 10.1.1.4: 56 data bytes, press CTRL_C to break
 Reply from 10.1.1.4: bytes=56 Sequence=1 ttl=255 time=32 ms
 Reply from 10.1.1.4: bytes=56 Sequence=2 ttl=255 time=32 ms
 Reply from 10.1.1.4: bytes=56 Sequence=3 ttl=255 time=32 ms
 Reply from 10.1.1.4: bytes=56 Sequence=4 ttl=255 time=32 ms
 Reply from 10.1.1.4: bytes=56 Sequence=5 ttl=255 time=32 ms
 Reply from 10.1.1.4: bytes=56 Sequence=6 ttl=255 time=32 ms
 Reply from 10.1.1.4: bytes=56 Sequence=7 ttl=255 time=32 ms
 Reply from 10.1.1.4: bytes=56 Sequence=8 ttl=255 time=32 ms
--- 10.1.1.4 ping statistics ---
 8 packet(s) transmitted
 8 packet(s) received
 0.00% packet loss
 round-trip min/avg/max = 32/32/32 ms
```

# Enable the device to send ICMP Echo Request messages with variable payload lengths.

```
<HUAWEI> ping -range min 56 max 60 192.168.1.9
PING 192.168.1.9: 56-60 data bytes, press CTRL_C to break
 Reply from 192.168.1.9: bytes=56 Sequence=1 ttl=255 time=80 ms
 Reply from 192.168.1.9: bytes=57 Sequence=2 ttl=255 time=60 ms
 Reply from 192.168.1.9: bytes=58 Sequence=3 ttl=255 time=80 ms
 Reply from 192.168.1.9: bytes=59 Sequence=4 ttl=255 time=80 ms
 Reply from 192.168.1.9: bytes=60 Sequence=5 ttl=255 time=50 ms
--- 192.168.1.9 ping statistics ---
 5 packet(s) transmitted
 5 packet(s) received
 0.00% packet loss
 round-trip min/avg/max = 50/70/80 ms
```

# Check whether the host at 10.1.1.10 is reachable.

```
<HUAWEI> ping 10.1.1.10
ping 10.1.1.10
PING 10.1.1.10: 56 data bytes, press CTRL_C to break
 Reply from 10.1.1.10: bytes=56 Sequence=1 ttl=128 time=1 ms
 Reply from 10.1.1.10: bytes=56 Sequence=1 ttl=64 time=1 ms (DUP!)
 Reply from 10.1.1.10: bytes=56 Sequence=2 ttl=128 time=1
ms
 Reply from 10.1.1.10: bytes=56 Sequence=2 ttl=64 time=1 ms
(DUP!)
 Reply from 10.1.1.10: bytes=56 Sequence=3 ttl=128 time=1 ms
 Reply from 10.1.1.10: bytes=56 Sequence=3 ttl=64 time=1 ms (DUP!)
 Reply from 10.1.1.10: bytes=56 Sequence=4 ttl=128 time=1
ms
 Reply from 10.1.1.10: bytes=56 Sequence=4 ttl=64 time=1 ms
(DUP!)
 Reply from 10.1.1.10: bytes=56 Sequence=5 ttl=128 time=1
ms
--- 10.1.1.10 ping statistics ---
 5 packet(s) transmitted
 9 packet(s) received
 4 duplicates
 -- somebody's printing up packets
 round-trip min/avg/max = 1/0/1 ms
```

**Table 16-80** Description of the ping command output

Item	Description
PING x.x.x.x	Reachability of the destination host with the IP address as x.x.x.x is tested.
x data bytes	Length of a sent ICMP Echo Request message.
press CTRL_C to break	The ongoing ping test is terminated after you press <b>Ctrl +C</b> .
Reply from x.x.x.x	<p>The destination host responds to the ICMP Echo Request message with an ICMP Echo Reply message that contains the following items:</p> <ul style="list-style-type: none"> <li>• bytes: indicates the length of the ICMP Echo Reply message.</li> <li>• Sequence: indicates the sequence number of the ICMP Echo Reply message.</li> <li>• ttl: indicate the TTL value of the ICMP Echo Reply message.</li> <li>• time: indicates the RTT, in milliseconds.</li> </ul> <p>If no ICMP Echo Reply message is received after the timeout period, the system displays "Request time out".</p> <p><b>NOTE</b> If a received packet ends with (DUP!), the device has received the Echo Reply messages with repeated sequence number.</p>
x.x.x.x ping statistics	<p>Statistics collected after the ping test on the destination host. The statistics include the following information:</p> <ul style="list-style-type: none"> <li>• packet(s) transmitted: indicates the number of sent ICMP Echo Request messages.</li> <li>• packet(s) received: indicates the number of received ICMP Echo Reply messages.</li> <li>• duplicates: indicates that the device has received the Echo Reply messages with repeated sequence number.</li> <li>• % packet loss: indicates the percentage of unresponded messages to total sent messages.</li> <li>• -- somebody's printing up packets: indicates that the number of received Echo Reply messages is larger than the number of send Echo Request messages.</li> <li>• round-trip min/avg/max: indicates the minimum, average, and maximum RTTs. The unit is ms. (On an IPv4 network, round-trip min/avg/max is not displayed if the ping fails. On an IPv6 network, round-trip min/avg/max = 0/0/0 ms is displayed if the ping fails.)</li> </ul>

## Related Topics

[16.12.3 ping ipv6](#)

[16.12.4 tracert](#)

[16.12.5 tracert ipv6](#)

## 16.12.3 ping ipv6

### Function

The **ping ipv6** command checks whether a specified IPv6 address is reachable and exports corresponding statistics.

### Format

```
ping ipv6 [ -a source-ipv6-address | -c count | -h ttl-value | -m time | -name | -s
packetsize | -t timeout | -tc traffic-class-value | vpn-instance vpn-instance-name ]
* host [ -i interface-type interface-number ]
```

#### NOTE

The **vpn-instance vpn-instance-name** command is supported only by the S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI.

### Parameters

Parameter	Description	Value
<b>-a</b> <i>source-ipv6-address</i>	Specifies a source IPv6 address for sending ICMPv6 Echo Request messages.  If no source IPv6 address is specified, the IPv6 address of the outbound interface is used as the source address for sending ICMPv6 Echo Request messages.	The value is a 32-digit hexadecimal number, in the format of X:X:X:X:X:X:X.
<b>-c</b> <i>count</i>	Specifies the number of times for sending ICMPv6 Echo Request messages.  You can increase the number of outgoing packets to detect the network quality based on the packet loss rate.	The value is an integer that ranges from 1 to 4294967295. The default value is 5.



Parameter	Description	Value
<b>-h</b> <i>ttl-value</i>	Specifies the TTL value.  If the TTL field is reduced to 0 during message forwarding, the Layer 3 switch that the message reaches sends an ICMPv6 timeout message to the source host, indicating that the destination host is unreachable.	The value is an integer that ranges from 1 to 255. The default value is 255.
<b>-m</b> <i>time</i>	Specifies the time to wait before sending the next ICMPv6 Echo Request message.  Each time the source sends an ICMPv6 Echo Request message using the <b>ping ipv6</b> command, the source waits a period of time (2000 ms by default) before sending the next ICMPv6 Echo Request message. You can set the time to wait before sending the next ICMPv6 Echo Request message using the parameter <i>time</i> . In the case of poor network condition, the value should be equal to or larger than 2000, in milliseconds.	The value is an integer that ranges from 1 to 10000, in milliseconds. The default value is 2000.
<b>-name</b>	Displays the name of the destination host.	-
<b>-s</b> <i>packetsize</i>	Specifies the length of an ICMPv6 Echo Request message, excluding the IP header and ICMPv6 header.	The value is an integer that ranges from 20 to 9600, in bytes. The default value is 56.

Parameter	Description	Value
<b>-t</b> <i>timeout</i>	<p>Specifies the timeout period to wait for an ICMPv6 Echo Reply message after an ICMPv6 Echo Request message is sent.</p> <p>After the <b>ping ipv6</b> command is run, the source sends an ICMPv6 Echo Request message to a destination and waits for an ICMPv6 Echo Reply message. If the destination, after receiving the ICMPv6 Echo Request message, returns an ICMPv6 Echo Reply message to the source within the period specified by the parameter <i>timeout</i>, the destination is reachable. If the destination does not return an ICMPv6 Echo Reply message within the specified period, the source displays that the message times out. Normally, the source receives an ICMPv6 Echo Reply message within 1 to 10 seconds after sending an ICMPv6 Echo Request message. If the transmission speed is low, properly prolong the timeout period.</p>	<p>The value is an integer that ranges from 0 to 65535, in milliseconds. The default value is 2000.</p>
<b>-tc</b> <i>traffic-class-value</i>	<p>Specifies the traffic classification in the ICMPv6 Echo Request message.</p> <p>To configure traffic control for ICMPv6 packets, set the parameter <i>traffic-class-value</i>.</p>	<p>The value is an integer that ranges from 0 to 255. The default value is 0.</p>
<b>vpn-instance</b> <i>vpn-instance-name</i>	<p>Specifies the name of a VPN instance for the IPv6 address family.</p>	<p>The value must be an existing VPN instance name.</p>
<i>host</i>	<p>Specifies the host name or IPv6 address of the destination host.</p>	<p>The value is a string of 1 to 255 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string. The IPv6 address is a 32-bit string in hexadecimal format, namely, the format X:X:X:X:X:X:X.</p>

Parameter	Description	Value
<b>-i</b> <i>interface-type interface-number</i>	Specifies the outbound interface for sending ICMPv6 Echo Request messages.	-

## Views

All views

## Default Level

0: Visit level

## Usage Guidelines

### Usage Scenario

The **ping ipv6** command is a widely used debugging tool for checking network connectivity and host reachability on an IPv6 network by transmitting ICMPv6 messages. It can detect the following items:

- Availability of the remote device
- Round-trip delay in communication between the local and remote devices
- Packet loss rate

You can run the **ping ipv6** command to check the IPv6 network connectivity or line quality in the following scenarios:

- Check the protocol stack on the local device. You can run the **ping ipv6 IPv6-loopback-address** command to check whether the TCP/IP protocol stack works properly on the local device.
- Check whether the destination IPv6 host is reachable on an IPv6 network. You can run the **ping ipv6 host** command to send an ICMPv6 Echo Request message to the destination host. If a reply is received, the destination host is reachable.
- Check whether the peer is reachable on a Layer 3 VPN. On a Layer 3 VPN, devices may not have routing information about each other. Therefore, you cannot use the **ping ipv6 host** command to check whether the peer is reachable. When a VPN instance name is specified, you can run the **ping ipv6 vpn-instance vpn-instance-name host** command to send an ICMPv6 Echo Request message to the peer. If the peer returns an ICMPv6 Echo Reply message, the peer is reachable.
- In the case of an unstable network, you can run the **ping ipv6 -c count -t timeout host** command to check the quality of the network between the local device and the peer. By analyzing the packet loss rate and average delay in the command output, you can evaluate the network quality. If the network is unreliable, set the packet transmission count (-c) and timeout (-t) to the upper limits. This makes the test result accurate.

### Prerequisites

- Before running the **ping ipv6** command, ensure that the ICMPv6 module is working properly.
- If **-vpn-instance** is specified, ensure that the VPN module is working properly.

#### Precautions

- If an intermediate device is disabled from responding to ICMPv6 messages, detection on this node fails.
- If the IPv6 address of the destination host maps the local address, specify the name of the local outbound interface through which the ICMPv6 Echo Request message is sent. Otherwise, reply to the **ping ipv6** command times out.
- When the destination host is unreachable, the system displays "Request time out" indicating that the ICMPv6 Echo Request message times out and displays statistics collected by the IPv6 ping test.
- If a fault occurs in the IPv6 ping process, you can press **Ctrl+C** to terminate the IPv6 ping operation.

## Example

# Check whether the host with the IPv6 address as FC00::1 is reachable.

```
<HUAWEI> ping ipv6 FC00::1
PING FC00::1 : 56 data bytes, press CTRL_C to break
  Reply from FC00::1:
    bytes=56 Sequence=1 hop limit=64 time=115 ms
  Reply from FC00::1:
    bytes=56 Sequence=2 hop limit=64 time=1 ms
  Reply from FC00::1:
    bytes=56 Sequence=3 hop limit=64 time=1 ms
  Reply from FC00::1:
    bytes=56 Sequence=4 hop limit=64 time=1 ms
  Reply from FC00::1:
    bytes=56 Sequence=5 hop limit=64 time=1 ms
---FC00::1 ping statistics---
 5 packet(s) transmitted
 5 packet(s) received
 0.00% packet loss
 round-trip min/avg/max=1/23/115 ms
```

**Table 16-81** Description of the ping ipv6 command output

Item	Description
PING HH:HH::HH:H	IPv6 address of the destination host.
x data bytes	Length of a sent ICMPv6 Echo Request message.
press CTRL_C to break	The ongoing IPv6 ping test is terminated after you press <b>Ctrl+C</b> .

Item	Description
Reply from HH:HH::HH:H	<p>The destination host responds to the ICMPv6 Echo Request message with an ICMPv6 Echo Reply message that contains the following items:</p> <ul style="list-style-type: none"> <li>• bytes: indicates the length of the ICMPv6 Echo Reply message.</li> <li>• sequence: indicates the sequence number of the ICMPv6 Echo Reply message.</li> <li>• hop limit: indicates the TTL of the ICMPv6 Echo Reply message.</li> <li>• time: indicates the RTT, in milliseconds.</li> </ul> <p>If no ICMPv6 Echo Reply message is received after the timeout period, the system displays "Request time out".</p>
HH:HH::HH:H ping statistics	<p>Statistics collected after the IPv6 ping test on the destination host. The statistics include the following information:</p> <ul style="list-style-type: none"> <li>• packet(s) transmitted: indicates the number of sent ICMPv6 Echo Request messages.</li> <li>• packet(s) received: indicates the number of received ICMPv6 Echo Reply messages.</li> <li>• % packet loss: indicates the percentage of unresponded messages to total sent messages.</li> <li>• round-trip min/avg/max: indicates the minimum, average, and maximum RTTs.</li> </ul>

## Related Topics

[16.12.5 tracert ipv6](#)

## 16.12.4 tracert

### Function

The **tracert** command checks the path of packets from the source to the destination, checks network connectivity, and locates a network fault.

### Format

```
tracert [ -a source-ip-address | -f first-ttl | -m max-ttl | -name | -p port | -q
nqueries | -v | -vpn-instance vpn-instance-name [ pipe ] | -w timeout | -s
packetsize ] * host
```

 NOTE

Only S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support **-vpn-instance** *vpn-instance-name*.

Only S5720EI, S5720HI, S6720EI, and S6720S-EI support **-v**.

## Parameters

Parameter	Description	Value
<b>-a</b> <i>source-ip-address</i>	Specifies the source address of a probe packet.  If this parameter is not specified, the IP address of the outbound interface is used as the source IP address for sending tracerp packets.	The value is in dotted decimal notation.
<b>-f</b> <i>first-ttl</i>	Specifies the initial TTL. The TTL field is carried in the IP header. It indicates the lifetime of packets and specifies the maximum hops that packets can pass through. The TTL value is set on the source and reduced by 1 each time the packet passes through a hop. When the TTL value is reduced to 0, the packet is discarded. At the same time, an ICMP Timeout message is sent to notify the source host. If <i>first-ttl</i> is specified and the number of hops is smaller than the value of <i>first-ttl</i> , no ICMP Timeout packet is sent to the source host when the packet passes through these hops. If <i>max-ttl</i> is specified, the value of <i>first-ttl</i> must be smaller than the value of <i>max-ttl</i> .	The value is an integer that ranges from 1 to 255. The default value is 1.
<b>-m</b> <i>max-ttl</i>	Specifies the maximum TTL. Usually, the maximum TTL is set to the number of hops the packet passes through. You need to use this parameter to change the TTL. If <i>first-ttl</i> is specified, the value of <i>max-ttl</i> must be greater than the value of <i>first-ttl</i> .	The value is an integer that ranges from 1 to 255. The default value is 30.
<b>-name</b>	Displays the host name of each hop.	-

Parameter	Description	Value
<b>-p</b> <i>port</i>	Specifies the UDP port number of the destination.  Before specifying the UDP port number of the destination, ensure that the port is not in use; otherwise, the tracert fails.	The value is an integer that ranges from 0 to 65535. The default value is 33434.
<b>-q</b> <i>nqueries</i>	Specifies the number of probe packets to be sent each time. In the case of poor network quality, you can set this parameter to a comparatively large value to ensure that the probe packet can reach the destination.	The value is an integer that ranges from 1 to 65535. The default value is 3.
<b>-v</b>	Displays the MPLS label carried in the ICMP Time Exceeded packet.	By default, the MPLS label carried in the ICMP Time Exceeded is not displayed. Instead, only the path information carried in the ICMP Time Exceeded and Port-Unreachable packets is displayed.
<b>-vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of the VPN instance to which the destination address belongs.	The value must be an existing VPN instance name.
<b>pipe</b>	Specifies the pipe mode. When a probe packet passes through the MPLS domain, the entire MPLS domain is considered as one hop and the IP TTL of the probe packet is reduced by one on the ingress node and egress node respectively.	-
<b>-w</b> <i>timeout</i>	Specifies the timeout period to wait for a reply. If a tracert packet times out when reaching a gateway, an asterisk (*) is displayed.  In the case of poor network quality and a low network transmission rate, you are advised to prolong the timeout period.	The value is an integer that ranges from 0 to 65535, in milliseconds. The default value is 5000.
<b>-s</b> <i>packetsize</i>	Specifies the length of an ICMP Echo Request message, excluding the IP header and ICMP header.	The value is an integer that ranges from 12 to 9600, in bytes. The default value is 12.

Parameter	Description	Value
<i>host</i>	Indicates the domain name or IPv4 address of the destination host.	The value is a string of 1 to 255 case-sensitive characters with spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string. Alternatively, the value can be a valid IPv4 address in dotted decimal notation.

## Views

All views

## Default Level

0: Visit level

## Usage Guidelines

### Usage Scenario

During routine system maintenance, you can run the **ping** command to check network connectivity. If the ping fails, run the **tracert** command to locate the fault on the network.

You can specify different parameters in the **tracert** command for different scenarios:

- To check information about nodes between the source and the destination, run the **tracert host** command.
- To check information about nodes between the source and the destination on a Layer 3 VPN, run the **tracert -vpn-instance vpn-instance-name host** command. On a Layer 3 VPN, devices may not have routing information about each other. Therefore, you cannot use the **tracert host** command to check whether the peer is reachable. To check information about nodes between the source and the destination in a specified VPN instance, run the **tracert -vpn-instance vpn-instance-name host** command.
- On an unstable network, you can run the **tracert -q nqueries -w timeout host** command to check information about nodes between the source and the destination. If the network is unreliable, set the packet transmission count (-q) and timeout (-w) to the upper limits. This makes the test result accurate.
- To check information about nodes along a segment of a path, run the **tracert -f first-ttl -m max-ttl host** command that has initial TTL and maximum TTL specified.

### Prerequisite



- The UDP module of each node is working properly; otherwise, the **tracert** operation fails.
- If **-vpn-instance** is specified, ensure that the VPN module of each node is working properly.
- The ICMP module of each node is working properly; otherwise, " \* \* \* " is displayed.

### Procedure

The execution process of the **tracert** command is as follows:

1. The source sends a packet with the TTL being 1. After the TTL times out, the first hop sends an ICMP Error message to the source, indicating that the packet cannot be forwarded.
2. The source sends a packet with the TTL being 2. After the TTL times out, the second hop sends an ICMP Error message to the source, indicating that the packet cannot be forwarded.
3. The source sends a packet with the TTL being 3. After the TTL times out, the third hop sends an ICMP Error message to the source, indicating that the packet cannot be forwarded.
4. The preceding process proceeds until the packet reaches the destination.

When receiving a packet, each destination hop cannot find the port specified in the packet, and returns an ICMP Port Unreachable message, indicating that the destination port is unreachable and the **tracert** ends. In this manner, the result of each probe is displayed on the source, according to which you can find the path from the source to the destination.

### Configuration Impact

If a fault occurs when you run the **tracert** command, the following information may be displayed:

- !H: The host is unreachable.
- !N: The network is unreachable.
- !: The port is unreachable.
- !P: The protocol type is incorrect.
- !F: The packet is incorrectly fragmented.
- !S: The source route is incorrect.

### Precautions

Once **-r** is specified, the outputs of both the **tracert** and **ping** commands show information about nodes between the source and the destination. Differences between the outputs of the **tracert** and **ping** commands are as follows:

- If the **ping** command times out on a transit node, a timeout packet is returned and the command output displays no path information.
- If the **tracert** command times out on a transit node, the command output displays " \* \* \* " indicating that the **tracert** times out on the node but the **tracert** is not interrupted.

## Example

# Tracert the gateways from the source host to the destination host with the IP address being 10.1.1.11.

```
<HUAWEI> tracert 10.1.1.11
traceroute to 10.1.1.11 (10.1.1.11), max hops: 30, packet length: 40, press CTRL_C to break
 1 10.3.112.1  10 ms 10 ms 10 ms
 2 10.32.216.1 19 ms 19 ms 19 ms
 3 * * *
 4 * * *
 5 * * *
 6 * * *
 7 10.1.1.11  339 ms 279 ms 279 ms
```

**Table 16-82** Description of the tracert command output

Item	Description
traceroute to	Tracert to a destination IP address.
max hops	Maximum TTL value.
packet length	Length of a sent packet.
10.3.112.1 10 ms 10 ms 10 ms	The integer 1 indicates the first hop gateway. Each hop increments the hop count. By default, the maximum hop count is 30. "10.3.112.1" is the gateway address of the first hop. The IPv4 address following the serial number of each hop is the gateway address of the hop. "10 ms 10 ms 10 ms" indicates the difference between the time when the three UDP packets are sent and when corresponding ICMP Time Exceeded or ICMP Port Unreachable messages are received. By default, each hop sends three UDP probe packets.
* * *	No ICMP Time Exceeded message or ICMP Port Unreachable message is returned within a specified period on the Nth hop. By default, an ICMP Time Exceeded message or ICMP Port-unreachable message should be returned within 5000 ms.

## Related Topics

[16.12.2 ping](#)

[16.12.3 ping ipv6](#)

[16.12.5 tracert ipv6](#)

## 16.12.5 tracer IPv6

### Function

The **tracer IPv6** command checks the path of packets from the source to the destination, checks IPv6 network connectivity, and locates a network fault.

### Format

```
tracer IPv6 [ -f first-hop-limit | -m max-hop-limit | -p port-number | -q probes | -w timeout | vpn-instance vpn-instance-name | -a source-IPv6-address | -s packet-size | -name | -v ] * host
```

#### NOTE

Only S1720GW, S1720GW-E, S1720GWR, S1720GWR-E, S1720X, S1720X-E, S2720EI, S5720LI, S5720S-LI, S5720SI, S5720S-SI, S5730SI, S5730S-EI, S5720EI, S5720HI, S6720LI, S6720S-LI, S6720SI, S6720S-SI, S6720EI, and S6720S-EI support **vpn-instance** *vpn-instance-name*, **-a** *source-IPv6-address*, **-s** *packet-size*, and **-name**.

Only S5720EI, S5720HI, S6720EI, and S6720S-EI support **-v**.

## Parameters

Parameter	Description	Value
<b>-f</b> <i>first-hop-limit</i>	<p>Specifies the initial hop-limit.</p> <p>Carried in the IPv6 header, the hop-limit (time to live) indicates the lifetime of IPv6 packets and specifies the maximum number of hops that the IPv6 packets can pass through. The hop-limit field in IPv6 packets is similar to the TTL field in the IPv4 packets. The hop-limit value is set on the source and reduced by 1 each time the packet passes through a Layer 3 device. When the hop-limit value is reduced to 0 on a Layer 3 device, the Layer 3 device discards the packet and sends an ICMPv6 Timeout message to the source.</p> <p>If <i>first-hop-limit</i> is specified and the number of hops is smaller than the specified value, the hop-limit value will be greater than 0 after the packet passes through all the nodes. Therefore, no ICMPv6 Timeout message is sent to the source.</p> <p>If <i>max-hop-limit</i> is specified, the value of <i>first-hop-limit</i> must be smaller than the value of <i>max-hop-limit</i>.</p>	<p>The value is an integer that ranges from 1 to 255. The default value is 1.</p>
<b>-m</b> <i>max-hop-limit</i>	<p>Specifies the maximum hop-limit.</p> <p>Usually, the maximum hop-limit is set to the number of hops that a packet passes through. To change the hop-limit value, you need to use this parameter.</p> <p>If <i>first-hop-limit</i> is specified, the value of <i>max-hop-limit</i> must be greater than the value of <i>first-hop-limit</i>.</p>	<p>The value is an integer that ranges from 1 to 255. The default value is 30.</p>

Parameter	Description	Value
<b>-p</b> <i>port-number</i>	<p>Specifies the UDP port number of the destination.</p> <ul style="list-style-type: none"> <li>If no UDP port number is specified for the destination, when you run the <b>tracert ipv6</b> command, a port with the port number greater than 32768 is randomly chosen for the destination to receive tracert packets.</li> <li>Before specifying the UDP port number for the destination, ensure that the port is not in use; otherwise, the tracert fails.</li> </ul>	The value is an integer that ranges from 1 to 65535. The default value is 33434.
<b>-q</b> <i>probes</i>	<p>Specifies the number of tracert packets sent each time.</p> <p>In the case of poor network quality, you can set <i>probes</i> to a comparatively large value to ensure that tracert packets can reach the destination.</p>	The value is an integer that ranges from 1 to 65535. The default value is 3.
<b>-w</b> <i>timeout</i>	<p>Sets the timeout period to wait for a reply.</p> <p>If a tracert packet times out when reaching a gateway, an asterisk (*) is displayed.</p> <p>In the case of poor network quality and a low network transmission rate, you are advised to prolong the timeout period.</p>	The value is an integer that ranges from 1 to 65535, in milliseconds. The default value is 5000.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of a VPN instance for the IPv6 address family.	The value must be an existing VPN instance name.
<b>-a</b> <i>source-ipv6-address</i>	<p>Specifies the source address of a tracert packet.</p> <p>If this parameter is not specified, the IP address of the outbound interface is used as the source IP address for sending tracert packets.</p>	The value is a 32-digit hexadecimal number, in the format of X:X:X:X:X:X.
<b>-s</b> <i>packetsize</i>	Specifies the length of an ICMPv6 Echo Request message, excluding the IP header and ICMPv6 header.	The value is an integer that ranges from 20 to 9600, in bytes. The default value is 56.
<b>-name</b>	Displays the name of the destination host.	-

Parameter	Description	Value
<b>-v</b>	Displays the MPLS label carried in the ICMP Time Exceeded packet.	By default, the MPLS label carried in the ICMP Time Exceeded is not displayed. Instead, only the path information carried in the ICMP Time Exceeded and Port-Unreachable packets is displayed.
<i>host</i>	Specifies the host name or IPv6 address of the destination host.	The value is a string of 1 to 255 case-sensitive characters, spaces not supported. When double quotation marks are used around the string, spaces are allowed in the string. The IPv6 address is a 32-bit string in hexadecimal format, namely, the format X:X:X:X:X:X:X.

## Views

All views

## Default Level

0: Visit level

## Usage Guidelines

### Usage Scenario

When a fault occurs on the network and the peer is an IPv6 device, you can run the **ping ipv6** command to check network connectivity based on the reply message, and then run the **tracert ipv6** command to locate the fault.

You can specify different parameters in the **tracert ipv6** command for different scenarios:

- To check information about nodes between the source and the IPv6 destination, run the **tracert ipv6 host** command.
- To check information about nodes between the source and the IPv6 destination on a Layer 3 VPN, run the **tracert ipv6 vpn-instance vpn-instance-name host** command. On a Layer 3 VPN, devices may not have routing information about each other. Therefore, you cannot use the **tracert ipv6 host** command to check whether the peer is reachable. To check information about nodes between the source and the IPv6 destination in a specified VPN instance, run the **tracert ipv6 vpn-instance vpn-instance-name host** command.

- On an unstable network, you can run the **tracert ipv6 -q probes -w timeout host** command to check information about nodes between the source and the IPv6 destination. If the network is unreliable, set the packet transmission count (-q) and timeout (-w) to the upper limits. This makes the test result accurate.
- To check information about nodes along a segment of a path, run the **tracert ipv6 -f first-hop-limit -m max-hop-limit host** command that has initial hop-limit and maximum hop-limit specified.

### Prerequisites

- The UDP module of each node is working properly; otherwise, the IPv6 tracert operation fails.
- The VPN module of each node is working properly if **vpn-instance** is specified.
- The ICMPv6 module of each node is working properly; otherwise, " \* \* \* " is displayed.

### Procedure

The execution process of the **tracert ipv6** command is as follows:

- The source sends a packet with the hop-limit being 1. After the hop-limit times out, the first hop sends an ICMPv6 Error message to the source, indicating that the packet cannot be forwarded.
- The source sends a packet with the hop-limit being 2. After the hop-limit times out, the second hop sends an ICMPv6 Error message to the source, indicating that the packet cannot be forwarded.
- The source sends a packet with the hop-limit being 3. After the hop-limit times out, the third hop sends an ICMPv6 Error message to the source, indicating that the packet cannot be forwarded.
- The preceding process proceeds until the packet reaches the destination.

When receiving an IPv6 packet, each destination hop cannot find the port specified in the IPv6 packet, and therefore returns an ICMPv6 Port Unreachable message, indicating that the destination port is unreachable and the IPv6 tracert ends. In this manner, the result of each probe is displayed on the source, according to which you can find the path from the source to the destination.

### Configuration Impact

If a fault occurs when you run the **tracert ipv6** command, the following information may be displayed:

- !H: The host is unreachable.
- !N: The network is unreachable.
- !: The port is unreachable.
- !P: The protocol type is incorrect.
- !F: The packet is incorrectly fragmented.
- !S: The source route is incorrect.

### Precautions

By default, the ICMPv6 module is automatically enabled after you enable the IPv6 module.

## Example

# Set the number of packets to be sent to 5 and timeout period to 8000 ms, and tracet the gateways from the source to the destination at FC00::3.

```
<HUAWEI> tracert ipv6 -q 5 -w 8000 FC00::3
tracert to FC00::3 30 hops max,60 bytes packet
1 FC00:1::3 26 ms 23 ms 26 ms 30 ms 29 ms
2 FC00::3 3020 ms 3024 ms 4040 ms 6820 ms 5584 ms
```

**Table 16-83** Description of the tracert ipv6 command output

Item	Description
tracert to HH:HH::HH:H	IPv6 address of the destination host.
x hops max	Maximum hop-limit value.
x bytes packet	Length of a tracert packet.
1 2	Sequence number of the received ICMPv6 Echo Reply message.
HH:HH::HH:H	Address of the ICMPv6 Echo Reply message.
26 ms 23 ms 26 ms 30 ms 29 ms	RTT, in milliseconds.

## Related Topics

[16.12.3 ping ipv6](#)

# 16.13 TWAMP Light Configuration Commands

[16.13.1 Command Support](#)

[16.13.2 display twamp-light responder test-session](#)

[16.13.3 nqa twamp-light](#)

[16.13.4 responder](#)

[16.13.5 test-session \(TWAMP-Light-Responder view\)](#)

## 16.13.1 Command Support

Huawei S series switches can only function as the Responders in the TWAMP Light system. And only the S5720EI, S5720HI, S6720EI, and S6720S-EI support this function.



## 16.13.2 display twamp-light responder test-session

### Function

The **display twamp-light responder test-session** command displays real-time measurement session information on the TWAMP Light Responder.

### Format

**display twamp-light responder test-session** [ **verbose** | *session-id* ]

### Parameters

Parameter	Description	Value
<b>verbose</b>	Displays details about all measurement sessions on the TWAMP Light Responder.	-
<i>session-id</i>	Displays details about the specified measurement session on the TWAMP Light Responder.	The value is an integer that ranges from 1 to 5.

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

After the performance measurement function is enabled, you can run this command to view measurement session information on the TWAMP Light Responder if you want to check the measurement session configuration or locate the fault in measurement.

### Example

# Display the summary of all measurement sessions.

```
<HUAWEI> display twamp-light responder test-session
Total number : 2
-----
ID   Local-IP   Local-Port  Remote-IP  Remote-Port
-----
 1   10.1.1.2   10000      10.2.2.2   20000
 2   10.1.1.3   10001      10.2.2.3   20001
```

# Display details about all measurement sessions.

```
<HUAWEI> display twamp-light responder test-session verbose
Session ID       : 1
Local IP         : 10.1.1.2
Local Port       : 10000
Remote IP        : 10.2.2.2
```

```

Remote Port      : 20000
Mode            : unauthenticated
VPN Instance    : test
Description     : -

Session ID      : 2
Local IP        : 10.1.1.3
Local Port      : 10001
Remote IP       : 10.2.2.3
Remote Port     : 20001
Mode           : unauthenticated
VPN Instance    : shuai
Description     : -
    
```

# Display details about the specified measurement session.

```

<HUAWEI> display twamp-light responder test-session 1
Session ID      : 1
Local IP        : 10.1.1.2
Local Port      : 10000
Remote IP       : 10.2.2.2
Remote Port     : 20000
Mode           : unauthenticated
VPN Instance    : test
Description     : -
    
```

**Table 16-84** Description of the **display twamp-light responder test-session** command output

Item	Description
Total number	Total number of sessions.
ID/Session ID	Session ID.
Local-IP/Local IP	IP address of the session Responder.
Local-Port/Local Port	UDP port number of the session Responder.
Remote-IP/Remote IP	IP address of the session Sender.
Remote-Port/Remote Port	UDP port number of the session Sender.
Mode	Authentication mode. The value <b>unauthenticated</b> indicates that authentication is disabled.
VPN Instance	VPN instance name. If the VPN instance name is not specified, the value of this field is empty.
Description	Session description.

## 16.13.3 nqa twamp-light

### Function

The **nqa twamp-light** command creates the TWAMP Light service and displays the TWAMP-Light view. If the TWAMP-Light service already exists, the TWAMP-Light view is directly displayed.

The **undo nqa twamp-light** command deletes the TWAMP Light service.

By default, the TWAMP Light service is not configured.

### Format

**nqa twamp-light**

**undo nqa twamp-light**

### Parameters

None

### Views

System view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

Using a simple structure of TWAMP, TWAMP Light lowers the requirements on the Responder . TWAMP Light measures bidirectional network performance between any nodes on the network. When the TWAMP Light service is required, run the **nqa twamp-light** command to create the TWAMP Light service.

#### Precautions

After you run the **undo nqa twamp-light** command, the device automatically deletes all TWAMP Light roles, sessions, and measurement services.

### Example

# Create the TWAMP Light service.

```
<HUAWEI> system-view  
[HUAWEI] nqa twamp-light  
[HUAWEI-twamp-light]
```

## 16.13.4 responder

### Function

The **responder** command enables the TWAMP Light Responder function and displays the TWAMP-Light-Responder view. If the Responder function has been enabled, the TWAMP-Light-Responder view is directly displayed.

The **undo responder** command disables the TWAMP Light Responder function.

By default, the TWAMP Light Responder function is disabled.

### Format

**responder**

**undo responder**

### Parameters

None

### Views

TWAMP-Light view

### Default Level

2: Configuration level

### Usage Guidelines

#### Usage Scenario

To use the TWAMP Light service, run the **Responder** command on the Responder to display the TWAMP-Light-Responder view and create a measurement session. Then the Controller starts the measurement service based on the session configuration.

#### Precautions

After the TWAMP Light Responder is deleted, the packet loss rate is displayed as 100%, which is inaccurate.

### Example

# Enable the TWAMP Light Responder function.

```
<HUAWEI> system-view  
[HUAWEI] nqa twamp-light  
[HUAWEI-twamp-light] responder  
[HUAWEI-twamp-light-responder]
```

## 16.13.5 test-session (TWAMP-Light-Responder view)

### Function

The **test-session** command creates a TWAMP Light measurement session on the Responder.

The **undo test-session** command deletes a TWAMP Light measurement session on the Responder.

By default, no TWAMP Light measurement session is created on the Responder.

### Format

**test-session** *session-id* **local-ip** *local-ip-address* **remote-ip** *remote-ip-address* **local-port** *local-port* **remote-port** *remote-port* [ **vpn-instance** *vpn-instance-name* ] [ **description** *description* ]

**undo test-session** *session-id* [ **local-ip** *local-ip-address* **remote-ip** *remote-ip-address* **local-port** *local-port* **remote-port** *remote-port* [ **vpn-instance** *vpn-instance-name* ] [ **description** *description* ] ]

### Parameters

Parameter	Description	Value
<i>session-id</i>	Specifies the ID of the measurement session.	The value is an integer that ranges from 1 to 5.
<b>local-ip</b> <i>local-ip-address</i>	Specifies the IP address of the Responder.	The value is in dotted decimal notation.
<b>remote-ip</b> <i>remote-ip-address</i>	Specifies the IP address of the Sender.	The value is in dotted decimal notation.
<b>local-port</b> <i>local-port</i>	Specifies the UDP port number of the Responder.	The value is 862, 863, or an integer that ranges from 1025 to 65535.
<b>remote-port</b> <i>remote-port</i>	Specifies the UDP port number of the Sender.	The value is 862, 863, or an integer that ranges from 1025 to 65535.
<b>vpn-instance</b> <i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The value must be the name of an existing VPN instance.
<b>description</b> <i>description</i>	Indicates the description of the specified measurement session. To configure description for a measurement session, specify the <b>description</b> parameter. The description facilitates session management and operation.	The value is a string of 3 to 32 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.

## Views

TWAMP-Light-Responder view

## Default Level

2: Configuration level

## Usage Guidelines

### Usage Scenario

After the TWAMP Light service is created, you need to create a TWAMP Light measurement session on the Responder and configure measurement instance information, including the Sender's IP address, Responder's IP address, Sender's UDP port number, Responder's UDP port number, and VPN instance name.

### Precautions

- A maximum of 5 measurement sessions can be created on a Responder.
- The created session starts measurement only when the measurement starts on the Controller.
- After a session is created, its parameters cannot be modified. To modify a session, delete it and create it again.
- The IP address must be a unicast address. By default, the DSCP field in a sent packet is 0 and the packet padding length is 128.
- The UDP port of the sender must be a port that is not occupied.
- The VPN instance must exist. When the VPN instance is deleted, the related measurement instance is also deleted.

## Example

# Create a TWAMP Light measurement session on the Responder.

```
<HUAWEI> system-view  
[HUAWEI] nqa twamp-light  
[HUAWEI-twamp-light] responder  
[HUAWEI-twamp-light-responder] test-session 1 local-ip 192.168.10.1 remote-ip 192.168.10.2 local-port  
3000 remote-port 3001
```

## 16.14 NETCONF Configuration Commands

[16.14.1 Command Support](#)

[16.14.2 callhome](#)

[16.14.3 display linux network status](#)

[16.14.4 display netconf all](#)

[16.14.5 ip address \(callhome template view\)](#)

[16.14.6 netconf](#)

[16.14.7 reset cloud-mng db-configuration](#)

[16.14.8 source ip](#)

[16.14.9 source ipv6-address](#)

## 16.14.1 Command Support

Only the S5720EI, S5720HI, S6720EI, and S6720S-EI support NETCONF.

## 16.14.2 callhome

### Function

The **callhome** command creates a callhome template and displays the callhome template view.

The **undo callhome** command deletes a callhome template.

By default, no callhome template exists on a switch.

### Format

**callhome** *callhome-name*

**undo callhome** *callhome-name*

### Parameters

Parameter	Description	Value
<i>callhome-name</i>	The name of a callhome template.	The value is a string of 1 to 31 case-sensitive characters without spaces. If the string is enclosed in double quotation marks (" "), the string can contain spaces.

### Views

NETCONF view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

If the NMS needs to configure and manage a switch in NETCONF over SSH Callhome mode, the switch actively sets up a NETCONF connection with the NMS. Run the **callhome** command to create a callhome template.

#### Follow-up Procedure

Run the [16.14.5 ip address \(callhome template view\)](#) command to configure the NMS IP address and port number.

### Precautions

Only one callhome template can be created on a switch. To create a new callhome template, delete the existing one by running the **undo callhome** *callhome-name* command. After this command is run, communication between the switch and NMS is interrupted.

### Example

# Create the callhome template **Huawei** and display the callhome template view.

```
<HUAWEI> system-view
[HUAWEI] netconf
[HUAWEI-netconf] callhome Huawei
[HUAWEI-netconf-callhome-Huawei]
```

## 16.14.3 display linux network status

### Function

The **display linux network status** command displays information of transport layer connections.

### Format

**display linux network status**

### Parameters

None

### Views

All views

### Default Level

1: Monitoring level

### Usage Guidelines

You can run the **display network status** command to view which transport-layer ports are in use. However, this command does not display the transport-layer ports used in NETCONF connections set up between the switch and remote device. To view these ports, run the **display linux network status** command.

### Example

# Display information of transport layer connections.

```
<HUAWEI> display linux network status
Active Internet connections (servers and established)
Proto Recv-Q Send-Q Local Address      Foreign Address    State
tcp    0    0 192.168.20.102:55800 192.168.10.7:55804 ESTABLISHED
tcp    0    0 192.168.20.103:55801 192.168.10.8:55805 ESTABLISHED
tcp    0    0 192.168.20.104:55803 192.168.10.9:55806 ESTABLISHED
```



**Table 16-85** Description of the **display linux network status** command output

Item	Description
Active Internet connections (servers and established)	Information of transport layer connections.
Proto	Transport layer protocol: <ul style="list-style-type: none"> <li>• tcp</li> <li>• udp</li> </ul>
Recv-Q	The count of bytes not copied by the user program connected to this socket.
Send-Q	The count of bytes not acknowledged by the remote host.
Local Address	IP address and TCP port used by the switch to set up a connection with the remote end.
Foreign Address	IP address and TCP port used by the remote end to set up a connection with the switch.
State	status of the connection: <ul style="list-style-type: none"> <li>• ESTABLISHED: The socket has an established connection.</li> <li>• SYN_SENT: The socket is actively attempting to establish a connection.</li> <li>• SYN_RECV: A connection request has been received from the network.</li> <li>• FIN_WAIT1: The socket is closed, and the connection is shutting down.</li> <li>• FIN_WAIT2: Connection is closed, and the socket is waiting for a shutdown from the remote end.</li> <li>• TIME_WAIT: The socket is waiting after close to handle packets still in the network.</li> <li>• CLOSE_WAIT: The remote end has shut down, waiting for the socket to close.</li> <li>• LAST_ACK: The remote end has shut down, and the socket is closed. Waiting for acknowledgement.</li> <li>• LISTEN: The socket is listening for incoming connections.</li> <li>• CLOSING: Both sockets are shut down but we still don't have all our data sent.</li> <li>• CLOSED: The socket is not being used.</li> </ul>

## 16.14.4 display netconf all

### Function

The **display netconf all** command displays the NETCONF configuration on a switch.

### Format

```
display netconf all
```

### Parameters

None

### Views

All views

### Default Level

3: Management level

### Usage Guidelines

To view the NETCONF configuration on a switch, run this command.

### Example

# View the NETCONF configuration on the switch.

```
<HUAWEI> display netconf all
Netconf status      : enable
Netconf src-ip      : 192.168.150.20
Netconf src-ipv6    : --
Netconf src-port    : 55555
Controller information:
No Mode   name                IP                Port Connected
-----
1 callhome -                  -                  -      N
2 ssh    -                  10.134.27.157    55555 Y
3 ssh    -                  -                  -      N
4 ssh    -                  -                  -      N
5 ssh    -                  -                  -      N
6 ssh    -                  -                  -      N
```

**Table 16-86** Description of the **display netconf all** command output

Item	Description
Netconf status	<p>Status of the NETCONF function:</p> <ul style="list-style-type: none"> <li>enable: The function is enabled.</li> <li>disable: The function is disabled.</li> </ul> <p>To configure the NETCONF function, run the <a href="#">16.14.6 netconf</a> command.</p>

Item	Description
Netconf src-ip	IPv4 address of the switch. To configure the IPv4 address of the switch, run the <a href="#">16.14.8 source ip</a> command.
Netconf src-ipv6	IPv6 address of the switch. To configure the IPv6 address of the switch, run the <a href="#">16.14.9 source ipv6-address</a> command.
Netconf src-port	<ul style="list-style-type: none"> <li>This parameter is the port number used by the switch in NETCONF over SSH Callhome mode.</li> <li>This parameter is the port number used by the switch and NMS in NETCONF over SSH mode.</li> </ul> To configure the port number, run the <a href="#">16.14.8 source ip</a> command.
Controller information	Information about the connected NMS.
No	Connection number.
Mode	NETCONF mode: <ul style="list-style-type: none"> <li>callhome: NETCONF over SSH Callhome</li> <li>ssh: NETCONF over SSH</li> </ul>
name	Name of a callhome template. This parameter is not supported in NETCONF over SSH mode and a hyphen (-) is displayed. To configure the name of a callhome template, run the <a href="#">16.14.2 callhome</a> command.
IP	IP address of the NMS. To configure the IP address of the NMS in NETCONF over SSH Callhome mode, run the <a href="#">16.14.5 ip address (callhome template view)</a> command.
Port	<ul style="list-style-type: none"> <li>This parameter is the port number used by the NMS in NETCONF over SSH Callhome mode. To configure the port number, run the <a href="#">16.14.5 ip address (callhome template view)</a> command.</li> <li>This parameter is the port number used by the switch and NMS in NETCONF over SSH mode. To configure the port number, run the <a href="#">16.14.8 source ip</a> command.</li> </ul>
Connected	Whether the NMS has set up a NETCONF connection with the switch: <ul style="list-style-type: none"> <li>Y: The NMS has set up a NETCONF connection with the switch.</li> <li>N: The NMS has not set up a NETCONF connection with the switch.</li> </ul>

## 16.14.5 ip address (callhome template view)

### Function

The **ip address** command configures the IP address and port number used by the NMS that communicates with a switch through NETCONF.

The **undo ip address** command deletes the IP address and port number used by the NMS that communicates with a switch through NETCONF.

By default, no IP address and port number used by the NMS that communicates with a switch through NETCONF is configured on a switch.

### Format

```
ip address ip-address port port-number  
undo ip address
```

### Parameters

Parameter	Description	Value
<i>ip-address</i>	The NMS IP address.	The value is in dotted decimal notation.
<b>port</b> <i>port-number</i>	The NMS port number.	The value is an integer that ranges from 0 to 65535.

### Views

Callhome template view

### Default Level

3: Management level

### Usage Guidelines

If the NMS needs to configure and manage a switch in NETCONF over SSH Callhome mode, the switch actively sets up a NETCONF connection with the NMS. Run the **ip address** command to configure the IP address and port number used by the NMS.

### Example

```
# Set the IP address and port number used by the NMS that communicates with  
the switch through NETCONF to 10.1.2.1 and 830, respectively.
```

```
<HUAWEI> system-view  
[HUAWEI] netconf
```

```
[HUAWEI-netconf] callhome Huawei  
[HUAWEI-netconf-callhome-Huawei] ip address 10.1.2.1 port 830
```

## 16.14.6 netconf

### Function

The **netconf** command enables the NETCONF function and displays the NETCONF view.

The **undo netconf** command disables NETCONF.

By default, NETCONF is disabled on a switch.

### Format

**netconf**

**undo netconf**

### Parameters

None

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario

If the NMS needs to configure and manage a switch using NETCONF, run the **netconf** command on the switch to enable the NETCONF function.

#### Precautions

After the **undo netconf** command is run, all NETCONF configurations on the switch are deleted and the communication between the switch and NMS is interrupted.

Before running the **netconf** command to enable the NETCONF function, ensure that port 830 and ports 55552 to 55807 are not in use. Otherwise, NETCONF cannot be enabled.

### Example

```
# Enable NETCONF and display the NETCONF view.
```

```
<HUAWEI> system-view  
[HUAWEI] netconf  
[HUAWEI-netconf]
```

## 16.14.7 reset cloud-mng db-configuration

### Function

The **reset cloud-mng db-configuration** command clears the database configuration.

### Format

**reset cloud-mng db-configuration**

### Parameters

None

### Views

System view

### Default Level

3: Management level

### Usage Guidelines

To stop providing network services, run the **reset cloud-mng db-configuration** command to clear all the database configuration.

---

#### NOTICE

After the **reset cloud-mng db-configuration** command is executed, the system asks whether you want to restart the switch. If you enter **Y**, the switch restarts and clears all the database configuration. Confirm your action.

---

### Example

```
# Clear the database configuration.
```

```
<HUAWEI> system-view  
[HUAWEI] reset cloud-mng db-configuration  
Warning: This operation will clear the database configuration and saved configuration file and restart the device. Continue? [Y/N]:
```

## 16.14.8 source ip

### Function

The **source ip** command configures the IP address and port number used by the switch to communicate with the NMS using NETCONF.

The **undo source ip** command deletes the IP address and port number used by the switch to communicate with the NMS using NETCONF.

By default, the IP address and port number used by a switch to communicate with the NMS using NETCONF are not configured.

## Format

**source ip** *ip-address* [ **port** *port-number* ]

**undo source ip**

## Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the IP address of a switch.	The value must be an existing IP address of a switch.
<b>port</b> <i>port-number</i>	<ul style="list-style-type: none"> <li>This parameter is the port number used by the switch in NETCONF over SSH Callhome mode.</li> <li>This parameter is the port number used by the switch and NMS in NETCONF over SSH mode.</li> </ul>	The value is 830 or an integer in the range 55552 to 55807. The default value is 830.

## Views

NETCONF view

## Default Level

3: Management level

## Usage Guidelines

### Usage Scenario

If the NMS needs to configure and manage a switch using NETCONF, run the **source ip** command to configure the IP address and port number used by the switch to communicate with the NMS in NETCONF over SSH or NETCONF over SSH Callhome mode.

### Precautions

When you run the **16.14.9 source ipv6-address** command to configure or change the port number for IPv6 communication between the switch and NMS, the port number for IPv4 communication between the two systems will be changed accordingly.

Changing the IPv4 address or port number will cause communication interruption between the switch and NMS.

## Example

# Set the IP address and port number used by the switch to communicate with the NMS using NETCONF to 10.1.1.1 and 55555, respectively.

```
<HUAWEI> system-view
[HUAWEI] netconf
[HUAWEI-netconf] source ip 10.1.1.1 port 55555
Warning: Changing the port number will tear down the SSH connection with the original port. Continue?
[Y/N]:y
```

## 16.14.9 source ipv6-address

### Function

The **source ipv6-address** command configures the IPv6 address and port number used by a switch to communicate with the NMS using NETCONF.

The **undo source ipv6-address** command deletes the IPv6 address and port number used by a switch to communicate with the NMS using NETCONF.

By default, the IPv6 address and port number used by a switch to communicate with the NMS using NETCONF are not configured.

### Format

**source ipv6-address** *ipv6-address* [ **port** *port-number* ]

**undo source ipv6-address**

### Parameters

Parameter	Description	Value
<i>ipv6-address</i>	Specifies the IPv6 address of a switch.	The value must be an existing IPv6 address of a switch.
<b>port</b> <i>port-number</i>	Specifies the port number used by the switch and NMS.	The value is 830 or an integer in the range 55552 to 55807. The default value is 830.

### Views

NETCONF view

### Default Level

3: Management level

### Usage Guidelines

#### Usage Scenario



If the NMS needs to configure and manage a switch using an IPv6 address in NETCONF over SSH mode, run the **source ipv6-address** command to configure the IPv6 address and port number of the switch.

### Precautions

When you run the **16.14.8 source ip** command to configure or change the port number for IPv4 communication between the switch and NMS, the port number for IPv6 communication between the two systems will be changed accordingly.

Changing the IPv6 address or port number will cause communication interruption between the switch and NMS.

## Example

# Set the IPv6 address and port number for the switch to communicate with the NMS using NETCONF to FC00::1 and 55555, respectively.

```
<HUAWEI> system-view
[HUAWEI] netconf
[HUAWEI-netconf] source ipv6-address FC00::1 port 55555
Warning: Changing the port number will tear down the SSH connection with the original port. Continue?
[Y/N]:y
```