

19 Upgrade-compatible Commands Reference

This chapter describes upgrade-compatible commands of each feature of all fixed switches. Upgrade-compatible commands are supported in earlier versions, but are deleted in the new version or have the command format changed. They exist to prevent configuration loss or impact on other configurations after the upgrade.

Due to version evolution, there may be changes on upgrade-compatible commands supported by some products. This chapter does not describe the differences.

Upgrade-compatible commands are classified into two types based on user operations:

- You can write these commands to the configuration file but cannot run them in the CLI after the device restarts.
- You can run these commands by entering commands in their complete format.

NOTE

You are not advised to use upgrade-compatible commands to perform operations on the device. If required, perform operations under the guidance of technical support personnel.

[19.1 Basic Configuration Compatible Commands](#)

[19.2 Device Management Compatible Commands](#)

[19.3 Interface Management Compatible Commands](#)

[19.4 Ethernet Switching Compatible Commands](#)

[19.5 IP Service Compatible Commands](#)

[19.6 IP Multicast Compatible Commands](#)

[19.7 MPLS compatible command](#)

[19.8 VPN compatible command](#)

[19.9 WLAN Compatible Commands](#)

[19.10 Reliability Compatible Commands](#)

[19.11 User Access and Authentication Compatible Commands](#)

[19.12 Security Compatible Commands](#)

[19.13 QoS Compatible Commands](#)

[19.14 Network Management Compatible Commands](#)

19.1 Basic Configuration Compatible Commands

19.1.1 set authentication password simple (upgrade-compatible command)

Function

The **set authentication password simple** command sets the simple format for a local authentication password.

Format

set authentication password simple *password*

Parameters

Parameter	Description	Value
<i>password</i>	Specifies a password.	The value is a string of 1 to 16 characters. The password must contain at least two of the following characters: upper-case character, lower-case character, digit, and special character. Special character except the question mark (?) and space.

Views

User view

Default Level

3: Management level

Task Name and Operations

Task Name	Operations
telnet-server	write

Usage Guidelines

It is replaced by the **set authentication password** command.

This command is saved in simple text after it is configured, which brings security risks. Saving the command configuration in ciphertext is recommended.

19.1.2 certificate load (upgrade-compatible command)

Function

The **certificate load** command loads a digital certificate in the Secure Sockets Layer (SSL) policy view.

The **undo certificate load** command unloads a digital certificate for the SSL policy.

By default, no digital certificate is loaded for the SSL policy.

Format

Load a PEM digital certificate for the SSL policy.

certificate load pem-cert *cert-filename* **key-pair** { **dsa** | **rsa** } **key-file** *key-filename* **auth-code** *auth-code*

Load a PFX digital certificate for the SSL policy.

certificate load pfx-cert *cert-filename* **key-pair** { **dsa** | **rsa** } { **mac** *mac-code* | **key-file** *key-filename* } **auth-code** *auth-code*

Load a PEM certificate chain for the SSL policy.

certificate load pem-chain *cert-filename* **key-pair** { **dsa** | **rsa** } **key-file** *key-filename* **auth-code** *auth-code*

Parameters

Parameter	Description	Value
pem-cert	Loads a PEM digital certificate for the SSL policy. A PEM digital certificate has a file name extension .pem. A PEM digital certificate transfers text data between systems.	-

Parameter	Description	Value
<i>cert-filename</i>	Specifies the name of a certificate file. The file is in the subdirectory of the system directory security . If the security directory does not exist in the system, create this directory.	The value is a string of 1 to 64 characters. The file name is the same as that of the uploaded file.
key-pair	Specifies the key pair type.	-
dsa	Sets the key pair type to DSA.	-
rsa	Sets the key pair type to RSA.	-
key-file <i>key-filename</i>	Specifies the key pair file. The file is in the subdirectory of the system directory security . If the security directory does not exist in the system, create this directory.	The value is a string of 1 to 64 characters. The file name is the same as that of the uploaded file.
auth-code <i>auth-code</i>	Specifies the authentication code of the key pair file. The authentication code verifies user identity to ensure that only authorized clients access the server.	When the authentication code is in plain text, the value is a string of 1 to 31 case-sensitive characters without any space.
pfx-cert	Loads a PFX digital certificate for the SSL policy. A PFX digital certificate has a file name extension .pfx. A digital certificate can be converted from the PFX format to another format.	-
mac <i>mac-code</i>	Specifies a message authentication code. The message authentication code ensures the packet data reliability and security.	When the authentication code is in plain text, the value is a string of 1 to 31 case-sensitive characters without any space.
pem-chain	Specifies a PEM certificate chain.	-

Views

SSL policy view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

SSL security mechanism includes:

- Data transmission security: Uses the symmetric key algorithm to encrypt data.
- Message integrity: uses the multiplexed analog component (MAC) algorithm to ensure message integrity.
- Identity authentication mechanism: authenticates users based on the digital signatures and certificates.

The Certificate Authority (CA) issues PEM, ASN1, and PFX digital certificates that provide user identity information. Based on digital certificates, users establish trust relationships with partners who require high security.

A digital certificate data includes the applicant information such as the applicant's name, applicant's public key, digital signature of the CA that issues the certificate, and the certificate validity period. A certificate chain can be released when a certificate is sent so that the receiver can have all certificates in the certificate chain.

Prerequisites

Before running the **certificate load** command, you have run the **ssl policy** command to create the SSL policy in the system view.

Precautions

- You can load a certificate or certificate chain for only one SSL policy. Before loading a certificate or certificate chain, you must unload the existing certificate or certificate chain.
- When you configure an SSL policy to load a certificate or certificate chain, ensure that the maximum length of the key pair in the certificate or certificate chain is 2048 bits. If the length of the key pair exceeds 2048 bits, the certificate file or certificate chain file cannot be uploaded to the device.

Example

Load a PEM digital certificate for the SSL policy.

```
<HUAWEI> system-view
[HUAWEI] ssl policy ftp_server
[HUAWEI-ssl-policy-ftp_server] certificate load pem-cert servercert.pem key-pair dsa key-file
serverkey.pem auth-code YsHsjx_202206
```

Load a PFX digital certificate for the SSL policy.

```
<HUAWEI> system-view
[HUAWEI] ssl policy http_server
[HUAWEI-ssl-policy-http_server] certificate load pfx-cert servercert.pfx key-pair dsa key-file
serverkey.pfx auth-code %$%$"DlqKik*GE*~`u4H+LFJ(K=%$%$
```

Load a PEM certificate chain for the SSL policy.

```
<HUAWEI> system-view
```

```
[HUAWEI] ssl policy http_server  
[HUAWEI-ssl-policy-http_server] certificate load pem-chain chain-servercert.pem key-pair dsa key-file  
chain-servercertkey.pem auth-code YsHsjx_202206
```

19.1.3 set device usb-deployment password (upgrade-compatible command)

Function

The **set device usb-deployment password** command sets an authentication password for USB-based deployment.

Format

```
set device usb-deployment password password
```

Parameters

Parameter	Description	Value
<i>password</i>	Specifies the authentication password for USB-based deployment.	-

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

A user with a level lower than the management level cannot query the password configured using this command. If this user query the configuration file, the password is displayed as asterisks (*****).

19.1.4 set save-configuration backup-to-server server (upgrade-compatible command)

Function

The **set save-configuration backup-to-server server** command specifies the server where the system periodically saves the configuration file.

The **undo set save-configuration backup-to-server server** command cancels the server where the system periodically saves the configuration file.

By default, the system does not periodically save configurations to the server.

Format

set save-configuration backup-to-server server *server-ip* [**transport-type** { **ftp** | **sftp** }] **path** *path* **user** *user-name* **password** *password*

set save-configuration backup-to-server server *server-ip* **user** *user-name* **password** *password* [**path** *path*]

undo set save-configuration backup-to-server server [*server-ip*]

Parameters

Parameter	Description	Value
server <i>server-ip</i>	Specifies the IP address of the server where the system periodically saves the configuration file.	-
transport-type	Specifies the mode in which the configuration file is transmitted to the server.	The value can be ftp or sftp .
user <i>user-name</i>	Specifies the name of the user who saves the configuration file on the server.	The value is a string of 1 to 64 case-sensitive characters without spaces.
password <i>password</i>	Specifies the password of the user who saves the configuration file on the server.	The value is a string of 1 to 16 or 32 case-sensitive characters without spaces.
path <i>path</i>	Specifies the relative save path on the server.	The value is a string of 1 to 64 case-sensitive characters without spaces.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

Run this command to periodically save the configuration file to the server.

Precautions

If the mode in which the configuration file is transmitted to the server is not specified, FTP is used.

If the specified path on the server does not exist, configuration files cannot be sent to the server. The system then sends an alarm message indicating the

transmission failure to the NMS, and the transmission failure is recorded as a log message on the device.

The user name and password must be the same as those used in FTP or SFTP login mode.

Example

Specify the server to which the system periodically sends the configuration file, and set the transmission mode to FTP.

```
<HUAWEI> system-view  
[HUAWEI] set save-configuration backup-to-server server 10.1.1.1 transport-type ftp path d:/ftp user  
huawei password huawei@1234
```

19.1.5 set save-configuration (upgrade-compatible command)

Function

Using the **set save-configuration** command, you can enable automatic saving of configurations.

Using the **undo set save-configuration** command, you can disable automatic saving of configurations.

By default, automatic saving of configurations is not enabled.

Format

set save-configuration nochange-time *nochange-time*

undo set save-configuration nochange-time [*nochange-time*]

Parameters

Parameter	Description	Value
nochange-time <i>nochange-time</i>	Specifies a period and configures the system to automatically save configurations if no configurations are changed over the specified period.	The value is an integer ranging from 30 to 43200, in minutes. The default value is 30.

Views

System view

Default Level

3: Management level

Usage Guidelines

If **nochange-time** *nochange-time* is specified in the command, the system automatically saves configurations if no configuration changes in the period specified by *nochange-time*.

If the interval from the time of the last configuration to the current time is shorter than the set interval, the system cancels the current automatic saving operation.

Example

Configure the system to automatically save configurations at 60-minute intervals if no configuration changes in the period.

```
<HUAWEI> system-view  
[HUAWEI] set save-configuration nochange-time 60
```

19.1.6 smart-upgrade information (upgrade-compatible command)

Function

The **smart-upgrade information** command sets the contact phone number and email address for smart upgrade.

The **undo smart-upgrade information** command deletes the configured contact number and email address for smart upgrade.

By default, no contact phone number or email address is configured for smart upgrade.

Format

smart-upgrade information telephone *phonevalue* **email** *emailvalue*

undo smart-upgrade information telephone

Parameters

Parameter	Description	Value
<i>phonevalue</i>	Specifies a mobile phone number.	The value is a string of 1 to 21 characters. The value can contain the plus sign (+) and digits (0 to 9), and cannot contain spaces. The plus sign (+) can be used only at the beginning of a character string. If a character string starts with a plus sign (+), the maximum string length is 21. If a character string starts with a digit, the maximum string length is 20.

Parameter	Description	Value
<i>emailvalue</i>	Specifies the email address.	The value is a string of 1 to 128 case-sensitive characters. The following characters are supported: letters, digits, apostrophes ('), equal signs (=), parentheses (), plus signs (+), minus signs (-), periods (.), slashes (/), colons (:), at signs (@), and underscore (_).

Views

System view

Default Level

3: Management level

Usage Guidelines

If smart upgrade fails on a switch, the switch can notify the user of the upgrade result based on the contact phone number and email address provided by the user.

NOTE

The contact information is used only for emergency contact upon an upgrade failure.

Example

Set the contact phone number and email address for smart upgrade.

```
<HUAWEI> system-view  
[HUAWEI] smart-upgrade information telephone 11111111 email abcd@huawei.com  
Privacy Policy
```

Your privacy is important to us.

When enabling the automatic upgrade function for Huawei devices, you may, at your discretion, provide your personal information such as the telephone number, mobile number, and email address on the Command Line Interface (CLI).

This information will be used to notify you immediately of the upgrade result after the automatic upgrade function is enabled.

By agreeing to these terms and conditions, you are authorizing Huawei to collect and process the aforementioned personal information provided by you for the stated purpose.

Your information may be transferred to a third party of Huawei or affiliated company of Huawei for the purpose of providing the aforementioned service for you.

The information you provide will be stored on the servers of Huawei and its affiliates.

The information may be transmitted outside your country or region and accessed, stored, and processed in another country or region, including China.

Huawei is committed to protecting your personal information and preventing the information from being used without authorization.

For more details, please refer to the full privacy policy at <https://www.huawei.com/en/privacy-policy>.

Do you agree to these terms and conditions? [Y/N]:y

Info: Set the phone and email successfully.

19.1.7 snmp-agent trap enable configuration (upgrade-compatible command)

Function

The **snmp-agent trap enable configuration** command enables the trap function of the Configuration module.

By default, the trap function of the Configuration module is disabled.

Format

snmp-agent trap enable configuration

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **snmp-agent trap enable feature-name configuration** command.

19.1.8 snmp-agent trap enable ssh (upgrade-compatible command)

Function

The **snmp-agent trap enable ssh** command enables the trap function of the SSH module.

By default, the alarm function of the SSH module is disabled.

Format

snmp-agent trap enable ssh

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.1.9 snmp-agent trap enable system (upgrade-compatible command)

Function

The **snmp-agent trap enable system** command enables the trap function of the system module.

By default, the trap function of the system module is enabled.

Format

snmp-agent trap enable system

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **snmp-agent trap enable feature-name system** command.

19.1.10 snmp-agent trap enable flash (upgrade-compatible command)

Function

The **snmp-agent trap enable flash** command enables the trap function of the flash module.

By default, the trap function of the flash module is disabled.

Format

snmp-agent trap enable flash

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **snmp-agent trap enable feature-name vfs { hwflhopernotification | hwflsyncfailnotification | hwflsyncsuccessnotification }** command.

19.1.11 super password (upgrade-compatible command)

Function

The **super password** command sets the password used to change a user from a lower level to a higher level.

By default, the system does not set the password used to change a user from a lower level to a higher level.

Format

super password [*level user-level*] **simple** *simple-password*

Parameters

Parameter	Description	Value
level <i>user-level</i>	Specifies a user level.	The value is an integer that ranges from 1 to 15. By default, the system sets passwords for users of level 3.
simple <i>simple-password</i>	Specifies the simple password for changing a user level.	The value is a string of 1 to 16 case-sensitive characters.

Views

System view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

The device makes it possible to switch a user from a lower level to a higher level. To prevent illegal intrusion of unauthorized users, when a user switches to a higher user level, the system authenticates the user identity by requiring the user to input the password for the higher user level.

- If the **cipher** *cipher-password* parameter is not specified, the system starts the interactive password setting mode. Enter a plain text password of 6 to 16 characters. The requirements for the password are the same as the requirements for the plain text password configured when the **cipher** keyword is specified. The password you enter will not be displayed on the device. You can press **CTRL_C** to cancel the password setting.
- The password is in plain or cipher text and displayed on the device when the **cipher** *cipher-password* parameter is specified. When you run the **super** command to switch the user level, the password must be entered in plain text.
- Whether the password is entered in **cipher** or interactive mode, the password is saved in cipher text to the configuration file. Therefore, the password cannot be obtained from the system after it is set. Keep the password secure.
- This command is saved in simple text after it is configured, which brings security risks. Saving the command configuration in ciphertext is recommended.

Example

```
# Set the password used when low-level users switch to level 10 to YsHsjx_202206.
```

```
<HUAWEI> system-view  
[HUAWEI] super password level 10 simple YsHsjx_202206
```

19.1.12 trusted-ca load (upgrade-compatible command)

Function

The **trusted-ca load** command loads the trusted CA file for the SSL policy for the FTP client.

By default, no trusted CA file is loaded for the SSL policy.

Format

Load the trusted CA file for the SSL policy in PFX format.

```
trusted-ca load pfx-ca ca-filename auth-code { auth-code | cipher auth-code }
```

Parameters

Parameter	Description	Value
pfx-ca	Load the trusted CA file for the SSL policy in PFX format.	-
<i>ca-filename</i>	Specifies the name of the trusted CA file. The file is in the subdirectory of the system directory security . If the security directory does not exist in the system, create this directory.	The value is a string of 1 to 64 characters. The file name is the same as that of the uploaded file.
auth-code <i>auth-code</i>	Specifies the verification code for the trusted CA file in PFX format. The authentication code verifies user identity to ensure that only authorized users can log in to the server.	When the authentication code is in plain text, the value is a string of 1 to 31 case-sensitive characters without any space.

Views

SSL policy view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

CAs that are widely trusted in the world are called root CAs. Root CAs can authorize other lower-level CAs. The identity information about a CA is provided in the file of a trusted CA. To ensure the communication security and verify the server validity, you must run the **trusted-ca load** command to load the trusted CA file.

Prerequisites

Before running the **trusted-ca load** command, you have run the **ssl policy** command to create the SSL policy in the system view.

Precautions

A maximum of four trusted CA files can be loaded for an SSL policy.

Example

```
# Load the trusted CA file for the SSL policy in PFX format.
```

```
<HUAWEI> system-view  
[HUAWEI] ssl policy ftp_server  
[HUAWEI-ssl-policy-ftp_server] trusted-ca load pfx-ca servercert.pfx auth-code cipher 123456
```

19.2 Device Management Compatible Commands

19.2.1 cpu-usage threshold (upgrade-compatible command)

Function

The **cpu-usage threshold** command sets the upper and lower CPU usage alarm thresholds.

Format

```
cpu-usage threshold [ unit unit-id ] { high | low } threshold-value
```

Parameters

Parameter	Description	Value
high	Specifies the upper CPU usage alarm threshold.	-
low	Specifies the lower CPU usage alarm threshold.	-
unit <i>unit-id</i>	<ul style="list-style-type: none">Specifies the slot ID if stacking is not configured.Specifies the stack ID if stacking is configured.	The value range depends on the device configuration.

Parameter	Description	Value
<i>threshold-value</i>	Specifies the alarm threshold of CPU usage.	<ul style="list-style-type: none">• The value is an integer that ranges from 2 to 100 when specifies the upper CPU usage alarm threshold.• The value is an integer that ranges from 1 to 99 when specifies the lower CPU usage alarm threshold.

Views

System view

Default Level

3: Management level

Usage Guidelines

When the CPU usage is not within the allowed range, a log is recorded. You can conveniently know CPU usage through log information.

19.2.2 display autosave config (upgrade-compatible command)

Function

The **display autosave config** command displays the configuration about the autosave function, including the status of the autosave function, time for autosave check, threshold of the CPU usage, and interval during which configurations are not changed.

Format

display autosave config

Parameters

None

Views

All views

Default Level

3: Management level

Usage Guidelines

After the autosave function is configured, you can run the **display autosave config** command to check whether the configured parameters are correct. You can also run this command to check whether the parameters about the autosave function are properly configured when autosave cannot function normally. If not, run the **set save-configuration** command to adjust the parameters to restore the normal state of the autosave function.

Example

Display the configuration about the autosave function.

```
<HUAWEI> display autosave config
Auto save function status: enable
Auto save checking interval: 60 minutes
The threshold of the CPU usage: 50%
The interval of the configuration not changing: 30 minutes
```

Table 19-1 Description of the display autosave config command output

Item	Description
Auto save function status	Indicates the status of the autosave function: <ul style="list-style-type: none">• Enable• Disable
Auto save checking interval	Indicates the time for autosave check.
The threshold of the CPU usage	Indicates the threshold of the CPU usage during the autosave operation.
The interval of the configuration not changing	Indicates the interval during which system configurations are not changed.

19.2.3 display fault-management (upgrade-compatible command)

Function

The **display fault-management** command displays the contents of an alarm message, active alarm message, or event.

Format

```
display fault-management { alarm | active-alarm | event } [ sequence-number sequence-number ]
```

Parameters

Parameter	Description	Value
alarm	Displays information about alarms.	-
active-alarm	Displays information about active alarms.	-
event	Displays information about events.	-
sequence-number <i>sequence-number</i>	Specifies the number of an alarm message, active alarm message, or event.	The value is an integer ranging from 0 to 2147483647. When the value is 0, information about all alarm messages, active messages, or events is displayed.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

This command helps you obtain the contents of all alarm messages or one alarm message on a device.

Example

Display the contents of active alarm messages in the system.

```
<HUAWEI> display fault-management active-alarm
A/B/C/D/E/F/G/H/I/J
A=Sequence, B=RootKindFlag(Independent|RootCause|nonRootCause)
C=Generating time, D=Clearing time
E=ID, F=Name, G=Level, H=State
I=Description information for locating(Para info, Reason info)
J=RootCause alarm sequence(Only for nonRootCause alarm)

 1/Independent/2008-10-13 01:49:45+08:00/-/0x41932001/hwLldpEnabled/Warning/Start/OID: 1.3.6.1.4.1.2011.5.25.134.2.1 Global LLDP is enabled.
 2/Independent/2008-10-13 01:50:06+08:00/-/0x41932000/ldpRemTablesChange/Warning/Start/OID: 1.0.8802.1.1.2.0.0.1 Neighbor information is changed. (LldpStatsRemTablesInserts=1, LldpStatsRemTablesDeletes=0, LldpStatsRemTablesDrops=0, LldpStatsRemTablesAgeouts=0)
 5/Independent/2008-10-13 02:22:52+08:00/-/0x40c12014/hwPortPhysicalEthHalfDuplexAlarm/Minor/Start/OID 1.3.6.1.4.1.2011.5.25.129.2.5.11 The port works in half duplex mode. (EntityPhysicalIndex=10, BaseTrapSeverity=3, BaseTrapProbableCause=1024, BaseTrapEventType=8, EntPhysicalName=GigabitEthernet0/0/5, RelativeResource=interface GigabitEthernet0/0/5)
```

19.2.4 display fault-management alarm information (upgrade-compatible command)

Function

The **display fault-management alarm information** command displays registration information about an alarm message.

Format

display fault-management alarm information [*alarm-name*]

Parameters

Parameter	Description	Value
<i>alarm-name</i>	Specifies the name of an alarm message.	The value is a case-sensitive string of 1 to 256 characters without spaces.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

None

Example

Check registration information about the alarm message named linkUp.

```
<HUAWEI> display fault-management alarm information linkUp
*****
AlarmName: linkUp
AlarmType: Resume Alarm
AlarmLevel: Cleared
Suppress Period: NA
CauseAlarmName: linkDown
Match VB Name: ifIndex
*****
```

Table 19-2 Description of the display fault-management alarm information command output

Item	Description
AlarmName	Name of an alarm message
AlarmType	Type of an alarm

Item	Description
AlarmLevel	Level of an alarm
Suppress Period	Suppress period of an alarm
CauseAlarmName	Name of the corresponding root alarm
Match VB Name	Contents of the matching rule set for the alarm messages

19.2.5 dual-active detect mode direct (upgrade-compatible command)

Function

The **dual-active detect mode direct** command enables DAD in direct mode on a specified interface.

By default, DAD is disabled on an interface in a stack.

Format

dual-active detect mode direct

Parameters

None

Views

GE interface view, XGE interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

DAD in direct mode applies to a stack containing two DAD-supporting member switches.

Prerequisites

The stack containing two member switches is running properly, and DAD in relay mode is not configured for the stack.

Precautions

Disabling DAD in direct mode on an interface restores the forwarding function on the interface. If a loop exists on the network, a broadcast storm occurs.

The **dual-active detect mode direct** command performs the same function as the **mad detect mode direct** command.

Example

```
# Configure DAD in direct mode on GigabitEthernet1/0/1.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 1/0/1  
[HUAWEI-GigabitEthernet1/0/1] dual-active detect mode direct  
Warning: This command will block the port, and no other configuration running on this port is  
recommended. Continue?[Y/N]:y
```

19.2.6 dual-active detect mode relay (upgrade-compatible command)

Function

The **dual-active detect mode relay** command enables DAD in relay mode on a specified interface.

By default, DAD is disabled on an interface in a stack.

Format

dual-active detect mode relay

Parameters

None

Views

Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

You can configure DAD in relay mode only when a stack containing two member switches is configured with an inter-chassis Eth-Trunk and a proxy device supports the relay function.

Prerequisites

The stack containing two member switches is running properly, and DAD in direct mode is not configured for the stack.

Precautions

The **dual-active detect mode relay** command performs the same function as the **mad detect mode relay** command.

Example

```
# Configure DAD in relay mode on Eth-Trunk 10.
```

```
<HUAWEI> system-view  
[HUAWEI] interface eth-trunk 10  
[HUAWEI-Eth-Trunk10] dual-active detect mode relay
```

19.2.7 dual-active exclude (upgrade-compatible command)

Function

The **dual-active exclude** command excludes specified interfaces of a stack from shutdown.

By default, only physical member ports are excluded from shutdown.

Format

dual-active exclude interface { *interface-type interface-number1* [**to** *interface-type interface-number2*] } &<1-10>

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-type interface-number2</i>] }	Specifies the type and number of an interface: <ul style="list-style-type: none">• <i>interface-type</i> specifies the type of the interface.• <i>interface-number1</i> specifies the number of the first interface.• <i>interface-number2</i> specifies the number of the second interface.	The value of <i>interface-number2</i> must be larger than that of <i>interface-number1</i> .

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **mad exclude** command.

19.2.8 dual-active relay (upgrade-compatible command)

Function

The **dual-active relay** command enables the relay function on a specified interface of a proxy device.

By default, the relay function is disabled on an interface.

Format

dual-active relay

Parameters

None

Views

Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

In DAD in relay mode, you need to use the **dual-active relay** command to configure the relay function on a specified Eth-Trunk interface of a proxy device. Member interfaces of the Eth-Trunk interface forward DAD packets to each other so that member switches can exchange DAD packets.

It is replaced by the **mad relay** command.

Example

Enable the relay function on Eth-Trunk 10 of a proxy device.

```
<HUAWEI> system-view  
[HUAWEI] interface eth-trunk 10  
[HUAWEI-Eth-Trunk10] dual-active relay
```

19.2.9 dual-active restore (upgrade-compatible command)

Function

The **dual-active restore** command restores the blocked interfaces of the standby switch that enters the Recovery state after its stack splits.

Format

dual-active restore

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After a stack splits, if the active switch fails, you can restore the blocked interfaces of the standby switch that enters the Recovery state to make the standby switch to take over the active role.

Precautions

When the active switch is working properly, do not use this command. Otherwise, DAD detects a dual-active scenario again and blocks all service interfaces, causing interface status flapping.

It is replaced by the **mad restore** command.

Example

Restore all the blocked interfaces of the standby switch that enters the Recovery state after its stack splits.

```
<HUAWEI> system-view  
[HUAWEI] dual-active restore
```

19.2.10 fault-management alarm (upgrade-compatible command)

Function

The **fault-management alarm** command configures the type or severity of an alarm message or event.

The **undo fault-management alarm** command cancels the type or severity of an alarm message or event.

Format

fault-management alarm *alarm-name* **level** *alarm-level*

undo fault-management alarm *alarm-name* [**level**]

Parameters

Parameter	Description	Value
alarm <i>alarm-name</i>	Specifies the name of an alarm message or event.	The value is a case-sensitive string of 1 to 64 characters without spaces.

Parameter	Description	Value
level <i>alarm-level</i>	Specifies the severity of an alarm message or event: <ol style="list-style-type: none"> 1. Critical: indicates that a service affecting condition has occurred and an immediate corrective action is required. Such a severity can be reported. For example, when a managed object becomes totally out of service, its capability must be restored. 2. Major: indicates that a service affecting condition has developed and an urgent corrective action is required. Such a severity can be reported. For example, when there is a severe degradation in the capability of a managed object, its full capability must be restored. 3. Minor: indicates the existence of a non-service affecting fault condition and that corrective action should be taken in order to prevent a more serious (for example, service affecting) fault. Such a severity can be reported. For example, when the detected alarm condition is not currently degrading the capacity of the managed object. 4. Warning: indicates the detection of a potential or impending service affecting fault, before any significant effects have been felt. Action should be taken to further diagnose (if necessary) and correct the problem in order to prevent it from becoming a more serious service affecting fault. 5. Indeterminate: indicates that the severity level cannot be determined. 6. Cleared: indicates the clearing of one or more previously reported alarms. This alarm clears all alarms for this managed object that have the same alarm type, possible causes and fault symptoms (if given). Multiple associated notifications may be cleared by using the Correlated notifications parameter. 	The value is a character string. In the X.733 standard, according to the severity and emergency, alarm messages are classified into six levels. The more serious event an alarm message indicates, the smaller <i>alarm-level</i> is. Critical indicates the alarm severity 1, whereas Cleared indicates the alarm severity 6.

Views

System view

Default Level

3: Management level

Usage Guidelines

Alarm messages are classified into root alarm messages and resume-alarm messages. All the alarms are saved on the device.

Events are classified into critical events and events. Critical events are saved on a device and can be obtained by the NMS. Events are not saved on a device.

The **fault-management alarm** command can be used to promote or degrade the level of an alarm message according to the severity and emergency of the alarm message.

Example

```
# Set the alarm severity of the alarm message named hwCfgManEventlog to major.
```

```
<HUAWEI> system-view  
[HUAWEI] fault-management alarm hwCfgManEventlog level major
```

19.2.11 poe af-inrush enable (upgrade-compatible command)

Function

The **poe af-inrush enable** command changes the power supply standards of interfaces from 802.3at to 802.3af.

The **undo poe af-inrush enable** command restores the power supply standards of interfaces to 802.3at.

By default, interfaces comply with 802.3at.

Format

```
poe af-inrush enable [ slot slot-id ]
```

```
undo poe af-inrush enable [ slot slot-id ]
```

Parameters

Parameter	Description	Value
slot <i>slot-id</i>	Specifies the stack ID.	The value is 0 if stacking is not configured. The value ranges from 0 to 8 if stacking is configured.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, it is replaced by the **poe af-inrush enable** command in the interface view.

19.2.12 reset fault-management (upgrade-compatible command)

Function

The **reset fault-management** command clears all alarm messages.

Format

reset fault-management { **active-alarm** | **event** } [**sequence-number** *sequence-number*]

Parameters

Parameter	Description	Value
active-alarm	Clears information about active alarms.	-
event	Clears event information.	-
sequence-number <i>sequence-number</i>	Specifies the number of an alarm message.	The value is an integer ranging from 0 to 2147483647. If the value is 0, it indicates that all alarm messages are cleared.

Views

System view

Default Level

3: Management level

Usage Guidelines

If *sequence-number* is not specified, the system clears all the alarm messages on the device.

NOTICE

After this command is run, all alarm messages on a device are cleared and cannot be restored.

Example

```
# Clear all active alarm messages.
```

```
<HUAWEI> system-view  
[HUAWEI] reset fault-management active-alarm
```

19.2.13 ntp-service authentication-keyid (upgrade-compatible command)

Function

The **ntp-service authentication-keyid** command sets NTP authentication key.

The **undo ntp-service authentication-keyid** command removes NTP authentication key.

By default, no authentication key is set.

Format

```
ntp-service authentication-keyid key-id authentication-mode { md5 | hmac-sha256 } plain password-plain
```

```
undo ntp-service authentication-keyid key-id
```

Parameters

Parameter	Description	Value
<i>key-id</i>	Indicates the key number.	Key ID is an integer and ranges from 1 to 4294967295.
authentication-mode md5	Indicates MD5 authentication mode.	-
authentication-mode hmac-sha256	Indicates HMAC-SHA256 authentication mode.	-

Parameter	Description	Value
<code>plain password-plain</code>	<p>Indicates that the configured password is displayed in plain text, and specifies the password.</p> <p>NOTICE</p> <p>If plain is selected, the password is saved in the configuration file in plain text. This brings security risks.</p>	The password is a string of 1 to 255 case-sensitive characters without spaces.

Views

System view

Default Level

2: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **ntp-service authentication-keyid**.

19.3 Interface Management Compatible Commands

19.3.1 Ethernet Interface Compatible Commands

19.3.1.1 **error-shutdown auto-recovery cause efm-threshold-event (upgrade-compatible command)**

Function

The **error-shutdown auto-recovery cause efm-threshold-event** command enables an interface in error-shutdown state to go Up.

NOTE

An interface enters the error-shutdown state after being shut down due to an error.

Format

error-shutdown auto-recovery cause efm-threshold-event

Parameters

Parameter	Description	Value
cause	Indicates the cause for an interface in error-down state.	-
efm-threshold-event	Indicates that a threshold crossing event occurs.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When link monitoring is configured for an interface on a link, the link is considered unavailable, if the number of errored frames, errored codes, or errored frame seconds detected by the interface reaches or exceeds the threshold within a period. You can associate an EFM crossing event with an interface. Then the system sets the administrative status of the interface to Down. In this manner, all services on the interface are interrupted.

By default, an interface can only be resumed by a network administrator after being shut down. To configure the interface to restore to the Up state automatically, run the **error-down auto-recovery** command to set an auto recovery.

Example

Set the auto recovery after an EFM threshold crossing event is associated with an interface.

```
<HUAWEI> system-view  
[HUAWEI] error-shutdown auto-recovery cause efm-threshold-event
```

19.3.1.2 error-shutdown auto-recovery interval (upgrade-compatible command)

Function

The **error-shutdown auto-recovery interval** command sets the auto recovery delay.

 NOTE

An interface enters the error-shutdown state after being shut down due to an error.

Format

error-shutdown auto-recovery interval *interval-value*

Parameters

Parameter	Description	Value
interval <i>interval-value</i>	Specifies the auto recovery delay.	The value is an integer that ranges from 30 to 86400, in seconds. <ul style="list-style-type: none">• A smaller value indicates a higher frequency at which an interface alternates between Up and Down states.• A larger value indicates longer traffic interruption.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

By default, an interface can only be resumed by a network administrator after being shut down. To configure the interface to restore to the Up state automatically, run the **error-shutdown auto-recovery interval** command to set an auto recovery delay. After the delay, the interface goes Up automatically.

Example

Set the auto recovery delay to 50s.

```
<HUAWEI> system-view  
[HUAWEI] error-shutdown auto-recovery interval 50
```

19.3.1.3 port-down holdoff-timer (upgrade-compatible command)

Function

Using the **port-down holdoff-timer** command, you can set the delay in reporting a port status change event.

Format

port-down holdoff-timer *interval*

Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the delay timer.	The value is an integer. The value can be 0 or in the range of 50 to 50000, in milliseconds.

Views

GE interface view, XGE interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When the cable connected to an interface is faulty, the interface status may change frequently. When this occurs, the system frequently updates the matching entries. If link backup is configured on the interface, active/standby switchovers occur frequently. To prevent frequent status change, you can use the **port-down holdoff-timer** command to set the delay in reporting a port status change event.

If an interface is connected to a wavelength division multiplexing device, the interface becomes Down when a protective switchover occurs on the wavelength division multiplexing device, and services are interrupted. To prevent service interruption, you can set the delay in reporting a port Down event.

Configuration Impact

If you run the **port-down holdoff-timer** command multiple times in the same interface view, only the latest configuration takes effect.

It is replaced by the **carrier { up-hold-time | down-hold-time } interval** command.

Example

```
# Set the delay in reporting a port status change event to 1000 milliseconds on  
GigabitEthernet0/0/1.
```

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet0/0/1  
[HUAWEI-GigabitEthernet0/0/1] port-down holdoff-timer 1000
```

19.3.1.4 snmp-agent trap enable port (upgrade-compatible command)

Function

The **snmp-agent trap enable port** command enables the system to generate an alarm when the inbound or outbound bandwidth usage on all Ethernet sub-interfaces exceeds the threshold.

Format

```
snmp-agent trap enable port { input-rate | output-rate }
```

Parameters

Parameter	Description	Value
input-rate	Enables the system to generate an alarm when the inbound bandwidth usage on all Ethernet sub-interfaces exceeds the threshold.	-
output-rate	Enable the system to generate an alarm when the outbound bandwidth usage on all Ethernet sub-interfaces exceeds the threshold.	-

Views

System review

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

If the threshold for the inbound or outbound bandwidth usage has been configured on an Ethernet sub-interface, you can enable the system to generate an alarm when the threshold is exceeded. This allows you to determine whether the device is functioning normally.

After the configuration is complete, the system generates an alarm when the bandwidth usage exceeds or falls below the threshold.

Example

None

19.4 Ethernet Switching Compatible Commands

19.4.1 MAC Compatible Commands

19.4.1.1 mac-address blackhole (upgrade-compatible command)

Function

Using the **mac-address blackhole** command, you can add a blackhole MAC address entry.

Format

mac-address blackhole *mac-address* [*interface-type interface-number*] **vlan** *vlan-id1* [**ce-vlan** *vlan-id2*]

Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies the destination MAC address in a MAC address entry.	The value is in H-H-H format. H is a hexadecimal number of 1 to 4 digits.
<i>interface-type interface-number</i>	Specifies the outbound interface in a MAC address entry. <ul style="list-style-type: none">• <i>interface-type</i> specifies the type of the outbound interface.• <i>interface-number</i> specifies the number of the outbound interface.	-
vlan <i>vlan-id1</i>	Specifies the VLAN ID in the outer VLAN tag.	The value is an integer that ranges from 1 to 4094.

Views

Ethernet interface view, GE interface view, XGE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **mac-address blackhole** command.

19.4.1.2 mac-address static (upgrade-compatible command)

Function

Using the **mac-address static** command, you can add a static MAC address entry.

Format

mac-address static *mac-address interface-type interface-number* **vlan** *vlan-id1*

Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies the destination MAC address in a MAC address entry.	The value is in H-H-H format. H is a hexadecimal number of 1 to 4 digits.
<i>interface-type interface-number</i>	Specifies the outbound interface in a MAC address entry. <ul style="list-style-type: none"><i>interface-type</i> specifies the type of the outbound interface.<i>interface-number</i> specifies the number of the outbound interface.	-
vlan <i>vlan-id1</i>	Specifies the VLAN ID in the VLAN tag.	The value is an integer that ranges from 1 to 4094.

Views

Ethernet interface view, GE interface view, XGE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **mac-address static vlan**, **mac-address static vlanif**, and **mac-address static vsi** command.

19.4.2 Link Aggregation Compatible Commands

19.4.2.1 mode lacp-static (upgrade-compatible command)

Function

The **mode** command configures the LACP mode of an Eth-Trunk.

Format

mode lacp-static

Parameters

none

Views

Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **mode lacp** command.

19.4.2.2 lacp e-trunk system-id (Eth-Trunk interface view) (upgrade-compatible command)

Function

The **lacp e-trunk system-id** command configures the Link Aggregation Control Protocol (LACP) system ID of an E-Trunk.

The **undo lacp e-trunk system-id** command deletes the LACP system ID of an E-Trunk.

By default, the LACP system ID is the Ethernet MAC address of the device.

Format

lacp e-trunk system-id *mac-address*

undo lacp e-trunk system-id

Parameters

Parameter	Description	Value
system-id <i>mac-address</i>	Specifies the LACP system ID of the E-Trunk.	The value is in the format of H-H-H. An H contains 1 to 4 hexadecimal digits, such as 00e0 and fc01. If an H contains fewer than four digits, 0s are padded ahead. For example, if an H is specified as e0, it is displayed as 00e0. The LACP system ID cannot be all 0s or all Fs. NOTE The LACP system ID cannot be all 0s. If the value is all Fs, it indicates that the LACP system ID is restored to the default.

Views

Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

It is replaced by the **lacp system-id** *mac-address* command.

19.4.2.3 snmp-agent trap enable eth-trunk (upgrade-compatible command)

Function

The **snmp-agent trap enable eth-trunk** command enables the Simple Network Management Protocol (SNMP) trap function on an Eth-Trunk.

The **undo snmp-agent trap enable eth-trunk** command disables the SNMP trap function on an Eth-Trunk.

By default, the SNMP trap function is disabled on an Eth-Trunk.

Format

snmp-agent trap enable eth-trunk

undo snmp-agent trap enable eth-trunk

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

If the SNMP trap function is enabled on an Eth-Trunk, the system sends a trap to the network management system (NMS) server in case of when the following exceptions occur:

- The negotiation of the LAG fails.
- The bandwidth of the LAG is lost. For example, if the lower threshold of the number of active interfaces is set by using the **least active-linknumber** command and if the number of active interfaces is smaller than this value, the Eth-Trunk becomes Down and the system sends the trap.
- Part of the bandwidth of the LAG is lost. When one of active interfaces fails, the system sends the trap because the number of active interfaces is reduced.

Example

Enable the SNMP trap function on an Eth-Trunk so that the trap can be sent to the NMS server promptly when the status of the LAG changes.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable eth-trunk
```

19.4.3 VLAN Compatible Commands

19.4.3.1 port mux-vlan enable (upgrade-compatible command)

Function

The **port mux-vlan enable** command enables the MUX VLAN function on an interface.

The **undo port mux-vlan enable** command disables the MUX VLAN function on an interface.

By default, the MUX VLAN function is disabled on an interface.

Format

port mux-vlan enable

undo port mux-vlan enable

Parameters

None

Views

GE interface view, XGE interface view, Eth-Trunk interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **port mux-vlan enable vlan** command.

19.4.4 Voice VLAN Compatible Commands

19.4.4.1 voice-vlan enable (upgrade-compatible command)

Function

The **voice-vlan enable** command enables the voice VLAN function on an interface.

By default, the voice VLAN function is disabled on an interface.

Format

voice-vlan enable

Parameters

None

Views

GE interface view, Ethernet interface view, XGE interface view, Eth-Trunk interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **voice-vlan *vlan-id* enable** command.

19.4.5 GVRP Compatible Commands

19.4.5.1 garp leaveall timer (upgrade-compatible command)

Function

The **garp leaveall timer** command sets the GARP LeaveAll timer.

Format

garp leaveall timer *timer-value*

Parameters

Parameter	Description	Value
<i>timer-value</i>	Specifies the value of the GARP LeaveAll timer.	The value is an integer that ranges from 65 to 32765 and that can be exactly divided by 5, in centiseconds. The value of the LeaveAll timer must be greater than the values of Leave timers on all the interfaces.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When a GARP participant is enabled, the LeaveAll timer is started. When the LeaveAll timer expires, the GARP participant sends LeaveAll messages to request other GARP participants to re-register all its attributes. Then the LeaveAll timer restarts.

Devices on a network may have different settings for the LeaveAll timer. In this case, all the devices use the smallest LeaveAll timer value on the network. When the LeaveAll timer of a device expires, the device sends LeaveAll messages to other devices. After other devices receive the LeaveAll messages, they reset their LeaveAll timers. Therefore, only the LeaveAll timer with the smallest value takes effect even if devices have different settings for the LeaveAll timer.

Prerequisites

Before setting GARP timers on an interface, you must enable GVRP globally.

Precautions

The Leave timer length on an interface is restricted by the global LeaveAll timer length. When configuring the global LeaveAll timer, ensure that all the interfaces that have a GARP Leave timer configured are working properly.

Example

```
# Set the LeaveAll timer to 510 centiseconds.
```

```
<HUAWEI> system-view  
[HUAWEI] garp leaveall timer 510
```

19.4.6 STP Compatible Commands

19.4.6.1 snmp-agent trap enable mstp (upgrade-compatible command)

Function

The **snmp-agent trap enable mstp** command enables the trap function for the MSTP module.

Format

```
snmp-agent trap enable mstp
```

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **snmp-agent trap enable feature-name mstp** command in the system view.

19.4.6.2 snmp-agent trap enable feature-name mstp (upgrade-compatible command)

Function

The **snmp-agent trap enable feature-name mstp** command enables the trap function for the MSTP module.

By default, the trap function is disabled for the MSTP module.

Format

```
snmp-agent trap enable feature-name mstp trap-name { nnewroot |  
ntopologychange }
```

```
undo snmp-agent trap enable feature-name mstp trap-name { nnewroot |  
ntopologychange }
```

Parameters

Parameter	Description	Value
trap-name	Enables the traps of spanning tree protocol events of specified types.	-
nnewroot	Enables the device to send trap when the current device is elected as the root bridge.	-
ntopologychange	Enables the device to send trap when the topology changes.	-

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **snmp-agent trap enable feature-name mstp trap-name { newroot | topologychange }** command in the system view.

19.4.6.3 stp tc-protection (upgrade-compatible command)

Function

The **stp tc-protection** command enables the trap function for the Topology Change (TC) BPDU protection.

The **undo stp tc-protection** command disables the trap function for the TC BPDU protection.

By default, the trap function for the TC BPDU protection is disabled.

Format

stp tc-protection

undo stp tc-protection

Parameters

None

Views

System view or MST process region view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The TC attack defense function is enabled by default, you can run the **stp tc-protection interval** command to set the time that a device needs to process the maximum number of TC BPDUs which is configured using the **stp tc-protection threshold** command. If there are packets exceeding the maximum number, the switch processes the packets after the time specified in the **stp tc-protection interval** command expires. For example, if the time is set to 10 seconds and the maximum number is set to 5, when a switch receives TC BPDUs, the switch processes only the first 5 TC BPDUs within 10 seconds and processes the other TC BPDUs after the time expires. In this way, the device does not frequently update its MAC address entries and ARP entries, reducing CPU usage.

To learn about detailed processing information on TC BPDUs, run the **stp tc-protection** command to enable the trap function for the TC BPDU protection.

After the function is enabled, MSTP_1.3.6.1.4.1.2011.5.25.42.4.2.15 hwMstpIcGuarded and MSTP_1.3.6.1.4.1.2011.5.25.42.4.2.16 hwMstpProTcGuarded are generated.

Precautions

The trap function for the TC BPDU protection takes effect only when the **snmp-agent trap enable feature-name mstp** and **stp tc-protection** are both run.

19.4.7 L2PT Compatible Commands

19.4.7.1 bpdu-tunnel (upgrade-compatible command)

Function

The **bpdu-tunnel** command configures an interface to forward or discard BPDUs. By default, an interface discards the received BPDUs.

Format

bpdu-tunnel { enable | disable }

Parameters

Parameter	Description	Value
enable disable	Indicates the action that an interface performs on BPDUs. <ul style="list-style-type: none">● enable: The interface discards BPDUs.● disable: The interface forwards BPDUs.	-

Views

Ethernet interface view, GE interface view, XGE interface view, port group view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **l2protocol-tunnel stp { enable | disable }** command.

19.4.7.2 bpdu-tunnel enable (upgrade-compatible command)

Function

The **bpdu-tunnel enable** command enables Layer 2 protocol tunneling on an interface.

Format

bpdu-tunnel { all | *protocol-type* &<1-15> } enable

Parameters

Parameter	Description	Value
all	Enables or disables transparent transmission of packets of all standard Layer 2 protocols and user-defined Layer 2 protocols.	-
<i>protocol-type</i>	Enables or disables transparent transmission of packets of a specified Layer 2 protocol. You can specify multiple protocols in the command.	-

Views

Ethernet interface view, XGE interface view, GE interface view, Eth-Trunk interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **l2protocol-tunnel { all | { *protocol-type* } &<1-15> | **user-defined-protocol** *protocol-name* } enable** command.

19.4.7.3 bpdu-tunnel group-mac (upgrade-compatible command)

Function

The **bpdu-tunnel group-mac** command enables the switch to replace the multicast destination MAC address of Layer 2 protocol packets with a specified multicast MAC address.

Format

bpdu-tunnel *protocol-type* **group-mac** *group-mac*

Parameters

Parameter	Description	Value
<i>protocol-type</i>	Specifies the type of a Layer 2 protocol.	The value is a string of 1 to 31.
group-mac <i>group-mac</i>	Specifies the multicast MAC address that replaces the destination MAC address of Layer 2 protocol packets.	The value is in H-H-H format. An H is a hexadecimal number of 1 to 4 digits. The value ranges from 0100-0000-0000 to 01ff-ffff-ffff.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **l2protocol-tunnel protocol-type group-mac group-mac** command.

19.4.7.4 bpdu-tunnel stp group-mac (upgrade-compatible command)

Function

Using the **bpdu-tunnel stp group-mac** command, you can replace the global well-known MAC address of the STP BPDU packets with a multicast MAC address.

Format

bpdu-tunnel stp group-mac *group-mac*

Parameters

Parameter	Description	Value
group-mac <i>group-mac</i>	Specifies the multicast MAC address that replaces the well-known global MAC address of the BPDU packets.	The value is in H-H-H format. An H is a hexadecimal number of 1 to 4 digits. The value ranges from 0100-0000-0000 to 01ff-ffff-ffff.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **l2protocol-tunnel stp group-mac** *group-mac* command.

19.4.7.5 bpdu-tunnel stp vlan (upgrade-compatible command)

Function

Using the **bpdu-tunnel stp vlan** command, you can configure the interface to accept the BPDU packets whose tag values range from *low-vid* to *high-vid*.

Using the **undo bpdu-tunnel stp vlan** command, you can cancel the configuration.

By default, an interface does not accept the tagged BPDU packets.

Format

bpdu-tunnel stp vlan { *low-vid* [**to** *high-vid*] } &<1-10>

undo bpdu-tunnel stp vlan { *low-vid* [**to** *high-vid*] } &<1-10>

Parameters

Parameter	Description	Value
<i>low-vid</i>	Specifies the start VLAN ID of the BPDU packets that can be accepted by the interface.	The value is a decimal integer ranging from 1 to 4094. It must be smaller than <i>high-vid</i> .
<i>high-vid</i>	Specifies the end VLAN ID of the BPDU packets that can be accepted by the interface.	The value is a decimal integer ranging from 1 to 4094. It must be greater than <i>low-vid</i> .

Views

Ethernet interface view, GE interface view, XGE interface view, Eth-Trunk interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **l2protocol-tunnel stp { vlan *low-id* [to *high-id*] }** &<1-10> command.

19.4.7.6 bpdu-tunnel vlan (upgrade-compatible command)

Function

The **bpdu-tunnel vlan** command enables VLAN-based Layer 2 protocol tunneling on an interface.

Format

bpdu-tunnel { all | *protocol-type* &<1-15> } vlan { *low-id* [to *high-id*] } &<1-10>

Parameters

Parameter	Description	Value
all	Enables or disables transparent transmission of packets of all standard Layer 2 protocols and user-defined Layer 2 protocols.	-
<i>protocol-type</i>	Enables or disables transparent transmission of packets of a specified Layer 2 protocol. You can specify multiple protocols in the command.	-
<i>low-id</i>	Specifies the start VLAN ID.	The value is an integer that ranges from 1 to 4094. The value must be smaller than the end VLAN ID.
<i>high-id</i>	Specifies the end VLAN ID.	The value is an integer that ranges from 1 to 4094. The value must be greater than the start VLAN ID.

Views

Ethernet interface view, XGE interface view, GE interface view, Eth-Trunk interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **l2protocol-tunnel vlan** command.

19.4.7.7 l2protocol-tunnel user-defined-protocol (upgrade-compatible command)

Function

The **l2protocol-tunnel user-defined-protocol** command defines the characteristics of a Layer 2 protocol whose packets are transparently transmitted, including the protocol name, Ethernet encapsulation type, destination MAC address of packets, multicast MAC address replacing the destination multicast MAC address of packets, and priority of packets.

By default, there is no user-defined characteristics of a Layer 2 protocol whose packets are transparently transmitted.

Format

```
l2protocol-tunnel user-defined-protocol protocol-name protocol-mac protocol-mac encap-type { ethernetii protocol-type | llc dsap dsap-value ssap ssap-value | snap protocol-type } group-mac { group-mac | default-group-mac } [ priority priority-id ]
```

Parameters

Parameter	Description	Value
<i>protocol-name</i>	Specifies the name of a user-defined Layer 2 protocol whose packets are transparently transmitted.	The name is a string of 1 to 31 case-insensitive characters without spaces. When quotation marks are used around the string, spaces are allowed in the string.
protocol-mac <i>protocol-mac</i>	Specifies the destination multicast MAC address of the Layer 2 protocol packets that are transparently transmitted. This MAC address must be an ordinary MAC address that has not been used on the devices.	The address is in the format of H-H-H, H indicating a 4-bit hexadecimal number.

Parameter	Description	Value
encap-type	<p>Defines the encapsulation format for Layer 2 protocol packets that are transparently transmitted.</p> <ul style="list-style-type: none"> • ethernetII: indicates Ethernet_II, the encapsulation format for Layer 2 protocol packets that are transparently transmitted. • llc: indicates Logical Link Control (LLC), the encapsulation format for Layer 2 protocol packets that are transparently transmitted. • snap: indicates Sub-Network Access Protocol (SNAP), the encapsulation format for Layer 2 protocol packets that are transparently transmitted. <p>When transparently-transmitted Layer 2 protocol packets carry the same protocol MAC address and protocol type, you can use the parameter encap-type to define different encapsulation formats to differentiate these packets.</p>	-
protocol-type <i>protocol-type</i>	Specifies the value of Ethernet encapsulation type.	The value is a hexadecimal number ranging from 0600 to FFFF.
dsap <i>dsap-value</i>	Specifies the destination service access point.	The value ranges from 0x00 to 0xff, in hexadecimal format.
ssap <i>ssap-value</i>	Specifies the source service access point.	The value ranges from 0x00 to 0xff, in hexadecimal format.
group-mac <i>group-mac</i>	Specifies the multicast MAC address that replaces the destination multicast MAC address of the Layer 2 protocol packets that are transparently transmitted. The address must be an ordinary MAC address, which cannot be the MAC address of bridge protocol data units (BPDUs), the MAC address of Smart Link protocol packets, or a special MAC address.	The address is in the format of H-H-H, H indicating a 4-bit hexadecimal number.

Parameter	Description	Value
default-group-mac	<p>Specifies the default MAC address of a multicast group, which is 0100-0ccd-cdd0.</p> <p>This parameter can simplify the configuration and reduce the configuration error. For example:</p> <p>Most Layer 2 protocols can be classified by types. Default MAC addresses of Layer 2 protocols in the same type are the same. In this case, you can attach the parameter default-group-mac to the l2protocol-tunnel user-defined-protocol command to reduce the configuration workload and the probability of configuration error.</p>	-
priority <i>priority-id</i>	Specifies the priority of the Layer 2 protocol packets that are transparently transmitted.	The value is an integer that ranges from 1 to 7. The default value is 0.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **l2protocol-tunnel user-defined-protocol** command.

19.5 IP Service Compatible Commands

19.5.1 DHCP Upgrade-compatible Commands

19.5.1.1 expired (upgrade-compatible command)

Function

The **expired** command sets the lease for IP addresses in a global IP address pool.

By default, the lease of IP addresses is one day.

Format

expired { **day** *day* [**hour** *hour* [**minute** *minute*]] | **unlimited** }

Parameters

Parameter	Description	Value
day <i>day</i>	Specifies the number of days in the IP address lease.	The value is an integer ranging from 0 to 999, in days. The default value is 1.
hour <i>hour</i>	Specifies the number of hours in the IP address lease.	The value is an integer ranging from 0 to 23, in hours. The default value is 0.
minute <i>minute</i>	Specifies the number of minutes in the IP address lease.	The value is an integer ranging from 0 to 59, in minutes. The default value is 0.
unlimited	Indicates that the IP address lease is unlimited.	-

Views

IP address pool view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The **expired-hide** command applies to DHCP servers. To meet different client requirements, DHCP supports dynamic, automatic, and static address assignment. Different hosts require different IP address leases. For example, if some hosts such as a DNS server need to use certain IP addresses for a long time, configure **expired** as **unlimited** to set the IP address lease of the specified global address pool to unlimited. If some hosts such as a portable computer just need to use temporary IP addresses, set the IP address lease of the specified global address pool to the required time so that the expired IP addresses can be released and assigned to other clients.

When a DHCP client starts or half of its IP address lease has passed, the DHCP client sends a DHCP Request packet to the DHCP server to renew the lease. If the IP address can still be assigned to the client, the DHCP server informs a renewed IP address lease to the client. If the IP address can no longer be assigned to this

client, the DHCP server informs the client that the IP address lease cannot be renewed and it needs to apply for another IP address.

Prerequisites

Run the **ip pool** command to create a global IP address pool and the **dhcp enable** command to globally enable the DHCP server function.

Precautions

Different IP address leases can be specified for different global IP address pools on a DHCP server. In a global IP address pool, all addresses have the same lease.

Example

Specify the IP address lease of the global address pool global1 to 1 day 2 hours and 30 minutes.

```
<HUAWEI> system-view  
[HUAWEI] ip pool global1  
[HUAWEI-ip-pool-global1] expired day 1 hour 2 minute 30
```

19.5.1.2 dhcp server expired (upgrade-compatible command)

Function

The **dhcp server expired** command sets the lease for IP addresses in an interface IP address pool.

By default, the lease of IP addresses is one day.

Format

dhcp server expired { **day** *day* [**hour** *hour* [**minute** *minute*]] | **unlimited** }

Parameters

Parameter	Description	Value
<i>day</i>	Specifies the number of days in the IP address lease.	The value is an integer ranging from 0 to 999, in days. The default value is 1.
<i>hour</i>	Specifies the number of hours in the IP address lease.	The value is an integer ranging from 0 to 23, in hours. The default value is 0.
<i>minute</i>	Specifies the number of minutes in the IP address lease.	The value is an integer ranging from 0 to 59, in minutes. The default value is 0.

Parameter	Description	Value
unlimited	Indicates that the IP address lease is unlimited.	-

Views

VLANIF interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The **dhcp server expired** command applies to DHCP servers. To meet different client requirements, DHCP supports dynamic, automatic, and static address assignment. Different hosts require different IP address leases. For example, if some hosts such as a DNS server need to use certain IP addresses for a long time, run the **dhcp server expired unlimited** command to set the IP address lease of the specified VLANIF interface address pool to unlimited. If some hosts such as a portable computer just need to use temporary IP addresses, run the **dhcp server expired** command to set the IP address lease of the specified VLANIF interface address pool to the required time so that the expired IP addresses can be released and assigned to other clients.

When a DHCP client starts or half of its IP address lease has passed, the DHCP client sends a DHCP Request packet to the DHCP server to renew the lease. If the IP address can still be assigned to the client, the DHCP server informs the client of a renewed IP address lease. If the IP address can no longer be assigned to this client, the DHCP server informs the client that the IP address lease cannot be renewed.

Prerequisites

Run the **dhcp enable** command to globally enable the DHCP function. Run the **dhcp select interface** command in the VLANIF interface view to enable the interface IP address pool.

Precautions

Different IP address leases can be specified for different interface IP address pools on a DHCP server. In an interface IP address pool, all IP addresses have the same lease.

Example

```
# Set the IP address lease of the IP address pool on VLANIF 100 to 2 days 2 hours and 30 minutes.
```

```
<HUAWEI> system-view  
[HUAWEI] dhcp enable
```

```
[HUAWEI] interface vlanif 100
[HUAWEI-Vlanif100] ip address 10.1.1.1 24
[HUAWEI-Vlanif100] dhcp select interface
[HUAWEI-Vlanif100] dhcp server expired day 2 hour 2 minute 30
```

19.5.1.3 dhcp server forbidden-ip (upgrade-compatible command)

Function

The **dhcp server forbidden-ip** command specifies the range of IP addresses that cannot be assigned to clients by the DHCP server.

By default, the system does not configure the range of IP addresses that cannot be assigned to clients by the DHCP server.

Format

```
dhcp server forbidden-ip start-ip-address [ end-ip-address ]
```

Parameters

Parameter	Description	Value
<i>start-ip-address</i>	Specifies the start IP address that cannot be automatically assigned.	The value is in dotted decimal notation.
<i>end-ip-address</i>	Specifies the end IP address that cannot be automatically assigned. If <i>end-ip-address</i> is not specified, only <i>start-ip-address</i> cannot be assigned to clients.	The value is in dotted decimal notation. <i>end-ip-address</i> and <i>start-ip-address</i> must be on the same network segment and <i>end-ip-address</i> must be larger than <i>start-ip-address</i> .

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The **dhcp server forbidden-ip** command applies to DHCP servers. In an IP address pool, some IP addresses need to be reserved for other services, and some IP addresses are statically assigned to certain hosts (such as the DNS server) and cannot be automatically assigned to clients. You can run the **dhcp server**

forbidden-ip command to specify the range of the IP addresses that cannot be automatically assigned to clients from the IP address pool.

Precautions

- The excluded IP address must be in the IP address pool range.
- The excluded IP address or IP address segment cannot be automatically assigned to clients from a local address pool.
- If you run the **dhcp server forbidden-ip** command multiple times, you can specify multiple IP addresses or IP address segments that cannot be automatically assigned to clients from the specified address pool.

Example

Configure that IP addresses in the address pool 10.10.10.10 to 10.10.10.20 cannot be automatically assigned to clients.

```
<HUAWEI> system-view  
[HUAWEI] dhcp server forbidden-ip 10.10.10.10 10.10.10.20
```

19.5.1.4 dhcp server ip-pool

Function

The **dhcp server ip-pool** command creates a global IP address pool.

The **undo dhcp server ip-pool** command deletes a global IP address pool.

By default, no global IP address pool is created.

Format

dhcp server ip-pool *pool-name*

undo dhcp server ip-pool *pool-name*

Parameters

Parameter	Description	Value
<i>pool-name</i>	Specifies the name of a global IP address pool.	The value is a string of 1 to 64 case-insensitive characters without spaces.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

This function equals to the **ip pool** *ip-pool-name* command.

19.5.1.5 dhcp server ping

Function

The **dhcp server ping** command sets the maximum number of ping packets to be sent and the maximum response time of a ping packet.

By default, a DHCP server does not send any ping packet.

Format

dhcp server ping { **packets** *number* | **timeout** *milliseconds* } *

Parameters

Parameter	Description	Value
packets <i>number</i>	Specifies the maximum number of ping packets to be sent.	The value is an integer that ranges from 0 to 10.
timeout <i>milliseconds</i>	Specifies the maximum response time of a ping packet.	The value is an integer that ranges from 0 to 10000, in milliseconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the upgrade, it is replaced by the **dhcp server ping** { **packet** *number* | **timeout** *milliseconds* } * command.

Example

```
# Set the maximum number of ping packets to be sent to 5.
```

```
<HUAWEI> system-view  
[HUAWEI] dhcp server ping packets 5
```

19.5.1.6 dns-suffix

Function

The **dns-suffix** command configures the domain name suffix to be assigned by the DHCP server to a DHCP client.

By default, no domain name suffix is configured for a DHCP client.

Format

dns-suffix *domain-name*

Parameters

Parameter	Description	Value
<i>domain-name</i>	Specifies the domain name suffix to be assigned to a DHCP client.	The value is a string of 1 to 63 case-insensitive characters without spaces. When quotation marks are used around the string, spaces are allowed in the string.

Views

IP address pool view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, it is replaced by the **domain-name** *domain-name* command.

19.5.1.7 ip relay address (upgrade-compatible command)

Function

Using the **ip relay address** command, you can configure DHCP server addresses on a VLANIF interface enabled with DHCP relay.

Using the **undo ip relay address** command, you can delete the configured DHCP server addresses.

By default, no DHCP server address is configured on a VLANIF interface enabled with DHCP relay.

Format

ip relay address *ip-address*

undo ip relay address { *ip-address* | **all** }

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the IP address of a DHCP server.	The value is in dotted decimal notation.
all	Deletes all the DHCP server addresses configured on an interface.	-

Views

VLANIF interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The **ip relay address** command is applicable to DHCP relay agents. When a DHCP client needs to send a DHCP request packet to a DHCP server on a different network segment by using a DHCP relay agent, run the **ip relay address** command on the DHCP relay agent to configure a DHCP server address.

Prerequisites

DHCP relay has been enabled on the VLANIF interface by using the **dhcp select relay** command.

Precautions

If you run the **ip relay address** command multiple times, multiple DHCP server addresses are configured.

Example

```
# Configure DHCP server addresses 10.2.2.2 on VLANIF100 enabled with DHCP relay.
```

```
<HUAWEI> system-view  
[HUAWEI] dhcp enable  
[HUAWEI] interface vlanif 100  
[HUAWEI-Vlanif100] dhcp select relay  
[HUAWEI-Vlanif100] ip relay address 10.2.2.2
```

19.5.1.8 lease (upgrade-compatible command)

Function

The **lease** command sets the lease for IP addresses in a global IP address pool.
By default, the lease of IP addresses is one day.

Format

lease *day* [*hour* [*minute*]]

Parameters

Parameter	Description	Value
<i>day</i>	Specifies the number of days in the IP address lease.	The value is an integer ranging from 0 to 999, in days. The default value is 1.
<i>hour</i>	Specifies the number of hours in the IP address lease.	The value is an integer ranging from 0 to 23, in hours. The default value is 0.
<i>minute</i>	Specifies the number of minutes in the IP address lease.	The value is an integer ranging from 0 to 59, in minutes. The default value is 0.

Views

IP address pool view

Default Level

2: Configuration level

Usage Guidelines

After the upgrade, it is replaced by the **lease { day *day* [hour *hour* [minute *minute*]] | unlimited }** command.

Example

Specify the IP address lease of the global address pool **global1** to 1 day.

```
<HUAWEI> system-view  
[HUAWEI] ip pool global1  
[HUAWEI-ip-pool-global1] lease 1
```

19.5.1.9 static-bind mac-address

Function

The **static-bind mac-address** command binds a MAC address to a global IP address pool.

Format

static-bind mac-address *mac-address*

Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies the user MAC address.	The value is in H-H-H format. An H is a hexadecimal number of 1 to 4 digits.

Views

IP address pool view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, it is replaced by the **static-bind ip-address mac-address mac-address** command.

19.5.1.10 dhcpv6 relay destination (upgrade-compatible command)

Function

The **dhcpv6 relay destination** command enables the DHCPv6 relay function on interfaces and configures the IPv6 address of the DHCPv6 server or next-hop relay agent.

By default, the DHCPv6 relay function is disabled on an interface.

Format

dhcpv6 relay destination *ipv6-address* **interface** *interface-type interface-number*

Parameters

Parameter	Description	Value
<i>ipv6-address</i>	Specifies the destination address of relay messages, which can be the IPv6 address of the DHCPv6 server or next hop relay agent.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X:X.
interface <i>interface-type interface-number</i>	Specifies the type and number of the outbound interface of relay messages.	-

Views

Interface view

Default Level

2: Configuration level

Usage Guidelines

When a client applies to a DHCPv6 server on a different network segment for an IPv6 address, you need to deploy a relay agent between the client and the DHCPv6 server. In this manner, the relay agent transmits DHCPv6 messages exchanged between the client and the DHCPv6 server.

19.6 IP Multicast Compatible Commands

19.6.1 MLD Snooping Compatible Commands

19.6.1.1 mld-snooping group-policy (interface view) (upgrade-compatible command)

Function

The **mld-snooping group-policy** command configures an IPv6 multicast group policy on an interface.

Format

mld-snooping group-policy *acl6-number* **vlan** *vlan-id* *mld-version* [**default-permit**]

Parameters

Parameter	Description	Value
<i>acl6-number</i>	Specifies the number of an IPv6 ACL that defines a range of multicast groups. A basic or advanced ACL can be used in an IPv6 multicast group policy.	The value is an integer that ranges from 2000 to 3999.
vlan <i>vlan-id</i>	Applies the IPv6 multicast group policy to a specified VLAN on an interface.	The value is an integer that ranges from 1 to 4094.
<i>mld-version</i>	Specifies an MLD version. The multicast group policy is applied only to the MLD messages of this version. If this parameter is not specified, the multicast group policy applies to all MLD messages.	The value is 1 or 2. <ul style="list-style-type: none">• 1: MLDv1• 2: MLDv2
default-permit	Configures the multicast group policy to permit all groups by default. That is, if the referenced ACL has no rules, the multicast group policy allows hosts in the VLAN to join all groups.	-

Views

Ethernet interface view, GE interface view, XGE interface view, port group view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Example

```
# Prevent MLDv2 hosts in VLAN 10 on GE0/0/1 from joining IPv6 multicast group ff1c::3/32.
```

```
<HUAWEI> system-view
[HUAWEI] acl ipv6 number 2000
[HUAWEI-acl6-basic-2000] rule deny source ff1c::3/32
[HUAWEI-acl6-basic-2000] quit
[HUAWEI] mld-snooping enable
[HUAWEI] vlan 10
[HUAWEI-vlan10] mld-snooping enable
[HUAWEI-vlan10] quit
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] port link-type trunk
[HUAWEI-GigabitEthernet0/0/1] port trunk allow-pass vlan 10
[HUAWEI-GigabitEthernet0/0/1] mld-snooping group-policy 2000 vlan 10 2 default-permit
```

19.6.1.2 mld-snooping group-policy (VLAN view) (upgrade-compatible command)

Function

The **mld-snooping group-policy** command configures an IPv6 multicast group policy in a VLAN.

Format

```
mld-snooping group-policy acl6-number mld-version [ default-permit ]
```

Parameters

Parameter	Description	Value
<i>acl6-number</i>	Specifies the number of an IPv6 ACL that defines a range of multicast groups. A basic or advanced ACL can be used in an IPv6 multicast group policy.	The value is an integer that ranges from 2000 to 3999.
<i>mld-version</i>	Applies the multicast group policy only to the MLD messages of the specified version. If this parameter is not specified, the multicast group policy applies to all MLD messages.	The value is 1 or 3. <ul style="list-style-type: none"> • 1: MLDv1 • 2: MLDv2

Parameter	Description	Value
default-permit	Configures the multicast group policy to permit all groups by default. That is, if the referenced ACL has no rules, the multicast group policy allows hosts in the VLAN to join all groups.	-

Views

VLAN view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Example

```
# Prevent MLDv2 hosts in VLAN 4 from joining IPv6 multicast group ff1e::1/32.
```

```
<HUAWEI> system-view  
[HUAWEI] acl ipv6 number 2001  
[HUAWEI-acl6-basic-2001] rule deny source ff1e::1/32  
[HUAWEI-acl6-basic-2001] quit  
[HUAWEI] mld-snooping enable  
[HUAWEI] vlan 4  
[HUAWEI-vlan4] mld-snooping enable  
[HUAWEI-vlan4] mld-snooping group-policy 2001 2 default-permit
```

19.7 MPLS compatible command

19.7.1 explicit-path (upgrade-compatible command)

Function

Using the **explicit-path** command, you can configure an explicit path of a tunnel.
By default, no explicit path of a tunnel is configured.

Format

```
explicit-path path-name { enable | disable }
```

Parameters

Parameter	Description	Value
<i>path-name</i>	Indicates the name of an explicit path.	The value is a string of 1 to 31 characters.
enable	Enables the explicit path of a tunnel.	-
disable	Disables the explicit path of a tunnel.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

You can configure an explicit path only after MPLS TE is enabled.

The addresses of the hops along the explicit path cannot overlap or loops cannot occur. If a loop occurs, CSPF detects the loop and fails to calculate the path.

When the explicit path is in use, you cannot perform the following operations:

- Run the **explicit-path** *path-name* **disable** command to disable the explicit path.
- Run the **undo explicit-path** command to delete the explicit path.

Example

Create an explicit path named **path1**.

```
<HUAWEI> system-view
[HUAWEI] mpls
[HUAWEI-mpls] mpls te
[HUAWEI-mpls] quit
[HUAWEI] explicit-path path1 enable
[HUAWEI-explicit-path-path1]
```

19.7.2 mpls rsvp-te authentication handshake (upgrade-compatible command)

Function

The **mpls rsvp-te authentication handshake** command configures the RSVP-TE handshake mechanism and sets a local password.

The **undo mpls rsvp-te authentication handshake** command deletes the RSVP-TE handshake mechanism configuration.

By default, no RSVP-TE handshake mechanism is configured.

Format

mpls rsvp-te authentication handshake *local-secret*

undo mpls rsvp-te authentication handshake

Parameters

Parameter	Description	Value
<i>local-secret</i>	Specifies the local password.	The value is a string of 8 to 40 characters without spaces. It has no default value.

Views

Interface view, RSVP-TE neighbor view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Enhanced RSVP authentication can be configured to improve the system security and the capability to authenticate users in the unfavorable environment such as network congestion. Enhanced RSVP authentication functions are as follows:

- Sets the sliding window size for RSVP authentication messages.
- Configures the RSVP-TE handshake mechanism and sets the local password.

Traditional RSVP authentication is used to prevent an unauthorized remote node from setting up a neighbor relationship with the local node. It also prevents attacks (such as maliciously reserving a large number of bandwidth resources) initiated by a remote node after the remote node constructs pseudo RSVP messages to set up an RSVP neighbor relationship with the local node. Traditional RSVP authentication, however, cannot prevent anti-replay attacks or prevent the problem of neighbor relationship termination due to RSVP message disorder.

In an unfavorable environment, the **mpls rsvp-te authentication handshake** command can be used to configure the RSVP-TE handshake mechanism and sets the local password to prevent anti-replay and improve network security.

Prerequisites

The RSVP authentication function must have been enabled by running the **mpls rsvp-te authentication { { cipher | plain } auth-key | keychain keychain-name }** command in the interface view or the MPLS RSVP-TE neighbor view.

Precautions

local-secret is valid only on the local device and can be different from *local-secret* configured on neighbors.

Example

```
# Configure the RSVP-TE handshake mechanism.
<HUAWEI> system-view
[HUAWEI] interface vlanif 100
[HUAWEI-Vlanif100] mpls
[HUAWEI-Vlanif100] mpls te
[HUAWEI-Vlanif100] mpls rsvp-te
[HUAWEI-Vlanif100] mpls rsvp-te authentication cipher beijing123
[HUAWEI-Vlanif100] mpls rsvp-te authentication handshake 12345678
```

```
# Configure the RSVP-TE handshake mechanism.
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] undo portswitch
[HUAWEI-GigabitEthernet0/0/1] mpls
[HUAWEI-GigabitEthernet0/0/1] mpls te
[HUAWEI-GigabitEthernet0/0/1] mpls rsvp-te
[HUAWEI-GigabitEthernet0/0/1] mpls rsvp-te authentication cipher beijing123
[HUAWEI-GigabitEthernet0/0/1] mpls rsvp-te authentication handshake 12345678
```

19.7.3 mpls rsvp-te send-message (upgrade-compatible command)

Function

The **mpls rsvp-te send-message** command configures the formats of objects in a sent message.

The **undo mpls rsvp-te send-message** command restores the default configuration.

By default, the formats of objects in the sent message are not configured.

Format

mpls rsvp-te send-message suggest-label exclude

undo mpls rsvp-te send-message suggest-label exclude

Parameters

Parameter	Description	Value
suggest-label exclude	Indicates that an RSVP message does not carry the suggest-label object.	-

Views

MPLS view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The **mpls rsvp-te send-message** command controls the formats of objects in the messages sent by nodes. If required, you can use this command to adjust the transmission of messages so that downstream nodes can use the carried object format in processing.

Precautions

The modification takes effect only for new LSPs.

Configurations of the four formats of objects in a sent message can take effect simultaneously.

Example

```
# Exclude the suggest-label object from a message.  
<HUAWEI> system-view  
[HUAWEI] mpls  
[HUAWEI-mpls] mpls rsvp-te send-message suggest-label exclude
```

19.7.4 mpls te max-reservable-bandwidth (upgrade-compatible command)

Function

The **mpls te max-reservable-bandwidth** command sets the maximum reservable bandwidth of a link.

The maximum reservable bandwidth of a link is not configured by default.

Format

mpls te max-reservable-bandwidth *bw-value* [**bc1** *bc1-bw-value*]

Parameters

Parameter	Description	Value
<i>bw-value</i>	Specifies the maximum reservable link bandwidth.	The value is an integer ranging from 0 to 40000000, in kbit/s. The default value is 0.
bc1 <i>bc1-bw-value</i>	Specifies the maximum reservable bandwidth for a BC1 link.	The value is an integer ranging from 0 to 40000000, in kbit/s. The default value is 0.

Views

Interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After an upgrade, this command is no longer supported, and it is replaced by the **mpls te bandwidth max-reservable-bandwidth** command.

19.7.5 mpls te bypass-tunnel bandwidth (upgrade-compatible command)

Function

Using the **mpls te bypass-tunnel bandwidth** command, you can configure the bypass LSP bandwidth.

By default, no bypass LSP bandwidth is configured.

Format

mpls te bypass-tunnel bandwidth { *bandwidth* | { **bc0** | **bc1** } { *bandwidth* | **un-limited** } }

Parameters

Parameter	Description	Value
<i>bandwidth</i>	Specifies the bandwidth that the bypass tunnel can protect.	The value is an integer that ranges from 1 to 32000000, in kbit/s.
bc0	Indicates the BC0 bandwidth (global bandwidth) that the bypass tunnel can protect.	-
bc1	Indicates the BC1 bandwidth (subaddress pool bandwidth) that the bypass tunnel can protect.	-
un-limited	Indicates that there is no limit on the total bandwidth that can be protected.	-

Views

Tunnel interface view

Default Level

2: Configuration level

Usage Guidelines

The total bandwidth of LSPs protected by the bypass tunnel is not more than the bandwidth of the primary tunnel. When multiple bypass tunnels exist, the system selects a single bypass tunnel through the best-fit algorithm.

The total bandwidth of all the LSPs protected by the bypass tunnel is not greater than the bandwidth of the primary tunnel. When multiple bypass tunnels exist, the system determines the bypass tunnel through the best-fit algorithm.

Example

Configure Tunnel1 to protect the LSPs that use the BC0 bandwidth and set no limit on the bandwidth to be protected.

```
<HUAWEI> system-view
[HUAWEI] interface tunnel 1
[HUAWEI-Tunnel1] tunnel-protocol mpls te
[HUAWEI-Tunnel1] destination 2.2.2.2
[HUAWEI-Tunnel1] mpls te tunnel-id 100
[HUAWEI-Tunnel1] mpls te bypass-tunnel bandwidth bc0 un-limited
[HUAWEI-Tunnel1] mpls te commit
```

19.7.6 mpls te protect-switch manual (upgrade-compatible command)

Function

The **mpls te protect-switch manual** command sends a manual switchover request to a specified tunnel.

By default, no manual switching request for a specified tunnel is configured.

Format

mpls te protect-switch manual [**work-lsp** | **protect-lsp**]

Parameters

Parameter	Description	Value
work-lsp	Switches traffic manually to the primary tunnel.	-
protect-lsp	Switches traffic manually to a protection tunnel.	-

Views

Tunnel interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After an upgrade, this command is no longer supported, and it is replaced by the **mpls te protect-switch manual** command.

19.7.7 snmp-agent trap enable (MPLS) (upgrade-compatible command)

Function

The **snmp-agent trap enable** command enables SNMP traps with a related parameter.

The **undo snmp-agent trap enable** command disables SNMP traps with a related parameter.

Format

```
snmp-agent trap enable { static-lsp | ldp | lsp [ mplsxcup | mplsxcdown ] |  
tunnel-ps | te { tunnel-reop | te-frr [ private ] | hot-standby | ordinary |  
bandwidth-change } | [ te ] tunnel }
```

```
undo snmp-agent trap enable { static-lsp | ldp | lsp [ mplsxcup | mplsxcdown ]  
| tunnel-ps | te { tunnel-reop | te-frr [ private ] | hot-standby | ordinary |  
bandwidth-change } | [ te ] tunnel }
```

Parameters

Parameter	Description	Value
static-lsp	Enables the trap of static LSPs.	-
ldp	Enables LDP traps.	-
lsp mplsxcup	Enables the mplsXCUp trap.	-
lsp mplsxcdown	Enables the mplsXCDown trap.	-
tunnel-ps	Enables the TE protection switching trap.	-
te tunnel-reop	Enables trap of the TE route re-optimization.	-
te te-frr	Enables the public trap of TE FRR.	-
te-frr private	Enables the private trap of TE FRR.	-
te hot-standby	Enables the trap of the hot-standby CR-LSP.	-
te ordinary	Enables the trap of the ordinary CR-LSP.	-
bandwidth-change	Enables the system to send related private traps when the tunnel bandwidth changes.	-
tunnel	Enables the trap of the tunnel.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

By default, the trap function is disabled in the process of the MPLS LSP establishment.

To check the status of an LSP, run the **snmp-agent trap enable lsp { mplsxcup | mplsxcdown }** command when mplsXCUp or mplsXCDown is enabled.

After the **undo snmp-agent trap enable** command is run, information about mplsXCUp or mplsXCDown is not displayed, and the status of the trap is unchanged. When you run the **snmp-agent trap enable** command again, information about the restored trap is displayed.

Example

Enable the private trap of TE FRR.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable te te-frr private
```

Enable the mplsXCUp trap.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable lsp mplsxcup  
Warning: Enabling the alarm function will lead to the generation of excessive a  
larms. Continue? [Y/N]
```

19.7.8 snmp-agent trap enable feature-name ldp (upgrade-compatible command)

Function

The **snmp-agent trap enable feature-name ldp** command enables the trap for the MPLS LDP module.

The **undo snmp-agent trap enable feature-name ldp** command disables the trap for the MPLS LDP module.

By default, the trap is disabled for the MPLS LDP module.

Format

```
snmp-agent trap enable feature-name ldp trap-name { session-down |  
session-up }
```

```
undo snmp-agent trap enable feature-name ldp trap-name { session-down |  
session-up }
```

Parameters

Parameter	Description	Value
trap-name	Enables the trap of MPLS LDP events of a specified type.	-
session-down	Enables the trap of the event that an LDP session goes Down in the MIB.	-
session-up	Enables the trap of the event that an LDP session goes Up in the MIB.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Run the **snmp-agent trap enable feature-name ldp** command to enable the LDP session trap. Currently, all traps of the MPLS LDP module are non-excessive trap. The frequent LDP session status changes do not trigger a large number of traps.

Example

Enable the trap of the event that an LDP session is reestablished.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name ldp trap-name session-up
```

19.7.9 static-cr-lsp ingress bandwidth (upgrade-compatible command)

Function

Using the **static-cr-lsp ingress bandwidth** command, you can configure a static CR-LSP and specify its bandwidth on the ingress LSR.

By default, no static CR-LSP on the ingress LSR is configured.

Format

```
static-cr-lsp ingress { tunnel-interface tunnel interface-number | tunnel-name }  
destination destination-address { nexthop next-hop-address | outgoing-interface  
interface-type interface-number } * out-label out-label bandwidth { bc0 | bc1 }  
bandwidth
```

Parameters

Parameter	Description	Value
tunnel-interface tunnel <i>interface-number</i>	Specifies the tunnel interface of a static CR-LSP. <i>interface-number</i> indicates the tunnel interface number.	-
<i>tunnel-name</i>	Specifies the name of a CR-LSP.	The name is a string of 1 to 19 case-sensitive characters, spaces and abbreviation not supported. If you use the interface Tunnel 2 command to create a tunnel interface for a static CR-LSP, the tunnel name in the static-cr-lsp ingress command must be formatted as "Tunnel2", otherwise, the tunnel cannot be created. There is no such a limit for the transit node and egress node.
destination <i>destination-address</i>	Specifies the destination IP address of a static CR-LSP.	-
nexthop <i>next-hop-address</i>	Specifies the next-hop IP address of a static CR-LSP.	-
outgoing-interface <i>interface-type</i> <i>interface-number</i>	Specifies the type and number of an outgoing interface. This parameter is only applicable to a P2P link.	-
out-label <i>out-label</i>	Specifies the value of an outgoing label.	<i>out-label</i> is an integer ranging from 16 to 1048575.
bc0	Specifies BC0 bandwidth of a static CR-LSP.	-
bc1	Specifies BC1 bandwidth of a static CR-LSP.	-
<i>bandwidth</i>	Specifies the bandwidth required by a CR-LSP.	The value ranges from 0 to 4000000000, in kbit/s. The default value is 0.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Before setting up an MPLS TE tunnel through a static CR-LSP, configure a static route or an IGP to ensure connectivity between LSRs, and enable basic MPLS and MPLS TE functions.

Example

```
# Configure the static CR-LSP named Tunnel1, with the destination IP address  
being 10.1.3.1, the next-hop address being 10.1.1.2, the outgoing label being 237,  
and the required bandwidth being 20 kbit/s from BC0 on the ingress.
```

```
<HUAWEI> system-view  
[HUAWEI] static-cr-lsp ingress tunnel-interface Tunnel 1 destination 10.1.3.1 nexthop 10.1.1.2 out-  
label 237 bandwidth bc0 20
```

19.7.10 static-cr-lsp transit bandwidth (upgrade-compatible command)

Function

Using the **static-cr-lsp transit bandwidth** command, you can configure a static CR-LSP and specify its bandwidth on a transit LSR.

By default, no static CR-LSP on a transit LSR is configured.

Format

```
static-cr-lsp transit lsp-name [ incoming-interface interface-type interface-number ] in-label in-label { nexthop next-hop-address | outgoing-interface interface-type interface-number } * out-label out-label bandwidth { bc0 | bc1 } bandwidth [ description description ]
```

Parameters

Parameter	Description	Value
<i>lsp-name</i>	Specifies the CR-LSP name.	The name is a string of 1 to 19 case-sensitive characters, spaces not supported.
incoming-interface <i>interface-type interface-number</i>	Specifies the name of an incoming interface.	-
in-label <i>in-label</i>	Specifies the value of an incoming label.	An integer ranging from 16 to 1023
nexthop <i>next-hop-address</i>	Specifies the next-hop address.	-
outgoing-interface <i>interface-type interface-number</i>	Specifies the name of an outgoing interface.	-

Parameter	Description	Value
out-label <i>out-label</i>	Specifies the value of an outgoing label.	An integer ranging from 16 to 1048575.
bc0	Obtains the bandwidth from BC0.	-
bc1	Obtains the bandwidth from BC1.	-
<i>bandwidth</i>	Specifies the bandwidth required by a CR-LSP.	The value ranges from 0 to 4000000000, in kbit/s. The default value is 0.
description <i>description</i>	Specifies the description information.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Before setting up an MPLS TE tunnel through a static CR-LSP, configure a static route or an IGP to ensure connectivity between LSRs, and enable basic MPLS and MPLS TE functions.

Example

Configure the static CR-LSP named tunnel34, with the incoming interface being VLANIF10, the incoming label being 123, the outgoing interface being VLANIF20, the outgoing label as 253, the required BC0 bandwidth being 20 kbit/s on the transit node.

```
<HUAWEI> system-view
[HUAWEI] static-cr-lsp transit tunnel34 incoming-interface vlanif 10 in-label 123 outgoing-interface
vlanif 20 out-label 253 bandwidth bc0 20
```

19.7.11 undo mpls te auto-frr (upgrade-compatible command)

Function

The **undo mpls te auto-frr** command disables MPLS TE Auto FRR in the interface view.

Format

undo mpls te auto-frr

Parameters

None

Views

Interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **mpls te auto-frr block** command.

19.8 VPN compatible command

19.8.1 display ipv6 prefix-limit statistics (upgrade-compatible command)

Function

The **display ipv6 prefix-limit statistics** command displays the statistics of the prefix limits of IPv6 VPN instances.

Format

```
display ipv6 prefix-limit { all-vpn6-instance | vpn6-instance vpn-instance-name } statistics
```

Parameters

Parameter	Description	Value
all-vpn6-instance	Indicates all IPv6 VPN instances.	-
vpn6-instance <i>vpn-instance-name</i>	Specifies the name of an IPv6 VPN instance.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

You can run the **display ipv6 prefix-limit statistics** command to view the number of times that a protocol re-adds or deletes routes according to the prefix limit of a specified IPv6 VPN instance.

Example

Display the statistics of the prefix limits of all IPv6 VPN instances.

```
<HUAWEI> display ipv6 prefix-limit all-vpn6-instance statistics
-----
IPv6 VPN instance name: vrf1
      DenyAdd TryAddInDelState NotifyDelAll NotifyDelFinish NotifyAddRoute
DIRECT      0          0          0          0          0
STATIC      0          0          0          0          0
OSPFv3      11          3          1          0          5
IS-IS      106         0          1          0          5
RIPng       98          0          1          1          5
BGP          2          0          1          1          5
-----
IPv6 VPN instance name: VPN123
      DenyAdd TryAddInDelState NotifyDelAll NotifyDelFinish NotifyAddRoute
DIRECT      0          0          0          0          0
STATIC      0          0          0          0          0
OSPFv3      11          3          1          0          5
IS-IS      106         0          1          0          5
RIPng       98          0          1          1          5
BGP          2          0          1          1          5
```

Table 19-3 Description of the display ipv6 prefix-limit statistics command output

Item	Description
DenyAdd	Number of routes that the protocol fails to add to the RIB because of the prefix limit.
TryAddInDelState	Number of routes that the protocol fails to add to the RIB because the RIB is in the process of deleting routes.
NotifyDelAll	Number of times that the RIB notifies the protocol of deleting routes when the prefix limit is decreased.
NotifyDelFinish	Number of times that the protocol notifies the RIB of completion of deleting routes.
NotifyAddRoute	Number of times that the RIB notifies the protocol of re-adding routes.

Display the statistics of the prefix limit of the IPv6 VPN instance named **vrf1**.

```
<HUAWEI> display ipv6 prefix-limit vpn6-instance vrf1 statistics
-----
```

```
IPv6 VPN instance name: vrf1
DenyAdd TryAddInDelState NotifyDelAll NotifyDelFinish NotifyAddRoute
DIRECT      0      0      0      0      0
STATIC      0      0      0      0      0
OSPFv3      11     3      1      0      5
IS-IS      106    0      1      0      5
RIPng       98     0      1      1      5
BGP         2      0      1      1      5
```

19.8.2 display ipv6 vpn-instance (upgrade-compatible command)

Function

The **display ipv6 vpn6-instance** command displays information about an IPv6 VPN instance.

Format

display ipv6 vpn6-instance [**brief** | **verbose**] [*vpn6-instance-name*]

Parameters

Parameter	Description	Value
brief	Displays summary information about an IPv6 VPN instance.	-
verbose	Displays detailed information about the IPv6 VPN instances and their associated interfaces.	-
<i>vpn6-instance-name</i>	Specifies the name of an IPv6 VPN instance.	The name is a string of 1 to 31 case-sensitive characters.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

If a VPN instance is configured, you can check the configuration of the instance by using the **display ipv6 vpn6-instance** command. You can also use this command to view the VPN instances configured on the local device.

When no parameters are specified, the command displays brief information about all the configured VPN instances.

Example

View brief information about all the configured IPv6 VPN instances.

```
<HUAWEI> display ipv6 vpn6-instance
Total VPN-Instances configured : 3
Total IPv4 VPN-Instances configured : 2
Total IPv6 VPN-Instances configured : 1

VPN-Instance Name      RD          Address-family
vpn1
vpna                    100:1      IPv4
vpna                    100:3      IPv6
vpnb                    100:2      IPv4
```

Table 19-4 Description of the display ip vpn-instance command output

Item	Description
Total VPN-Instances configured	Total number of VPN instances configured on the local end.
Total IPv4 VPN-Instances configured	Total number of locally configured VPN instances for which IPv4 address families are enabled.
Total IPv6 VPN-Instances configured	Total number of locally configured VPN instances for which IPv6 address families are enabled.
VPN-Instance Name	Name of the VPN instance.
RD	RD of the VPN instance IPv4 address family or IPv6 address family.
Creation Time	Time when an IPv4 or IPv6 address family is enabled for the VPN instance.
Address-family	Address family enabled for the VPN instance. The address family can be: <ul style="list-style-type: none"> Null, if no address family is enabled. ipv4, if only the IPv4 address family is enabled. ipv6, if only the IPv6 address family is enabled.

```
<HUAWEI> display ipv6 vpn6-instance brief
Total VPN-Instances configured : 3
Total IPv4 VPN-Instances configured : 2
Total IPv6 VPN-Instances configured : 1

VPN-Instance Name      RD          Address-family
vpn1
vpna                    100:1      IPv4
vpna                    100:3      IPv6
vpnb                    100:2      IPv4
```

View detailed information about all IPv6 VPN instances.

```
<HUAWEI> display ipv6 vpn-instance verbose
Total VPN-Instances configured      : 1
Total IPv4 VPN-Instances configured : 1
Total IPv6 VPN-Instances configured : 1

VPN-Instance Name and ID : vpna, 6
Description : vpna-1
Service ID : 12
Interfaces : Vlanif10
Address family ipv4
Create date : 2012/12/3 15:36:20 UTC+08:00
Up time : 6 days, 04 hours, 41 minutes and 57 seconds
Route Distinguisher : 100:1
Export VPN Targets : 1:1
Import VPN Targets : 1:1
Label Policy : label per instance
Per-Instance Label : 1024
IP FRR Route Policy : 20
VPN FRR Route Policy : 12
Import Route Policy : 10
Export Route Policy : 20
Tunnel Policy : bindTE
Maximum Routes Limit : 2000
Threshold Routes Limit : 80%
Maximum Prefixes Limit : 1024
Threshold Prefixes Limit : 50%
Install Mode : route-unchanged
Log Interval : 10
Address family ipv6
Create date : 2012/12/3 15:36:20 UTC+08:00
Up time : 6 days, 04 hours, 41 minutes and 57 seconds
Log Interval : 5
```

Table 19-5 Description of the display ip vpn-instance verbose command output

Item	Description
Total VPN-Instances configured	Total number of VPN instances configured on the local end.
Total IPv4 VPN-Instances configured	Total number of locally configured VPN instances for which IPv4 address families are enabled.
Total IPv6 VPN-Instances configured	Total number of locally configured VPN instances for which IPv6 address families are enabled.
VPN-Instance Name and ID	Name and ID of the VPN instance. The ID is assigned by the system, which facilitates indexing.
Description	Description of the VPN instance. This field is displayed in the command output only when the description (VPN instance view) command is used.

Item	Description
Service ID	Service ID of the VPN instance. This item is displayed only after the service-id (VPN instance view) command is run in the VPN instance view.
Interfaces	Interfaces bound to the VPN instance. This field is displayed only after the ip binding vpn-instance command is configured on these interfaces.
Address family ipv4	Information about the IPv4 address family enabled for the VPN instance.
Address family ipv6	Information about the IPv6 address family enabled for the VPN instance.
Create date	Time when the VPN instance is created.
Up time	Period during which the VPN instance maintains in the Up state.
Route Distinguisher	RD of the VPN instance IPv4 address family or IPv6 address family
Export VPN Targets	Route Target list in the outbound direction. To set the VPN target, run the vpn-target command.
Import VPN Targets	Route Target list in the inbound direction. To set the VPN target, run the vpn-target command.
Label Policy	Label policy: <ul style="list-style-type: none"> • label per instance: indicates that the same label is allocated to routes of a VPN instance. This field is displayed in the command output only when the apply-label per-instance command is run in the VPN instance view. • label per route: indicates that each route of a VPN instance is assigned a label. Label allocation for routes of a VPN instance is implemented in this mode.

Item	Description
Per-Instance Label	Label value used when all VPN routes of the VPN instance address family share one label. This field is displayed only after the apply-label per-instance command is run in the VPN instance address family view.
IP FRR Route Policy	IP FRR route policy used for the address family. This item is displayed only after the ip frr command is run in the VPN instance IPv4 address family view.
VPN FRR Route Policy	VPN FRR route policy used for the address family. This item is displayed only after the vpn frr command is run in the VPN instance IPv4 address family view.
Import Route Policy	Import Route-Policy applied to the VPN instance. This field is displayed only after the import route-policy command is run in the VPN instance address family view.
Export Route Policy	Export Route-Policy applied to the VPN instance. This field is displayed only after the export route-policy command is run in the VPN instance address family view.
Tunnel Policy	Tunnel policy applied to the VPN instance. This field is displayed only after the tnl-policy command is run in the VPN instance address family view.
Maximum Routes Limit	Maximum number of routes supported by the current address family. This field is displayed only after the routing-table limit command is run in the VPN instance address family view.
Threshold Routes Limit	Percentage of the maximum number of routes specified for the current address family. When the maximum number of routes reaches the percentage threshold, an alarm is generated. This field is displayed only after the routing-table limit command is run in the VPN instance address family view.

Item	Description
Maximum Prefixes Limit	Maximum number of prefixes supported by the current address family of the VPN instance. This field is displayed only after the prefix limit command is run in the VPN instance address family view.
Threshold Prefixes Limit	Percentage of the maximum number of prefixes specified for the current address family of the VPN instance. When the maximum number of prefixes reaches the percentage threshold, an alarm is generated. This field is displayed only after the prefix limit command is run in the VPN instance address family view.
Install Mode	Method of processing routes. The prefix limit command can be used to specify the route processing method when the threshold is lowered due to the number of route prefixes exceeding the upper threshold. <ul style="list-style-type: none">• If route-unchanged is configured, routes in the routing information base (RIB) table remain unchanged.• If route-unchanged is not configured, all routes in the RIB table are deleted and the routes are re-installed in the RIB table.
Log Interval	Interval for displaying log messages when the number of VPN instance routes exceeds the maximum value. The default interval is 5 seconds. The value can be set by the command limit-log-interval .

19.8.3 ipv6 binding vpn6-instance (upgrade-compatible command)

Function

The **ipv6 binding vpn6-instance** command binds the current interface to an IPv6 VPN instance.

The **undo ipv6 binding vpn6-instance** command unbinds the current interface from an IPv6 VPN instance.

By default, an interface is a public network interface and is not bound to any IPv6 VPN instance.

Format

ipv6 binding vpn6-instance *vpn6-instance-name*

undo ipv6 binding vpn6-instance *vpn6-instance-name*

Parameters

Parameter	Description	Value
<i>vpn6-instance-name</i>	Specifies the name of an IPv6 VPN instance.	The name is a string of 1 to 31 case-sensitive characters.

Views

Interface view

Default Level

2: Configuration level

Usage Guidelines

After an IPv6 VPN instance is created, the device interfaces belonging to the IPv6 VPN instance need to be bound to the instance; otherwise, the interfaces are public network interfaces.

After an interface is bound to an IPv6 VPN instance or an interface is unbound from an IPv6 VPN instance, the Layer 3 features such as the IPv6 address and IPv6 routing protocol configured on this interface are deleted.

19.8.4 ipv6 vpn6-instance (upgrade-compatible command)

Function

The **ipv6 vpn6-instance** command creates an IPv6 VPN instance and displays the IPv6 VPN instance view.

The **undo ipv6 vpn6-instance** command deletes a specified IPv6 VPN instance.

By default, no IPv6 VPN instance exists.

Format

ipv6 vpn6-instance *vpn6-instance-name*

undo ipv6 vpn6-instance *vpn6-instance-name*

Parameters

Parameter	Description	Value
<i>vpn6-instance-name</i>	Specifies the name of an IPv6 VPN instance.	The name is a string of 1 to 31 case-sensitive characters without any spaces.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After this command is run, an IPv6 VPN instance is created and the IPv6 VPN instance view is displayed.

19.8.5 link-alive (upgrade-compatible command)

Function

The **link-alive** command enables the link-alive function on a GRE tunnel.

The **undo link-alive** command disables the link-alive function on a GRE tunnel.

By default, the link-alive function is disabled on a GRE tunnel.

Format

link-alive [**period** *period*] [**retry-times** *retry-times*]

undo link-alive

Parameters

Parameter	Description	Value
<i>period</i>	Specifies the interval for sending link-alive packets.	The value is an integer that ranges from 1 to 32767, in seconds. The default value is 5.
retry-times <i>retry-times</i>	Specifies the tunnel-unreachable counter value.	The value is an integer that ranges from 1 to 255. The default value is 3.

Views

Tunnel interface view

Default Level

2: Configuration level

Usage Guidelines

The link-alive function takes effect on a GRE tunnel immediately after you run the **link-alive** command on the tunnel interface. After you run the **undo link-alive** command, the link-alive function immediately becomes invalid. The source end of a GRE tunnel periodically sends link-alive packets. The tunnel-unreachable counter increases by 1 every time a link-alive packet is sent. If the source end does not receive any response packet when the tunnel-unreachable counter value reaches *retry-times*, the source end considers the remote end unreachable.

Example

Enable the link-alive function on a GRE tunnel and retain the default parameter values.

```
<HUAWEI> system-view
[HUAWEI] interface tunnel 1
[HUAWEI-Tunnel1] tunnel-protocol gre
[HUAWEI-Tunnel1] link-alive
```

Disable the link-alive function on a GRE tunnel.

```
<HUAWEI> system-view
[HUAWEI] interface tunnel 1
[HUAWEI-Tunnel1] undo link-alive
```

Enable the link-alive function on a GRE tunnel. Set the interval for sending link-alive packets to 12 seconds and retain the default tunnel-unreachable counter value.

```
<HUAWEI> system-view
[HUAWEI] interface tunnel 1
[HUAWEI-Tunnel1] link-alive period 12
```

Enable the link-alive function on a GRE tunnel. Set the interval for sending link-alive packets to 12 seconds and the tunnel-unreachable counter to 4.

```
<HUAWEI> system-view
[HUAWEI] interface tunnel 1
[HUAWEI-Tunnel1] link-alive period 12 retry-times 4
```

19.8.6 snmp-agent trap enable feature-name l3vpn (upgrade-compatible command)

Function

The **snmp-agent trap enable feature-name l3vpn** command enables the trap function for the L3VPN module.

The **undo snmp-agent trap enable feature-name l3vpn** command disables the trap function for the L3VPN module.

By default, the trap function for the L3VPN module is disabled.

Format

**snmp-agent trap enable feature-name l3vpn trap-name
l3vpn_mib_trap_mid_exceed**

**undo snmp-agent trap enable feature-name l3vpn trap-name
l3vpn_mib_trap_mid_exceed**

Parameters

Parameter	Description	Value
trap-name	Enables the traps of L3VPN events of specified types.	-
l3vpn_mib_trap_mid_exceed	Enables the trap of the event indicating that the number of private route prefixes exceeds the middle threshold.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The Simple Network Management Protocol (SNMP) is a standard network management protocol widely used on TCP/IP networks. It uses a central computer (a network management station) that runs network management software to manage network elements. The management agent on the network element automatically reports traps to the network management station. After that, the network administrator immediately takes measures to resolve the problem.

The **snmp-agent trap enable feature-name l3vpn** command enables the trap function for L3VPN modules.

Example

Enable the trap of the event indicating that the number of private route prefixes exceeds the middle threshold in the system view.

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable feature-name l3vpn trap-name l3vpn_mib_trap_mid_exceed
```

19.8.7 snmp-agent trap enable l3vpn (upgrade-compatible command)

Function

The **snmp-agent trap enable l3vpn** command enables the device to send the L3VPN trap message.

The **undo snmp-agent trap enable l3vpn** command prohibits the device from sending the L3VPN trap message.

By default, the L3VPN trap message cannot be sent.

Format

snmp-agent trap enable l3vpn

undo snmp-agent trap enable l3vpn

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

None

Example

```
# Permit the device to send the L3VPN trap message.
```

```
<HUAWEI> system-view  
[HUAWEI] snmp-agent trap enable l3vpn
```

19.8.8 sa authentication-hex (upgrade-compatible command)

Function

The **sa authentication-hex** command sets an authentication in hexadecimal format or cipher text for Security Associations (SAs).

Format

sa authentication-hex { **inbound** | **outbound** } { **ah** | **esp** } **plain** *hex-plain-key*

Parameters

Parameter	Description	Value
inbound	Specifies SA parameters for incoming packets.	-

Parameter	Description	Value
outbound	Specifies SA parameters for outgoing packets.	-
ah	Specifies SA parameters for Authentication Header (AH). If the security proposal applied to an SA uses AH, ah must be configured in the sa authentication-hex command.	-
esp	Specifies SA parameters for Encapsulating Security Payload (ESP). If the security proposal applied to an SA uses ESP, esp must be configured in the sa authentication-hex command.	-
plain	Indicates the plain text used for authentication.	-
<i>hex-plain-key</i>	Specifies the plain text key.	<p>The value is in hexadecimal notation.</p> <ul style="list-style-type: none"> • If authentication algorithm Message Digest 5 (MD5) is used, the length of the key is 16 bytes. • If authentication algorithm Secure Hash Algorithm-1 (SHA-1) is used, the length of the key is 20 bytes. • If authentication algorithm SHA2-256 is used, the length of the key is 32 bytes. <p>NOTE</p> <p>The MD5 and SHA-1 authentication algorithms have security risks; therefore, you are advised to use SHA-256 preferentially.</p>

Views

SA view

Default Level

3: Management level

Usage Guidelines

This command is upgrade compatible and can be executed during configuration recovery. Users cannot manually configure this command.

After the upgrade, this command is no longer supported, and it is replaced by the **sa authentication-hex** command.

19.8.9 sa encryption-hex (upgrade-compatible command)

Function

The **sa encryption-hex** command configures an encryption key for manual Security Association (SA) in hexadecimal format.

Format

sa encryption-hex { **inbound** | **outbound** } { **ah** | **esp** } **plain** *hex-plain-key*

Parameters

Parameter	Description	Value
inbound	Specifies SA parameters for incoming packets.	-
outbound	Specifies SA parameters for outgoing packets.	-
ah	Specifies SA parameters for Authentication Header (AH). If the security proposal applied to an SA uses AH, ah must be configured in the sa encryption-hex command.	-
esp	Specifies SA parameters for Encapsulating Security Payload (ESP). If the security proposal applied to an SA uses ESP, esp must be configured in the sa encryption-hex command.	-
plain	Indicates the plaintext used for authentication.	-

Parameter	Description	Value
<i>hex-plain-key</i>	Specifies the plaintext key.	<p>The value is in hexadecimal notation.</p> <ul style="list-style-type: none">• If encryption algorithm Data Encryption Standard (DES) is used, the length of the key is 8 bytes.• If encryption algorithm Triple Data Encryption Standard (3DES) is used, the length of the key is 24 bytes.• If encryption algorithm Advanced Encryption Standard 128 (AES-128) is used, the length of the key is 16 bytes.• If encryption algorithm AES-192 is used, the length of the key is 24 bytes.• If encryption algorithm AES-256 is used, the length of the key is 32 bytes. <p>NOTE</p> <p>The DES and 3DES encryption algorithms have security risks; therefore, you are advised to use AES-128, AES-192 or AES-256 preferentially.</p>

Views

SA view

Default Level

3: Management level

Usage Guidelines

This command is upgrade compatible and can be executed during configuration recovery. Users cannot manually configure this command.

After the upgrade, this command is no longer supported, and it is replaced by the **sa encryption-hex** command.

19.8.10 sa string-key (upgrade-compatible command)

Function

The **sa string-key** command configures an authentication key in the string format.

Format

sa string-key { **inbound** | **outbound** } { **ah** | **esp** } **plain** *string-plain-key*

Parameters

Parameter	Description	Value
inbound	Specifies SA parameters for incoming packets.	-
outbound	Specifies SA parameters for outgoing packets.	-
ah	Specifies SA parameters for Authentication Header (AH). If the security proposal applied to an SA uses AH, ah must be configured in the sa string-key command.	-
esp	Specifies SA parameters for Encapsulating Security Payload (ESP). If the security proposal applied to an SA uses ESP, esp must be configured in the sa string-key command.	-
plain	Indicates the plaintext used for authentication.	-
<i>string-plain-key</i>	Specifies the plaintext key.	The value is a string of 1 to 127 case-sensitive characters.

Views

SA view

Default Level

3: Management level

Usage Guidelines

This command is upgrade compatible and can be executed during configuration recovery. Users cannot manually configure this command.

After the upgrade, this command is no longer supported, and it is replaced by the **sa string-key** command.

19.9 WLAN Compatible Commands

19.9.1 agc-threshold low

Function

The **agc-threshold low** command sets the receiver sensitivity threshold of an AP.

The **undo agc-threshold low** command restores the default receiver sensitivity threshold of an AP.

By default, the receiver sensitivity threshold of an AP is -128 dBm.

Format

agc-threshold low *low-threshold*

undo agc-threshold low

Parameters

Parameter	Description	Value
<i>low-threshold</i>	Specifies the receiver sensitivity threshold of an AP.	The value is an integer that ranges from -128 to -40, in dBm.

Views

2G radio profile view, 5G radio profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the configuration is restored, this command is restored to **rx-sensitivity threshold**.

19.9.2 anti-attack broadcast-flood blacklist disable (upgrade-compatible command)

Function

The **anti-attack broadcast-flood blacklist disable** command disables the broadcast flood blacklist function.

The **undo anti-attack broadcast-flood blacklist disable** command enables the broadcast flood blacklist function.

By default, the broadcast flood blacklist function is disabled.

Format

anti-attack broadcast-flood blacklist disable

undo anti-attack broadcast-flood blacklist disable

Parameters

None

Views

VAP profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After the broadcast flood blacklist function is enabled, the device considers traffic with a rate higher than that specified in **anti-attack broadcast-flood sta-rate-threshold** *sta-rate-threshold* a broadcast flood attack and adds the STA to the blacklist.

Prerequisites

The broadcast flood detection function has been enabled using the **undo anti-attack broadcast-flood sta-rate-threshold** command.

19.9.3 anti-attack broadcast-flood blacklist enable (upgrade-compatible command)

Function

The **anti-attack broadcast-flood blacklist enable** command enables the broadcast flood blacklist function.

The **undo anti-attack broadcast-flood blacklist enable** command disables the broadcast flood blacklist function.

By default, the broadcast flood blacklist function is disabled.

Format

anti-attack broadcast-flood blacklist enable

undo anti-attack broadcast-flood blacklist enable

Parameters

None

Views

VAP profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.4 anti-attack broadcast-flood disable (upgrade-compatible command)

Function

The **anti-attack broadcast-flood disable** command disables the broadcast flood detection function.

The **undo anti-attack broadcast-flood disable** command enables the broadcast flood detection function.

By default, the broadcast flood detection function is enabled.

Format

anti-attack broadcast-flood disable

undo anti-attack broadcast-flood disable

Parameters

None

Views

VAP profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.5 anti-attack broadcast-flood sta-rate-threshold (upgrade-compatible command)

Function

The **anti-attack broadcast-flood sta-rate-threshold** command sets the broadcast flood threshold.

The **undo anti-attack broadcast-flood sta-rate-threshold** command restores the default broadcast flood threshold.

By default, the broadcast flood threshold is 10 pps.

Format

anti-attack broadcast-flood sta-rate-threshold *sta-rate-threshold*

undo anti-attack broadcast-flood sta-rate-threshold

Parameters

Parameter	Description	Value
<i>sta-rate-threshold</i>	Specifies the rate threshold of broadcast traffic from STAs.	The value is an integer that ranges from 5 to 5000, in pps.

Views

VAP profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.6 ap-location (upgrade-compatible command)

Function

ap-location command sets the latitude and longitude of an AP.

By default, no latitude or longitude is configured for an AP.

Format

ap-location longitude { **e** | **w** } *longitude-value* **latitude** { **s** | **n** } *latitude-value*

ap-location latitude { s | n } *latitude-value* longitude { e | w } *longitude-value*

Parameters

Parameter	Description	Value
longitude e <i>longitude-value</i>	Specifies the east longitude value of an AP.	<p>The value supports two formats: degrees, minutes, and seconds (DMS) and decimal degrees (DD).</p> <ul style="list-style-type: none"> The DMS format is XXX-XX-XX. XXX ranges from 0 to 180, and XX ranges from 0 to 59. The DD format is XXX.XXXXXXXXXX. XXX ranges from 0 to 180, and XXXXXXXXXX is a decimal supporting a maximum of 9 digits. <p>For example, the east longitude value of an AP can be set to longitude e 120-45-23 in DMS format and longitude e 120.756333333 in DD format.</p>
longitude w <i>longitude-value</i>	Specifies the west longitude value of an AP.	<p>The value supports two formats: DMS and DD.</p> <ul style="list-style-type: none"> The DMS format is XXX-XX-XX. XXX ranges from 0 to 180, and XX ranges from 0 to 59. The DD format is XXX.XXXXXXXXXX. XXX ranges from 0 to 180, and XXXXXXXXXX is a decimal supporting a maximum of 9 digits. <p>For example, the west longitude value of an AP can be set to longitude w 120-45-23 in DMS format and longitude w 120.756333333 in DD format.</p>
latitude s <i>latitude-value</i>	Specifies the south longitude value of an AP.	<p>The value supports two formats: DMS and DD.</p> <ul style="list-style-type: none"> The DMS format is XX-XX-XX. The first XX ranges from 0 to 90, and the other XXs range from 0 to 59. The DD format is XX.XXXXXXXXXX. XX ranges from 0 to 90, and XXXXXXXXXX is a decimal supporting a maximum of 9 digits. <p>For example, the south longitude value of an AP can be set to latitude s 78-45-23 in DMS format and latitude s 78.756333333 in DD format.</p>

Parameter	Description	Value
latitude n <i>latitude-value</i>	Specifies the north longitude value of an AP.	The value supports two formats: DMS and DD. <ul style="list-style-type: none">The DMS format is XX-XX-XX. The first XX ranges from 0 to 90, and the other XXs range from 0 to 59.The DD format is XX.XXXXXXXXXX. XX ranges from 0 to 90, and XXXXXXXXXX is a decimal supporting a maximum of 9 digits. For example, the north longitude value of an AP can be set to latitude n 78-45-23 in DMS format and latitude n 78.756333333 in DD format.

Views

AP view

Default Level

2: Configuration level

Usage Guidelines

You can run this command to set the longitude and latitude of an AP for easily locating it.

19.9.7 **calibrate auto-channel-select disable** (upgrade-compatible command)

Function

The **calibrate auto-channel-select disable** command disables automatic channel selection.

The **undo calibrate auto-channel-select disable** command enables automatic channel selection.

By default, automatic channel selection is enabled.

Format

calibrate auto-channel-select disable

undo calibrate auto-channel-select disable

Parameters

None

Views

RRM profile view

Default Level

2: Configuration level

Usage Guidelines

Two channel selection modes are available:

- Automatic mode (enabling automatic channel selection): An AP automatically selects a proper channel based on the WLAN radio environment, removing the need to specify channels manually.
- Fixed mode (disabling automatic channel selection): Channels must be manually specified.

The automatic mode (automatic channel selection) is recommended because you do not need to specify a channel for each radio. The fixed mode provides users with an alternative way when they want to specify channels by themselves or to avoid frequent channel adjustment (this may cause intermittent service interruption).

If an AP needs radio calibration, automatic channel selection must be enabled.

NOTE

When automatic channel selection is enabled, the manually configured channels do not take effect to ensure that the radio works in the optimal channel environment.

19.9.8 calibrate auto-txpower-select disable (upgrade-compatible command)

Function

The **calibrate auto-txpower-select disable** command disables automatic transmit power selection.

The **undo calibrate auto-txpower-select disable** command enables automatic transmit power selection.

By default, automatic transmit power selection is enabled.

Format

calibrate auto-txpower-select disable

undo calibrate auto-txpower-select disable

Parameters

None

Views

RRM profile view

Default Level

2: Configuration level

Usage Guidelines

Two power selection modes are available:

- Automatic mode (enabling automatic transmit power selection): An AP automatically selects or adjusts the transmit power based on the WLAN radio environment, removing the need to specify AP power manually.
- Fixed mode (disabling automatic transmit power selection): The transmit power must be manually specified.

If an AP needs radio calibration, automatic transmit power selection must be enabled.

19.9.9 calibrate error-rate-threshold (upgrade-compatible command)

Function

The **calibrate error-rate-threshold** command sets the retransmission rate threshold.

The **undo calibrate error-rate-threshold** command restores the default retransmission rate threshold.

By default, the retransmission rate threshold is 60%.

Format

calibrate error-rate-threshold *error-rate-threshold*

undo calibrate error-rate-threshold

Parameters

Parameter	Description	Value
<i>error-rate-threshold</i>	Specifies the retransmission rate threshold.	The value is an integer that ranges from 20 to 100, in percentage.

Views

RRM profile view

Default Level

2: Configuration level

Usage Guidelines

The retransmission rate is the ratio of retransmitted packets to all packets sent by a radio.

The retransmission rate threshold determines whether the radio environment is normal. When the retransmission rate of a radio reaches the threshold, the system considers that the radio environment deteriorates. When this occurs, the system may start radio calibration or take measures to avoid signal interference.

19.9.10 calibrate noise-threshold (upgrade-compatible command)

Function

The **calibrate noise-threshold** command specifies the noise floor threshold for triggering radio calibration.

The **undo calibrate noise-threshold** command restores the default noise floor threshold for triggering radio calibration.

The default noise floor threshold for triggering radio calibration is -75 dBm.

Format

calibrate noise-threshold *threshold*

undo calibrate noise-threshold

Parameters

Parameter	Description	Value
noise-threshold <i>threshold</i>	Specifies the noise floor threshold for triggering radio calibration.	The value is an integer that ranges from -95 to 0, in dBm.

Views

RRM profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

The noise floor indicates the noise strength in the current environment. A high noise floor value will make noise drown out valid data, affecting user services.

The noise floor threshold for triggering radio calibration can be used to determine whether the environment noise is normal. When detecting a noise floor value higher than the threshold, an AP reports a high noise floor message to the AC. The AC then performs radio calibration to avoid channels with high noise floor values to improve user experience.

19.9.11 calibrate policy (upgrade-compatible command)

Function

The **calibrate policy** command creates a radio calibration policy.

The **undo calibrate policy** command deletes a radio calibration policy.

By default, no radio calibration policy is created.

Format

calibrate policy noise

undo calibrate policy noise

Parameters

Parameter	Description	Value
noise	Indicates the noise floor mode.	-

Views

WLAN view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Noise floor policy: When the noise floor of APs is high due to special external interference, service experience may deteriorate. With this radio calibration policy, the device takes actions to avoid interference. When detecting that the noise floor of the current channel exceeds the threshold for three consecutive times, an AP notifies the AC of the high noise floor. The AC then allocates another channel to the AP and does not allocate the current channel to the AP in 30 minutes.

Prerequisites

The noise floor threshold for triggering radio calibration has been specified using the **calibrate noise-floor-threshold** *threshold* command.

19.9.12 contain-mode (upgrade-compatible command)

Function

The **contain-mode** command sets the wireless intrusion protection system (WIPS) mode.

The **undo contain-mode** command deletes the WIPS mode.

By default, no WIPS mode is set.

Format

contain-mode all

undo contain-mode all

Parameters

Parameter	Description	Value
all	Sets WIPS against all unauthorized devices.	-

Views

WIDS profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.13 dot11r private

Function

The **dot11r private** command enables the Huawei's proprietary 802.11r function.

The **undo dot11r private** command disables the Huawei's proprietary 802.11r function.

By default, Huawei's proprietary 802.11r is disabled.

Format

dot11r private

undo dot11r private

Parameters

None

Views

SSID profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Due to the characteristics of Wi-Fi and different behaviors of different terminals on the WLAN, the actual roaming experience for the terminals varies. The roaming experience for latency-sensitive services such as audio, video, and gaming cannot be guaranteed. Roaming optimization policies are different for terminals and APs and may conflict with each other. Therefore, simply optimization for terminals or APs cannot solve the problem. AirEngine series APs (except the AirEngine 5760-10) are optimized for Huawei terminals running EMUI 10.0 or later. After the Huawei's proprietary 802.11r function is enabled, APs can carry the interworking IE in Beacon and Probe Response frames and perform roaming negotiation with Huawei terminals based on the specified frame format and interaction action. This function implements mutual trust and interworking between devices and pipes, reduces resource overheads during roaming negotiation, and effectively improves roaming experience.

Precautions

- Security policies supported by 802.11r include open system, WPA2+PSK+AES, WPA2+PPSK+AES, and WPA2+802.1X+AES.
- The 802.11r and Protected Management Frame (PMF) functions are mutually exclusive. If the 802.11r function has been configured, the PMF function cannot be configured.

Example

Enable the Huawei's proprietary 802.11r function.

```
<HUAWEI> system-view
[HUAWEI] wlan
[HUAWEI-wlan-view] ssid-profile name ssid1
[HUAWEI-wlan-ssid-prof-ssid1] dot11r private
```

19.9.14 frame-format (serial profile view) (upgrade-compatible command)

Function

The **frame-format** command configures the format for serial frames on an IoT card interface.

The **undo frame-format** command restores the configured format for serial frames to the default value.

By default, the frame format is **frame-start-stop**.

Format

frame-format { **fixed-length** | **frame-start-stop** }

undo frame-format

Parameters

Parameter	Description	Value
fixed-length	Specifies a fixed frame length.	-
frame-start-stop	Specifies the start and stop flags for frames.	-

Views

Serial profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.15 frame-length (serial profile view) (upgrade-compatible command)

Function

The **frame-length** command configures the length for serial frames on an IoT card interface.

The **undo frame-length** command restores the configured length for serial frames to the default value.

By default, the frame length is 512 bytes.

Format

frame-length *frame-length-value*

undo frame-length

Parameters

Parameter	Description	Value
<i>frame-length-value</i>	<ul style="list-style-type: none">If the frame format adopts a fixed length, this parameter is used for framing.If the frame format is set to frame-start-stop, this parameter specifies the maximum frame length used to verify the validity of framing.	The value is an integer that ranges from 1 to 280, in bytes.

Views

Serial profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.16 frame-start (serial profile view) (upgrade-compatible command)

Function

The **frame-start** command configures the start flag byte for serial frames on an IoT card slot.

The **undo frame-start** command restores the configured start flag byte to the default value.

By default, the start flag byte is aa.

Format

frame-start *frame-start-value*

undo frame-start

Parameters

Parameter	Description	Value
<i>frame-start-value</i>	Specifies the start flag byte of a frame.	The value ranges from 0 to ff.

Views

Serial profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.17 frame-stop (serial profile view) (upgrade-compatible command)

Function

The **frame-stop** command configures the stop flag byte for serial frames on an IoT card slot.

The **undo frame-stop** command restores the configured stop flag byte to the default value.

By default, the stop flag byte is 7e.

Format

frame-stop *frame-stop-value*

undo frame-stop

Parameters

Parameter	Description	Value
<i>frame-stop-value</i>	Specifies the stop flag byte of a frame.	The value ranges from 0 to ff.

Views

Serial profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.18 gap-threshold (upgrade-compatible command)

Function

The **gap-threshold** command sets the load difference threshold for load balancing based on the number of users in a static load balancing group.

The **undo gap-threshold** command restores the default load difference threshold for load balancing based on the number of users in a static load balancing group.

By default, the load difference threshold of a static load balancing group is 20%.

Format

gap-threshold *gap-threshold-value*

undo gap-threshold

Parameters

Parameter	Description	Value
gap-threshold <i>gap-threshold-value</i>	Specifies the load difference threshold for load balancing based on the number of users in a static load balancing group.	The value is an integer that ranges from 1 to 100. It indicates the threshold of the load difference among radios in a load balancing group, in percentage. The load difference refers to the difference between the number of users on radios.

Views

Static load balancing group view

Default Level

2: Configuration level

Usage Guidelines

After the load difference threshold for load balancing based on the number of users is configured using the **gap-threshold** command, an AP implements load balancing based on the difference between the number of users on different radios. The load balancing algorithm is as follows:

The AC calculates the load percentage of each radio in a load balancing group using the formula: Load percentage of a radio = (Number of associated users on the radio/Maximum number of users allowed on the radio) x 100%. The AC compares load percentages of all radios in the load balancing group and obtains the smallest load percentage value. When a user requests to associate with an AP radio, the AC calculates the difference between the radio's load percentage and the smallest load percentage value and compares the load difference with the threshold. If the difference is smaller than the threshold, the AC allows the user to associate with the radio. If not, the AC rejects the association request of the user. If users continue to send association requests to the AP and the maximum number of times the AP rejects users' association requests for a static load balancing group, the AP allows user access.

19.9.19 sta-number gap-threshold (upgrade-compatible command)

Function

The **sta-number gap-threshold** command sets the load difference threshold for load balancing based on the number of users in a static load balancing group.

The **undo sta-number gap-threshold** command restores the default load difference threshold for load balancing based on the number of users in a static load balancing group.

By default, the load difference threshold of a static load balancing group is 20%.

Format

sta-number gap-threshold *gap-threshold-value*

undo sta-number gap-threshold

Parameters

Parameter	Description	Value
gap-threshold <i>gap-threshold-value</i>	Specifies the load difference threshold for load balancing based on the number of users in a static load balancing group.	The value is an integer that ranges from 1 to 100. It indicates the threshold of the load difference among radios in a load balancing group, in percentage. The load difference refers to the difference between the number of users on radios.

Views

Static load balancing group view

Default Level

2: Configuration level

Usage Guidelines

After the load difference threshold for load balancing based on the number of users is configured using the **sta-number gap-threshold** command, an AP implements load balancing based on the difference between the number of users on different radios.

19.9.20 learn-client-address disable (VAP profile view) (upgrade-compatible command)

Function

learn-client-address disable command disables STA address learning.

undo learn-client-address disable command disables STA address learning.

By default, STA address learning is enabled.

Format

learn-client-address disable

undo learn-client-address disable

Parameters

None

Views

VAP profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If a STA associates with an AP that has STA address learning enabled and obtains an IP address, the AP automatically reports the STA IP address to the AC to maintain the STA' IP address and MAC address binding entry

Prerequisites

- You have disabled the DHCP trusted interface by running **undo dhcp trust port** in the VAP profile view.
- Before disabling STA address learning, run the **undo learn-client-address dhcp-strict** command to disable strict STA IP address learning through DHCP.

Precautions

If a bridging device functions as a STA to connect to an AP enabled with STA address learning, the AP cannot learn IP addresses of users connected to the bridging device; therefore, the users cannot communicate with the network. In this situation, disable STA address learning.

19.9.21 parity (serial profile view) (upgrade-compatible command)

Function

The **parity** command configures the parity bit for serial data on an IoT card slot.

The **undo parity** command restores the configured parity bit to the default value.

By default, the parity bit is set to **none** on an IoT card slot.

Format

parity { **none** | **odd** | **even** | **mark** | **space** }

undo parity

Parameters

Parameter	Description	Value
none	Indicates no parity.	-
odd	Indicates odd parity.	-
even	Indicates even parity.	-
mark	Indicates mark parity.	-
space	Indicates space parity.	-

Views

Serial profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.22 serial-profile (WLAN view) (upgrade-compatible command)

Function

The **serial-profile** command creates a serial profile and displays the serial profile view.

The **undo serial-profile** command deletes a serial profile.

By default, serial profile **preset-enjoyor-toeap** is bound to an IoT card interface.

Format

serial-profile name *profile-name*

undo serial-profile { **name** *profile-name* | **all** }

Parameters

Parameter	Description	Value
name <i>profile-name</i>	Specifies the name of a serial profile.	The value is a string of 1 to 35 case-insensitive characters. It does not contain question marks (?) or spaces, and cannot start or end with double quotation marks (" ").
all	Specifies all serial profiles.	-

Views

WLAN view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.23 serial-profile (IoT card interface view) (upgrade-compatible command)

Function

The **serial-profile** command binds a serial profile to an AP or AP group.

The **undo serial-profile** command deletes the serial profile bound to an AP or AP group.

By default, serial profile **preset-enjoyor-toeap** is bound to an AP group, and no serial profile is bound to an AP.

Format

serial-profile *profile-name*

undo serial-profile

Parameters

Parameter	Description	Value
<i>profile-name</i>	Specifies the name of a serial profile.	The value is a string of 1 to 35 case-insensitive characters. It does not contain question marks (?) or spaces, and cannot start or end with double quotation marks (" ").

Views

IoT card interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.24 smart-roam enable (upgrade-compatible command)

Function

The **smart-roam enable** command enables smart roaming.

The **undo smart-roam enable** command disables smart roaming.

By default, smart roaming is disabled.

Format

smart-roam enable

undo smart-roam enable

Parameters

None

Views

RRM profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

On a traditional WLAN, when a STA is farther from an AP, the access rate of the STA becomes lower but the STA still associates with the AP without reinitiating a connection with the AP or roaming to another AP. This degrades user experience. To prevent this situation, configure the smart roaming function. When detecting that the SNR or access rate of a STA is lower than the specified threshold, the AP sends a Disassociation packet to the STA so that the STA can reconnect or roam to another AP.

19.9.25 speed (serial profile view) (upgrade-compatible command)

Function

The **speed** command configures the baud rate for serial communications on an IoT card slot.

The **undo speed** command restores the configured baud rate to the default value.

By default, the baud rate is 115,200 bit/s.

Format

speed *speed-value*

undo speed

Parameters

Parameter	Description	Value
<i>speed-value</i>	Specifies the baud rate for serial communication on an IoT card slot.	The unit is bit/s and the value can be: <ul style="list-style-type: none">● 9600 bit/s● 19200 bit/s● 38400 bit/s● 57600 bit/s● 115200 bit/s

Views

Serial profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.26 start-threshold (upgrade-compatible command)

Function

The **start-threshold** command sets the start threshold for load balancing based on the number of users in a static load balancing group.

The **undo start-threshold** command deletes the configured start threshold for load balancing based on the number of users in a static load balancing group.

By default, the start threshold for load balancing based on the number of users in a static load balancing group is 10.

Format

start-threshold *start-threshold-value*

undo start-threshold

Parameters

Parameter	Description	Value
start-threshold <i>start-threshold-value</i>	Specifies the start threshold for load balancing based on the number of users in a static load balancing group.	The value is an integer that ranges from 1 to 40.

Views

Static load balancing group view

Default Level

2: Configuration level

Usage Guidelines

You can use this command to set the start threshold for load balancing based on the number of users in a static load balancing group. If the load on a radio does not reach the start threshold, the device does not implement load balancing control on access STAs.

19.9.27 sta-load-balance dynamic gap-threshold (upgrade-compatible command)

Function

The **sta-load-balance dynamic gap-threshold** command sets the load difference threshold for dynamic load balancing based on the number of users.

The **undo sta-load-balance dynamic gap-threshold** command restores the default load difference threshold for dynamic load balancing based on the number of users.

By default, the load difference threshold of a dynamic load balancing group is 20%.

Format

sta-load-balance dynamic gap-threshold *gap-threshold*

undo sta-load-balance dynamic gap-threshold

Parameters

Parameter	Description	Value
gap-threshold <i>gap-threshold</i>	Specifies the load difference threshold for dynamic load balancing based on the number of users.	The value is an integer that ranges from 1 to 100, in percentage.

Views

RRM profile view

Default Level

2: Configuration level

Usage Guidelines

When a user requests to connect to an AP, the AP will count the total number of access users on all radios. If the total number of access users does not exceed the start threshold, the AP does not implement dynamic load balancing. The AP implements dynamic load balancing only when the total number of access users on all radios exceeds the start threshold.

In dynamic load balancing mode, an AC uses a load balancing algorithm to determine whether to allow a user to associate with a radio. The load balancing algorithm is as follows:

When implementing dynamic load balancing, the AC calculates the load percentage of each radio in a load balancing group using the formula: Load

percentage of a radio = (Number of associated users on the radio/Maximum number of users allowed on the radio) x 100%. The AC compares load percentages of all radios in the load balancing group and obtains the smallest load percentage value. When a user requests to associate with an AP radio, the AC calculates the difference between the radio's load percentage and the smallest load percentage value and compares the load difference with the threshold. If the difference is smaller than the threshold, the AC allows the user to associate with the radio. If not, the AC rejects the association request of the user. If the user continues sending association requests to this AP, the AC allows the user to associate with the AP when the number of consecutive association attempts of the user exceeds the maximum number of rejection times.

19.9.28 sta-load-balance dynamic sta-number gap-threshold (upgrade-compatible command)

Function

The **sta-load-balance dynamic sta-number** command sets the load difference threshold for dynamic load balancing based on the number of users.

The **undo sta-load-balance dynamic sta-number gap-threshold** command restores the default load difference threshold for dynamic load balancing based on the number of users.

By default, the load difference threshold of a dynamic load balancing group is 20%.

Format

sta-load-balance dynamic sta-number gap-threshold *gap-threshold*

undo sta-load-balance dynamic sta-number gap-threshold

Parameters

Parameter	Description	Value
gap-threshold <i>gap-threshold</i>	Specifies the load difference threshold for dynamic load balancing based on the number of users.	The value is an integer that ranges from 1 to 100, in percentage.

Views

RRM profile view

Default Level

2: Configuration level

Usage Guidelines

When a user requests to connect to an AP, the AP will count the total number of access users on all radios. If the total number of access users does not exceed the start threshold configured, the AP does not implement dynamic load balancing. The AP implements dynamic load balancing only when the total number of access users on all radios exceeds the start threshold.

In dynamic load balancing mode, an AC uses a load balancing algorithm to determine whether to allow a user to associate with a radio.

19.9.29 **sta-load-balance dynamic start-threshold (upgrade-compatible command)**

Function

The **sta-load-balance dynamic start-threshold** command sets the start threshold for dynamic load balancing based on the number of users.

The **undo sta-load-balance dynamic start-threshold** command restores the default start threshold for dynamic load balancing based on the number of users.

By default, the start threshold for dynamic load balancing based on the number of users is 10.

Format

sta-load-balance dynamic start-threshold *start-threshold*

undo sta-load-balance dynamic start-threshold

Parameters

Parameter	Description	Value
start-threshold <i>start-threshold</i>	Specifies the start threshold for dynamic load balancing based on the number of users.	The value is an integer that ranges from 1 to 40.

Views

RRM profile view

Default Level

2: Configuration level

Usage Guidelines

When a user requests to connect to an AP, the AP counts the total number of access users on all radios. If the number of access users on the requested radio

does not exceed the start threshold, the AP does not implement dynamic load balancing based on the number of users. The AP implements dynamic load balancing based on the number of users only after the number of access users exceeds the start threshold.

19.9.30 stopbits (serial profile view) (upgrade-compatible command)

Function

The **stopbits** command configures stop bits for serial data on an IoT card slot.

The **undo stopbits** command restores the configured stop bits to the default value.

The default stop bit is 1.

Format

stopbits { 1 | 2 }

undo stopbits

Parameters

Parameter	Description	Value
1	Specifies one stop bit.	-
2	Specifies two stop bits.	-

Views

Serial profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.31 traffic-filter (AP wired port profile view) (upgrade-compatible command)

Function

The **traffic-filter** command configures ACL-based IPv4 packet filtering on an AP's wired interface.

The **undo traffic-filter** command cancels ACL-based IPv4 packet filtering configuration on an AP's wired interface.

By default, ACL-based IPv4 packet filtering is not configured on an AP's wired interface.

Format

```
traffic-filter { inbound | outbound } acl { acl-number | name acl-name }  
undo traffic-filter { inbound | outbound }
```

Parameters

Parameter	Description	Value
inbound	Configures ACL-based IPv4 packet filtering in the inbound direction.	-
outbound	Configures ACL-based IPv4 packet filtering in the outbound direction.	-
acl	Filters IPv4 packets based on a specified ACL.	-
<i>acl-number</i>	Specifies an ACL number.	The ACL must exist. The value is an integer that ranges from 3000 to 3031.
name <i>acl-name</i>	Filters IPv4 packets based on a named ACL. <i>acl-name</i> indicates the ACL name.	The ACL name must exist. The value range is the same as that of the <i>acl-number</i> parameter.

Views

AP wired port profile view

Default Level

3: Management level

Usage Guidelines

Usage scenario

The rules for an AP's wired interface to filter IPv4 packets based on ACLs are as follows:

- If the action in the ACL rule is **deny**, the device discards IPv4 packets matching the rule.
- If the action in the ACL rule is **permit**, the device allows IPv4 packets matching the rule to pass through.
- If no rule is matched, IPv4 packets are allowed to pass through.

Prerequisites

An ACL rule has been created by running the **acl [number] *acl-number* [match-order { auto | config }]** or **acl name *acl-name* *acl-number* [match-order { auto | config }]** command.

Precautions

The **traffic-filter** command can reference an ACL with no rule configured. You can configure a rule for the ACL after running this command.

You can configure IPv4 packet filtering based on only one ACL in one direction. If a referenced ACL needs to be replaced, configure a new ACL to overwrite the original one.

19.9.32 traffic-filter (traffic profile view) (upgrade-compatible command)

Function

The **traffic-filter** command configures ACL-based IPv4 packet filtering in a traffic profile.

The **undo traffic-filter** command cancels configuration of ACL-based IPv4 packet filtering in a traffic profile.

By default, ACL-based IPv4 packet filtering is not configured in a traffic profile.

Format

traffic-filter { inbound | outbound } acl { *acl-number1* | *acl-number2* | name *acl-name* }

undo traffic-filter { inbound | outbound }

Parameters

Parameter	Description	Value
inbound	Configures ACL-based IPv4 packet filtering in the inbound direction.	-
outbound	Configures ACL-based IPv4 packet filtering in the outbound direction.	-

Parameter	Description	Value
acl	Filters IPv4 packets based on a specified ACL.	-
<i>acl-number</i>	Specifies an ACL number.	The ACL must exist. The value is an integer that ranges from 3000 to 3031 and from 6000 to 6031. <ul style="list-style-type: none"> • 3000 to 3031: advanced ACLs • 6000 to 6031: user ACLs
name <i>acl-name</i>	Filters IPv4 packets based on a named ACL. <i>acl-name</i> indicates the ACL name.	The ACL name must exist. The value range is the same as that of the <i>acl-number</i> parameter.

Views

Traffic profile view

Default Level

3: Management level

Usage Guidelines

Usage Scenario

After the **traffic-filter** command is executed in the traffic profile view, the device filters packets matching a specified ACL rule:

- If the action in the ACL rule is **deny**, the device discards IPv4 packets matching the rule.
- If the action in the ACL rule is **permit**, the device allows IPv4 packets matching the rule to pass through.
- If no rule is matched, IPv4 packets are allowed to pass through.

Prerequisites

An ACL rule has been created by running the **acl [number] *acl-number* [match-order { auto | config }]** or **acl name *acl-name* *acl-number* [match-order { auto | config }]** command.

Precautions

The **traffic-filter** command can reference an ACL with no rule configured. You can configure a rule for the ACL after running this command.

You can configure IPv4 packet filtering based on only one ACL in one direction. If a referenced ACL needs to be replaced, configure a new ACL to overwrite the original one.

19.9.33 traffic-optimize broadcast-suppression enable (upgrade-compatible command)

Function

The **traffic-optimize broadcast-suppression enable** command enables rate limit for broadcast and multicast packets on an AP.

The **undo traffic-optimize broadcast-suppression enable** command disables rate limit for broadcast and multicast packets on an AP.

By default, rate limit for broadcast and multicast packets is disabled on an AP.

Format

traffic-optimize broadcast-suppression { all | arp | igmp | nd | other } enable

undo traffic-optimize broadcast-suppression { all | arp | igmp | nd | other } enable

Parameters

Parameter	Description	Value
all	Enables rate limit for all broadcast and multicast packets.	-
arp	Enables rate limit for ARP broadcast packets.	-
igmp	Enables rate limit for IGMP multicast packets.	-
nd	Enables rate limit for ND broadcast packets.	-
other	Enables rate limit for broadcast packets other than ARP and ND broadcast packets.	-

Views

AP system profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.34 traffic-optimize broadcast-suppression disable (AP system profile view) (upgrade-compatible command)

Function

The **traffic-optimize broadcast-suppression disable** command disables rate limit for broadcast and multicast packets on an AP.

The **undo traffic-optimize broadcast-suppression disable** command enables rate limit for broadcast and multicast packets on an AP.

By default, rate limit for broadcast and multicast packets is enabled on an AP.

Format

traffic-optimize broadcast-suppression other disable

undo traffic-optimize broadcast-suppression other disable

Parameters

Parameter	Description	Value
other	Disables rate limit for broadcast packets other than ARP and ND broadcast packets.	-

Views

AP system profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.35 traffic-optimize broadcast-suppression rate-threshold (AP system profile view) (upgrade-compatible command)

Function

The **traffic-optimize broadcast-suppression rate-threshold** command sets a rate threshold for broadcast and multicast packets on an AP.

The **undo traffic-optimize broadcast-suppression rate-threshold** command restores the default threshold of broadcast and multicast packets on an AP.

The default rate threshold for ARP broadcast packets, ND broadcast packets, IGMP multicast packets, and other types of broadcast packets is 256 pps.

Format

traffic-optimize broadcast-suppression other rate-threshold *threshold-value*

undo traffic-optimize broadcast-suppression other rate-threshold

Parameters

Parameter	Description	Value
other	Specifies broadcast packets other than ARP and ND broadcast packets.	-
rate-threshold <i>threshold-value</i>	Specifies a rate threshold.	The value is an integer that ranges from 64 to 1024, in pps. The default value is 256.

Views

AP system profile view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.9.36 vht mcs-map (upgrade-compatible command)

Function

The **vht mcs-map** command configures the maximum MCS value corresponding to a specific number of 802.11ac spatial streams in the 5G radio profile.

The **undo vht mcs-map** command restores the default maximum MCS value corresponding to a specific number of 802.11ac spatial streams in the 5G radio profile.

By default, the maximum MCS value of the 802.11 ac radios is 9 in the 5G radio profile.

Format

vht mcs-map { *nss nss-value* { *max-mcs max-mcs-value* } } & <2-3>

undo vht mcs-map

Parameters

Parameter	Description	Value
<i>nss nss-value</i>	Specifies the number of spatial streams.	The value is an integer ranging from 1 to 4.
<i>max-mcs max-mcs-value</i>	Specifies the maximum MCS value corresponding to a specific number of spatial streams.	The value is an integer ranging from 7 to 9.

Views

5G radio profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Rates of 802.11ac radios depend on the index value of Modulation and Coding Scheme (MCS). A larger MCS value indicates a higher transmission rate.

- If *nss-value* is equal to or larger than the actual number of spatial streams supported by an AP, the maximum MCS value corresponding to all spatial streams of the AP is *max-mcs-value*.
- If *nss-value* is smaller than the actual number of spatial streams supported by an AP, only the maximum MCS value of configured spatial streams is *max-*

mcs-value. The maximum MCS value of the other spatial streams does not take effect.

For example, if *nss-value* is 2, and the AP supports 3 spatial streams. Only the maximum MCS value of spatial stream 1 and spatial stream 2 is *max-mcs-value*, and that of spatial stream 3 does not take effect.

Precautions

This configuration applies only to STAs associated with an AP in 802.11ac mode but does not take effect on STAs associated with the AP in other modes.

19.9.37 sniffer enable (upgrade-compatible command)

Function

The **sniffer enable** command enables and configures the working mode of an AP's built-in Bluetooth module.

The **undo sniffer enable** command disables the configured working mode of an AP's built-in Bluetooth module.

By default, the Bluetooth function of an AP's built-in Bluetooth module is disabled.

Format

sniffer enable

undo sniffer enable

Parameters

None

Views

BLE profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After enabling the Bluetooth monitoring function, the built-in Bluetooth module of an AP will scan and obtain information about surrounding BLE devices, and reports the obtained information such as MAC addresses, RSSIs, BLE broadcast frame contents, and battery power.

After the Bluetooth monitoring function is enabled, an AP obtains battery power of surrounding Bluetooth devices at WLAN service off-peak time, for example, 2:00 am of the system time. Precisely configure the system time of an AC to ensure that WLAN services are not affected when the AC obtains battery power of Bluetooth devices.

The Bluetooth broadcast and Bluetooth monitoring functions can be enabled simultaneously for an AP's built-in Bluetooth module. When the two functions are enabled simultaneously, the AP's built-in Bluetooth module is also monitored.

After you run the **undo sniffer enable** command to disable the BLE monitoring function, the AC will trigger an alarm indicating that BLE devices are offline.

Follow-up Procedure

After the Bluetooth monitoring function is enabled, you are advised to run the **ble monitoring-list** command to add Bluetooth devices to the monitoring list for easy management. When a Bluetooth device in the monitoring list is offline or has low battery power, an alarm is triggered on the AC accordingly. If a Bluetooth device is not in the monitoring list, no such alarm will be triggered on the AC.

19.9.38 broadcasting-content (upgrade-compatible command)

Function

The **broadcasting-content** command configures the content of a BLE broadcast frame sent by an AP's built-in Bluetooth module.

The **undo broadcasting-content** command restores the default content of a BLE broadcast frame sent by an AP's built-in Bluetooth module.

By default, the UUID, Major, and Minor fields in a BLE broadcast frame sent by an AP's built-in Bluetooth module are null, and the RSSI calibration value is -65 dBm.

NOTE

Only the AP4050DN-E supports the Bluetooth broadcast function.

Format

broadcasting-content { **uuid** *uuid-value* | **major** *major-value* | **minor** *minor-value* | **reference-rssi** *reference-rssi-value* }*

undo broadcasting-content

Parameters

Parameter	Description	Value
uuid <i>uuid-value</i>	Specifies the UUID field in a BLE broadcast frame. UUID is the universally unique identifier of a BLE device.	The value is a string of 1 to 16 characters. The default value is null.
major <i>major-value</i>	Specifies the Major field in a BLE broadcast frame. This field specifies a major group and is combined with the Minor field to define information about a BLE device, for example, location of a BLE device.	The value is a string of 1 or 2 characters. The default value is null.

Parameter	Description	Value
minor <i>minor-value</i>	Specifies the Minor field in a BLE broadcast frame. This field specifies a minor group and is combined with the Major field to define information about a BLE device, for example, location of a BLE device.	The value is a string of 1 or 2 characters. The default value is null.
reference-rssi <i>reference-rssi-value</i>	Specifies the RSSI calibration value of a BLE device. RSSI calibration value indicates the RSSI value of a BLE device measured at a distance of 1 m. It is used to estimate the distance between the BLE device and Bluetooth terminals.	The value is an integer that ranges from -97 to -50, in dBm. The default value is -65 that is measured when the transmit power of an APs' built-in Bluetooth module is 0 dBm.

Views

BLE profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After enabling the broadcast function of an AP's built-in Bluetooth module using the **broadcaster enable** command, you can run the **broadcasting-content** command to configure the content of BLE broadcast frames sent by the module.

Precautions

The RSSI calibration value in a BLE broadcast frame is set based on the actual measurement result.

After changing the transmit power of a built-in Bluetooth module using the **tx-power (BLE profile view)** command, you need to remeasure and reconfigure the RSSI calibration value. Therefore, you are advised to run the **tx-power (BLE profile view)** command to configure the transmit power of a built-in Bluetooth module before configuring the RSSI calibration value.

19.9.39 radio-5g-profile (upgrade-compatible command)

Function

The **radio-5g-profile** command binds a 5G radio profile to a 5G radio.

The **undo radio-5g-profile** command unbinds a 5G radio profile from a 5G radio.

By default, no 5G radio profile is applied in the AP view and AP radio view, but the 5G radio profile **default** is applied to the AP group view and AP group radio view.

Format

radio-5g-profile *profile-name*

undo radio-5g-profile

Parameters

Parameter	Description	Value
<i>profile-name</i>	Specifies the name of a 5G radio profile.	The 5G radio profile must exist.

Views

AP group view, AP view, AP radio view, AP group radio view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After you create a 5G radio profile, bind it to a 5G radio so that the 5G radio profile can take effect.

Precautions

The configuration in the AP view and AP radio view has a higher priority than that in the AP group view and AP group radio view.

19.9.40 vap-profile (upgrade-compatible command)

Function

The **vap-profile** command binds a VAP profile to a radio.

The **undo vap-profile** command unbinds a VAP profile from a radio.

By default, no VAP profile is bound to a radio.

Format

vap-profile *profile-name* **wlan** *wlan-id*

undo vap-profile *profile-name* **wlan** *wlan-id*

Parameters

Parameter	Description	Value
<i>profile-name</i>	Specifies the name of a VAP profile.	The VAP profile must exist.
wlan <i>wlan-id</i>	Specifies the WLAN ID of a VAP.	The value is an integer that ranges from 1 to 16.

Views

AP group view, AP view, AP radio view, AP group radio view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After you create a VAP profile, bind it to a radio so that the VAP profile can take effect.

Precautions

After a VAP profile is bound to a radio, parameter settings in the VAP profile apply to the radio using the profile.

19.9.41 learn-client-address enable (AP wired port profile view) (upgrade-compatible command)

Function

The **learn-client-address enable** command enables terminal address learning on an AP's wired interface.

The **undo learn-client-address enable** command disables terminal address learning on an AP's wired interface.

By default, terminal address learning is disabled on an AP's wired interface.

Format

learn-client-address enable

undo learn-client-address enable

Parameters

None

Views

AP wired port profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After terminal address learning is enabled on an AP's wired interface, if a wired terminal connected to the AP wired interface successfully obtains an IP address, the AP automatically reports the IP address of the terminal to the AC, helping to maintain the ARP binding entries of wired terminals.

Prerequisites

You have disabled the DHCP trusted interface by running **undo dhcp trust port** in the AP wired port profile view.

Follow-up Procedure

Bind the AP wired port profile to an AP group or AP.

Precautions

The AP wired interfaces added to an Eth-trunk interface do not support this function.

19.9.42 radio-2g-profile (upgrade-compatible command)

Function

The **radio-2g-profile** command binds a 2G radio profile to a 2G radio.

The **undo radio-2g-profile** command unbinds a 2G radio profile from a 2G radio.

By default, no 2G radio profile is applied in the AP view and AP radio view, but the 2G radio profile **default** is applied to the AP group view and AP group radio view.

Format

radio-2g-profile *profile-name*

undo radio-2g-profile

Parameters

Parameter	Description	Value
<i>profile-name</i>	Specifies the name of a 2G radio profile.	The 2G radio profile must exist.

Views

AP group view, AP view, AP radio view, AP group radio view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After you create a 2G radio profile, bind it to a 2G radio so that the 2G radio profile can take effect.

Precautions

After a 2G radio profile is applied in the AP group view or AP view, the parameter settings in the profile take effect on all 2G radios in the AP group or the 2G radio of the AP.

The configuration in the AP view and AP radio view has a higher priority than that in the AP group view and AP group radio view.

19.9.43 master controller (upgrade-compatible command)

Function

The **master controller** command displays the configuration view of the Master Controller.

Format

master controller

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To perform configurations on the Master Controller, run the **master controller** command to enter the configuration view of the Master Controller.

Prerequisite

Run the **master-controller enable** command to enable the Master Controller role.

19.9.44 mu-mimo enable (upgrade-compatible command)

Function

The **mu-mimo enable** command enables MU-MIMO.

The **undo mu-mimo enable** command disables MU-MIMO.

By default, the MU-MIMO function is disabled.

Format

mu-mimo enable

undo mu-mimo enable

Parameters

None

Views

SSID profile view, WDS profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Carrier sense multiple access with collision avoidance (CSMA-CA) allows an air interface channel to be occupied only by one STA, and other STAs cannot communicate with the AP. After MU-MIMO is enabled, STAs supporting MU-MIMO can form an MU group to simultaneously receive downlink data from the same air interface channel, improving channel efficiency and overall downlink throughput.

19.9.45 mpp-active-reselection enable (upgrade-compatible command)

Function

The **mpp-active-reselection enable** command enables active MPP reselection.

The **undo mpp-active-reselection** command disables active MPP reselection.

By default, active MPP reselection is disabled.

Format

mpp-active-reselection enable

undo mpp-active-reselection

Parameters

None

Views

AP system profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After active MPP reselection is enabled on an MP, the MP evaluates MPPs of the same Mesh ID and on the same channel based on the signal strength of Mesh links, the number of link hops, and the number of Mesh links. If a more preferable MPP is available, the MP selects the MPP as its Mesh gateway.

By default, active MPP reselection is disabled, and an MP can only passively reselect MPPs. When the minimum RSSI of all Mesh links on the optimal route to the current MPP is lower than the RSSI threshold of a Mesh link, the MPP reselection process is triggered.

Precautions

This configuration is invalid for the MPP.

In train-to-ground communication scenarios, this configuration takes effect only on vehicle-mounted APs working in client mode but not those working in Mesh handover mode. This is because in Mesh handover mode, vehicle-mounted APs use the link handover algorithm to select the MPP.

Active MPP reselection will cause service loss. Configure the function according to actual needs.

19.10 Reliability Compatible Commands

19.10.1 BFD Compatible Commands

19.10.1.1 bfd bind peer-ipv6 (upgrade-compatible command)

Function

The **bfd bind peer-ipv6** command creates a BFD6 session to test an IPv6 link.

By default, no BFD6 session is created to test an IPv6 link.

Format

bfd *bfd-name* **bind peer-ipv6** *peer-ipv6* [**vpn6-instance** *vpn6-instance-name*]
[**interface** *interface-type interface-number*] [**source-ipv6** *ipv6-address*]

Parameters

Parameter	Description	Value
<i>bfd-name</i>	Specifies a BFD6 session name.	The value is a string of 1 to 15 characters, spaces not supported.
peer-ipv6 <i>peer-ipv6</i>	Specifies the peer IPv6 address that is to be bound to a BFD6 session.	-
vpn6-instance <i>vpn6-instance-name</i>	Specifies the name of the VPN instance that is bound to a BFD6 session. If no VPN instance is specified, the peer IP address is regarded as a public IP address.	The value is a string of 1 to 31 characters.
interface <i>interface-type interface-number</i>	Specifies the local Layer 3 interface that is bound to a BFD6 session.	-

Parameter	Description	Value
source-ipv6 <i>ipv6-address</i>	<p>Specifies the source IPv6 address carried in BFD packets. Generally, you do not need to configure this parameter.</p> <p>If no source IPv6 address is specified, the device specifies one based on the following situations:</p> <ul style="list-style-type: none">• During BFD for IPv6 negotiation, the device searches for the IPv6 address of an outbound interface that connects to the peer in the local routing table as the source IPv6 address before sending BFD packets.• During BFD for IPv6 detection, the device sets the source IPv6 address to a fixed value. <p>NOTE</p> <p>BFD works with unicast reverse path forwarding (URPF). When URPF checks the source IPv6 address in received packets, you must manually set the source IPv6 address for the BFD packets.</p>	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

It is replaced by the **bfd bfd-name bind peer-ipv6 peer-ipv6 [vpn-instance vpn-instance-name] [interface interface-type interface-number] [source-ipv6 ipv6-address]** command.

Example

Create a BFD6 session named **test** to test the single-hop link.

```
<HUAWEI> system-view
[HUAWEI] bfd
[HUAWEI-bfd] quit
[HUAWEI] bfd test bind peer-ipv6 2001:db8:1::1 vpn-instance vpn1 interface gigabitethernet 0/0/1
[HUAWEI-bfd-session-test] discriminator local 1
[HUAWEI-bfd-session-test] discriminator remote 2
[HUAWEI-bfd-session-test] commit
```

19.10.1.2 display bfd statistics session (upgrade-compatible command)

Function

The **display bfd statistics session** command displays BFD statistics.

Format

display bfd statistics session peer-ipv6 *peer-ipv6* [{ **vpn-instance** | **vpn6-instance** } *vpn-instance-name*]

Parameters

Parameter	Description	Value
peer-ipv6 <i>peer-ipv6</i>	Displays statistics about a BFD6 session bound to a specified peer IPv6 address.	-
{ vpn-instance vpn6-instance } <i>vpn-instance-name</i>	Displays statistics about a BFD6 session bound to a specified VPN instance.	The value must be an existing VPN instance name.

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

It is replaced by the **display bfd statistics session peer-ipv6** *peer-ipv6* [**vpn-instance** *vpn-instance-name*] command.

19.10.1.3 display bfd session (upgrade-compatible command)

Function

The **display bfd session** command displays information about BFD sessions.

Format

display bfd session peer-ipv6 *peer-ipv6* [{ **vpn-instance** | **vpn6-instance** } *vpn-instance-name*] [**verbose**]

Parameters

Parameter	Description	Value
peer-ipv6 <i>peer-ipv6</i>	Displays the configuration of a BFD6 session bound to a specified peer IPv6 address.	-
{ vpn-instance vpn6-instance } <i>vpn-instance-name</i>	Displays information about a BFD6 session bound to a specified VPN instance.	The value must be an existing VPN instance name.
verbose	Displays detailed information about the BFD6 configuration.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

It is replaced by the **display bfd session peer-ipv6** *peer-ipv6* [**vpn-instance** *vpn-instance-name*] [**verbose**] command.

19.10.1.4 display bfd configuration (upgrade-compatible command)

Function

The **display bfd configuration** command displays configurations of BFD sessions.

Format

display bfd configuration peer-ipv6 *peer-ipv6* [{ **vpn-instance** | **vpn6-instance** } *vpn6-instance-name*] [**verbose**]

Parameters

Parameter	Description	Value
peer-ipv6 <i>peer-ipv6</i>	Displays the configuration of a BFD6 session bound to a specified peer IPv6 address.	-

Parameter	Description	Value
{ vpn-instance vpn6-instance } <i>vpn6-instance-name</i>	Displays the configuration of a BFD6 session bound to a specified VPN instance	The value must be an existing VPN instance name.
verbose	Displays detailed information about BFD6 configurations.	-

Views

All views

Default Level

1: Monitoring level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

It is replaced by the **display bfd configuration peer-ipv6** *peer-ipv6* [**vpn-instance** *vpn-instance-name*] [**verbose**] command.

19.10.1.5 snmp-agent trap enable bfd (upgrade-compatible command)

Function

The **snmp-agent trap enable bfd** command enables the trap function for the BFD module.

By default, the trap function is disabled for the BFD module.

Format

snmp-agent trap enable bfd

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

It is replaced by the **snmp-agent trap enable feature-name bfd** command in the system view.

19.10.2 DLDP Compatible Commands

19.10.2.1 snmp-agent trap enable dldp (upgrade-compatible command)

Function

The **snmp-agent trap enable dldp** command enables the trap function for the DLDP module.

By default, the trap function is disabled for the DLDP module.

Format

```
snmp-agent trap enable dldp
```

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **snmp-agent trap enable feature-name dldp** command.

19.10.2.2 dldp authentication-mode md5-compatible (upgrade-compatible command)

Function

The **dldp authentication-mode md5-compatible** command configures MD5-compatible authentication.

By default, DLDP packets are not authenticated.

Format

lldp authentication-mode md5-compatible *md5-password*

Parameters

Parameter	Description	Value
md5-compatible <i>md5-password</i>	Uses MD5-compatible to authenticate DLDP packets exchanged between the interfaces on the local and neighbor devices. <i>md5-password</i> specifies the MD5-compatible authentication password. NOTE To ensure security, the password is saved in cipher text in the configuration file.	The value is a string of 1 to 16 case-sensitive characters in plain text without any question mark (?) and space. NOTE During the upgrade, the device is compatible with the cipher-text passwords with different lengths before the upgrade.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Scenario

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

When the device that uses MD5 authentication is upgraded from V200R001 or V200R002 to V200R008 or later, to ensure compatibility, upgrade the DLDP authentication mode to MD5-compatible.

Running the **lldp authentication-mode md5-compatible** command is equivalent to running the **lldp authentication-mode** command in the system view.

19.10.3 Ethernet OAM Compatible Commands

19.10.3.1 ma format (upgrade-compatible command)

Function

The **ma** command creates an MA in an MD and displays the MA view. If the MA already exists, this command displays the MA view.

Format

ma *ma-name* **format** { **icc-based** | **string** }

Parameters

Parameter	Description	Value
<i>ma-name</i>	Specifies the name of an MA. Names of MAs in an MD are unique.	The value is a string of characters without spaces, hyphen (-), or question mark (?). The total length of the names of the MA and MD must be within 44 case-sensitive characters.
icc-based	Specifies an ICC-based MA name carried in CCMs to be sent. ITU carrier codes (ICCs) are assigned to network operators or service providers and maintained by ITU-T Telecommunication Standardization Bureau (TSB) in compliance with ITU-T M.1400 Recommendation.	-
string	Specifies a string-based MA name carried in CCMs to be sent.	-

Views

MD view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After an upgrade, this command is no longer supported, and it is replaced by the **ma** *ma-name* [**format** { **icc-based** *iccbased-ma-format-name* | **string** *ma-format-name* }] command.

19.10.3.2 cfm md format (upgrade-compatible command)

Function

Using the **cfm md** command, you can create an MD and enter the MD view. If the MD exists, you can use this command to enter the MD view.

Format

```
cfm md md-name format { dnsname-and-mdname | mac-address | md-name }  
[ level level ]
```

Parameters

Parameter	Description	Value
md <i>md-name</i>	Specifies the name of an MD.	The value is a string of 1 to 43 characters, which are case sensitive. The characters, such as ?, -, and space are excluded. The name of an MD is used to identify the MD. Different MDs on a device cannot have the same name. NOTE When double quotation marks are used around the string, spaces are allowed in the string.
dnsname-and-mdname	Indicates the MD name in the format that a DNS name is followed by an MD name.	-
mac-address	Indicates the MD name in the format that a MAC address is followed by an MD name.	-
md-name	Indicates that the MA ID field of the sent packet contains the MD name.	-
level <i>level</i>	Specifies the level of the MD.	The value is an integer ranging from 0 to 7. The greater the value, the higher the priority. The default value is 0.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

It is replaced by the **cfm md** *md-name* [**format** { **no-md-name** | **dns** *dns-md-format-name* | **mac-address** *mac-md-format-name* | **string** *string-md-format-name* }] [**level** *level*] command.

19.10.3.3 delay-measure one-way continual receive (upgrade-compatible command)

Function

The **delay-measure one-way continual receive** command configures a remote device to receive DMMs to implement proactive one-way frame delay measurement.

By default, the remote device enabled with proactive one-way frame delay measurement in the maintenance association (MA) is not configured to receive DMMs.

Format

delay-measure one-way continual receive

Parameters

None

Views

MA view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After an upgrade, this command is no longer supported, and it is replaced by the **delay-measure one-way continual receive mep** *mep-id* command.

19.10.3.4 delay-measure one-way receive (upgrade-compatible command)

Function

Using the **delay-measure one-way receive** command, you can configure the DM frame receiving function on the remote end of the local device enabled with one-way frame delay measurement.

By default, the DM frame receiving function is not configured for the remote end in an MA.

Format

delay-measure one-way receive

Parameters

None

Views

MA view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After an upgrade, this command is no longer supported, and it is replaced by the **delay-measure one-way receive mep** *mep-id* [**peer-ip** *peer-ip* [**vc-id** *vc-id*]].

19.10.3.5 delay-measure two-way receive (upgrade-compatible command)

Function

Using the **delay-measure two-way receive** command, you can enable DM frame reception on the remote MEP to implement the two-way frame delay measurement.

By default, DM frame reception is not configured on the remote MEP in an MA.

Format

delay-measure two-way receive

Parameters

None

Views

MA view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **delay-measure two-way receive mep** *mep-id* [**8021p** { *8021p-value* } &<1-3>] [**peer-ip** *peer-ip* [**vc-id** *vc-id*]] command.

19.10.3.6 efm threshold-event trigger error-shutdown (upgrade-compatible command)

Function

Using the **efm threshold-event trigger error-shutdown** command, you can enable the error-triggered shutdown function on an interface. After this function is enabled, the interface is shut down when the number of EFM errored frames or errored codes reaches the threshold.

By default, the error-triggered shutdown function is disabled on an interface.

Format

efm threshold-event trigger error-shutdown

Parameters

None

Views

Interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

It is replaced by the **efm threshold-event trigger error-down** command.

19.10.3.7 efm trigger if-net (upgrade-compatible command)

Function

The **efm trigger if-net** command associates EFM with an interface.

Format

efm trigger if-net

Parameters

None

Views

Interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

It is replaced by the **efm trigger if-down** command.

19.10.3.8 oam-bind ingress interface egress cfm md ma (upgrade-compatible command)

Function

The **oam-bind ingress interface egress cfm md ma** command configures an interface to report faults to Ethernet CFM.

Format

oam-bind ingress interface *interface-type interface-number* **egress cfm md** *md-name* **ma** *ma-name*

Parameters

Parameter	Description	Value
<i>interface-type</i> <i>interface-number</i>	Specifies the type and number of an interface. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number.	-
md <i>md-name</i>	Specifies the name of an MD.	The value is a string of 1 to 43 case-sensitive characters without spaces, hyphen (-), and question mark (?).

Parameter	Description	Value
ma <i>ma-name</i>	Specifies the name of an MA.	The value is a string of 1 to 43 case-sensitive characters without spaces, hyphen (-), and question mark (?). The total length of the names of the MA and MD must be within 44 characters.

Views

OAM management view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After an upgrade, it is replaced by the **oam-bind ingress interface** *interface-type interface-number* **egress cfm md** *md-name* **ma** *ma-name* **trigger if-down** command.

19.10.3.9 oam-bind ingress interface egress efm interface (upgrade-compatible command)

Function

The **oam-bind ingress interface egress efm interface** command enables an interface to report faults to EFM OAM.

Format

oam-bind ingress interface *interface-type1 interface-number1* **egress efm interface** *interface-type2 interface-number2*

Parameters

Parameter	Description	Value
<i>interface-type1 interface-number1</i>	Specifies the type and number of the interface enabled with EFM. <ul style="list-style-type: none"> <i>interface-type1</i> specifies the interface type. <i>interface-number1</i> specifies the interface number. 	-

Parameter	Description	Value
<i>interface-type2</i> <i>interface-number2</i>	Specifies the type and number of the interface bound to an EFM OAM session. <ul style="list-style-type: none">• <i>interface-type2</i> specifies the interface type.• <i>interface-number2</i> specifies the interface number.	-

Views

OAM management view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After an upgrade, it is replaced by the **oam-bind ingress interface** *interface-type1 interface-number1* **egress efm interface** *interface-type2 interface-number2* **trigger if-down** command.

19.10.3.10 snmp-agent trap enable efm (upgrade-compatible command)

Function

The **snmp-agent trap enable efm** command enables the trap function for the EFM module.

By default, the trap function is disabled for the EFM module.

Format

snmp-agent trap enable efm

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After an upgrade, this command is no longer supported, and it is replaced by the **snmp-agent trap enable feature-name efm** command.

19.10.3.11 snmp-agent trap enable eoam-1ag (upgrade-compatible command)

Function

The **snmp-agent trap enable eoam-1ag** command enables the trap function for the Eoam-1ag module.

By default, the trap function is disabled for the Eoam-1ag module.

Format

```
snmp-agent trap enable eoam-1ag
```

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After an upgrade, this command is no longer supported, and it is replaced by the **snmp-agent trap enable feature-name eoam-1ag** command.

19.10.3.12 snmp-agent trap enable test-packet (upgrade-compatible command)

Function

The **snmp-agent trap enable test-packet** command enables an Ethernet OAM module to send traps to the NMS.

By default, an Ethernet OAM module is enabled to send traps to the NMS.

Format

snmp-agent trap enable test-packet

Parameters

None

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

It is replaced by the **snmp-agent trap enable feature-name efm** command.

19.11 User Access and Authentication Compatible Commands

19.11.1 AAA Compatible Commands

19.11.1.1 adminuser-priority (upgrade-compatible command)

Function

The **adminuser-priority** command configures a user as an administrator to log in to the device and sets the administrator level during login.

Format

adminuser-priority *level*

Parameters

Parameter	Description	Value
<i>level</i>	Specifies the level of an administrator.	The value is an integer ranging from 0 to 15. After logging in to the device, a user can run only the commands of the same level or lower levels.

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **admin-user privilege level *level*** command.

19.11.1.2 hwtacacs-server shared-key (upgrade-compatible command)

Function

The **hwtacacs-server shared-key** command configures the shared key of an HWTACACS server.

The **undo hwtacacs-server shared-key** command deletes the shared key of an HWTACACS server.

By default, no shared key of an HWTACACS server is configured.

Format

hwtacacs-server shared-key simple *key-string*

undo hwtacacs-server shared-key

Parameters

Parameter	Description	Value
simple	Indicates the shared key in simple text.	-
<i>key-string</i>	Specifies the shared key of an HWTACACS server.	The value is a string of 1 to 255 characters in plain text and a string of 20 to 392 characters in cipher text.

Views

HWTACACS server template view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **hwtaacs-server shared-key [cipher] key-string** command.

19.11.1.3 local-user (upgrade-compatible command)

Function

The **local-user** command creates a local user and sets parameters of the local user.

By default, a local user exists in the system. The privilege of the user is **15**, and service type is **http**. The default username and password are available in *S Series Switches Default Usernames and Passwords* ([Enterprise Network](#) or [Carrier](#)). If you have not obtained the access permission of the document, see **Help** on the website to find out how to obtain it.

Format

```
local-user user-name password { key-string [ old-password password ] | simple simple-string } [ access-limit max-number | idle-timeout minutes [ seconds ] | state { block | active } ] *
```


Parameters

Parameter	Description	Value
<i>user-name</i>	Specifies the user name. If the user name contains a delimiter "@", the character before "@" is the user name and the character after "@" is the domain name. If the value does not contain "@", the entire character string represents the user name and the domain name is the default one.	The value is a string of 1 to 64 characters. It cannot contain spaces, asterisk, double quotation mark and question mark.

Parameter	Description	Value
		<p>NOTE</p> <ul style="list-style-type: none"> • During local authentication or authorization, run the authentication-mode { local local-case } or authorization-mode { local local-case } command to configure case sensitivity for user names. If the parameter is set to local, user names are case-insensitive. If the parameter is set to local-case, user names are case-sensitive. • Note the following when configuring case sensitivity for user names: <ul style="list-style-type: none"> • Only the user name is case-sensitive and the domain name is case-insensitive. • For user security purposes, you cannot configure multiple local users with the user names that differ only in uppercase or lowercase. For example, after configuring ABC, you cannot configure Abc or abc as the user name. • When a device is upgraded from V200R011C10 or an earlier version to a version later than V200R011C10, all local user names in the original configuration file are saved in lowercase. When a configuration file that is manually configured or generated using the third-party tool is used for configuration restoration, local user names that differ only in uppercase or lowercase are considered as one user name and the first one among these local user

Parameter	Description	Value
password <i>key-string</i>	Specifies the password of a local user. It is recommended that you set the user password when creating a user.	The value is a string of 1 to 256 case-sensitive characters without spaces.
old-password <i>password</i>	Specifies the old password of a local user. NOTE This parameter cannot be automatically displayed through the question mark help function and must be entered completely. It should be configured by the network administrator on the NMS and delivered to the device. It is not recommended that you directly specify this parameter on the device.	The value is the password used by the local user for the current login.
password simple <i>simple-string</i>	Specifies the password of a local user. It is recommended that you set the user password when creating a user.	The value is a string of 1 to 256 case-sensitive characters without spaces.
access-limit <i>max-number</i>	Specifies the number of connections that can be created with a specified user name. If this parameter is not specified, the number of connections that can be established by a specified user is not limited.	The value is an integer that varies according to the types and number of devices.

Parameter	Description	Value
<p>idle-timeout <i>minutes</i> [<i>seconds</i>]</p>	<p>Specifies the timeout period for disconnection of the user.</p> <ul style="list-style-type: none"> • <i>minutes</i> is the period when the user interface is disconnected in minutes. • <i>seconds</i> is the period when the user interface is disconnected in seconds. <p>If this parameter is not specified, the device uses the user level configured by the idle-timeout command in the user view.</p> <p>If <i>minutes</i> [<i>seconds</i>] is set to 0 0, the idle disconnection function is disabled.</p>	<ul style="list-style-type: none"> • <i>minutes</i>: the value is an integer ranging from 0 to 35791 minutes. • <i>seconds</i>: the value is an integer ranging from 0 to 59 seconds.
<p>state { active block }</p>	<p>Specifies the status of a local user.</p> <ul style="list-style-type: none"> • active indicates that a local user is in active state. • block indicates that a local user is in blocking state. <p>If a user has established a connection with the device, when the user is set in blocking state, the connection still takes effect but the device rejects subsequent authentication requests from the user.</p> <p>If this parameter is not specified, the status of a local user is active.</p>	<p>-</p>

Views

AAA view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **local-user** *user-name* { **password** { **cipher** | **irreversible-cipher** } *password* [**old-password** *old-password*] | **access-limit** *max-number* | **ftp-directory** *directory* | **idle-timeout** *minutes* [*seconds*] | **privilege level** *level* | **state** { **block** | **active** } } * command.

19.11.1.4 local-user level (upgrade-compatible command)

Function

The **local-user level** command sets the level of a local user.

Format

local-user *user-name* **level** *level*

Parameters

Parameter	Description	Value
<i>user-name</i>	Specifies the user name.	The value is a string of 1 to 64 case-insensitive characters without spaces.
<i>level</i>	Specifies the user level.	The value is an integer that ranges from 0 to 15. A larger value indicates a higher level of a user. After logging in to the device, a user can run only the commands of the same level or lower levels.

Views

AAA view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **local-user *user-name* privilege level *level*** command.

19.11.1.5 radius-attribute encap optimize (upgrade-compatible command)

Function

The **radius-attribute encap optimize disable** command disables RADIUS attribute encapsulation optimization.

The **radius-attribute encap optimize enable** command enables RADIUS attribute encapsulation optimization.

By default, the RADIUS attribute encapsulation optimization function is enabled.

Format

radius-attribute encap optimize { enable | disable }

undo radius-attribute encap optimize disable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.11.1.6 radius-server accounting (upgrade-compatible command)

Function

The **radius-server accounting** command configures the RADIUS accounting server.

The **undo radius-server accounting** command deletes the configuration.

By default, no RADIUS accounting server is configured.

Format

radius-server accounting *ipv4-address port* [**vpn-instance** *vpn-instance-name* | **source** { **loopback** *interface-number* | **ip-address** *ipv4-address* } | **weight** *weight-value*] * **secondary**

radius-server accounting *ipv6-address port* [**source** { **loopback** *interface-number* | **ip-address** *ipv6-address* } | **weight** *weight-value*] * **secondary**

undo radius-server accounting secondary

undo radius-server accounting *ip-address port source* { **loopback** | **ip-address** *ip-address* } **secondary**

undo radius-server accounting *ipv6-address port source* { **loopback** | **ip-address** *ipv6-address* } **secondary**

Parameters

Parameter	Description	Value
<i>ipv4-address</i>	Specifies the IPv4 address of a RADIUS accounting server.	The value is a valid unicast address in dotted decimal notation.
<i>ipv6-address</i>	Specifies the IPv6 address of a RADIUS accounting server.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X:X.
<i>port</i>	Specifies the port number of a RADIUS accounting server.	The value is an integer that ranges from 1 to 65535.
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance that the RADIUS accounting server is bound to.	The vpn-instance must already exist.
source loopback <i>interface-number</i>	Specifies the number of a loopback interface.	The loopback interface must already exist.
source ip-address <i>ipv4-address</i>	Specifies the source IPv4 address of a RADIUS accounting server.	The value is a valid unicast address in dotted decimal notation.
source ip-address <i>ipv6-address</i>	Specifies the source IPv6 address of a RADIUS accounting server.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X:X.

Parameter	Description	Value
weight <i>weight-value</i>	Specifies the weight of a RADIUS accounting server.	The value is an integer that ranges from 0 to 100.
secondary	Specifies the configured accounting server as the secondary accounting server. If you do not configure this parameter, it indicates that you configure the primary accounting server.	-

Views

RADIUS server template view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **radius-server accounting** *ipv4-address port [vpn-instance vpn-instance-name | source { loopback interface-number | ip-address ipv4-address } | weight weight-value] ** or **radius-server accounting** *ipv6-address port [source { loopback interface-number | ip-address ipv6-address } | weight weight-value] ** command.

19.11.1.7 radius-server authentication (upgrade-compatible command)

Function

The **radius-server authentication** command configures a RADIUS authentication server.

The **undo radius-server authentication** command deletes the configured RADIUS authentication server.

By default, no RADIUS authentication server is specified.

Format

radius-server authentication *ipv4-address port [vpn-instance vpn-instance-name | source { loopback interface-number | ip-address ipv4-address } | weight weight-value] * secondary*

radius-server authentication *ipv6-address port* [**source** { **loopback** *interface-number* | **ip-address** *ipv6-address* } | **weight** *weight-value*] * **secondary**

undo radius-server authentication secondary

undo radius-server authentication *ipv4-address port* **source** { **loopback** | **ip-address** *ipv4-address* } **secondary**

undo radius-server authentication *ipv6-address port* **source** { **loopback** | **ip-address** *ipv6-address* } **secondary**

Parameters

Parameter	Description	Value
<i>ipv4-address</i>	Specifies the IPv4 address of a RADIUS authentication server.	The value is a valid unicast address in dotted decimal notation.
<i>ipv6-address</i>	Specifies the IPv6 address of a RADIUS authentication server.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X:X.
<i>port</i>	Specifies the port number of a RADIUS authentication server.	The value is an integer that ranges from 1 to 65535.
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance that the RADIUS authentication server is bound to.	The value is a string of 1 to 31 case-sensitive characters without spaces.
source loopback <i>interface-number</i>	Specifies the IP address of the loopback interface taken as the source IP address. <i>interface-number</i> specifies the number of a loopback interface.	The value is an integer that ranges from 0 to 1023.
source ip-address <i>ipv4-address</i>	Specifies the source IPv4 address in RADIUS packets sent from the device to a RADIUS authentication server. If this parameter is not specified, the IPv4 address of the outbound interface is used as the source IPv4 address in RADIUS packets sent from the device to a RADIUS authentication server.	The value is a valid unicast address in dotted decimal notation.

Parameter	Description	Value
source ip-address <i>ipv6-address</i>	Specifies the source IPv6 address in RADIUS packets sent from the device to a RADIUS authentication server. If this parameter is not specified, the IPv6 address of the outbound interface is used as the source IPv6 address in RADIUS packets sent from the device to a RADIUS authentication server.	The value is a 32-digit hexadecimal number, in the format X:X:X:X:X:X:X.
weight <i>weight-value</i>	Specifies the weight of a RADIUS authentication server.	The value is an integer that ranges from 0 to 100.
secondary	Specifies the configured authentication server as the secondary accounting server. If you do not configure this parameter, it indicates that you configure the primary authentication server.	-

Views

RADIUS server template view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **radius-server authentication** *ipv4-address port [vpn-instance vpn-instance-name | source { loopback interface-number | ip-address ipv4-address } | weight weight-value] ** or **radius-server authentication** *ipv6-address port [source { loopback interface-number | ip-address ipv6-address } | weight weight-value] ** command.

19.11.1.8 radius-server authorization (upgrade-compatible command)

Function

The **radius-server authorization** command configures the RADIUS authorization server.

The **undo radius-server authorization** command deletes the configured RADIUS authorization server.

By default, no RADIUS authorization server is configured.

Format

```
radius-server authorization ip-address [ vpn-instance vpn-instance-name ]
{ server-group group-name | shared-key { key-string | simple simple-string } } *
[ ack-reserved-interval interval ]
```

```
undo radius-server authorization ip-address [ vpn-instance vpn-instance-name ]
```

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the IP address of a RADIUS authorization server.	The value is a valid unicast address in dotted decimal notation.
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance that the RADIUS authorization server is bound to.	The value is a string of 1 to 31 case-sensitive characters without spaces.
server-group <i>group-name</i>	Specifies the name of a RADIUS group corresponding to a RADIUS server template.	The value is a string of 1 to 32 case-sensitive characters without spaces.
shared-key <i>key-string</i>	Specifies the shared key in cipher text.	The value is a string of 32 characters in cipher text, for example, %\$%\$m^NF\$L^SO%2@^y\$T^1' lcZ%\$\$\$, or a string of 1 to 16 characters in plain text, for example, 1234567.
shared-key simple <i>simple-string</i>	Specifies the shared key in plain text.	The value is a string of 1 to 16 case-sensitive characters, without spaces. By default, the key is converted to cipher text.

Parameter	Description	Value
ack-reserved-interval <i>interval</i>	Specifies the duration for retaining a RADIUS authorization response packet.	The value is an integer that ranges from 0 to 300, in seconds. By default, the value is 0s.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **radius-server authorization** command.

19.11.1.9 radius-server shared-key (upgrade-compatible command)

Function

The **radius-server shared-key** command configures the shared key of a RADIUS server.

By default, the password is in cipher text. The default username and password are available in *S Series Switches Default Usernames and Passwords* ([Enterprise Network](#) or [Carrier](#)). If you have not obtained the access permission of the document, see **Help** on the website to find out how to obtain it.

Format

radius-server shared-key { *key-string* | **simple** *simple-string* }

Parameters

Parameter	Description	Value
<i>key-string</i>	Specifies a cipher text password.	The value is a case-sensitive character string of 1 to 256 without spaces, quotation mark ("), and question mark (?).

Parameter	Description	Value
simple <i>simple-string</i>	Specifies a simple text password.	The value is a string of 1 to 16 case-sensitive characters, without spaces.

Views

RADIUS server template view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **radius-server shared-key cipher** *key-string* command.

19.11.1.10 radius-server testuser (upgrade-compatible command)

Function

Using the **radius-server testuser** command, you can create a user account for automatic detection in the RADIUS server template.

Using the **undo radius-server testuser** command, you can delete a user account for automatic detection.

By default, a user account for automatic detection in the RADIUS server template is not created.

Format

radius-server testuser **username** *username* **password** *password*

undo radius-server testuser

Parameters

Parameter	Description	Value
username <i>username</i>	Specifies a user name used for automatic detection.	The value is a string of 1 to 64 characters without spaces. It is case insensitive.

Parameter	Description	Value
password <i>password</i>	Specifies the user password for automatic detection.	The value is a character string of 1 to 16 characters without spaces, single quotation marks and question marks. It is case sensitive. If it is in cipher text, the password is a string of 32 characters.

Views

RADIUS server template view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **radius-server testuser username *username* password cipher *password*** command.

19.11.1.11 radius-server test-user (upgrade-compatible command)

Function

Using the **radius-server test-user** command, you can create a user account for automatic detection in the RADIUS server template.

Using the **undo radius-server test-user** command, you can delete a user account for automatic detection.

By default, a user account for automatic detection in the RADIUS server template is not created.

Format

radius-server test-user *username password*

undo radius-server test-user

Parameters

Parameter	Description	Value
<i>username</i>	Specifies a user name used for automatic detection.	The value is a string of 1 to 64 characters without spaces. It is case insensitive.
<i>password</i>	Specifies the user password for automatic detection.	The value is a character string of 1 to 16 characters without spaces, single quotation marks and question marks. It is case sensitive. If it is in cipher text, the password is a string of 32 characters.

Views

RADIUS server template view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **radius-server testuser username *username* password cipher *password*** command.

19.11.1.12 radius-server test-user detect interval (upgrade-compatible command)

Function

The **radius-server test-user detect interval** command sets the interval for automatic user status detection.

Format

radius-server test-user detect interval *interval-time*

Parameters

Parameter	Description	Value
<i>interval-time</i>	Specifies the interval for automatic user status detection.	The value is an integer that ranges from 5 to 3600, in seconds.

Views

RADIUS server template view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **radius-server detect-server interval interval** *interval* command.

19.11.1.13 radius-server user-name domain-included force (upgrade-compatible command)

Function

The **radius-server user-name domain-included force** command configures the device encapsulate the domain name in the user name in RADIUS packets to be sent to a RADIUS server.

Format

radius-server user-name domain-included force

Parameters

None

Views

RADIUS server template view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **radius-server user-name domain-included** command.

19.11.1.14 remote-aaa-user authen-fail (upgrade-compatible command)

Function

The **remote-aaa-user authen-fail** command enables the remote AAA authentication account locking function, and sets the authentication retry interval, maximum number of consecutive authentication failures, and account locking period.

The **undo remote-aaa-user authen-fail** command disables the remote AAA authentication account locking function.

By default, the remote AAA account locking function is enabled, authentication retry interval is 5 minutes, maximum number of consecutive authentication failures is 30, and account locking period is 5 minutes.

Format

remote-aaa-user authen-fail **retry-interval** *retry-interval* **retry-time** *retry-time*
block-time *block-time*

undo remote-aaa-user authen-fail

Parameters

Parameter	Description	Value
retry-interval <i>retry-interval</i>	Specifies the authentication retry interval.	The value is an integer that ranges from 5 to 65535, in minutes.
retry-time <i>retry-time</i>	Specifies the maximum number of consecutive authentication failures.	The value is an integer that ranges from 3 to 65535.
block-time <i>block-time</i>	Specifies the account locking period.	The value is an integer that ranges from 5 to 65535, in minutes.

Views

AAA view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Its function is the same as that of the **access-user remote authen-fail** command and **administrator remote authen-fail** command.

19.11.2 NAC Compatible Commands

19.11.2.1 authentication arp handshake

Function

The **authentication arp handshake** command enables the handshake with pre-connection users and authorized users.

The **undo authentication arp handshake** command disables the handshake with pre-connection users and authorized users.

By default, the handshake with pre-connection users and authorized users is enabled.

Format

authentication arp handshake

undo authentication arp handshake

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication handshake** command.

19.11.2.2 authentication handshake (upgrade-compatible command)

Function

The **authentication handshake** command enables the handshake with pre-connection users and authorized users.

The **undo authentication handshake** command disables the handshake with pre-connection users and authorized users.

By default, the handshake with pre-connection users and authorized users is enabled.

Format

authentication handshake

undo authentication handshake

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication handshake** command in the authentication profile view.

19.11.2.3 authentication event action authorize (upgrade-compatible command)

Function

The **authentication event action authorize** command configures the device to assign network access policies to users before the users are authenticated.

The **undo authentication event action authorize** command deletes the configured network access policies.

By default, no network access right is granted to users before the users are authenticated.

Format

authentication event pre-authen action authorize service-scheme *service-scheme*

undo authentication event pre-authen action authorize

authentication event { *authen-fail* | *authen-server-down* } action authorize service-scheme *service-scheme* [*response-fail*]

undo authentication event { *authen-fail* | *authen-server-down* } action authorize

Parameters

Parameter	Description	Value
pre-authen	Configures the device to assign network access policies to users when the users establish pre-connections with the device.	-
authen-fail	Configures the device to assign network access policies to users when the authentication server sends authentication failure packets to the device.	-
authen-server-down	Configures the device to assign network access policies to users when the authentication server is Down and thereby the users fail to be authenticated.	-
response-fail	Configures the device to send authentication failure packets to users after assigning network access policies to the users. If this parameter is not specified, the device by default sends authentication success packets to users and therefore the users cannot know the fact that they fail to be authenticated. To solve this problem, specify this parameter so that the device will send authentication failure packets for the users to know their authentication results.	-

Parameter	Description	Value
service-scheme <i>service-scheme</i>	Specifies the name of the service scheme based on which network access policies are assigned to users.	The value is a string of 1 to 32 case-sensitive characters without spaces and the following: \ / : < > @ ' % * " ?

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication event pre-authen action authorize service-scheme** *scheme-name* and **authentication event { authen-fail | authen-server-down } action authorize service-scheme** *service-scheme* [**response-fail**] commands in the authentication profile view.

19.11.2.4 authentication event authen-server-up action re-authen (upgrade-compatible command)

Function

The **authentication event authen-server-up action re-authen** command enables the device to re-authenticate users when the authentication server changes from Down to Up.

The **undo authentication event authen-server-up action re-authen** command restores the default setting.

By default, the device does not re-authenticate users when the authentication server changes from Down to Up.

Format

authentication event authen-server-up action re-authen

undo authentication event authen-server-up action re-authen

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication event authen-server-up action re-authen** command in the authentication profile view.

19.11.2.5 authentication event client-no-response action authorize (upgrade-compatible command)

Function

The **authentication event client-no-response action authorize** command configures the device to assign network access policies to users before the users are authenticated.

The **undo authentication event client-no-response action authorize** command deletes the configured network access policies.

By default, no network access right is granted to users before the users are authenticated.

Format

authentication event client-no-response action authorize service-scheme
service-scheme

undo authentication event client-no-response action authorize

Parameters

Parameter	Description	Value
service-scheme <i>service-scheme</i>	Specifies the name of the service scheme based on which network access policies are assigned to users.	The value is a string of 1 to 32 case-sensitive characters without spaces and the following: \ / : < > @ ' % * " ?

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication event client-no-response action authorize service-scheme** *service-scheme* command in the 802.1X access profile view.

19.11.2.6 authentication event portal-server-down action authorize (upgrade-compatible command)

Function

The **authentication event portal-server-down action authorize** command configures network access policies for users when the Portal server is Down.

The **undo authentication event portal-server-down action authorize** command deletes the configured network access policies.

By default, no network access policy is configured for users when the Portal server is Down.

Format

authentication event portal-server-down action authorize service-scheme
service-scheme

undo authentication event portal-server-down action authorize

Parameters

Parameter	Description	Value
service-scheme <i>service-scheme</i>	Specifies the name of the service scheme based on which network access policies are assigned to users.	The value is a string of 1 to 32 case-sensitive characters without spaces and the following: \ / : < > @ ' % * " ?

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication event portal-server-down action authorize service-scheme** *service-scheme* command in the Portal access profile view.

19.11.2.7 authentication event portal-server-up action re-authen (upgrade-compatible command)

Function

The **authentication event portal-server-up action re-authen** command enables the device to re-authenticate users when the Portal server changes from Down to Up.

The **undo authentication event portal-server-up action re-authen** command restores the default setting.

By default, the device does not re-authenticate users when the Portal server changes from Down to Up.

Format

authentication event portal-server-up action re-authen

undo authentication event portal-server-up action re-authen

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication event portal-server-up action re-authen** command in the Portal access profile view.

19.11.2.8 authentication timer arp handshake-period

Function

The **authentication timer arp handshake-period** command sets the handshake interval of the device with pre-connection users and authorized users.

The **undo authentication timer arp** command restores the default setting.

The default handshake interval of the device with pre-connection users and authorized users is 300 seconds.

Format

authentication timer arp handshake-period *handshake-period*

undo authentication timer arp

Parameters

Parameter	Description	Value
<i>handshake-period</i>	Specifies the handshake interval.	The value is an integer that ranges from 5 to 7200, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication timer handshake-period** *handshake-period* command.

19.11.2.9 authentication timer handshake-period (upgrade-compatible command)

Function

The **authentication timer handshake-period** command sets the handshake interval of the device with pre-connection users and authorized users.

The **undo authentication timer handshake-period** command restores the default setting.

The default handshake interval of the device with pre-connection users and authorized users is 300 seconds.

Format

authentication timer handshake-period *handshake-period*

undo authentication timer handshake-period

Parameters

Parameter	Description	Value
<i>handshake-period</i>	Specifies the handshake interval.	The value is an integer that ranges from 5 to 7200, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication timer handshake-period** *handshake-period* command in the authentication profile view.

19.11.2.10 authentication timer authen-fail-user-aging (upgrade-compatible command)

Function

The **authentication timer authen-fail-user-aging** command configures the aging time for entries of the users who fail to be authenticated.

The **undo authentication timer authen-fail-user-aging** command restores the default aging time for entries of the users who fail to be authenticated.

By default, the aging time for entries of the users who fail to be authenticated is 23 hours.

Format

authentication timer authen-fail-user-aging *aging-time*

undo authentication timer authen-fail-user-aging

Parameters

Parameter	Description	Value
<i>aging-time</i>	Specifies the aging time. If the user still fails to be authenticated when the user aging time expires, the user entry is deleted.	The value is an integer that ranges from 0 or 60 to 4294860, in seconds. The value 0 indicates that the entry does not age.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication timer authen-fail-aging** *aging-time* command in the authentication profile view.

19.11.2.11 authentication timer pre-authen-user-aging (upgrade-compatible command)

Function

The **authentication timer pre-authen-user-aging** command configures the aging time for pre-connection user entries.

The **undo authentication timer pre-authen-user-aging** command restores the default aging time for pre-connection user entries.

By default, the aging time for pre-connection user entries is 23 hours.

Format

authentication timer pre-authen-user-aging *aging-time*

undo authentication timer pre-authen-user-aging

Parameters

Parameter	Description	Value
<i>aging-time</i>	Specifies the aging time. If the user still fails to be authenticated when the user aging time expires, the user entry is deleted.	The value is an integer that ranges from 0 or 60 to 4294860, in seconds. The value 0 indicates that the entry does not age.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication timer pre-authen-aging** *aging-time* command in the authentication profile view.

19.11.2.12 authentication timer re-authen (upgrade-compatible command)

Function

The **authentication timer re-authen** command configures the interval for re-authenticating pre-connection users or users who fail to be authenticated.

The **undo authentication timer re-authen** command restores the default setting.

By default, pre-connection users and users who fail to be authenticated are re-authenticated at an interval of 60 seconds.

Format

authentication timer re-authen { **pre-authen** *re-authen-time* | **authen-fail** *re-authen-time* }

undo authentication timer re-authen { **pre-authen** | **authen-fail** }

Parameters

Parameter	Description	Value
pre-authen <i>re-authen-time</i>	Specifies the interval for re-authenticating pre-connection users.	The value is an integer that ranges from 0 or 30 to 7200, in seconds. The value 0 indicates that the re-authentication function is disabled for pre-connection users.
authen-fail <i>re-authen-time</i>	Specifies the interval for re-authenticating users who fail to be authenticated.	The value is an integer that ranges from 30 to 7200, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication timer re-authen** { **pre-authen** *re-authen-time* | **authen-fail** *re-authen-time* } command in the authentication profile view.

19.11.2.13 authentication device-type voice authorize (upgrade-compatible command)

Function

The **authentication device-type voice authorize** command enables voice terminals to go online without authentication.

The **undo authentication device-type voice authorize** command disables voice terminals from going online without authentication.

By default, voice terminals are disabled from going online without authentication.

Format

authentication device-type voice authorize [**service-scheme** *scheme-name*]

undo authentication device-type voice authorize [**service-scheme**]

Parameters

Parameter	Description	Value
service-scheme	Assigns network access rights to voice terminals based on a specified service scheme.	-
<i>scheme-name</i>	Specifies the name of the service scheme based on which network access rights are assigned to voice terminals.	The value must be an existing service scheme name.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication device-type voice authorize service-scheme** *scheme-name* command in the authentication profile view.

19.11.2.14 authentication free-rule (upgrade-compatible command)

Function

The **authentication free-rule** command configures the NAC authentication-free rule for users.

The **undo authentication free-rule** command restores the default configuration.

By default, no NAC authentication-free rule is configured.

Format

```
authentication free-rule rule-id { destination { any | ip { ip-address mask
{ mask-length | ip-mask } [ tcp destination-port port | udp destination-port
port ] | any } } | source { any | { interface interface-type interface-number | ip
{ ip-address mask { mask-length | ip-mask } | any } | vlan vlan-id } * } } *
undo authentication free-rule { rule-id | all }
```

Parameters

Parameter	Description	Value
<i>rule-id</i>	Specifies the ID of the NAC authentication-free rule.	The value is an integer of which the range depends on product models
destination	Specifies the destination network resources that the authentication-free users can access.	-
source	Specifies the source information of the authentication-free users.	-
any	Specifies any condition. When any is used together with different keywords, the effect of the command is different.	-
ip <i>ip-address</i>	Specifies the IP address in the rule. This parameter can specify the source or destination address depending on the keyword.	The value is in dotted decimal notation.
mask <i>mask-length</i>	Specifies the mask length of an IP address. This parameter can specify the source or destination address mask depending on the keyword.	The value is an integer that ranges from 1 to 32.
mask <i>ip-mask</i>	Specifies the IP address mask. This parameter can specify the source or destination address mask depending on the keyword.	The value is in dotted decimal notation.
tcp destination-port <i>port</i>	Specifies the TCP destination port number.	The value is an integer that ranges from 1 to 65535.

Parameter	Description	Value
udp destination-port <i>port</i>	Specifies the UDP destination port number.	The value is an integer that ranges from 1 to 65535.
interface <i>interface-type</i> <i>interface-number</i>	Specifies the type and number of the source interface in the rule. <ul style="list-style-type: none"> <i>interface-type</i> specifies the interface type. <i>interface-number</i> specifies the interface number. 	-
vlan <i>vlan-id</i>	Specifies the VLAN ID of the source packet in the rule.	The value is an integer that ranges from 1 to 4094.
all	Specifies all rules.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **free-rule** *rule-id* { **destination** { **any** | **ip** { *ip-address* **mask** { *mask-length* | *ip-mask* } } [**tcp destination-port** *port* | **udp destination-port** *port*] | **any** } } | **source** { **any** | { **ip** { *ip-address* **mask** { *mask-length* | *ip-mask* } } | **any** } | **vlan** *vlan-id* } * } } * command in the authentication-free rule profile view.

19.11.2.15 authentication mode (upgrade-compatible command)

Function

The **authentication mode** command configures the user access mode.

The **undo authentication mode** command restores the default user access mode.

By default, the user access mode is **multi-authen**.

Format

authentication mode { **single-terminal** | **single-voice-with-data** | **multi-share** | **multi-authen** [**max-user** *max-user-number*] }

undo authentication mode [**multi-authen** **max-user**]

Parameters

Parameter	Description	Value
single-terminal	Specifies the interface to allow only one user to go online.	-
single-voice-with-data	Specifies the interface to allow only one data user and one voice user to go online. This mode applies to the scenario in which a data user connects to a network through a voice terminal.	-
multi-share	Specifies the interface to allow multiple users to go online. In this mode, the device only authenticates the first user. If the first user can be authenticated, the subsequent users share the same network access rights with the first user. If the first user goes offline, other users are also offline.	-
multi-authen	Specifies the interface to allow multiple users to go online. In this mode, the device authenticates each access user. If users can be authenticated, the users have their individual network access rights. If a user goes offline, other users are not affected.	-
max-user <i>max-user-number</i>	Specifies the maximum number of access users on the interface in multi-authen mode.	The value is an integer that depends on device types.

Views

Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication mode { single-terminal | single-voice-with-data | multi-share | multi-authen [max-user *max-user-number*] }** command in the authentication profile view.

19.11.2.16 authentication (upgrade-compatible command)

Function

The **authentication** command enables NAC authentication.

The **undo authentication** command disables NAC authentication.

By default, NAC authentication is disabled.

Format

Layer 2 interface view:

authentication { { dot1x | mac-authen } * [portal] | portal }

undo authentication { dot1x | mac-authen | portal } *

VLANIF interface view:

authentication { mac-authen [portal] | portal }

undo authentication { mac-authen | portal } *

Layer 3 interface view:

authentication portal

undo authentication portal

Parameters

Parameter	Description	Value
dot1x	Enables 802.1X authentication.	-
mac-authen	Enables MAC address authentication.	-
portal	Enables Portal authentication.	-

Views

VLANIF interface view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **dot1x-access-profile** *access-profile-name*, **mac-access-profile** *access-profile-name*, and **portal-access-profile** *access-profile-name* commands in the authentication profile view.

19.11.2.17 authentication single-access (upgrade-compatible command)

Function

The **authentication single-access** command enables the device to allow users to access in only one authentication mode.

The **undo authentication single-access** command restores the default setting.

By default, the device allows users to access in different authentication modes.

Format

authentication single-access

undo authentication single-access

Parameters

None

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication single-access** command in the authentication profile view.

19.11.2.18 authentication trigger-condition dhcp dhcp-option (upgrade-compatible command)

Function

The **authentication trigger-condition dhcp dhcp-option** command enables the device to send DHCP option information to the authentication server when triggering MAC address authentication through DHCP packets.

The **undo authentication trigger-condition dhcp dhcp-option** command restores the default configuration.

By default, the device does not send DHCP option information to the authentication server when triggering MAC address authentication through DHCP packets.

Format

authentication trigger-condition dhcp dhcp-option *option-code*

undo authentication trigger-condition dhcp dhcp-option *option-code*

Parameters

Parameter	Description	Value
<i>option-code</i>	Specifies the option that the device sends to the authentication server.	The value is fixed as 82.

Views

System view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication trigger-condition dhcp dhcp-option** *option-code* command in the mac access profile view.

19.11.2.19 authentication trigger-condition (802.1X authentication) (upgrade-compatible command)

Function

The **authentication trigger-condition** command configures the packet types that can trigger 802.1X authentication.

The **undo authentication trigger-condition** command restores the default configuration.

By default, DHCP/ARP packets can trigger 802.1X authentication.

Format

authentication trigger-condition { dhcp | arp } *

undo authentication trigger-condition [dhcp | arp] *

Parameters

Parameter	Description	Value
dhcp	Triggers 802.1X authentication through DHCP packets.	-
arp	Triggers 802.1X authentication through ARP packets.	-

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication trigger-condition { dhcp | arp } *** command in the 802.1X access profile view.

19.11.2.20 authentication trigger-condition (MAC address authentication) (upgrade-compatible command)

Function

The **authentication trigger-condition** command configures the packet types that can trigger MAC address authentication.

The **undo authentication trigger-condition** command restores the default configuration.

By default, DHCP/ARP/DHCPv6/ND packets can trigger MAC address authentication.

Format

authentication trigger-condition { dhcp | arp | dhcpv6 | nd } *

undo authentication trigger-condition [dhcp | arp | dhcpv6 | nd] *

Parameters

Parameter	Description	Value
dhcp	Triggers MAC address authentication through DHCP packets.	-
arp	Triggers MAC address authentication through ARP packets.	-
dhcpv6	Triggers MAC address authentication through DHCPv6 packets.	-
nd	Triggers MAC address authentication through ND packets.	-

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication trigger-condition { dhcp | arp | dhcpv6 | nd } *** command in the mac access profile view.

19.11.2.21 domain (upgrade-compatible command)

Function

The **domain** command configures the default domain or force domain for users.

The **undo domain** command deletes the configured default domain or force domain.

By default, no default domain or force domain is configured for users.

Format

Layer 2 interface view:

domain name *domain-name* [**dot1x** | **mac-authen** | **portal**] [**force**]

undo domain name *domain-name* [**dot1x** | **mac-authen** | **portal**] [**force**]

VLANIF interface view:

domain name *domain-name* [**mac-authen** | **portal**] [**force**]

undo domain name *domain-name* [**mac-authen** | **portal**] [**force**]

Layer 3 interface view:

domain name *domain-name* [**portal**] [**force**]

undo domain name *domain-name* [**portal**] [**force**]

System view (for all access authentication users):

domain *domain-name* **force** [**mac-address** *mac-address* **mask** *mask*]

undo domain *domain-name* **force** [**mac-address** *mac-address*]

System view (only for MAC address authentication users):

domain *domain-name* **mac-authen** **force**

undo domain *domain-name* **mac-authen** **force**

domain name *domain-name* **mac-authen** **force** [**mac-address** *mac-address* **mask** *mask*]

undo domain name *domain-name* **mac-authen** **force** [**mac-address** *mac-address*]

Parameters

Parameter	Description	Value
name <i>domain-name</i>	Specifies the name of the default domain or force domain. If no user authentication mode is specified, the default domain or force domain takes effect for all access authentication users.	The value must be an existing domain name on the device.

Parameter	Description	Value
mac-address <i>mac-address</i> mask <i>mask</i>	Specifies the MAC address range within which the MAC address authentication users use the forcible domain. <ul style="list-style-type: none"> • mac-address <i>mac-address</i>: user MAC addresses. • mask <i>mask</i>: masks of the MAC addresses. NOTE You can specify a maximum of 16 MAC address ranges.	The MAC address and mask are both in the format of H-H-H, in which H is a 4-digit hexadecimal number.
mac-address <i>mac-address</i>	User MAC addresses.	The MAC address and mask are both in the format of H-H-H, in which H is a 4-digit hexadecimal number.
dot1x	Specifies 802.1X authentication as the user authentication mode.	-
mac-authen	Specifies MAC address authentication as the user authentication mode.	-
portal	Specifies Portal authentication as the user authentication mode.	-

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **access-domain** *domain-name* [**dot1x** | **mac-authen** | **portal**]* [**force**] command in the authentication profile view.

19.11.2.22 dot1x authentication-method (upgrade-compatible command)

Function

The **dot1x authentication-method** command sets the authentication mode for 802.1X users.

The **undo dot1x authentication-method** command restores the default authentication mode for 802.1X users.

By default, the global 802.1X user authentication mode is CHAP authentication and the 802.1X user authentication mode on interfaces is the same as the mode globally configured.

Format

dot1x authentication-method { **chap** | **pap** | **eap** }

undo dot1x authentication-method

Parameters

Parameter	Description	Value
chap	Indicates the CHAP-based EAP termination authentication mode.	-
pap	Indicates the PAP-based EAP termination authentication mode.	-
eap	Indicates that the EAP relay mode.	-

Views

System view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **dot1x authentication-method { chap | pap | eap }** command in the 802.1X access profile view.

19.11.2.23 dot1x eap-notify-packet (upgrade-compatible command)

Function

The **dot1x eap-notify-packet** command enables the device to send an EAP packet code number to users.

The **undo dot1x eap-notify-packet** command disables the device from sending an EAP packet code number to users.

By default, the device is disabled from sending an EAP packet code number to users.

Format

dot1x eap-notify-packet eap-code *code-number* **data-type** *type-number*

undo dot1x eap-notify-packet [**eap-code** *code-number* **data-type** *type-number*]

Parameters

Parameter	Description	Value
eap-code <i>code-number</i>	Specifies an EAP packet code number sent to users.	The value is an integer that ranges from 5 to 255. The default value is 255.
data-type <i>type-number</i>	Specifies the data type in EAP packets sent to users.	The value is an integer that ranges from 1 to 255. The default value is 255.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **dot1x eap-notify-packet eap-code** *code-number* **data-type** *type-number* command in the 802.1X access profile view.

19.11.2.24 dot1x reauthenticate (upgrade-compatible command)

Function

The **dot1x reauthenticate** command enables periodic 802.1X re-authentication on an interface.

The **undo dot1x reauthenticate** command disables periodic 802.1X re-authentication on an interface.

By default, periodic 802.1X re-authentication is disabled on an interface.

Format

dot1x reauthenticate

undo dot1x reauthenticate

Parameters

None

Views

Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **dot1x reauthenticate** command in the 802.1X access profile view.

19.11.2.25 dot1x retry (upgrade-compatible command)

Function

The **dot1x retry** command sets the maximum number of times an authentication request is sent to an 802.1X user.

The **undo dot1x retry** command restores the default setting.

By default, the device sends an authentication request to an 802.1X user twice.

Format

dot1x retry *max-retry-value*

undo dot1x retry

Parameters

Parameter	Description	Value
<i>max-retry-value</i>	Specifies the maximum number of times an authentication request is sent to an 802.1X user. The default value is recommended.	The value is an integer that ranges from 1 to 10.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **dot1x retry** *max-retry-value* command in the 802.1X access profile view.

19.11.2.26 dot1x timer reauthenticate-period (upgrade-compatible command)

Function

The **dot1x timer reauthenticate-period** command sets the re-authentication interval for 802.1X authentication users.

The **undo dot1x timer reauthenticate-period** command restores the default re-authentication interval.

By default, the re-authentication interval is 3600 seconds.

Format

dot1x timer reauthenticate-period *reauthenticate-period-value*

undo dot1x timer reauthenticate-period

Parameters

Parameter	Description	Value
<i>reauthenticate-period-value</i>	Specifies the re-authentication interval for 802.1X address authentication users.	The value is an integer that ranges from 60 to 7200, in seconds.

Views

System view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **dot1x timer reauthenticate-period** *reauthenticate-period-value* command in the 802.1X access profile view.

19.11.2.27 dot1x timer (upgrade-compatible command)

Function

The **dot1x timer** command sets values of timers used in 802.1X authentication.

The **undo dot1x timer** command restores the default settings of timers used in 802.1X authentication.

By default, the values of timers used in 802.1X authentication are not set.

Format

dot1x timer client-timeout *client-timeout-value*

undo dot1x timer client-timeout

Parameters

Parameter	Description	Value
client-timeout <i>client-timeout-value</i>	Specifies the timeout interval of the authentication response from the client. For details, see dot1x retry .	The value is an integer that ranges from 1 to 120, in seconds. By default, the timeout interval of the authentication response from the client is 5 seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **dot1x timer** command in the 802.1X access profile view.

19.11.2.28 dot1x trigger dhcp-binding (upgrade-compatible command)

Function

The **dot1x trigger dhcp-binding** command enables the device to automatically generate the DHCP snooping binding table after static IP users pass 802.1X authentication or when the users are at the pre-connection phase.

The **undo dot1x trigger dhcp-binding** command restores the default setting.

By default, the device does not automatically generate the DHCP snooping binding table after static IP users pass 802.1X authentication or when the users are at the pre-authentication phase.

Format

dot1x trigger dhcp-binding

undo dot1x trigger dhcp-binding

Parameters

None

Views

Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **dot1x trigger dhcp-binding** command in the dot1x access profile view.

19.11.2.29 dot1x unicast-trigger (upgrade-compatible command)

Function

The **dot1x unicast-trigger** command enables 802.1X authentication triggered by unicast packets.

The **undo dot1x unicast-trigger** command disables 802.1X authentication triggered by unicast packets.

By default, 802.1X authentication triggered by unicast packets is disabled.

Format

dot1x unicast-trigger

undo dot1x unicast-trigger

Parameters

None

Views

Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **dot1x unicast-trigger** command in the 802.1X access profile view.

19.11.2.30 mac-authen offline dhcp-release (upgrade-compatible command)

Function

The **mac-authen offline dhcp-release** command enables the device to clear user entries when receiving DHCP Release packets from MAC address authentication users.

The **undo mac-authen offline dhcp-release** command restores the default configuration.

By default, the device does not clear user entries when receiving DHCP Release packets from MAC address authentication users.

Format

In the system view:

```
mac-authen offline dhcp-release interface { interface-type interface-number1  
[ to interface-number2 ] } &<1-10>
```

```
undo mac-authen offline dhcp-release interface { interface-type interface-  
number1 [ to interface-number2 ] } &<1-10>
```

In the interface view:

```
mac-authen offline dhcp-release
```

```
undo mac-authen offline dhcp-release
```

Parameters

Parameter	Description	Value
interface <i>interface-type interface-number1</i> [<i>to interface-number2</i>] } &<1-10>	Specifies the type and number of an interface. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number1</i> specifies the number of the first interface.• <i>interface-number2</i> specifies the number of the last interface. The value of <i>interface-number2</i> must be greater than the value of <i>interface-number1</i>. <i>interface-number2</i> and <i>interface-number1</i> together specify an interface range.	-

Views

System view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **mac-authen offline dhcp-release** command in the mac access profile view.

19.11.2.31 mac-authen permit mac-address (upgrade-compatible command)

Function

The **mac-authen permit mac-address** command specifies the MAC address range allowed for MAC address authentication.

The **undo mac-authen permit mac-address** command deletes the MAC address range allowed for MAC address authentication.

By default, no MAC address range is specified for MAC address authentication.

Format

mac-authen permit mac-address *mac-address* **mask** { *mask* | *mask-length* }

undo mac-authen permit mac-address *mac-address* **mask** { *mask* | *mask-length* }

Parameters

Parameter	Description	Value
<i>mac-address</i>	Specifies a MAC address for MAC address authentication.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.
mask <i>mask</i>	Specifies the MAC address mask.	The value is in H-H-H format. H contains 1 to 4 hexadecimal digits.
mask <i>mask-length</i>	Specifies the MAC address mask length.	The value is an integer that ranges from 1 to 48.

Views

VLANIF interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **mac-authen permit mac-address mac-address mask { mask | mask-length }** command in the mac access profile view.

19.11.2.32 mac-authen reauthenticate dhcp-renew (upgrade-compatible command)

Function

The **mac-authen reauthenticate dhcp-renew** command enables the device to re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users.

The **undo mac-authen reauthenticate dhcp-renew** command restores the default setting.

By default, the device does not re-authenticate the users when receiving DHCP lease renewal packets from MAC address authentication users.

Format

mac-authen reauthenticate dhcp-renew

undo mac-authen reauthenticate dhcp-renew

Parameters

None

Views

Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **mac-authen reauthenticate dhcp-renew** command in the mac access profile view.

19.11.2.33 mac-authen reauthenticate (upgrade-compatible command)

Function

The **mac-authen reauthenticate** command enables periodic MAC address re-authentication on a specified interface.

The **undo mac-authen reauthenticate** command disables periodic MAC address re-authentication on a specified interface.

By default, periodic MAC address re-authentication is enabled on a specified interface.

Format

mac-authen reauthenticate

undo mac-authen reauthenticate

Parameters

None

Views

Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **mac-authen reauthenticate** command in the mac access profile view.

19.11.2.34 mac-authen timer reauthenticate-period (upgrade-compatible command)

Function

The **mac-authen timer reauthenticate-period** command sets the re-authentication interval for MAC address authentication users.

The **undo mac-authen timer reauthenticate-period** command restores the default re-authentication interval.

By default, the re-authentication interval is 1800 seconds.

Format

mac-authen timer reauthenticate-period *reauthenticate-period-value*

undo mac-authen timer reauthenticate-period

Parameters

Parameter	Description	Value
<i>reauthenticate-period-value</i>	Specifies the re-authentication interval for MAC address authentication users.	The value is an integer that ranges from 60 to 7200, in seconds.

Views

System view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **mac-authen timer reauthenticate-period** *reauthenticate-period-value* command in the mac access profile view.

19.11.2.35 mac-authen username (upgrade-compatible command)

Function

The **mac-authen username** command configures the user name format for MAC address authentication.

The **undo mac-authen username** restores the default user name format.

By default, the MAC address without hyphens (-) is used as the user name and password for MAC address authentication.

Format

mac-authen username { **fixed** *username* [**password cipher** *password*] | **macaddress** [**format** { **with-hyphen** | **without-hyphen** } [**password cipher** *password*]] | **dhcp-option** *option-code* { **circuit-id** | **remote-id** } **password cipher** *password* }

undo mac-authen username [**fixed** *username* [**password cipher** *password*] | **macaddress** [**format** { **with-hyphen** | **without-hyphen** } [**password cipher** *password*]] | **dhcp-option** *option-code* [**password cipher** *password*]]

Parameters

Parameter	Description	Value
fixed <i>username</i>	Specifies the fixed user name for MAC address authentication.	The value is a string of 1 to 64 case-sensitive that do not contain spaces and question marks (?).
password cipher <i>password</i>	<p>Specifies the password displayed in cipher text for MAC address authentication.</p> <ul style="list-style-type: none"> The user with a fixed name can log in without a password if no password is set, which is not recommended. When a MAC address is used as the user name, the MAC address can be used as the password if no password is set. When local authentication is specified in the AAA authentication scheme, you must set a password. If the DHCP option is used as the user name, you must set a password. <p>NOTE If fixed user names are configured in the VLANIF interface view, Eth-Trunk interface view or Port group view, the password must be set.</p> <p>If a MAC address is configured as the user name in the Port group view, the password cannot be set.</p>	<p>The value is a case-sensitive string without question marks (?) or spaces. The password contains 1 to 128 characters in plain text or 48 to 188 characters in cipher text.</p> <p>NOTE To improve security, it is recommended that the password contains at least two types of lower-case letters, upper-case letters, numerals, and special characters, and contains at least 8 characters.</p>

Parameter	Description	Value
macaddress	Specifies that the user name in MAC address authentication is the MAC address.	-
format	Specifies the format of the MAC address.	-
with-hyphen	Specifies that the MAC address with hyphens is used as the user name, for example, 0005-e01c-02e3.	-
without-hyphen	Specifies that the MAC address without hyphens is used as the user name, for example, 0005e01c02e3.	-
dhcp-option <i>option-code</i>	<p>Specifies the name of the MAC address authentication user to a specified DHCP option.</p> <ul style="list-style-type: none"> • circuit-id: Specifies the circuit ID in the DHCP Option82 as the user name in MAC address authentication. • remote-id: Specifies the remote ID in the DHCP Option82 as the user name in MAC address authentication. <p>NOTE In VLANIF interface view, the parameter does not support.</p>	The value is an integer. In the current version, the value is fixed as 82.

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **mac-authen username** command in the mac access profile view.

19.11.2.36 portal auth-network (upgrade-compatible command)

Function

The **portal auth-network** command configures a source subnet for Portal authentication.

The **undo portal auth-network** command restores the default source subnet for Portal authentication.

By default, the source subnet for Portal authentication is 0.0.0.0/0, indicating that users in all subnets must pass Portal authentication.

Format

portal auth-network *network-address* { *mask-length* | *mask-address* }

undo portal auth-network { *network-address* { *mask-length* | *mask-address* } | **all** }

Parameters

Parameter	Description	Value
<i>network-address</i>	Specifies the IP address of the source subnet for Portal authentication.	The value is in dotted decimal notation.
<i>mask-length</i>	Specifies the mask length.	The value is an integer that ranges from 1 to 32.
<i>mask-address</i>	Specifies the mask of the source subnet for Portal authentication.	The value is in dotted decimal notation.
all	Deletes all Portal authentication subnets.	-

Views

VLANIF interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **portal auth-network** *network-address* { *mask-length* | *mask-address* } command in the Portal access profile view.

19.11.2.37 portal https-redirect enable (upgrade-compatible command)

Function

The **portal https-redirect enable** command enables HTTPS redirection of Portal authentication.

The **undo portal https-redirect enable** command disables HTTPS redirection of Portal authentication.

By default, HTTPS redirection is enabled for wireless Portal authentication users and disabled for wired Portal authentication users.

Format

portal https-redirect enable

undo portal https-redirect enable

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **authentication https-redirect enable** command.

19.11.2.38 portal local-server anonymous (interface view) (upgrade-compatible command)

Function

The **portal local-server anonymous** command enables anonymous login for users in built-in Portal authentication.

The **undo portal local-server anonymous** command disables anonymous login for users in built-in Portal authentication.

By default, anonymous login for users in built-in Portal authentication is disabled.

Format

portal local-server anonymous
undo portal local-server anonymous

Parameters

None

Views

VLANIF interface view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **portal local-server anonymous** command in the Portal access profile view.

19.11.2.39 portal local-server ad-image load (upgrade-compatible command)

Function

The **portal local-server ad-image load** command loads an advertisement image file to the built-in Portal server login page.

The **undo portal local-server ad-image load** command deletes the advertisement image file loaded to the built-in Portal server login page.

By default, no advertisement image file is loaded to the built-in Portal server login page.

Format

portal local-server ad-image load *ad-image-file*

undo portal local-server ad-image load

Parameters

Parameter	Description	Value
<i>ad-image-file</i>	<p>Specifies the name of an advertisement image file to be loaded to the built-in Portal server login page.</p> <p>The size of the advertisement image file must be equal to or less than 256 KB. A file of 670 x 405 pixels is recommended.</p>	<p>The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i>.</p> <ul style="list-style-type: none">• <i>drive</i>: indicates the storage device name.• <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~ * / \ : ' "• <i>filename</i>: indicates the file name. The jpg and png formats are supported, and the file name extension must be .jpg, .jpeg, or .png. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

There is a blank area on the login page of the default page package used by the built-in Portal server. Users can customize this area by loading an advertisement

image file. When the login page needs to be customized based on special requirements, the administrator can upload the user-defined advertisement image file to the device and run the **portal local-server ad-image load** command. After the advertisement image file is loaded, the user-defined advertisement images are displayed on the built-in Portal server login page for authentication.

Prerequisites

The user-defined advertisement image file has been uploaded to the device.

Example

Load the advertisement image file **ad.png** to the built-in Portal server login page.

```
<HUAWEI> system-view
[HUAWEI] portal local-server ad-image load flash:/ad.png
Info: The loading process may take a few seconds.Please wait for a moment.
Info: Load web file successfully.
```

19.11.2.40 portal local-server anonymous (Portal access profile view) (upgrade-compatible command)

Function

The **portal local-server anonymous** command enables the anonymous login function for users authenticated through the built-in Portal server.

The **undo portal local-server anonymous** command disables the anonymous login function for users authenticated through the built-in Portal server.

By default, the anonymous login function is disabled for users authenticated through the built-in Portal server.

Format

portal local-server anonymous [**redirect-url** *url*]

undo portal local-server anonymous [**redirect-url**]

Parameters

Parameter	Description	Value
redirect-url <i>url</i>	Specifies the redirect URL. The URL is generally used to push advertisement information.	The value is a string of 1 to 200 case-sensitive characters without spaces and question marks (?). If the string is enclosed in double quotation marks (" "), the string can contain spaces.

Views

Portal access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In places such as airports, hotels, cafes, and public recreation places, the anonymous login function allows users to access the network without entering the user name and password, facilitating network service provisioning.

After the anonymous login function is enabled, users are redirected to the login page the first time they access a web page. To connect to the network, users only need to accept terms in the license agreement and click **Login**.

If the **redirect-url** *url* parameter is specified, the web page corresponding to the specified URL will be automatically displayed when anonymous login users access web pages for the first time. This function can be used for advertisement push and users are unaware of the anonymous login process, improving user experience.

Precautions

When anonymous login is configured, it is recommended that you set AAA authentication mode to none authentication.

Example

In the Portal access template **p1**, configure the anonymous login function for users authenticated through the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal-access-profile name p1  
[HUAWEI-portal-access-profile-p1] portal local-server anonymous
```

19.11.2.41 portal local-server authentication-method (upgrade-compatible command)

Function

The **portal local-server authentication-method** command configures the authentication mode for Portal users on the built-in Portal server.

The **undo portal local-server authentication-method** command restores the default authentication mode for Portal users on the built-in Portal server.

By default, the built-in Portal server uses CHAP to authenticate Portal users.

Format

```
portal local-server authentication-method { chap | pap }  
undo portal local-server authentication-method
```

Parameters

Parameter	Description	Value
chap	Indicates that the built-in Portal server uses CHAP to authenticate Portal users.	-
pap	Indicates that the built-in Portal server uses PAP to authenticate Portal users.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Password Authentication Protocol (PAP) is a two-way handshake authentication protocol. It transmits passwords in plain text format in RADIUS packets.

Challenge Handshake Authentication Protocol (CHAP) is a three-way handshake authentication protocol. It transmits only user names using RADIUS packets, but does not transmit passwords. CHAP is more secure and reliable than PAP. If high security is required, CHAP is recommended.

Prerequisites

The built-in Portal server function has been enabled globally using the **portal local-server** command.

Example

```
# Configure the built-in Portal server to use PAP to authenticate Portal users.
```

```
<HUAWEI> system-view  
[HUAWEI] portal local-server authentication-method pap
```

19.11.2.42 portal local-server background-color (upgrade-compatible command)

Function

The **portal local-server background-color** command configures the background color of the built-in Portal server login page.

The **undo portal local-server background-color** command cancels the background color configured for the built-in Portal server login page.

By default, no background color of the built-in Portal server login page is configured.

Format

portal local-server background-color *background-color-value*

undo portal local-server background-color

Parameters

Parameter	Description	Value
<i>background-color-value</i>	Specifies the background color of the built-in Portal server login page.	The value is a string that ranges from #000000 to #FFFFFF in the RGB format. The hexadecimal code is used to indicate the page color, and the format is always #DEFABC (A-F and 0-9).

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Users can customize the login page of the default page package used by the built-in Portal server. The administrator can configure the background color of the login page.

Example

Configure the user-defined background color of the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server background-color #AABBCC
```

19.11.2.43 portal local-server background-image load (upgrade-compatible command)

Function

The **portal local-server background-image load** command loads a background image file to the built-in Portal server login page.

The **undo portal local-server background-image load** command deletes the background image file loaded to the built-in Portal server login page.

By default, the device has two background images **default-image0** and **default-image1**. The built-in Portal server uses **default-image0** as the background image by default.

Format

portal local-server background-image load { *background-image-file* | **default-image1** }

undo portal local-server background-image load

Parameters

Parameter	Description	Value
<i>background-image-file</i>	<p>Specifies the name of the background image file to be loaded to the built-in Portal server login page.</p> <p>The size of the background image file must be equal to or less than 512 KB. A file of 1366 x 768 pixels is recommended.</p>	<p>The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i>.</p> <ul style="list-style-type: none"> • <i>drive</i>: indicates the storage device name. • <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~ * / \ : ' " • <i>filename</i>: indicates the file name. The jpg and png formats are supported, and the file name extension must be .jpg, .jpeg, or .png. If you enter only the file name, the system considers that the file is stored in the default directory.
default-image1	<p>Loads the background image default-image1 to the built-in Portal server login page.</p>	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Users can customize the login page of the default page package used by the built-in Portal server. Users can customize background images or select the default

ones. When the background image of the login page needs to be customized based on special requirements, the administrator can upload the user-defined background image file to the device and run the **portal local-server background-image load** command. After the image is loaded, the user-defined background image file is displayed on the built-in Portal server login page for authentication.

Prerequisites

The user-defined background image has been uploaded to the device.

Example

Load the background image file **bg.png** to the built-in Portal server login page.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server background-image load flash:/bg.png  
Info: The loading process may take a few seconds.Please wait for a moment.  
Info: Load web file successfully.
```

19.11.2.44 portal local-server enable (Portal access profile view) (upgrade-compatible command)

Function

The **portal local-server enable** command enables the built-in Portal server function in a Portal access profile.

The **undo portal local-server enable** command restores the default setting.

By default, the built-in Portal server function is disabled in a Portal access profile.

Format

```
portal local-server enable  
undo portal local-server enable
```

Parameters

None

Views

Portal access profile view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

In Portal authentication, the device needs to provide the IP address of the Portal server. The device supports external and built-in Portal servers. When the built-in Portal server is required to authenticate users, enable the built-in Portal server

function globally and then run the **portal local-server enable** command in the Portal access profile. Then the built-in Portal server can be used to authenticate the users who use the Portal access profile.

Prerequisites

The built-in Portal server function has been enabled globally using the **portal local-server** command.

Example

In the Portal access profile **p1**, enable the built-in Portal server function.

```
<HUAWEI> system-view
[HUAWEI] interface loopback 1
[HUAWEI-LoopBack1] ip address 10.1.1.1 24
[HUAWEI-LoopBack1] quit
[HUAWEI] portal local-server ip 10.1.1.1
[HUAWEI] ssl policy s1
[HUAWEI-ssl-policy-s1] quit
[HUAWEI] portal local-server https ssl-policy s1
[HUAWEI] portal-access-profile name p1
[HUAWEI-portal-access-profile-p1] portal local-server enable
```

19.11.2.45 portal local-server enable (upgrade-compatible command)

Function

The **portal local-server enable** command enables built-in Portal authentication on an interface.

The **undo portal local-server enable** command disables built-in Portal authentication on an interface.

By default, built-in Portal authentication is disabled on an interface.

Format

In the system view:

```
portal local-server enable interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

```
undo portal local-server enable interface { interface-type interface-number1 [ to interface-number2 ] } &<1-10>
```

In the interface view:

```
portal local-server enable
```

```
undo portal local-server enable
```

Parameters

Parameter	Description	Value
interface { <i>interface-type interface-number1</i> [to <i>interface-number2</i>] }	Specifies the interface type and number. <ul style="list-style-type: none">• <i>interface-type</i> specifies the interface type.• <i>interface-number</i> specifies the interface number.	-

Views

System view, VLANIF interface view, Ethernet interface view, GE interface view, MultiGE interface view, XGE interface view, 25GE interface view, 40GE interface view, 100GE interface view, Eth-Trunk interface view, Port group view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Compared with the external Portal server, the built-in Portal server is easy to use, cost-effective, and easy to maintain. After built-in Portal authentication is enabled, the external Portal server is not required. After the built-in Portal server function is enabled using the **portal local-server** command, built-in Portal authentication must be enabled on the interface using the **portal local-server enable** command to authenticate users on the interface.

Prerequisites

Portal authentication has been enabled globally using the **portal local-server** command.

Precautions

It is recommended that you enable built-in Portal authentication on a VLANIF interface. The VLANIF interface of a super-VLAN does not support built-in Portal authentication.

Built-in Portal authentication of Layer 3 interfaces cannot be configured using this command in the system view.

If 802.1X authentication, MAC address authentication, MAC address bypass authentication or built-in Portal authentication is enabled on a Layer 2 interface, this command cannot be executed on the VLANIF interface of a VLAN to which the Layer 2 interface is added.

The **portal local-server enable** command cannot be used together with the following commands on the same interface.

Command	Function
mac-vlan enable	Enables MAC address-based VLAN assignment on an interface.
ip-subnet-vlan enable	Enables IP subnet-based VLAN assignment on an interface.

Example

Enable built-in Portal authentication on VLANIF 10.

```
<HUAWEI> system-view
[HUAWEI] interface loopback 1
[HUAWEI-LoopBack1] ip address 10.1.1.1 24
[HUAWEI-LoopBack1] quit
[HUAWEI] portal local-server ip 10.1.1.1
[HUAWEI] ssl policy s1
[HUAWEI-ssl-policy-s1] pki-realm default
[HUAWEI-ssl-policy-s1] quit
[HUAWEI] http secure-server ssl-policy s1
[HUAWEI] portal local-server https ssl-policy s1 port 1025
[HUAWEI] vlan batch 10
[HUAWEI] interface vlanif 10
[HUAWEI-Vlanif10] portal local-server enable
```

19.11.2.46 portal local-server ip (upgrade-compatible command)

Function

The **portal local-server ip** command configures an IP address for the built-in Portal server.

The **undo portal local-server ip** command deletes an IP address of the built-in Portal server.

By default, no IP address is configured for the built-in Portal server.

Format

portal local-server ip *ip-address*

undo portal local-server ip

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies an IP address for the built-in Portal server.	The value is in dotted decimal notation.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

When the device is used as a built-in Portal server, you can run the **portal local-server ip** command to configure an IP address for the built-in Portal server. Users are then redirected to the Portal server if they enter URLs that are not located in the free IP subnet.

NOTE

- The IP address assigned to the built-in Portal server must have a reachable route to the user.
- It is recommended that a loopback interface address be assigned to the built-in Portal server because the loopback interface is stable. Additionally, packets destined for loopback interfaces are not sent to other interfaces on the network; therefore, system performance is not deteriorated even if many users request to go online.
- After users go online through the built-in Portal server, if the interface address or interface (non-physical interface) matching the built-in Portal server's IP address is deleted, online users cannot go offline and offline users cannot go online. Therefore, exercise caution when you delete the interface address or interface.

Example

Assign the IP address 10.1.1.1 to the built-in Portal server.

```
<HUAWEI> system-view
[HUAWEI] interface loopback 1
[HUAWEI-LoopBack1] ip address 10.1.1.1 24
[HUAWEI-LoopBack1] quit
[HUAWEI] portal local-server ip 10.1.1.1
```

19.11.2.47 portal local-server keep-alive (upgrade-compatible command)

Function

The **portal local-server keep-alive** command configures the heartbeat detection interval and mode of the built-in Portal server.

The **undo portal local-server keep-alive** command cancels the configured heartbeat detection interval and mode of the built-in Portal server.

By default, the heartbeat detection function of the built-in Portal server is not configured.

Format

portal local-server keep-alive interval *interval-value* [**auto**]

undo portal local-server keep-alive

Parameters

Parameter	Description	Value
interval <i>interval-value</i>	Specifies the heartbeat detection interval of the built-in Portal server.	The value is an integer that ranges from 30 to 7200, in seconds.
auto	Specifies the automatic detection mode. If this parameter is not configured, the forcible detection mode is specified.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

When a user closes the browser or an exception occurs, the device can detect the user's online state to determine whether to make the user go offline. The administrator can configure the heartbeat detection function of the built-in Portal server. If the device does not receive a heartbeat packet from the client within a specified period, the user is specified to go offline. The heartbeat detection mode of the built-in Portal server can be either of the following modes:

- Forcible detection mode: This mode is valid for all users. If the device does not receive a heartbeat packet from a user within a specified period, the device specifies the user to go offline.
- Automatic detection mode: The device checks whether the client browser supports the heartbeat program. If yes, the forcible detection mode is used for the user; if no, the device does not detect the user. You are advised to configure this mode to prevent users from going offline because the browser does not support the heartbeat program.

NOTE

Currently, the heartbeat program is supported by Internet Explorer 8, FireFox 3.5.2, Chrome 28.0.1500.72, and Opera 12.00 on Windows 7. A Java program must be installed and configured on the operating system.

Browsers using Java1.7 and later versions do not support the heartbeat program.

Precautions

When the forcible detection mode is configured, the device specifies users to go offline to prevent from failing to receive heartbeat packets for a long time during

network congestion. In this scenario, the heartbeat detection interval must be increased.

If you run this command multiple times in the same view, only the latest configuration takes effect.

Example

Configure the automatic detection function of the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server keep-alive interval 60 auto
```

19.11.2.48 portal local-server load (upgrade-compatible command)

Function

The **portal local-server load** command loads a page file package to the built-in Portal server.

The **undo portal local-server load** command restores the default configuration.

By default, the built-in Portal server loads the default page file package **portalpage.zip**.

Format

portal local-server load *string*

undo portal local-server load

Parameters

Parameter	Description	Value
<i>string</i>	Specifies the name of the page file package to be loaded to the built-in Portal server.	The value is a string of 1 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i> . <ul style="list-style-type: none">• <i>drive</i>: indicates the storage device name.• <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~ * / \ : ' "• <i>filename</i>: indicates the file name. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Customized page file packages can be loaded to the built-in Portal server.

Prerequisites

The page file (.zip) has been uploaded from the PC to the device storage media.

Precautions

The default page file package can be modified but cannot be deleted. If it is deleted, the built-in Portal server fails to load the pages after startup.

This function is used by technical support personnel to develop limited page customization based on customer requirements and does not apply to customization by customers themselves.

Example

Load the page file **portalpage_01.zip** on the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server load portalpage_01.zip  
Warning: Portal local server has been enabled, and this operation will affect online user, continue?[Y/N]:y
```

19.11.2.49 portal local-server logo load (upgrade-compatible command)

Function

The **portal local-server logo load** command loads a logo file to the built-in Portal server login page.

The **undo portal local-server logo load** command deletes the logo file loaded to the built-in Portal server login page.

By default, no logo file is loaded to the built-in Portal server login page.

Format

portal local-server logo load *logo-file*

undo portal local-server logo load

Parameters

Parameter	Description	Value
<i>logo-file</i>	<p>Specifies the name of the logo file to be loaded to the built-in Portal server login page.</p> <p>The size of the logo file must be equal to or less than 128 KB. A file of 591 x 80 pixels is recommended.</p>	<p>The value is a string of 5 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i>.</p> <ul style="list-style-type: none">• <i>drive</i>: indicates the storage device name.• <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~ * / \ : ' "• <i>filename</i>: indicates the file name. The jpg and png formats are supported, and the file name extension must be .jpg, .jpeg, or .png. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

There is a blank area on the login page of the default page package used by the built-in Portal server. Users can customize this area by loading a logo file. When the login page needs to be customized based on special requirements, the administrator can upload the user-defined logo file to the device and run the **portal local-server logo load** command. After the logo file is loaded, the user-defined logo is displayed on the built-in Portal server login page for authentication.

Prerequisites

The user-defined logo file has been uploaded to the device.

Example

Load the logo file **logo.png** to the built-in Portal server login page.

```
<HUAWEI> system-view
[HUAWEI] portal local-server logo load flash:/logo.png
Info: The loading process may take a few seconds.Please wait for a moment.
Info: Load web file successfully.
```

19.11.2.50 portal local-server (upgrade-compatible command)

Function

The **portal local-server** command enables the built-in Portal server function.

The **undo portal local-server** command disables the built-in Portal server function.

By default, the built-in Portal server function is disabled.

Format

portal local-server https ssl-policy *policy-name* [**port** *port-num*]

undo portal local-server https

Parameters

Parameter	Description	Value
https	Configures the built-in Portal server to exchange authentication messages with users using the Hypertext Transfer Protocol Secure (HTTPS) protocol.	-
ssl-policy <i>policy-name</i>	Specifies the Secure Sockets Layer (SSL) policy used by the built-in Portal server.	The value must be the name of an existing SSL policy.
port <i>port-num</i>	Specifies the TCP port number used. If you do not specify a port number, the default port number is used.	The value can be 443 or any integer in the range of 1025 to 55535. By default, the port number is 443.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Compared with an external Portal server, a built-in Portal server is easy to use, cost-effective, and easy to maintain. After a built-in Portal server is configured, Portal authentication can be implemented for users without an external Portal server. When using the **portal local-server** command to enable the built-in Portal server function, configure the built-in Portal server to exchange authentication messages with users using the HTTPS protocol. HTTPS is a secure extension of HTTP and uses the SSL protocol to guarantee secure communication. To enable the built-in Portal server to exchange authentication messages using HTTPS, you need to configure an SSL policy and load a digital certificate to the server.

Prerequisites

- The IP address of the built-in Portal server has been configured using the **portal local-server ip** command.
- An SSL policy has been configured using the **ssl policy *policy-name*** command in the system view, and a certificate has been loaded using the **certificate load** command in the SSL policy view.
- You have obtained a digital certificate for the SSL policy from an authorized certificate authority.

Precautions

When there are Portal authentication users online, you cannot disable the built-in Portal server function or change the SSL policy for the built-in Portal server.

Example

Enable the built-in Portal server function and configure the server to use the SSL policy **s1**.

```
<HUAWEI> system-view
[HUAWEI] interface loopback 1
[HUAWEI-LoopBack1] ip address 10.1.1.1 24
[HUAWEI-LoopBack1] quit
[HUAWEI] portal local-server ip 10.1.1.1
[HUAWEI] ssl policy s1
[HUAWEI-ssl-policy-s1] quit
[HUAWEI] portal local-server https ssl-policy s1
```

19.11.2.51 portal local-server page-text load (upgrade-compatible command)

Function

The **portal local-server page-text load** command loads the use instruction page file of the built-in Portal server.

The **undo portal local-server page-text load** command deletes the loaded use instruction page file of the built-in Portal server.

By default, no use instruction page file of the built-in Portal server is loaded.

Format

portal local-server page-text load *string*

undo portal local-server page-text load

Parameters

Parameter	Description	Value
<i>string</i>	Specifies the use instruction page file of the built-in Portal server.	The value is a string of 1 to 64 case-insensitive characters without spaces, in the format of [drive] [path] filename. <ul style="list-style-type: none">• drive indicates the storage device name.• path indicates the directory or sub-directory. The directory name cannot contain the following characters: ~ * / \ : ' "• filename indicates the file name. The file name extension must be .txt or .html. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

If you need to customize the use instruction page, you can upload the customized use instruction page file to the device, and run this command to load the file. After the file is loaded, the hyperlink **Instruction for Use** is generated on the login page of the built-in Portal server, and users can click the hyperlink to access the use instruction page.

Prerequisite

The page file to be loaded has been uploaded to the device.

Precautions

When the to-be-loaded page is customized, the page length and width are fixed. After adjusting the page, the administrator must upload and load the modified page again.

Currently, only Chinese or English page files can be loaded on the device.

Example

Load the use instruction page file **page.html** to the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server page-text load flash:/page.html  
Info: The loading process may take a few seconds.Please wait for a moment.  
Info: Load web file successfully.
```

19.11.2.52 portal local-server policy-text load (upgrade-compatible command)

Function

The **portal local-server policy-text load** command loads a disclaimer page file to the built-in Portal server.

The **undo portal local-server policy-text load** command deletes the loaded disclaimer page file.

By default, no disclaimer page file is loaded to the built-in Portal server.

Format

portal local-server policy-text load *string*

undo portal local-server policy-text load

Parameters

Parameter	Description	Value
<i>string</i>	Specifies the name of the disclaimer page file to be loaded to the built-in Portal server.	The value is a string of 1 to 64 case-insensitive characters without spaces, in the format of [<i>drive</i>] [<i>path</i>] <i>filename</i> . <ul style="list-style-type: none">• <i>drive</i>: indicates the storage device name.• <i>path</i>: indicates the directory and its subdirectory. The directory name cannot contain the following characters: ~ * / \ : ' "• <i>filename</i>: indicates the file name. The file name extension must be .txt or .html. If you enter only the file name, the system considers that the file is stored in the default directory.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

To customize a disclaimer page, upload the disclaimer page file to the device and run this command to load the file. After the file is loaded, the hyperlink **Disclaimer** will be displayed on the login page. You can click the link to visit the disclaimer page.

Prerequisite

The disclaimer page file to be loaded has been uploaded to the device.

Precautions

Currently, only Chinese and English disclaimer page files can be loaded on the device.

Example

Load the disclaimer page file **policy.html** to the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server policy-text load policy.html  
Info: The loading process may take a few seconds.Please wait for a moment.  
Info: Load web file successfully.
```

19.11.2.53 portal local-server timer session-timeout (upgrade-compatible command)

Function

The **portal local-server timer session-timeout** command configures the session timeout interval for built-in Portal authentication users.

The **undo portal local-server timer session-timeout** command restores the default session timeout interval for built-in Portal authentication users.

By default, the session timeout interval is 8 hours for built-in Portal authentication users.

Format

portal local-server timer session-timeout *interval*

undo portal local-server timer session-timeout

Parameters

Parameter	Description	Value
<i>interval</i>	Specifies the session timeout interval for built-in Portal authentication users.	The value is an integer that ranges from 1 to 720, in hours.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Scenario

When built-in Portal authentication is used for users and the device functions as a built-in Portal server, you can configure the session timeout interval for the users.

The users are disconnected after the specified session timeout interval. To connect to the network again, the users need to be re-authenticated.

Precautions

The session timeout interval for built-in Portal authentication users is calculated based on the device time. For example, if the session timeout interval is 6 hours and the device time is 2014-09-01 02:00:00 when a user was connected, the user should be disconnected at 2014-09-01 08:00:00. Therefore, ensure that the device time and time zone are correct after the session timeout interval is configured for users. If the device time is incorrect, users may fail to be connected or disconnected properly. You can run the **display clock** command to check the device time and the time zone.

Example

```
# Set the session timeout interval to 10 hours for built-in Portal authentication users.
```

```
<HUAWEI> system-view  
[HUAWEI] portal local-server timer session-timeout 10
```

19.11.2.54 portal local-server syslog-limit enable (upgrade-compatible command)

Function

The **portal local-server syslog-limit enable** command enables the log suppression function for users authenticated through the built-in Portal server.

The **undo portal local-server syslog-limit enable** command disables the log suppression function for users authenticated through the built-in Portal server.

By default, the log suppression function is enabled for users authenticated through the built-in Portal server.

Format

```
portal local-server syslog-limit enable
```

```
undo portal local-server syslog-limit enable
```

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device generates logs when users authenticated through the built-in Portal server fail to go online or offline. If a user fails to go online or offline, the user attempts to go online or offline repeatedly, and the device generates a large number of logs within a short time. This results in a high failure rate in the statistics and degrades the system performance. You can run the **portal local-server syslog-limit enable** command to enable the log suppression function for users authenticated through the built-in Portal server. The device then only generates one log if a user fails to go online or offline within a suppression period (configured using the **portal local-server syslog-limit period** command).

Example

```
# Enable the log suppression function for users authenticated through the built-in Portal server.
```

```
<HUAWEI> system-view  
[HUAWEI] portal local-server syslog-limit enable
```

19.11.2.55 portal local-server syslog-limit period (upgrade-compatible command)

Function

The **portal local-server syslog-limit period** command configures the log suppression period for users authenticated through the built-in Portal server.

The **undo portal local-server syslog-limit period** command restores the default log suppression period.

By default, the log suppression period is 300 seconds for users authenticated through the built-in Portal server.

Format

```
portal local-server syslog-limit period value
```

```
undo portal local-server syslog-limit period
```

Parameters

Parameter	Description	Value
<i>value</i>	Specifies the log suppression period for users authenticated through the built-in Portal server.	The value is an integer that ranges from 60 to 604800, in seconds.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The device generates logs when users authenticated through the built-in Portal server fail to go online or offline. If a user fails to go online or offline, the user attempts to go online or offline repeatedly, and the device generates a large number of logs within a short time. This results in a high failure rate in the statistics and degrades the system performance. You can enable the log suppression function (configured using the **portal local-server syslog-limit enable** command) for users authenticated through the built-in Portal server. The device then only generates one log if a user fails to go online or offline within a suppression period.

Example

Set the log suppression period to 1000 seconds for users authenticated through the built-in Portal server.

```
<HUAWEI> system-view  
[HUAWEI] portal local-server syslog-limit period 1000
```

19.11.2.56 portal timer offline-detect (upgrade-compatible command)

Function

The **portal timer offline-detect** command sets the Portal user offline detection interval.

The **undo portal timer offline-detect** command restores the default Portal user offline detection interval.

By default, the Portal user offline detection interval is 300 seconds.

Format

portal timer offline-detect *time-length*

undo portal timer offline-detect

Parameters

Parameter	Description	Value
<i>time-length</i>	Specifies the Portal user offline detection interval.	The value is 0 or an integer that ranges from 30 to 7200, in seconds. The default value is 300. The value 0 indicates that offline detection is not performed.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **portal timer offline-detect** *time-length* command in the Portal access profile view.

19.11.2.57 url-parameter

Function

The **url-parameter** command sets parameters in a URL.

The **undo url-parameter** command deletes parameters in a URL.

By default, a URL does not carry parameters.

Format

url-parameter { **ac-ip** *ac-ip-value* | **ac-mac** *ac-mac* }*

undo url-parameter

NOTE

The command is only supported by the S5731-H, S5731S-H, S6730S-H, S5732-H, and S6730-H.

Parameters

Parameter	Description	Value
ac-ip <i>ac-ip-value</i>	Specifies the IP address of the ac carried in the URL and sets the parameter name displayed in the URL. In the wireless access scenario, the value of ac-ip carried in the URL is the CAPWAP gateway address.	The value is a string of 1 to 16 case-sensitive characters without spaces or Chinese characters. If the string is enclosed in double quotation marks (" "), the string can contain spaces.

Parameter	Description	Value
ac-mac <i>ac-mac-value</i>	Specifies the MAC address of the ac carried in the URL and sets the parameter name displayed in the URL.	The value is a string of 1 to 16 case-sensitive characters without spaces or Chinese characters. If the string is enclosed in double quotation marks (" "), the string can contain spaces.

Views

URL template view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade. After the upgrade, this command is no longer supported, and it is replaced by the following command in the URL template view:

```
url-parameter { device-ip device-ip-value | device-mac device-mac }*
```

19.11.2.58 url (URL template view) (upgrade-compatible command)

Function

The **url** command configures the redirect URL or pushed URL.

The **undo url** command cancels the redirect URL or pushed URL.

By default, no redirect URL or pushed URL is configured.

Format

```
url [ ssid ssid ] [ push-only | redirect-only ] url-string
```

Parameters

Parameter	Description	Value
<i>url-string</i>	Specifies the redirect URL of the Portal server or pushed URL.	It is a string of 1 to 200 case-sensitive characters that do not contain spaces and question marks (?).
ssid <i>ssid</i>	Specifies the SSID that users associate with.	The SSID must already exist.
push-only	Specifies the URL as a pushed URL.	-
redirect-only	Specifies the URL as a redirect URL.	-

Views

URL template view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Example

```
# Set the redirect URL to http://10.1.1.1.
```

```
<HUAWEI> system-view  
[HUAWEI] url-template name huawei  
[HUAWEI-url-template-huawei] url http://10.1.1.1
```

19.11.2.59 ucl-group (upgrade-compatible command)

Function

The **ucl-group** command creates a UCL group.

By default, no UCL group is created.

Format

```
ucl-group name group-name [ extend ]
```

Parameters

Parameter	Description	Value
name <i>group-name</i>	Specifies the name of a UCL group.	The value is a string of 1 to 31 case-sensitive characters without spaces.
extend	Extends the maximum number of UCL groups.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Example

```
# Create a UCL group named abc.
```

```
<HUAWEI> system-view  
[HUAWEI] ucl-group name abc
```

19.11.2.60 voice-vlan (service scheme view) (upgrade-compatible command)

Function

The **voice-vlan** command configures a voice VLAN in a service scheme.

The **undo voice-vlan** command deletes the voice VLAN configured in the service scheme.

By default, no voice VLAN is configured in the service scheme.

Format

```
voice-vlan vlan-id
```

```
undo voice-vlan
```

Parameters

Parameter	Description	Value
<i>vlan-id</i>	Specifies the voice VLAN ID.	The value is an integer that ranges from 1 to 4094.

Views

Service scheme view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

Example

Configure voice VLAN 100 in the service scheme **huawei**.

```
<HUAWEI> system-view
[HUAWEI] aaa
[HUAWEI-aaa] service-scheme huawei
[HUAWEI-aaa-service-huawei] voice-vlan 100
```

19.11.2.61 web-auth-server (interface view) (upgrade-compatible command)

Function

The **web-auth-server** command binds a Portal server template to an interface.

The **undo web-auth-server** command unbinds a Portal server template from an interface.

By default, no Portal server template is bound to an interface.

Format

- Layer 2 interface view
web-auth-server *server-name* [*bak-server-name*] **direct**
undo web-auth-server [*server-name* [*bak-server-name*] **direct**]
- VLANIF interface view
web-auth-server *server-name* [*bak-server-name*] { **direct** | **layer3** }
undo web-auth-server [*server-name* [*bak-server-name*] { **direct** | **layer3** }]
- Routed main interface view


```
web-auth-server server-name [ bak-server-name ] layer3  
undo web-auth-server [ server-name [ bak-server-name ] layer3 ]
```

Parameters

Parameter	Description	Value
<i>server-name</i>	Specifies the name of the Portal server template.	The value must be an existing Portal server template name.
<i>bak-server-name</i>	Specifies the name of the secondary Portal server template. NOTE The name of the secondary Portal server template cannot be configured to the command-line keywords direct and layer3 .	The value must be an existing Portal server template name.
direct	Specifies Layer 2 authentication as the Portal authentication mode. When there is no Layer 3 forwarding device between the user and device, the device can learn the user's MAC address. The device identifies the user using the MAC address.	-
layer3	Specifies Layer 3 authentication as the Portal authentication mode. Whether Layer 3 forwarding devices exist between the user and device, the device cannot learn the user's MAC address. The device identifies the user using the IP address uniquely.	-

Views

VLANIF interface view, Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **web-auth-server** *server-name* [*bak-server-name*] { **direct** | **layer3** } command in the Portal access profile view.

19.12 Security Compatible Commands

19.12.1 ACL Compatible Commands

19.12.1.1 acl ipv6 (upgrade-compatible command)

Function

The **acl ipv6** command creates an ACL6 and enters the ACL6 view.

The **undo acl ipv6** command deletes an ACL.

Format

```
acl ipv6 [ number ] acl6-number [ name acl6-name ] [ match-order { auto | config } ]
```

```
undo acl ipv6 { all | [ number ] acl6-number | name acl6-name }
```

Parameters

Parameter	Description	Value
number <i>acl6-number</i>	Indicates the ID of an ACL6.	The value of <i>acl6-number</i> is an integer that ranges from 2000 to 3999. In these options, <ul style="list-style-type: none">• ACL6s numbered from 2000 to 2999 are basic ACL6s.• ACL6s numbered from 3000 to 3999 are advanced ACL6s.
name <i>acl6-name</i>	Specifies a named ACL6.	The value of <i>acl6-name</i> is a string of 1 to 64 case-sensitive characters without spaces. The name starts with a letter (case-sensitive) and can contain letters, digits, and symbols such as the number sign (#), percentage symbol (%), and hyphen (-).

Parameter	Description	Value
all	Deletes all ACL6s.	-
match-order { auto config }	<p>Indicates the matching order of ACL6 rules.</p> <ul style="list-style-type: none">• auto: indicates that ACL6 rules are matched based on the depth first principle. If the ACL rules are of the same depth first order, they are matched in ascending order of rule IDs.• config: indicates that ACL6 rules are matched based on the configuration order. The ACL6 rules are matched based on the configuration order only when the rule ID is not specified. If rule IDs are specified, the ACL6 rules are matched in ascending order of rule IDs. <p>If the match-order parameter is not specified when you create an ACL6, the default match order config is used.</p>	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

An ACL6 is a set of rules composed of **permit** or **deny** clauses. ACL6s are mainly used in QoS. ACL6s can limit data flows to improve network performance. For

example, ACL6s are configured on an enterprise network to limit video data flows, which lowers the network load and improves network performance.

Follow-up Procedure

Run the **rule** command to configure ACL6 rules and apply the ACL6 to services which packets need to be filtered.

Example

```
# Create an ACL6 named test and numbered 3100.
```

```
<HUAWEI> system-view  
[HUAWEI] acl ipv6 number 3100 name test  
[HUAWEI-acl6-adv-test]
```

19.12.1.2 acl (upgrade-compatible command)

Function

The **acl** command creates an ACL and enters the ACL view.

The **undo acl** command deletes a specified ACL.

Format

```
acl [ number ] acl-number [ name acl-name ]
```

```
undo acl { all | [ number ] acl-number | name acl-name }
```

Parameters

Parameter	Description	Value
number <i>acl-number</i>	Indicates the ID of an ACL.	The value of <i>acl-number</i> is an integer that ranges from 2000 to 5999. <ul style="list-style-type: none">• ACLs numbered from 2000 to 2999 are basic ACLs.• ACLs numbered from 3000 to 3999 are advanced ACLs.• ACLs numbered from 4000 to 4999 are Layer 2 ACLs.• ACLs numbered from 5000 to 5999 are customized ACLs.

Parameter	Description	Value
name <i>acl-name</i>	Specifies a named ACL.	The value of <i>acl-name</i> is a string of 1 to 32 case-sensitive characters without spaces. The name starts with a letter (case-sensitive) and can contain letters, digits, and symbols such as the number sign (#), percentage symbol (%), and hyphen (-).
all	Deletes all ACLs.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

An ACL consists of a list of rules. Each rule contains a permit or deny clause. Before creating an ACL rule, you must create an ACL.

Example

Create an ACL named test and numbered 3100.

```
<HUAWEI> system-view
[HUAWEI] acl number 3100 name test
[HUAWEI-acl-adv-test]
```

19.12.1.3 rule (advanced ACL6 view) (upgrade-compatible command)

Function

The **rule** command adds or modifies advanced ACL6 rules.

Format

```
rule [ rule-id ] { deny | permit } ipv6-ah [ destination { destination-ipv6-address
prefix-length | destination-ipv6-address/prefix-length | destination-ipv6-address
postfix postfix-length | any } | dscp dscp | fragment | logging | precedence
precedence | source { source-ipv6-address prefix-length | source-ipv6-address/
prefix-length | source-ipv6-address postfix postfix-length | any } | time-range
time-name | tos tos | vpn-instance vpn-instance-name ] *
```

rule [*rule-id*] { **deny** | **permit** } **ipv6-esp** [**destination** { *destination-ipv6-address prefix-length* | *destination-ipv6-address/prefix-length* | *destination-ipv6-address postfix postfix-length* | **any** } | **dscp** *dscp* | **fragment** | **logging** | **precedence** *precedence* | **source** { *source-ipv6-address prefix-length* | *source-ipv6-address/prefix-length* | *source-ipv6-address postfix postfix-length* | **any** } | **time-range** *time-name* | **tos** *tos* | **vpn-instance** *vpn-instance-name*] *

Parameters

Parameter	Description	Value
<i>rule-id</i>	Indicates the ID of an ACL6 rule.	The value ranges from 0 to 2047. <ul style="list-style-type: none"> If the ID of a rule is specified and the rule exists, the new rule is added to the rule with this ID, that is, the old rule is modified. If the rule associated with a rule ID does not exist, a rule can be created with this rule ID and its position in the ACL is determined by the rule ID. If no rule ID is specified, the device allocates an ID to the new rule. The rule IDs are sorted in ascending order.
deny	Discards packets that do not match ACL rules.	-
permit	Allows packets to pass.	-
ipv6-ah	Indicates the protocol type.	-
ipv6-esp	Indicates the protocol type.	-
destination { <i>destination-ipv6-address prefix-length</i> <i>destination-ipv6-address/prefix-length</i> any }	Indicates the destination address and prefix of a packet.	<i>destination-ipv6-address</i> is expressed in hexadecimal notation. The value of <i>prefix-length</i> is an integer that ranges from 1 to 128. You can also use any to represent any destination address.

Parameter	Description	Value
destination <i>destination-ipv6-address</i> postfix <i>postfix-length</i>	Indicates the destination address and the length of destination address postfix.	<i>destination-ipv6-address</i> indicates the destination address and is expressed in hexadecimal notation. <i>postfix-length</i> is an integer that ranges from 1 to 64.
dscp <i>dscp</i>	Specifies the value of a Differentiated Services CodePoint (DSCP).	The value ranges from 0 to 63.
fragment	Indicates that the rule is valid for only non-initial fragments.	-
logging	Indicates whether to record logs for packets that meet ACL rules.	Log contents include the ACL rule ID, pass or discard of packets, type of the protocol over IP, source or destination address, source or destination port number, and number of packets.
precedence <i>precedence</i>	Filters packets by priority.	The value is a name or a digit that ranges from 0 to 7.
source { <i>source-ipv6-address</i> <i>prefix-length</i> <i>source-ipv6-address/</i> <i>prefix-length</i> any }	Indicates the source address and prefix of a packet.	<i>source-ipv6-address</i> indicates the source address and is expressed in hexadecimal notation. <i>prefix-length</i> is an integer that ranges from 1 to 128. You can also use any to represent any source address.
source <i>source-ipv6-address</i> postfix <i>postfix-length</i>	Indicates the source address and the length of source address postfix.	<i>source-ipv6-address</i> indicates the source address and is expressed in hexadecimal notation. <i>postfix-length</i> is an integer that ranges from 1 to 64.
time-range <i>time-name</i>	Specifies the time range only in which ACL6 rules are effective. <i>time-name</i> indicates the name of the time range.	The value is a string of 1 to 32 characters.
tos <i>tos</i>	Filters packets by Type of Service (ToS).	The value is a name or a digit that ranges from 0 to 15.

Parameter	Description	Value
vpn-instance <i>vpn-instance-name</i>	Specifies the name of a VPN instance.	The vpn-instance must already exist.

Views

Advanced ACL6 view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Advanced ACL6s classify data packets based on the source IP address, destination IP address, source port number, destination port number, and protocol type.

Prerequisites

An ACL6 has been created before the rule is configured.

Precautions

If the specified rule ID already exists and the new rule conflicts with the original rule, the new rule replaces the original rule.

To modify an existing rule, delete the old rule, and then create a new rule. Otherwise, the configuration result may be incorrect.

When you use the **undo rule** command to delete an ACL6 rule, the rule ID must exist. If the rule ID is unknown, you can use the **display acl ipv6** command to view the rule ID.

The **undo rule** command deletes an ACL6 rule even if the ACL6 rule is referenced. Exercise caution when you run the **undo rule** command.

Example

```
# Create an advanced ACL6 with ID 3000 and configure a rule that allows only IPv6 ESP packets with the source IPv6 address xxxx:xxxx::xxxx and mask 64 to pass.
```

```
<HUAWEI> system-view
[HUAWEI] acl ipv6 number 3000
[HUAWEI-acl6-adv-3000] rule 0 permit ipv6-esp source xxxx:xxxx::xxxx/64
```

19.12.2 Local Attack Defense Compatible Commands

19.12.2.1 blacklist (upgrade-compatible command)

Function

The **blacklist** command configures an ACL-based blacklist.
By default, no blacklist is configured.

Format

blacklist *blacklist-id* **acl** *acl-number* **soft-drop**

Parameters

Parameter	Description	Value
acl <i>acl-number</i>	Indicates the ACL ID. The ACL referenced by a blacklist on the device can be a basic ACL, an advanced ACL, or a Layer 2 ACL.	The value is an integer that ranges from 2000 to 4999.
soft-drop	Indicates that the blacklist is implemented through software.	-
<i>blacklist-id</i>	Specifies the number of an ACL6 referenced by a blacklist.	The value is an integer that ranges from 2000 to 3999. <ul style="list-style-type: none">• 2000 to 2999: basic ACL6s• 3000 to 3999: advanced ACL6s

Views

System view, Attack defense policy view

Default Level

2: Configuration level

Usage Guidelines

A maximum of 8 blacklists can be configured in an attack defense policy on the device. You can set the attributes of a blacklist by defining ACL rules.

The packets sent from users in the blacklist are discarded after reaching the device.

Example

Reference ACL 2001 in the blacklist.

```
<HUAWEI> system-view  
[HUAWEI] cpu-defend policy test  
[HUAWEI-cpu-defend-policy-test] blacklist acl 2001 soft-drop
```

19.12.2.2 car cpu-port (upgrade-compatible command)

Function

The **car cpu-port** command configures the CIR of all the packets to be sent to the CPU.

By default, the CIR value of all the packets to be sent to the CPU is 1024 kbit/s on the device.

Format

```
car cpu-port cir cir-rate
```

Parameters

Parameter	Description	Value
car <i>cir-rate</i>	Sets the CIR of all the packets to be sent to the CPU.	The value is an integer that ranges from 64 to 2048, in kbit/s.

Views

Attack defense policy view

Default Level

2: Configuration level

Usage Guidelines

The **car cpu-port** command limits the total rate of all protocol packets sent to the CPU. The **car packet-type** command limits the rate of packets of a specified protocol. However, the total CIR of packets of specified protocols cannot exceed the CIR of all the packets sent to the CPU.

When the CIR is exceeded, excess packets including unicast, multicast, and broadcast packets are not sent to the CPU. In addition, the unicast packets are discarded directly.

Example

```
# Set the CIR of all the packets to be sent to the CPU to 512 kbit/s on the device.
```

```
<HUAWEI> system-view  
[HUAWEI] cpu-defend policy test  
[HUAWEI-cpu-defend-policy-test] car cpu-port cir 512
```

19.12.2.3 deny (upgrade-compatible command)

Function

The **deny** command sets the discard action taken for packets sent to the CPU.

The **undo deny** command restores the default action taken for packets sent to the CPU.

By default, the device limits the rate of protocol packets and user-defined flows based on the CAR configuration.

Format

deny packet-type bpu

deny packet-type ftp-dynamic

deny packet-type hotlimit

deny packet-type smlk-rrpp

deny packet-type nac-dhcp

undo deny packet-type bpu

undo deny packet-type ftp-dynamic

undo deny packet-type hotlimit

undo deny packet-type smlk-rrpp

undo deny packet-type nac-dhcp

Parameters

Parameter	Description	Value
packet-type bpu	Discards BPDU packets.	-
packet-type ftp-dynamic	Discards ftp-dynamic packets.	-
packet-type hotlimit	Discards hop-limit packets.	-
packet-type smlk-rrpp	Discards smlk-rrpp packets.	-
packet-type nac-dhcp	Discards nac-dhcp packets.	-

Views

Attack defense policy view

Default Level

2: Configuration level

Usage Guidelines

If you run the **deny** and **car** commands for the same type of packets sent to the CPU, the command that runs later takes effect. The **undo deny** command restores the default action taken for packets sent to the CPU. After you run this command, the system limits the rate of packets sent to the CPU based on the configured CIR and CBS values.

Example

Set the discard action taken for bpdv packets sent to the CPU attack in defense policy test.

```
<HUAWEI> system-view  
[HUAWEI] cpu-defend policy test  
[HUAWEI-cpu-defend-policy-test] deny packet-type bpdv
```

19.12.3 Attack Defense Compatible Commands

19.12.3.1 application-apperceive default drop (upgrade-compatible command)

Function

The **application-apperceive default drop** command enables the device to discard the received packets when no matching application layer association policy exists.

The **undo application-apperceive default drop** command enables the device to deliver the received packets to the upper layer though no matching application layer association policy exists.

By default, the device is enabled to deliver the received packets to the upper layer though no matching application layer association policy exists.

Format

application-apperceive default drop

undo application-apperceive default drop

Parameters

None

Views

System view

Default Level

2: Configuration level

Usage Guidelines

After the **application-apperceive default drop** command is run, if a protocol is not enabled in the system view nor in the interface view, the device discards all the packets of this protocol type.

Example

Enable the device to discard the received packets when no matching application layer association policy exists.

```
<HUAWEI> system-view  
[HUAWEI] application-apperceive default drop
```

19.12.4 Traffic Suppression Compatible Commands

19.12.4.1 broadcast-suppression (upgrade-compatible command)

Function

The **broadcast-suppression** command sets the maximum traffic rate of broadcast packets that can pass through an interface.

The **undo broadcast-suppression** command restores the default traffic rate of broadcast packets that can pass through an interface.

Format

broadcast-suppression { *broadcast-pct* | **packets** *packets-per-second* }

undo broadcast-suppression

Parameters

Parameter	Description	Value
<i>broadcast-pct</i>	Specifies the maximum percentage of broadcast traffic on an interface.	The value ranges from 0 to 100. The default value is 100. By default, broadcast traffic is not suppressed on interfaces.
packets <i>packets-per-second</i>	Specifies the maximum number of broadcast packets allowed to pass through an interface per second.	The value of <i>packets-per-second</i> is an integer.

Views

Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

When the traffic rate of broadcast packets exceeds the maximum value, the system discards excess broadcast packets to control the traffic rate and ensure normal operation of network services.

Example

Set the maximum percentage of broadcast traffic to 20% of interface bandwidth on Eth-Trunk1.

```
<HUAWEI> system-view  
[HUAWEI] interface eth-trunk 1  
[HUAWEI-Eth-Trunk1] broadcast-suppression 20
```

19.12.4.2 multicast-suppression (upgrade-compatible command)

Function

The **multicast-suppression** command sets the maximum traffic rate of unknown multicast packets that can pass through an interface.

The **undo multicast-suppression** command restores the default traffic rate of unknown multicast packets that can pass through an interface.

Format

multicast-suppression { *multicast-pct* | **packets** *packets-per-second* }

undo multicast-suppression

Parameters

Parameter	Description	Value
<i>multicast-pct</i>	Specifies the maximum percentage of unknown multicast traffic on an Ethernet interface.	The value ranges from 0 to 100. The default value is 100. By default, unknown multicast traffic is not suppressed on interfaces.

Parameter	Description	Value
packets <i>packets-per-second</i>	Specifies the maximum number of unknown multicast packets allowed to pass through an interface per second.	The value of <i>packets-per-second</i> is an integer.

Views

Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

When the traffic rate of unknown multicast packets exceeds the maximum value, the system discards excess unknown multicast packets to control the traffic rate and ensure normal operation of network services.

Example

Set the maximum percentage of unknown multicast traffic to 20% of interface bandwidth on Eth-Trunk1.

```
<HUAWEI> system-view  
[HUAWEI] interface eth-trunk 1  
[HUAWEI-Eth-Trunk1] multicast-suppression 20
```

19.12.4.3 unicast-suppression (upgrade-compatible command)

Function

The **unicast-suppression** command sets the maximum traffic rate of unknown unicast packets that can pass through an interface.

The **undo unicast-suppression** command restores the default traffic rate of unknown unicast packets that can pass through an interface.

Format

unicast-suppression { *unicast-pct* | **packets** *packets-per-second* }

undo unicast-suppression

Parameters

Parameter	Description	Value
<i>unicast-pct</i>	Specifies maximum percentage of unknown unicast traffic on an Ethernet interface.	The value ranges from 0 to 100. The default value is 100. By default, unknown unicast traffic is not suppressed on interfaces.
packets <i>packets-per-second</i>	Specifies the maximum number of unknown unicast packets allowed to pass through an interface per second.	The value of <i>packets-per-second</i> is an integer.

Views

Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

When the traffic rate of unknown unicast packets exceeds the maximum value, the system discards excess unknown unicast packets to control the traffic rate and ensure normal operation of network services.

Example

Set the maximum percentage of unknown unicast traffic to 20% of interface bandwidth on Eth-Trunk1.

```
<HUAWEI> system-view  
[HUAWEI] interface eth-trunk1  
[HUAWEI-Eth-Trunk1] unicast-suppression 20
```

19.12.4.4 storm-control action (upgrade-compatible command)

Function

The **storm-control action** sets the storm control action to **shutdown**.

The **undo storm-control action** command cancels the configuration.

By default, no storm control action is configured.

Format

storm-control action shutdown

undo storm-control action

Parameters

Parameter	Description	Value
shutdown	Shuts down an interface.	-

Views

Ethernet interface view, GE interface view, XGE interface view, port group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

It is replaced by the **storm-control action error-down** command.

Example

Configure the storm control action is **shutdown** on GE0/0/1.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] storm-control action shutdown
```

19.12.5 ARP Security Compatible Commands

19.12.5.1 arp anti-attack rate-limit (upgrade-compatible command)

Function

The **arp anti-attack rate-limit** command sets the maximum rate and rate limit duration of ARP packets globally, in a VLAN, or on an interface, enables the function of discarding all ARP packets received from the interface when the rate of ARP packets exceeds the limit on an interface.

The **undo arp anti-attack rate-limit** command restores the default maximum rate and rate limit duration of ARP packets globally, in a VLAN, or on an interface, and allows the device to send ARP packets to the CPU again.

By default, a maximum of 100 ARP packets are allowed to pass in 1 second, and the function of discarding all ARP packets received from the interface when the rate of ARP packets exceeds the limit is disabled.

Format

System view, VLAN view

arp anti-attack rate-limit *packet-number* [*interval-value*]

Interface view

arp anti-attack rate-limit *packet-number* [*interval-value* | **block timer** *timer*]*

undo arp anti-attack rate-limit

Parameters

Parameter	Description	Value
<i>packet-number</i>	Specifies the maximum rate of sending ARP packets, that is, the number of ARP packets allowed to pass through in the rate limit duration.	The value is an integer that ranges from 1 to 16384. The default value is 100.
<i>interval-value</i>	Specifies the rate limit duration of ARP packets.	The value is an integer that ranges from 1 to 86400, in seconds. The default value is 1 second.
block timer <i>timer</i>	Specifies the duration for blocking ARP packets.	The value is an integer that ranges from 5 to 864000, in seconds.

Views

System view, VLAN view, GE interface view, XGE interface view, port group view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

After rate limit on ARP packets is enabled, run the **arp anti-attack rate-limit** command to set the maximum rate and rate limit duration of ARP packets globally, in a VLAN, or on an interface. In the rate limit duration, if the number of received ARP packets exceeds the limit, the device discards the excess ARP packets.

If the parameter **block timer** *timer* is specified, the device discards all ARP packets received in the duration specified by *timer*.

Prerequisites

Rate limit on ARP packets has been enabled globally, in a VLAN, or on an interface using the **arp anti-attack rate-limit enable** command.

Precautions

If the maximum rate and rate limit duration are configured in the system view, VLAN view, and interface view, the device uses the configurations in the interface view, VLAN view, and system view in order.

If the maximum rate and rate limit duration are set globally or on an interface at the same time, the configurations on an interface and globally take effect in descending order of priority.

NOTE

The **arp anti-attack rate-limit** command takes effect only on ARP packets sent to the CPU for processing in **none-block** mode, and does not affect ARP packet forwarding by the chip. In **block** mode, only when the number of ARP packets sent to the CPU exceeds the limit, the device discards subsequent ARP packets on the interface.

Example

Configure GE0/0/1 to allow 200 ARP packet to pass through in 10 seconds, and configure GE0/0/1 to discard all ARP packets in 60 seconds when the number of ARP packets exceeds the limit.

```
<HUAWEI> system-view
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] arp anti-attack rate-limit enable
[HUAWEI-GigabitEthernet0/0/1] arp anti-attack rate-limit 200 10 block timer 60
```

19.12.5.2 arp filter source (upgrade-compatible command)

Function

The **arp filter source** command enables ARP gateway protection for the specified IP address.

The **undo arp filter source** command disables ARP gateway protection for the specified IP address.

By default, ARP gateway protection is disabled.

Format

arp filter source *ip-address*

undo arp filter source { *ip-address* | **all** }

Parameters

Parameter	Description	Value
<i>ip-address</i>	Specifies the protected gateway IP address.	The value is in dotted decimal notation.

Parameter	Description	Value
all	Disables ARP gateway protection for all IP addresses in the current view.	-

Views

Ethernet interface view, GE interface view, XGE interface view, 40GE interface view, MultiGE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, it is replaced by the **arp trust source** command.

19.12.6 DHCP Snooping Compatible Commands

19.12.6.1 dhcp option82 format (upgrade-compatible command)

Function

The **dhcp option82 format** command configures the format of the Option 82 field in DHCP messages.

Format

dhcp option82 [**circuit-id** | **remote-id**] **format userdefined** *text*

Parameters

Parameter	Description	Value
circuit-id	Specifies the format of the circuit-id (CID).	-
remote-id	Specifies the format of the remote-id (RID).	-
userdefined <i>text</i>	Indicates the user-defined format of the Option 82 field.	<i>text</i> is the user-defined character string of the Option 82 field.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

You can use the **dhcp option82 format** command to configure the format of the Option 82 field in DHCP messages.

Example

Configure the user-defined string for the CID in the Option 82 field and use the hexadecimal format to encapsulate the CID type (0, indicating the hexadecimal format), length (excluding the length of the CID type and the length keyword itself), outer VLAN ID, slot ID (5 bits), subslot ID (3 bits), and port number (8 bits).

```
<HUAWEI> system-view  
[HUAWEI] dhcp option82 circuit-id format userdefined 0 %length %svlan %5slot %3subslot %8port
```

19.12.6.2 dhcp snooping alarm { user-bind | mac-address | untrust-reply } enable (upgrade-compatible command)

Function

The **dhcp snooping alarm enable** command enables the alarm function for DHCP snooping.

The **undo dhcp snooping alarm enable** command disables the alarm function for DHCP snooping.

By default, the alarm function for discarded DHCP messages is disabled.

Format

```
dhcp snooping alarm { user-bind | mac-address | untrust-reply } { enable |  
[ enable ] threshold threshold }
```

```
undo dhcp snooping alarm { user-bind | mac-address | untrust-reply } { enable  
| [ enable ] threshold }
```

Parameters

Parameter	Description	Value
user-bind	Generates an alarm when the number of DHCP messages discarded because they do not match DHCP snooping binding entries reaches the threshold.	-

Parameter	Description	Value
mac-address	Generates an alarm when the number of DHCP messages discarded because the CHADDR field in the DHCP message does not match the source MAC address in the Ethernet frame header reaches the threshold.	-
untrust-reply	Generates an alarm when the number of DHCP Reply messages discarded by untrusted interfaces reaches the threshold.	-
threshold <i>threshold</i>	Specifies the alarm threshold. When the number of discarded DHCP messages reaches the threshold, an alarm is generated.	The value is an integer that ranges from 1 to 1000.

Views

Ethernet interface view, GE interface view, XGE interface view, Eth-Trunk interface view, Port-group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

It is replaced by the **dhcp snooping alarm { dhcp-request | dhcp-chaddr | dhcp-reply } enable [threshold *threshold*]** command.

Example

On GE0/0/1, enable DHCP snooping, and enable the alarm function for DHCP snooping.

```
<HUAWEI> system-view
[HUAWEI] dhcp snooping enable
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] dhcp snooping enable
[HUAWEI-GigabitEthernet0/0/1] dhcp snooping alarm user-bind enable
```

19.12.6.3 dhcp snooping bind-table autosave (upgrade-compatible command)

Function

The **dhcp snooping bind-table autosave** command configures a device to automatically back up DHCP snooping binding entries in a specified file.

Format

dhcp snooping bind-table autosave *file-name* [**write-delay** *delay-time*]

Parameters

Parameter	Description	Value
<i>file-name</i>	Specifies the path for storing the file that backs up DHCP snooping binding entries and the file name. You must specify both the path and name of the file supported by the system.	The value is a string of 1 to 51 characters.
write-delay <i>delay-time</i>	Specifies the interval for local automatic backup of the DHCP snooping binding table. If this parameter is not specified, the backup interval is the default value.	The value is an integer that ranges from 60 to 4294967295, in seconds. By default, the system backs up the DHCP snooping binding table every two days.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

You can use the **dhcp snooping bind-table** command to back up DHCP snooping binding entries in a specified file.

Example

Configure a device to automatically back up DHCP snooping binding entries in the file **backup.tbl** in the flash memory.

```
<HUAWEI> system-view  
[HUAWEI] dhcp snooping enable  
[HUAWEI] dhcp snooping bind-table autosave flash:/backup.tbl
```

19.12.6.4 dhcp snooping check enable (upgrade-compatible command)

Function

The **dhcp snooping check enable** enables the device to check DHCP messages.

The **undo dhcp snooping check enable** disables the device from checking DHCP messages.

By default, the device does not check DHCP messages.

Format

In the system view:

```
dhcp snooping check { user-bind | mac-address } enable vlan { vlan-id1 [ to vlan-id2 ] }&<1-10>
```

```
undo dhcp snooping check { user-bind | mac-address } enable vlan { vlan-id1 [ to vlan-id2 ] }&<1-10>
```

In the VLAN view, Ethernet interface view, GE interface view, XGE interface view, Eth-Trunk interface view, Port-group view:

```
dhcp snooping check { user-bind | mac-address } enable
```

```
undo dhcp snooping check { user-bind | mac-address } enable
```

Parameters

Parameter	Description	Value
user-bind	Check DHCP messages against the DHCP snooping binding table.	-
mac-address	Compare the MAC address in DHCP ACK or DHCP Request messages with the CHADDR value.	-
vlan { <i>vlan-id1</i> [to <i>vlan-id2</i>] } &<1-10>	Enables the device to check the HCP messages from a specified VLAN to the processing unit. <ul style="list-style-type: none">• <i>vlan-id1</i> specifies the first VLAN ID.• to <i>vlan-id2</i> specifies the last VLAN ID. <i>vlan-id2</i> must be larger than <i>vlan-id1</i>.	The value is an integer that ranges from 1 to 4094.

Views

VLAN view, System view, Ethernet interface view, GE interface view, XGE interface view, Eth-Trunk interface view, Port-group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the command is used, you can check DHCP messages against the DHCP snooping binding table or Compare the MAC address in DHCP ACK or DHCP Request messages with the CHADDR value.

Example

```
# Enable the function of checking DHCP messages against the binding table in  
VLAN 100.
```

```
<HUAWEI> system-view  
[HUAWEI] vlan 100  
[HUAWEI-vlan100] dhcp snooping check user-bind enable
```

19.12.6.5 dhcp snooping check dhcp-rate alarm enable (upgrade-compatible command)

Function

The **dhcp snooping check dhcp-rate alarm enable** command enables the device to generate an alarm when the number of discarded DHCP messages reaches the threshold.

By default, the device is disabled from generating an alarm when the number of discarded DHCP messages reaches the threshold.

Format

```
dhcp snooping check dhcp-rate alarm { enable | [ enable ] threshold  
threshold }
```

Parameters

Parameter	Description	Value
threshold <i>threshold</i>	Specifies the alarm threshold for checking the rate of sending DHCP messages to the processing unit. An alarm is generated after the rate for sending DHCP messages is checked and the number of discarded DHCP messages reaches the alarm threshold.	The value is an integer that ranges from 1 to 1000.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the alarm function is enabled, the device sends a trap message when the number of discarded DHCP messages reaches the alarm threshold.

Example

In the system view, enable the device to generate an alarm when the number of discarded DHCP messages reaches the threshold.

```
<HUAWEI> system-view  
[HUAWEI] dhcp snooping check dhcp-rate alarm enable
```

19.12.6.6 dhcp snooping check dhcp-rate enable alarm dhcp-rate enable (upgrade-compatible command)

Function

Using the **dhcp snooping check dhcp-rate enable alarm dhcp-rate enable** command, you can:

- Enable the function of checking the rate of sending DHCP messages to the DHCP protocol stack.
- Set the rate limit of sending DHCP messages to the DHCP protocol stack.
- Enable the DHCP message discard alarm.
- Set the alarm threshold for discarded DHCP messages.

By default, the function of checking the rate of sending DHCP messages to the DHCP stack is disabled; the rate limit of sending DHCP messages to the DHCP stack is 100 pps; the DHCP message discard alarm is disabled; the alarm threshold for discarded DHCP messages is 100.

Format

dhcp snooping check dhcp-rate { enable | [enable] [rate] rate } alarm dhcp-rate { enable | [enable] threshold threshold-value }

Parameters

Parameter	Description	Value
[rate] rate	Specifies the rate limit of sending DHCP messages to the DHCP protocol stack.	The value ranges from 1 to 100, in pps. The default value is 100.
alarm dhcp-rate enable	Enables the DHCP message discard alarm.	-

Parameter	Description	Value
threshold <i>threshold-value</i>	Specifies the alarm threshold for discarded DHCP messages. After the function is enabled, an alarm is generated when the number of discarded DHCP messages reaches the alarm threshold on an interface.	The value ranges from 1 to 1000. The default value is 100.

Views

Ethernet interface view, GE interface view, XGE interface view, Eth-Trunk interface view, Port-group view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the command is used, the DHCP message discard alarm is enabled. If the number of discarded messages reaches the alarm threshold, an alarm is generated.

Example

On GE 0/0/1, enable the function of checking the rate of sending DHCP messages, set the rate limit of sending DHCP messages to the DHCP protocol stack to 50 pps, enable the DHCP message discard alarm, and set the alarm threshold for discarded DHCP messages to 50.

```
<HUAWEI> system-view  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] dhcp snooping check dhcp-rate enable 50 alarm dhcp-rate enable threshold 50
```

19.12.6.7 dhcp snooping check dhcp-rate enable alarm enable (upgrade-compatible command)

Function

Using the **dhcp snooping check dhcp-rate enable alarm enable** command, you can:

- Enable the function of checking the rate of sending DHCP messages to the processing unit.

- Set the rate limit of sending DHCP messages to the processing unit.
- Enable the device to generate an alarm when the number of discarded DHCP messages reaches the threshold.
- Set the alarm threshold for the number of discarded DHCP messages.

By default, the device does not check the rate of sending DHCP messages to the processing unit; the maximum rate of sending DHCP messages to the processing unit is 100 pps; the device does not generate an alarm when the number of discarded DHCP messages reaches the threshold; the alarm threshold for the number of discarded DHCP messages is 100.

Format

```
dhcp snooping check dhcp-rate enable [ [ rate ] rate ] alarm [ dhcp-rate ]  
{ enable | [ enable ] threshold threshold }
```

Parameters

Parameter	Description	Value
[rate] rate	Specifies the rate limit of sending DHCP messages to the processing unit.	The value is an integer that ranges from 1 to 100, in pps. The default value is 100.
dhcp-rate	Generates an alarm when the number of discarded DHCP messages reaches the threshold.	-
threshold threshold	Specifies the alarm threshold. When the number of discarded DHCP messages reaches the threshold, an alarm is generated.	The value is an integer that ranges from 1 to 1000. The default value is 100.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

After the command is used, the DHCP message discard alarm is enabled. If the number of discarded messages reaches the alarm threshold, an alarm is generated.

Example

```
# Enable the function of checking the rate of sending DHCP messages to the
processing unit, set the rate limit of sending DHCP messages to the processing
unit to 50 pps, enable the DHCP message discard alarm, and set the alarm
threshold for discarded DHCP messages to 50.
```

```
<HUAWEI> system-view
[HUAWEI] dhcp snooping check dhcp-rate enable 50 alarm dhcp-rate enable threshold 50
```

19.12.6.8 dhcp snooping check { dhcp-request | dhcp-chaddr | dhcp-giaddr } enable alarm

Function

The **dhcp snooping check { dhcp-request | dhcp-chaddr | dhcp-giaddr | user-bind | mac-address } enable alarm enable** command enables the DHCP packet check and alarm function.

By default, the DHCP packet check and alarm function is disabled.

Format

```
dhcp snooping check { dhcp-request | dhcp-chaddr | dhcp-giaddr | user-bind |
mac-address } enable alarm { dhcp-request | dhcp-chaddr | dhcp-reply | user-
bind | mac-address | untrust-reply } { enable | [ enable ] threshold threshold }
```

Parameters

Parameter	Description	Value
dhcp-request or user-bind	Generates alarms when the number of DHCP packets that are discarded because they do not match the binding table reaches the threshold.	-
dhcp-chaddr or mac-address	Generates alarms when the number of DHCP packets that are discarded because the CHADDR field in the packets is different from the MAC address in the frame header reaches the threshold.	-
dhcp-reply or untrust-reply	Generates alarms when the number of DHCP server response packets discarded by untrusted interfaces reaches the threshold.	-

Parameter	Description	Value
threshold <i>threshold</i>	Specifies the alarm threshold. The device generates alarm information when the number of discarded DHCP packets reaches the threshold.	The value is an integer that ranges from 1 to 1000.

Views

Interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

This function equals to the combination of the **dhcp snooping check dhcp-giaddr enable**, **dhcp snooping check dhcp-chaddr enable**, **dhcp snooping check dhcp-request enable**, and **dhcp snooping alarm { user-bind | mac-address | untrust-reply } threshold *threshold*** commands.

Example

Enable the **user-bind** check function on GE0/0/1. Set the alarm threshold to 1000 for the discarded packet in the **user-bind** check.

```
<HUAWEI> system-view
[HUAWEI] dhcp enable
[HUAWEI] dhcp snooping enable
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] dhcp snooping enable
[HUAWEI-GigabitEthernet0/0/1] dhcp snooping check user-bind enable alarm user-bind enable
threshold 100
```

19.12.6.9 dhcp snooping check enable alarm enable (upgrade-compatible command)

Function

The **dhcp snooping check enable alarm enable** command enables the DHCP packet check and alarm function.

By default, the DHCP packet check and alarm function is disabled.

Format

```
dhcp snooping check { dhcp-request | dhcp-chaddr | dhcp-giaddr } enable  
alarm { user-bind | mac-address | untrust-reply } { enable | [ enable ]  
threshold threshold
```

Parameters

Parameter	Description	Value
dhcp-request	Matches DHCP packets with entries in the binding table.	-
dhcp-chaddr	Checks whether the MAC address and CHADDR field in DHCP packets are consistent.	-
dhcp-giaddr	Checks whether the GIADDR field in DHCP packets is not zero.	-
user-bind	Generates an alarm when the number of DHCP packets discarded because they do not match DHCP snooping binding entries reaches the threshold.	-
mac-address	Generates an alarm when the number of DHCP packets discarded because the CHADDR field in the DHCP packet does not match the source MAC address in the Ethernet frame header reaches the threshold.	-
untrust-reply	Generates an alarm when the number of DHCP Reply packets discarded by untrusted interfaces reaches the threshold.	-
threshold <i>threshold</i>	Specifies the alarm threshold. When the number of discarded DHCP packets reaches the threshold, an alarm is generated.	The value is an integer that ranges from 1 to 1000.

Views

Interface view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade. This function equals to the combination of the **dhcp snooping check dhcp-giaddr enable**, **dhcp snooping check dhcp-chaddr enable**, **dhcp snooping check dhcp-request enable**, and **dhcp snooping alarm { dhcp-request | dhcp-chaddr | dhcp-reply } threshold *threshold*** commands.

19.12.6.10 dhcp snooping global max-user-number (upgrade-compatible command)

Function

The **dhcp snooping global max-user-number** command sets the maximum number of global DHCP users.

By default, the maximum number of global DHCP users is 1024.

Format

dhcp snooping global max-user-number *max-user-number*

Parameters

Parameter	Description	Value
<i>max-user-number</i>	Specifies the maximum number of global DHCP users.	The value is an integer that ranges from 1 to 1024.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

The **dhcp snooping global max-user-number** command takes effect only when DHCP snooping is enabled globally and is valid for only DHCP users. When the number of global DHCP users reaches the threshold set by this command, no more users can access.

You can use the **dhcp snooping global max-user-number** command to set the maximum number of global users.

Example

Set the maximum number of global DHCP users to 100.

```
<HUAWEI> system-view  
[HUAWEI] dhcp snooping enable  
[HUAWEI] dhcp snooping global max-user-number 100
```


19.12.6.11 dhcp snooping information circuit-id (upgrade-compatible command)

Function

The **dhcp snooping information circuit-id** command configures the Option 82 circuit-id format.

Format

System view:

```
dhcp snooping information circuit-id string string
```

Interface view:

```
dhcp snooping information [ vlan vlan-id ] circuit-id string string
```

Parameters

Parameter	Description	Value
string <i>string</i>	Specifies the circuit-id format.	The value is a string of 1 to 63 characters.
vlan <i>vlan-id</i>	Specifies a VLAN ID.	The value is an integer that ranges from 1 to 4094.

Views

System view, Ethernet interface view, GE interface view, XGE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

You can use the **dhcp snooping information circuit-id** command to configure the Option 82 circuit-id format.

Example

```
# Configure the Option 82 circuit-id format.
```

```
<HUAWEI> system-view  
[HUAWEI] dhcp snooping information circuit-id string teststring
```

19.12.6.12 dhcp snooping information format (upgrade-compatible command)

Function

The **dhcp snooping information format** command configures the Option 82 field format.

Format

dhcp snooping information format { **hex** | **ascii** }

Parameters

Parameter	Description	Value
hex	Sets the Option 82 format to hexadecimal.	-
ascii	Sets the Option 82 format to ASCII.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

You can use the **dhcp snooping information format** command to configure the Option 82 field format.

Example

```
# Set the Option 82 format to ASCII.
```

```
<HUAWEI> system-view  
[HUAWEI] dhcp snooping information format ascii
```

19.12.6.13 dhcp snooping information remote-id (upgrade-compatible command)

Function

The **dhcp snooping information remote-id** command configures the Option 82 remote-id format.

Format

System view:

```
dhcp snooping information remote-id { sysname | string string }
```

Interface view:

```
dhcp snooping information [ vlan vlan-id ] remote-id string string
```

Parameters

Parameter	Description	Value
sysname	System name.	-
string <i>string</i>	Specifies the remote-id format.	The value is a string of 1 to 63 characters.
vlan <i>vlan-id</i>	Specifies a VLAN ID.	The value is an integer that ranges from 1 to 4094.

Views

System view, Ethernet interface view, GE interface view, XGE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

You can use the **dhcp snooping information remote-id** command to configure the Option 82 remote-id format.

Example

```
# Configure the Option 82 remote-id format.
```

```
<HUAWEI> system-view  
[HUAWEI] dhcp snooping information remote-id string teststring
```

19.12.6.14 dhcp snooping max-user-number global (upgrade-compatible command)

Function

The **dhcp snooping max-user-number global** command sets the maximum number of global DHCP users.

By default, the maximum number of global DHCP users is 1024.

Format

dhcp snooping max-user-number *max-user-number* **global**

Parameters

Parameter	Description	Value
<i>max-user-number</i>	Specifies the maximum number of global DHCP users.	The value is an integer that ranges from 1 to 1024.

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

The command takes effect only when DHCP snooping is enabled globally and is valid for only DHCP users. When the number of global DHCP users reaches the threshold set by this command, no more users can access. You can use the command to set the maximum number of global users.

Example

```
# Set the maximum number of global DHCP users to 100.
```

```
<HUAWEI> system-view  
[HUAWEI] dhcp snooping enable  
[HUAWEI] dhcp snooping max-user-number 100 global
```

19.12.6.15 dhcp snooping sticky-mac (upgrade-compatible command)

Function

The **dhcp snooping sticky-mac** command enables the device to generate static MAC address entries based on dynamic DHCP snooping binding entries.

The **undo dhcp snooping sticky-mac** command disables the device from generating static MAC address entries based on dynamic DHCP snooping binding entries.

By default, the device is disabled to generate static MAC address entries based on dynamic DHCP snooping binding entries.

Format

dhcp snooping sticky-mac
undo dhcp snooping sticky-mac

Parameters

None

Views

Ethernet interface view, GE interface view, XGE interface view, port group view,
Eth-trunk interface view

Default Level

2: Configuration level

Usage Guidelines

Usage Scenario

Dynamic MAC address entries are learned and generated by the device, and static MAC address entries are configured by command lines. A MAC address entry consists of the MAC address, VLAN ID, and port number of a DHCP client. The device implements Layer 2 forwarding based on MAC address entries.

After the **dhcp snooping sticky-mac** command is executed on an interface, the device generates static MAC address entries (snooping type) of DHCP users on the interface based on the corresponding dynamic binding entries, clears all the dynamic MAC address entries on the interface, disables the interface to learn dynamic MAC address entries, and enables the device to match the source MAC address based on MAC address entries. Then only the message with the source MAC address matching the static MAC address entry can pass through the interface; otherwise, messages are discarded. Therefore, the administrator needs to manually configure static MAC address entries (the static type) for non-DHCP users on the interface so that messages sent from non-DHCP users can pass through; otherwise, DHCP messages are discarded. This prevents attacks from non-DHCP users.

NOTE

- If a DHCP snooping binding entry is updated, the corresponding static MAC address entry is automatically updated.
- If you run the **dhcp snooping sticky-mac** command on the interface, DHCPv6 users cannot go online. Run the **nd snooping enable** command in the system view and interface view to enable ND snooping and the **savi enable** command in the system view to enable SAVI.

Prerequisites

DHCP snooping has been enabled on the device using the **dhcp snooping enable** command.

Precautions

The **dhcp snooping sticky-mac** command cannot be used with the following commands on an interface.

Command	Description
dot1x enable	Enables 802.1X authentication on an interface.
mac-authen	Enables MAC address authentication on an interface.
mac-address learning disable	Enables MAC address learning.
mac-limit	Sets the maximum number of MAC addresses to be learned.
port vlan-mapping vlan map-vlan port vlan-mapping vlan inner-vlan	Enables VLAN mapping.
port-security enable	Enables port security.

Example

Enable the device to generate static MAC address entries based on DHCP snooping binding entries on GE0/0/1.

```
<HUAWEI> system-view  
[HUAWEI] dhcp enable  
[HUAWEI] dhcp snooping enable  
[HUAWEI] interface gigabitethernet 0/0/1  
[HUAWEI-GigabitEthernet0/0/1] dhcp snooping sticky-mac
```

19.12.6.16 dhcp snooping trusted interface no-user-binding (upgrade-compatible command)

Function

The **dhcp snooping trusted interface no-user-binding** command configures a trusted interface.

The **undo dhcp snooping trusted interface no-user-binding** command deletes a trusted interface.

By default, no trusted interface is configured.

Format

dhcp snooping trusted interface *interface-type interface-number* **no-user-binding**

undo dhcp snooping trusted interface *interface-type interface-number* **no-user-binding**

Parameters

Parameter	Description	Value
<i>interface-type interface-number</i>	Specifies the type and number of an interface.	-

Views

VLAN view

Default Level

2: Configuration level

Usage Guidelines

You can use the **dhcp snooping trusted interface no-user-binding** command to configure a trusted interface in the VLAN view.

Before using this command:

- Enable DHCP snooping globally.
- Add the interface to a VLAN.

This command can only be used during a configuration restoration.

Example

```
# Configure a trusted interface GE0/0/1 in VLAN 100.
```

```
<HUAWEI> system-view  
[HUAWEI] vlan 100  
[HUAWEI-vlan100] dhcp snooping trusted interface gigabitethernet 0/0/1 no-user-binding
```

19.12.6.17 dhcp snooping trusted no-user-binding (upgrade-compatible command)

Function

The **dhcp snooping trusted no-user-binding** command configures an interface as the trusted interface.

The **undo dhcp snooping trusted no-user-binding** command restores the default state of an interface.

By default, no trusted interface is configured.

Format

dhcp snooping trusted no-user-binding

undo dhcp snooping trusted no-user-binding

Parameters

None

Views

Ethernet interface view, GE interface view, XGE interface view, Eth-Trunk interface view

Default Level

2: Configuration level

Usage Guidelines

When DHCP snooping is enabled on an interface, the interface is an untrusted interface by default. After you use the **dhcp snooping trusted no-user-binding** command in the interface view, the interface becomes a trusted interface.

This command can only be used during a configuration restoration.

Example

Configure a trusted interface GE0/0/1.

```
<HUAWEI> system-view
[HUAWEI] dhcp enable
[HUAWEI] dhcp snooping enable
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] dhcp snooping trusted no-user-binding
```

19.12.7 Keychain Upgrade-compatible Commands

19.12.7.1 receive-time (upgrade-compatible command)

Function

The **receive-time** command makes a key act as a receive-key for the specified interval of time.

The **undo receive-time** command deletes the receive-time configuration.

By default, no receive-time is configured.

Format

```
receive-time utc start-time start-date { duration { duration-value | infinite } |  
{ to end-time end-date } }
```


Parameters

Parameter	Description	Value
utc	Specifies that the given time is in Coordinated Universal Time (UTC) format.	-
<i>start-time</i>	Specifies the start receive time.	In HH:MM format. The value ranges from 00:00 to 23:59.
<i>start-date</i>	Specifies the start date.	In YYYY-MM-DD format. The value ranges from 1970-01-01 to 2050-12-31.
duration <i>duration-value</i>	Specifies the duration of the receive time in minutes.	The value ranges from 1 to 26280000.
infinite	Specifies that the key will be acting as a active receive key forever from the configured start-time.	-
to	Acts as a separator.	-
<i>end-time</i>	Specifies the end receive time.	In HH:MM format. The value ranges from 00:00 to 23:59. The end-time should be greater than the start-time.
<i>end-date</i>	Specifies the end date.	In YYYY-MM-DD format. The value ranges from 1970-01-01 to 2050-12-31.

Views

key-id view

Default Level

2: Configuration Level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

It is replaced by the **receive-time** *start-time start-date* { **duration** { *duration-value* | **infinite** } } | { **to** *end-time end-date* } } command.

19.12.7.2 send-time (upgrade-compatible command)

Function

The **send-time** command makes a key act as a send key for the specified interval of time.

By default, no send-time is configured.

Format

send-time utc *start-time start-date* { **duration** { *duration-value* | **infinite** } | { **to** *end-time end-date* } }

Parameters

Parameter	Description	Value
utc	Specifies that the given time is in Coordinated Universal Time (UTC) format.	-
<i>start-time</i>	Specifies the start send time.	In HH:MM format. The value ranges from 00:00 to 23:59.
<i>start-date</i>	Specify the start date.	In YYYY-MM-DD format. The value ranges from 1970-01-01 to 2050-12-31.
duration <i>duration-value</i>	Specifies the duration of the send time in minutes.	The value ranges from 1 to 26280000.
infinite	Specifies that the key will be acting as a send key forever from the configured start-time.	-
to	Acts as a separator.	-
<i>end-time</i>	Specifies the end send time.	In HH:MM format. The value ranges from 00:00 to 23:59. The end-time should be greater than the start-time.
<i>end-date</i>	Specifies the end date.	In YYYY-MM-DD format. The value ranges from 1970-01-01 to 2050-12-31.
daily	Specifies the daily send timing for the given key.	-

Views

Key-ID view

Default Level

2: Configuration Level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

It is replaced by the **send-time** *start-time start-date* { **duration** { *duration-value* | **infinite** } | { **to** *end-time end-date* } } command.

19.13 QoS Compatible Commands

19.13.1 count (upgrade-compatible command)

Function

Using the **count** command, you can enable the function of counting packets that match traffic classification rules.

By default, the counting function is disabled.

Format

count

Parameters

None

Views

Traffic behavior view

Default Level

2: Configuration level

Usage Guidelines

When there are many traffic classification rules on the switch, you can run the **count** command to count the specific traffic. The counting start time is the time when the policy is applied.

Currently, the switch counts packets rather than bytes.

Example

Configure the traffic policy **p1** so that the switch counts packets that flow through GigabitEthernet 0/0/1. After a period of time, the switch displays the traffic statistics.

```
<HUAWEI> system-view
[HUAWEI] traffic classifier c1
[HUAWEI-classifier-c1] if-match any
[HUAWEI-classifier-c1] quit
[HUAWEI] traffic behavior b1
[HUAWEI-behavior-b1] count
[HUAWEI-behavior-b1] quit
[HUAWEI] traffic policy p1
[HUAWEI-trafficpolicy-p1] classifier c1 behavior b1
[HUAWEI-trafficpolicy-p1] quit
```

```
[HUAWEI] interface gigabitethernet 0/0/1
[HUAWEI-GigabitEthernet0/0/1] traffic-policy p1 inbound
[HUAWEI-GigabitEthernet0/0/1] display traffic policy interface gigabitethernet 0/0/1
Interface: GigabitEthernet0/0/1

Direction: Inbound

Policy: p1
Classifier: c1
Rule(s) : if-match any
Behavior: b1
Count
Matched : 10 (Packets)
```

19.14 Network Management Compatible Commands

19.14.1 SNMP Compatible Commands

19.14.1.1 snmp-agent group (upgrade-compatible command)

Function

The **snmp-agent group** command creates an SNMP group by mapping SNMP users to SNMP views.

The **undo snmp-agent group** command deletes a specified SNMP user group.

By default, no SNMP group is configured.

Format

snmp-agent group v3 *group-name* [**authentication** | **privacy**] [**read-view** *read-view* | **write-view** *write-view* | **notify-view** *notify-view*] * [**acl** *acl-number*]

undo snmp-agent group v3 *group-name* [**authentication** | **privacy**]

Parameters

Parameter	Description	Value
v3	Indicates that the SNMP group uses the security mode in SNMPv3.	-
<i>group-name</i>	Specifies the name of an SNMP group.	It is a string of 1 to 32 case-sensitive characters without spaces.

Parameter	Description	Value
authentication privacy	Indicates the security level of the SNMP group. <ul style="list-style-type: none"> • authentication: authenticates SNMP messages without encryption. • privacy: authenticates and encrypts SNMP messages. 	To ensure security, it is recommended that you set the security level of the SNMP group to privacy .
read-view <i>read-view</i>	Specifies a read-only view.	It is a string of 1 to 32 case-sensitive characters without spaces. <i>read-view</i> specified by the snmp-agent mib-view command.
write-view <i>write-view</i>	Specifies a read-write view.	It is a string of 1 to 32 case-sensitive characters without spaces. <i>write-view</i> is specified by the snmp-agent mib-view command.
notify-view <i>notify-view</i>	Specifies a notify view.	It is a string of 1 to 32 case-sensitive characters without spaces. <i>notify-view</i> is specified by the snmp-agent mib-view command.
acl <i>acl-number</i>	Specifies a basic ACL. NOTE The ACL configured by the acl <i>acl-number</i> parameter takes effect on both IPv4 and IPv6 networks.	The value is an integer that ranges from 2000 to 2999.

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.14.1.2 snmp-agent trap enable (upgrade-compatible command)

Function

The **snmp-agent trap enable** command enables a specified trap for a specified feature.

The **undo snmp-agent trap enable** command disables a specified trap for a specified feature.

The default configuration of the **snmp-agent trap enable** command can be checked using the **display snmp-agent trap all** command.

Format

snmp-agent trap enable *feature-name*

undo snmp-agent trap enable *feature-name*

Parameters

Parameter	Description	Value
<i>feature-name</i>	Specifies the name of the feature that generates traps.	-

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.14.1.3 snmp-agent trap enable standard (upgrade-compatible command)

Function

Using the **snmp-agent trap enable standard** command, you can enable the trap function of standard SNMP.

Using the **undo snmp-agent trap enable standard** command, you can disable the trap function of standard SNMP.

By default, no trap messages are sent to a device.

Format

snmp-agent trap enable standard [**authentication** | **coldstart** | **warmstart** | **linkup** | **linkdown**] *

undo snmp-agent trap enable standard [authentication | coldstart | warmstart | linkup | linkdown] *

Parameters

Parameter	Description	Value
Authentication	Indicates that a trap message is sent when packets failed to be authenticated through SNMP.	-
Coldstart	Indicates that a trap message is sent when the system is cold started.	-
Warmstart	Indicates that a trap message is sent when the system is hot started.	-
Linkup	Indicates that a trap message is sent when the interface goes Up.	-
Linkdown	Indicates that a trap message is sent when the interface goes Down.	-

Views

System view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.14.1.4 snmp-agent usm-user (upgrade-compatible command)

Function

The **snmp-agent usm-user** command adds a user to an SNMP user group.

The **undo snmp-agent usm-user** command deletes a user from an SNMP user group.

By default, the SNMP user group has no users added.

NOTE

It is recommended that you deliver the **snmp-agent usm-user v3 user-name group-name authentication-mode { md5 | sha } password [privacy-mode { des56 | aes128 | aes192 | aes256 | 3des } encrypt-password] [acl acl-number]** to the switch from the NMS. Do not directly configure the command on the switch.

Format

snmp-agent usm-user v3 *user-name group-name simple* [**authentication-mode** { *md5* | *sha* } *password* [**privacy-mode** { *des56* | *aes128* | *aes192* | *aes256* | *3des* } *encrypt-password*]] [**acl** *acl-number*]

snmp-agent usm-user v3 *user-name group-name* [**cipher**] [**authentication-mode** { *md5* | *sha* } *password* [**privacy-mode** { *des56* | *aes128* | *aes192* | *aes256* | *3des* } *encrypt-password*]] [**acl** *acl-number*]

undo snmp-agent usm-user v3 *user-name group-name* [**engineid** *engineid* | **local**]

Parameters

Parameter	Description	Value
v3	Indicates that the security mode in SNMPv3 is adopted.	-
<i>user-name</i>	Specifies the name of a user.	It is a string of 1 to 32 case-sensitive characters without spaces.
<i>group-name</i>	Specifies the name of the group to which a user belongs.	It is a string of 1 to 32 case-sensitive characters without spaces.
simple	Indicates the simple authentication.	-
cipher	Specifies that the password is in ciphertext, which is the default password type. If this parameter is specified, you can enter only a password in ciphertext. This type of password can be viewed using the configuration file.	-

Parameter	Description	Value
authentication-mode	<p>Sets the authentication mode.</p> <p>NOTE</p> <p>Authentication is a process in which the SNMP agent (or the NMS) confirms that the message is received from an authorized NMS (or SNMP agent) and the message is not changed during transmission. RFC 2104 defines Keyed-Hashing for Message Authentication Code (HMAC), an effective tool that uses the security hash function and key to generate the message authentication code. This tool is widely used in the Internet. HMAC used in SNMP includes HWAC-MD5-96 and HWAC-SHA-96. The hash function of HWAC-MD5-96 is MD5 that uses 128-bit authKey to generate the key. The hash function of HWAC-SHA-96 is SHA-1 that uses 160-bit authKey to generate the key.</p>	-
md5 sha	<p>Indicates the authentication protocol.</p> <ul style="list-style-type: none">• md5: Specifies HMAC-MD5-96 as the authentication protocol.• sha: Specifies HMAC-SHA-96 as the authentication protocol.	-

Parameter	Description	Value
<i>password</i>	Specifies the password for user authentication.	<p>For plain-text password, the value is a string of 6 to 64 characters by default, and the minimum length is 6 characters. If the set password min-length command is run to set the minimum length of passwords to a value greater than 6, the minimum length is the value configured using the set password min-length command. For cipher-text password, the value is a string of 32 to 104 characters.</p> <p>NOTE The password cannot be the same as the user name or reverse of the user name. The password must contain at least two types of characters, including letters, digits, and special characters. The special characters cannot be question mark (?) or space.</p>
privacy-mode	<p>Specifies the authentication with encryption.</p> <p>The system adopts the cipher block chaining (CBC) code of the data encryption standard (DES) and uses 128-bit privKey to generate the key. The NMS uses the key to calculate the CBC code and then adds the CBC code to the message while the SNMP agent fetches the authentication code through the same key and then obtains the actual information. Like the identification authentication, the encryption requires the NMS and the SNMP agent to share the same key to encrypt and decrypt the message.</p>	-

Parameter	Description	Value
des56 aes128 aes192 aes256 3des	Indicates the encryption protocol.	-
<i>encrypt-password</i>	Indicates the encryption password.	For plain-text password, the value is a string of 6 to 64 characters by default, and the minimum length is 6 characters. If the set password min-length command is run to set the minimum length of passwords to a value greater than 6, the minimum length is the value configured using the set password min-length command. For cipher-text password, the value is a string of 32 to 104 characters. NOTE The password cannot be the same as the user name or reverse of the user name. The password must contain at least two types of characters, including letters, digits, and special characters. The special characters cannot be question mark (?) or space.
acl <i>acl-number</i>	Specifies the ACL number of the access view.	The value is an integer that ranges from 2000 to 2999.
engineid <i>engineid</i>	Specifies the ID of the engine associated with a user.	The value is a string of 10 to 64 case-insensitive characters without spaces.
local	Indicates the local entity user.	-

Views

System view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

19.14.2 NQA Compatible Commands

19.14.2.1 send-trap overthreshold (upgrade-compatible command)

Function

Using the **send-trap overthreshold** command, you can configure conditions for sending trap messages.

Using the **undo send-trap overthreshold** command, you can delete the previous configuration.

By default, the device is disabled from sending traps.

Format

send-trap overthreshold

undo send-trap overthreshold

Parameters

None

Views

NQA view

Default Level

2: Configuration level

Usage Guidelines

This command is available to aid upgrade compatibility. It can only be run during the configuration restoration phase of the upgrade.

After the upgrade, this command is no longer supported, and it is replaced by the **send-trap rtd** command.

19.14.3 Mirror Compatible Commands

19.14.3.1 port-mirroring (upgrade-compatible command)

Function

The **port-mirroring** command configures a mirroring behavior on an interface.

Format

port-mirroring to observe-port *index*

Parameters

Parameter	Description	Value
<i>index</i>	Specifies the index of a global observing interface.	The value is integer.

Views

Traffic behavior view

Default Level

3: Management level

Usage Guidelines

This command is available to aid upgrade compatibility. It can be run when it is entered in full.

Example

Mirror traffic to observing interface with index 1.

```
<HUAWEI> system-view  
[HUAWEI] traffic behavior b1  
[HUAWEI-traffic-behavior-b1] port-mirroring to observe-port 1
```